

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Open - Bank 1	P0010	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 200 K Q impedance between signal and controller ground.	P0010is Enabled  System supply voltage  Output driver is commanded on  Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples  250 ms /sample, continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance - Bank 1	P0011	Detects a VVT system error by comparing the desired and actual cam positions when WT is activated.	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive.	(Intake cam Bank 1)  Cam Position Error > ( <b>P0011_CamPosErrorLimId</b> )deg	<b>Intake Cam Phsr Enable</b>  System Voltage  Engine Running  Power Take Off (PTO) active  Desired cam position  Desired AND Measured cam position        Desired cam position variation          No Active DTCs	= TRUE  > 11.00 Volts  = TRUE  = FALSE  > 0 deg  > ( <b>P0011_CamPosErrorLimIc1</b> )deg AND < ( <b>CalculatedPerfMaxId</b> )deg  < 7.50 deg for ( <b>P0011_P05CC_StablePositionTimeld</b> ) seconds  P0010 P2088 P2089	100.00 failures out of 500.00 samples  100 ms /sample	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 SensorA	P0016	Detects cam to crank misalignment by monitoring if the cam sensor pulse for bank 1 sensor A occurs during the incorrect crank position, diagnostic passes when the cam sensor pulse is in the expected range	Out of range cam edge measurements in one engine cycle  Out of range values are:  cam edge measurement OR cam edge measurement  from the expected nominal cam position	 >= 2 cam edges   < -11.0Crank Degrees  >11.0 Crank Degrees	Crankshaft and camshaft position signals are synchronized  Engine is Spinning  Cam phaser control indicates the phaser is 'parked'  No Active DTCs:  Time since last execution of a test  IntCamECCjDilPresLow	Test is Enabled    CrankSensor_FA P0340, P0341  > 1.0 sec  = FALSE	4 cam edge measurements and 1 test sample per engine cycle  Test failure is 4 fails in 5 samples  Diagnostic failure is 2 failed tests out of 3  If the first test fails, the next test is delayed to confirm the phaser 'parked'  This delay time is defined by <b>P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold</b>  For mid-park phasers, an additional delay <b>P0016-0019 Mid-Park Phaser Delay</b> is applied	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 1	P0030	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 200 K Q impedance between output and controller ground.	Diagnostic is Enabled  Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controllers P0031 may also set

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensors	P0031	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 0.5 Q impedance between output and controller ground.	Diagnostic is Enabled  Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controllers P0030 may also set

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensors	P0032	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 0.5 Q impedance between output and controller power.	Diagnostic is Enabled  Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 2	P0036	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 200 K Q impedance between output and controller ground.	Diagnostic is Enabled  Ignition Voltage Engine Speed	= Crank or Run >11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controlle rs P0037 may also set

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0037	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 0.5 Q impedance between output and controller ground.	Diagnostic is Enabled  Ignition Voltage Engine Speed	= Crank or Run >11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controllers P0036 may also set



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0038	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 0.5 Q impedance between output and controller power.	Diagnostic is Enabled  Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 2 Sensor 1	P0050	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 200 K Q impedance between output and controller ground.	Diagnostic is Enabled  Ignition Voltage Engine Speed	= Crank or Run >11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controlle rs P0051 may also set

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensors	P0051	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 0.5 Q impedance between output and controller ground.	Diagnostic is Enabled  Ignition Voltage Engine Speed	= Crank or Run >11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controllers P0050 may also set

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensori	P0052	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 0.5 Q impedance between output and controller power.	Diagnostic is Enabled  Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 1	P0053	<p>Detects an oxygen sensor heater having an incorrect or out of range resistance value. This test calculates the heater's resistance (using voltage and current) at engine start after a longer soak condition and compares it to the expected values for the released sensor.</p> <p>This fault is set if the heater resistance is outside the expected range.</p>	Heater Resistance outside of the expected range of	3.1 < ohms < 8.4	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>Coolant - IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time</p>	<p>ECT_Sensor_FA P262B IAT_SensorFA &lt;8.0 °C &gt;28,800 seconds &gt; -30.0 °C &lt; 32.0 volts &lt;0.04 seconds</p>	Once per valid cold start	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0054	<p>Detects an oxygen sensor heater having an incorrect or out of range resistance value. This test calculates the heater's resistance (using voltage and current) at engine start after a soak condition and compares it to the expected values for the released sensor.</p> <p>This fault is set if the heater resistance is outside the expected range.</p>	Heater Resistance outside of the expected range of	3.1 < ohms <8.4	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>Coolant - IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time</p>	<p>ECT_Sensor_FA P262B IAT_SensorFA &lt; 8.0 °C &gt;28,800 seconds &gt; -30.0 °C &lt; 32.0 volts &lt; 0.04 seconds</p>	Once per valid cold start	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 2 Sensor 2	P0056	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 200 K Q impedance between output and controller ground.	Diagnostic is Enabled  Ignition Voltage Engine Speed	= Crank or Run >11.0 volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controllers P0057 may also set

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensor2	P0057	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 0.5 Q impedance between output and controller ground.	Diagnostic is Enabled  Ignition Voltage Engine Speed	= Crank or Run > 11.0volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips Note: In certain controllers P0056 may also set



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensor2	P0058	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 0.5 Q impedance between output and controller power.	Diagnostic is Enabled  Ignition Voltage Engine Speed	= Crank or Run > 11.0volts > 400 RPM	20 failures out of 25 samples  250 ms / sample  Continuous	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 2 Sensor 1	P0059	<p>Detects an oxygen sensor heater having an incorrect or out of range resistance value.. This test calculates the heater's resistance (using voltage and current) at engine start after a soak condition and compares it to the expected values for the released sensor.</p> <p>This fault is set if the heater resistance is outside the expected range.</p>	Heater Resistance outside of the expected range of	3.4 < ohms <8.6	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>Coolant - IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time</p>	<p>ECT_Sensor_FA P262B IAT_SensorFA &lt;8.0 °C &gt;28,800 seconds &gt; -30.0 °C &lt; 32.0 volts &lt;0.09 seconds</p>	Once per valid cold start	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 2 Sensor 2	P0060	<p>Detects an oxygen sensor heater having an incorrect or out of range resistance value. This test calculates the heater's resistance (using voltage and current) at engine start after a soak condition and compares it to the expected values for the released sensor.</p> <p>This fault is set if the heater resistance is outside the expected range.</p>	Heater Resistance outside of the expected range of	3.4 < ohms < 8.6	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>Coolant - IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time</p>	<p>ECT_Sensor_FA P262B IAT_SensorFA &lt;8.0 °C &gt;28,800 seconds &gt; -30.0 °C &lt; 32.0 volts &lt;0.09 seconds</p>	Once per valid cold start	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
MAP / MAF / Throttle Position Correlation	P0068	Detect when MAP and MAF do not match estimated engine airflow as established by the TPS	<p>Difference between MAP and estimated MAP exceeds threshold (kPa), or P0651 (5 Volt Ref), or P0107 (MAP circuit low), or P0108 (MAP circuit high) have failed this key cycle, then MAP portion of diagnostic fails</p> <p>Absolute difference between MAF and estimated MAF exceed threshold (grams/sec), or P0102 (MAF circuit low), or P0103 (MAF circuit hi) have failed this key cycle, or maximum MAF versus RPM (Table) is greater than or equal to maximum MAF versus battery voltage, then MAF portion of diagnostic fails</p>	<p>Table, f(TPS). See supporting tables: <b>P0068_Delta MAP Threshold f(TPS)</b></p> <p>Table, f(TPS). See supporting tables: <b>P0068_Delta MAF Threshold f(TPS)</b></p> <p>Table, f(RPM). See supporting tables: <b>P0068_Maximum MAF f(RPM)</b></p> <p>Table, f(Volts). See supporting tables: <b>P0068_Maximum MAF f(Volts)</b></p>	<p>Engine Speed</p> <p>Run/Crank voltage</p>	<p>&gt; 800 RPM</p> <p>&gt; 6.41 Volts</p>	<p>Continuously fail MAP and MAF portions of diagnostic for 0.1875 s</p> <p>Continuous in MAIN processor</p>	Type A, 1 Trips

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit Performance	P0071	<p>Detects an Outside Air Temperature (OAT) sensor that is stuck in range. There are two components to the test: an engine off component, and an engine running component.</p> <p>If the engine has been off for a long enough period of time, and the coolant temperature and Intake Air Temperature (IAT) values are similar, then the air temperature values in the engine compartment of the vehicle are considered to have equalized. In this case, the engine off component of the diagnostic can be enabled.</p> <p>If the IAT and the OAT values are similar, then the OAT Performance Diagnostic passes. If the IAT and OAT values are not similar, the diagnostic will continue to monitor the IAT and the OAT as the vehicle starts to move.</p> <p>For applications that have ability to move without engaging the internal combustion</p>	<p><b>Engine Off:</b></p> <p>If IAT &gt;= OAT: IAT - OAT</p> <p>If IAT &lt; OAT: OAT - IAT</p> <p>If either of the following conditions are met, this diagnostic will pass:</p> <p>If IAT &gt;= OAT: IAT - OAT</p> <p>If IAT &lt; OAT: OAT - IAT</p>	<p>&gt; 15.0 deg C</p> <p>&gt; 15.0 deg C</p> <p>&lt;= 15.0 deg C</p> <p>&lt;= 15.0 deg C</p>	<p>Diagnostic is Enabled</p> <p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is not running</p> <p>Vehicle Speed</p> <p>Coolant Temperature - IAT</p> <p>IAT - Coolant Temperature</p> <p>OAT-to-IAT engine off equilibrium counter</p> <p>The "OAT-to-IAT engine off equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is off. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared. The value that is added or subtracted to the counter every 100 msec is contained in table <b>P0071: OAT Performance Drive Equilibrium Engine Off</b></p> <p>No Active DTCs:</p>	<p>&gt;= 28,800.0 seconds</p> <p>&gt;= 15.5 MPH</p> <p>&lt; 15.0 deg C</p> <p>&lt; 15.0 deg C</p> <p>&gt;= 300.0 counts</p> <p>VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA</p>	<p>Executed every 100 msec until a pass or fail decision is made</p>	<p>Type B, 2 Trips</p>

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		engine, the engine off test will continue. If the vehicle has been moving quickly enough for a long enough period of time, the IAT and OAT values should have reached an equilibrium. This period of time is defined by the "OAT-to-IAT engine off equilibrium counter". The "OAT-to-IAT engine off equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is off. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared.				EngineModeNotRunTimer Error		
		While the "OAT-to-IAT engine off equilibrium counter" is counting, IAT and OAT are monitored for similarity. If they are similar, the OAT Performance Diagnostic passes. If the counter reaches an equilibrium and the IAT and OAT values are not similar, the OAT Performance Diagnostic will fail.	<p><b>Engine Running:</b></p> <p>If IAT &gt;= OAT: IAT - OAT</p> <p>If IAT &lt; OAT: OAT - IAT</p> <p>If either of the following conditions are met, this diagnostic will pass:</p> <p>If IAT &gt;= OAT: IAT - OAT</p> <p>If IAT &lt; OAT: OAT - IAT</p>	<p>&gt; 15.0 deg C</p> <p>&gt; 15.0 deg C</p> <p>&lt;= 15.0 deg C</p> <p>&lt;= 15.0 deg C</p>	<p>Diagnostic is Enabled</p> <p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is running</p> <p>Vehicle Speed</p> <p>Engine airflow</p> <p>OAT-to-IAT engine running equilibrium counter</p> <p>The "OAT-to-IAT engine running equilibrium counter" is a counter that is incremented or decremented based on vehicle speed and engine air flow when the engine is running. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared. The value that is added or subtracted to the counter every 100 msec is contained in table</p> <p><b>P0071: OAT Performance Drive Equilibrium Engine Running</b></p> <p>No Active DTCs:</p>	<p>&gt;= 28,800.0 seconds</p> <p>&gt;= 15.5 MPH</p> <p>&gt;= 10.0 grams/second</p> <p>&gt;= 300.0 counts</p> <p>VehicleSpeedSensor_FA</p>	<p>Executed every 100 msec until a pass or fail decision is made</p>	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>If the engine off component of the diagnostic was enabled, but did not make a pass or fail decision, the engine running component will begin executing when the internal combustion engine starts to run.</p> <p>If the vehicle has been moving quickly enough for a long enough period of time, the IAT and OAT values should have reached an equilibrium. This period of time is defined by the "OAT-to-IAT engine running equilibrium counter". The "OAT-to-IAT engine running equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is running. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared.</p> <p>While the "OAT-to-IAT engine running equilibrium counter" is counting, IAT and OAT are monitored for</p>				<p>IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngineModeNotRunTimer Error</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		similarity. If they are similar, the OAT Performance Diagnostic passes. If the counter reaches an equilibrium and the IAT and OAT values are not similar, the OAT Performance Diagnostic will fail.						



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit Low	P0072	Detects a continuous short to ground in the Outside Air Temperature (OAT) signal circuit by monitoring the OAT sensor output resistance and failing the diagnostic when the OAT resistance is too low. The OAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A lower resistance is equivalent to a higher temperature.	Raw OAT Input	<= 46 Ohms (-150 deg C)	Diagnostic is Enabled		40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit High	P0073	Detects a continuous open circuit in the Outside Air Temperature (OAT) signal circuit by monitoring the OAT sensor output resistance and failing the diagnostic when the OAT resistance is too high. The OAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A higher resistance is equivalent to a lower temperature.	Raw OAT Input	>= 427,757 Ohms (~-60 deg C)	Diagnostic is Enabled		40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Intermittent In-Range	P0074	<p>Detects a noisy or erratic signal in the OAT circuit by monitoring the OAT sensor and failing the diagnostic when the OAT signal has a noisier output than is expected.</p> <p>When the value of the OAT signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of OAT readings. The result of this summation is called a "string length".</p> <p>Since the OAT signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic OAT signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where:</p> <p>"String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current OAT reading - OAT reading from 100 milliseconds previous)</p>	<p>&gt; 100 deg C</p> <p>10 consecutive OAT readings</p>	Diagnostic is Enabled		<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump min/ max authority	P0089	This DTC determines when the high pressure pump control has reached to its max or min authority	High Pressure Fuel Pump Delivery Angle  OR  High Pressure Fuel Pump Delivery Angle	$\geq 124^\circ$  $\leq 0^\circ$	High Pressure Pump Performance Diagnostic Enable  Battery Voltage  Low Side Fuel Pressure    Barometric Pressure Inlet Air Temp  Fuel Temp  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In	True  $\geq 11$ Volts  $> 0.275$ MPa  Enabled when a code clear is not active or not exiting device control  Engine is not cranking  $\geq 70.0$ KPA $\geq -40.0$ degC  $-40 \leq \text{Temp degC} \leq 132$	Windup High/ Low  10.00 seconds failures out of 12.50 Seconds samples	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active			



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Control Solenoid Enable Low Side Short to Ground	P0091	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 0.1 Amps between signal and controller ground	Engine Speed  Battery Voltage	>=50 RPM  >=11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Cntrl Solenoid Enable Low Side Short to Power	P0092	Controller specific output driver circuit diagnoses diagnoses High Pressure pump Control Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1.1 or 15 Amps selectable thershold based on High pressure Pump .	Engine Speed  Battery Voltage	>= 50 RPM  >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0096	<p>Detects an Intake Air Temperature 2 (IAT2) sensor value that is stuck in range by comparing the IAT2 sensor value against the IAT and coolant temperature sensor values and failing the diagnostic if the IAT2 value is more different than the IAT and coolant temperature values than is expected. If the engine has been off for a long enough period of time, the air temperature values in the engine compartment of the vehicle are considered to have equalized, and the diagnostic can be enabled.</p> <p>The diagnostic will fail if the IAT and coolant temperature values are similar, and the IAT2 value is not similar to the IAT and coolant temperature values.</p> <p>This diagnostic is executed once per ignition cycle if the enable conditions are met.</p>	<p>ABS(Power Up IAT - Power Up IAT2)</p> <p>AND</p> <p>ABS(Power Up ECT - Power Up IAT2)</p> <p>&gt;=</p> <p>ABS(Power Up ECT - Power Up IAT)</p>	> 25 deg C	<p>Diagnostic is Enabled</p> <p>Time between current ignition cycle and the last time the engine was running</p> <p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p> <p>LIN communications established with MAF</p>	<p>&gt; 28,800 seconds</p> <p>&gt;= 11.0 Volts</p> <p>&gt;= 0.9 seconds</p> <p>PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA HumTempSnsrCktFA EngineModeNotRunTimer Error</p>	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 Low (applications with LIN MAF)	P0097	<p>Detects an erroneously low value being reported over the LIN serial connection from the Intake Air Temperature 2 (IAT2) sensor. The diagnostic monitors the IAT2 sensor output temperature and fails the diagnostic when the IAT2 temperature is too low.</p> <p>The IAT2 sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	IAT 2 Temperature	< -60 degrees C	<p>Diagnostic is Enabled</p> <p>Powertrain Relay Voltage for a time</p> <p>LIN communications established with MAF</p> <p>No Active DTCs:</p>	<p>&gt;= 11.0 Volts</p> <p>&gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 High (applications with LIN MAF)	P0098	<p>Detects an erroneously high value being reported over the LIN serial connection from the Intake Air Temperature 2 (IAT2) sensor. The diagnostic monitors the IAT2 sensor output temperature and fails the diagnostic when the IAT2 temperature is too high.</p> <p>The IAT2 sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	IAT 2 Temperature	> 150 degrees C	<p>Diagnostic is Enabled</p> <p>Powertrain Relay Voltage for a time</p> <p>LIN communications established with MAF</p> <p>No Active DTCs:</p>	<p>&gt;= 11.0 Volts</p> <p>&gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Intermittent In-Range (applications with humidity)	P0099	<p>Detects a noisy or erratic signal in the Intake Air Temperature 2 (IAT2) circuit by monitoring the IAT2 sensor and failing the diagnostic when the IAT2 signal has a noisier output than is expected.</p> <p>When the value of the IAT2 signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of IAT2 readings. The result of this summation is called a "string length". Since the IAT2 signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic IAT2 signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current IAT2 reading - IAT 2 reading from 100 milliseconds previous)</p>	<p>&gt; 100.00 deg C</p> <p>10 consecutive IAT 2 readings</p>	<p>Diagnostic is Enabled</p> <p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p> <p>LIN communications established with MAF</p>	<p>&gt;= 11.0 Volts &gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Start Diagnostic	P00C6	The DTC Diagnoses the high side fuel pressure during engine cranking.	<p>The ECM detects that the fuel pressure is not rising or has fallen beyond acceptable limits during engine cranking</p> <p>Pressure Rise Test: Sensed High Pressure Fuel Rail Pressure value</p> <p>Pressure Fall Test: Sensed High Pressure Fuel Rail Pressure value</p>	<p>&lt; <b>P00C6 - Minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery</b> (see Supporting Table)</p> <p>&lt;= <b>P00C6 - Minimum acceptable value of fuel rail pressure after High Pressure Start</b> (see Supporting Table)</p>	<p>High Pressure Rise Diagnostic During Start</p> <p>High Pressure Fall Diagnostic During Start</p> <p>Low side feed fuel pressure</p> <p>Engine Run Time Run/Crank Voltage Engine Coolant</p> <p>For each engine start, only 1 diagnostic is performed. The pressure rise test will run if High side fuel pressure is less than KtFHPC_p_HighPressStart, otherwise, the pressure fall diagnostic will run when the engine is cranking.</p>	<p>Enabled</p> <p>Disabled</p> <p>&gt;= 0 KPA</p> <p>&lt; = 0 sec &gt; 8 Volts -100 &lt;= °C &lt;= 132</p> <p>All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP orTFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT, IAT2 and ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control</p>	<p>Pressure Rise Test: Crank Time &gt;= <b>P00C6 - High Pressure Pump Control Mode timeout</b> (see Supporting Table) 6.25 ms per sample</p> <p>Pressure Fall Test: Injected cylinder events &gt;= <b>P00C6 - maximum acceptable counts of fuel rail pressure below KtFHPD_p_HPS_PressFallLoThrsh after High Pressure Start</b> (see Supporting Table)</p> <p>8 samples per engine rotation</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Barometric Pressure Inlet Air Temp	commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active >= 70.0 KPA >= -40.0 DegC		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Pressure Measurement System - Multiple Sensor Correlation (naturally aspirated with TIAP/ Baro sensor)	P00C7	<p>Detects an inconsistency between pressure sensors in the induction system in which a particular sensor cannot be identified as the failed sensor.</p> <p>If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The Manifold Pressure (MAP) and Barometric Pressure (BARO) sensors values are checked to see if they are within the normal expected atmospheric pressure range. If one of the sensors is outside the normal expected atmospheric pressure range, this monitor will fail. Otherwise, MAP and BARO are compared to see if their values are similar.</p> <p>If the MAP and BARO values are not similar, there are no other pressure sensors to compare against to identify which sensor is not rational. The Multiple Pressure</p>	ABS(Manifold Pressure - Baro Pressure)	> 10.0 kPa	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is not rotating</p> <p>Manifold Pressure Manifold Pressure Baro Pressure Baro Pressure</p> <p>No Active DTCs:</p> <p>No Pending DTCs:</p> <p>Diagnostic is Enabled</p> <p>LIN communications established with MAF</p>	<p>&gt; 5.0 seconds</p> <p>&gt;= 50.0 kPa &lt;= 115.0 kPa &gt;= 50.0 kPa &lt;= 115.0 kPa</p> <p>EngineModeNotRunTimer Error MAP_SensorFA AAP_SnsrFA AAP_LIN1_SnsrCktFA</p> <p>MAP_SensorCircuitFP AAP_SnsrCktFP AAP_LIN1_SnsrCktFP</p>	<p>4 failures out of 5 samples</p> <p>1 sample every 12.5 msec for applications without LIN MAF</p> <p>1 sample every 25 msec for applications with LIN MAF</p>	Type B, 2 Trips
			Manifold Pressure OR Manifold Pressure	<p>&lt; 50.0 kPa &gt; 115.0 kPa</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is not rotating</p> <p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>&gt; 5.0 seconds</p> <p>EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA AAP_LIN1_SnsrCktFA</p> <p>MAP_SensorCircuitFP AAP_SnsrCktFP</p>	<p>4 failures out of 5 samples</p> <p>1 sample every 12.5 msec for applications without LIN MAF</p> <p>1 sample every 25 msec for applications with LIN MAF</p>	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Sensor Correlation Diagnostic will fail in this case.			Diagnostic is Enabled  LIN communications established with MAF	AAP_LIN1_SnsrCktFP		
			Barometric Pressure OR Barometric Pressure	< 50.0 kPa  > 115.0 kPa	Time between current ignition cycle and the last time the engine was running  Engine is not rotating  No Active DTCs:    No Pending DTCs:  Diagnostic is Enabled  LIN communications established with MAF	> 5.0 seconds  EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA AAP_LIN1_SnsrCktFA  MAP_SensorCircuitFP AAP_SnsrCktFP AAP_LIN1_SnsrCktFP	4 failures out of 5 samples  1 sample every 12.5 msec for applications without LIN MAF  1 sample every 25 msec for applications with LIN MAF	



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control High Side Circuit Short to ground	P00C9	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1.1 or 15 Amps selectable thershold based on High pressure Pump.	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control High Side Circuit Short to power	POOCA	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 0.1 Amps between signal and controller power	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Low (applications with LIN MAF)	P00F4	<p>Detects an erroneously low value being reported over the LIN serial connection from the humidity sensor. The diagnostic monitors the humidity sensor relative humidity output and fails the diagnostic when the humidity percentage is too low.</p> <p>The humidity sensor converts the capacitance across the sensor to a relative humidity. The relative humidity percentage value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	Relative Humidity	<= -6.25 %	<p>Diagnostic is Enabled</p> <p>Powertrain Relay Voltage for a time</p> <p>LIN communications established with MAF</p> <p>No Active DTCs:</p>	<p>&gt;= 11.0 Volts</p> <p>&gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit High (applications with LIN MAF)	P00F5	<p>Detects an erroneously high value being reported over the LIN serial connection from the humidity sensor. The diagnostic monitors the humidity sensor relative humidity output and fails the diagnostic when the humidity percentage is too high.</p> <p>The humidity sensor converts the capacitance across the sensor to a relative humidity. The relative humidity percentage value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	Relative Humidity	>= 106.25 %	<p>Diagnostic is Enabled</p> <p>Powertrain Relay Voltage for a time</p> <p>LIN communications established with MAF</p> <p>No Active DTCs:</p>	<p>&gt;= 11.0 Volts</p> <p>&gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Intermittent	P00F6	<p>Detects a noisy or erratic signal in the humidity circuit by monitoring the humidity sensor and failing the diagnostic when the humidity signal has a noisier output than is expected.</p> <p>When the value of relative humidity in % is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of humidity readings. The result of this summation is called a "string length".</p> <p>Since the humidity signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic humidity signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current Humidity reading - Humidity reading from 100 milliseconds previous)</p>	<p>&gt; 80 %</p> <p>10 consecutive Humidity readings</p>	<p>Diagnostic is Enabled</p> <p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p> <p>LIN communications established with MAF</p>	<p>&gt;= 11.0 Volts &gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (naturally aspirated)	P0101	<p>Detects a performance failure in the Mass Air Flow (MAF) sensor, such as when a MAF value is stuck in range.</p> <p>This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Manifold Pressure (MAP) sensor and Throttle Position sensor (TPS).</p> <p>These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAF sensor. In this case, the MAF Performance diagnostic will fail.</p>	<p>Filtered Throttle Model Error AND ABS(Measured Flow - Modeled Air Flow) Filtered AND ABS(Measured MAP - MAP Model 2) Filtered</p>	<p>&lt;= 300 kPa*(g/s)  &gt; 25.0 grams/sec  &gt; 22.0 kPa</p>	<p>Engine Speed Engine Speed</p> <p>(Coolant Temp OR OBD Coolant Enable Criteria</p> <p>(Coolant Temp OR OBD Max Coolant Achieved</p> <p>Intake Air Temp Intake Air Temp</p> <p>Minimum total weight factor (all factors multiplied together)</p> <p>See Residual Weight Factor tables.</p>	<p>&gt;= 400 RPM &lt;= 4,230 RPM</p> <p>&gt;= -9 Deg C</p> <p>= TRUE)</p> <p>&lt;= 130 Deg C</p> <p>= FALSE)</p> <p>-20 Deg C &lt;= 129 Deg C</p> <p>&gt;= 0.50</p> <p>Filtered Throttle Model Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM</b></p> <p>Modeled Air Flow Error multiplied by <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM</b> and <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est</b></p>	<p>Continuous</p> <p>Calculation are performed every 12.5 msec</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Active DTCs:  No Pending DTCs:  Diagnostic is Enabled	MAP Model 2 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM</b>  MAP_SensorCircuitFA EGRValvePerformance_FA A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA  EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

24OBDG06B HD ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit Low Frequency (Continental MAF)	P0102	<p>Detects a continuous short to ground in the MAF sensor circuit or a MAF sensor that is outputting a frequency that is too low. The diagnostic monitors the MAF sensor frequency output and fails the diagnostic when the MAF frequency is too low. A low MAF frequency is associated with a high engine air flow.</p> <p>The MAF sensor monitors the temperature of a circuit in the airflow of the engine. The temperature of this circuit is related to the mass airflow across the sensor. The mass air flow value is converted by the sensor to a frequency value in Hertz. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the frequency of the square wave signal and converts that frequency to a mass air flow value in grams/second through a transfer function.</p>	MAF Output	<= 850 Hertz (>= 393.7 gm/sec)	<p>Engine Run Time Engine Speed Powertrain Relay Voltage Above criteria present for a period of time</p> <p>Diagnostic is Enabled</p>	<p>&gt; 0.0 seconds &gt;= 300 RPM &gt;= 9.1 Volts</p> <p>&gt;= 0.5 seconds</p>	<p>400 failures out of 500 samples</p> <p>1 sample every cylinder firing event</p>	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit High Frequency (Continental MAF)	P0103	<p>Detects a MAF sensor that is outputting a frequency signal that is too high. The diagnostic monitors the MAF sensor frequency output and fails the diagnostic when the MAF frequency is too high. A high MAF frequency is associated with a low engine air flow.</p> <p>The MAF sensor monitors the temperature of a circuit in the airflow of the engine. The temperature of this circuit is related to the mass airflow across the sensor. The mass air flow value is converted by the sensor to a frequency value in Hertz. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the frequency of the square wave signal and converts that frequency to a mass air flow value in grams/second through a transfer function.</p>	MAF Output	>= 14,500 Hertz (<= 0.00 gm/sec)	<p>Engine Run Time Engine Speed Powertrain Relay Voltage Above criteria present for a period of time</p> <p>Diagnostic is Enabled</p>	<p>&gt; 0.0 seconds &gt;= 300 RPM &gt;= 9.1 Volts</p> <p>&gt;= 0.5 seconds</p>	<p>400 failures out of 500 samples</p> <p>1 sample every cylinder firing event</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (naturally aspirated)	P0106	<p>Detects a performance failure in the Manifold Pressure (MAP) sensor, such as when a MAP value is stuck in range.</p> <p>This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Mass Air Flow (MAF) sensor and Throttle Position sensor (TPS).</p> <p>These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAP sensor. In this case, the MAP Performance diagnostic will fail.</p>	<p>Filtered Throttle Model Error AND ABS(Measured MAP - MAP Model 1) Filtered AND ABS(Measured MAP - MAP Model 2) Filtered</p>	<p><math>\leq 300 \text{ kPa}*(\text{g/s})</math></p> <p><math>&gt; 22.0 \text{ kPa}</math></p> <p><math>&gt; 22.0 \text{ kPa}</math></p>	<p>Engine Speed Engine Speed</p> <p>(Coolant Temp OR OBD Coolant Enable Criteria</p> <p>(Coolant Temp OR OBD Max Coolant Achieved</p> <p>Intake Air Temp Intake Air Temp</p> <p>Minimum total weight factor (all factors multiplied together)</p> <p>See Residual Weight Factor tables.</p>	<p><math>\geq 400 \text{ RPM}</math> <math>\leq 4,230 \text{ RPM}</math></p> <p><math>\geq -9 \text{ Deg C}</math></p> <p>= TRUE)</p> <p><math>\leq 130 \text{ Deg C}</math></p> <p>= FALSE)</p> <p>-20 Deg C <math>\leq 129 \text{ Deg C}</math></p> <p><math>\geq 0.50</math></p> <p>Filtered Throttle Model Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM</b></p> <p>MAP Model 1 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM</b></p> <p>MAP Model 2 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM</b></p>	<p>Continuous</p> <p>Calculations are performed every 12.5 msec</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Active DTCs:  No Pending DTCs:  Diagnostic is Enabled	MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA  EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low	P0107	Detects a continuous short to ground in the Manifold Absolute Pressure (MAP) signal circuit by monitoring the MAP sensor output voltage and failing the diagnostic when the MAP voltage is too low. The MAP sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	MAP Voltage	< 3.0% of 5 Volt Range (This is equal to 6.1 kPa)	Diagnostic is Enabled		320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit High	P0108	Detects a continuous short to power or open circuit in the Manifold Absolute Pressure (MAP) signal circuit by monitoring the MAP sensor output voltage and failing the diagnostic when the MAP voltage is too high. The MAP sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	MAP Voltage	> 90.0% of 5 Volt Range (This is equal to 115.1 kPa)	Diagnostic is Enabled		320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0111	<p>Detects an Intake Air Temperature (IAT) sensor value that is stuck in range by comparing the IAT sensor value against the IAT2 and coolant temperature sensor values and failing the diagnostic if the IAT value is more different than the IAT2 and coolant temperature values than is expected. If the engine has been off for a long enough period of time, the air temperature values in the engine compartment of the vehicle are considered to have equalized, and the diagnostic can be enabled.</p> <p>The diagnostic will fail if the IAT2 and coolant temperature values are similar, and the IAT value is not similar to the IAT2 and coolant temperature values.</p> <p>This diagnostic is executed once per ignition cycle if the enable conditions are met.</p>	<p>ABS(Power Up IAT - Power Up IAT2)</p> <p>AND</p> <p>ABS(Power Up ECT - Power Up IAT) &gt; ABS(Power Up ECT - Power Up IAT2)</p>	> 25 deg C	<p>Diagnostic is Enabled</p> <p>Time between current ignition cycle and the last time the engine was running</p> <p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p> <p>LIN communications established with MAF</p>	<p>&gt; 28,800 seconds</p> <p>&gt;= 11.0 Volts</p> <p>&gt;= 0.9 seconds</p> <p>PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA HumTempSnsrCktFA EngineModeNotRunTimer Error</p>	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Low (applications with LIN MAF)	P0112	<p>Detects an erroneously low value being reported over the LIN serial connection from the Intake Air Temperature (IAT) sensor. The diagnostic monitors the IAT sensor output temperature and fails the diagnostic when the IAT temperature is too low.</p> <p>The IAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	IAT Temperature	< -60 degrees C	<p>Diagnostic is Enabled</p> <p>LIN Communications established with MAF</p>		<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit High (applications with LIN MAF)	P0113	<p>Detects an erroneously high value being reported over the LIN serial connection from the Intake Air Temperature (IAT) sensor. The diagnostic monitors the IAT sensor output temperature and fails the diagnostic when the IAT temperature is too high.</p> <p>The IAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	IAT Temperature	> 150 degrees C	<p>Diagnostic is Enabled</p> <p>LIN Communications established with MAF</p>		<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Intermittent In-Range	P0114	<p>Detects a noisy or erratic signal in the Intake Air Temperature (IAT) circuit by monitoring the IAT sensor and failing the diagnostic when the IAT signal has a noisier output than is expected.</p> <p>When the value of the IAT signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of IAT readings. The result of this summation is called a "string length".</p> <p>Since the IAT signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic IAT signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current IAT reading - IAT reading from 100 milliseconds previous)</p>	<p>&gt; 80.00 deg C</p> <p>10 consecutive IAT readings</p>	<p>Diagnostic is Enabled</p> <p>LIN communications established with MAF</p>		<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Sensor Not Plausible (Non-ATM)	P0116	This DTC detects either a biased high or low ECT (Engine Coolant temperature) sensor. This is done by comparing the ECT sensor output to two other temperature sensor outputs after a soak condition.	<p>This sensor is compared to two other sensors for this diagnostic to function.</p> <p>This program uses a highly configurable sensor reading system.</p> <p>This DTC is associated with the temp sensor that is equal to: EngCoolantTempSnsr1</p> <p>Temperature Sensor 1: CeEECR_e_EngCoolantTempSnsr1</p> <p>Temperature Sensor 2: CeEECR_e_NoUseAssgnmnt</p> <p>Temperature Sensor 3: CeEECR_e_NollseAssgnmnt</p> <p>Temperature Sensor 4: CeEECR_e_NollseAssgnmnt</p> <p>Temperature Sensor 5: CeEECR_e_NollseAssgnmnt</p> <p>The comparison sensors, temperature thresholds, and aux heater effects can be looked up by finding the location associated with the physical (Temperature)</p>		<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>Propulsion system Inactive timer error</p> <p>Sensor under diagnosis is not faulted</p> <p>Used comparison sensors are not currently faulted:</p> <ul style="list-style-type: none"> <li>- BiasChkCylHdCIntSnsr</li> <li>- BiasChkBlockCIntSnsr</li> <li>- BiasChkEngInCIntSnsr</li> <li>- BiasChkEngOutCIntSnsr</li> <li>- BiasChkHtrCrInCIntSnsr</li> <li>- BiasChkHtrCrOutCInSnsr</li> <li>- BiasChkRadOutCIntSnsr</li> <li>- BiasChkByplnCIntSnsr</li> <li>- BiasChkEngMetalSnsr</li> <li>- BiasChkIntakeAirSnsr</li> <li>- BiasChkHumTmpSnsr</li> <li>- BiasChkManfldAirSnsr</li> <li>- BiasChkOutsideAirSnsr</li> <li>- BiasChkEngOilSnsr</li> <li>- BiasChk_EGR_UpStrmSn</li> </ul>	<p>OAT_PtEstFiltFA</p> <p>PSAR_PropSysInactiveCr s_FA</p> <p>= FALSE</p> <p>EECR_EngineOutlet_CktFA</p> <p>EECR_CylHeadCoolant_CktFA</p> <p>EECR_BlockCoolant_CktFA</p> <p>EECR_EngineInlet_CktFA</p> <p>EECR_EngineOutlet_CktFA</p> <p>EECR_HeaterCoreInlet_CktFA</p> <p>EECR_HeaterCoreOutlet_CktFA</p> <p>EECR_RadiatorOutlet_CktFA</p> <p>EECR_BypassInlet_CktFA</p> <p>EECR_CylHeadMetal1_CktFA</p> <p>IAT_SensorFA</p> <p>HumTempSnsrFA</p> <p>MnfdTempSensorFA</p> <p>OAT_AmbientSensorFA</p> <p>EngOilTempFA</p>	<p>1 failure to set DTC</p> <p>1 sec/ sample</p> <p>Once per valid cold start</p>	Type B, 2 Trips







24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>A block heater is detected if a drop is</p> <p><b>IAT Drop Criteria:</b></p> <p>The sensor will be used as IAT for this method</p> <p>A block heater will be detected if:</p> <p>IAT has a drop of during a drive defined by:                      Drive time                      Vehicle speed</p> <p>Additional drive time is provided when vehicle speed drops below above threshold as follows</p> <p>This detection method will abort if the engine is off                      OR                      Engine runtime</p> <p><b>Temperature Derivative Criteria:</b></p> <p>Derivative will be monitored using</p> <p>Derivative will be monitored once coolant flow is                      AND                      Flow time is between                      AND either</p>	<p>&gt;5.0 °C</p> <p>CeAEHR_e_BlkHtrIntake AirSnsr</p> <p>&gt;5.0 °C</p> <p>&gt;400.0 seconds                      &gt;24.0kph</p> <p>0.5 times the seconds with vehicle speed below the threshold above</p> <p>&gt; 180.0 seconds                      &gt; 1,800 seconds</p> <p>CeAEHR_e_BlkHtrEngO utCIntSnsr</p> <p>&gt;3.00 L/min</p> <p>1.0 -20.0 seconds</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine runtime is OR Insufficient coolant flow is present for  Derivative count will increment if derivative is  If counts are a block heater is detected =====	< 80.0 seconds  >300.0 seconds  <-0.10°C/sec  > 2 counts		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit Low (Non-ATM)	P0117	Circuit Continuity This DTC detects a short to ground in the ECT (Engine Coolant temperature) signal circuit or the ECT sensor. This is accomplished by monitoring the resistance of the circuit. If the resistance goes out of the expected range the DTC is set.	ECT Resistance (@ 150°C)  This program uses a highly configurable sensor reading system.  This DTC is associated with the temp sensor that is equal to: EngCoolantTempSnsrl  Temperature Sensor 1: CeEECR_e_EngCoolantTempSnsrl  Temperature Sensor 2: CeEECR_e_NoUseAssgnmnt  Temperature Sensor 3: CeEECR_e_NoUseAssgnmnt  Temperature Sensor 4: CeEECR_e_NoUseAssgnmnt  Temperature Sensor 5: CeEECR_e_NoUseAssgnmnt	< X Ohms  X is equal to: Temp Sensor 1: 55 Ohms  Temp Sensor 2: 55.0 Ohms  Temp Sensor 3: 55.0 Ohms  Temp Sensor 4: 55.0 Ohms  Temp Sensor 5: 55.0 Ohms	Diagnostic is Enabled		5 seconds out of a 6 seconds window  Continuously sampled	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit High (Non-ATM)	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT (Engine Coolant temperature) signal circuit or the ECT sensor. This is accomplished by monitoring the resistance of the circuit. If the resistance goes out of the expected range the DTC is set.	ECT Resistance (@ -60°C)  This program uses a highly configurable sensor reading system.  This DTC is associated with the temp sensor that is equal to: EngCoolantTempSnsrl  Temperature Sensor 1: CeEECR_e_EngCoolantTempSnsrl  Temperature Sensor 2: CeEECR_e_NollseAssg nmnt  Temperature Sensor 3: CeEECR_e_NollseAssg nmnt  Temperature Sensor 4: CeEECR_e_NollseAssg nmnt  Temperature Sensor 5: CeEECR_e_NollseAssg nmnt	> X Ohms  X is equal to: Temp Sensor 1: 175,000 Ohms  Temp Sensor 2: 175,000 Ohms  Temp Sensor 3: 175,000 Ohms  Temp Sensor 4: 175,000 Ohms  Temp Sensor 5: 175,000 Ohms	Diagnostic is Enabled  Engine run time OR IAT min	> 10.0 seconds  > -20.0 °C	5 seconds out of a 6 seconds window  Continuously sampled	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent (Non-ATM)	P0119	Circuit Erratic This DTC detects large step changes in the ECT (Engine Coolant temperature) signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample and sensor time constant. If the sensor responds faster than should be possible the DTC is set.	Temperature step change:  1) positive step change is greater than calculated high limit  OR  2) negative step change is lower than calculated low limit.  This program uses a highly configurable sensor reading system.  This DTC is associated with the temp sensor that is equal to: EngCoolantTempSnsr1  Temperature Sensor 1: CeEECR_e_EngCoolant TempSnsr1 Temperature Sensor 2: CeEECR_e_NollseAssg nmnt Temperature Sensor 3: CeEECR_e_NollseAssg nmnt Temperature Sensor 4: CeEECR_e_NollseAssg nmnt Temperature Sensor 5: CeEECR_e_NollseAssg nmnt  The calculated high and low limits for the next reading use the following calibrations:		Diagnostic is Enabled  No Active DTC's	ECT_Sensor_Ckt_FA EECR_EngineOut_Erratic _TFTKO	5 seconds out of a 6 seconds window  Continuously sampled	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Temperature Sensor 1: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit	7.4 seconds -60.0 °C 200.0 °C				
			Temperature Sensor 2: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit	7.4 seconds -60.0 °C 200.0 °C				
			Temperature Sensor 3: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit	7.4 seconds -60.0 °C 200.0 °C				
			Temperature Sensor 4: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit	7.4 seconds -60.0 °C 200.0 °C				
			Temperature Sensor 5: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit	7.4 seconds -60.0 °C 200.0 °C				
			*****Generic Example*****  If the last temp reading was 90 °C, the Time constant was calibrated at 10 seconds, the low limit was calibrated to -80 °C and the high limit was calibrated to 200 °C the					

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			calculated limits are 101 °C and 73 °C.  The next reading (after the 90 °C reading) must be between 73 °C and 101 °C to be valid.  *****					

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (naturally aspirated)	P0121	<p>Detects a performance failure in the Throttle Position sensor (TPS) sensor, such as when a TPS value is stuck in range.</p> <p>This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Manifold Pressure (MAP) sensor and Mass Air Flow (MAF) sensor.</p> <p>These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the TPS sensor. In this case, the TPS Performance diagnostic will fail.</p>	<p>Filtered Throttle Model Error AND ABS(Measured MAP - MAP Model 2) Filtered</p>	<p>&gt; 300 kPa*(g/s)</p> <p>&lt;= 22.0 kPa</p>	<p>Engine Speed Engine Speed</p> <p>(Coolant Temp OR OBD Coolant Enable Criteria</p> <p>(Coolant Temp OR OBD Max Coolant Achieved</p> <p>Intake Air Temp Intake Air Temp</p> <p>Minimum total weight factor (all factors multiplied together)</p> <p>See Residual Weight Factor tables.</p> <p>No Active DTCs:</p>	<p>&gt;= 400 RPM &lt;= 4,230 RPM</p> <p>&gt;= -9 Deg C</p> <p>= TRUE)</p> <p>&lt;= 130 Deg C</p> <p>= FALSE)</p> <p>-20 Deg C &lt;= 129 Deg C</p> <p>&gt;= 0.50</p> <p>Filtered Throttle Model Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM</b></p> <p>MAP Model 2 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM</b></p> <p>MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA</p>	<p>Continuous</p> <p>Calculation are performed every 12.5 msec</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Pending DTCs:  Diagnostic is Enabled	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit Low	P0122	Detects a continuous or intermittent short low or open in TPS1 circuit by monitoring the TPS 1 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too low. This diagnostic only runs when battery voltage is high enough.	TPS1 % Vref < (100% corresponds to 5.0 Volt)	6.50 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P06A3	79/159 counts;  57 counts continuous;  3.125 ms /count in the ECM main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit High	P0123	Detects a continuous or intermittent short high in TPS1 circuit by monitoring the TPS 1 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too high. This diagnostic only runs when battery voltage is high enough.	TPS1 % Vref >  (100% corresponds to 5.0 Volt)	95.00 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P06A3	79/159 counts;  57 counts continuous;  3.125 ms /count in the ECM main processor	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Below Stat Regulating Temperature	P0128	This DTC detects if the ECT (EngineCoolant temperature) does not achieve the required target temperature after an allowed energy accumulation by the engine. This can be caused by an ECT sensor biased low or a cooling system that is not warming up correctly because of a stuck open thermostat or other fault.	<p>Energy is accumulated after the first combustion event using Range 1, 2 or 3:</p> <p>If the maximum energy is greater than as shown in the supporting tables prior to the Engine outlet coolant achieving the target a fault will be indicated.</p> <p><b>Range 1 (Primary):</b> Ambient air temperature is between 10.0 and 52.0 °C</p> <p>Engine Outlet Coolant reaches the start to open temperature of the flow control device to the radiator (ie: thermostat) minus 11.1 °C. The target temperature for this range will not drop below 74.9 °C</p> <p><b>Range 2 (Secondary):</b> Ambient air temperature is between -9.0 and 10.0 °C</p> <p>Engine Outlet Coolant reaches the start to open temperature of the flow control device to the radiator (ie: thermostat) minus 31.0 °C. The target temperature for this range will not drop below 55.0 °C</p>	<p><b>P0128 Maximum Accumulated Energy - Primary</b></p> <p><b>P0128 Maximum Accumulated Energy - Secondary</b></p>	<p>Diagnostic is Enabled</p> <p>No DTCs</p> <p>Engine soak time</p> <p>Engine run time</p> <p>Engine Outlet Coolant Temperature</p> <p>- Range 1:</p> <p>- Range 2:</p> <p>- Range 3:</p> <p>Devices in main cooling circuit are not in in device control</p> <p>If Engine RPM is continuously greater than for this time period</p> <p>Distance traveled</p>	<p>THMR_AWP_AuxPumpFA</p> <p>THMR_AHV_FA</p> <p>THMR_SWP_Control_FA</p> <p>THMR_SWP_Flow8tuckOn_FA</p> <p>THMR_SWP_NoFlow_FA</p> <p>OAT_PtEstFiltFA</p> <p>VehicleSpeedSensor_FA</p> <p>EngineTorqueEstInaccuracy</p> <p>MAF_SensorFA</p> <p>ETHR_CoolantEnergyModel</p> <p>ETHR_RemedialActionLevel</p> <p>ETHR_RemedialActionLevel2</p> <p>ETHR_RemedialActionLevel3</p> <p>EECR_EngineOutlet_FA</p> <p>&gt; 1,800.0 seconds</p> <p>20.0- 1,800.0 seconds</p> <p>&lt;55.5 °C</p> <p>&lt;35.6 °C</p> <p>&lt;35.6 °C</p> <p>8,192 rpm</p> <p>5.0 seconds</p> <p>&gt; 1.2 km</p>	<p>1 failure to set DTC</p> <p>1 sec/ sample</p> <p>Once per ignition key cycle</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>C</p> <p><b>Range 3 (Tertiary):</b> Ambient air temperature is between -9.1 and -9.0 °C</p> <p>Engine Outlet Coolant reaches the start to open temperature of the flow control device to the radiator (ie: thermostat) minus 31.0°C. The target temperature for this range will not drop below 55.0° C</p>	<p><b>P0128 Maximum Accumulated Energy - Tertiary</b></p> <p>This diagnostic models the net energy into and out of the cooling system during the warm-up process.</p> <p>The ten energy terms are: heat from combustion (with AFM correction), heat from after-run, heat loss to transmission oil, heat loss to enviroment, heat loss to cabin, heat loss to DFCO, heat loss to engine oil, heat loss to exhaust, and eat loss to autostop.</p>	<p>The diagnostic will abort if the temperature has dropped by after the customer has commanded the engine off</p>	<p>&gt;5.0 °C</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 1	P0131	<p>This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	<40.0mVolts	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Commanded Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active</p>	<p>TPS_ThrottleAuthorityDefaulted MAP_SensorFA AIR_System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA</p> <p>= Not active = Not active = Not active = Not active 10.0 &lt; Volts = Not active = Not active = Not active = Not active</p> <p>= False = False</p> <p>0.9922 &lt; ratio &lt; 1.0137 150 &lt; mgram &lt; 800 = Closed Loop = TRUE (Please see "<b>Closed Loop Enable</b>")</p>	<p>320 failures out of 400 samples</p> <p>Frequency: Continuous in 100 milli-second loop</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition  Ethanol Estimation in Progress  Fuel State  All of the above met for	<b>Clarification</b> ”in Supporting Tables).  Enabled (On) Ethanol < 87 %  = Not Active (Please see “ <b>Ethanol Estimation in Progress</b> ” in Supporting Tables).  DFCO not active  > 5.0 seconds		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1	P0132	<p>This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	> 1,050 mvolts	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>System Voltage</p> <p>AFM Status</p> <p>Heater Warm-up delay</p> <p>Engine Run Time</p> <p>Engine Run Accum</p> <p>Low Fuel Condition Diag Only when</p> <p>FuelLevelDataFault</p> <p>*****</p> <p>Secondary delay after above conditions are complete (cold start condition)</p> <p>Secondary delay after above conditions are complete (not cold start condition)</p> <p>Commanded Equivalence Ratio</p> <p>*****</p> <p>All of the above met for</p>	<p>TPS_ThrottleAuthorityDefaulted</p> <p>MAF_SensorFA</p> <p>MAP_SensorFA</p> <p>EvapExcessPurgePsbl_FA</p> <p>FuelInjectorCircuit_FA</p> <p>Ethanol Composition Sensor FA</p> <p>AIR System FA</p> <p>10.0 &lt; Volts</p> <p>= All Cylinders active</p> <p>= Complete</p> <p>&gt; 5.0 seconds</p> <p>&gt; 30.0 seconds</p> <p>= False</p> <p>= False</p> <p>*****</p> <p>&gt; 100.0 seconds when engine soak time &gt; 28,800 seconds</p> <p>&gt; 100.0 seconds when engine soak time &lt; 28,800 seconds</p> <p>&lt; 1.014 EQR</p> <p>*****</p> <p>&gt; 3.0 seconds</p>	<p>100 failures out of 125 samples</p> <p>Frequency: Continuous in 100 milli-second loop</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 1	P0135	<p>This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor.</p> <p>The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.</p>	Heater Current outside of the expected range of	0.3 < Amps < 3.1	Diagnostic is Enabled  No Active DTC's  System Voltage Heater Warm-up delay O2S Heater device control  B1S1 O2S Heater Duty Cycle  All of the above met for	ECT_Sensor_FA  >10.0 Volts = Complete  = Not active  > zero  >120 seconds	/failures out of 9 samples  Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0137	<p>This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	< 50 mvolts	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Commanded Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active</p>	<p>TPS_ThrottleAuthorityDefaulted MAP_SensorFA AIR_System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA</p> <p>= Not active = Not active = Not active = Not active 10.0 &lt; Volts = Not active = Not active = Not active = Not active</p> <p>= False = False</p> <p>0.992 &lt; ratio &lt; 1.014 150 &lt; mgrams &lt; 800 = Closed Loop = TRUE (Please see "<b>Closed Loop Enable</b>")</p>	<p>320 failures out of 400 samples</p> <p>Frequency: Continuous in 100 milli-second loop</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition  Ethanol Estimation in Progress  Fuel State  All of the above met for	<b>Clarification</b> ”in Supporting Tables).  Enabled (On) Ethanol < 87 %  = Not Active (Please see “ <b>Ethanol Estimation in Progress</b> ” in Supporting Tables).  DFCO not active  >5.0 seconds		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0138	<p>This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	> 1,050 mvolts	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>System Voltage</p> <p>AFM Status</p> <p>Heater Warm-up delay</p> <p>Engine Run Time</p> <p>Engine Run Accum</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>*****</p> <p>Secondary delay after above conditions are complete (cold start condition)</p> <p>Secondary delay after above conditions are complete (not cold start condition)</p> <p>Commanded Equivalence Ratio</p> <p>*****</p> <p>All of the above met for</p>	<p>TPS_ThrottleAuthorityDefaulted</p> <p>MAF_SensorFA</p> <p>MAP_SensorFA</p> <p>EvapExcessPurgePsbl_FA</p> <p>FuelInjectorCircuit_FA</p> <p>Ethanol Composition Sensor FA</p> <p>AIR System FA</p> <p>10.0 &lt; Volts = All Cylinders active = Complete</p> <p>&gt; 5.0 seconds &gt; 30.0 seconds</p> <p>= False</p> <p>= False</p> <p>*****</p> <p>&gt; 100.0 seconds when engine soak time &gt; 28,800 seconds</p> <p>&gt; 100.0 seconds when engine soak time &lt; 28,800 seconds</p> <p>&lt; 1.014 EQR</p> <p>*****</p> <p>&gt; 3.0 seconds</p>	<p>100 failures out of 125 samples</p> <p>Frequency: Continuous in 100 milli- second loop</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Slow Response Rich to Lean Bank 1 Sensor 2	P013A	<p>The P013A diagnostic is the third in a sequence of six intrusive secondary 02 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, &amp;P013B. ThisDTC determines if the secondary 02 sensor has an slow response to an A/F change from Rich to Lean and thereby can no longer be used for secondary 02 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>Note: The Primary method is used when the secondary 02 sensor signal transitions from above the upper threshold to below the lower threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P013A diagnostic measures the secondary 02 sensor voltage response rate</p>	<p>Primary Method: The EWMA of the Post 02 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient.</p> <p>OR</p> <p>Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)</p>	<p>&gt; 8.0 units &lt; 7.0 units</p> <p>&gt; 75.0 grams (upper voltage threshold is 500 mvolts and lower voltage threshold is 200 mvolts)</p>	<p>Diagnostic is Enabled</p> <p>No Active DTCs</p> <p>B1S2 DTCs Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013B, P013E, P013F, P2270 or P2271</p> <p>&gt;10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTCs" ) = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.</p>	<p>Type A, 1 Trips EWMA</p>

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>between an upper and lower voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized integral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTCP013A is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p>Secondary method:</p>			<p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>Crankshaft Torque</p> <p>DTC's Passed</p> <p>===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).</p>	<p>only enabled when airflow is above 22.0 grams/sec.</p> <p>= False</p> <p>= False</p> <p>= Enabled, refer to <b>Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests</b> for additional info. &lt; 125.0 Nm</p> <p>P2270 (and P2272 if applicable) P013E (and P014A if applicable)</p> <p>===== =====</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required lower voltage threshold before the accumulated mass air flow threshold is reached.						

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	<p>The P013B diagnostic is the sixth in a sequence of six intrusive secondary 02 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, &amp;P013B. ThisDTC determines if the secondary 02 sensor has an slow response to an A/F change from Lean to Rich and thereby can no longer be used for secondary 02 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>Note: The Primary method is used when the secondary 02 sensor signal transitions from below the lower threshold to above the upper threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P013B diagnostic measures the secondary 02 sensor voltage response rate</p>	<p>Primary Method: The EWMA of the Post 02 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient.</p> <p>OR</p> <p>Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)</p>	<p>&gt; 8.0 units &lt; 7.0 units</p> <p>&gt; 250 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 600 mvolts)</p>	<p>Diagnostic is Enabled</p> <p>No Active DTCs</p> <p>B1S2 DTCs Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013A, P013E, P013F, P2270 or P2271</p> <p>&gt;10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTCs" )</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.</p>	<p>Type A, 1 Trips EWMA</p>

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>between an lower and upper voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized integral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTCP013Bis set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p>Secondary method:</p>			<p>Green Cat System Condition</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>DTC's Passed</p> <p>===== After above conditions are met: Fuel Enrich mode continued.</p>	<p>Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p> <p>= Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False</p> <p>= False</p> <p>= Enabled, refer to <b>Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests</b> for additional info.</p> <p>P2270 P013E P013A P2271 P013F</p> <p>=====</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required upper voltage threshold before the accumulated mass air flow threshold is reached.			<p>=====</p> <p>During this test the following must stay TRUE or the test will abort:                      0.950 &lt; Base Commanded EQR &lt; 1.100</p> <p>=====</p> <p>During this test: Engine Airflow must stay below:</p> <p>and the delta Engine Airflow over 12.5msec must be :</p>	<p>=====</p> <p>150 gps</p> <p>&lt; 100.0 gps</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Slow Response Rich to Lean Bank 2 Sensor 2	P013C	<p>The P013C diagnostic is the third in a sequence of six intrusive secondary 02 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, &amp;P013D. ThisDTC determines if the secondary 02 sensor has an slow response to an A/F change from Rich to Lean and thereby can no longer be used for secondary 02 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>Note: The Primary method is used when the secondary 02 sensor signal transitions from above the upper threshold to below the lower threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P013C diagnostic measures the secondary 02 sensor voltage response rate</p>	<p>Primary Method: The EWMA of the Post 02 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient.</p> <p>OR</p> <p>Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)</p>	<p>&gt; 8.0 units &lt; 7.0 units</p> <p>&gt;75.0 grams (upper voltage threshold is 500 mvolts and lower voltage threshold is 200 mvolts)</p>	<p>Diagnostic is Enabled</p> <p>No Active DTCs</p> <p>B2S2 DTCs Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013D, P014A, P014B, P2272 or P2273</p> <p>&gt;10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTCs" )</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 in Supporting Tables tab.</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.</p>	<p>Type A, 1 Trips EWMA</p>



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>between an upper and lower voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized integral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTCP013C is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p>Secondary method:</p>			<p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>Crankshaft Torque</p> <p>DTC's Passed</p> <p>=====</p> <p>After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).</p>	<p>Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p> <p>= False</p> <p>= False</p> <p>= Enabled, refer to <b>Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests</b> for additional info. &lt; 125.0 Nm</p> <p>P2272 P014A</p> <p>=====</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required lower voltage threshold before the accumulated mass air flow threshold is reached.						

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Slow Response Lean to Rich Bank 2 Sensor 2	P013D	<p>The P013D diagnostic is the sixth in a sequence of six intrusive secondary 02 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, &amp;P013D. ThisDTC determines if the secondary 02 sensor has an slow response to an A/F change from Lean to Rich and thereby can no longer be used for secondary 02 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>Note: The Primary method is used when the secondary 02 sensor signal transitions from below the lower threshold to above the upper threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P013D diagnostic measures the secondary 02 sensor voltage response rate</p>	<p>Primary Method: The EWMA of the Post 02 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient.</p> <p>OR</p> <p>Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)</p>	<p>&gt; 8.0 units &lt; 7.0 units</p> <p>&gt; 250 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 600 mvolts)</p>	<p>Diagnostic is Enabled</p> <p>No Active DTCs</p> <p>B2S2 DTCs Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013C, P014A, P014B, P2272 or P2273</p> <p>&gt;10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTCs" )</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 in Supporting Tables tab.</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.</p>	<p>Type A, 1 Trips EWMA</p>

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>between an lower and upper voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized integral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTCP013D is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p>Secondary method:</p>			<p>Green Cat System Condition</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>DTC's Passed</p> <p>===== After above conditions are met: Fuel Enrich mode continued.</p>	<p>Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p> <p>= Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False</p> <p>= False</p> <p>= Enabled, refer to <b>Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests</b> for additional info.</p> <p>P2272 P014A P013C P2273 P014B</p> <p>=====</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required upper voltage threshold before the accumulated mass air flow threshold is reached.			<p>=====                      During this test the following must stay TRUE or the test will abort:                      0.950 &lt; Base Commanded EQR &lt; 1.100                      =====</p> <p>=====                      During this test: Engine Airflow must stay below:                      and the delta Engine Airflow over 12.5msec must be :</p>	<p>=====                      =====</p> <p>150 gps</p> <p>&lt; 100.0 gps</p>		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Delayed Response Rich to Lean Bank 1 Sensor 2	P013E	<p>The P013E diagnostic is the second in a sequence of six intrusive secondary 02 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, &amp;P013B. ThisDTC determines if the secondary 02 sensor has an initial delayed response to an A/F change from Rich to Lean and thereby can no longer be used for secondary 02 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary 02 sensor does not achieve the required voltage before the accumulated mass airflow threshold is reached.</p>	<p>Post 02 sensor voltage</p> <p>AND</p> <p>The Accumulated mass airflow monitored during the Delayed Response Test under DFCO</p> <p>DFCO begins after: 1) Catalyst has been rich for a minimum of AND 2) Catalyst Rich Accumulation Air Flow is</p>	<p>&gt; 500 mvolts</p> <p>&gt; 165 grams</p> <p>&gt; 1 secs</p> <p>&gt;3.0 grams</p>	<p>Diagnostic is Enabled</p> <p>No Active DTCs</p> <p>B1S2 DTCs Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green 02S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA 02S_Bank_ 1_TFTKO 02S_Bank_ 2_TFTKO</p> <p>P013A, P013B, P013F, P2270 or P2271</p> <p>&gt;10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTCs" )</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Only when FuelLevelDataFault  Post fuel cell  Crankshaft Torque  DTC's Passed  Number of fueled cylinders ===== After above conditions are met: DFCO mode entered (wo driver initiated pedal input).	Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.  = False  = False  = Enabled, refer to <b>Multiple DTC Use -                      Block learn cells to                      enable Post oxygen                      sensor tests</b> for additional info. < 125.0 Nm  P2270  < 7 cylinders =====		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Delayed Response Lean to Rich Bank 1 Sensor 2	P013F	<p>The P013F diagnostic is the fifth in a sequence of six intrusive secondary 02 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, &amp;P013B. ThisDTC determines if the secondary 02 sensor has an initial delayed response to an A/F change from Lean to Rich and thereby can no longer be used for secondary 02 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary 02 sensor does not achieve the required voltage before the accumulated mass airflow threshold is reached.</p>	<p>Post 02 sensor voltage</p> <p>AND</p> <p>The Accumulated mass airflow monitored during the Delayed Response Test</p>	<p>&lt; 350 mvolts</p> <p>&gt;500 grams</p>	<p>Diagnostic is Enabled</p> <p>No Active DTCs</p> <p>B1S2 DTCs Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green 02S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA 02S_Bank_ 1_TFTK0 02S_Bank_ 2_TFTK0</p> <p>P013A, P013B, P013E, P2270 or P2271</p> <p>&gt;10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTCs" )</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed</p>	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Green Cat System Condition  Low Fuel Condition Only when FuelLevelDataFault  Post fuel cell  DTC's Passed  Number of fueled cylinders  ===== After above conditions are met: Fuel Enrich mode	Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.  = Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/ sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).  = False  = False  = Enabled, refer to <b>Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests</b> for additional info.  P2270 P013E P013A P2271  > 1 cylinders  =====		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					entered.  ===== During this test the following must stay TRUE or the test will abort: 0.950 < Base Commanded EQR < 1.100  ===== During this test: Engine Airflow must stay below:  and the delta Engine Airflow over 12.5msec must be :	=====          150 gps          < 100.0 gps		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0141	<p>This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor.</p> <p>The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.</p>	Heater Current outside of the expected range of	0.3 > amps > 2.9	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>System Voltage</p> <p>Heater Warm-up delay</p> <p>O2S Heater device control</p> <p>B1S1 O2S Heater Duty Cycle</p> <p>All of the above met for</p>	<p>ECT_Sensor_FA</p> <p>&gt;10.0 Volts</p> <p>= Complete</p> <p>= Not active</p> <p>&gt; zero</p> <p>&gt;120 seconds</p>	<p>/failures out of 9 samples</p> <p>Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate.</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Delayed Response Rich to Lean Bank 2 Sensor 2	P014A	<p>The P014A diagnostic is the second in a sequence of six intrusive secondary 02 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, &amp;P013D. ThisDTC determines if the secondary 02 sensor has an initial delayed response to an A/F change from Rich to Lean and thereby can no longer be used for secondary 02 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary 02 sensor does not achieve the required voltage before the accumulated mass airflow threshold is reached.</p>	<p>Post 02 sensor voltage</p> <p>AND</p> <p>The Accumulated mass airflow monitored during the Delayed Response Test under DFCE</p> <p>DFCE begins after: 1) Catalyst has been rich for a minimum of AND 2) Catalyst Rich Accumulation Air Flow is</p>	<p>&gt; 500 mvolts</p> <p>&gt; 150 grams</p> <p>&gt; 1 secs</p> <p>&gt; 3.0 grams</p>	<p>Diagnostic is Enabled</p> <p>No Active DTCs</p> <p>B2S2 DTCs Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013C, P013D, P014B, P2272 or P2273</p> <p>&gt;10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTCs" )</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 in Supporting Tables tab.</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Only when FuelLevelDataFault  Post fuel cell  Crankshaft Torque  DTC's Passed  Number of fueled cylinders =====  After above conditions are met: DFCO mode entered (wo driver initiated pedal input).	Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.  = False  = False  = Enabled, refer to <b>Multiple DTC Use -                      Block learn cells to                      enable Post oxygen                      sensor tests</b> for additional info. < 125.0 Nm  P2272  < 7 cylinders =====		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Green Cat System Condition  Low Fuel Condition Only when FuelLevelDataFault  Post fuel cell  DTC's Passed  Number of fueled cylinders  ===== After above conditions are met: Fuel Enrich mode	Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.  = Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).  = False = False  = Enabled, refer to <b>Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests</b> for additional info.  P2272 P014A P013C P2273  > 1 cylinders  =====		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					entered.  ===== During this test the following must stay TRUE or the test will abort: 0.950 < Base Commanded EQR < 1.100  ===== During this test: Engine Airflow must stay below:  and the delta Engine Airflow over 12.5msec must be :	=====  ===== 150 gps  < 100.0 gps		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 2 Sensor 1	P0151	<p>This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	< 40 mvolts	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Commanded Equivalence Ratio Air Per Cylinder</p> <p>Fuel Control State Closed Loop Active</p>	<p>TPS_ThrottleAuthorityDefaulted MAP_SensorFA AIR_System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA</p> <p>= Not active = Not active = Not active = Not active 10.0 &lt; Volts = Not active = Not active = Not active = Not active</p> <p>= False = False</p> <p>0.992 &lt; ratio &lt; 1.014 150 &lt; APC &lt; 800 mgrams</p> <p>= Closed Loop = TRUE</p>	<p>320 failures out of 400 samples</p> <p>Frequency: Continuous in 100 milli-second loop</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition  Ethanol Estimation in Progress  Fuel State  All of the above met for	(Please see “ <b>Closed Loop Enable Clarification</b> ” in Supporting Tables).  Enabled (On) < 87% Ethanol  = Not Active (Please see “ <b>Ethanol Estimation in Progress</b> ” in Supporting Tables).  DFCO not active  > 5.0 seconds		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 2 Sensor 1	P0152	<p>This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	> 1,050 mvolts	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>System Voltage</p> <p>AFM Status</p> <p>Heater Warm-up delay</p> <p>Engine Run Time</p> <p>Engine Run Accum</p> <p>Low Fuel Condition</p> <p>Only when</p> <p>FuelLevelDataFault</p> <p>*****</p> <p>Secondary delay after above conditions are complete (cold start condition)</p> <p>Secondary delay after above conditions are complete (not cold start condition)</p> <p>Commanded Equivalence Ratio</p> <p>*****</p> <p>All of the above met for</p>	<p>TPS_ThrottleAuthorityDefaulted</p> <p>MAF_SensorFA</p> <p>MAP_SensorFA</p> <p>EvapExcessPurgePsb1_FA</p> <p>FuelInjectorCircuit_FA</p> <p>Ethanol Composition Sensor FA</p> <p>AIR System FA</p> <p>10.0 &lt; Volts</p> <p>= All Cylinders active</p> <p>= Complete</p> <p>&gt; 5.0 seconds</p> <p>&gt; 30.0 seconds</p> <p>= False</p> <p>= False</p> <p>*****</p> <p>&gt; 140.0 seconds when engine soak time &gt; 28,800 seconds</p> <p>&gt; 140.0 seconds when engine soak time &lt; 28,800 seconds</p> <p>&lt; 1.014 EQR</p> <p>*****</p> <p>&gt; 3 seconds</p>	<p>100 failures out of 125 samples</p> <p>Frequency: Continuous in 100 milli-second loop</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 2 Sensor 1	P0155	<p>This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor.</p> <p>The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.</p>	Heater Current outside of the expected range of	0.3 > amps > 3.1	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>System Voltage</p> <p>Heater Warm-up delay</p> <p>O2S Heater device control</p> <p>B1S1 O2S Heater Duty Cycle</p> <p>All of the above met for</p>	<p>ECT_Sensor_FA</p> <p>&gt;10.0 Volts</p> <p>= Complete</p> <p>= Not active</p> <p>&gt; zero</p> <p>&gt; 120 seconds</p>	<p>/failures out of 9 samples</p> <p>Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 2 Sensor 2	P0157	<p>This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	< 50 mvolts	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Commanded Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active</p>	<p>TPS_ThrottleAuthorityDefaulted MAP_SensorFA AIR_System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA</p> <p>= Not active = Not active = Not active = Not active 10.0 &lt; Volts = Not active = Not active = Not active = Not active</p> <p>= False = False</p> <p>0.992 &lt; ratio &lt; 1.014 150 &lt; mgrams &lt; 800 = Closed Loop = TRUE (Please see "<b>Closed Loop Enable</b>")</p>	<p>320 failures out of 400 samples</p> <p>Frequency: Continuous in 100 milli-second loop</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition  Ethanol Estimation in Progress  Fuel State  All of the above met for	<b>Clarification</b> ”in Supporting Tables).  Enabled (On) < 87% Ethanol  = Not Active (Please see “ <b>Ethanol Estimation in Progress</b> ” in Supporting Tables).  DFCO not active  > 5.0 seconds		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 2 Sensor 2	P0158	<p>This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	> 1,050 mvolts	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>System Voltage</p> <p>AFM Status</p> <p>Heater Warm-up delay</p> <p>Engine Run Time</p> <p>Engine Run Accum</p> <p>Low Fuel Condition</p> <p>Only when</p> <p>FuelLevelDataFault</p> <p>*****</p> <p>Secondary delay after above conditions are complete (cold start condition)</p> <p>Secondary delay after above conditions are complete (not cold start condition)</p> <p>Commanded Equivalence Ratio</p> <p>*****</p> <p>All of the above met for</p>	<p>TPS_ThrottleAuthorityDefaulted</p> <p>MAF_SensorFA</p> <p>MAP_SensorFA</p> <p>EvapExcessPurgePsb1_FA</p> <p>FuelInjectorCircuit_FA</p> <p>Ethanol Composition Sensor FA</p> <p>AIR System FA</p> <p>10.0 &lt; Volts</p> <p>= All Cylinders active</p> <p>= Complete</p> <p>&gt; 5.0 seconds</p> <p>&gt; 30.0 seconds</p> <p>= False</p> <p>= False</p> <p>*****</p> <p>&gt; 140.0 seconds when engine soak time &gt; 28,800 seconds</p> <p>&gt; 140.0 seconds when engine soak time &lt; 28,800 seconds</p> <p>&lt; 1.014 EQR</p> <p>*****</p> <p>&gt; 3 seconds</p>	<p>100 failures out of 125 samples</p> <p>Frequency: Continuous in 100 milli-second loop</p>	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Delayed Response Rich to Lean Bank 1 Sensor 1) (For use w/o WRAF	P015A	<p>DTC P015A detects that the primary oxygen sensor for Bank 1 has delayed response when the air fuel ratio transitions from rich to lean condition. This diagnostic runs simultaneously with the intrusive secondary 02 monitor rich to lean tests (P013E / P013A/ P2271), which commands fuel cut off.</p> <p>Note: The Primary method is used when the primary 02 sensor signal transitions from above to below the 02 voltage threshold, otherwise the Secondary method is used.</p> <p>Primary method: The P015A diagnostic measures the primary 02 sensor response time between a rich condition above a starting voltage threshold and a lower voltage threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air temperature resulting in a normalized delay</p>	<p>Primary Method: The EWMA of the Pre 02 sensor normalized R2L time delay value. The EWMA repass limit is The EWMA calculation uses a 0.20 coefficient. This method calculates the result when the Pre 02 sensor voltage is</p> <p>OR</p> <p>Secondary Method: The Accumulated time monitored during the R2L Delayed Response Test.</p> <p>AND</p> <p>Pre 02 sensor voltage is</p>	<p>&gt; 0.68 EWMA (sec) &lt; 0.60 EWMA (sec)</p> <p>&lt; 450mvolts</p> <p>&gt; 3.2 Seconds</p> <p>&gt; 100.0 mvolts</p>	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p>	<p>TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA</p> <p>P0131, P0132, P013A, P013B, P013E, P013F, P2270, P2271</p> <p>&gt;10.0 Volts = Not active = Not active = Not active = Not active</p> <p>= False = False</p>	<p>Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed</p>	Type A, 1 Trips EWMA

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>value. The normalized delay is fed into a 1st order lag filter to update the final EWMA result. DTC P015A is set when the EWMA value exceeds the EWMA threshold.                      Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p>Secondary method:                      This fault is set if the primary 02 sensor does not achieve the required lower voltage threshold before a delay time threshold is reached.</p>			<p>Green 02S Condition</p> <p>02 Heater (pre sensor) on for                      Learned Htr resistance</p> <p>Engine Coolant                      ( Or OBD Coolant Enable                      Criteria</p> <p>IAT                      Engine run Accum</p> <p>Engine Speed to initially                      enable test                      Engine Speed range to                      keep test enabled (after                      initially enabled)</p> <p>Engine Airflow                      Vehicle Speed to initially                      enable test                      Vehicle Speed range to                      keep test enabled (after                      initiallyv enabled)</p>	<p>= Not Valid,                      Green 02S condition is                      considered valid until the                      accumulated air flow is                      greater than  <b>Multiple DTC Use_Green                      Sensor Delay Criteria -                      Limit</b>                      for the following locations:                      B1S1, B2S1 (if applicable)                      in Supporting Tables tab.                      Airflow accumulation is                      only enabled when airflow                      is above 22.0 grams/sec.</p> <p>&gt; 30 seconds                      = Valid ( the heater                      resistance has learned                      since NVM reset, see                      enable conditions for                      "HO2S Heater Resistance                      DTC's" )</p> <p>&gt; 50 °C                      =TRUE)</p> <p>&gt; -40 °C                      &gt; 30 seconds</p> <p>800 &lt; RPM &lt; 3,000</p> <p>750 &lt; RPM &lt; 3,200</p> <p>2.0 &lt; gps &lt; 35.0</p> <p>31.1 &lt; MPH &lt; 82.0</p> <p>27.3 &lt; MPH &lt; 87.0</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed loop integral Closed Loop Active  Evap  Ethanol Estimation in Progress  Baro Post fuel cell  EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State  ===== All of the above met for at least 0.5 seconds, and then the Force Cat Rich intrusive stage is requested. ===== Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders  ===== After above conditions are	0.75 < C/L Int < 1.08 = TRUE (Please see “ <b>Closed                      Loop Enable                      Clarification</b> ” in Supporting Tables).  not in control of purge  = Not Active (Please see “ <b>Ethanol                      Estimation in Progress</b> ” in Supporting Tables).  > 70kpa = enabled  = not active  = not active  > 60.0 sec 475 < °C < 1,000 = DFCO possible  ===== =====  > 750mvolts = DFCO active  < 7 cylinders  ===== =====		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					met: DFCO Mode is entered (wo driver initiated pedal input).			

24OBDG06B HD ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Delayed Response Lean to Rich Bank 1 Sensor 1) (For use w/o WRAF	P015B	<p>DTC P015B detects that the primary oxygen sensor for Bank 1 has delayed response when the air fuel ratio transitions from lean to rich condition. This diagnostic runs simultaneously with the intrusive secondary 02 monitor lean to rich tests (P013F / P013B), which commands fuel enrichment.</p> <p>Note: The Primary method is used when the primary 02 sensor signal transitions from lean condition to above the 02 voltage threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P015B diagnostic measures the primary 02 sensor response time between a lean condition and a higher voltage threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air temperature resulting in a normalized delay value. The normalized delay is fed into a 1st</p>	<p>Primary method: The EWMA of the Pre 02 sensor normalized L2R time delay value. The EWMA repass limit is The EWMA calculation uses a 0.20 coefficient.</p> <p>OR</p> <p>Secondary method: The Accumulated time monitored during the L2R Delayed Response Test.</p> <p>AND</p> <p>Pre 02 sensor voltage is</p> <p>OR</p> <p>At end of Cat Rich stage the Pre 02 sensor output is</p>	<p>&gt; 0.68 EWMA (sec) &lt; 0.60 EWMA (sec)</p> <p>&gt; 2.5 Seconds</p> <p>&lt; 450mvolts</p> <p>&lt; 750mvolts</p>	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>P015Atest is complete and</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition</p>	<p>TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA</p> <p>P0131, P0132, P013A, P013B, P013E, P013F, P015A, P2270, P2271</p> <p>= Passed</p> <p>&gt;10.0 Volts = Not active = Not active = Not active = Not active</p> <p>= False</p>	<p>Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed</p>	Type A, 1 Trips EWMA

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>order lag filter to update the final EWMA result. DTC P015B is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p><u>Secondary method:</u> This fault is set if the primary O2 sensor does not achieve the required higher voltage threshold before a delay time threshold is reached.</p>			<p>Only when FuelLevelDataFault</p> <p>Green O2S Condition</p> <p>O2 Heater (pre sensor) on for Learned Htr resistance</p> <p>Engine Coolant ( Or OBD Coolant Enable Criteria</p> <p>IAT Engine run Accum</p> <p>Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow Vehicle Speed to initiallv</p>	<p>= False</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p> <p>&gt; 30 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>&gt; 50 °C =TRUE)</p> <p>&gt; -40 °C &gt; 30 seconds</p> <p>800 &lt; RPM &lt; 3,000</p> <p>750 &lt; RPM &lt; 3,200</p> <p>2.0 &lt; gps &lt; 35.0</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					enable test Vehicle Speed range to keep test enabled (after initially enabled)  Closed loop integral Closed Loop Active  Evap  Ethanol Estimation in Progress  Baro Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time  Predicted Catalyst temp Fuel State Number of fueled cylinders  ===== When above conditions are met: Fuel Enrich mode is entered.  =====  During this test: Engine Airflow must stav	31.1 < MPH < 82.0  27.3 < MPH < 87.0  0.75 < C/L Int < 1.08 = TRUE (Please see “ <b>Closed                      Loop Enable                      Clarification</b> ” in Supporting Tables).  not in control of purge  = Not Active (Please see “ <b>Ethanol                      Estimation in Progress</b> ” in Supporting Tables).  > 70kpa = enabled = not active  = not active  > 60.0 sec  475 < °C < 1,000 = DFCO inhibit  > 1 cylinders  ===== =====		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					between: and the delta Engine Airflow over 12.5msec must be :	4 < gps < 30  < 50.0 gps		



24OBDG06B HD ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Delayed Response Rich to Lean Bank 2 Sensor 1) (For use w/o WRAF	P015C	<p>DTC P015C detects that the primary oxygen sensor for Bank 2 has delayed response when the air fuel ratio transitions from rich to lean condition. This diagnostic runs simultaneously with the intrusive secondary 02 monitor rich to lean tests (P014A/ P013C / P2273), which commands fuel cut off.</p> <p>Note: The Primary method is used when the primary 02 sensor signal transitions from above to below the 02 voltage threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P015C diagnostic measures the primary 02 sensor response time between a rich condition above a starting voltage threshold and a lower voltage threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air temperature resulting in a normalized delay</p>	<p>Primary method: The EWMA of the Pre 02 sensor normalized R2L time delay value. The EWMA repass limit is The EWMA calculation uses a 0.20 coefficient. This method calculates the result when the Pre 02 sensor voltage is</p> <p>OR</p> <p>Secondary method: The Accumulated time monitored during the R2L Delayed Response Test.</p> <p>AND</p> <p>Pre 02 sensor voltage is above</p>	<p>&gt; 0.68 EWMA (sec) &lt; 0.60 EWMA (sec)</p> <p>&lt; 450mvolts</p> <p>&gt; 3.2 Seconds</p> <p>&gt; 100mvolts</p>	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p>	<p>TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA</p> <p>P0151, P0152, P013C, P013D, P014A, P014B, P2272, P2273</p> <p>&gt;10.0 Volts = Not active = Not active = Not active = Not active</p> <p>= False</p> <p>= False</p>	<p>Frequency: Once per trip Note: if NaESPD_b_FastInitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed</p>	<p>Type A, 1 Trips EWMA</p>

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>value. The normalized delay is fed into a 1st order lag filter to update the final EWMA result. DTC P015C is set when the EWMA value exceeds the EWMA threshold.                      Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p><u>Secondary method:</u>                      This fault is set if the primary O2 sensor does not achieve the required lower voltage threshold before a delay time threshold is reached.</p>			<p>Green O2S Condition</p> <p>02 Heater (pre sensor) on for                      Learned Htr resistance</p> <p>Engine Coolant                      ( Or OBD Coolant Enable                      Criteria</p> <p>IAT                      Engine run Accum</p> <p>Engine Speed to initially                      enable test                      Engine Speed range to                      keep test enabled (after                      initially enabled)</p> <p>Engine Airflow</p> <p>Vehicle Speed to initially                      enable test                      Vehicle Speed range to                      keen test enabled (after</p>	<p>= Not Valid,                      Green O2S condition is                      considered valid until the                      accumulated air flow is                      greater than  <b>Multiple DTC Use_Green                      Sensor Delay Criteria -                      Limit</b>                      for the following locations:                      B1S1, B2S1 (if applicable)                      in Supporting Tables tab.                      Airflow accumulation is                      only enabled when airflow                      is above 22.0 grams/sec.</p> <p>&gt; 30 seconds                      = Valid ( the heater                      resistance has learned                      since NVM reset, see                      enable conditions for                      "HO2S Heater Resistance                      DTC's" )</p> <p>&gt; 50 °C                      =TRUE)</p> <p>&gt; -40 °C                      &gt;30seconds</p> <p>800 &lt; RPM &lt; 3,000</p> <p>750 &lt; RPM &lt; 3,200</p> <p>2.0 &lt; gps &lt; 35.0</p> <p>31.1 &lt; MPH &lt; 82.0</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					initially enabled)  Closed loop integral Closed Loop Active  Evap  Ethanol Estimation in Progress  Baro Post fuel cell  EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time  Predicted Catalyst temp Fuel State  ===== All of the above met for at least 0.5 seconds, and then the Force Cat Rich intrusive stage is requested. =====  Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders =====	27.3 < MPH < 87.0  0.75 < C/L Int < 1.08 = TRUE (Please see “ <b>Closed                      Loop Enable                      Clarification</b> ” in Supporting Tables).  not in control of purge  = Not Active (Please see “ <b>Ethanol                      Estimation in Progress</b> ” in Supporting Tables).  > 70kpa = enabled  = not active  = not active  > 60.0 sec  475 < °C < 1,000 = DFCE possible  =====  =====  > 750mvolts = DFCE active  <= 7 cylinders =====		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).			

24OBDG06B HD ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Delayed Response Lean to Rich Bank 2 Sensor 1) (For use w/o WRAF	P015D	<p>DTC P015D detects that the primary oxygen sensor for Bank 2 has delayed response when the air fuel ratio transitions from lean to rich condition. This diagnostic runs simultaneously with the intrusive secondary 02 monitor lean to rich tests (P014B / P013D), which commands fuel enrichment.</p> <p>Note: The Primary method is used when the primary 02 sensor signal transitions from lean condition to above the 02 voltage threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P015D diagnostic measures the primary 02 sensor response time between a lean condition and a higher voltage threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air temperature resulting in a normalized delay value. The normalized delay is fed into a 1st</p>	<p>Primary method: The EWMA of the Pre 02 sensor normalized L2R time delay value. The EWMA repass limit is The EWMA calculation uses a 0.20 coefficient.</p> <p>OR</p> <p>Secondary method: The Accumulated time monitored during the L2R Delayed Response Test.</p> <p>AND</p> <p>Pre 02 sensor voltage is below</p> <p>OR</p> <p>At end of Cat Rich stage the Pre 02 sensor output is</p>	<p>&gt; 0.68 EWMA (sec) &lt; 0.60 EWMA (sec)</p> <p>&gt; 2.5 Seconds</p> <p>&lt; 450 mvolts</p> <p>&lt; 750 mvolts</p>	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>P015C test is complete and</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition</p>	<p>TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA</p> <p>P0151, P0152, P013C, P013D, P014A, P014B, P015C, P2272, P2273</p> <p>= Passed</p> <p>&gt;10.0 Volts = Not active = Not active = Not active = Not active</p> <p>= False</p>	<p>Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed</p>	Type A, 1 Trips EWMA

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>order lag filter to update the final EWMA result. DTC P015D is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p><u>Secondary method:</u> This fault is set if the primary O2 sensor does not achieve the required higher voltage threshold before a delay time threshold is reached.</p>			<p>Only when FuelLevelDataFault</p> <p>Green O2S Condition</p> <p>O2 Heater (pre sensor) on for Learned Htr resistance</p> <p>Engine Coolant ( Or OBD Coolant Enable Criteria</p> <p>IAT Engine run Accum</p> <p>Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow Vehicle Speed to initially enable test</p>	<p>= False</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p> <p>&gt; 30 seconds = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>&gt; 50 °C =TRUE)</p> <p>&gt; -40 °C &gt; 30 seconds</p> <p>800 &lt; RPM &lt; 3,000</p> <p>750 &lt; RPM &lt; 3,200</p> <p>2.0 &lt; gps &lt; 35.0</p> <p>31.1 &lt; MPH &lt; 82.0</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Vehicle Speed range to keep test enabled (after initially enabled)  Closed loop integral Closed Loop Active  Evap  Ethanol Estimation in Progress  Baro Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time  Predicted Catalyst temp Fuel State Number of fueled cylinders  ===== When above conditions are met: Fuel Enrich mode is entered.  =====  During this test: Engine Airflow must stay between:	$27.3 < \text{MPH} < 87.0$  $0.75 < \text{C/L Int} < 1.08$ = TRUE (Please see “ <b>Closed Loop Enable Clarification</b> ” in Supporting Tables).  not in control of purge  = Not Active (Please see “ <b>Ethanol Estimation in Progress</b> ” in Supporting Tables).  $> 70\text{kpa}$ = enabled = not active  = not active  $> 60.0 \text{ sec}$  $475 < \text{°C} < 1,000$ = DFCO inhibit  $> 1 \text{ cylinders}$  =====  =====  $4 < \text{aos} < 30$		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					and the delta Engine Airflow over 12.5msec must be :	< 50.0 gps		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 2 Sensor 2	P0161	<p>This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor.</p> <p>The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.</p>	Heater Current outside of the expected range of	0.3 > amps > 2.9	<p>Diagnostic is Enabled</p> <p>No Active DTC's</p> <p>System Voltage</p> <p>Heater Warm-up delay</p> <p>O2S Heater device control</p> <p>B1S1 O2S Heater Duty Cycle</p> <p>All of the above met for</p>	<p>ECT_Sensor_FA</p> <p>&gt;10.0 Volts</p> <p>= Complete</p> <p>= Not active</p> <p>&gt; zero</p> <p>&gt; 120 seconds</p>	<p>/failures out of 9 samples</p> <p>Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Lean Bank 1	P0171	<p>Determines if the primary fuel control system for Bank 1 is in a lean condition, based on the filtered long-term and short-term fuel trim. A normally operating system operates centered around long-term fuel trim metric of 1.0. For lean conditions extra fuel trim is required therefor values &gt; 1.0 indicate a Lean condition.</p> <p>A fault is determined, when the long term fuel metric exceeds the threshold value. In addition to the long-term fuel trim limit, the short-term fuel trim metric can be monitored and the fault sets once both threshold values are exceeded. The short-term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority.</p>	<p>The filtered long-term fuel trim metric</p> <p>AND</p> <p>The filtered short-term fuel trim metric (Note: any value below 0.95 effectively nullifies the short-term fuel trim criteria)</p>	<p>&gt;= 1.270</p> <p>&gt;= 0.100</p> <p>If a fault has been detected the long-term fuel trim metric must be &lt; 1.130 and the short-term fuel trim metric must be &lt; 1.150 to re-pass the diagnostic.</p>	<p>The primary fuel trim diagnostic is enabled</p> <p>Engine speed BARO Coolant Temp</p> <p>Coolant Temp MAP Inlet Air Temp MAF Fuel Level</p> <p>Long Term Fuel Trim data accumulation:</p> <p>Sometimes, certain Long-Term Fuel Trim Cells are not utilized for control and/or diagnosis</p>	<p>400 &lt;rpm&lt; 7,000 &gt; 70 kPa &gt; -40 °C (or OBD Coolant Enable Criteria = TRUE) &lt; 150 °C 10 &lt;kPa&lt; 255 -40 &lt;°C&lt; 150 1 &lt;g/s&lt; 1,000 &gt; 10% or if fuel sender is faulty the diagnostic will bypass the fuel level criteria.</p> <p>&gt; 25.00 seconds of data must accumulate on each trip, with at least 15.00 seconds of data in the current fuel trim cell before a pass or fail decision can be made. Additional time can be required for cold ambient starts to accommodate larger minimum LTM's for startability reasons. See <b>Startup Engine Coolant adjustment to Minimum accumulation time</b></p> <p>(Please see <b>P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage</b> in Supporting Tables for a list of cells utilized for diagnosis)</p>	<p>Frequency: 100 ms Continuous Loop</p>	<p>Type B, 2 Trips</p>

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Closed Loop Long Term FT</p> <p>EGR Diag. Catalyst Diag. Post O2 Diag. Device Control EVAP Diag.</p> <p>-----</p> <p>Delay during GPF Regeneration</p> <p>Standard startup delays are re-initialized following completion of GPF Regen to allow system stabilization. (See "Long Term Fuel Trim data accumulation" above.)</p> <p>-----</p> <p>No active DTC:</p>	<p>Enabled Enabled (Please see "<b>Closed Loop Enable Clarification</b>" and "<b>Long Term FT Enable Criteria</b>" in Supporting Tables.)</p> <p>Intrusive Test Not Active Intrusive Test Not Active Intrusive Test Not Active Not Active Large Leak Diagnostic (P0455) Not Active</p> <p>-----</p> <p>No Delay</p> <p>-----</p> <p>1AC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR_System FA EvapExcessPurgePsbl_F A Ethanol Composition Sensor FA FuelInjectorCircuit_FA</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngineMisfireDetected_FA EGRValvePerformance_FA EGRValveCircuit.FA MAP_EngineVacuumStatus AmbPresDfIttdStatus TC_BoostPresSnsrFA O2S_Bank_1_Sensor_1_FA		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority.</p> <p>Once purge is enabled if the filtered Purge Long Term Fuel Trim metric &gt; 0.710, the test passes without intrusively checking the filtered Non-Purge Long Term Fuel Trim metric. However if the filtered Purge Long Term Fuel Trim metric is &lt;= 0.710, the Intrusive test is invoked. The purge is ramped off to determine if excess purge vapor is the cause of the rich condition. If during 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric &lt;= 0.705 the fault will set.</p> <p>Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions, and the execution frequency of other diagnostics. This is why the intrusive test is operated over several</p>		<p>term fuel trim metric must be &gt; 0.850 to re-pass the diagnostic. The intrusive test will be enabled at long-term fuel metric values &lt; 0.75 until the diagnostic re-passes after a failure.</p>		<p>If the accumulated purge volume is &gt; 4,250.0 grams, the intrusive test will not be inhibited even if Purge Vapor Fuel is &gt; 20.0%.</p>	<p>time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge Long Term Fuel Trim metric &gt; 0.710 for at least 200.00 seconds, indicating that the canister has been purged.</p>	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		segments allowing Purge to reenable between segments. Likewise, for these reasons, if after the 5 intrusive segments the diagnostic continues to pass, there is a delay period of 300 seconds to allow sufficient time to purge excess vapors from the canister, before re-evaluating a Rich condition if it still exists.						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Lean Bank 2	P0174	Determines if the primary fuel control system for Bank 2 is in a lean condition, based on the filtered long-term and short-term fuel trim. A normally operating system operates centered around long-term fuel trim metric of 1.0. For lean conditions extra fuel trim is required therefor values > 1.0 indicate a Lean condition. A fault is determined, when the long term fuel metric exceeds the threshold value. In addition to the long-term fuel trim limit, the short-term fuel trim metric can be monitored and the fault sets once both threshold values are exceeded. The short-term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority.	The filtered long-term fuel trim metric  AND  The filtered short-term fuel trim metric (Note: any value below 0.95 effectively nullifies the short-term fuel trim criteria)	>= 1.270   >= 0.100  If a fault has been detected the long-term fuel trim metric must be < 1.130 and the short-term fuel trim metric must be < 1.150 to repass the diagnostic.	The primary fuel trim diagnostic is enabled  Engine speed BARO Coolant Temp  Coolant Temp MAP Inlet Air Temp MAF Fuel Level  Long Term Fuel Trim data accumulation:  Sometimes, certain Long-Term Fuel Trim Cells are not utilized for control and/or diagnosis	400 <rpm< 7,000 > 70 kPa > -40 °C (or OBD Coolant Enable Criteria = TRUE) < 150 °C 10 <kPa< 255 -40 <°C< 150 1 <g/s< 1,000 > 10% or if fuel sender is faulty the diagnostic will bypass the fuel level criteria.  > 25.00 seconds of data must accumulate on each trip, with at least 15.00 seconds of data in the current fuel trim cell before a pass or fail decision can be made. Additional time can be required for cold ambient starts to accommodate larger minimum LTM's for startability reasons. See <b>Startup Engine Coolant adjustment to Minimum accumulation time</b>  (Please see <b>P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage</b> in Supporting Tables for a list of cells utilized for diagnosis)	Frequency: 100 ms Continuous Loop	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed Loop Long Term FT	Enabled Enabled (Please see " <b>Closed Loop Enable Clarification</b> " and " <b>Long Term FT Enable Criteria</b> " in Supporting Tables.)		
					EGR Diag. Catalyst Diag. Post 02 Diag. Device Control EVAP Diag.	Intrusive Test Not Active Intrusive Test Not Active Intrusive Test Not Active Not Active Large Leak Diagnostic (P0455) Not Active		
					----- Delay during GPF Regeneration Standard startup delays are re-initialized following completion of GPF Regen to allow system stabilization. (See "Long Term Fuel Trim data accumulation" above.) -----	No Delay		
					No active DTC:	1AC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR_System FA EvapExcessPurgePsbl_F A Ethanol Composition Sensor FA FuelInjectorCircuit_FA		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngineMisfireDetected_FA EGRValvePerformance_FA EGRValveCircuit.FA MAP_EngineVacuumStatus AmbPresDfIttdStatus TC_BoostPresSnsrFA O2S_Bank_2_8ensor_1_FA		

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 2	P0175	<p>Determines if the fuel control system is in a rich condition, based on the filtered long-term fuel trim metric. A normally operating system operates centered around long-term fuel trim metric of 1.0. For rich conditions less fuel trim is required therefore values &lt; 1.0 indicate a rich condition.</p> <p>There are two methods to determine a Rich fault. They are Passive and Intrusive.</p> <p>A Passive Test decision can be made up until the time that purge is first enabled. From that point forward, rich faults can only be detected by turning purge off intrusively. If during this period of time the filtered long-term fuel trim metric exceeds the threshold a fault will be set. In addition to the long-term fuel trim limit, the short-term fuel trim metric can be monitored and the fault sets once both threshold values are exceeded. The short-</p>	<p><b>Passive Test:</b> The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>*****</p> <p><b>Intrusive Test:</b> For 3 out of 5 intrusive segments,</p> <p>the filtered Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)</p>	<p>&lt;= 0.705</p> <p>&lt;= 2.000</p> <p>*****</p> <p>&lt;= 0.710</p> <p>&lt;= 0.705</p> <p>&lt;= 2.000</p> <p>If a fault has been detected (by the passive or intrusive test) the long-term fuel trim metric must be &gt;</p>	<p>Purge Vapor Fuel</p>	<p>Secondary Parameters and Enable Conditions are identical to those for P0174, with the exception that fuel level is not considered.</p> <p>&lt;= 20.00 % Intrusive Test is inhibited when Purge Vapor percentage is greater than this threshold. (Note: values greater than 50% indicate the Purge Vapor Fuel requirement is not being used)</p> <p>A minimum number of accumulated Fuel Trim Data samples are required to adequately learn a correct Purge Vapor Fuel value. See the table</p> <p><b>Minimum Non-Purge Samples for Purge (Vapor Fuel )</b> for the Purge Off cells used to validate the Purge Vapor Fuel parameter.</p> <p>If the accumulated purge volume is &gt; 4,250.0</p>	<p>Frequency: 100 ms Continuous Loop</p> <p><b>Segment Definition:</b> Segments can last up to 60 seconds and are separated by the lesser of 20.00 seconds of purge-on time or enough time to purge 36 grams of vapor. A maximum of 5 completed segments or 20 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 300 seconds to allow sufficient time to</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority.</p> <p>Once purge is enabled if the filtered Purge Long Term Fuel Trim metric &gt; 0.710 , the test passes without intrusively checking the filtered Non-Purge Long Term Fuel Trim metric. However if the filtered Purge Long Term Fuel Trim metric is &lt;= 0.710, the Intrusive test is invoked. The purge is ramped off to determine if excess purge vapor is the cause of the rich condition. If during 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric &lt;= 0.705 the fault will set.</p> <p>Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions, and the execution frequency of other diagnostics. This is why the intrusive test is operated over several</p>		<p>0.745 and the short-term fuel trim metric must be &gt; 0.850 to repass the diagnostic. The intrusive test will be enabled at long-term fuel metric values &lt; 0.75 until the diagnostic repasses after a failure.</p>		<p>grams, the intrusive test will not be inhibited even if Purge Vapor Fuel is &gt; 20.0%.</p> <p>(Note: values greater than 50% indicate the Purge Vapor Fuel requirement is not being used)</p>	<p>purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge Long Term Fuel Trim metric &gt; 0.710 for at least 200.00 seconds, indicating that the canister has been purged.</p>	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		segments allowing Purge to reenable between segments. Likewise, for these reasons, if after the 5 intrusive segments the diagnostic continues to pass, there is a delay period of 300 seconds to allow sufficient time to purge excess vapors from the canister, before re-evaluating a Rich condition if it still exists.						

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit Range/ Performance	P018B	<p>This DTC detects a fuel pressure sensor response stuck within the normal operating range using an intrusive test ( as follows)</p> <p>a] Intrusive Test Trigger: 1] Fuel Pump Duty Cycle Clamped Time ( min or max duty cycle) &gt;= 5 sec</p> <p>Or 2] Fuel Pres Err Variance &lt;= calibration value KeFDBR_cmp_FPSS_MinPres</p> <p>Variance ; Otherwise, Report status as Pass</p> <p>b] Intrusive test freq limit: 60 sec between intrusive tests that pass,</p> <p>c] Intrusive test Fuel Flow limit: Fuel Flow Actual &lt; Max allowed Fuel Flow rate</p>	<p>Sensed fuel pressure change</p> <p>[absolute value, during intrusive test]</p>	>= 30.00 kPa	<p>a) Diagnostic is ..</p> <p>b) Timer Engine Running</p> <p>c1) Fuel Flow Rate Valid c2) Fault bundle FDB_FuelPresSnrCktFA c3) Reference Voltage Fault Status [DTC P0641] c4) Fault bundle FAB_FuelPmpCktFA c5) Fuel Control Enable Fault Active [DTC P12A6] c6) Fuel Pump Driver Module OverTemp Fault Active [DTC P1255] c7) Fuel Pump Speed Fault Active [DTCP129F] c8) CAN Sensor Bus message \$0C3 Comm Fault [DTCP165C] c9) CAN Sensor Bus Fuel Pmp Speed Command ARC and Checksum Comm Fault Code [DTC U18A7] c10) Fuel Pump Duty Cycle Fault Active c11) Sensor Configuration [Wired to FTZM?] c12) Sensor Bus Relay On d) Emissions Fuel Level Low [Message \$3FB] e) Fuel Control Enable f) Fuel Pump Control State g) Instantaneous Fuel</p>	<p>a) ENABLED</p> <p>b) &gt;= 5.00 seconds</p> <p>c1) == TRUE c2) == False c3) == False c4) == False c5) == False c6) == False c7) == False c8) == False c9) == False c10) == False c11) == CeFDBR_e_WiredTo_FT ZM c12) == TRUE d) == False e) == TRUE f) == Normal Control OR == Fuel Pres Sensor Stuck Control g) &gt;= 0.05 gm/sec</p>	<p>1 sample/ 12.5 millisec</p> <p>Intrusive Test Duration: Fuel Flow - related ( 5 to 12 sec)</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Flow h) Diagnostic System Disabled j1) Fuel Pmp Speed Command Alive Rolling Count and Checksum Error [CAN Bus B \$0CE] [DTCU18A7] j2) CAN Sensor Bus message \$0C3_Available j3) Fuel Pres Sensor Ref Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B \$0C3][DTC U18A7]	h) == False j1) == False j2) == TRUE j3) == False		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit Low	P018C	This DTC detects if the fuel pressure sensor circuit is shorted low  Values are analyzed as percent of sensor reference voltage $[[Abs [5.0V - SensorVoltsActual] / 5.0V] * 100\%]$	Fuel Pressure Sensor output %  [re. full range as percent of 5.0V reference]	< 4.00 % or [0 kPa gauge]	a) Diagnostic is .. b) Run_Crank Active c) Diagnostic System Disabled d) Pressure Sensor Configuration	a) ENABLED b) == TRUE c) == False d) If calibration value CeFDBR_e_WiredTo_FT ZM == WiredTo ECM Else see Case2	64.00 failures/ 80.00 samples  1 sample/12.5 ms	Type B, 2 Trips
			Fuel Pressure Sensor output %  [re. full range as percent of 5.0V reference]	< 4.00 % or [0 kPa gauge]	a) Diagnostic is .. b) Run_Crank Active c) Diagnostic System Disabled d1) Pressure Sensor Configuration d2) Sensor Bus Relay On d3) CAN Sensor Bus message \$0C3 Available d4) Fuel Pres Sensor Ref Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B \$0C3] [Info]	a) ENABLED b) == TRUE c) == False d1) If calibration value CeFDBR_e_WiredTo_FT ZM == WiredTo FTZM Else see Case1 d2) == TRUE d3) == TRUE d4) == False	64.00 failures/ 80.00 samples  1 sample/12.5 ms	



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit High	P018D	This DTC detects if the fuel pressure sensor circuit is shorted High  Values are analyzed as percent of sensor reference voltage $[[Abs [5.0V - SensorVoltsActual] / 5.0V] * 100\%]$	Fuel Pressure Sensor output %  [re. full range as percent of 5.0V reference]	> 96.00 % or [743 kPa ga]	a) Diagnostic is .. b) Run_Crank Active c) Diagnostic System Disabled d) Pressure Sensor Configuration	a) ENABLED b) == TRUE c) == False d) If calibration value CeFDBR_e_WiredTo_FT ZM == WiredTo ECM Else see Case2	64.00 failures/ 80.00 samples  1 sample/12.5 ms	Type B, 2 Trips
			Fuel Pressure Sensor output %  [re. full range as percent of 5.0V reference]	> 96.00 % or [743 kPa ga]	a) Diagnostic is .. b) Run_Crank Active c) Diagnostic System Disabled d1) Pressure Sensor Configuration d2) Sensor Bus Relay On d3) CAN Sensor Bus message \$0C3 Available d4) Fuel Pres Sensor Ref Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B \$0C3][Info1]	a) ENABLED b) == TRUE c) == False d1) If calibration value CeFDBR_e_WiredTo_FT ZM == WiredTo FTZM Else See Case 1 d2) == TRUE d3) == TRUE d4) == False	64.00 failures/ 80.00 samples  1 sample/12.5 ms	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT SIDI High Pressure Sensor Performance	P0191	The DTC determines if there is a skewed control fuel rail sensor (Sensor1) via a comparison to diagnostic sensor (sensor2) continuously when the engine is running and the commanded pressure is steady.	Primary sensor (P1) vs. Secondary sensor (P2) performance rationality  ((Low Limit fail Filtered Fuel Control Error )  OR  (High Limit Fail: Filtered Fuel Control Error))  AND  (Filtered Absolute delta between sensor1 and sensor2	<= <b>P0191 - Low fail limit of fuel control due to pressure sensor skewed low</b> (See supporting table)  >= <b>P0191 - High fail limit of fuel control due to high pressure sensor skewed High</b> (see Supporting table)  >= 1.00 mpa  Note: fuel control error is calculated based on the squerroot of sensor1 divided by sensor2, this value is filter to ensure proper failure detection.  Absolute delta between sensor1 and sensor2 value is filter to ensure proper failure detection.	Commanded Pressure rate of change (increasing or dercresing)  for a period of time	<0.70 mpa  >= 1.25 seconds  Enabled when a code clear is not active or not exiting device control	Filter Fuel Control Error term and Absolute delta between sensor1 and sensor2 exceed Low or High Fail limit for a duration >= 1.50 seconds  This is diagnostic runs Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure Sensor 1 Out of Range	P0192	<p>This DTC diagnose SENT high pressure sensor 1 that is too low out of range.</p> <p>If the sensor digital value (repressing the refernce voltage) is below the lower digital threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported. A pass is reported for this DTC if the low sample counter reaches its threshold.</p>	High Pressure Rail Sensor 1 SENT digital read value	=< 94			Time Based: 400 Failuerout of 500 Samples 6.25 ms per Sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Coolant Temperature Dropped Below Diagnostic Monitoring Temperature	P01F0	This DTC detects an unexplained cooling system cool down below the OBD monitoring threshold during normal operating conditions. This check is run throughout the key cycle.	Engine outlet coolant temperature drops below for an unexpected reason	< 68.9 Deg C	Diagnostic is Enabled  No Active DTC's  Engine Runtime  Distance traveled this key cycle  Ambient air pressure  Ambient air temperature *****  Engine coolant temperature At least once during the key cycle *****  Heat to coolant  DFCO time  Thermostat duty cycle	ECT_Sensor_Ckt_FA VehicleSpeedSensor_FA OAT_PtEstFiltFA THMR_AWP_AuxPumpFA THMR_AHV_FA THMR_SWP_Control_FA EngineTorqueEstInaccurate ECT_Sensor_Perf_FA THMR_SWP_NoFlow_FA THMR_SWP_Flow8tuckOn_FA  >30.0 seconds  >1.2 km  > 55.0 kPa  > -9.0 Deg C  > 74.9 Deg C  > <b>P01F0 - Heat To Coolant Min 2D</b>  < 75.0 seconds  < 101.0%	48 seconds out of a 60 seconds window	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					RPM Active Fuel Management is not in	< 8,192 Half Cylinder Mode		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit - (SIDI)	P0201	<p>Controller specific output driver circuit diagnoses Injector 1 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 1 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p><math>\geq 200</math> KOhms impedance between signal and controller ground</p> <p><math>\geq 200</math> KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p><math>\geq 11</math> Volts <math>\geq 0</math> Seconds</p> <p>P062B notFAorTFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit - (SIDI)	P0202	<p>Controller specific output driver circuit diagnoses Injector 2 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 2 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>&gt;= 200 KOhms impedance between signal and controller ground</p> <p>&gt;= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>&gt;=11 Volts &gt;= 0 Seconds</p> <p>P062B notFAorTFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector3 Open Circuit - (SIDI)	P0203	<p>Controller specific output driver circuit diagnoses Injector 3 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 3 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>&gt;= 200 KOhms impedance between signal and controller ground</p> <p>&gt;= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>&gt;=11 Volts &gt;= 0 Seconds</p> <p>P062B notFAorTFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit - (SIDI)	P0204	<p>Controller specific output driver circuit diagnoses Injector 4 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 4 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>&gt;= 200 KOhms impedance between signal and controller ground</p> <p>&gt;= 200 KOhms impedance between signal and controller ground</p>	<p>Battery Voltage Engine Run Time</p>	<p>&gt;=11 Volts &gt;= 0 Seconds</p> <p>P062B notFAorTFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	<p>Type A, 1 Trips</p>

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector5 Open Circuit - (SIDI)	P0205	<p>Controller specific output driver circuit diagnoses Injector 5 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 5 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>&gt;= 200 KOhms impedance between signal and controller ground</p> <p>&gt;= 200 KOhms impedance between signal and controller ground</p>	<p>Battery Voltage Engine Run Time</p>	<p>&gt;=11 Volts &gt;= 0 Sec</p> <p>P062B notFAorTFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	<p>Type A, 1 Trips</p>

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Open Circuit - (SIDI)	P0206	<p>Controller specific output driver circuit diagnoses Injector 6 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 6 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>&gt;= 200 KOhms impedance between signal and controller ground</p> <p>&gt;= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>&gt;=11 Volts &gt;= 0 Seconds</p> <p>P062B notFAorTFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 Open Circuit - (SIDI)	P0207	<p>Controller specific output driver circuit diagnoses Injector 7 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 7 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>&gt;= 200 KOhms impedance between signal and controller ground</p> <p>&gt;= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>&gt;=11 Volts &gt;=0 Seconds</p> <p>P062B notFAorTFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector8 Open Circuit - (SIDI)	P0208	<p>Controller specific output driver circuit diagnoses Injector 7 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 7 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>&gt;= 200 KOhms impedance between signal and controller ground</p> <p>&gt;= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>&gt;=11 Volts &gt;=0 Seconds</p> <p>P062B notFAorTFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short low or open in TPS2 circuit by monitoring the TPS 2 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too low. This diagnostic only runs when battery voltage is high enough.	TPS2 % Vref < (100% corresponds to 5.0 Volt)	5.00 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P06A3	79/159 counts;  57 counts continuous;  3.125 ms /count in the ECM main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit High	P0223	Detects a continuous or intermittent short high in TPS2 circuit by monitoring the TPS 2 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too high. This diagnostic only runs when battery voltage is high enough.	TPS2 % Vref >  (100% corresponds to 5.0 Volt)	91.80 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P06A3	79/159 counts;  57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground (SIDI)	P0261	Controller specific output driver circuit diagnoses Injector 1 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to power (SIDI)	P0262	Controller specific output driver circuit diagnoses Injector 1 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground (SIDI)	P0264	Controller specific output driver circuit diagnoses Injector 2 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power (SIDI)	P0265	Controller specific output driver circuit diagnoses Injector 2 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector3 Low side circuit shorted to ground (SIDI)	P0267	Controller specific output driver circuit diagnoses Injector 3 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector3 Low side circuit shorted to power (SIDI)	P0268	Controller specific output driver circuit diagnoses Injector 3 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground (SIDI)	P0270	Controller specific output driver circuit diagnoses Injector 4 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to power (SIDI)	P0271	Controller specific output driver circuit diagnoses Injector 4 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector5 Low side circuit shorted to ground (SIDI)	P0273	Controller specific output driver circuit diagnoses Injector 5 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector5 Low side circuit shorted to power (SIDI)	P0274	Controller specific output driver circuit diagnoses Injector 5 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Low side circuit shorted to ground (SIDI)	P0276	Controller specific output driver circuit diagnoses Injector 6 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Low side circuit shorted to power (SIDI)	P0277	Controller specific output driver circuit diagnoses Injector 6 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 Low side circuit shorted to ground (SIDI)	P0279	Controller specific output driver circuit diagnoses Injector 7 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 Low side circuit shorted to power (SIDI)	P0280	Controller specific output driver circuit diagnoses Injector 7 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector8 Low side circuit shorted to ground (SIDI)	P0282	Controller specific output driver circuit diagnoses Injector 8 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector8 Low side circuit shorted to power (SIDI)	P0283	Controller specific output driver circuit diagnoses Injector 8 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 to 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.			
Random Misfire Detected	P0300	These DTC's will determine if a random or a cylinder specific misfire is occurring by monitoring various terms derived from crankshaft velocity. The rate of misfire over an interval is compared to both emissions and catalyst damaging thresholds. The pattern of crankshaft acceleration after the misfire is checked to differentiate between real misfire and other sources of crank shaft noise.	Crankshaft Deceleration Value(s) vs. Engine Speed and Engine load  The equation used to calculate deceleration value is tailored to specific vehicle operating conditions. The selection of the equation used is based on the 1st single cylinder continuous misfire threshold tables encountered that are not max of range. If all tables are max of range at a given speed/load, that speed load region is an <b>Undetectable region</b> see Algorithm Description Document for additional details.		Engine Run Time	> 2 crankshaft revolution	Emission Exceedence = any ( 5 ) failed 200 rev blocks out of ( 16 ) 200 rev block tests	Type B, 2 Trips (Mil Flashes with Catalyst damage level of Misfire)			
Cylinder 1 Misfire Detected	P0301										
Cylinder 2 Misfire Detected	P0302										
Cylinder 3 Misfire Detected	P0303										
Cylinder 4 Misfire Detected	P0304										
Cylinder 5 Misfire Detected	P0305				Emissions Neutral Default Action: If consumed Emissions Neutral Default DTCs from other subsystems are set: Ignore Rough Road, Traction, Stability, and Antilock brake signals. If default action not activated, Misfire Monitor could complete less frequently or inaccurately. Default Action Latched for duration of Trip				System Voltage + Throttle delta - Throttle delta	9.00 < volts < 32.00 < 95.00 % per 25 ms < 95.00 % per 25 ms	
Cylinder 6 Misfire Detected	P0306				SINGLE CYLINDER CONTINUOUS MISFIRE( (Medres_Decel Medres_Jerk	> RufSCD_Decel AND > RufSCD_Jerk)			Early Termination option: (used on plug ins that may not have enough engine run time at end of trip for normal interval to complete.)	Not Enabled	OR when Early Termination Reporting = Enabled and engine rev > 1,000 revs and < 3,200 revs at end of trip
Cylinder 7 Misfire Detected	P0307				OR (Medres_Decel Medres_Jerk	> SCD.Decel AND > SCD_Jerk )					
Cylinder 8 Misfire Detected	P0308	OR (Lores_Decel Lores_Jerk	> RufCyl_Decel AND > RufCyl.Jerk)								
		Default Action: If Misfire P030x sets on some hybrid applications, the isolation damper	OR (Lores_Decel Lores_Jerk	> CylModeDecel AND > CylModeJerk )							
			OR RevBalanceTime	>RevMode_Decel							



Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		between engine and transmission can go into extreme resonance. Default action is to move rpm out of the resonance zone. If default action not activated, significant hardware damage could occur rendering vehicle inoperable.	***** **This Feature not used on Gasoline engines**  Combustion Modes that force selection of Idle Tables *****  Other patterns of misfire use adjustments to the single cylinder continuous misfire threshold tables:  RANDOM MISFIRE Use random misfire thresholds If no misfire for  (Medres_Decel AND Medres_Jerk)  OR (Medres_Decel AND Medres_Jerk)  OR (Lores_Decel AND Lores_Jerk)	***** **This Feature not used on Gasoline engines**  <b>CombustModelIdleTbl</b> in Supporting Tables *****  > 3 Engine Cycles  > RufSCD_Decel * Random_SCD_Decel  >RufSCD_Jerk * Random_SCD_Jerk  >SCD_Decel * Random_SCD_Decel  > SCD_Jerk * Random_SCD_Jerk  > RufCyl_Decel * RandomCylModDecel  > RufCyl_Jerk * RandomCylModJerk			any Catalyst Exceedence = ( 1 ) 200 rev block as data supports for catalyst damage.  Catalyst Failure reported with (1 or 3) Exceedences in FTP, or (1) Exceedence outside FTP.  Continuous	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR (Lores_Decel AND Lores_Jerk)  OR RevBalanceTime  PAIRED CYLINDER MISFIRE If a cylinder & it's pair are above PAIR thresholds (Medres_Decel AND Medres_Jerk)  OR (Medres_Decel AND Medres_Jerk)  OR (Lores_Decel AND Lores_Jerk)  OR (Lores_Decel AND Lores_Jerk)	> CylModeDecel * RandomCylModDecel  > CylModeJerk * RandomCylModJerk  > RevMode_Decel * RandomRevModDecl  > RufSCD_Decel * Pair_SCD_Decel  > RufSCD_Jerk * Pair_SCD_Jerk  >SCD_Decel * Pair_SCD_Decel  > SCD_Jerk * Pair_SCD_Jerk  > RufCyl_Decel * PairCylModeDecel  > RufCyl.Jerk * PairCylModeJerk  > CylModeDecel * PairCylModeDecel  > CylModeJerk * PairCylModeJerk				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR (Revmode Active AND (within one engine cycle: 2nd largest Lores_Decel)	> <b>CylModeDecel</b> * <b>PairCylModeDecel</b>				
			BANK MISFIRE Cylinders above Bank Thresholds	>= 2 cylinders				
			(Medres_Decel AND Medres_Jerk)	> <b>RufSCD_Decel</b> * <b>Bank_SCD_Decel</b> > <b>RufSCD_Jerk</b> * <b>Bank_SCD_Jerk</b>				
			OR (Medres_Decel AND Medres_Jerk)	> <b>SCD_Decel</b> * <b>Bank_SCD_Decel</b> > <b>SCD_Jerk</b> * <b>Bank_SCD_Jerk</b>				
			OR (Lores_Decel AND Lores_Jerk)	> <b>RufCyl_Decel</b> * <b>BankCylModeDecel</b> > <b>RufCyl.Jerk</b> * <b>BankCylModeJerk</b>				
			OR (Lores_Decel AND Lores_Jerk)	> <b>CylModeDecel</b> * <b>BankCylModeDecel</b> > <b>CylModeJerk</b> * <b>BankCylModeJerk</b>				

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>CONSECUTIVE CYLINDER MISFIRE 1st cylinder uses single cyl continuous misfire thresholds; 2nd Cylinder uses: (Medres_Decel AND Medres_Jerk)</p> <p>OR (Medres_Decel AND Medres_Jerk)</p> <p>OR (Lores_Decel AND Lores_Jerk)</p> <p>OR (Lores_Decel AND Lores_Jerk)</p>	<p>&gt; RufSCD_Decel * ConsecSCD_Decel</p> <p>&gt; RufSCD_Jerk * ConsecSCD_Jerk</p> <p>&gt;SCD_Decel * ConsecSCD_Decel</p> <p>&gt; SCD_Jerk * ConsecSCD_Jerk</p> <p>&gt; RufCyl_Decel * ConsecCylModDecel</p> <p>&gt; RufCyl.Jerk * ConsecCylModeJerk</p> <p>&gt; CylModeDecel * ConsecCylModDecel</p> <p>&gt; CylModeJerk * ConsecCylModeJerk</p>				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			CYLINDER DEACTIVATIONMODE (Active Fuel Managment)  AFM: SINGLE CYLINDER CONTINUOUS MISFIRE (CylAfterDeacCyl_Decel AND CylAfterDeacCyl_Jerk)  OR (CylBeforeDeacCylDecel AND CylBeforeDeacCyl_Jerk)  AFM: RANDOM MISFIRE Use random misfire thresholds If no misfire for (CylAfterDeacCyl_Decel AND CylAfterDeacCyl_Jerk)  (CylBeforeDeacCylDecel AND	> CylModeDecel * CylAfterAFM_Decel  > CylModeJerk * CylAfterAFM_Jerk  > CylModeDecel * CylBeforeAFM_Decel  > CylModeJerk * CylBeforeAFM_Jerk  > 3 Engine Cycles  > CylModeDecel * CylAfterAFM_Decel * RandomAFM_Decl  > CylModeJerk * CylAfterAFM_Jerk * RandomAFM_Jerk  > CylModeDecel * CylBeforeAFM_Decel * RandomAFM_Decl				

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>CylBeforeDeacCyl_Jerk)</p> <p>OR IF option Crank based IMEP estimate is Enabled and CrankBasedJMEP is</p> <p>Misfire Percent Emission Failure Threshold</p> <p>Misfire Percent Catalyst</p>	<p>&gt; CylModeJerk * ClyBeforeAFM_Jerk * RandomAFM_Jerk</p> <p>Not Enabled</p> <p>&lt;</p> <p><b>Misfire_IMEP_Thresh _vs_BinID</b> (Note: Thresholds uses following tables to pick threshold vs BinID. See supporting tables for more information on how BinID works to select appropriate calibration threshold) <b>Misfire_IMEP_BinID_ vs_RPM_Load</b> <b>Misfire_IMEP_BinID_ RPM_Axis</b> <b>Misfire_IMEP_BinID_ Load_Axis</b></p> <p>- see details on Supporting Tables Tab</p> <p>&gt; 2.10%P0300</p> <p>&gt;</p>				

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Damage</p> <p>When engine speed and load are less than the FTP calcs (3) catalyst damage exceedences are allowed.</p>	<p><b>Catalyst_Damage_Misfire_Percentage</b> in Supporting Tables whenever secondary conditions are met.</p> <p>&lt; 1,500 FTP rpm AND &lt; 15 FTP % load</p>	<p>(at low speed/loads, one cylinder may not cause cat damage)</p> <p>Engine Speed Engine Load Misfire counts</p>	<p>&gt; 1,500 rpm AND &gt; 20 % load AND &lt; 180 counts on one cylinder</p>		
					Engine Speed	<p>400 &lt; rpm &lt; ((Engine Over Speed Limit) - 400 ) OR 8,191 )</p> <p>Engine speed limit is a function of inputs like Gear and temperature</p> <p>see <b>EngineOverSpeedLimit</b> in supporting tables</p>	4 cycle delay	
					No active DTCs:	<p>TPS_FA EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO ECT_Sensor_Ckt_TFTKO 5VoltReferenceB_FA CrankSensor_TFTKO CrankSensor_FA CamLctnlntFA</p>	4 cycle delay	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						CamLctnExhFA CamSensorAnyLctnTFTK 0 AnyCamPhaser_FA AnyCamPhaser_TFTKO AmbPresDfIttdStatus		
					P0315 & engine speed	> 1,000 rpm	4 cycle delay	
					Fuel Level Low	LowFuelConditionDiagnostic	500 cycle delay	
					Cam and Crank Sensors	in sync with each other	4 cycle delay	
					Misfire requests TCC unlock	Not honored because Transmission in hot mode or POPD intrusive diagnostic running	4 cycle delay	
					Fuel System Status	# Fuel Cut	4 cycle delay	
					Active FuelManagement	Transition in progress	0 cycle delay	
					Undetectable engine speed and engine load region	<b>Undetectable region</b> from Malfunction Criteria	4 cycle delay	
					Abusive Engine Over Speed	> 8,192 rpm	0 cycle delay	
					Below zero torque (except CARB approved 3000 rpm to redline triangle.)	< <b>ZeroTorqueEngLoad</b> or < <b>ZeroTorqueAFM</b> if AFM is active in Supporting Tables	4 cycle delay	
					Below zero torque: TPS Vehicle Speed	< 0.8 % (< 0.8% in AFM) > 30 mph (> 30 mph AFM)	4 cycle delay	



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					NEGATIVE TORQAFM If deactivated cylinders appear to make power, torque is negative: DeactivatedCyl_Decel AND DeactivatedCyl_Jerk AND # of Deact Cyls Inverted	<DeacCylInversionDecel  <DeacCylInversionJerk  > 4 cylinders	0 cycle delay   4 cycle delay 7 cycle delay  2 Cylinder delay  4 cycle delay  3 cycle delay  4 cycle delay	
					Manual Trans  Accel Pedal Position AND Automatic transmission shift  After Fuel resumes on Automatic shift containing Fuel Cut  Delay if PTC engaged  Delay if error in indices of buffered data is detected and delay is enabled  Delay if IMEP calculation	Clutch shift  > 95.00 %  Enabled  Delay Enabled  initializing on startup or running resets (expires before rpm enablement)	4 cycle delay  7 cycle delay  2 Cylinder delay  4 cycle delay  3 cycle delay  4 cycle delay	
					***** **This Feature not used on Gasoline engines** Combustion Mode	***** ***** = InfrequentRegen value in Supporting Tables	***** ***** 0 cycle delay	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Driver cranks before Wait to Start lamp extinguishes</p> <p>Brake Torque *****</p> <p>DRIVELINE RING FILTER After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early. Filter Driveline ring:  Stop filter early:</p> <p>ABNORMAL ENGINE SPEED OSCILLATION: (checks each "misfire" candidate in 100 engine Cycle test to see if it looks like some disturbance like rough road (abnormal). )</p> <p>Used Off Idle, and while not shifting, TPS Engine Speed Veh Speed Auto Transmission</p> <p>individual candidate deemed abnormal if number of consecutive decelerating</p>	<p>IF TRUE</p> <p>&gt; 199.99% Max Torque *****</p> <p>&gt; "Ring Filter" # of engine cycles after misfire in Supporting Tables</p> <p>&gt; "Number of Normals" # of engine cycles after misfire in Supporting Tables tab</p> <p>&gt; 3 % &gt; 950 rpm &gt; 3 mph not shifting</p>	<p>WaitToStart cycle delay</p> <p>0 cycle delay *****</p>	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>cylinders after "misfire": (Number of decels can vary with misfire detection equation) Consecutive decels while in SCD Mode Cyl Mode Rev Mode</p> <p>At the end of 100 engine cycle test, the ratio of abnormal/candidate is checked to confirm if real misfire is present within the 100 engine cycles,</p> <p>abnormal candidates/ total candidates</p> <p>MISFIRE CRANKSHAFT PATTERN RECOGNITION checks each "misfire" candidate in 100 engine Cycle test to see if overall crankshaft pattern looks like real misfire (recognized), or some disturbance like rough road (unrecognized). At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present within the 100 engine cycles.</p>	<p>&gt; <b>Abnormal SCD Mode</b> &gt; <b>Abnormal Cyl Mode</b> &gt; <b>Abnormal Rev Mode</b> in Supporting Tables</p> <p>&gt;0.50 ratio</p>	<p>discard 100 engine cycle test</p>	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Typically used for checking a single misfire per engine cycle but can support some other patterns on some packages</p> <p>Pattern Recog Enabled:</p> <p>Pattern Recog Enabled during Cylinder Deac</p> <p>Pattern Recog Enabled consecutive cyl patrn</p> <p>Engine Speed Veh Speed</p> <p>The 1st check for "recognized" is the 1st fired cylinder after the misfire candidate should both accelerate and jerk an amount based acceleration and jerk of Single Cylinder Misfire thresholds in effect at that speed and load. (CylAfter_Accel AND CylAfter_Jerk)</p> <p>Additionally, the crankhaft is checked aaain a small</p>	<p>Enabled</p> <p>Not Enabled</p> <p>Enabled</p> <p>1,000 &lt; rpm &lt; 4,530 &gt; 5.0 mph</p> <p>&gt; Misfire_decel * <b>1st_FireAftrMisfr_Acel</b></p> <p>&gt; Misfire_Jerk * <b>1st_FireAftrMisfr_Jerk</b></p> <p>Or if AFM mode is active: &gt; Misfire_decel * <b>IstFireAftrMisAcelAFM</b> &gt; Misfire_Jerk * <b>IstFireAfterMisJerkAFM</b></p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>calibratable number of cylinders later to see if the disturbance is still large like rough road, or has calmed down like real misfire. The size of disturbance is compared to a multiplier times the ddtjerk value used to detect misfire at that speed and load. If there is repetitive misfire on consecutive engine cycles, the expected snap is adjusted due to the higher expected disturbance.</p> <p>Num of Cylinders after misfire to start check of crankshaft snap</p> <p>"misfire" recognized if: Crankshaft snap after: isolated "misfire"</p> <p>repetative "misfire"</p> <p>At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present.</p> <p>Ratio of Unrecog/Recog</p>	<p>3 Cylinders</p> <p>&lt; Misfire_Jerk * <b>SnapDecayAfterMisfire</b></p> <p>&lt; Misfire_Jerk * <b>SnapDecayAfterMisfire *</b> <b>RepetSnapDecayAdjst</b> in Supporting Tables</p> <p>&gt;0.60</p>	<p>discard 100 engine cycle test</p>	



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>AND No Active DTCs</p> <p>*****</p> <p>Default Action</p> <p>Isolator Resonance Default Action Option</p> <p>*****</p> <p>If Isolator Resonance Option Enabled AND Misfire P030xTFTKO</p>	<p>TransmissionEngagedState_FA (Auto Trans only) ClutchPstnSnsr FA (Manual Trans only)</p> <p>*****</p> <p>Not Enabled</p> <p>*****</p> <p>Set engine speed limits: 0 &lt; Eng RPM &lt; 9,000</p>	<p>4 cycle delay</p> <p>*****</p> <p>*****</p>	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position System Variation Not Learned	P0315	This DTC determines if the crankshaft sensor learn values that are stored in memory are valid. The angle between each tooth of the reluctor wheel is learned, and the sum of all angles together should sum to 360° (one revolution of the reluctor wheel). Default values, or corrupted values will not sum to 360°.	The Crankshaft target wheel should be 360 degrees around in circumference. Loss or controller non-volatile memory or an error in memory will cause the values of individual teeth learn to be defaulted or incorrect.  Set the DTC if the Difference between the sum of the reluctor wheel's teeth and 360 degrees is greater than:	> 0.001 degrees	OBD Manufacturer Enable Counter	MEC = 0	0.50 seconds  Frequency Continuous100 msec	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Per Cylinder	P0324	This diagnostic checks for knock sensor performance out of the normal expected range on a per cylinder basis due to Excessive Knock (either real or false knock). In the knock detection algorithm, the term "Knock Intensity" (KI) is used to define the relative size of a knock event, and is calculated as (KI = current knock event - knock threshold). This results in a KI amplitude that is proportional to the size of the knock event (as seen by the knock sensor). In addition, Knock Intensity cannot be less than zero as it is forced/limited to be = 0 with no knock detected (i.e. whenever the current knock event < knock threshold, KI = 0). This diagnostic calculates a first-order lag filter version of the Knock Intensity and sets a fault when: (Filtered KI) > (Excessive Knock Diagnostic Threshold)	Filtered Knock Intensity  (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)	> <b>P0324_PerCyl_ExcessiveKnock_Threshold</b> (no units)	Diagnostic Enabled?  Engine Run Time  Engine Speed  Engine Air Flow  Engine Coolant Temperature  or  OBD Coolant Enable Criteria  Inlet Air Temperature  Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	Yes  > 2.0 seconds  > 400 RPM AND < 8,500 RPM  >200 mg/cylinder AND < 2,000 mg/cylinder  > -40 deg's C  = TRUE  > -40 deg's C  > 42 revs	First Order Lag Filters with Weight Coefficient = 0.0234  Updated each engine event	Type B, 2 Trips

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 1	P0325	<p>This diagnostic checks for an open in the knock sensor circuit Sensor 1/Bank 1. There are two possible methods used:</p> <p><b>1. 20 kHz Method:</b> This method injects a 20 kHz signal (internal to the ECU) onto one of the Knock Sensor inputs. For a normal/good circuit the 20 kHz signal will propagate through the Knock sensor and back to the ECU through the sensor return circuit. The 20 kHz signal is processed through the Fast Fourier Transform (FFT) and then filtered with a first-order lag filter. Since the Knock Detection algorithm uses a Differential Op-Amp to compare the input from the two knock sensor wires, the FFT 20 kHz diagnostic signal will have either: A. Low output with a good circuit (because the 20 kHz injected signal is detected on both of the sensor inputs) or B. High output for an Open Circuit (because</p>	<p>Open Circuit Method chosen (2 possible methods: 20 kHz or Normal Noise):</p> <p>Filtered FFT Output</p> <p>Filtered FFT Output</p>	<p>= <b>P0325_P0330_OpenMethod_2</b></p> <p><b>Case 1 (20 kHz Method):</b> &gt; <b>P0325_P0330_OpenCktThrshMin (20 kHz)</b> AND &lt; <b>P0325_P0330_OpenCktThrshMax (20 kHz)</b></p> <p><b>Case 2 (Normal Noise Method):</b> &gt; <b>P0325_P0330_OpenCktThrshMin (Normal Noise)</b> AND &lt; <b>P0325_P0330_OpenCktThrshMax (Normal Noise)</b></p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)</p> <p>Engine Air Flow</p> <p>Engine Coolant Temperature</p> <p>or</p> <p>OBD Coolant Enable Criteria</p> <p>Inlet Air Temperature</p>	<p>Yes</p> <p>&gt; 2.0 seconds</p> <p>&gt; 400 RPM and &lt; 8,500 RPM</p> <p>&gt; 100 revs</p> <p>&gt; 50 mg/cylinder and &lt; 2,000 mg/cylinder</p> <p>&gt; -40 deg's C</p> <p>= TRUE</p> <p>&gt; -40 deg's C</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p>Weight Coefficient = 0.0100</p> <p>Updated each engine event</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>the 20 kHz injected signal is detected only on one of the sensor inputs).                      The 20 kHz method is typically used for the entire operating region of the engine. However, some engines may not have adequate separation between good and bad circuits at high engine speed. In these cases the 20 kHz method is used at low and medium engine speeds, and the "Normal Noise" method is used at high engine speed only.</p> <p><b>2. Normal Noise:</b> The Normal Noise method monitors the background engine noise level for a selected frequency range output of the knock detection FFT. The background noise (i.e. Normal Noise) is filtered with a first-order lag filter. A good circuit is determined when the filtered Normal Noise signal is greater than the threshold.</p> <p>See Supporting Tables for method definition:  <b>P0325 P0330 OoenM</b></p>						

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p><b>ethod</b> defines which of the two diagnostic methods is used as a function of engine speed (RPM).                      Typical implementations:                      A. Use 20 kHz method at all engine RPM (used when acceptable separation achieved at all RPM) or                      B. Use 20 kHz method at low/medium RPM and Normal Noise at high RPM</p>						

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Bank 1	P0326	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis. This diagnostic is specifically designed to identify the fault condition where the knock sensor is properly attached electrically, but produces an abnormally low output due to being unattached (or loosely attached) with the mounting bolt (and thus unable to properly transfer the engine vibration energy from the engine block to the knock sensor). The term "Abnormal (engine) Noise" is used to define this diagnostic method. A fault condition is identified when a first-order lag filtered version of the Abnormal Noise signal falls below the diagnostic threshold.	<p>Filtered FFT Intensity (where 'FFT Intensity' = Non-knocking, background engine noise for a selected frequency)</p> <p>Filtered FFT Intensity</p>	<p><b>Case 1: Engine not in AFM mode</b></p> <p>&lt;</p> <p><b>P0326_P0331_AbnormalNoise_Threshold</b> (Supporting Table)</p> <p>OR</p> <p><b>Case 2: Engine is in AFM mode</b></p> <p>&lt;</p> <p><b>P0326_P0331_AbnormalNoise_Thresh_AFM</b> (Supporting Table; Engine is in AFM mode)</p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Engine Air Flow</p> <p>Engine Coolant Temperature</p> <p>or</p> <p>OBD Coolant Enable Criteria</p> <p>Inlet Air Temperature</p> <p>Individual Cylinders enabled for Abnormal Noise</p> <p>Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)</p>	<p>Yes</p> <p>&gt; 2.0 seconds</p> <p>&gt; 2,000 RPM (not in AFM mode) OR &gt; 2,000 (in AFM mode)</p> <p>AND &lt; 8,500 RPM</p> <p>&gt; 300 mg/cylinder AND &lt; 2,000 mg/cylinder</p> <p>&gt; -40 deg's C</p> <p>= TRUE</p> <p>&gt; -40 deg's C</p> <p><b>P0326_P0331-Abnormal NoiseCylsEnabled</b> (Supporting Table)</p> <p>&gt; 158 Revs</p>	<p>First Order Lag Filters with Weight Coefficient = 0.0043</p> <p>Updated each engine event</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 1	P0327	This diagnostic checks for an out of range low knock sensor signal. A 3-resistor bias network at each sensor input to the ECM provides a DC diagnostic voltage that will remain within a normal range when the external knock sensor circuit is free of short circuit faults. The diagnostic output is reported as a percentage (0 to 100%) when compared to the 5.0 volt reference voltage.	Sensor Input or Return Signal Line	< 8.0 Percent  (of 5.0 Volt reference)	Diagnostic Enabled?  Engine Speed	Yes  > 400 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 1	P0328	This diagnostic checks for an out of range high knock sensor signal. A 3-resistor bias network at each sensor input to the ECM provides a DC diagnostic voltage that will remain within a normal range when the external knock sensor circuit is free of short circuit faults. The diagnostic output is reported as a percentage (0 to 100%) when compared to the 5.0 volt reference voltage.	Sensor Input or Return Signal Line	> 39.0 Percent  (of 5 Volt Reference)	Diagnostic Enabled?  Engine Speed	Yes  > 400 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 2	P0330	<p>This diagnostic checks for an open in the knock sensor circuit Sensor 2/Bank 2</p> <p>There are two possible methods used:</p> <p><b>1. 20 kHz Method:</b> This method injects a 20 kHz signal (internal to the ECU) onto one of the Knock Sensor inputs. For a normal/good circuit the 20 kHz signal will propagate through the Knock sensor and back to the ECU through the sensor return circuit. The 20 kHz signal is processed through the Fast Fourier Transform (FFT) and then filtered with a first-order lag filter. Since the Knock Detection algorithm uses a Differential Op-Amp to compare the input from the two knock sensor wires, the FFT 20 kHz diagnostic signal will have either:</p> <p>A. Low output with a good circuit (because the 20 kHz injected signal is detected on both of the sensor inputs) or B. High output for an</p>	<p><b>Individual Sensor Thresholds Enabled?</b></p> <p><b>Open Circuit Method chosen</b> (2 possible methods: 20 kHz or Normal Noise):</p>	<p>= 0, Use Case 1 and 2</p> <p>= <b>P0325_P0330_OpenMethod_2</b> (supporting table)</p> <p><b>Case 1 (20 kHz Method):</b></p> <p>&gt; <b>P0325_P0330_OpenCktThrshMin (20 kHz) AND</b> &lt; <b>P0325_P0330_OpenCktThrshMax (20 kHz)</b></p> <p><b>Case 2 (Normal Noise Method):</b></p> <p>&gt; <b>P0325_P0330_OpenCktThrshMin (Normal Noise) AND</b> &lt; <b>P0325_P0330_OpenCktThrshMax (Normal Noise)</b></p> <p><b>Case 3 (20 kHz Method):</b></p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)</p> <p>Engine Air Flow</p> <p>Engine Coolant Temperature</p> <p>or</p> <p>OBD Coolant Enable Criteria</p> <p>Inlet Air Temperature</p>	<p>Yes</p> <p>&gt; 2.0 seconds</p> <p>&gt; 400 RPM and &lt; 8,500 RPM</p> <p>≥ 100 revs</p> <p>&gt; 50 mg/cylinder and &lt; 2,000 mg/cylinder</p> <p>&gt; -40 deg's C</p> <p>= TRUE</p> <p>&gt; -40 deg's C</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p><b>Case 1 &amp; 2:</b> Weight Coefficient = 0.0100</p> <p>Updated each engine event</p>	Type B, 2 Trips
			<p>Filtered FFT Output</p> <p>Filtered FFT Output</p>					





Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>for method definition:  <b>P0325_P0330_OpenMethod</b> defines which of the two diagnostic methods is used as a function of engine speed (RPM).                      Typical implementations:                      A. Use 20 kHz method at all engine RPM (used when acceptable separation achieved at all RPM) or                      B. Use 20 kHz method at low/medium RPM and Normal Noise at high RPM</p> <p>For each method the failure thresholds can be the same for both sensors (in a 2 sensor application), or the failure thresholds can be unique to each sensor.</p>						

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Bank 2	P0331	<p>This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis. This diagnostic is specifically designed to identify the fault condition where the knock sensor is properly attached electrically, but produces an Abnormally low output due to being unattached (or loosely attached) with the the mounting bolt (and thus unable to properly transfer the engine vibration energy from the engine block to the knock sensor). The term "Abnormal (engine) Noise" is used to define this diagnostic method. A fault condition is identified when a first-order lag filtered version of the Abnormal Noise signal falls below the diagnostic threshold.</p> <p>The failure thresholds can be the same for both sensors (in a 2 sensor application), or the failure thresholds can be unique to each sensor.</p>	<p>Individual Sensor Thresholds Enabled?</p> <p>Filtered FFT Intensity (where 'FFT Intensity' = Non-knocking, background engine noise)</p> <p>Filtered FFT Intensity</p>	<p>= 0, Use Case 1 and 2</p> <p><b>Case 1: Engine not in AFM mode</b> &lt; <b>P0326_P0331_AbnormalNoise_Threshold</b> (Supporting Table)</p> <p>OR</p> <p><b>Case 2: Engine is in AFM mode</b> &lt; <b>P0326_P0331_AbnormalNoise_Thresh_AFM</b> (Supporting Table)</p> <p><b>Case 3: Engine not in AFM mode</b> &lt; <b>P0331_AbnormalLo2</b> (Supporting Table)</p> <p>OR</p> <p><b>Case 4: Engine is in AFM mode</b> &lt; <b>P0331_AbnormalLoA FM_2</b> (Supporting Table)</p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Engine Air Flow</p> <p>Engine Coolant Temperature</p> <p>or</p> <p>OBD Coolant Enable Criteria</p> <p>Inlet Air Temperature</p> <p>Individual Cylinders enabled for Abnormal Noise</p> <p>Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)</p>	<p>Yes</p> <p>&gt; 2.0 seconds</p> <p>&gt; 2,000 RPM (not in AFM mode) OR &gt; 2,000 (in AFM mode)</p> <p>AND &lt; 8,500 RPM</p> <p>&gt; 300 mg/cylinder AND &lt; 2,000 mg/cylinder</p> <p>&gt; -40 deg's C</p> <p>= TRUE</p> <p>&gt; -40 deg's C</p> <p><b>P0326_P0331-Abnormal NoiseCylsEnabled</b> (Supporting Table)</p> <p>&gt; 158 Revs</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p><b>Case 1 &amp; 2:</b> Weight Coefficient = 0.0100</p> <p>Updated each engine event</p> <p><b>Case 3 &amp; 4:</b> Weight Coefficient = 0.01</p> <p>Updated each engine eventFirst</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 2	P0332	This diagnostic checks for an out of range low knock sensor signal. A 3-resistor bias network at each sensor input to the ECM provides a DC diagnostic voltage that will remain within a normal range when the external knock sensor circuit is free of short circuit faults. The diagnostic output is reported as a percentage (0 to 100%) when compared to the 5.0 volt reference voltage.	Sensor Input or Return Signal Line	< 8.0 Percent  (of 5 Volt Reference)	Diagnostic Enabled?  Engine Speed	Yes  > 400 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 2	P0333	This diagnostic checks for an out of range high knock sensor signal. A 3-resistor bias network at each sensor input to the ECM provides a DC diagnostic voltage that will remain within a normal range when the external knock sensor circuit is free of short circuit faults. The diagnostic output is reported as a percentage (0 to 100%) when compared to the 5.0 volt reference voltage.	Sensor Input or Return Signal Line	> 39.00 Percent  (of 5 Volt Reference)	Diagnostic Enabled?  Engine Speed	Yes  > 400 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) SensorA Circuit	P0335	Diagnostic will fail if a crank sensor pulse was not received during a period of time; if crank sensor pulses are received the diagnostic will pass.	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	Starter engaged AND (cam pulses being received OR ( MAF_SensorFA AND Engine Air Flow	Test is Enabled  = FALSE > 3.0 grams/second ) )	Continuous every 100 msec	Type B, 2 Trips
			No crankshaft pulses received	>= 0.1 seconds	Engine is Running  Starter is not engaged	Test is Enabled	Continuous every 12.5 msec	
			No crankshaft pulses received		Engine is Running OR Starter is engaged  No DTC Active:	Test is Enabled  P0340 P0341	2 failures out of 10 samples  One sample per engine revolution	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) SensorA Performance	P0336	1. Fail counts will occur if the engine goes out of synchronization repeatedly over a period of time and will pass if the engine stays in synchronization. 2. Diagnostic will fail if synchronization gap is not found in a specified period of time and will pass if the synchronization gap is found. 3. Diagnostic will fail if the incorrect number of crank sensor teeth are detected in-between detecting the synchronization gap and will pass if the correct number of teeth are seen.	Time in which 10 or more crank re-synchronizations occur	< 10.0 seconds	Engine Air Flow  Cam-based engine speed  No DTC Active:	Test is Enabled  >= 3.0 grams/second  > 450 RPM  P0335	Continuous every 250 msec	Type B, 2 Trips
			No crankshaft synchronization gap found	>= 0.4 seconds	Engine is Running  Starter is not engaged	Test is Enabled	Continuous every 12.5 msec	
			Time since starter engaged without detecting crankshaft synchronization gap	>= 3.3 seconds	Starter engaged AND (cam pulses being received OR ( MAF_SensorFA AND Engine Air Flow	Test is Enabled  = FALSE  > 3.0 grams/second ) )	Continuous every 100 msec	
			Crank pulses received in one engine revolution OR Crank pulses received in one engine revolution	< 1 pulses  > 65,535 pulses	Engine is Running OR Starter is engaged  No DTC Active:	Test is Enabled  P0340 P0341	8 failures out of 10 samples  One sample per engine revolution	



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor A	P0340	Diagnostic will fail if a cam sensor pulse was not received during a period of time; if cam sensor pulses are received the diagnostic will pass.	Time since last camshaft position sensor pulse received	$\geq 5.5$ seconds	Starter engaged AND (crank pulses being received OR ( MAF_SensorFA AND Engine Air Flow	Test is Enabled  = FALSE  > 3.0 grams/second ) )	Continuous every 100 msec	Type B, 2 Trips
			OR Time that starter has been engaged without a camshaft sensor pulse	$\geq 4.0$ seconds	Engine is running  Starter is not engaged	Test is Enabled	Continuous every 100 msec	
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged	Test is Enabled	Continuous, every MEDRES event until test completes, one test at every start attempt	
			No camshaft pulses received during 24 MEDRES events  (There are 24 MEDRES events per engine cycle)  Test begins when MEDRES region AND accumulated number of MEDRES events	= region 5  $\geq 0$ counts	No DTC Active:	CrankSensor_FA		
			The number of camshaft pulses received during 100 engine cycles	= 0 pulses	Crankshaft is synchronized  No DTC Active:	Test is Enabled  CrankSensor_FA	8 failures out of 10 samples  Continuous every engine cycle	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 SensorA	P0341	Diagnostic will fail if an incorrect number of cam sensor pulses are detected over a number of engine cycles and will pass if the number of cam pulses is correct.	The number of camshaft pulses received during 24 MEDRES events is OR (There are 24 MEDRES events per engine cycle)	< 4 pulses > 8 pulses	Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged	Test is Enabled  CrankSensor_FA	Continuous, every MEDRES event until test completes, one test at every start attempt	Type B, 2 Trips
			Test begins when MEDRES region AND accumulated number of MEDRES events	= region 5 >= 0 counts	No DTC Active:			
			The number of camshaft pulses received during 100 engine cycles OR	< 398 pulses > 402 pulses	Crankshaft is synchronized  No DTC Active:	Test is Enabled  CrankSensor_FA	8 failures out of 10 samples  Continuous every engine cycle	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT	P0351	Diagnoses Cylinder #1 Ignition Control (E8T) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 30 kQ impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0Volts	50 Failures  out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT	P0352	Diagnoses Cylinder #2 Ignition Control (E8T) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 30 kQ impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0Volts	50 Failures  out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT	P0353	Diagnoses Cylinder #3 Ignition Control (E8T) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 30 kQ impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT	P0354	Diagnoses Cylinder #4 Ignition Control (E8T) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 30 kQ impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #5 CIRCUIT	P0355	Diagnoses Cylinder #5 Ignition Control (E8T) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 30 kQ impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #6 CIRCUIT	P0356	Diagnoses Cylinder #6 Ignition Control (E8T) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 30 kQ impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #7 CIRCUIT	P0357	Diagnoses Cylinder #7 Ignition Control (E8T) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 30 kQ impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #8 CIRCUIT	P0358	Diagnoses Cylinder #8 Ignition Control (E8T) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 30 kQ impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420	<p>NOTE: The information below applies to applications that use the Decel Catalyst Monitor Algorithm</p> <p>Oxygen Storage. The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O<sub>2</sub> during lean A/F excursions to store the excess oxygen (Le. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H<sub>2</sub> to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Rich (intrusive rich) and Lean (decel fuel cutoff) A/F excursions</p> <p>Normalized Ratio OSC Value Calculation Information and Definitions =                      1. Raw OSC Calculation = (post cat O<sub>2</sub> Resp time - pre cat O<sub>2</sub> Resp time)                      2. BestFailing OSC value from a calibration</p>	Normalized Ratio OSC Value The EWMA calculation uses a 0.16 coefficient.	< 0.35	<p>Diagnostic is Enabled</p> <p>All enable criteria associated with P0420 can be found under P2270 - (O<sub>2</sub> Sensor Signal Stuck Lean Bank 1 Sensor 2)</p> <p>Rapid Step Response (RSR) feature will initiate multiple tests:</p> <p>If the difference between current EWMA value and the current OSC Normalized Ratio value is</p> <p>and the current OSC Normalized Ratio value is</p> <p>Maximum number of RSR tests to detect failure when RSR is enabled.</p> <p>MAF</p> <p>Predicted catalyst temperature</p> <p>Front O<sub>2</sub> Sensor or Front WRAF</p> <p>Rear O<sub>2</sub> Sensor</p> <p>General Enable Criteria</p> <p>In addition to the p-codes</p>	<p>&gt;0.60</p> <p>&lt;0.10</p> <p>9</p> <p>&gt; 3.00 g/s &lt; 25.00 g/s</p> <p>&lt; 900 ° C</p> <p>&gt;740.00 mV or &gt;1.08 EQR</p> <p>&gt;815.00 mV</p>	<p>1 test attempted per valid decel period</p> <p>Minimum of 1 test per trip</p> <p>Maximum of 3 tests per trip</p> <p>Frequency: Fueling Related : 12.5 ms</p> <p>OSC Measurements: 100 ms</p> <p>Temp Prediction: 12.5ms</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow)</p> <p>Normalized Ratio Calculation = (1-2) / (3-2)</p> <p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part.</p> <p>Refer to the <b>P0420_WorstPassingOSCTableBI</b> and <b>P0420_BestFailingOSCTableBI</b> in Supporting Tables tab for details</p> <p>The Catalyst Monitoring Test is completed during a decel fuel cutoff event. This fuel cutoff event occurs following a rich intrusive fueling event initiated by the 02 Sensor Signal Stuck Lean Bank 1 Sensor 2 test(P2270). Several conditions must be met in order to execute this test.</p> <p>Additional conditions and their related values</p>			<p>listed under P2270, the following DTC's shall also not be set:</p> <p>For switching 02 sensors:</p> <p>For WRAF 02 sensors:</p>	<p>O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA</p> <p>WRAF_Bank_1_FA WRAF_Bank_2_FA</p> <p><b>P0420_WorstPassingOSCTableBI</b></p> <p><b>P0420_BestFailingOSCTableBI</b></p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		are listed in the "Secondary Parameters" and "Enable Conditions" section of this document for P2270 (02 Sensor Signal Stuck Lean Bank 1 Sensor 2)						

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 2	P0430	<p>Note: The information below applies to applications that use the Decel Catalyst Monitor Algorithm</p> <p>Oxygen Storage. The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O<sub>2</sub> during lean A/F excursions to store the excess oxygen (Le. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H<sub>2</sub> to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Rich (intrusive rich) and Lean (decel fuel cutoff) A/F excursions</p> <p>Normalized Ratio OSC Value Calculation Information and Definitions =                      1. Raw OSC Calculation = (post cat O<sub>2</sub> Resp time - pre cat O<sub>2</sub> Resp time)                      2. BestFailing OSC value from a calibration</p>	<p>Normalized Ratio OSC Value                      The EWMA calculation uses a 0.16 coefficient.</p>	< 0.35	<p>Diagnostic is Enabled</p> <p>All enable criteria associated with P0430 can be found under P2272 - (O<sub>2</sub> Sensor Signal Stuck Lean Bank 2 Sensor 2)</p> <p>Rapid Step Response (RSR) feature will initiate multiple tests:</p> <p>If the difference between current EWMA value and the current OSC Normalized Ratio value is</p> <p>and the current OSC Normalized Ratio value is</p> <p>Maximum number of RSR tests to detect failure when RSR is enabled.</p> <p>MAF</p> <p>Predicted catalyst temperature</p> <p>Front O<sub>2</sub> Sensor or Front WRAF</p> <p>Rear O<sub>2</sub> Sensor</p> <p>General Enable Criteria</p> <p>In addition to the p-codes</p>	<p>&gt;0.60</p> <p>&lt;0.10</p> <p>9</p> <p>&gt; 3.00 g/s &lt; 25.00 g/s</p> <p>&lt;900 °C</p> <p>&gt;740.00 mV or &gt;1.08 EQR</p> <p>&gt; 815.00 mV</p>	<p>1 test attempted per valid decel period</p> <p>Minimum of 1 test per trip</p> <p>Maximum of 3 tests per trip</p> <p>Frequency: Fueling Related : 12.5 ms</p> <p>OSC Measurements: 100 ms</p> <p>Temp Prediction: 12.5ms</p>	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow)</p> <p>Normalized Ratio Calculation = (1-2) / (3-2)</p> <p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part.</p> <p>Refer to the <b>P0430_WorstPassingOSCTableB2</b> and <b>P0430_BestFailingOSCTableB2</b> in Supporting Tables tab for details</p> <p>The Catalyst Monitoring Test is completed during a decel fuel cutoff event. This fuel cutoff event occurs following a rich intrusive fueling event initiated by the 02 Sensor Signal Stuck Lean Bank 2 Sensor 2 test(P2272). Several conditions must be met in order to execute this test.</p> <p>Additional conditions and their related values</p>			<p>listed under P2272, the following DTC's shall also not be set:</p> <p>For switching 02 sensors:</p> <p>For WRAF 02 sensors:</p>	<p>O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA</p> <p>WRAF_Bank_1_FA WRAF_Bank_2_FA</p> <p><b>P0430_WorstPassingOSCTableB2</b></p> <p><b>P0430_BestFailingOSCTableB2</b></p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		are listed in the "Secondary Parameters" and "Enable Conditions" section of this document for P2272 (02 Sensor Signal Stuck Lean Bank 2 Sensor 2)						





24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>the pressure drops (-62) Pa from peak pressure, the vent is then opened for 60 seconds to normalize the system pressure. The vent is again closed to begin the vacuum portion of the test (phase-2). As the fuel temperature continues to fall, a vacuum will begin forming. The vacuum will continue until it reaches a vacuum peak. When the pressure rises 62 Pa from vacuum peak, the test then completes. If the key is turned on while the diagnostic test is in progress, the test will abort.</p>			<p>Ambient Temperature Using OAT Sensor to be Valid *****</p> <p>1. Startup OAT is less than previous trip EAT</p> <p>OR</p> <p>2. Startup ECT - previous trip EAT</p> <p>OR</p> <p>3. Engine off time</p> <p>OR</p> <p>4. At startup, time since previous EAT valid and able to learn</p> <p>OR</p> <p>5. EAT - current OAT</p> <p>OR</p> <p>6. EAT &lt; current OAT and speed timer and current OAT - EAT</p> <p>Speed timer increments at 100 msec rate and increments vary based on vehicle speed as follows:</p> <p>vehicle speed &lt; 10mph -0.2 seconds                      10 mph&lt;speed&lt; 35 mph 0.10 seconds                      35mph&lt;speed&lt;124 0.20 seconds                      124mph&lt;speed&lt; 124 0.20 seconds</p> <p>Speed timer can never be less than 0 seconds</p> <p>*****</p> <p>1. High Fuel Volatility</p>	<p>*****</p> <p>&lt;0 °C</p> <p>&gt; 9,000 seconds</p> <p>&lt; 3,600 seconds</p> <p>0 °C &lt; difference &lt; 2 °C</p> <p>&gt; 240 seconds</p> <p>&lt; 2 °C</p> <p>*****</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>During the volatility phase, pressure in the fuel tank is integrated vs. volatility time. If the integrated pressure is then test aborts and unsuccessful attempts is incremented. This value equates to an average integrated fuel tank pressure &gt; 1,245 Pa. Please see <b>P0442 Volatility Time as a Function of Estimate of Ambient Temperature</b> in Supporting Tables.</p> <p>OR</p> <p>2. Vacuum Refueling Detected</p> <p>See P0454 Fault Code for information on vacuum refueling algorithm.</p> <p>OR</p> <p>3. Fuel Level Refueling Detected</p> <p>See P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>4. Vacuum Out of Range and No Refueling</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for</p>	< -5		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>information on fuel level refueling.</p> <p>OR</p> <p>5. Vacuum Out of Range and Refueling Detected</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>6. Vent Valve Override Failed</p> <p>Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test</p> <p>OR</p> <p>7. Key up during EONV test</p> <p>No active DTCs:</p> <p>No Active DTCs TFTKO</p>	<p>0.50 seconds</p> <p>MAF_SensorFA ECT_Sensor_FA IAT_SensorFA VehicleSpeedSensor_FA ModuleOffTime_FA AmbientAirDefault FuelLevelDataFault</p> <p>P0443 P0446 P0449 P0452 P0453 P0455</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P0458 P0459 P0498 P0499 P0496 P1001 P1005 P11FF P130F U18A2		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Circuit (ODM)  (No ELCP - Conventional EVAP Diagnostic)	P0443	Controller specific output driver circuit diagnoses the canister purge solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 200 K Q impedance between output and controller ground.	Diagnostic is Enabled  Powertrain relay voltage	Voltage > 11.0 volts	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controlle rs P0458 may also set (Caniste r Purge Solenoid Short to Ground)

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent System Performance  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister.  This diagnostic runs with normal purge control and canister vent solenoid commanded open. The diagnostic fails when the FTP sensor vacuum measurement is above a vacuum threshold before it accumulates purge volume above a threshold. The diagnostic passes when it accumulates purge volume above a threshold before the FTP sensor vacuum measurement is above a vacuum threshold.	Vent Restriction Prep Test: Vented Vacuum for OR Vented Vacuum for  Vent Restriction Test: Tank Vacuum for before Purge Volume  After setting the DTC for the first time, 0 liters of fuel must be consumed before setting the DTC for the second time.	< -623 Pa 60 seconds  > 1,245 Pa 60 seconds  > 3,487 Pa 5 seconds > 12 liters	Diagnostic is Enabled  Fuel Level System Voltage Startup IAT Startup ECT BARO  No active DTCs:    No Active DTCs TFTKO	10 % < Percent < 90% > 10.0 volts 4 °C < Temperature < 35 °C < 35 °C > 70 kPa  MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited FuelLevelDataFault	Once per Cold Start  Time is dependent on driving conditions  Maximum time before test abort is 1,400 seconds	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM)  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0449	Controller specific output driver circuit diagnoses the vent solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	> 200 K Q impedance between output and controller ground	Diagnostic is Enabled  No active DTCs:	P1005 P130F U18A2	50 failures out of 63 samples  100 ms /sample	Type B, 2 Trips  Note: In certain controlle rs P0498 may also set (Vent Solenoid Short to Ground)



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Performance  (No ELCP - Conventional EVAP Diagnostic)	P0451	<p>The DTC will be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test.</p> <p>During the EONV test, the fuel tank vacuum sensor is re-zeroed. A re-zero occurs:                      1) At the transition from the volatility phase to the pressure phase.                      2) At the transition from the pressure phase to the vacuum phase.</p> <p>The re-zero test determines if the tank vacuum signal falls within a calibratable window about atmospheric pressure. If after some time, the tank vacuum signal does not fall to within the window, the re-zero test exits to the refueling rationality test.</p> <p>The refueling rationality test determines if a refueling event caused the re-zero problem. If so, the re-zero problem is ignored. If a refueling event is not</p>	<p>The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts)</p> <p>Upper voltage threshold (voltage addition above the nominal voltage)</p> <p>Lower voltage threshold (voltage subtraction below the nominal voltage)</p> <p>The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail).</p> <p>When EWMA is the DTC light is illuminated.</p> <p>The EWMA calculation uses a 0.20 weighting coefficient.</p> <p>The DTC light can be turned off if the EWMA is and stays below the</p>	<p>0.2 volts</p> <p>0.2 volts</p> <p>&gt; 0.73 (EWMA Fail Threshold),</p> <p>&lt;0.40 (EWMA Re-Pass Threshold)</p>	<p>This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes</p>		<p>This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.</p>	<p>Type A, 1 Trips</p> <p>EWMA</p> <p>Average run length: 6 Run length is 2 trips after code clear or non-volatile reset</p>

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>detected, then the results of the re-zero test are used to determine if there is a re-zero problem.</p> <p>1) An individual re-zero test generates a re-zero ratio. The ratio goes from 0.0 to 1.0.</p> <p>2) A 0.0 means that the re-zero pressure signal achieved exactly atmospheric pressure.</p> <p>3) A ratio of 1.0 means that the re-zero pressure did not get within the window.</p> <p>4) Re-zero pressure within the window generates values between 0.0 and 1.0.</p> <p>If a refueling event is not detected, then the resulting re-zero ratio is filtered using an exponentially weighted moving average (EWMA). When the EWMA exceeds a fail threshold, the vacuum re-zero test reports a failure. Once the vacuum re-zero test fails, the EWMA fall below a lower re-pass threshold before it can pass the vacuum re-zero test again.</p>	<p>EWMA fail threshold for 3 additional consecutive trips.</p>					

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0452	<p>This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too low out of range.</p> <p>The FTP sensor circuit out of range diagnostic compares the raw sensor voltage to a lower voltage threshold. It is an X out of Y diagnostic that runs continuously anytime the controller is awake.</p> <p>If the sensor voltage is below the lower voltage threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported for P0452 DTC. A pass is reported for P0452 DTC if the low sample counter reaches its threshold.</p>	<p>FTP sensor signal</p> <p>The normal operating range of the FTP sensor is 0.5 volts (-1245 Pa) to 4.5 volts (-3736 Pa).</p>	< 0.15 volts (3.0 % of Vref or -1,495 Pa)	No active DTC's:	P1001 P1005 U18A2	<p>640 failures out of 800 samples</p> <p>12.5 ms /sample</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit High Voltage  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0453	<p>This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too high out of range.</p> <p>The FTP sensor circuit out of range diagnostic compares the raw sensor voltage to an upper voltage threshold. It is an X out of Y diagnostic that runs continuously anytime the controller is awake.</p> <p>If the sensor voltage is above the upper voltage threshold, the high fail counter then increments. If the high fail counter reaches its threshold then a fail is reported for P0453 DTC. A pass is reported for P0453 DTC if the high sample counter reaches its threshold.</p>	<p>FTP sensor signal</p> <p>The normal operating range of the FTP sensor is 0.5 volts (-1245 Pa) to 4.5 volts (-3736 Pa).</p>	> 4.85 volts (97.0 % of Vref or -3,985 Pa)	No active DTCs:	P1001 P1005 U18A2	<p>640 failures out of 800 samples</p> <p>12.5 ms /sample</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Intermittent  (No ELCP - Conventional EVAP Diagnostic)	P0454	<p>This DTC will detect intermittent tank vacuum sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.</p> <p>During the EONV test, an abrupt change in fuel tank vacuum is identified as a possible refueling event. If the abrupt change occurs while the vent valve is closed, the EONV small-leak test aborts and the refueling rationality test starts.</p> <p>If the refueling rationality test detects a refueling event, then the vacuum change is considered "rational." If the refueling rationality test does not detect a refueling event, then the vacuum change is considered "irrational."</p> <p>The vacuum change rationality diagnostic is an "X out of Y" test.                      1) Each time the EONV test completes, the (Y) sample counter is incremented.                      2) Each time the</p>	<p>If an abrupt change in tank vacuum is detected the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that a refueling event occurred. If a refueling is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An abrupt change is defined as a change in vacuum in the span of 1.0 seconds. But in 12.5 msec. A refueling event is confirmed if the fuel level has a persistent change of for 30 seconds during a 600 second refueling rationality test.</p>	<p>&gt; 112 Pa                      &lt; 249 Pa                        &gt;10 %</p>	<p>This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes and the canister vent solenoid is closed</p>		<p>This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.</p> <p>12.5 ms /sample</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		rationality test has an irrational result; the (X) fail counter is incremented. 3) If the (X) fail counter reaches the fail limit before the (Y) sample counter reaches the sample limit, the vacuum change rationality test fails. 4) If the (Y) sample counter reaches the limit before the (X) fail counter fails, the vacuum change rationality test passes.						

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Large Leak Detected  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0455	<p>This DTC will detect a weak vacuum condition (large leak or purge blockage) in the EVAP system.</p> <p>This mode checks for large leaks and blockages when proper driving conditions are met. If these conditions are met, the diagnostic commands the vent valve closed and controls the purge duty cycle to allow purge flow to purge the fuel tank and canister system while monitoring the fuel tank vacuum level.</p> <p>The algorithm accumulates purge flow during the test to determine a displaced purge volume as the test proceeds.</p> <p>If the displaced purge volume reaches a threshold before the fuel tank vacuum level reaches its passing threshold, then a large leak failure is detected.</p> <p>On fuel systems with fuel caps</p> <p>If the first failure of</p>	<p>Purge volume while Tank vacuum</p> <p>After setting the DTC for the first time, 0 liters of fuel must be consumed before setting the DTC for the second time.</p> <p>Weak Vacuum Follow-up Test (fuel cap replacement test) Weak Vacuum Test failed.</p> <p>Passes if tank vacuum</p> <p>Note: Weak Vacuum Follow-up Test can only report a pass.</p>	<p>&gt;60 liters</p> <p>&lt; 2,740 Pa</p> <p>&gt; 2,740 Pa</p>	<p>Diagnostic is Enabled</p> <p>Fuel Level System Voltage BARO Purge Flow</p> <p>No active DTCs:</p> <p>No Active DTCs TFTKO</p> <p>If ECT &gt; IAT, Startup temperature delta (ECT-IAT): Startup IAT Startup ECT</p> <p>Weak Vacuum Follow-up Test This test can run following</p>	<p>10% &lt; Percent &lt; 90 % &gt; 10.0 volts &gt;70 kPa &gt;2.50%</p> <p>MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited FuelLevelDataFault</p> <p>P0443 P0449 P0452 P0453 P0454 P0458 P0459 P0498 P0499 P1001 P1005 P11FF P130F U18A2</p> <p>&lt;8 °C 4 °C&lt;Temperature&lt;35 °C &lt;35 °C</p>	<p>Once per cold start</p> <p>Time is dependent on driving conditions</p> <p>Maximum time before test abort is 1,400 seconds</p> <p>Weak Vacuum Follow-up Test</p> <p>With large leak detected, the follow-up test is limited to 1,300 seconds. Once the MIL is on, the follow-up test runs indefinitely.</p>	Type B, 2 Trips

240BDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>P0455 occurred after a refueling event was detected and the MIL is off for P0455, the MIL will be commanded off after the first pass of P0455 is reported. If the first failure of P0455 did not occur after a refueling event was detected, the MIL will be commanded off on the ignition cycle after the third consecutive pass of P0455 is reported.the MIL will be commanded off on the ignition cycle after the third consecutive pass of P0455 is reported.</p> <p>On fuel systems without fuel caps</p> <p>The P0455 MIL will be commanded off on the ignition cycle after the third consecutive pass of P0455 is reported.</p>			<p>a weak vacuum failure or on a hot restart.</p>			



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit Low  (No ELCP - Conventional EVAP Diagnostic)	P0458	Controller specific output driver circuit diagnoses the canister purge solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 0.5 Q impedance between output and controller ground	Diagnostic is Enabled  Powertrain relay voltage	Voltage > 11.0 volts	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controlle rs P0443 may also set (Caniste r Purge Solenoid Open Circuit)

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit High  (No ELCP - Conventional EVAP Diagnostic)	P0459	Controller specific output driver circuit diagnoses the canister purge solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 0.5 Q impedance between output and controller power	Diagnostic is Enabled  Powertrain relay voltage	Voltage > 11.0 volts	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance  (For use on vehicles with a single fuel tank)	P0461	This DTC will detect a primary fuel tank level sensor stuck in-range.	a) Sensed fuel volume change is b) while engine fuel consumption is	a) < 5 liters  b) > 35.69 liters	1. Diagnostic Enabled  2. Engine Operational State	1. == True  2. == Running	250 ms / sample	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Low Voltage (For use on vehicles with a fuel float connected to an FTZM)	P0462	This DTC will detect a primary fuel tank sensor out-of-range low.	Fuel level Sender % of 5V range	<10%	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	40 failures out of 50 samples  250 ms / sample	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit High Voltage (For use on vehicles with a fuel float connected to an FTZM)	P0463	This DTC will detect a primary fuel tank level sensor out-of-range high.	Fuel level Sender % of 5V range	> 60 %	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	40 failures out of 50 samples  250 ms / sample	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Intermittent  (No ELCP - Conventional EVAP Diagnostic)	P0464	<p>This DTC will detect intermittent fuel level sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.</p> <p>During the EONV test, a change in fuel level is identified as a possible refueling event. If the change occurs while the vent valve is closed, the EONV small-leak test aborts and the refueling rationality test starts.</p> <p>If the refueling rationality test detects a refueling event, the fuel level change is considered "rational." If the refueling rationality test does not detect refueling, the fuel level change is considered "irrational."</p> <p>The fuel level change rationality diagnostic is an "X out of Y" test.                      1) Each time the EONV test completes, the (Y) sample counter is incremented.                      2) Each time the rationality test has an</p>	<p>If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, if a refueling event is not confirmed, then the test sample is considered failing which indicates an intermittent signal problem.</p> <p>An intermittent fuel level signal problem is defined as:                      The fuel level changes by &gt; 10% and does not remain &gt; 10% for 30 seconds during a 600 second refueling rationality test.</p>	> 10% > 10%	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		<p>This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.</p> <p>100 ms /sample</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		irrational result; the (X) fail counter is incremented. 3) If the (X) fail counter reaches the fail limit before the (Y) sample counter reaches the sample limit, the fuel level change rationality test fails. 4) If the (Y) sample counter reaches the limit before the (X) fail counter fails, the fuel level change rationality test passes.						

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Flow During Non- Purge  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0496	<p>This DTC will determine if the purge solenoid is leaking to engine manifold vacuum.</p> <p>This test checks for purge valve leaks to intake manifold vacuum such that there would always be a small amount of purge flow present. It does this by sealing the EVAP system (purge and vent valve closed) and then monitors fuel tank vacuum level. The fuel tank vacuum level should not increase. If tank vacuum increases above a threshold, a malfunction is indicated.</p> <p>Additional Information</p> <p>This diagnostic test detects purge valve leaks to intake manifold vacuum. It is not intended to detect purge valve leaks to the atmosphere which are monitored by the EONV small leak diagnostic (P0442).</p> <p>The purge valve leak diagnostic exists to help service replace</p>	<p>Tank Vacuum for</p> <p>Test time</p>	<p>&gt; 2,491 Pa 5 seconds</p> <p>&lt; refer to <b>P0496 Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level</b> in Supporting Tables.</p> <p>Test time only increments when engine vacuum &gt; 10.0 kPa.</p>	<p>Diagnostic is Enabled</p> <p>Fuel Level System Voltage BARO Startup IAT</p> <p>Startup ECT Engine Off Time</p> <p>No active DTCs:</p> <p>No Active DTCs TFTKO</p>	<p>10% &lt; Percent &lt; 90 % &gt; 10.0 volts &gt;70 kPa 4 °C&lt;Temperature&lt;35 °C</p> <p>&lt;35 °C &gt;28,800.0 seconds</p> <p>MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited FuelLevelDataFault</p> <p>P0443 P0449 P0452 P0453 P0454 P0458 P0459 P0498 P0499 P1001 P1005 P11FF P130F U18A2</p>	<p>Once per cold start</p> <p>Cold start: max time is 1,400 seconds</p>	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		leaking purge valves that could otherwise be detected with the EONV small leak diagnostic (P0442).						

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit Low  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0498	Controller specific output driver circuit diagnoses the vent solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 0.5 Q impedance between output and controller ground	Diagnostic is Enabled  No active DTC's:	P1005 P130F U18A2	50 failures out of 63 samples  100 ms /sample	Type B, 2 Trips  Note: In certain controlle rs P0449 may also set (Vent Solenoid Open Circuit)

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit High  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0499	Controller specific output driver circuit diagnoses the vent solenoid low sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.  If the P0499 is active, an intrusive test is performed with the vent solenoid commanded closed for 15 seconds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 0.5 Q impedance between output and controller power	Diagnostic is Enabled  No active DTC's:	P1005 P130F U18A2	50 failures out of 63 samples  100 ms /sample	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Low Engine Speed Idle System	P0506	This DTC indicates that actual engine speed is lower than desired engine speed at idle so that it is out of speed control capability. Testing is performed when basic conditions are met. If filtered engine speed error exceeds a calibrated threshold for a calibrated duration, code is set. This testing is performed continuously per trip if basic conditions are met	Filtered Engine Speed Error. It is calculated with a calibrated filter coefficient  Filter coefficient	> 91.00 rpm  0.00300	Baro  Coolant Temp  Engine run time Ignition voltage Time since gear change  Time since a TCC mode change  IAT Vehicle speed Commanded RPM delta Idle time  For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa  > 60 °C  > 30 sec 32 > volts > 11  > 3 sec  > 3 sec  > -20 °C < 1.24 mph, 2kph < 25 rpm > 10 sec  > 90.00 pct or < 16.00 pct  PTC not active  Transfer Case not in 4WD LowState	Diagnostic runs in every 12.5 ms loop  Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	Off-vehicle device control (service bay control) must not be active.  following conditions not TRUE: (VeTESR_e_EngSpdReqLimitType = CeTESR_e_EngSpdMinLimitAND VeTESR_e_EngSpdReqRespType = CeTESR_e_NoSuggestion)  Clutch is not depressed  TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit.FA EGRValvePerformance_FA IAT_SensorCircuitFA EvapFlowDuringNonPurge_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_FA IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFault LowFuelConditionDiagnostic Clutch Sensor FA AmbPresDfltStatus		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	P2771  > 10 sec  The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Engine Speed Idle System	P0507	This DTC indicates that actual engine speed is higher than desired engine speed at idle so that it is out of speed control capability. Testing is performed when basic conditions are met. If filtered engine speed error exceeds a calibrated threshold for a calibrated duration, code is set. This testing is performed continuously per trip if basic conditions are met	Filtered Engine Speed Error. It is calculated with a calibrated filter coefficient  Filter coefficient	< -182.00 rpm  0.00300	Baro  Coolant Temp  Engine run time  Ignition voltage  Time since gear change  Time since a TCC mode change  IAT  Vehicle speed  Commanded RPM delta  For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa  > 60 °C  > 30 sec  32 > volts > 11  > 3 sec  > 3 sec  > -20 °C  < 1.24 mph, 2kph  < 25 rpm   > 90.00 pct or < 16.00 pct  PTC not active  Transfer Case not in 4WD LowState  Off-vehicle device control (service bay control) must not be active.	Diagnostic runs in every 12.5 ms loop  Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips





24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					for Idle time	The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

24OBDG06B HD ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Performance - Two Stage Oil Pump	P0521	<p>Determines if the Engine Oil Pressure (EOP) Sensor is stuck or biased in range. The engine oil pressure is compared against thresholds when engine is running and when engine is off. The engine oil pressure rationality diagnostic has two parts: engine running test and engine off test.</p> <p>The engine running test compares the measured oil pressure to threshold. If the measured oil pressure is out of the thresholds, then the error counter increments. The engine off test compares the measured oil pressure against thresholds after the engine has stopped rotating. If the measured oil pressure is out of the thresholds, then the error counter increments.</p>	<p><b>Two Stage Oil Pump EOP Sensor Test with Engine Running, High Pressure State</b></p> <p><u>To Fail when previously passing with the engine running:</u></p> <p>Filtered Engine Oil Pressure below expected threshold</p> <p>OR</p> <p>Filtered Engine Oil Pressure above expected threshold</p> <p><u>To pass when previously failing:</u></p> <p>Filtered Engine Oil Pressure above low threshold plus an offset</p> <p>OR</p>	<p>Filtered Oil Pressure &lt; ( P0521_P06DD_P06DE_OP_HiStatePressure * 1.00 - 133.0 kPa)</p> <p>OR</p> <p>Filtered Oil Pressure &gt; ( P0521_P06DD_P06DE_OP_HiStatePressure * 1.00 + 180.0 kPa)</p> <p>OR</p> <p>Filtered Oil Pressure &gt; ( P0521_P06DD_P06DE_OP_HiStatePressure * 1.00 - 133.0 kPa + 10.0 kPa)</p> <p>OR</p> <p>Filtered Oil Pressure &lt; (</p>	<p>Two Stage Oil Pump is Present = TRUE</p> <p>Pump is in high pressure state</p> <p>Engine Running Diagnostic Status</p> <p>Engine Off Rationality Test Diagnostic Reporting Status</p> <p>Oil Pressure Sensor In Use</p> <p>Engine Running</p> <p>Ambient Air Pressure</p> <p>Oil Aeration (= TRUE if engine speed &gt; 8,000 RPM for longer than 30.0 seconds)</p> <p>Filtered Engine Speed within range</p> <p>Modelled Oil Temperature within range</p> <p>Pump state change complete</p> <p>No active DTC's</p>	<p>TRUE</p> <p>Enabled</p> <p>Test not report a fail state</p> <p>Yes</p> <p>&gt;30.0 seconds</p> <p>&gt;70.0 kPa</p> <p>FALSE</p> <p>1,000 RPM &lt; Filtered Engine Speed &lt; 4,500 RPM</p> <p>40.0 deg C &lt; Modelled Oil Temperature &lt; 100.0 degC</p> <p>Time since state change &gt; 0.50 s</p> <p>Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA</p>	<p>&gt; 40 errors out of 50 samples.</p> <p>Performed every 100 msec</p> <p>&gt; 10passes out of 50 samples.</p> <p>Performed every 100 msec</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Engine Oil Pressure below high threshold minus an offset	<b>P0521_P06DD_P06DE_OP_HiStatePressure</b> * 1.00 + 180.0 kPa - 10.0 kPa)  (Details on Supporting Tables Tab: <b>P0521_P06DD_P06DE_OP_HiStatePressure</b> )		EngOilPressureSensorCkt FA AmbientAirDefault EngOilTempFA CrankSensor_FA		
			<b>Two Stage Oil Pump EOP Sensor Test with Engine Running, Low Pressure State</b>  <u>To Fail when previously passing with the engine running:</u>  Filtered Engine Oil Pressure below expected threshold  OR  Filtered Engine Oil Pressure above expected threshold	Filtered Oil Pressure < ( <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> * 1.00 - 133.0 kPa)  OR  Filtered Oil Pressure > ( <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> * 1.00 + 180.0 kPa)	Two Stage Oil Pump is Present = TRUE  Pump is in low pressure state  Engine Running Diagnostic Status  Engine Off Rationality Test Diagnostic Reporting Status  Oil Pressure Sensor In Use  Engine Running  Ambient Air Pressure  Oil Aeration (= TRUE if engine speed > 8,000 RPM for longer than 30.0 seconds)  Filtered Engine Speed within range	TRUE  Enabled  Test not report a fail state  Yes  >30.0 seconds  >70.0 kPa  FALSE  1,000 RPM < Filtered Engine Speed < 4,500 RPM	> 40 errors out of 50 samples.  Performed every 100 msec	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p><u>To pass when previously failing:</u></p> <p>Filtered Engine Oil Pressure above low threshold plus an offset</p> <p>OR</p> <p>Filtered Engine Oil Pressure below high threshold minus an offset</p>	<p>Filtered Oil Pressure &gt; ( <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> * 1.00 - 133.0 kPa + 10.0 kPa)</p> <p>OR</p> <p>Filtered Oil Pressure &lt; ( <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> * 1.00 + 180.0 kPa - 10.0 kPa)</p> <p>(Details on Supporting Tables Tab: <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> )</p>	<p>Modelled Oil Temperature within range</p> <p>Pump state change complete</p> <p>No active DTC's</p>	<p>40.0 deg C &lt; Modelled Oil Temperature &lt; 100.0 deg C</p> <p>Time since state change &gt; 0.50 s</p> <p>Time since state change &gt; Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA EngOilPressureSensorCktFA AmbientAirDefault EngOilTempFA CrankSensor_FA</p>	<p>&gt; 10passes out of 50 samples.</p> <p>Performed every 100 msec</p>	
			<p><b>Two Stage Oil Pump EOP Sensor Test with Engine Off</b></p> <p>If enabled:</p> <p><u>To Fail when previously passing with the engine off:</u></p> <p>Filtered Engine Oil Pressure greater than threshold</p>	<p>Filtered Oil Pressure &gt; 40.0 kPa</p>	<p>Two Stage Oil Pump is Present = TRUE</p> <p>Engine Off Rationality Test Diagnostic Status</p> <p>Engine Running Rationality Test Diagnostic Status</p> <p>Modelled Oil Temperature No Engine Movement No active DTC's</p>	<p>TRUE</p> <p>Enabled</p> <p>Test not report a fail state</p> <p>&gt; 40.0 deg C &gt; 10.0 seconds EngineModeNotRunTimer_FA EngOilTempFA</p>	<p>&gt; 20 errors out of 40 samples.</p> <p>Run once per trip</p>	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngOilPressureSensorCkt FA CrankSensor_FA		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Circuit Low Voltage	P0522	Determines if the Engine Oil Pressure (EOP) Sensor circuit voltage is too low. This diagnostic compares the EOP circuit voltage to the reference voltage.	(Engine Oil Pressure Sensor Circuit Voltage) - 5 Volts) *100	< 5.00 percent  Deadband: < 5 percent or > 95 percent	Engine Speed Enable Engine Speed Disable  Oil Pressure Sensor In Use  Diagnostic Status	> 400 rpm < 350 rpm  Yes  Enabled	1,280 failures out of 1,600 samples  Performed every 3.125 msec	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Circuit High Voltage	P0523	Determines if the Engine Oil Pressure (EOP) Sensor circuit voltage is too high. This diagnostic compares the EOP circuit voltage to the reference voltage.	(Engine Oil Pressure Sensor Circuit Voltage) - 5 Volts) *100	> 95.00 percent  Deadband: < 5 percent or > 95 percent	Oil Pressure Sensor In Use  Diagnostic Status	Yes  Enabled	1,280 failures out of 1,600 samples Performed every 3.125 msec	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage Low	P0562	Detects a low 12V battery system. This diagnostic reports the DTC when battery voltage is low. Monitoring occurs when the engine speed is above a calibrated value.	System voltage low	Battery voltage <= 9.00	System voltage low diag enable = TRUE  Run Crank voltage  Engine speed >=	1.00  Voltage >5.00 volts  400.00	400 failures out of 500 samples  12.5 ms /sample	Type C, 1 Trip No MIL Emissions Neutral



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage High	P0563	Detects a high 12V battery system. This diagnostic reports the DTC when battery voltage is high.	System voltage high	Battery voltage >= 18.00	System voltage high diag enable = TRUE  Run Crank voltage	1.00  Voltage >5.00 volts	400 failures out of 500 samples  12.5 ms /sample	Type C, 1 Trip No MIL Emissions Neutral

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Resume Circuit Legacy	P0567	<p>Detects a failure of the cruise resume switch in a continuously applied state</p> <p>"Emissions Neutral Default Action : When the BCM tells the ECM that the cruise control analog input voltage is in the Resume range for too long, the code is set and cruise control is disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."</p>	Cruise Control Resume switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 89.000 seconds	<p>Diagnostic is enabled.</p> <p>CAN cruise switch diagnostic enable in ECM</p>	1.00	fail continuously for greater than 89.00 seconds	Type C, 1 Trip No MIL Emissions Neutral, "Emissions Neutral Diagnostics - special type C"

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Set Circuit Legacy	P0568	<p>Detects a failure of the cruise set switch in a continuously applied state</p> <p>"Emissions Neutral Default Action : When the BCM tells the ECM that the cruise control analog input voltage is in the Set range for too long, the code is set and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."</p>	Cruise Control Set switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 89.000 seconds	<p>Diagnostic is enabled.</p> <p>CAN cruise switch diagnostic enable in ECM</p>	1.00	fail continuously for greater than 89.00 seconds	Type C, 1 Trip No MIL Emissions Neutral, "Emissions Neutral Diagnostics - special type C"



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Range/ Performance	P057B	This diagnostic monitors the Brake Pedal Position Sensor for a stuck in range failure	Brake pedal position sensor movement diagnostic cal is enabled 1.00	True	Diagnostic is enabled.  Brake Pedal Position Sensor Circuit Range / Performance Diagnostic Enable	1.00  ignition voltage > 10.00		MIL: Type A, 1 Trips
			Calculated EWMA value must be greater than calibratable threshold after calibratable number of tests have completed to report a "test passed" for P057B	EWMA value looked up in supporting table <b>P057B</b> <b>KtBRKI_K_FastTestPointWeight</b> P057B as a function of calculated brake pedal position delta EWMA value is > 0.80	calculated brake pedal position delta sample counter > 50.00 for fast test  OR calculated brake pedal position delta sample counter > 1,000.00 for slow test	calculated brake pedal position delta > 2.63  OR (for slow test) shift lever has been in park once this key cycle vehicle speed >= 6.00 accelerator pedal position < 5.00	total number of EWMA tests > 20.00	
			Calculated EWMA Value must be less than calibratable threshold after calibratable number of tests have completed to report a "test failed" for P057B. This test runs once per key cycle	EWMA value looked up in supporting table <b>P057B</b> <b>KtBRKI_K_CmpltTestPointweight</b> P057B as a function of calculated brake pedal position delta EWMA value is less than 0.40	no DTC's active (P057C, P057D)	shift lever has been in park once this key cycle vehicle speed >= 6.00 accelerator pedal position < 5.00	total number of EWMA tests > 2.00	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Low	P057C	detects short to ground for brake pedal position sensor	If x of y samples are observed below failure threshold, default brake pedal position to zero percent and set DTC.	5.00	Diagnostic is enabled.  Brake Pedal Position Sensor Low Voltage Diagnostic Enable	1.00	20.00 / 32.00 counts	MIL: Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit High	P057D	detects open circuit for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	95.00	Diagnostic is enabled.  Brake Pedal Position Sensore High Voltage Diagnostic Enable	1.00	20.00/  32.00 counts	MIL: Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Intermittent/ Erratic	P057E	detects noisy / erratic ouput for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	25.00	Diagnostic is enabled.  Brake Pedal Position Sensor Circuit Intermittent / Erratic Diagnostic Enable	1.00	5.00/  20.00 counts	MIL: Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5.00 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
				In all cases, the failure count is cleared when controller shuts down				

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the ECU is a service part that has not been programmed.	Service (reflash) controller calibration present	= 1		none	Diagnostic runs at powerup and once per second continuously after that	Type A, 1 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM Long Term Memory Reset	P0603	This DTC detects an invalid NVM which includes a Static NVM, Perserved NVM, ECC ROM in NVM Flash Region, and Perserved NVM during shut down.	Static NVM region error detected during initialization				Diagnostic runs at controller power up.	Type A, 1 Trips
			Perserved NVM region error detected during initialization				Diagnostic runs at controller power up.	
			Perserved NVM region error detected during shut down.				Diagnostic runs at controller power down.	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604	Indicates that the ECM has detected a RAM fault. This includes Primary Processor System RAM Fault, Primary Processor Cache RAM Fault, Primary Processor TPU RAM Fault, Primary Processor Update Dual Store RAM Fault, Primary Processor Write Protected RAM Fault, and Secondary Processor RAM Fault. This diagnostic runs continuously.	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips
			Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.47272 s			When dual store updates occur.	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	65,534 counts			Diagnostic runs continuously (background loop)	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault. These include diagnostics done on the SPI Communication as well as a host of diagnostics for both the primary and secondary processors.	Time new seed not received exceeded			always running	0.450 seconds	Type A, 1 Trips
			MAIN processor receives seed in wrong order			always running	3 / 18 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the MAIN processor's ALU check			Test is Enabled: 1 (If 0, this test is disabled)	25 ms	
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			Test is Enabled: 1 (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	3.00		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		Test is Enabled: 1 (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occurred since last controller initialization.	3 (results in MIL), 5 (results in MIL and remedial action)		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Counter >=					
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to write flash to RAMvariable, depends on length of time to write flash to RAM	
			MAIN processor DMA transfer from Flash to RAM has 1 failure			Test is Enabled: 0 (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	
			Safety critical software is not executed in proper order.	>= 1 incorrect sequence.		Test is Enabled: 1 (If 0, this test is disabled)	Fail Table, f(Loop Time). See supporting tables: <b>P0606.PSW Sequence Fail f (Loop Time)</b> /  Sample Table, f (Loop Time)See supporting tables: <b>P0606_PSW Sequence Sample f(Loop Time)</b>  counts  50 ms/count in the ECM main processor.	



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			MAIN processor determines a seed has not changed within a specified time period within the 50ms task.	Previous seed value equals current seed value.		KePISD_b_SeedUpdKey StorFltEnbl == 1 Value of KePISD_b_SeedUpdKey StorFltEnbl is: 1. (If 0, this test is disabled)	Table, f(Loop Time). See supporting tables: <b>P0606_Last Seed Timeout f (Loop Time)</b>	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Performance	P0607	Indicates that the ECM has detected an internal processor integrity performance.	Performs the failure diagnostic for the offline and online BIST results.			Test is Enabled: 1 .  (If 0, this test is disabled)	5 counts  background task/ count in the ECM main processor	Type A, 1 Trips
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		Test is Enabled: 1 . (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		Test is Enabled: 1 . (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM variable, depends on length of time to write flash to RAM	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ANDRADC Fault	P060B	Indicates that the ECM has detected an ANDRADC Fault.	Resistance deviation percent >	6.00 %	Run/Crank Voltage >	7.00 V	2/ 14 counts or 1.75 seconds continuous; 250 ms/count in the ECM main processor	Type A, 1 Trips
			Resistance deviation percent >	6.00 %	Run/Crank Voltage >	7.00 V	2/ 14 counts or 1.75 seconds continuous; 250 ms/count in the ECM main processor	
			Resistance deviation percent >	6.00 %	Run/Crank Voltage >	7.00 V	2/ 14 counts or 1.75 seconds continuous; 250 ms/count in the ECM main processor	
			Resistance deviation percent >	6.00 %	Run/Crank Voltage >	7.00 V	2/ 14 counts or 1.75 seconds continuous; 250 ms/count in the ECM main processor	
			Resistance deviation percent >	6.00 %	Run/Crank Voltage >	7.00 V	2/ 14 counts or 1.75 seconds continuous; 250 ms/count in the ECM main processor	
			Resistance deviation percent >	6.00 %	Run/Crank Voltage >	7.00 V	2/ 14 counts or 1.75 seconds continuous; 250 ms/count in the ECM main processor	
			Resistance deviation	6.00 %	Run/Crank Voltage >	7.00 V	2/ 14 counts or	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			percent >				1.75 seconds continuous; 250 ms/count in the ECM main processor	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Main Processor Performance (Gasoline applications ONLY)	P060C	<p>Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures</p> <p>For all of the following cases: If the individual diagnostic threshold is equal to 2048 ms, this individual case is not applicable. If any of the following cases are X out of Y diagnostics and the fail (x) is greater than the sample (Y), this individual case is also not applicable.</p>	Equivalence Ratio torque compensation exceeds threshold	-288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	Type A, 1 Trips
			Absolute difference between Equivalence Ratio torque compensation and its dual store out of bounds given by threshold	288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	199.58 mg	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	15.00 degrees		Engine speed >0rpm	Up/down timer 427 ms continuous, 0.5 down time multiplier	
			Torque Learn offset is out of bounds given by threshold range	High Threshold  0.00 Nm  Low Threshold  0.00	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Nm				
			One step ahead calculation of air-per-cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed > 550 rpm	Up/down timer 462 ms continuous, 0.5 down time multiplier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 3,154.80 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 3,154.80 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Arbitrated Air-Per-Cylinder filter coefficient is out of bounds given by threshold range	High Threshold 1.000  Low Threshold 0.074	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Launch spark is active but the launch spark redundant path indicates it should not be active	N/A		Engine speed < 7,900.00 or 8,000.00 rpm (hysteresis pair)	Up/down timer 162 ms continuous, 0.5 down time multiplier	
			Rate limited vehicle speed and its dual store do not equal	N/A		Time since first CAN message with vehicle speed >= 0.500 sec	10/40 counts; 25.0msec/count	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded engine torque due to fast actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to slow actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			TOS to wheel speed conversion factor is out of bounds given by threshold range	High Threshold: 1.10 T/C Range Hi  0.10 T/C Range Lo  Low Threshold: 1.10 T/C Range Hi  0.10 T/C Range Lo	Ignition State	Accessory, run or crank	255/6 counts; 25.0msec/count	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cylinders active greater than commanded	5 cylinders		Engine run flag = TRUE > 2.00 s Number of cylinder events since engine run > 24  No fuel injector faults active	Up/down timer 462 ms continuous, 0.5 down time multiplier	
			Driver progression mode and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Predicted torque for uncorrected zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). <b>P060C_Speed Control External Load f(Oil Temp, RPM) +</b> 288.00	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Nm				
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	287.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	287.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Positive Torque Offset is greater than its redundant calculation plus threshold  OR  Positive Torque Offset is less than its redundant calculation minus threshold	288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, down time multiplier 0.5	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Hybrid Immediate Crankshaft Request is less than its redundant calculation minus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Regeneration Brake Assist is not within a specified range	Brake Regen Assist < 0 Nm or Brake Regen Assist > 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Cylinder Torque Offset exceeds step size threshold  OR  2. Sum of Cylinder Torque Offset exceeds sum threshold	1. 288.00 Nm  2. 288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Speed Lores Intake Firing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than Orpm	Up/down timer 162 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing timing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than Orpm	Up/down timer 162 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: <b>P060C_Speed Control External Load f(Oil Temp, RPM) + 288.00 Nm</b>	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: <b>P060C_Speed Control External Load f(Oil Temp, RPM) +</b> 288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Difference between Driver Requested Immediate Torque primary path and its secondary exceeds threshold	3,154.80 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Driver Immediate Request is less than its redundant calculation minus threshold	3,154.80 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Immediate Request is greater than its redundant calculation plus threshold  OR  Commanded Immediate Request is less than its redundant calculation minus threshold	3,154.80 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Response Type is set to Inactive	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Difference between Cruise Axle Torque Arbitrated Request and	118.31 Nm		Cruise has been engaged for more than 4.00	Up/down timer 2,048 ms continuous.	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cruise Axle Torque Request exceeds threshold			seconds	0.5 down time multiplier	
			Desired engine torque request greater than redundant calculation plus threshold	287.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Engine min capacity above threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 69 ms continuous, 0.5 down time multiplier	
			No fast unmanaged retarded spark above the applied spark plus the threshold	15.00 Degree		Engine speed greater than Orpm	Up/down timer 427 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s	Ignition State	Accessory, run or crank	Up/down timer 91 ms continuous, 0.5 down time multiplier	
			1. Absolute difference of redundant calculated engine speed above threshold	500 RPM		Engine speed greater than 0 RPM	Up/down timer 162 ms continuous, 0.5 down time multiplier	
			After throttle blade pressure and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Speed Control's Predicted Torque Request and its dual store	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous,	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			do not match				0.5 down time multiplier	
			Engine oil temperature and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 220 ms continuous, 0.5 down time multiplier	
			Desired throttle position greater than redundant calculation plus threshold	10.00 percent	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	0.06 kpa	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Throttle desired torque above desired torque plus threshold	288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of Final Torque feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	High Threshold 288.00 Nm  Low Threshold -288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of torque model coefficients and its redundant calculation is out of bounds given by threshold range	High Threshold 0.0003013 Low Threshold -0.0003013	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 288.00 Nm  Low Threshold -288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 288.00 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			AC friction torque is	High Threshold	Ignition State	Accessory, run or crank	Up/down timer	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			greater than commanded by AC control software or less than threshold limit	60.00 Nm  Low Threshold  0.00 Nm			475 ms continuous, 0.5 down time multiplier	
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 288.00 Nm  Low Threshold -288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Generator friction torque is out of bounds given by threshold range	High Threshold 288.00 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between the Supercharger friction torque and its redundant calculation greater than threshold	288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Filtered Torque error magnitude or its increase rate of change is out of allowable range or its dual store copy do not match	High Threshold 288.00 Nm  Low Threshold -288.00 Nm  Rate of change threshold		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				18.00 Nm/loop				
			Torque error compensation is out of bounds given by threshold range	High Threshold 288.00 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Delta Torque Baro compensation is out of bounds given by threshold range	High Threshold 13.14 Nm  Low Threshold -19.80 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Difference of reserve torque value and its redundant calculation exceed threshold  OR  2. Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation exceed threshold  OR  3. Rate of change of reserve torque exceeds threshold, increasing direction only  OR  4. Reserve engine torque above allowable capacity threshold	1. 287.00 Nm  2. N/A  3. 287.00 Nm  4. 287.00 Nm	3. & 4.: Ignition State	1. & 2.: Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 288.00 Nm  3. & 4.: Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Engine Vacuum and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the	Table. ffDesired		Enoine soeed >0rom	Uo/down timer	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			calculated Intake Manifold Pressure during engine event versus during time event is greater than threshold	Engine Torque). See supporting tables: <b>P060C_Delta MAP Threshold f(Desired Engine Torque)</b>			162 ms continuous, 0.5 down time multiplier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Driver Predicted Request is greater than its redundant calculation plus threshold  OR  Driver Predicted Request is less than its redundant calculation minus threshold	3,154.80 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cold Delta Friction Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Predicted torque for zero pedal determination is greater than calculated limit.	Table, f(Oil Temp, RPM). See supporting tables: <b>Speed Control External Load f(Oil Temp, RPM) + 288.00 Nm</b>	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Axle Torque and its dual store do not match	1 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Steady State Estimated	N/A		AFM not changing from	Up/down timer	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Torque and its dual store are not equal			Active to Inactive and preload torque not changing and one loop after React command  Engine speed >0rpm	2,048 ms continuous, 0.5 down time multiplier	
			Difference of Weighting factor for number of cylinders fueled and its redundant calculation is above threshold	0.26		Engine run flag = TRUE > 10.00 s	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference of minimum spark advance limit and its redundant calculation is out of bounds given by threshold range	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 162 ms continuous, 0.5 down time multiplier	
			Difference of commanded spark advance and adjusted delivered is out of bounds aiven bv	15.00 degrees		Engine speed >0rpm	Up/down timer 427 ms continuous, 0.5	



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			threshold range				down time multiplier	
			Absolute difference between Estimated Engine Torque and its dual store are above a threshold	288.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold	288.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	15.00 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 288.00 Nm	Up/down timer 462 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range	288 Nm		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			One step ahead calculation of air-per-cylinder greater than two step ahead calculation by threshold for time	Threshold: Dynamically calculated based on current engine conditions Fault Pending Threshold: 100 ms		Engine speed > 550 rpm	Up/down timer 462 ms continuous, 0.5 down time multiplier	
			Rate limited cruise axle torque request and its dual store do not match within a threshold	118.31 Nm	Ignition State	Accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			1. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its redundant calculation is out of bounds given by threshold range  OR  2. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its dual store do not equal  OR  3. Absolute difference of Calculated accelerator pedal position and its dual store do not equal	1. 3.50 %  2. N/A  3. N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded axle torque is greater than its redundant calculation by threshold	3,154.80 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded axle torque is less than its redundant calculation by threshold	4,732.20 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Preload timer and its redundant calculation do not equal	N/A	Ignition State	Accessory, run or crank  AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			AC friction torque is greater than commanded by AC control software	60.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Speed Lores Intake Firing (time based) calculation does not equal its redundant calculation	N/A		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated spark offset for equivalence ratio and its redundant calculation is greater than a threshold	15.00 degrees		Engine speed >0rpm	Up/down timer 162 ms continuous, 0.5 down time multiplier	
			Transmission Torque Request calculations do not equal their dual stores	N/A		Run or Crank = TRUE > 0.50 s	16/32 counts; 25.0msec/count	
			Absolute difference of the predicted motor torque ACS and its redundant calculation is greater than a threshold	0.01 Nm			Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of maximum throttle area and its redundant calculation is greater than a threshold	15 mm2			Up/down timer 91 ms continuous, 0.5 down time multiplier	
			Pedal learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Throttle learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Desired Throttle Position and its redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Calculated or Commanded Engine to Axle ratio is lower than a threshold  -OR- Engine to Axle Offset is greater than a threshold	0.9  288.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175.00 ms continuous, 0.5 down time multiplier	
			Difference between Cruise Arbitration Request and its redundant calculation exceeds a threshold	118.31 Nm	Ignition State	Accessory, run or crank	Up/down timer 500.00 ms continuous, 0.5	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			-OR- Difference between Cruise Accleration Request and its redundant calcultion exceeds a threshold	0.05 KPH/Second			down time multiplier	
			Difference between commanded Axle Torque and its redundant calcultion is greater than a threshold  -OR- Difference between commanded Axle Torque and its redundant calcultion is less than a threshold	3,154.80 Nm  4,732.20 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,047.97 ms continuous, 0.5 down time multiplier	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit Open	P0627	Controller specific output driver circuit diagnoses the Feed Fuel Pump Relay high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	>= 200 KOhms impedance between signal and controller ground.	Run/Crank Voltage	Voltage 11.00 volts	8 failures out of 10 samples  250 ms / sample	Type A, 1 Trips  Note: In certain controllers P0629 may also set (Fuel Pump Relay Control Short to Power)



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit Low Voltage	P0628	Controller specific output driver circuit diagnoses the Feed Fuel Pump Relay high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 0.5 Ohms impedance between signal and controller ground	Run/Crank Voltage	Voltage 11.00 volts	8 failures out of 10 samples  250 ms / sample	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit High Voltage	P0629	Controller specific output driver circuit diagnoses the Feed Fuel Pump Relay high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 0.5 Ohms impedance between signal and controller power	Run/Crank Voltage	Voltage 11.00 volts	8 failures out of 10 samples  250 ms / sample	Type A, 1 Trips  Note: In certain controllers P0627 may also set (Fuel Pump Relay Control Open Circuit)



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Internal Control Module EEPROM Error	P062F	This DTC detects a NVM long term performance. There are two types of diagnostics that run during controller power up. One for HWIO reports that writing to NVM (at shutdown) will not succeed, and the other HWIO reports the assembly calibration integrity check has failed.	HWIO reports that writing to NVM (at shutdown) will not succeed				Diagnostic runs at controller power up.	Type B, 2 Trips
			HWIO reports the assembly calibration integrity check has failed				Diagnostic runs at controller power up.	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks that the VIN is correctly written	At least one of the programmed VIN digits	Is not a valid ASCII character	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on the 5 volt reference circuit #1 by monitoring the reference percent Vrefl and failing the diagnostic when the percent Vrefl is too low or too high or if the delta between the filtered percent Vrefl and non-filtered percent Vrefl is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vrefl < or ECM percent Vrefl >  or the difference between ECM filtered percent Vrefl and percent Vrefl >  (100% corresponds to 5.5 Volt)	88.64 % Vrefl  93.18% Vrefl  0.90 % Vrefl	Diagnostic enabled  AND [  (Run/Crank voltage for Time period AND Starter engaged)  OR  (Run/Crank voltage AND Starter engaged) ]	= 1   >6.41 Volts = 25.00 Seconds = FALSE   >8.41 Volts = TRUE	19/39 counts; or  0.2500 ms continuous;  12.5 ms/count in main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #2 Circuit	P0651	Detects a continuous or intermittent short on the 5 volt reference circuit #2 by monitoring the reference percent Vref2 and failing the diagnostic when the percent Vref2 is too low or too high or if the delta between the filtered percent Vref2 and non-filtered percent Vref2 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref2 < or ECM percent Vref2 > or the difference between ECM filtered percent Vref2 and percent Vref2 >  (100% corresponds to 5.5 Volt)	88.64 % Vref2  93.18% Vref2  0.90 % Vref2	Diagnostic enabled  AND [ (Run/Crank voltage for Time period AND Starter engaged)  OR  (Run/Crank voltage AND Starter engaged) ]	= 1  >6.41 Volts = 25.00 Seconds = FALSE  >8.41 Volts = TRUE	19/39 counts; or  0.2500 ms continuous;  12.5 ms/count in main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Relay Control Circuit	P0685	Detects an open circuit in the Powertrain Relay driver. This diagnostic reports the DTC when an open circuit failure is present. Monitoring occurs when the output is powered off. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: > 200 K 0 ohms impedance between output and controller ground	Powertrain relay Open circuit diagnostic diagnostic enable = TRUE  Run/Crank Voltage	1.00  Voltage >11.00 volts	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controllers P0686 may also set (Powertrain Relay Control Short to Ground).



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Relay Control Circuit Low Voltage	P0686	Detects a short to ground in the Powertrain Relay low side driver. This diagnostic reports the DTC when a short to ground failure is present. Monitoring occurs when the output is powered off. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to ground: < 0.5 Q impedance between output and controller ground	Powertrain relay Low Side driver short to ground diagnostic diagnostic enable = TRUE  Run/Crank Voltage	1.00  Voltage >11.00 volts	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controllers P0685 may also set (Powertrain Relay Control Open Circuit).

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Relay Control Circuit High Voltage	P0687	Detects a short to power in the Powertrain Relay low side driver. This diagnostic reports the DTC when a short to power failure is present. Monitoring occurs when the output is powered off. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to power: < 0.5 Q impedance between output and controller power	Powertrain relay Low Side driver short to power diagnostic enable = TRUE  Run/Crank Voltage	1.00  Voltage >11.00 volts	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Relay Feedback Circuit Low Voltage	P0689	Detects low voltage in the control module relay feedback circuit. This diagnostic reports the DTC when low voltage is present. Monitoring occurs when run crank voltage is above a calibrated value.	Control module relay feedback circuit low voltage	Powertrain relay voltage <=5.00	Powertrain relay short low diagnostic enable  Run Crank voltage  Powertrain relay state	= 1.00  >9.00  = ON	5 failures out of 6 samples  1000 ms/ sample	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Relay Feedback Circuit High Voltage	P0690	Detects higher than expected voltage in the powertrain relay feedback circuit. This diagnostic reports the DTC when higher than expected voltage is present. For example, the powertrain relay could be stuck on. Monitoring occurs when the relay is commanded "off" for a calibrated duration.	Powertrain Relay Voltage	>= 4.00 volts will increment the fail counter	Powertrain relay high voltage feedback circuit diagnostic enable = TRUE  Powertrain relay commanded "OFF"  No active DTCs:	1.00  >=2.00 seconds  PowertrainRelayStateOn_ FA	50 failures out of 63 samples  100ms /Sample	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #3 Circuit	P0697	Detects a continuous or intermittent short on the 5 volt reference circuit #3 by monitoring the reference percent Vref3 and failing the diagnostic when the percent Vref3 is too low or too high or if the delta between the filtered percent Vref3 and non-filtered percent Vref3 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref3 < or ECM percent Vref3 > or the difference between ECM filtered percent Vref3 and percent Vref3 >  (100% corresponds to 5.5 Volt)	88.64 % Vref3  93.18% Vref3  0.90 % Vref3	Diagnostic enabled  AND [ (Run/Crank voltage for Time period AND Starter engaged)  OR  (Run/Crank voltage AND Starter engaged) ]	= 1  >6.41 Volts = 25.00 Seconds = FALSE  >8.41 Volts = TRUE	19/39 counts; or  0.2500 ms continuous;  12.5 ms/count in main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #4 Circuit	P06A3	Detects a continuous or intermittent short on the 5 volt reference circuit #4 by monitoring the reference percent Vref4 and failing the diagnostic when the percent Vref4 is too low or too high or if the delta between the filtered percent Vref4 and non-filtered percent Vref4 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref4 < or ECM percent Vref4 > or the difference between ECM filtered percent Vref4 and percent Vref4 >  (100% corresponds to 5.5 Volt)	88.64 % Vref4  93.18% Vref4  0.90 % Vref4	Diagnostic enabled  AND [ (Run/Crank voltage for Time period AND Starter engaged)  OR  (Run/Crank voltage AND Starter engaged) ]	= 1  >6.41 Volts = 25.00 Seconds = FALSE  >8.41 Volts = TRUE	19/39 counts; or  0.2500 ms continuous;  12.5 ms/count in main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 1 Performance	P06B6	This diagnostic checks for a fault with the internal test circuit (sensor #1) used only for the '20 kHz' method of the Open Circuit Diagnostic. A fault is present when the signal level from the 20 kHz range of the FFT output falls between the Open Test Circuit thresholds.	FFT Diagnostic Output	> <b>P06B6_P06B7_OpenT estCktThrshMin</b>  <b>AND</b>  < <b>P06B6_P06B7_OpenT estCktThrshMax</b>  <b>See Supporting Tables</b>	Diagnostic Enabled?  Engine Run Time  Engine Speed  Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)  Engine Air Flow	Yes  > 2.0 seconds  > 400 RPM and < 4,000 RPM  > 200 Revs  > 50 mg/cylinder and < 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient  Weight Coefficient =  0.0100  Updated each engine event	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 2 Performance	P06B7	This diagnostic checks for a fault with the internal test circuit (sensor #2) used only for the '20 kHz' method of the Open Circuit Diagnostic. A fault is present when the signal level from the 20 kHz range of the FFT output falls between the Open Test Circuit thresholds.	Individual Sensor Threshold Enabled?  FFT Diagnostic Output	0.00 , Use Case 1  <b>Case 1:</b>  > <b>P06B6_P06B7_OpenTestCktThrshMin</b>  <b>AND</b>  < <b>P06B6_P06B7_OpenTestCktThrshMax</b>  <b>See Supporting Tables</b>  <b>Case 2:</b>  > <b>P06B7_OpenTestCktMin2</b>  <b>AND</b>  < <b>P06B7_OpenTestCktMax2</b>  <b>See Supporting Tables</b>	Diagnostic Enabled?  Engine Run Time  Engine Speed  Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)  Engine Air Flow	Yes  > 2.0 seconds  > 400 RPM and < 4,000 RPM  > 200 Revs  > 50 mg/cylinder and < 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient  <b>Case 1 Weight Coefficient =</b>  0.0100  Updated each engine event  <b>Case 2 Weight Coefficient =</b> 0.0100  Updated each engine event	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure Control Circuit/Open	P06DA	Controller specific output driver circuit diagnoses the oil pump low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit > 200 k Q impedance between output and controller ground	Powertrain Relay Voltage  Run/Crank Active  Cranking State	> 11.00  = True  = False	>= 40 errors out of 50 samples.  Performed every 100 msec	Type B, 2 Trips  Note: In certain controllers P06DB may also set (Engine Oil Pressure Control Circuit Short To Ground)

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure Control Circuit Low	P06DB	Controller specific output driver circuit diagnoses the oil pump low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit < 0.5 0 impedance between output and controller ground	Powertrain Relay Voltage  Run/Crank Active  Cranking State	> 11.00  = True  = False	>= 40 errors out of 50 samples.  Performed every 100 msec	Type B, 2 Trips  Note: In certain controllers P06DA may also set (Engine Oil Pressure Control Circuit Open)

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure Control Circuit High	P06DC	Controller specific output driver circuit diagnoses the oil pump low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power < 0.5 Q impedance between output and controller power	Powertrain Relay Voltage  Run/Crank Active  Cranking State	> 11.00  = True  = False	>= 40 errors out of 50 samples.  Performed every 100 msec	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit Performance - One Sided	P06DD	<p>Diagnoses the two stage oil pump is stuck. This diagnostic includes an intrusive test and a passive test.</p> <p>Intrusive test: The oil pump control is cycled off (high pressure) and on (low pressure) Y = 15 times at calibratable intervals. If a change in oil pressure above a calibration is not detected then the oil pressure is checked to determine if it is stuck. It takes X-out-of-Y failures to fail and set the appropriate code.</p> <p>Passive test: After the intrusive test passes, then a passive test will begin to run. The passive test will monitor the oil pressure changes associated with oil pump control state changes. If the passive test determines that the oil pressure change was less than desired then the intrusive test is retriggered.</p>	<p><u>Fail from passing state:</u></p> <p>Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is above a threshold</p>	<p>Oil Pressure delta = ABS [ Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.5 seconds]</p> <p>Oil Pressure delta &lt; <b>P06DD_P06DE_OP_S tateChangeMin</b></p> <p>AND</p> <p>Filtered Oil Pressure &gt; <b>P06DD_P06DE_MinOi IPressThresh</b></p> <p>(see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_OP_S tateChangeMin</b> <b>P06DD_P06DE_MinOi IPressThresh</b> )</p>	<p><u>Common Criteria:</u></p> <p>Two Stage Oil Pump is Present</p> <p>Engine Running</p> <p>Ambient Air Pressure</p> <p>Oil Aeration (= TRUE if engine speed &gt; 8,000 RPM for longer than 30.0 seconds)</p> <p>No active DTC's for diagnosis enable:</p> <p>Check oil pump TFTKO as a diagnostic enable when Enabled.</p> <p>No active DTC's for control enable:</p> <p><u>Active Criteria:</u> One Sided Performance Test = Enabled</p>	<p>TRUE</p> <p>&gt; 30.0 seconds</p> <p>&gt;70.0 kPa</p> <p>FALSE</p> <p>Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCkt FA AmbientAirDefault EngOilTempFA</p> <p>Enabled : OilPmpTFTKO</p> <p>Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstlnaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA</p> <p>Enabled</p>	<p>&gt;12 errors out of 15 samples.</p> <p>Run once per trip or activated by the Passive Test</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Oil Pump in Low State  Modelled Oil Temperature within range  Filtered Engine Speed within range  Engine Torque within range  Delta Filtered Engine Speed within a range  Filtered Oil Pressure within range	> 1.5 seconds  40.0 deg C < Oil Temp < 100.0 deg C  1,000 RPM < Filtered Engine Speed < 3,300 RPM  <b>P06DD_P06DE_MinEnableTorque_OP</b> < Indicated Requested Engine Torque < <b>P06DD_P06DE_MaxEnableTorque_OP</b>  (see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_MinEnableTorque_OP</b> <b>P06DD_P06DE_MaxEnableTorque_OP</b> )  ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds ] < 50 RPM  Filtered Engine Oil Pressure > <b>P06DD_P06DE_MinOilPressThresh</b>  (see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_MinOilPressThresh</b> )		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Expected Oil Pressure Delta within range</p> <p><u>Passive Criteria:</u></p> <p>Active Test Passed</p> <p>Filtered Engine Speed within range</p> <p>Modelled Oil Temperature within range</p> <p>Delta Filtered Engine Speed within a range</p> <p>Oil Pressure Delta within a range</p>	<p>82.0 kPa &lt; ABS[ P0521_P06DD_P06DE_OP_HiStatePressure - P0521_P06DD_P06DE_OP_LoStatePressure ] &lt; 200.0 kPa</p> <p>TRUE</p> <p>1,000 RPM &lt; Filtered Engine Speed &lt; 4,500 RPM</p> <p>40.0 deg C &lt; Oil Temp &lt; 100.0 deg C</p> <p>ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.00 seconds ] &lt; 1,000 RPM</p> <p>Oil Pressure Delta &lt; P06DD_P06DE_OP_StateChangeMin (see P06DD details on Supporting Tables Tab P06DD_P06DE_OP_StateChangeMin )</p>		
			<p><u>Fast Pass Condition</u></p> <p>Oil Pressure delta is less than a minimum delta pressure on a state</p>	<p>Oil Pressure delta = ABS [ Filtered Oil Pressure at beginning</p>	<p><u>Common Criteria:</u></p> <p>Two Stage Oil Pump is Present</p>	<p>TRUE</p>	<p>0 errors out of 5 samples.</p> <p>Run once per trip</p>	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			change and the measured filtered oil pressure is above a threshold	of state change - filtered oil pressure after 1.5 seconds]  Oil Pressure delta < <b>P06DD_P06DE_OP_S tateChangeMin</b>  AND Filtered Oil Pressure > <b>P06DD_P06DE_MinOi IPresThresh</b>  (see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_OP_S tateChangeMin P06DD_P06DE_MinOi IPresThresh</b> )	Engine Running  Ambient Air Pressure  Oil Aeration (= TRUE if engine speed > 8,000 RPM for longer than 30.0 seconds)  No active DTC's for diagnsotic enable:  Check oil pump TFTKO as a diagnostic enable when Enabled.  No active DTC's for control enable:  <u>Active Criteria:</u> One Sided Performance Test = Enabled  Oil Pump in Low State  Modelled Oil Temperature within range	> 30.0 seconds  >70.0 kPa  FALSE  Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCkt FA AmbientAirDefault EngOilTempFA  Enabled : OilPmpTFTKO  Enabled Fault bundles for control disable :  OilPmpTFTKO EngineTorqueEstlnaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA  Enabled	or activated by the Passive Test	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Filtered Engine Speed within range</p> <p>Engine Torque within range</p> <p>Expected Oil Pressure Delta within range</p> <p>Delta Filtered Engine Speed within a range</p> <p>Filtered Oil Pressure within range</p>	<p>1,000 RPM &lt; Filtered Engine Speed &lt; 3,300 RPM</p> <p><b>P06DD_P06DE_MinEnableTorque_OP</b> &lt; Indicated Requested Engine Torque &lt; <b>P06DD_P06DE_MaxEnableTorque_OP</b></p> <p>(see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_MinEnableTorque_OP</b> <b>P06DD_P06DE_MaxEnableTorque_OP</b> )</p> <p>82.0 kPa &lt; ABS[ <b>P0521_P06DD_P06DE_OP_HiStatePressure</b> - <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> ] &lt; 200.0 kPa</p> <p>ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] &lt; 50 RPM</p> <p>Filtered Engine Oil Pressure &gt; <b>P06DD_P06DE_MinOilPressureThresh</b></p> <p>(see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_MinOilPressureThresh</b> )</p>		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Traction Control Torque Request Circuit	P0856	Determines if torque request from the EBCM is valid	Serial Communication 2's complement message - (\$1C7/\$1C9 for engine torque, \$1CA/\$1C6 for axle torque)  OR Serial Communication message (\$1C7/\$1C9 for engine torque, \$1CA/\$1C6for axle torque) rolling count index value  OR Too many minimum limit torque request transitions occur from TRUE to FALSE to TRUE within a time period  Torque request greater than torque request diagnostic maximum threshold	Message <> 2's complement of message  Message rolling count value <> previous message rolling count value plus one  Requested torque intervention type toggles from not increasing request to increasing request  > 251 Nm for engine torque based traction torque system, OR > 4,000 Nm for axle torque based traction torque system	Active Communication with EBCM  Power Mode Engine Running  Status of traction in GMLAN message (\$4E9)  Run/Crank Active  Ignition Voltage	Received serial data  = Run = True  = Traction Present  > 0.50 seconds  > 6.41 volts	>= 6 failures out of 10  Performed on every received message  6 rolling count failures out of 10 samples  Performed on every received message  >= 3 multi-transitions out of 5 samples.  Performed every 200 ms  >= 4 out of 10 samples  Performed on every received message	Type C, 1 Trip No MIL Emissio ns Neutral Emissio ns Neutral Diagnost ic - Type C



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Signals Message Counter Incorrect	P1001	This DTC monitors for an error in communication with the Evaporative Emission (EVAP) System Signal.	The signal value of the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) of the following signals received over serial data is incorrect for:  Fuel Tank Zone Module Info 11 ARC  Fuel Tank Zone Module Info 11 CSUM	  >=8.00 counts out of >= 18.00 counts  >=8.00 counts out of >= 18.00 counts	Message frame containing the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) is available on the bus.  All the following conditions are met for:  Battery voltage  Accessory mode to off mode transition not pending  If controller is a non-OBD controller then battery voltage  Controller type: OBD Controller	  >= 3,000.00 milliseconds  >= 11.00 volts    <= 18.00 volts	Fuel Tank Zone Module Info 11 ARC samples every 10.00 milliseconds.  Fuel Tank Zone Module Info 11 CSUM samples every 10.00 milliseconds.	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module System Voltage Performance (Only on applications that use an FTZM)	P1002	Detects low system voltage performance of the fuel pump driver control module system. This diagnostic reports the DTC when the absolute value of the difference between the fuel pump driver battery voltage and the fuel pump driver run/crank voltage exceeds a calibrated value.	Fuel Pump Driver Control Module Run Crank voltage low and high	ABS (Fuel Pump Driver Control Module Battery voltage - Fuel Pump Driver Control Module Run Crank voltage) > 3.00	Fuel Tank Zone Module (FTZM) is present on vehicle  Fuel Pump Driver Control Module System Voltage Performance diagnostic is enabled  Fuel Tank Zone Module (FTZM) serial messages are available  FTZM Run Crank Active is TRUE  Starter motor not engaged  Sensor Bus relay is commanded ON  Sensor Bus Relay FA = False	= 1         SensorBusRelayFA	50 failures out of 63 samples  12.5 ms /sample	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Control System Signals Message Counter Incorrect	P1003	This DTC monitors for an error in communication with the Fuel Control System Signals.	The signal value of the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) of the following signals received over serial data is incorrect for:  Fuel Tank Zone Module Info 12 ARC  Fuel Tank Zone Module Info 12 CSUM	  >=8.00 counts out of >= 18.00 counts  >=8.00 counts out of >= 18.00 counts	Message frame containing the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) is available on the bus.  All the following conditions are met for:  Battery voltage  Accessory mode to off mode transition not pending  If controller is a non-OBD controller then battery voltage  Controller type: OBD Controller	  >= 3,000.00 milliseconds  >= 11.00 volts          <= 18.00 volts	Fuel Tank Zone Module Info 12 ARC samples every 20.00 milliseconds.  Fuel Tank Zone Module Info 12 CSUM samples every 20.00 milliseconds.	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Reset Error	P1005	This diagnostic is intended to monitor a message from the Fuel Pump Driver Control Module/Fuel Tank Zone Module and use the information in the message to diagnose if the module is resetting unexpectedly. The message contains the time since the last reset as measured by the module. If the time since the last reset decreases from one message to another without indicating that a timer rollover occurred, a reset of the external module will be indicated. If too many resets occur in a sample window the diagnostic will fail.	<p>If the diagnostic has detected that an unexpected reset has occurred:</p> <p>The time since last module reset event data value received from the FPDCM/FTZM is less than the previous value and also</p> <p>And</p> <p>The rollover occurred value received from the FPDCM/FTZM is false</p> <p>for</p> <p>out of total samples</p>	<p><math>\leq 0.50</math> seconds</p> <p><math>\geq 2.00</math> counts</p> <p><math>\geq 400.00</math> counts</p>	<p>DTC is enabled</p> <p>Sensor bus relay is on</p> <p>Battery voltage</p> <p>No FTZM reconfiguration is requested for</p> <p>A new message that contains the FPDCM/FTZM reset data is received</p> <p>The following DTCs that diagnose the message that contains the FPDCM/FTZM reset data are not active:</p> <p>P1000</p> <p>U18A2</p>	<p>Enabled</p> <p><math>&gt; 11.00</math> Volts</p> <p>1.00 second(s)</p>	This diagnostic samples every 100.00 milliseconds.	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit High (Only on applications that use an FTZM)	P1007	Detects high voltage of the fuel pump driver control module ignition switch circuit. This diagnostic reports the DTC when the fuel pump driver control module ignition switch circuit voltage exceeds a calibrated value.	Fuel Pump Driver Control Module Ignition switch Run/Start position circuit high	FTZM Run Crank Active is TRUE	Fuel Tank Zone Module (FTZM) is present on vehicle  Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit High diagnostic is enabled  Fuel Tank Zone Module (FTZM) serial messages are available  Run Crank Active  Sensor Bus relay is commanded ON  Sensor Bus Relay FA = False	= 1    = FALSE   SensorBusRelayFA	50 failures out of 63 samples  50 ms / sample	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Temperature (Fuel Tank Zone Module) Too High Signal Message Counter Incorrect	P1009	This DTC monitors for an error in communication with the Fuel Pump Driver Control Module (FTZM) Temperature Too High Signal Message.	The signal value of the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) of the following signals received over serial data is incorrect for:  Fuel Tank Zone Module Info 7 ARC  Fuel Tank Zone Module Info 7 CSUM	  >=3.00 counts out of >= 10.00 counts  >=3.00 counts out of >= 10.00 counts	Message frame containing the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) is available on the bus.  All the following conditions are met for:  Battery voltage  Accessory mode to off mode transition not pending  If controller is a non-OBD controller then battery voltage  Controller type: OBD Controller	  >= 3,000.00 milliseconds  >= 11.00 volts          <= 18.00 volts	Fuel Tank Zone Module Info 7 ARC samples every 100.00 milliseconds.  Fuel Tank Zone Module Info 7 CSUM samples every 100.00 milliseconds.	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V- W Circuit Open	P1029	<p>This DTC detects if any of the 3phase fuel pump control circuits is Open [system configuration "Brushless"]</p> <p>The diagnostic can detect open circuit faults when the fuel pump is not rotating. In the "stopped" state, small currents are injected into each motor phase circuit pair by an internal fixed source and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage falls into a specific range [adjusted for source voltage]. This process is completed in less than 1 millisecond. The FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are</p>	Phased-pair circuit voltage	3V <= V [back-EMF] <= 6V	<p>a) Sensed fuel pump speed</p> <p>b) Device configuration Chassis Fuel Pres System type</p> <p>c) Diagnostic is ..</p> <p>d) CAN Sensor Bus message \$3EC Available</p> <p>e) Sensor Bus Relay On</p> <p>f) Sensor Bus B Message \$3EC Temp Signal Message Counter Incorrect [Info7]</p>	<p>a) == 0 RPM</p> <p>b) == Brushless motor</p> <p>c) ENABLED</p> <p>d) == TRUE</p> <p>e) == TRUE</p> <p>f) == False</p>	<p>40.00 failures / 80.00 samples</p> <p>1 sample / 12.5 ms</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		active at any moment. Brushless fuel pump speed is inferred using the rate of zero- crossings detection and number of motor pole- pairs. Speed is reported to the ECM as serial data every 10 milliseconds. This open circuit diagnostic follows "smart device" Component Technical Specifications.						

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V- W Circuit Low	P102A	<p>This DTC detects if the fuel pump control circuit is shorted to low [Short to Ground]</p> <p>The diagnostic detects short-to-ground faults using 2 methods depending on whether the fuel pump is rotating. 1) In the "rotating" state, voltage drop across each phase-pair high-side drive is monitored, or 2) in the "stopped" state, small currents are injected into each motor phase circuit pair by an internal fixed source and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage falls into a specific range [adjusted for source voltage].</p> <p>The FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-</p>	Phased-pair circuit voltage Difference	Vdelta > 0.145 V	a) Chassis Fuel Pres System type Device configuration b) Diagnostic is .. c) CAN Sensor Bus message \$3EC_Avail d) Sensor Bus Relay On e) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [Info7]	a) == Brushless motor b) Enabled c) == TRUE d) == TRUE e) == False	40.00 failures / 80.00 samples  1 sample / 12.5 ms	Type A, 1 Trips
			Phased-pair circuit voltage	V [back-EMF] >= 6 V	a) Sensed fuel pump speed b) Chassis Fuel Pres System type Device configuration c) Diagnostic is .. d) CAN Sensor Bus message \$3EC Available e) Sensor Bus Relay On f) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [Info7]	a) == 0 RPM b) == Brushless motor c) Enabled d) == TRUE e) == TRUE f) == False	40.00 failures / 80.00 samples  1 sample / 12.5 ms	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		phase signal wherein only 2 phases are active at any moment. Brushless fuel pump speed is inferred using the rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 milliseconds. This open circuit diagnostic follows "smart device" Component Technical Specifications.						

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V- W Circuit High	P102B	<p>This DTC detects if the fuel pump control circuit is shorted to high voltage [Short to Battery]</p> <p>The diagnostic detects short-to-battery faults using 2 methods depending on whether the fuel pump is rotating. 1) In the "rotating" state, voltage drop across each phase-pair low-side current shunt is monitored, or 2) in the "stopped" state, small currents are injected into each motor phase circuit pair by an internal fixed source and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage falls into a specific range [adjusted for source voltage]. The FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the</p>	Phased-pair circuit voltage Difference	Vdelta > 0.4 V	a) Diagnostic is .. b) Device configuration Chassis Fuel Pressure SysType == FTZM Electronically Commutated c) CAN Sensor Bus message \$3EC_Avail d) Sensor Bus Relay On e) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect	a) Enabled b) == TRUE c) == TRUE d) == TRUE e) == False	40.00 failures/ 80.00 samples  1 sample / 12.5 ms	Type A, 1 Trips
			Phased-pair circuit voltage	V[backEMF] > 6 V	a) Diagnostic is .. b) Sensed fuel pump speed b) Device configuration Fuel Pressure System Type == FTZM Electronically Commutated c) CAN Sensor Bus message \$3EC_Avail d) Sensor Bus Relay On e) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect	a) Enabled b) == 0 RPM b) == TRUE c) == TRUE d) == TRUE e) == False	40.00 failures/ 80.00 samples  1 sample / 12.5 ms	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		inactive phase of the 3-phase signal wherein only 2 phases are active at any moment. Brushless fuel pump speed is inferred using the rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 milliseconds. This open circuit diagnostic follows "smart device" Component Technical Specifications.						





24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (naturally aspirated)	P1101	<p>Detects a performance failure in the Manifold Pressure (MAP) sensor, Throttle Position sensor (TPS) or Mass Air Flow (MAF) sensor that cannot be uniquely identified as a failure in one individual sensor. This diagnostic can set when more than one of these sensors has a performance concern.</p> <p>This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from these three sensors.</p> <p>These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the system, but no</p>	<p>Filtered Throttle Model Error</p> <p>AND</p> <p>ABS(Measured Flow - Modeled Air Flow) Filtered</p> <p>OR</p> <p>ABS(Measured MAP - MAP Model 1) Filtered</p> <p>AND</p> <p>ABS(Measured MAP - MAP Model 2) Filtered</p>	<p>&gt; 300 kPa*(g/s)</p> <p>&gt; 25.0 grams/sec</p> <p>&gt; 22.0 kPa )</p> <p>&gt; 22.0 kPa</p>	<p>Engine Speed Engine Speed</p> <p>(Coolant Temp OR OBD Coolant Enable Criteria</p> <p>(Coolant Temp OR OBD Max Coolant Achieved</p> <p>Intake Air Temp Intake Air Temp</p> <p>Minimum total weight factor (all factors multiplied together)</p> <p>See Residual Weight Factor tables.</p>	<p>&gt;= 400 RPM &lt;= 4,230 RPM</p> <p>&gt;= -9 Deg C</p> <p>= TRUE)</p> <p>&lt;= 130 Deg C</p> <p>= FALSE)</p> <p>-20 Deg C &lt;= 129 Deg C</p> <p>&gt;= 0.50</p> <p>Filtered Throttle Model Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM</b></p> <p>Modeled Air Flow Error multiplied by <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM</b> and <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est</b></p>	<p>Continuous</p> <p>Calculation are performed every 12.5 msec</p>	Type B, 2 Trips

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		single failed sensor can uniquely be identified. In this case, the Inlet Airflow System Performance diagnostic will fail.			No Active DTCs:  No Pending DTCs:  Diagnostic is Enabled	MAP Model 1 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101:</b> <b>MAPI Residual Weight Factor based on RPM</b>  MAP Model 2 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101:</b> <b>MAP2 Residual Weight Factor based on RPM</b>  MAP_SensorCircuitFA EGRValvePerformance_FA A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA  EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		







24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 low side circuit shorted to high side circuit	P1248	Controller specific output driver circuit diagnoses injector 1 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 low side circuit shorted to high side circuit	P1249	Controller specific output driver circuit diagnoses injector 2 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector3 low side circuit shorted to high side circuit	P124A	Controller specific output driver circuit diagnoses injector 3 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 low side circuit shorted to high side circuit	P124B	Controller specific output driver circuit diagnoses injector 4 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector5 low side circuit shorted to high side circuit	P124C	Controller specific output driver circuit diagnoses injector 5 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 low side circuit shorted to high side circuit	P124D	Controller specific output driver circuit diagnoses injector 6 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 low side circuit shorted to high side circuit	P124E	Controller specific output driver circuit diagnoses injector 7 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector8 low side circuit shorted to high side circuit	P124F	Controller specific output driver circuit diagnoses injector 8 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Over Temperature	P1255	To detect if an internal fuel pump driver over-temperature condition exists under normal operating conditions.  The FTZM ERFS control may adjust the PWM slew rate or frequency as a self-protection method, but may not reduce pump rotational speed or impact pumping performance in any way due to an over-temperature condition.	Fuel Pump Driver Temperature	T > 160 degC	a) Diagnostic is ..  b) Sensor Bus Relay On  c) CAN Sensor Bus message \$3EC_Available  d) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_A RC_ChkErr]	a) Enabled  b) == TRUE  c) == TRUE  d) <> TRUE	5.00 failures/ 10.00 samples  1 sample / 100 millisec	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail High Pressure Sensor 2 Out of Range	P127C	<p>This DTC diagnose SENT high pressure sensor 2 that is too low out of range.</p> <p>If the sensor digital value (repressing the refernce voltage) is below the lower digital threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported. A pass is reported for this DTC if the low sample counter reaches its threshold.</p>	High Pressure Rail Sensor 2 SENT digital read value	=< 94			Time Based: 400 Failuer out of 500 Samples 6.25 ms per Sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure Sensor 1 Internal Performance	P128A	This DTC determines if there is internal error within the SENT pressure sensor 1 (i.e. Broken wire bond internal to the SENT Sensor). Once the internal error is detected a fixed faulted digital values is communicated to the ECU.	Digital pressure sesnor 1 value	>= 4,089	SENT Fuel Rail Pressure Sensor Internal Performance Enable  No Fault Pending	Enabled when a code clear is not active or not exiting device control  True  U0625 P16E5 P128F	400 failures out of 500 samples  6.25 ms per Sample Continuous	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure Sensor 2 Internal Performance	P128B	This DTC determines if there is internal error within the SENT pressure sensor 2 (i.e. Broken wire bond internal to the SENT Sensor). Once the internal error is detected a fixed faulted digital values is communicated to the ECU.	Digital pressure sesnor 2 value	>= 4,089	SENT Fuel Rail Pressure Sensor Internal Performance Enable  No Fault Pending	Enabled when a code clear is not active or not exiting device control  True  U0625 P16E5 P128F	400 failures out of 500 samples  6.25 ms per Sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure & Temperature Sensor Pressure Message Incorrect	P128F	This DTC determines if there is any SENT signal waveform for discrepancies (i.e. too many pulse, too few pulse, clock shift). The SENT HWIO Determines message waveform fault (i.e. too many pulse, too few pulse, clock shift) and if the message age is too long.	SENT HWIO Determines message fault (i.e. too many pulse, too few pulse, clock shift)  Message Age	= true  > 1.69 ms	SENT signal Serial waveform diagnostics enable  SENT power up delay    No Fault Active on	True  >= 0.00 seconds  Enabled when a code clear is not active or not exiting device control  U0625 P16E5	400 failures out of 500 samples  6.25 ms per sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit Low (Only on applications that use an FTZM)	P129D	Detects low voltage of the fuel pump driver control module ignition switch circuit. This diagnostic reports the DTC when the fuel pump driver control module ignition switch circuit voltage is below a calibrated value.	Fuel Pump Driver Control Module Ignition switch Run/Start position circuit low	FTZM Run Crank Active is FALSE	Fuel Tank Zone Module (FTZM) is present on vehicle  Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit High diagnostic is enabled  Fuel Tank Zone Module (FTZM) serial messages are available  Run Crank Active  Sensor Bus relay is commanded ON  Sensor Bus Relay FA = False	= 1   = TRUE  SensorBusRelayFA	40 failures out of 50 samples  50 ms / sample	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Fuel Pump Speed Signal Incorrect	P129F	FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are active at any moment. Brushless pump speed is inferred using rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 millisecons. Diagnostic software [FABR ring] calculates the error between the commanded, arbitrated fuel pump speed [FCBR ring] and the FTZM sensed fuel pump speed. The error is filtered and evaluated against calibratable threshold limits to determine pass/fail status. Any failure that exists on the fuel pump output circuit (3 phases) will be manifested in a Fuel Pump Speed	Sensed Filtered Fuel Pump Speed Error	> Speed Error Low Threshold [Supporting Table] <b>P129F Threshold Low</b>  OR  < Speed Error High Threshold [Supporting Table] <b>P129F Threshold High</b>	a) Diagnostic is .. b) CAN Sensor Bus message \$0CB_Available c) FABR Fuel Control Enable Fault Active d) Fuel Pmp Speed Command Alive Rolling Count and Checksum Error [CAN Bus B \$0CE] [CFMR_b_FTZM_Cmd1_ARC_ChkErr] e) FABR Fuel Pump Ckt FA f) FABR Driver OverTemp FA g) Run_Crank input Voltage h) Sensor Bus Relay On j) CAN Sensor Bus message \$0CB Data Fault [CFMR_b_FTZM_Info8_ARC_ChkErr] k) CAN Sensor Bus message \$0CB Comm Fault [CFMR_b_FTZM_Info8_UcodeCmFA] l) Fuel Pmp Spd Command ARC and Checksum Comm Fault Code [CFMR_b_FTZM_Cmd1_UcodeCmFA] m) Timer - FABR Rising Edge Diagnostic Delay n) Timer - FABR Falling Edge Diagn Delay	a) Enabled  b) == TRUE  c) <> TRUE  d) <> TRUE    e) <> TRUE f) <> TRUE   g) > 9.00 volts  h) == TRUE j) <> TRUE    k) <> TRUE   l) <> TRUE    m) > 2.20 seconds  n) > 1.00 seconds	1 sample / 12.5 msec	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Rationality Diagnostic fault. Reported fuel pump speed data will only be consumed in this same diagnostic.						

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Enable Circuit Performance	P12A6	The purpose of the Fuel Pump Driver Control Module Enable Circuit Performance diagnostic is to detect if the state of the fuel control enable circuit is valid. This is done by comparing the fuel control enable circuit state [high or low] sensed by the Fuel Tank Zone Module device to the commanded state of the fuel control enable signal from the ECM [in serial data]. When the sensed state does not match the commanded state, the fail counter increments.	Sensed Fuel Control Enable circuit state  [Fuel Tank Zone Module device]	<> Fuel Control Enable Active command  [serial data]	a) Diagnostic is ..  b) Sensor Bus message \$0CC Fuel Pump Command Message Signal Counter Incorrect [CFMR_b_FTZM_Info2_ARC_ChkErr]  c) CAN Sensor Bus message \$OCC_Available  d) Sensor Bus Relay On  e) Timer [FABR t RunCrankActive ]	a) Enabled  b) <> TRUE  c) == TRUE  d) == TRUE  e) >= 0.51 seconds	40.00 failures / 80.00 samples  1 sample / 12.5 millisec	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Module (Fuel Tank Zone Module) Control Signal Message Counter Incorrect	P12A8	This DTC monitors for an error in communication with the Fuel Pump Control Module (FTZM) Control Signal Message.	The signal value of the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) of the following signals received over serial data is incorrect for:  Fuel Tank Zone Module Info 8 ARC  Fuel Tank Zone Module Info 8 CSUM	  >=8.00 counts out of >= 18.00 counts  >=8.00 counts out of >= 18.00 counts	Message frame containing the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) is available on the bus.  All the following conditions are met for:  Battery voltage  Accessory mode to off mode transition not pending  If controller is a non-OBD controller then battery voltage  Controller type: OBD Controller	  >= 3,000.00 milliseconds  >= 11.00 volts    <= 18.00 volts	Fuel Tank Zone Module Info 8 ARC samples every 10.00 milliseconds.  Fuel Tank Zone Module Info 8 CSUM samples every 10.00 milliseconds.	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Run/ Start Voltage Signal Message Counter Incorrect	P130F	This DTC monitors for an error in the Ignition Run/Start Voltage Signal Message Counter.	The signal value of the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) of the following signals received over serial data is incorrect for:  Fuel Tank Zone Module Info 5 ARC  Fuel Tank Zone Module Info 5 CSUM	  >=4.00 counts out of >= 10.00 counts  >=4.00 counts out of >= 10.00 counts	Message frame containing the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) is available on the bus.  All the following conditions are met for:  Battery voltage  Accessory mode to off mode transition not pending  If controller is a non-OBD controller then battery voltage  Controller type: OBD Controller	  >= 3,000.00 milliseconds  >= 11.00 volts    <= 18.00 volts	Fuel Tank Zone Module Info 5 ARC samples every 50.00 milliseconds.  Fuel Tank Zone Module Info 5 CSUM samples every 50.00 milliseconds.	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Coil Positive Voltage Circuit Group 1 * * SIDI ONLY	P135A	This diagnostic checks for minimum voltage at the fuse which supplies power to the Ignition Coils (applicable only for SIDI applications). A diagnostic failure indicates a blown fuse.	Ignition Module Supply Voltage.	< 2.5 Volts	Diagnostic Enabled?  Three possible Ignition Coil Power Sources (only 1 used):  Ignition Coil Power Source =  <u>Case 1: Battery</u> Delay starting at Key-On  <u>Case 2: Ignition Run/Crank</u> Ignition Run/Crank Voltage  <u>Case 3: PT Relay</u> PT Relay Voltage	Yes    PT Relay (Case 3)  5 Engine Revs  > 5.0 volts  >11.0 volts	50 Failures out of 63 Samples  6.25 msec rate	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Coil Positive Voltage Circuit Group 2 * * SIDI ONLY	P135B	This diagnostic checks for minimum voltage at the fuse which supplies power to the Ignition Coils (applicable only for SIDI applications). A diagnostic failure indicates a blown fuse.	Ignition Module Supply Voltage.	< 2.5 Volts	Diagnostic Enabled?  Three possible Ignition Coil Power Sources (only 1 used):  Ignition Coil Power Source =  <u>Case 1: Battery</u> Delay starting at Key-On  <u>Case 2: Ignition Run/Crank</u> Ignition Run/Crank Voltage  <u>Case 3: PT Relay</u> PT Relay Voltage	Yes    PT Relay (Case 3)  5 Engine Revs  >5.0 volts  >11.0 volts	50 Failures out of 63 Samples  6.25 msec rate	Type: Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level SensorA Reference Feedback Range/ Performance  [For use on vehicles with FTZM]	P1434	This DTC will detect a fault in Primary fuel tank level sensor 5V reference by comparing DEC ECU commanded signal period and pulse width values against measured period and pulse width reported by the smart device	Reference Voltage 0 Period Error Maximum  [Measured Ref V Period - Commanded Ref V Period]	> 25.00 millise	a] CAN serial data available [\$2D7]  b] Calibration - Reference Voltage Command Source  c] Timer - Reference Voltage Pulse Width Available Synchronization  d] Timer - Reference Voltage Period Available Delay  e] Diagnostic System Disabled  f] FTZM Serial Data Info4 Rolling Counter Check Error  g] Reference Voltage Performance 0 Diagnostic Enabled	a] --- True  b] == ECM  c] > 1.25 sec  d] > 0.75 sec  e] <> True  f] <> True  g] == TRUE	250 ms / sample	Type B, 2 Trips
			Reference Voltage 0 Pulse Width Error Maximum  [Measured Ref V PW - Commanded Ref V PW]	> 1.50 millise	a] CAN serial data available [\$2D7]  b] Calibration - Reference Voltage Command Source  c] Timer - Reference Voltage Pulse Width Available Synchronization  d] Timer - Reference Voltage Period Available Delay  e] Diagnostic System Disabled	a] --- True  b] == ECM  c] > 1.25 sec  d] > 0.75 sec  e] <> True	250 ms / sample  16 Failures/ 20 Samples	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					fj FTZM Serial Data Info4 Rolling Counter Check Error  gj Reference Voltage Performance 0 Diagnostic Enabled	fj <> True  gj == TRUE		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor A Signal Message Counter Incorrect	P14B6	This DTC monitors for an error in communication with the Mass Air Flow Sensor A.	The signal value of the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) of the following signals received over serial data is incorrect for:  Temperature and Humidity ARC  Pressure ARC	  >=8.00 counts out of >= 10.00 counts  >=8.00 counts out of >= 10.00 counts	Message frame containing the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) is available on the bus.  All the following conditions are met for:  Battery voltage  Accessory mode to off mode transition not pending  If controller is a non-OBD controller then battery voltage  Controller type: OBD Controller	  >= 3,000.00 milliseconds  >= 11.00 volts    <= 18.00 volts	Temperature and Humidity ARC samples every 25.00 milliseconds.  Pressure ARC samples every 25.00 milliseconds.	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Configuration Command Signal 1 Message	P14CD	This DTC monitors for an error in communication with the Fuel Pump Driver Control Module Configuration Command Signal 1.	The Fuel Tank Zone Module has determined that signal value of the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) of Fuel Pump Driver Control Module Configuration Command Signal 1 Message transmitted by the Engine Control module is incorrect and sends a fail status back to the ECM for	>= 15.00 counts out of >= 16.00 counts	Diagnostic is enabled  Message frame from the Fuel Tank Zone Module containing the diagnostic status is received  All the following conditions are met for:  Battery Voltage  Sensor bus relay is on (if present)	Enabled  >= 300.00 milliseconds  >=11.00 Volts	Samples every 10.00 milliseconds.	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Configuratio n Status Signal Message Counter Incorrect	P14CE	This DTC monitors for an error in communication with the Fuel Pump Driver Control Module Configuration Status Signals.	The signal value of the Alive Rolling Count (ARC),Protection Value (PV), or Checksum (CSUM) of the following signals received over serial data is incorrect for:  Fuel Tank Zone Module Info 16 ARC  Fuel Tank Zone Module Info 16 CSUM	  >=3.00 counts out of >= 10.00 counts  >=3.00 counts out of >= 10.00 counts	Message frame containing the Alive Rolling Count (ARC),Protection Value (PV), or Checksum (CSUM) is available on the bus.  All the following conditions are met for:  Battery voltage  Accessory mode to off mode transition not pending  If controller is a non-OBD controller then battery voltage  Controller type: OBD Controller	  >= 3,000.00 milliseconds  >= 11.00 volts       <= 18.00 volts	Fuel Tank Zone Module Info 16 ARC samples every 250.00 milliseconds.  Fuel Tank Zone Module Info 16 CSUM samples every every 250.00 milliseconds.	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Engine Speed Request Circuit	P150C	This DTC monitors for an error in communication with the Transmission Engine Speed Request Signal.	The signal value of the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) of the following signals received over serial data is incorrect for:  Transmission 199 ARC  Transmission ARC  Transmission Engine Speed Request PV	  >=8.00 counts out of >= 18.00 counts  >=8.00 counts out of >= 18.00 counts  >=8.00 counts out of >= 18.00 counts	Message frame containing the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) is available on the bus.  All the following conditions are met for:  Battery voltage  Accessory mode to off mode transition not pending  If controller is a non-OBD controller then battery voltage  Controller type: OBD Controller	  >= 3,000.00 milliseconds  >= 11.00 volts         <= 18.00 volts	Transmission 199 ARC samples every 25.00 milliseconds.  Transmission ARC samples every 25.00 milliseconds.  Transmission Engine Speed Request PV samples every 25.00 milliseconds.	Type B, 2 Trips





24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Calibration Incorrect	P158A	Type of cruise in Body Control Module does not match that in the Engine Control Module for 2.5 seconds  "Emissions Neutral Default Action : This diagnostic compares the BCM and the ECM configuration calibrations of whether No Cruise, Conventional Cruise Control, or ACC is available on the vehicle. If the calibration for the cruise system type in the ECM does not match the value in \$4E9 signal Vehicle Speed Control System Type, a P158A DTC is set and cruise control is disabled."	Type of cruise system in GMLAN \$4E9 does not match with that in the Engine Control Module for a fix time.	2.5 seconds	Diagnostic is enabled.  DID \$40 from BCM says cruise system is present (ECM receives programmable information from Body Control Module)  OR  ECM will not receive Programmable information for Cruise from Body Control Module	CeACZR_e_ConvCruise	fail continuously for greater than 2.5 seconds.	Type C, 1 Trip No MIL Emissions Neutral "Emissions Neutral Diagnos- tics - Special Type C"



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Ignition voltage out of correlation error(P1682) not active and  Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -40.0 degC -40 <= Temp degC <= 132		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Reference Voltage Status Message Counter Incorrect	P165C	This DTC monitors for an error in communication with the Sensor Reference Voltage Status Signals.	The signal value of the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) of the following signals received over serial data is incorrect for:  Fuel Tank Zone Module Info 1 ARC  Fuel Tank Zone Module Info 1 CSUM	>=8.00 counts out of >= 18.00 counts  >=8.00 counts out of >= 18.00 counts	Message frame containing the Alive Rolling Count (ARC), Protection Value (PV), or Checksum (CSUM) is available on the bus.  All the following conditions are met for:  Battery voltage  Accessory mode to off mode transition not pending  If controller is a non-OBD controller then battery voltage  Controller type: OBD Controller	>= 3,000.00 milliseconds  >= 11.00 volts          <= 18.00 volts	Fuel Tank Zone Module Info 1 ARC samples every 6.00 milliseconds.  Fuel Tank Zone Module Info 1 CSUM samples every 6.00 milliseconds.	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage and the Powertrain Relay Ignition Voltage. The diagnostic monitors the difference in voltage between Run/Crank Voltage and the Powertrain Relay Ignition Voltage and fails the diagnostic when the voltage difference is too high. This diagnostic only runs when the powertrain is commanded on and the Run/Crank Voltage is greater than a threshold based on IAT or the powertrain ignition voltage is high enough the Run/Crank voltage is high enough.	Run/Crank - PT Relay Ignition  >	3.00 Volts	Powertrain Relay commanded on  AND  ( Run/Crank voltage >  OR  PT Relay Ignition voltage > )  AND  Run/Crank voltage >	Table, f(IAT). See supporting tables: <b>P1682_PT Relay Pull-in Run/Crank Voltage f(IAT)</b>  5.50 Volts  5.50 Volts	240/480 counts; or  0.175 sec continuous;  12.5 ms/count in main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation #2	P16A7	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage and the Powertrain Relay Ignition Voltage #2. The diagnostic monitors the difference in voltage between Run/Crank Voltage and the Powertrain Relay Ignition Voltage and fails the diagnostic when the voltage difference is too high. This diagnostic only runs when the powertrain is commanded on and the Run/Crank Voltage is greater than a threshold based on IAT or the powertrain ignition voltage is high enough the Run/Crank voltage is high enough. Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage #2.	Run/Crank - PT Relay Ignition  >	3.00 Volts	Powertrain Relay commanded on  AND  ( Run/Crank voltage >  OR  PT Relay Ignition voltage > )  AND  Run/Crank voltage >	Table, f(IAT). See supporting tables: <b>P16A7_PT Relay Pull-in Run/Crank Voltage f(IAT)</b>  5.50 Volts  5.50 Volts	240/480 counts; or  0.175 sec continuous;  12.5 ms/count in main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Controls Ignition Relay Feedback Circuit 2 Low Voltage - (GEN III and beyond controllers ONLY)	P16AF	Detects low voltage in the engine controls ignition relay feedback circuit 2. This diagnostic reports the DTC when low voltage is present. Monitoring occurs when run crank voltage is above a calibrated value.	Engine controls ignition relay feedback circuit 2 low voltage	Relay voltage <= 5.00	Powertrain relay low diag enable  Powertrain relay voltage  Run Crank voltage  Powertrain relay state	= 1.00  >=11.00  >9.00  = ON	5 failures out of 6 samples  1000 ms / sample	Type C, 1 Trip No MIL Emissions Neutral



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Controls Ignition Relay Feedback Circuit 2 High Voltage -(GEN III and beyond controllers ONLY)	P16B3	Detects high voltage in the engine controls ignition relay feedback circuit 2. This diagnostic reports the DTC when high voltage is present. Monitoring occurs when the relay state is inactive.	Engine controls ignition relay feedback circuit 2 high voltage	Relay voltage >=4.00	Powertrain relay high diag enable  Powertrain relay state	= 1.00  = INACTIVE	50 failures out of 63 samples  100 ms /sample	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Bus Relay Control Circuit	P16D7	Detects an open circuit in the sensor bus relay circuit. This diagnostic reports the DTC when an open circuit is present. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: > 200 K Q ohms impedance between output and controller ground	Sensor Bus relay circuit open diagnostic = TRUE  Run/Crank Voltage	1.00  Voltage > 11.00volts	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controllers P16D8 may also set (Sensor Bus Relay Control Circuit Low).

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Bus Relay Control Circuit Low	P16D8	Detects a short to ground in the sensor bus relay circuit. This diagnostic reports the DTC when a short to ground is present. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to ground: < 0.5 Q impedance between output and controller ground	Sensor Bus relay circuit short to ground diagnostic = TRUE  Run/Crank Voltage	1.00  Voltage >11.00 volts	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controllers P16D7 may also set (Sensor Bus Relay Control Circuit Open).

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Bus Relay Control Circuit High	P16D9	Detects a short to power in the sensor bus relay circuit. This diagnostic reports the DTC when a short to power is present. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to power: < 0.5 Q impedance between output and controller power	Sensor Bus relay circuit short to power diagnostic = TRUE  Run/Crank Voltage	1.00  Voltage >11.00 volts	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Low- Bank 1	P2088	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 0.5 Q impedance between signal and controller ground	Diagnostic is Enabled  System supply voltage  Output driver is commanded on  Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples  250 ms /sample, continuous	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit High - Bank 1	P2089	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 0.5 Q impedance between signal and controller power	Diagnostic is Enabled  System supply voltage  Output driver is commanded on  Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples  250 ms /sample, continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Lean Bank 1	P2096	<p>Determines if the post catalyst 02 sensor based fuel control system is indicating a lean exhaust gas condition. If the lean condition is such that the control system utilizes all or most of its available high limit authority (high limit = 100% authority), then P2096 will set.</p> <p>The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset.</p> <p>Note: When the post catalyst 02 voltage is too lean, the post catalyst 02 integral and proportional offset control is increased (positive % authority). This applies a rich bias to fuel control in an attempt to counteract the lean condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral</p>	<p>The Average Integral Offset % Authority</p> <p>AND</p> <p>The Average Total Offset % Authority</p> <p>(Note: any value greater than or equal to +100% effectively nullifies the Average Total Offset % Authority criteria)</p> <p>High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is &gt;= 35 % for &gt;= 5.0 seconds AND the % Authority metric is approaching the failure threshold.</p> <p>Diagnosis resumes if the purge valve is closed OR the percent vapor is &lt;= 30 % for &gt;= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.</p>	<p>&gt;= 86.0 %</p> <p>&gt;= 60.0 %</p> <p>If the P2096 is actively failing then the Average Integral Offset must be &lt; 75.0 % and the Average Total Offset must be &lt; 200.0 % for the diagnostic to report a pass.</p>	<p>The post cat fuel trim diagnostic is enabled</p> <p>The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration</p> <p>Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp.</p> <p>PTO Intrusive diag. fuel control Ethanol Estimation in Progress</p> <p>02 Heater Learned Resistance</p> <p>Long Term Secondary Fuel Trim Enabled for (see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables)</p> <p>High Vapor Conditions</p> <p>Green Cat System</p>	<p>No No Yes Yes Yes</p> <p>&gt;= 70 kPa &gt;= 0.0 g/s&lt;= 10,000.0 &gt;= 0 kPa &lt;= 256 -20 deg. C 200 &gt;= -20 deg. C (or OBD Coolant Enable Criteria = TRUE)</p> <p>Not Active Not Active Not Active</p> <p>= Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>&gt;= 0.1 seconds</p> <p>Not Present</p> <p>= Not Valid,</p>	<p>Frequency: Continuous Monitoring in 100ms loop.</p> <p>The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 75.0 seconds (750 samples) before comparing to their respective failure thresholds.</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of "0" (i.e. 0% authority) and a post catalyst O <sub>2</sub> sensor that is within its optimal operating range (neither rich nor lean).			<p>Condition</p> <hr/> <p>Delay during GPF Regeneration</p> <p>If the diagnostic delays during a GPF Regen, it will continue to delay following completion of the Regen until the following number of samples have been accumulated. (1 sample = 100ms):</p> <p>Deceleration 0.00                      Idle 0.00                      Cruise 0.00                      Light Acceleration 0.00                      Heavy Acceleration 0.00</p> <hr/> <p>No Fault Active for:</p>	<p>Green Cat System condition is considered valid until the accumulated air flow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is above 22 grams/sec.</p> <hr/> <p>No Delay</p> <hr/> <p>AmbientAirDefault                      AIR System FA                      Ethanol Composition Sensor FA                      ECT_Sensor_FA                      EGRValveCircuit_FA                      EGRValvePerformance_FA                      IAT_SensorFA</p>		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>For the cells identified as enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions column), the minimum accumulated samples required before the fuel control metric is considered usable for that cell (1 sample = 100ms):</p> <p>Deceleration 300                      Idle 300                      Cruise 700                      Light Acceleration 300                      Heavy Acceleration 300</p>	CamSensorAnyLocationF A EvapEmissionSystem_FA EvapFlowDuringNonPurge_FA FuelTankPressureSnrCkt_FA EvapPurgeSolenoidCircuit_FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorTFTKO MAP_SensorFA MAP_EngineVacuumStatus EngineMisfireDetected_FA A/F Imbalance BankI O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(Note: A value in any of the above operating "cells" that is an order of magnitude (or more) higher than other cells is an indication that the diagnostic is not capable of diagnosing in that cell).			

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Rich Bank 1	P2097	<p>Determines if the post catalyst 02 sensor based fuel control system is indicating a rich exhaust gas condition. If the rich condition is such that the control system utilizes all or most of its available low limit authority (low limit = -100% authority), then P2097 will set.</p> <p>The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset.</p> <p>Note: When the post catalyst 02 voltage is too rich, the post catalyst 02 integral and proportional offset control is decreased (negative % authority). This applies a lean bias to fuel control in an attempt to counteract the rich condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral</p>	<p>The Average Integral Offset % Authority</p> <p>AND</p> <p>The Average Total Offset % Authority</p> <p>(Note: any value less than or equal to -100% effectively nullifies the Average Total Offset % Authority criteria)</p> <p>High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is &gt;= 35 % for &gt;= 5.0 seconds.</p> <p>Diagnosis resumes if the purge valve is closed OR the percent vapor is &lt;= 30 % for &gt;= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.</p>	<p>&lt;= -80.0 %</p> <p>&lt;= -50.0 %</p> <p>If the P2097 is actively failing then the Average Integral Offset must be &gt; -75.0 % and the Average Total Offset must be &gt; -200.0% for the diagnostic to report a pass.</p>	Same as P2096	Same as P2096	<p>Frequency: Continuous Monitoring in 100ms loop.</p> <p>The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 75.0 seconds (750 samples) before comparing to their respective failure thresholds.</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of "0" (i.e. 0% authority) and a post catalyst O <sub>2</sub> sensor that is within its optimal operating range (neither rich nor lean).						

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Lean Bank 2	P2098	<p>Determines if the post catalyst O2 sensor based fuel control system is indicating a lean exhaust gas condition. If the lean condition is such that the control system utilizes all or most of its available high limit authority (high limit = 100% authority), then P2098 will set.</p> <p>The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset.</p> <p>Note: When the post catalyst O2 voltage is too lean, the post catalyst O2 integral and proportional offset control is increased (positive % authority). This applies a rich bias to fuel control in an attempt to counteract the lean condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral</p>	<p>The Average Integral Offset % Authority</p> <p>AND</p> <p>The Average Total Offset % Authority</p> <p>(Note: any value greater than or equal to +100% effectively nullifies the Average Total Offset % Authority criteria)</p> <p>High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is &gt;= 35 % for &gt;= 5.0 seconds AND the % Authority metric is approaching the failure threshold.</p> <p>Diagnosis resumes if the purge valve is closed OR the percent vapor is &lt;= 30 % for &gt;= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.</p>	<p>&gt;= 87.0 %</p> <p>&gt;= 60.0 %</p> <p>If the P2098 is actively failing then the Average Integral Offset must be &lt; 75.0 % and the Average Total Offset must be &lt; 200.0 % for the diagnostic to report a pass.</p>	<p>The post cat fuel trim diagnostic is enabled</p> <p>The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration</p> <p>Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp.</p> <p>PTO Intrusive diag. fuel control Ethanol Estimation in Progress</p> <p>O2 Heater Learned Resistance</p> <p>Long Term Secondary Fuel Trim Enabled for (see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables)</p> <p>High Vapor Conditions</p> <p>Green Cat System</p>	  <p>No No Yes Yes Yes</p> <p>&gt;= 70 kPa &gt;= 0.0 g/s&lt;= 10,000.0 &gt;= 0 kPa &lt;= 256 -20 deg. C 200 &gt;= -20 deg. C (or OBD Coolant Enable Criteria = TRUE)</p> <p>Not Active Not Active Not Active</p> <p>= Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>&gt;= 0.1 seconds</p> <p>Not Present</p> <p>= Not Valid,</p>	<p>Frequency: Continuous Monitoring in 100ms loop.</p> <p>The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 75.0 seconds (750 samples) before comparing to their respective failure thresholds.</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of "0" (i.e. 0% authority) and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean).			<p>Condition</p> <hr/> <p>Delay during GPF Regeneration</p> <p>If the diagnostic delays during a GPF Regen, it will continue to delay following completion of the Regen until the following number of samples have been accumulated. (1 sample = 100ms):</p> <p>Deceleration 0.00                      Idle 0.00                      Cruise 0.00                      Light Acceleration 0.00                      Heavy Acceleration 0.00</p> <hr/> <p>No Fault Active for:</p>	<p>Green Cat System condition is considered valid until the accumulated air flow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is above 22 grams/sec.</p> <hr/> <p>No Delay</p> <hr/> <p>AmbientAirDefault                      AIR System FA                      Ethanol Composition Sensor FA                      ECT_Sensor_FA                      EGRValveCircuit_FA                      EGRValvePerformance_FA                      IAT_SensorFA</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>For the cells identified as enabled (i.e. those containing a "Yes" above), the minimum accumulated samples required before the fuel control metric is considered usable for that cell (1 sample = 100ms):</p> <p>Deceleration 300                      Idle 700                      Cruise 300                      Light Acceleration 300                      Heavy Acceleration 300</p>	CamSensorAnyLocationFA EvapEmissionSystem_FA EvapFlowDuringNonPurge_FA FuelTankPressureSnrCkt_FA EvapPurgeSolenoidCircuit_FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorTFTKO MAP_SensorFA MAP_EngineVacuumStatus EngineMisfireDetected_FA A/F Imbalance Bank2 O2S_Bank_2_8sensor_1_FA O2S_Bank_2_Sensor_2_FA		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Note: A value in any of the above operating "cells" that is an order of magnitude (or more) higher than other cells is an indication that the diagnostic is not capable of diagnosing in that cell).			



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Rich Bank 2	P2099	<p>Determines if the post catalyst O2 sensor based fuel control system is indicating a rich exhaust gas condition. If the rich condition is such that the control system utilizes all or most of its available low limit authority (low limit = -100% authority), then P2099 will set.</p> <p>The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset.</p> <p>Note: When the post catalyst O2 voltage is too rich, the post catalyst O2 integral and proportional offset control is decreased (negative % authority). This applies a lean bias to fuel control in an attempt to counteract the rich condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral</p>	<p>The Average Integral Offset % Authority</p> <p>AND</p> <p>The Average Total Offset % Authority</p> <p>(Note: any value less than or equal to -100% effectively nullifies the Average Total Offset % Authority criteria)</p> <p>High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is &gt;= 35 % for &gt;= 5.0 seconds.</p> <p>Diagnosis resumes if the purge valve is closed OR the percent vapor is &lt;= 30 % for &gt;= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.</p>	<p>&gt;= -80.0 %</p> <p>.</p> <p>&gt;= -50.0 %</p> <p>If the P2099 is actively failing then the Average Integral Offset must be &lt; -75.0 % and the Average Total Offset must be &lt; -200.0% for the diagnostic to report a pass.</p>	Same as P2098	Same as P2098	<p>Frequency: Continuous Monitoring in 100ms loop.</p> <p>The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 75.0 seconds (750 samples) before comparing to their respective failure thresholds.</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of "0" (i.e. 0% authority) and a post catalyst O <sub>2</sub> sensor that is within its optimal operating range (neither rich nor lean).						



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					active))			
			Throttle Position >	36.00 %	TPS minimum learn active AND Powertrain Relay Contactl Fault is FALSE (no P1682 fault) AND Throttle Control is not in Service or DVT control	= TRUE	11 counts;  12.5 ms/count in the primary processor	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Return to Default Performance	P2119	Throttle unable to return to default throttle position after de-energizing ETC motor.	(Normalized TPS1 percent Vref > AND Normalized TPS2 percent Vref > On the main processor)  OR  (Normalized TPS1 percent Vref < AND Normalized TPS2 percent Vref < On the main processor)  (100% corresponds to 5.0 Volt)	1.7560 % Vref  1.7590 % Vref    1.4340 % Vref  1.4310% Vref	Throttle de-energized due to one of the following conditions:  Powerup Default Learn OR Default Throttle Authority OR PT Relay Voltage OR Main System Shutdown OR Battery Saver Active OR (Powertrain Relay On AND Run/Crank Active)	= TRUE  = TRUE  < 5.500 Volts  = TRUE  = TRUE  = FALSE  = FALSE	0.4969 s if ETC motor command is STOP (when Default Throttle Authority or Main System Shutdown is causing Throttle de-energize)    5.0000 s if ETC motor command is not STOP	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detects a continuous or intermittent short low or open in the APP sensor #1 by monitoring the APP1 sensor percent Vref and failing the diagnostic when the APP1 percent Vref is too low. This diagnostic only runs when battery voltage is high enough. Detects a continuous or intermittent short low or open in the APP sensor #1 on the Main processor.	APP1 percent Vref < (100% corresponds to 5.0 Volt)	9.25 %Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P06A3	19/39 counts; or  14 counts continuous;  12.5 ms/count in the main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Hi	P2123	Detects a continuous or intermittent short high in the APP sensor #1 by monitoring the APP1 sensor percent Vref and failing the diagnostic when the APP1 percent Vref is too high. This diagnostic only runs when battery voltage is high enough. Detect a continuous or intermittent short high in the APP sensor #1 on the Main processor.	APP1 percent Vref > (100% corresponds to 5.0 Volt)	95.00 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	>6.41 Volts  P06A3	19/39 counts; or  14 counts continuous;  12.5 ms/count in the main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detects a continuous or intermittent short low or open in the APP sensor #2 by monitoring the APP2 sensor percent Vref and failing the diagnostic when the APP2 percent Vref is too low. This diagnostic only runs when battery voltage is high enough. Detects a continuous or intermittent short low or open in the APP sensor #2 on the Main processor.	APP2 percent Vref < (100% corresponds to 5.0 Volt)	6.50 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P0697	19/39 counts; or  14 counts continuous;  12.5 ms/count in the main processor	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detects a continuous or intermittent short high in the APP sensor #2 by monitoring the APP2 sensor percent Vref and failing the diagnostic when the APP2 percent Vref is too high. This diagnostic only runs when battery voltage is high enough. Detect a continuous or intermittent short high in the APP sensor #2 on the Main processor.	APP2 percent Vref >  (100% corresponds to 5.0 Volt)	52.00 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P0697	19/39 counts; or  14 counts continuous;  12.5 ms/count in the main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position (TP) Sensor 1-2 Correlation	P2135	Detect a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor. 1.) The diagnostic monitors the difference in position between TPS1 and the TPS2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. 2.) The diagnostic monitors the difference in reference voltage between normalized min TPS1 and the normalized min TPS2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	Difference between TPS1 displaced and TPS2 displaced >	6.797% offset at min. throttle position with a linear threshold to 9.720% at max. throttle position	Run/Crank voltage  No TPS sensor faults  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  (P0122, P0123, P0222, P0223)  P06A3	79/159 counts; or  58 counts continuous;  3.125 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min TPS1 ) and (normalized min TPS2) >  (100% corresponds to 5.0 Volt)	5.000 % Vref	Run/Crank voltage  No TPS sensor faults  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  (P0122, P0123, P0222, P0223)  P06A3	79/159 counts; or  58 counts continuous;  3.125 ms/count in the main processor	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detect a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor. 1.) The diagnostic monitors the difference in position between APP1 and the APP2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. 2.) The diagnostic also monitors the difference in reference voltage between normalized min APP1 and the normalized min APP2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >  (100% corresponds to 5.0 Volt)	5.000% offset at min. pedal position with a linear threshold to 10.001 % at max. pedal position	Run/Crank voltage  No APP sensor faults  No 5V reference errors or faultst for # 3 & # 4 5V reference circuits	> 6.41 Volts  (P2122, P2123.P2127, P2128)  (P06A3, P0697)	19/39 counts intermittent; or  15 counts continuous,  12.5 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min APP1 ) and (normalized min APP2) >  (100% corresponds to 5.0 Volt)	3.500 % Vref	Run/Crank voltage  No APP sensor faults  No 5V reference errors or faultst for # 3 & # 4 5V reference circuits	> 6.41 Volts  (P2122, P2123.P2127, P2128)  (P06A3, P0697)	19/39 counts intermittent; or  15 counts continuous,  12.5 ms/count in the main processor	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 high side circuit shorted to ground	P2147	Controller specific output driver circuit diagnoses Injector 1 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 high side circuit shorted to power	P2148	Controller specific output driver circuit diagnoses Injector 1 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 high side circuit shorted to ground	P2150	Controller specific output driver circuit diagnoses Injector 2 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 high side circuit shorted to power	P2151	Controller specific output driver circuit diagnoses Injector 2 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector3 high side circuit shorted to ground	P2153	Controller specific output driver circuit diagnoses Injector 3 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector3 high side circuit shorted to power	P2154	Controller specific output driver circuit diagnoses Injector 3 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 high side circuit shorted to ground	P2156	Controller specific output driver circuit diagnoses Injector 4 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 high side circuit shorted to power	P2157	Controller specific output driver circuit diagnoses Injector 4 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector5 high side circuit shorted to ground	P216B	Controller specific output driver circuit diagnoses Injector 5 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector5 high side circuit shorted to power	P216C	Controller specific output driver circuit diagnoses Injector 5 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 high side circuit shorted to ground	P216E	Controller specific output driver circuit diagnoses Injector 6 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 high side circuit shorted to power	P216F	Controller specific output driver circuit diagnoses Injector 6 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Minimum Throttle Position Not Learned	P2176	Detect when the throttle position minimum learn on the main processor is not learned. This diagnostic detects this by monitoring if the throttle position is greater than a threshold and the number of learn attempts is greater than a threshold. This diagnostic only runs when the battery voltage is high enough and the throttle position minimum learn is active. Throttle position sensors were not in the minmum learn window after multiple attempts to learn the minimum.	During TPS min learn on the Main processor, TPS percent Vref >  AND  Number of learn attempts >  (100% corresponds to 5.0 Volt)	11.48% Vref   10 counts	Run/Crank voltage  TPS minimum learn is active  No previous TPS min learn values stored in long term memory	> 6.41 Volts  = TRUE	2.0 secs	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 high side circuit shorted to ground	P217B	Controller specific output driver circuit diagnoses Injector 7 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 high side circuit shorted to power	P217C	Controller specific output driver circuit diagnoses Injector 7 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector8 high side circuit shorted to ground	P217E	Controller specific output driver circuit diagnoses Injector 8 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector8 high side circuit shorted to power	P217F	Controller specific output driver circuit diagnoses Injector 7 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>=11 Volts >=0 Seconds  P062B notFAorTFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 1 Air-Fuel Ratio Imbalance	P219A	<p>This monitor determines if there is an Air Fuel Imbalance in the fueling system for a cylinder on Bank 1. Detection is based on a the pre catalyst oxygen sensor voltage. The pre catalyst O2 voltage is used to generate a variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without).</p> <p>The observed Variance is dependent on engine speed and load and is normalized by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric.</p> <p>The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (see Supporting Table</p>	<p>Standard Mode Filtered Ratio</p> <p>The EWMA calculation uses the weighting coefficient from the following supporting table: <b>P219A EWMA Coefficient</b></p> <p>For this program, the Optional Mode is NOT used</p> <p>Optional Mode Filtered Ratio</p> <p>The EWMA calculation uses the weighting coefficient from the following supporting table while in Optional Mode:</p>	<p>&gt;0.45</p> <p>If the diagnostic has reported a failure on the prior trip, the EWMA Filtered Ratio must fall below 0.40 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing.</p> <p>&gt; 0.50</p> <p>If the diagnostic has reported a failure on the prior trip, the Optional Mode Filtered Ratio must fall below 0.35 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing.</p>	<p>The A/F imbalance diagnostic is enabled</p> <p>System Voltage</p> <p>Fuel Level</p> <p>Engine Coolant Temperature</p> <p>Cumulative engine run time</p> <p>Diagnostic enabled at Idle (regardless of other operating conditions)</p> <p>Engine speed range</p> <p>Engine speed delta during a short term sample period</p> <p>Mass Airflow (MAF) range</p> <p>Cumulative delta MAF during a short term sample period</p> <p>Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF</p>	<p>No lower than 10.0 Volts for more than 0.2 seconds</p> <p>&gt; 10.0% The diagnostic will disregard the fuel level criteria if the fuel sender is faulty.</p> <p>&gt; -20 deg. C (or OBD Coolant Enable Criteria = TRUE)</p> <p>&gt; 0.0 seconds</p> <p>No</p> <p>900 to 3,800 RPM</p> <p>&lt;200 RPM</p> <p>7 to 700 g/s</p> <p>&lt;6 g/s</p> <p>&lt;0.75 g/s</p>	<p>Minimum of 1 test per trip, up to 6 tests per trip during RSR or FIR.</p> <p>The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example, 10.80 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such significantly more operating time is required than is indicated above. Generally, a report will be</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p><b>P219A Variance Threshold Bankl Table</b> ) and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table (see Supporting Table <b>P219A Normalizer Bankl Table</b> ). This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (see Supporting Table <b>P219A Quality Factor Bankl Table</b> ) . This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used.</p> <p>Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered</p>	<b>P219A EWMA Coefficient Opt Table</b>		<p>= 0.050</p> <p>Air Per Cylinder (APC)</p> <p>APC delta during short term sample period</p> <p>Filtered APC delta between samples Note: first order lag filter coefficient applied to APC = 0.100</p> <p>Spark Advance</p> <p>Throttle Area (percent of max)</p> <p>Intake Cam Phaser Angle</p> <p>Exhaust Cam Phaser Angle</p> <p>-----</p> <p>Electronic Waste Gate (eWG) present</p> <p>If eWG = yes then Waste Gate Position</p> <p>Intrusive eWG Feature</p> <p>If intrusive Waste Gate positin is enabled then the electronic Waste Gate will be commanded to the following range when the other enable conditions have been met.</p> <p>Intrusive Waste Gate Position Min</p>	<p>150 to 850 mg/cylinder</p> <p>&lt;80mg/cylinder</p> <p>&lt;7.00 percent</p> <p>5 to 55 degrees</p> <p>2 to 100 percent</p> <p>0 to 30 degrees</p> <p>0 to 30 degrees</p> <p>No</p> <p>0.0 to 101.0</p> <p>Disabled</p> <p>0.0</p>	<p>made within 5 minutes of operation.</p> <p>For RSRorFIR, 12 tests must complete before the diagnostic can report.</p>	

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>Ratio.</p> <p>The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific.</p> <p>Some applications may need to command a unique cam phaser value before performing the above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use his feature.</p> <p>For programs using Active Fuel Management or Multiple Cam profiles, a secondary Imbalance Ratio can be calculated while in the secondary operating modes. This secondary ratio is an optional calculation and is labeled as the "Optional Mode Ratio". The Optional Mode Ratio is calculated the same as explained above with the following supporting</p>			<p>Intrusive Waste Gate Position Max</p> <hr/> <p>Delay during GPF Regeneration</p> <hr/> <p>Active Fuel Management Firing Fraction</p> <p>if the Optional Mode is enabled (see Malfunction Criteria) Active Fuel Management Firing fraction for Optional Mode calculations</p> <p>Intrusive Firing Fraction during Fast Initial Response or Rapid Step Response</p> <p>If the intrusive Firing Fraction feature is enabled the Active Fuel Management firing fraction will be forced to a value above this threshold when in Fast Initial Response or in Rapid Step Response.</p> <hr/> <p>For programs using multi-step cam profiles:</p> <p>High Lift Cam Profile will use:</p>	<p>101.0</p> <hr/> <p>No Delay</p> <hr/> <p>0.99 to 1.10</p> <p>0.99 to 0.01</p> <p>Disabled</p> <p>&gt;=0.99</p> <hr/> <p>Standard Mode Filtered Ratio</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>tables:  <b>P219A Variance Threshold Bankl Opt Table</b>  <b>P219A Normalizer Bankl Opt Table</b> ,                      and  <b>P219A Quality Factor Bankl Opt Table</b></p>			<p>Low Lift Cam Profile will use:</p> <p>Quality Factor (QF)                      QF calibrations are located in a 17x17 lookup table versus engine speed and load (see Supporting Table  <b>P219A Quality Factor Bankl Table</b> ).                      QF values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data.</p> <p>Fuel Control Status                      Closed Loop and Long Term FT Enabled for:</p> <p>Device Control                      AIR pump                      CASE learn                      EGR                      EVAP                      Engine Over Speed Protection                      Idle speed control                      PTO                      Injector base pulse width</p>	<p>Standard Mode Filtered Ratio</p> <p>&gt;=0.99</p> <p>&gt;= 1.2 seconds                      (Please see "<b>Closed Loop Enable Clarification</b>" and "<b>Long Term FT Enable Criteria</b>" in Supporting Tables)</p> <p>Not active                      Not on                      Not active                      Not intrusive                      Not intrusive                      Not Active                      Normal                      Not Active                      Above min pulse limit</p>		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>02 learned htr resistance</p> <p>Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is AND it exceeds the last Filtered ratio by</p> <p>Once triggered, the filtered ratio is reset to:</p> <p>Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to:</p> <p>No Fault Active for:</p>	<p>= Valid (the 02 heater resistance has learned since NVM reset)</p> <p>&gt;= 0.45</p> <p>&gt;=0.44</p> <p>0.00</p> <p>0.00</p> <p>MAP_SensorFA MAF_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDefaulted FuelInjectorCircuit_FA AIR_System FA EvapExcessPurgePsbl_FA CamSensorAnyLocationFA FuelTrimSystemB1_FA O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						WRAF_Bank_1_FA		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 2 Air-Fuel Ratio Imbalance	P219B	<p>This monitor determines if there is an Air Fuel Imbalance in the fueling system for a cylinder on a Bank 2. Detection is based on a the pre catalyst oxygen sensor voltage. The pre catalyst O2 voltage is used to generate a variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without).</p> <p>The observed Variance is dependant on engine speed and load and is normalized by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric.</p> <p>The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (see Supporting Table</p>	<p>Standard Mode Filtered Ratio</p> <p>The EWMA calculation uses the weighting coefficient from the following supporting table: <b>P219B EWMA Coefficient</b></p> <p>Optional Mode Filtered Ratio</p> <p>For this program the Optional Mode is NOT used</p> <p>The EWMA calculation uses the weighting coefficient from the following supporting table while in Optional Mode: <b>P219B EWMA Coefficient Opt Mode</b></p>	<p>&gt; 0.41</p> <p>If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.38 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing.</p> <p>&gt; 0.60</p> <p>If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.45 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing</p>	<p>The A/F imbalance diagnostic is enabled</p> <p>System Voltage</p> <p>Fuel Level</p> <p>Engine Coolant Temperature</p> <p>Cumulative engine run time</p> <p>Diagnostic enabled at Idle (regardless of other operating conditions)</p> <p>Engine speed range</p> <p>Engine speed delta during a short term sample period</p> <p>Mass Airflow (MAF) range</p> <p>Cumulative delta MAF during a short term sample period</p> <p>Filtered MAF delta between samples</p> <p>Note: first order lag filter coefficient applied to MAF = 0.050</p>	<p>No lower than 10.0 Volts for more than 0.2 seconds</p> <p>&gt; 10.0% The diagnostic will disregard the fuel level criteria if the fuel sender is faulty.</p> <p>&gt; -20 deg. C (or OBD Coolant Enable Criteria = TRUE)</p> <p>&gt; 0.0 seconds</p> <p>No</p> <p>900 to 3,800 RPM</p> <p>&lt; 200 RPM</p> <p>7 to 700 g/s</p> <p>&lt;6 g/s</p> <p>&lt;0.75 g/s</p>	<p>Minimum of 1 test per trip, up to 6 tests per trip during RSR or FIR.</p> <p>The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example, 10.80 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such significantly more operating time is required than is indicated above.</p> <p>Generally, a report will be made within 5</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p><b>P219B Variance Threshold Bank2 Table</b> ) and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table (see Supporting Table <b>P219B Normalizer Bank2 Table</b> ) This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (see Supporting Table <b>P219B Quality Factor Bank2 Table</b> ) . This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used.</p> <p>Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered</p>			<p>Air Per Cylinder (APC)</p> <p>APC delta during short term sample period</p> <p>Filtered APC delta between samples Note: first order lag filter coefficient applied to APC = 0.100</p> <p>Spark Advance</p> <p>Throttle Area (percent of max)</p> <p>Intake Cam Phaser Angle</p> <p>Exhaust Cam Phaser Angle</p> <hr/> <p>Electronic Waste Gate (eWG) present</p> <p>If eWG = yes then</p> <p>Waste Gate Position</p> <p>Intrusive eWG Feature</p> <p>If intrusive Waste Gate positin is enabled then the electronic Waste Gate will be commanded to the following range when the other enable conditions have been met.</p> <p>Intrusive Waste Gate</p>	<p>150 to 850 mg/cylinder</p> <p>&lt;80mg/cylinder</p> <p>&lt; 7.00 percent</p> <p>5 to 55 degrees</p> <p>2 to 100 percent</p> <p>0 to 30 degrees</p> <p>0 to 30 degrees</p> <hr/> <p>No</p> <p>0.0 to 101.0</p> <p>Disabled</p> <p>0.0</p>	<p>minutes of operation.</p> <p>For RSRorFIR, 12 tests must complete before the diagnostic can report. See P219Ainfo</p>	

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>Ratio.</p> <p>The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific.</p> <p>Some applications may need to command a unique cam phaser value before performing the above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use this feature.</p> <p>For programs using Active Fuel Management or Multiple Cam profiles a secondary Imbalance Ratio can be calculated while in the secondary operating modes. This secondary ratio is an optional calculation and is labeled as the "Optional Mode Ratio". The Optional Mode Ratio is calculated the same as explained above with the following supporting</p>			<p>Position Min</p> <p>Intrusive Waste Gate Position Max</p> <hr/> <p>Delay during GPF Regeneration</p> <hr/> <p>Active Fuel Management Firing Fraction</p> <p>if the Optional Mode is enabled (see Malfunction Criteria) Active Fuel Management Firing fraction for Optional Mode calculations</p> <p>Intrusive Firing Fraction during Fast Initial Response or Rapid Step Response</p> <p>If the intrusive Firing Fraction feature is enabled the Active Fuel Management firing fraction will be forced to a value above this threshold when in Fast Initial Response or in Rapid Step Response.</p> <hr/> <p>For programs using multi-step cam profiles:</p> <p>High Lift Cam Profile will use:</p>	<p>101.0</p> <hr/> <p>No Delay</p> <hr/> <p>0.99 to 1.10</p> <p>0.99 to 0.01</p> <p>Disabled</p> <p>&gt;=0.99</p> <hr/> <p>Standard Mode Filtered Ratio</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		tables: <b>P219B Variance Threshold Bank2 Opt Table</b> , <b>P219B Normalizer Bank2 Opt Table</b> , and <b>P219B Quality Factor Bank2 Table</b>			Low Lift Cam Profile will use:  Quality Factor (QF) QF calibrations are located in a 17x17 lookup table versus engine speed and load (Supporting Table <b>P219B Quality Factor Bank2 Table</b> ). QF values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data.  Fuel Control Status Closed Loop and Long Term FT Enabled for:  Device Control AIR pump CASE learn EGR EVAP Engine Over Speed Protection Idle speed control PTO  Injector base pulse width  02 learned htr resistance	Standard Mode Filtered Ratio  >=0.99  >= 1.2 seconds (Please see "Closed Loop Enable Clarification" and "Long Term FT Enable Criteria" in Supporting Tables)  Not active Not on Not active Not intrusive Not intrusive Not Active  Normal Not Active  Above min pulse limit  = Valid (the 02 heater resistance has learned		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is</p> <p>AND it exceeds the last Filtered ratio by</p> <p>Once triggered, the filtered ratio is reset to:</p> <p>Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to:</p> <p>No Fault Active for:</p>	<p>since NVM reset)</p> <p><math>\geq 0.36</math></p> <p><math>\geq 0.39</math></p> <p>0.00</p> <p>0.00</p> <p>MAP_SensorFA MAF_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDefaulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbI_FA CamSensorAnyLocationFA FuelTrimSystemB2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA WRAF_Bank_2_FA</p>		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (applications with LIN MAF)	P2228	<p>Detects an erroneously low value being reported over the LIN serial connection from the BARO sensor. The diagnostic monitors the BARO sensor pressure output and fails the diagnostic when the pressure is too low.</p> <p>The BARO sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure. The BARO pressure value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	BARO Pressure	< 50.0 kPa	<p>Diagnostic is Enabled</p> <p>LIN communications established with MAF</p>		<p>160 failures out of 200 samples</p> <p>1 sample every 25 msec</p>	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (applications with LIN MAF)	P2229	<p>Detects an erroneously high value being reported over the LIN serial connection from the BARO sensor. The diagnostic monitors the BARO sensor pressure output and fails the diagnostic when the pressure is too high.</p> <p>The BARO sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure. The BARO pressure value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	BARO Pressure	> 110.0 kPa	<p>Diagnostic is Enabled</p> <p>LIN communications established with MAF</p>		<p>160 failures out of 200 samples</p> <p>1 sample every 25 msec</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Intermittent (applications with LIN MAF)	P2230	<p>Detects a noisy or erratic signal in the barometric pressure (BARO) circuit by monitoring the BARO sensor and failing the diagnostic when the BARO signal has a noisier output than is expected.</p> <p>When the value of BARO in kilopascals (kPa) is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of BARO readings. The result of this summation is called a "string length".</p> <p>Since the BARO signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic BARO signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current BARO reading - BARO reading from 25 milliseconds previous)</p>	<p>&gt; 100 kPa</p> <p>40 consecutive BARO readings</p>	<p>Diagnostic is Enabled</p> <p>LIN communications established with MAF</p>		<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	<p>Type B, 2 Trips</p>

24OBDG06B HD ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Signal Stuck Lean Bank 1 Sensor 2	P2270	<p>The P2270 diagnostic is the first in a sequence of six intrusive secondary 02 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, &amp;P013B. ThisDTC determines if the secondary 02 sensor is stuck in a normal lean voltage range and thereby can no longer be used for secondary 02 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary 02 sensor does not achieve the required rich voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post 02 sensor signal</p> <p>AND</p> <p>The Accumulated mass airflow monitored during the Stuck Lean Voltage Test</p>	<p>&lt; 825mvolts</p> <p>&gt; 275 grams</p>	<p>Diagnostic is Enabled</p> <p>No Active DTCs</p> <p>B1S2 DTCs Not active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green 02S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA 02S_Bank_ 1_TFTK0 02S_Bank_ 2_TFTK0 P013A, P013B, P013E, P013F, P2270 or P2271 &gt;10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "H02S Heater Resistance DTCs" ) = Not Valid, Green 02S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Only when FuelLevelDataFault  Pedal position  Engine Airflow  Closed loop integral Closed Loop Active  Evap  Ethanol Estimation in Progress  Post fuel cell  Crankshaft Torque  EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time  Transmission Temp	Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.  = False  = False  < 20.0%  2.0 < gps < 35.0  0.75 < C/L Int < 1.08 = TRUE (Please see “ <b>Closed                      Loop Enable                      Clarification</b> ” in Supporting Tables).  not in control of purge  = Not Active (Please see “ <b>Ethanol                      Estimation in Progress</b> ” in Supporting Tables).  = Enabled, refer to <b>Multiple DTC Use -                      Block learn cells to                      enable Post oxygen                      sensor tests</b> for additional info. < 125.0 Nm  = not active  = not active  > 60.0 sec  > -40.0 °C		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Predicted Catalyst temp Fuel State  ===== All of the above met for at least 0.0 seconds, and then check the following  Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)  Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) ===== All of the above met for at least 0.5 seconds, and then the Force Cat Rich intrusive stage is requested. ===== During Stuck Lean test the following must stay TRUE or the test will abort: Commanded Fuel Crankshaft Torque	475 < °C < 1,000 = DFCO possible  =====  800 < RPM < 3,000  750 < RPM < 3,200  31.1 < MPH < 82.0  27.3 < MPH < 87.0   0.95 < EQR < 1.10 < 125.0 Nm		

24OBDG06B HD ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Signal Stuck Rich Bank 1 Sensor 2	P2271	<p>The P2271 diagnostic is the fourth in a sequence of six intrusive secondary 02 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, &amp;P013B. ThisDTC determines if the secondary 02 sensor is stuck in a normal rich voltage range and thereby can no longer be used for secondary 02 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary 02 sensor does not achieve the required lean voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post 02 sensor signal</p> <p>AND</p> <p>The Accumulated mass airflow monitored during the Stuck Rich Voltage Test</p>	<p>&gt; 150 mvolts</p> <p>&gt; 12.0 grams</p>	<p>Diagnostic is Enabled</p> <p>No Active DTCs</p> <p>B1S2 DTCs Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green 02S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA 02S_Bank_ 1_TFTK0 02S_Bank_ 2_TFTK0 P013A, P013B, P013E, P013F or P2270 &gt;10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTCs" ) = Not Valid, Green 02S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab.</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Only when FuelLevelDataFault  Fuel State  DTC's Passed  ===== After above conditions are met: DFCO mode is continued (w/o driver initiated pedal input).	Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.  = False = False = DFCO possible = P2270 = P013E = P013A  =====		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Signal Stuck Lean Bank 2 Sensor 2	P2272	<p>The P2272 diagnostic is the first in a sequence of six intrusive secondary 02 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, &amp;P013D. ThisDTC determines if the secondary 02 sensor is stuck in a normal lean voltage range and thereby can no longer be used for secondary 02 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary 02 sensor does not achieve the required rich voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post 02 sensor signal</p> <p>AND</p> <p>The Accumulated mass airflow monitored during the Stuck Lean Voltage Test</p>	<p>&lt; 825 mvolts</p> <p>&gt; 275 grams.</p>	<p>Diagnostic is Enabled</p> <p>No Active DTCs</p> <p>B2S2 DTCs Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green 02S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA 02S_Bank_ 1_TFTK0 02S_Bank_ 2_TFTK0</p> <p>P013C, P013D, P014A, P014B, P2272 or P2273</p> <p>&gt;10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "H02S Heater Resistance DTCs" )</p> <p>= Not Valid, Green 02S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 in Supporting Tables tab.</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Only when FuelLevelDataFault  Pedal position  Engine Airflow  Closed loop integral Closed Loop Active  Evap  Ethanol Estimation in Progress  Post fuel cell  Crankshaft Torque  EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time  Transmission Temp	Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.  = False = False < 20.0% 2.0 < gps < 35.0 0.75 < C/L Int < 1.08 = TRUE (Please see “ <b>Closed                      Loop Enable                      Clarification</b> ” in Supporting Tables).  not in control of purge  = Not Active (Please see “ <b>Ethanol                      Estimation in Progress</b> ” in Supporting Tables).  = Enabled, refer to <b>Multiple DTC Use -                      Block learn cells to                      enable Post oxygen                      sensor tests</b> for additional info. < 125.0 Nm  = not active = not active >= 60.0 sec > -40.0 °C		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Predicted Catalyst temp Fuel State  ===== All of the above met for at least 0.0 seconds, and then check the following  Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)  Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)  ===== All of the above met for at least 0.5 seconds, and then the Force Cat Rich intrusive stage is requested. ===== During Stuck Lean test the following must stay TRUE or the test will abort: Commanded Fuel Crankshaft Torque	475 < °C < 1,000 = DFCE possible  =====  800 < RPM < 3,000  750 < RPM < 3,200  31.1 < MPH < 82.0  27.3 < MPH < 87.0      0.95 < EQR < 1.10 < 125.0 Nm		

24OBDG06B HD ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
02 Sensor Signal Stuck Rich Bank 2 Sensor 2	P2273	<p>The P2273 diagnostic is the fourth in a sequence of six intrusive secondary 02 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, &amp;P013D. ThisDTC determines if the secondary 02 sensor is stuck in a normal rich voltage range and thereby can no longer be used for secondary 02 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary 02 sensor does not achieve the required lean voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post 02 sensor signal</p> <p>AND</p> <p>The Accumulated mass airflow monitored during the Stuck Rich Voltage Test</p>	<p>&gt; 150 mvolts</p> <p>&gt; 12.0 grams.</p>	<p>Diagnostic is Enabled</p> <p>No Active DTCs</p> <p>B2S2 DTCs Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green 02S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA 02S_Bank_ 1_TFTK0 02S_Bank_ 2_TFTK0 P013C, P013D, P014A, P014B or P2272 &gt;10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTCs" ) = Not Valid, Green 02S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 in Supporting Tables tab.</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Only when FuelLevelDataFault  Fuel State DTC's Passed  ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.  = False = False  = DFCO possible = P2272 = P014A = P013C  =====		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor C Circuit Low	P227C	<p>Detects an erroneously low value being reported over the LIN serial connection from the BARO C sensor. The diagnostic monitors the BARO C sensor pressure output and fails the diagnostic when the pressure is too low.</p> <p>The BARO C sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure. The BARO C pressure value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	BARO C Pressure	< 50.0 kPa	<p>Diagnostic is Enabled</p> <p>LIN communications established with MAF</p>		<p>160 failures out of 200 samples</p> <p>1 sample every 25 msec</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor C Circuit High	P227D	<p>Detects an erroneously high value being reported over the LIN serial connection from the BARO C sensor. The diagnostic monitors the BARO C sensor pressure output and fails the diagnostic when the pressure is too high.</p> <p>The BARO C sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure. The BARO C pressure value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	BARO C Pressure	> 110.0 kPa	<p>Diagnostic is Enabled</p> <p>LIN communications established with MAF</p>		<p>160 failures out of 200 samples</p> <p>1 sample every 25 msec</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor C Circuit Intermittent/ Erratic	P227E	<p>Detects a noisy or erratic signal in the barometric pressure (BARO) C circuit by monitoring the BARO C sensor and failing the diagnostic when the BARO C signal has a noisier output than is expected.</p> <p>When the value of BARO C in kilopascals (kPa) is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of BARO C readings. The result of this summation is called a "string length".</p> <p>Since the BARO C signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic BARO C signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current BARO C reading - BARO C reading from 25 milliseconds previous)</p>	<p>&gt; 100 kPa</p> <p>40 consecutive BARO C readings</p>	<p>Diagnostic is Enabled</p> <p>LIN communications established with MAF</p>		<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance	P228C	This DTC determines if the high pressure pump is not able to maintain target pressure. The fault is set if the measured fuel rail pressure is lower than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	>= <b>P228C P2C1F-High Pressure Pump Control (HPC) fail threshold of pressure too low</b> Mpa (see supporting tables)	High Pressure Pump Performance Diagnostic Enable  Battery Voltage  Low Side Fuel Pressure   Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP orTFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) andCam or Crank Sensor Not FA and IAT,IAT2,ECTNot FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and	True  >=11 Volts  > 0.275 MPa  Enabled when a code clear is not active or not exiting device control Engine is not cranking	Positive Pressure Error -  10.00 second failures out of 12.50 second samples	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine movement detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active  Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >=-40.0 degC -40 <=Temp degC <= 132		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance	P228D	This DTC determines if the high pressure pump is delivering high pressure that desired pressure. The fault is set if the measured fuel rail pressure is higher than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	<= <b>P228D P2C20 - High Pressure Pump Control (HPC) fail threshold for pressure too high</b> Mpa (see supporting tables)	High Pressure Pump Performance Diagnostic Enable  Battery Voltage  Low Side Fuel Pressure  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECTNot FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement	True  >=11 Volts  >0.275 MPa  Enabled when a code clear is not active or not exiting device control Engine is not cranking	Negative Pressure Error -  10.00 second failures out of 12.50 second samples	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active  Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -40.0 DegC -40 <= Temp degC <= 132		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT LOW	P2300	Diagnoses Cylinder #1 Ignition Control (E8T) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 100 0 impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT High	P2301	Diagnoses Cylinder #1 Ignition Control (E8T) output driver circuit for a Short to Power fault. Controller specific output driver circuit diagnoses the low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 100 0 impedance between signal and controller power	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT Low	P2303	Diagnoses Cylinder #2 Ignition Control (E8T) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 100 0 impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT High	P2304	Diagnoses Cylinder #2 Ignition Control (E8T) output driver circuit for a Short to Power fault	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 100 0 impedance between signal and controller power	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT Low	P2306	Diagnoses Cylinder #3 Ignition Control (E8T) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 100 0 impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT High	P2307	Diagnoses Cylinder #3 Ignition Control (E8T) output driver circuit for a Short to Power fault	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 100 0 impedance between signal and controller power	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT Low	P2309	Diagnoses Cylinder #4 Ignition Control (E8T) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 100 0 impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT High	P2310	Diagnoses Cylinder #4 Ignition Control (E8T) output driver circuit for a Short to Power fault	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 100 0 impedance between signal and controller power	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #5 CIRCUIT Low	P2312	Diagnoses Cylinder #5 Ignition Control (E8T) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 100 0 impedance between signal and controller power	Engine running  Ignition Voltage	> 11.0Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #5 CIRCUIT High	P2313	Diagnoses Cylinder #5 Ignition Control (E8T) output driver circuit for a Short to Power fault	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 100 0 impedance between signal and controller power	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #6 CIRCUIT Low	P2315	Diagnoses Cylinder #6 Ignition Control (E8T) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 100 0 impedance between signal and controller power	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #6 CIRCUIT High	P2316	Diagnoses Cylinder #6 Ignition Control (E8T) output driver circuit for a Short to Power fault	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	< 100 0 impedance between signal and controller power	<p>Engine running</p> <p>Ignition Voltage</p>	> 11.0 Volts	<p>50 Failures out of 63 Samples</p> <p>100 msec rate</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #7 CIRCUIT Low	P2318	Diagnoses Cylinder #7 Ignition Control (E8T) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 100 0 impedance between signal and controller power	Engine running  Ignition Voltage	> 11.0Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #7 CIRCUIT High	P2319	Diagnoses Cylinder #7 Ignition Control (E8T) output driver circuit for a Short to Power fault	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	< 100 0 impedance between signal and controller power	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #8 CIRCUIT Low	P2321	Diagnoses Cylinder #8 Ignition Control (E8T) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	< 100 0 impedance between signal and controller power	Engine running  Ignition Voltage	> 11.0Volts	50 Failures out of 63 Samples  100 msec rate	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #8 CIRCUIT High	P2322	Diagnoses Cylinder #8 Ignition Control (E8T) output driver circuit for a Short to Power fault	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	< 100 0 impedance between signal and controller power	<p>Engine running</p> <p>Ignition Voltage</p>	> 11.0 Volts	<p>50 Failures out of 63 Samples</p> <p>100 msec rate</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Torque Request Circuit	P2544	Determines if the torque request from the TCM is valid	Protect error - Serial Communication message 2's complement not equal (\$189/\$199)	Message <> two's complement of message	Diagnostic Status	Enabled	>= 16 failures out of 20 samples.  Performed on every received message  >= 6 Rolling count errors out of 10 samples.  Performed on every received message  >=6 range errors out of 10 samples.  Performed on every received message  >=5 multi-transitions out of 5 samples. Performed every 200 msec	Type B, 2 Trips
			OR Rolling count error - Serial Communication message (\$189/\$199) rolling count index value	Message <> previous message rolling count value + one	Power Mode	= Run		
			OR Range Error - Serial Communication message - (\$189/\$199) TCM Requested Torque Increase	> 725 Nm	Ignition Voltage	> 6.41 volts		
			OR Multi-transition error - Trans torque intervention type request change	Requested torque intervention type toggles from not increasing request to increasing request	Engine Running	= True		
					Run/Crank Active	> 0.50 Sec		
				No Serial communication loss to TCM (U0101)	No loss of communication			

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Off Timer Performance	P262B	<p>This DTC determines if the hardware timer does not initialize or count properly. There are two tests to ensure proper functioning of the timer: Count Up Test (CUT) and Range Test (RaTe).</p> <p>Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment.</p> <p>Range Test (RaTe): When the run/crank is not active both the hardware and mirror timers are started. The timers are compared when module shutdown is initiated or run/crank becomes active.</p>	<p>Count Up Test: Time difference between the current read and the previous read of the timer</p> <p>Range Test: The variation of the HWIO timer and mirror timer is</p>	<p>&gt; 1.50 seconds</p> <p>&gt; 0.25%.</p>			<p>Count Up Test: 8 failures out of 40 samples</p> <p>1 sec / sample</p> <p>Continuous while run/crank is not active and until controller shutdown is initiated.</p> <p>Range Test: Once per trip when controller shutdown is initiated or run/crank becomes active.</p>	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Serial Number Not Programmed or Incompatible	P264F	This DTC checks that the engine serial number is correctly written	At least one of the programmed engine serial number digits	=0xFF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 1	P30D6	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>=6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent  12.5 ms /count in the ECM main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 2	P30D7	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>=6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent  12.5 ms /count in the ECM main processor	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 3	P30D8	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>=6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent  12.5 ms /count in the ECM main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 4	P30D9	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>=6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent  12.5 ms /count in the ECM main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 5	P30DA	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>=6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent  12.5 ms /count in the ECM main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 6	P30DB	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>=6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent  12.5 ms /count in the ECM main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 7	P30DC	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>=6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent  12.5 ms /count in the ECM main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 8	P30DD	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>=6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent  12.5 ms /count in the ECM main processor	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Performance - Under Pressure	P3187	This DTC detects degradation in the performance of the electronically regulated fuel system by calculating the difference between the sensed, filtered system [line] pressure versus the ECM-commanded pressure [error calculation]. The calculated error is then compared to calibrated fault threshold tables for a fault decision.	Sensed Filtered Fuel System [line] pressure error	> Threshold  [Supporting Table] <b>P3187_Threshold</b>	a) Diagnostic is ..  b) Timer - Engine Running Minimum  c1) Fuel Flow Rate Valid  c2) Ambient Air Pressure Value Defaulted  c3) Fault bundle FDB_FuelPresSnsrCktFA  c4) Reference Voltage Fault Status [DTC P0641]  c5) Exhaust AfterTreatment Fuel Injector A Control Circuit Short Low Fault [DTC P20CD]  c6) Fuel Pres Sensor Performance Fault Active [DTC P018B]  c7) Use Calculated Flow Performance Fault Thresholds  c8) Engine Speed Status Valid  c9) Fault bundle FAB_FuelPmpCktFA  c10) Fuel Control Enable Fault Active [DTC P12A6]  c11) Fuel Pump Driver Module OverTemp Fault	a) Enabled  b) >= 30.00 seconds  c1) == TRUE  c2) == False  c3) == False  c4) == False  c5) == False  c6) == False  c7) == False  c8) ==TRUE  c9) == False  c10) == False  d 1) == False	1 sample/ 12.5 millisec	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Active [DTC P1255]  c12) Fuel Pump Speed Fault Active [DTCP129F]  c13) CAN Sensor Bus message \$0C3 Comm Fault [DTCP165C]  c14) CAN Sensor Bus Fuel Pmp Spd Command ARC and Checksum Comm Fault Code [DTC U18A7]  c15) Sensor Configuration [is Wired To FTZM?]  c16) Sensor Bus Relay On  d) Emissions Fuel Level Low [Message \$3FB]  e) Fuel Control Enable  f) Fuel Pump Control State  g) Input circuit minimum voltage  h) High Pres Fuel Pump Mode Management Active  j) High Pres Fuel Pump Control Mode  mI) Fuel Pmp Speed Command Alive Rollina	c12) == False  c13) == False  c14) == False  c15) == CeFDBR_e_WiredTo_FT ZM  c16) == TRUE  d) == False  e) == TRUE  f) == normal  g) >= 11.00 volts  h) == False  j) == Not Disabled Mode AND == Not ZeroFlow Mode  mI) == False		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Count and Checksum Error [CAN Bus C \$0CE] [DTC P14CD]  m2) CAN Sensor Bus message \$0C3 Available  m3) Fuel Pres Sensor Ref Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus C \$0C3] [DTC U18A7]  n) Timer - Diagnostic Enable	m2) == TRUE  m3) == False  n) > 2.00 seconds		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Performance - Over Pressure	P3188	This DTC detects degradation in the performance of the electronically regulated fuel system by calculating the difference between the sensed, filtered system [line] pressure versus the ECM-commanded pressure [error calculation]. The calculated error is then compared to calibrated fault threshold tables for a fault decision.	Sensed Filtered Fuel System [line] pressure error	<= Threshold [Supporting Table] <b>P3188_Threshold</b>	a) Diagnostic is ..  b1) CAN Sensor Bus Fuel Pmp Spd Command ARC and Checksum Comm Fault Code [Cmd1 DTC U131D]  b2) Sensor Configuration  b3) Fuel Pres Sensor Serial Comm Ready  b4) Fuel Pres Sensor Serial Comm Fault Pending [DTC P14D5]  b5) Sensed Fuel Control Enable Serial Comm Ready  b6) Sensed Fuel Control Enable Serial Comm Fault Pending  c1) Fuel Flow data Valid  c2) Ambient Air Pressure Value Defaulted  c3) Fuel Pres Sensor Type  c4) Fault Bundle FDB_FuelPresSnsrCktFA  c5) Reference Voltage	a) Enabled  b1) == False  b2) == CeFDBR_e_WiredTo_FT ZM  b3) == TRUE  b4) == False  b5) == TRUE  b6) == False  c1) == TRUE  c2) == False  c3) == CeFDBR_e_AbsolutePressure  c4) == False  c5) == False	1 sample/ 12.5 millisec	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Fault Status [DTC P0641]  c6) Fuel Pres Sensor Performance Fault Active [DTC P018B]  c7) Use Calculated Flow Performance Fault Thresholds  c8) Engine Speed Status Valid  c9) Fault bundle FAB_FuelPmpCktFA  c10) Fuel Pump Driver Module OverTemp Fault Active [DTC P1255]  c11) Fuel Pump Speed Fault Active [DTCP129F]  c12) Fuel Pump Duty Cycle Fault Active [DTC P2BB3]  c13) CAN Sensor Bus message \$0C3 Comm Fault [DTCP165C]  c14) Fuel Pres Sensor Serial Comm Fault Active [DTC P14D5]  c15) Sensor Bus Relay On  d1) Timer -- Minimum Engine Running  d2) Diaanostic Data	c6) == False  c7) == False  c8) ==TRUE  c9) == False  c10) == False  d 1) == False  c12) == False  c13) ==False  c14) == False  c15) == TRUE  d1)>= 30.00 seconds  d2) == TRUE		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Integrity OK  e) Fuel Control Enable  f) Fuel Pump Control State    g) Instantaneous Fuel Flow  h) Fuel Control Enable Fault Active [DTC P12A6]  j) Emissions Fuel Level Low [Message \$3FB]  k) High Pres Fuel Pump Mode Management Enabled  l) High Pres Fuel Pump Control Mode  m) Diagnostic Data OK  n) Timer - Diagnostic Enable	e) == TRUE  f) == Normal  AND  == NOT Over Response Active  g) >= 0.05 gms /sec  h) == False  j) == False  k) == False  l) == NOT Disabled Mode AND NOT Over Response Active Mode  m) == TRUE  n) > 2.00 seconds		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If OBDII: Run/Crank ignition voltage  If EOBD: Run/Crank ignition voltage  If Secure: Starter motor engaged for Or Run/Crank ignition voltage  If Hybrid Secure: Run/Crank ignition voltage  If power mode = Accessory:  Off key cycle diagnostics are enabled Or Controller is an OBD controller  Controller shutdown is not impending  Power Mode is not run/ crank  Battery voltage	>=11.00 Volts  >=9.00 Volts  > 15,000.00 milliseconds  > 8.41 Volts  >=6.41 Volts  Enabled  >=11.00 Volts		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If OBDII: Run/Crank ignition voltage  If EOBD: Run/Crank ignition voltage  If Secure: Starter motor engaged for Or Run/Crank ignition voltage  If Hybrid Secure: Run/Crank ignition voltage  If power mode = Accessory:  Off key cycle diagnostics are enabled Or Controller is an OBD controller  Controller shutdown is not impending  Power Mode is not run/ crank  Battery voltage	>=11.00 Volts  >=9.00 Volts  > 15,000.00 milliseconds  > 8.41 Volts  >=6.41 Volts  Enabled  >=11.00 Volts		





24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If calibratable low voltage disable mode is not Never Disabled  Low voltage disable mode: OBDII  If OBDII: Run/Crank ignition voltage  If EOBD: Run/Crank ignition voltage  If Secure: Starter motor engaged for Or Run/Crank ignition voltage  If Hybrid Secure: Run/Crank ignition voltage  If power mode = Accessory:  Off key cycle diagnostics are enabled Or Controller is an OBD controller  Controller shutdown is not impending  Power Mode is not run/ crank  Battery voltage	>=11.00 Volts  >=9.00 Volts  > 15,000.00 milliseconds > 8.41 Volts  >=6.41 Volts  Enabled  >=11.00 Volts		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Message \$4C5	>10,000.00 milliseconds	If calibratable low voltage disable mode is not Never Disabled			
			Message \$4E1	>10,000.00 milliseconds	Low voltage disable mode: OBDII			
			Message \$4E9	>10,000.00 milliseconds	If OBDII: Run/Crank ignition voltage	>=11.00 Volts		
					If EOBD: Run/Crank ignition voltage	>=9.00 Volts		
					If Secure: Starter motor engaged for Or Run/Crank ignition voltage	> 15,000.00 milliseconds > 8.41 Volts		
					If Hybrid Secure: Run/Crank ignition voltage	>=6.41 Volts		
					If power mode = Accessory:			
					Off key cycle diagnostics are enabled Or Controller is an OBD controller	Enabled		
					Controller shutdown is not impending			
					Power Mode is not run/ crank			
					Battery voltage	>=11.00 Volts		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Throttle Position Sensor 1	U0606	<p>Detects a continuous or intermittent short low or short high or open fault in the TPS SENT Communication Circuit 1 by monitoring the voltage and failing the diagnostic when the voltage for the wave pulse is below or above state threshold as defined by SAE J2716 SENT Protocol.</p> <p>Detects a message fault in the TPS SENT Communication Circuit by monitoring the message pulse time and failing the diagnostic when the time for the pulse is below a low time threshold or above a high time threshold or if the message age limit is greater than a time threshold.</p> <p>This diagnostic only runs when battery voltage is high enough.</p>	<p>Voltage for wave pulse is below state threshold as defined by SAE J2716 SENT Protocol</p> <p>OR</p> <p>Voltage for wave pulse is above state threshold as defined by SAE J2716 SENT Protocol</p> <p>OR</p> <p>Message Pulse &lt; Message Pulse &gt;</p> <p>OR</p> <p>Message Age Limit &gt;=</p> <p>OR</p> <p>Signal CRC fails</p>	<p>0.5 V</p> <p>OR</p> <p>4.1 V</p> <p>OR</p> <p>0.125977 ms 0.209991 ms</p> <p>OR</p> <p>3.125 ms</p>	Run/Crank voltage	> 6.41 Volts	<p>79/159 counts;</p> <p>57 counts continuous;</p> <p>3.125 ms /count in the ECM main processor</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Throttle Position Sensor 2	U0607	<p>Detects a continuous or intermittent short low or short high or open fault in the TPS SENT Communication Circuit 2 by monitoring the voltage and failing the diagnostic when the voltage for the wave pulse is below or above state threshold as defined by SAE J2716 SENT Protocol.</p> <p>Detects a message fault in the TPS SENT Communication Circuit by monitoring the message pulse time and failing the diagnostic when the time for the pulse is below a low time threshold or above a high time threshold or if the message age limit is greater than a time threshold.</p> <p>This diagnostic only runs when battery voltage is high enough.</p>	<p>Voltage for wave pulse is below state threshold as defined by SAE J2716 SENT Protocol</p> <p>OR</p> <p>Voltage for wave pulse is above state threshold as defined by SAE J2716 SENT Protocol</p> <p>OR</p> <p>Message Pulse &lt; Message Pulse &gt;</p> <p>OR</p> <p>Message Age Limit &gt;=</p> <p>OR</p> <p>Signal CRC fails</p>	<p>0.5 V</p> <p>OR</p> <p>4.1 V</p> <p>OR</p> <p>0.125977 ms 0.209991 ms</p> <p>OR</p> <p>3.125 ms</p>	Run/Crank voltage	> 6.41 Volts	<p>79/159 counts;</p> <p>57 counts continuous;</p> <p>3.125 ms /count in the ECM main processor</p>	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Mass or Volume Air Flow Sensor A	U060F	This DTC monitors for a loss of communication on the LIN bus with Mass or Volume Air Flow Sensor A.	Message is not received from device for  MAF_Rsp_Press_2B_C03  MAF_Rsp_TmpHum_2A_C03	>=62.50 milliseconds   >= 250.00 milliseconds	General Enable Criteria:  Diagnostic is enabled  LIN channel is enabled  LIN module is initialized  Slave is calibrated as present  All below criteria have been met for  Accessory mode to off mode not pending  Battery voltage  Conroller is an OBD controller Or Battery Voltage  Controller type: OBD Controller  If power mode = Run/ Crank:  Power Mode is run  If calibratable low voltage disable mode is not Never Disabled  Low voltage disable mode: OBDII  IfOBDII: Run/Crank ignition	Enabled  Enabled      >= 3,000.00 milliseconds   >11.00 Volts   <=18.00 Volts         >=11.00 Volts	LIN bus communication executes in 500ms loop.	Type B, 2 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					voltage  If EOBD: Run/Crank ignition voltage  If Secure: Starter motor engaged for Or Run/Crank ignition voltage  If Hybrid Secure: Run/Crank ignition voltage  If power mode = Accessory:  Off key cycle diagnostics are enabled Or Controller is an OBD controller  Controller shutdown is not impending  Power Mode is not run/ crank  Battery voltage	>=9.00 Volts  > 15,000.00 milliseconds  > 8.41 Volts  >=6.41 Volts  Enabled  >=11.00 Volts		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication with Fuel Rail Pressure Sensor Bank 1	U0625	This DTC determines if the SENT signal shorted low, this is determined by monitoring the number pulses on the SENT signal line received at the ECU and the SENT Signal Line State always indicating low.	The number pulses on the SENT signal line  SENT Signal Line State	<= 5  = Low	SENT Sensor Communication Circuit Diagnostic Enabled  SENT power up delay	True  >= 0.00 seconds  Enabled when a code clear is not active or not exiting device control	400 failures out of 500 samples  6.25 ms per sample Continuous	Type A, 1 Trips

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Fuel Rail Pressure Sensor Bank1 Sensor 2	U101B	This DTC determines if the SENT signal shorted low, this is determined by monitoring the number pulses on the SENT signal line received at the ECU and the SENT Signal Line State always indicating high.	The number pulses on the SENT signal line  SENT Signal Line State	<= 5  = High	SENT Sensor Communication Circuit Diagnostic Enabled  SENT power up delay	True  >= 0.00 seconds  Enabled when a code clear is not active or not exiting device control	400 failures out of 500 samples  6.25 ms per sample Continuous	Type A, 1 Trips



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Run/Crank ignition voltage	>=11.00 Volts		
					If EOBD: Run/Crank ignition voltage	>= 9.00 Volts		
					If Secure: Starter motor engaged for Or Run/Crank ignition voltage	> 15,000.00 milliseconds  > 8.41 Volts		
					If Hybrid Secure: Run/Crank ignition voltage	>=6.41 Volts		
					If power mode = Accessory			
					Off key cycle diagnostics are enabled Or Controller is an OBD controller	Enabled		
					Controller shutdown not impending			
					Power Mode is not run/ crank			
					Battery voltage	>=11.00 Volts		
					LIN channel Wakeup Method:			
					Diagnostic is enabled	Enabled		
					LIN channel is enabled	Enabled		
					LIN channel is requesting			

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					full communications LIN module is initialized The following criteria have been enabled for: Accessory mode to off mode not pending Battery voltage Controller is an OBD controller Or Battery Voltage	>= 3,000.00 milliseconds  >11.00 Volts  <=18.00 Volts		



24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If calibratable low voltage disable mode is not Never Disabled  Low voltage disable mode: OBDII  If OBDII: Run/Crank ignition voltage  If EOBD: Run/Crank ignition voltage  If Secure: Starter motor engaged for Or Run/Crank ignition voltage  If Hybrid Secure: Run/Crank ignition voltage  If power mode = Accessory:  Off key cycle diagnostics are enabled Or Controller is an OBD controller  Controller shutdown is not impending  Power Mode is not run/ crank  Battery voltage	>=11.00 Volts     >=9.00 Volts   > 15,000.00 milliseconds Or > 8.41 Volts  >=6.41 Volts   Enabled          >=11.00 Volts		

24OBDG06B HD ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Input Power Circuit A - Ignition Input On/Start Circuit Correlation	U3023	Detect a Power A vs RunCrank correlation error	Power A- RunCrank - Voltage	> 3.00	PowerA- RunCrank Correlation monitoring enable = TRUE  Battey Present  RunCrank Active  Starter Motor NOT Engaged	Diagnostcis 1.00  Battey Present = TRUE RunCrank Active = TRUE  Starter Motor Engaged = FALSE	50.00 failures out of 63.00	Type B, 2 Trips



**Initial Supporting table - CalculatedPerfMaxIcl**

**Description:** Maximum desired camshaft position for Intake CAM - BankI

**Value Units:** Maximum desired camshaft position (degCam)

**X Unit:** Engine Oil Temperature (degC)

[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]

[-40 -28 -16 -4 8 20 32 44 56 68 80 92 104 116 128 140 152]

**Y Units:** Engine Speed (rpm)

[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]

[400 800 1200 1600 2000 2400 2800 3200 3600 4000 4400 4800 5200 5600 6000 6400 6800]

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
2	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
3	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
4	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
5	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
6	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
7	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
8	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
9	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
10	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
11	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
12	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
13	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
14	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
15	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
16	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
17	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0

### Initial Supporting table - P0521 P06QD\_P06DE\_OP\_HiStatePressure

**Description:** Two Stage Oil Pump Oil Pressure in High State

**Value Units:** Nominal high state oil pressure (kPa)

**X Unit:** Engine oil temperature, °C

y/x	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0
1,000.0	435.8	418.8	398.9	371.3	358.8	340.5	314.3	297.4	277.6
1,500.0	464.1	453.8	429.1	423.1	388.2	374.3	358.9	327.9	308.1
2,000.0	509.7	488.7	442.9	453.9	409.6	411.4	377.4	352.4	332.6
2,500.0	516.6	497.7	455.1	465.3	426.5	402.4	391.6	370.9	351.0
3,000.0	522.8	491.5	485.4	455.4	443.8	416.1	403.4	383.3	363.5
3,500.0	533.1	508.9	501.6	484.1	454.7	425.6	410.2	389.8	369.9
4,000.0	535.2	515.9	503.8	492.4	452.3	422.6	413.1	390.3	370.4
4,500.0	531.3	511.9	509.3	475.4	435.7	401.8	402.2	384.7	364.9
5,000.0	518.1	497.7	480.4	451.5	430.3	405.7	389.3	373.2	353.3

**Initial Supporting table - P0521 P06DD\_P06DE\_OP\_LoStatePressure**

**Description:** Two Stage Oil Pump Oil Pressure in Low State

**Value Units:** Nominal low state oil pressure (kPa)

**X Unit:** Engine oil temperature (deg C)

y/x	40	50	60	70	80	90	100	110	120
1,000	313	305	281	273	268	263	254	241	235
1,500	336	326	300	310	286	289	274	260	254
2,000	364	342	316	327	300	304	288	276	270
2,500	375	351	329	334	318	294	296	289	283
3,000	391	354	343	334	328	300	301	299	293
3,500	407	371	357	344	330	305	302	305	300
4,000	422	389	380	366	345	306	301	308	303
4,500	430	402	375	357	340	305	298	308	303
5,000	421	399	367	352	335	302	296	305	300

**Initial Supporting table - P06DD\_P06DE\_MaxEnableTorque\_OP**

**Description:** Two Stage Oil Pump Rationality Test Torque Max Enable Threshold

**Value Units:** Maximum engine torque (Nm)

**X Unit:** Engine speed (RPM)

y/x	1,000.0	1,250.0	1,500.0	1,750.0	2,000.0	2,250.0	2,500.0	2,750.0	3,000.0
1.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0

**Initial Supporting table - P06DD\_P06DE\_MinEnableTorque\_OP**

**Description:** Two Stage Oil Pump Rationality Test Torque Min Enable Threshold

**Value Units:** Min engine torque (Nm)

**X Unit:** Engine speed (RPM)

y/x	1,000.0	1,250.0	1,500.0	1,750.0	2,000.0	2,250.0	2,500.0	2,750.0	3,000.0
1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

## Initial Supporting table - P06DD\_P06DE\_MinOilPressThresh

**Description:** Intrusive diagnostic minimum pressure limit that is a function of Engine Speed and Oil Temperature

**Value Units:** Minimum engine oil pressure threshold (kPa)

**X Unit:** Engine oil temperature (deg C)

y/x	40	50	60	70	80	90	100	110	120
1,000	83	83	83	83	83	83	83	83	83
1,500	106	106	106	106	106	106	106	106	106
2,000	116	116	116	116	116	116	116	116	116
2,500	127	127	127	127	127	127	127	127	127
3,000	137	137	137	137	137	137	137	137	137
3,500	147	147	147	147	147	147	147	147	147
4,000	191	191	191	191	191	191	191	191	191
4,500	200	200	200	200	200	200	200	200	200
5,000	208	208	208	208	208	208	208	208	208

## Initial Supporting table - P06DD P06DE\_OP\_StateChangeMin

**Description:** Minimum allowed pressure change on a Two Stage Oil Pump state change

**Value Units:** Min pressure change (kPa)

**X Unit:** Engine oil temperature (deg C)

y/x	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0
1,000.0	29.2	20.6	17.8	21.4	19.2	15.6	13.3	10.0	10.0
1,500.0	33.1	25.2	22.8	29.1	22.3	19.9	16.9	10.0	10.0
2,000.0	36.4	29.9	27.8	32.9	27.1	23.5	15.5	10.0	10.0
2,500.0	37.5	35.4	28.7	30.9	31.1	25.5	14.0	10.0	10.0
3,000.0	29.6	37.6	28.1	30.4	29.5	23.4	10.8	10.0	10.0
3,500.0	26.1	37.3	33.9	35.1	31.1	23.7	10.3	10.0	10.0
4,000.0	28.1	31.2	34.6	32.6	29.2	21.1	12.0	10.0	10.0
4,500.0	23.1	32.6	30.4	32.9	29.8	26.4	23.6	10.0	10.0
5,000.0	15.0	19.3	21.1	20.3	15.5	13.9	11.4	10.0	10.0

**Initial Supporting table - P0128 Maximum Acculated Energy - Primary**

**Description:** KtETHD\_E\_EOR\_WrmllpEnrgyLimTestO

**Value Units:** Cooling system energy failure threshold (kJ)

**X Unit:** Minimum ECT for the key cycle (°C)

y/x	-20.0	-7.0	10.0	30.0	45.0	60.0	75.0
1.0	27,186.1	23,312.1	18,246.1	12,286.0	7,816.0	7,816.0	7,816.0



**Initial Supporting table - P0128 Maximum Acculated Energy - Secondary**

**Description:** KtETHD\_E\_EOR\_WrmllpEnrgyLimTest1

**Value Units:** Cooling system energy failure threshold (kJ)

**X Unit:** Minimum ECT for the key cycle (°C)

y/x	-20.0	-7.0	10.0	30.0	45.0	60.0	75.0
1.0	18,666.3	18,666.3	14,197.5	8,942.2	5,000.0	5,000.0	5,000.0

**Initial Supporting table - P0128 Maximum Acculated Energy - Tertiary**

**Description:** KtETHD\_E\_EOR\_WrmlpEnrgyLimTest2

**Value Units:** Cooling system energy failure threshold (kJ)  
**X Unit:** Minimum ECT for the key cycle (°C)

y/x	-20.0	-7.0	10.0	30.0	45.0	60.0	75.0
1.0	18,666.3	18,666.3	14,197.5	8,942.2	5,000.0	5,000.0	5,000.0

**Initial Supporting table - P01F0 - Heat To Coolant Min 2D**

**Description:** KtETHD\_P\_CDD\_HeatToCoolantMin

**Value Units:** Indicated Power (kW)

**X Unit:** Firing Fraction

**Y Units:** Ambient temperature (°C)

y/x	0.00	0.25	0.50	0.75	1.00
-20.0	20.0	20.0	20.0	20.0	20.0
-9.0	20.0	20.0	20.0	20.0	20.0
10.0	15.0	15.0	15.0	15.0	15.0
20.0	15.0	15.0	15.0	15.0	15.0
50.0	15.0	15.0	15.0	15.0	15.0

**Initial Supporting table - P219A EWMA Coefficient**

**Description:** The bank 1 EWMA coefficient used to filter the AFIM Variance Ratio.

**Value Units:** Unitless Scalar  
**X Unit:** Unitless Scalar

y/x	-1.00	-0.50	0.00	0.50	1.00
1	0.05	0.10	0.15	0.10	0.05

**Initial Supporting table - P219A EWMA Coefficient Opt Table**

**Description:** The bank 1 EWMA coefficient used to filter the AFIM Variance Ratio while in Optional Mode, if used.

**Value Units:** Unitless Scalar

**X Unit:** Unitless Scalar

y/x	-1.00	-0.50	0.00	0.50	1.00
1.0	0.10	0.20	0.50	0.20	0.10

**Initial Supporting table - P219A Quality Factor Bank1 Table**

**Description:** Bank 1 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

**Value Units:** Unitless Scalar

**X Unit:** Engine Speed (RPM)

**Y Units:** Air Per Cylinder (APC) (mg/cylinder)

y/x	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,200	3,400	3,600	3,800	4,000
120	0.00	0.00	0.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
160	0.00	0.00	0.00	1.00	0.00	0.00	0.00	1.00	0.00	0.00	0.00	0.00	1.00	0.00	0.00	0.00	0.00
200	1.00	0.00	1.00	1.00	0.00	1.00	0.00	0.00	1.00	0.00	0.00	0.00	1.00	0.00	0.00	0.00	0.00
240	1.00	1.00	1.00	1.00	1.00	1.00	0.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
280	0.00	1.00	1.00	1.00	1.00	1.00	0.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
320	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	1.00	0.00	0.00	0.00	0.00
360	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
400	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
440	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
480	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
520	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
560	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
600	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
700	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
750	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

**Initial Supporting table - P219B EWMA Coefficient**

**Description:** The bank 2 EWMA coefficient used to filter the AFIM Variance Ratio.

**Value Units:** Unitless Scalar

**X Unit:** Unitless Scalar

y/x	-1.00	-0.50	0.00	0.50	1.00
1.0	0.05	0.10	0.15	0.10	0.05

**Initial Supporting table - P219B EWMA Coefficient Opt Mode**

**Description:** The bank 2 EWMA coefficient used to filter the AFIM Variance Ratio while in Optional Mode, if used.

**Value Units:** Unitless Scalar

**X Unit:** Unitless Scalar

y/x	-1.00	-0.50	0.00	0.50	1.00
1.0	0.10	0.20	0.50	0.20	0.10



**Initial Supporting table - P219B Quality Factor Bank2 Table**

**Description:** Bank 2 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

**Value Units:** Unitless Scalar

**X Unit:** Engine Speed (RPM)

**Y Units:** Air Per Cylinder (APC) (mg/cylinder)

y/x	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,200	3,400	3,600	3,800	4,000
120	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
160	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
200	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
240	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
280	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
320	0.00	1.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
360	0.00	0.00	0.00	1.00	1.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
400	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
440	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
480	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
520	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
560	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
600	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
700	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
750	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

### Initial Supporting table - P0330\_OpenCktThrshMax2 (20kHz)

**Description:** Max threshold table for the 20 KHz portion of the open circuit diagnostic for sensor 2. The lookup into this table will be filtered to define the max threshold for the filtered intensity. To fail, the filtered intensity needs to fall between this cal and the min cal filters.

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	8.949	9.000	9.029	9.020	8.988	8.920	8.828	8.699	8.549	8.359	8.148	7.898	7.629	7.318	6.988	6.619	6.229

**Initial Supporting table - P0330\_OpenCktThrshMax2 (NN)**

**Description:** Max threshold table for the Normal Noise for sensor 2. The lookup into this table will be filtered to define the max threshold for the filtered intensity. To fail, the filtered intensity needs to fall between this cal and the min cal filters.

y/x	2,700	2,900	3,000	3,250	3,500	3,750	4,000	4,250	4,500	4,750	5,000	5,500	6,000	6,500	7,000	7,500	8,500
1	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000

### Initial Supporting table - P0330\_OpenCktThrshMin2 (20 kHz)

**Description:** Min threshold table for the Normal Noise portion of the open circuit diagnostic. The lookup into this table will be filtered to define the max threshold for the filtered intensity. To fail, the filtered intensity needs to fall between this cal and the max cal filters.

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	2.689	2.760	2.809	2.840	2.850	2.840	2.809	2.760	2.689	2.600	2.488	2.359	2.209	2.039	1.850	1.639	1.408

### Initial Supporting table - P0330\_OpenCktThrshMin2 (NN)

**Description:** Min threshold table for the Normal Noise portion of the open circuit diagnostic for sensor 2. The lookup into this table will be filtered to define the max threshold or the filtered intensity. To fail, the filtered intensity needs to fall between this cal and the max cal filters.

y/x	2,700	2,900	3,000	3,250	3,500	3,750	4,000	4,250	4,500	4,750	5,000	5,500	6,000	6,500	7,000	7,500	8,500
1	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000

### Initial Supporting table - P0331\_AbnormalLo2

**Description:** The low limit (no Hi limit, left for excessive knock) for sensor 2 for the performance diagnostic, abnormal noise; used for per sensor and per cyl performance diagnostics. The lookup in this table as a function of RPM and APC is then filtered using KeKNKD\_k\_PerfAbnFilter (KeKNKD\_k\_PerfCylAbnFilter for per cyl), and then this filtered quantity VaKNKD\_k\_PerfAbnFiltLimitLo (VaKNKD\_k\_PerfCylAbnFiltLimitLo for per cyl) becomes the actual limit. The code will immediately set if the filtered intensity goes below the filtered threshold

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.060	0.060	0.060	0.060	0.060	0.069	0.149	0.239	0.340	0.449	0.569	0.699	0.840	0.840	0.840	0.840	0.840

### Initial Supporting table - P0331\_AbnormalLoAFM\_2

**Description:** The low limit for AFM mode (no Hi limit, left for excessive knock) for sensor 2 for the performance diagnostic, abnormal noise; used for per sensor and per cyl performance diagnostics. The lookup in this table as a function of RPM and APC is then filtered using KeKNKD\_k\_PerfAbnFilter (KeKNKD\_k\_PerfCylAbnFilter for per cyl), and then this filtered quantity VaKNKD\_k\_PerfAbnFiltLimitLo (VaKNKD\_k\_PerfCylAbnFiltLimitLo for per cyl) becomes the actual limit. The code will immediately set if the filtered intensity goes below the filtered threshold

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.060	0.060	0.060	0.060	0.060	0.069	0.149	0.239	0.340	0.449	0.569	0.699	0.840	0.840	0.840	0.840	0.840

### Initial Supporting table - P06B7\_OpenTestCktMax2

**Description:** Max threshold table for the 20 KHz for the test circuit diagnostic for sensor 2. The lookup into this table will be filtered to define the max threshold for the filtered intensity. To fail, the filtered intensity needs to fall between this cal and the min cal filters.

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.049	0.100	0.119	0.180	0.299	0.398	0.510	0.520	0.529	0.750	1.100	1.398	1.600	1.799	2.000	2.199	2.398



### Initial Supporting table - P06B7\_OpenTestCktMin2

**Description:** Min threshold table for the 20 KHz for the test circuit diagnostic for sensor 2. The lookup into this table will be filtered to define the max threshold for the filtered intensity. To fail, the filtered intensity needs to fall between this cal and the max cal filters.

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.000	0.000	0.000	0.020	0.020	0.049	0.078	0.119	0.129	0.158	0.180	0.199	0.219	0.260	0.299	0.318	0.340

**Initial Supporting table - Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests**

**Description:** This table describes the adaptive (Block Learn) cells in which to enable the Post (Secondary) Oxygen sensor response tests.  
 Note: When the table column heading matches the calibration value below it, that individual cell is enabled.

The cell numbers in the table are defined as:  
 CeFADR\_e\_Cell00\_PurgOnAirMode5 = 0,  
 CeFADR\_e\_Cell01\_PurgOnAirMode4 = 1,  
 CeFADR\_e\_Cell02\_PurgOnAirMode3 = 2,  
 CeFADR\_e\_Cell03\_PurgOnAirMode2 = 3,  
 CeFADR\_e\_Cell04\_PurgOnAirMode1 = 4,  
 CeFADR\_e\_Cell05\_PurgOnAirMode0 = 5,  
 CeFADR\_e\_Cell06\_PurgOnIdle = 6,  
 CeFADR\_e\_Cell07\_PurgOnDecel = 7,  
 CeFADR\_e\_Cell08\_PurgOffAirMode5 = 8,  
 CeFADR\_e\_Cell09\_PurgOffAirMode4 = 9,  
 CeFADR\_e\_Cell10\_PurgOffAirMode3 = 10,  
 CeFADR\_e\_Cell11\_PurgOffAirMode2 = 11,  
 CeFADR\_e\_Cell12\_PurgOffAirMode1 = 12,  
 CeFADR\_e\_Cell13\_PurgOffAirMode0 = 13,  
 CeFADR\_e\_Cell14\_PurgOffIdle = 14,  
 CeFADR\_e\_Cell15\_PurgOffDecel = 15

**Value Units:** Block Learn cell number  
**X Unit:** Block Learn cell number

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	7	7	7	7	7	7	7	7	15	15	15	15	15	15	15	15

### Initial Supporting table - Multiple DTC Use Green Sensor Delay Criteria - Limit

**Description:** This Calibration is the accumulated airflow limit above which the Green condition is expired  
 Used for: P0133, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P0153, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273.  
 Note: This feature is only enabled when the vehicle is new and cannot be enabled in service.

**Value Units:** Grams

**X Unit:** Accumulated Engine Airflow

y/x	CiOXYR_O2_Bank1_Sensor1	CiOXYR_O2_Bank1_Sensor2	CiOXYR_O2_Bank2_Sensor1	CiOXYR_O2_Bank2_Sensor2
1	120,000	120,000	120,000	120,000

**Initial Supporting table - POI1\_CamPosErrorLimlc1**

**Description:** Maximum Intake Cam 1 phase error as a function of engine speed and engine oil temperature.

**Value Units:** Maximum Intake Cam 1 phase error (degCAM)

**X Unit:** Engine Oil Temperature (degC)

**Y Units:** Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
1,200	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
1,600	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
2,000	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
2,400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
2,800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
3,200	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
3,600	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
4,000	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
4,400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
4,800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
5,200	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
5,600	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
6,000	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
6,400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
6,800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0

**Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_EngOilPressEnbllc**

**Description:** Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met

**Value Units:** Time (sec)

**X Unit:** Engine Coolant Temperature (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3

**Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_HiEngSpdHiDsbllc**

**Description:** Minimum engine speed to disable Intake cam

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000

**Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_HiEngSpdLoEnbllc**

**Description:** Maximum engine speed to enable Intake cam - works as hysteresis.

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800

**Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_LoPresHiEnblc**

**Description:** Intake cam is enabled when oil pressure exceeds this value

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180



**Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_LoPresLoDsbllc**

**Description:** Intake cam is disabled when oil pressure falls below this value

**Value Units:** Engine Oil Pressure (kPa)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	170	170	170	170	160	150	150	150	150	150	150	150	150	150	160	170	170

**Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_LoRpmHiEnblc**

**Description:** Intake cam is enabled when engine speed exceeds this value.

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	825	825	825	825	800	800	800	800	800	800	800	800	875	925	1,175	1,325	1,825

**Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_LoRpmLoDsbllc**

**Description:** Intake cam is disabled when engine speed is below this value.

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	800	800	800	800	750	750	750	750	750	750	750	750	750	750	800	800	800

**Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_P0014\_P0024\_P05CE\_P05CF\_ColdStartEngRunning**

**Description:** Engine running time must be greater than this threshold during a cold start to enable cam phasing

**Value Units:** Time (sec)  
**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	15	15	14	13	12	11	10	9	8	7	6	5	4	4	4	4	4

**Initial Supporting table - P0011\_P( 05CC\_StablePositionTimeIc1**

**Description:** Minimum time for Intake Cam 1 phase position to be stable to enable performance diagnostic.

**Value Units:** Minimum time (sec)

**X Unit:** Engine Oil Temperature (degC)

**Y Units:** Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
1,200	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
1,600	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
2,000	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
2,400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
2,800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
3,200	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
3,600	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
4,000	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
4,400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
4,800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
5,200	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
5,600	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
6,000	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
6,400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
6,800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4

**Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_EngOilPressEnblEc**

**Description:** Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met

**Value Units:** Time (sec)

**X Unit:** Engine Coolant Temperature (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3

**Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_HiEngSpdHiDsblEc**

**Description:** Exhaust cam is disabled when engine speed exceeds this value

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_HiEngSpdLoEnblEc**

**Description:** Exhaust cam is enabled when engine speed remains below this value

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0



**Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_LoPresHiEnbIEc**

**Description:** Exhaust cam is enabled when oil pressure exceeds this value

**Value Units:** Engine Oil Pressure (kPa)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180

**Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_LoPresLoDsbIEc**

**Description:** Exhaust cam is disabled when oil pressure falls below this value

**Value Units:** Engine Oil Pressure (kPa)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	125	125	125	125	125	125	125	125	125	125	125	125	125	125	125	125	125

**Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_LoRpmHiEnbIEc**

**Description:** Exhaust cam is enabled when engine speed exceeds this value.

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	825	825	825	825	800	800	800	800	800	800	800	800	875	925	1,175	1,325	1,825

**Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_LoRpmLoDsblEc**

**Description:** Exhaust cam is disabled when engine speed is below this value.

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	750	750	750	750	750	750	750	750	750	750	750	750	750	750	750	750	750

**Initial Supporting table - P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold**

**Description:** P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

**Value Units:** Engine Run Time- Seconds

**X Unit:** Oil Temperature- C

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	20.0	10.0	7.0	5.0	3.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	2.0	2.0

**Initial Supporting table - P0016-0019 Mid-Park Phaser Delay**

**Description:** P0016-0019 Mid-Park Phaser Park Delay. Total delay is twice the calibration value as both 'hi' side and 'lo' side park check sequences are delayed by the stated calibration values

**Value Units:** Time - seconds

**X Unit:** Oil Temperature - degC

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	600.0	600.0	320.0	36.0	36.0	36.0	36.0	20.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

**Initial Supporting table - P0071: OAT Performance Drive Equilibrium Engine Off**

**Description:** OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine off (for hybrid applications)

**Value Units:** Counter Increment Value (Unitless)

**X Unit:** Vehicle Speed (KPH)

y/x	0.0	20.0	30.0	45.0	60.0	75.0	90.0	105.0	120.0
1.0	0.0	4.0	6.0	6.8	7.3	7.8	8.0	8.0	8.0

### Initial Supporting table - P0071: OAT Performance Drive Equilibrium Engine Running

**Description:** OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine running

**Value Units:** Counter Increment Value (Unitless)

**X Unit:** Vehicle Speed (KPH)

**Y Units:** Engine Air Flow (Grams/Second)

y/x	0.0	20.0	30.0	45.0	60.0	75.0	90.0	105.0	120.0
0.0	1.0	6.0	8.0	8.8	9.0	9.0	9.0	9.0	9.0
15.0	-3.0	1.0	3.0	3.8	4.3	4.8	5.0	5.0	5.0
25.0	-1.5	1.5	3.5	4.3	4.8	5.3	5.5	5.5	5.5
35.0	-0.5	2.0	4.0	4.8	5.3	5.8	6.0	6.0	6.0
45.0	0.0	2.5	4.5	5.3	5.8	6.3	6.5	6.5	6.5
55.0	0.0	3.5	5.5	6.3	6.8	7.3	7.5	7.5	7.5
65.0	0.5	4.5	6.5	7.3	7.8	8.3	8.5	8.5	8.5
75.0	1.0	5.5	7.5	8.3	8.7	8.9	9.0	9.0	9.0
85.0	1.0	6.5	8.0	8.4	8.7	8.9	9.0	9.0	9.0



**Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAPI Residual Weight Factor based on RPM**

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAPI Residual Weight Factor based on RPM

**Value Units:** Weight Factor (Unitless)  
**X Unit:** Engine Speed (RPM)

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

**Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM**

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP2 Residual Weight Factor based on RPM

**Value Units:** Weight Factor (Unitless)  
**X Unit:** Engine Speed (RPM)

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

**Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM**

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 TPS Residual Weight Factor based on RPM

**Value Units:** Weight Factor (Unitless)

**X Unit:** Engine Speed (RPM)

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

**Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est**

**Description:** P0101\_P0106\_P010B\_P01 21\_P012B\_P0236\_\_P1101 MAF1 Residual Weight Factor based on MAF Est

**Value Units:** Weight Factor (Unitless)  
**X Unit:** Estimated Engine Air Flow (Grams/Second)

y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

**Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM**

**Description:** P0101\_P0106\_P010B\_P0121\_P012B\_P0236\_P1101 MAF1 Residual Weight Factor based on RPM

**Value Units:** Weight Factor (Unitless)

**X Unit:** Engine Speed (RPM)

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	0.900	0.800	0.750	0.650	0.500	0.500	0.500	0.500	0.500	0.500	0.500

**Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)**

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

**P0606\_Last Seed Timeout f(Loop Time) - Part 1**

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000	200.000

**P0606\_Last Seed Timeout f(Loop Time) - Part 2**

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventASeq	CePISR_e_EventBSeq	CePISR_e_EventCSeq
1	200.000	500.000	500.000	1,000.000	8,191.875	8,191.875	8,191.875	8,191.875

**Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)**

**Description:** Fail threshold for PSW per operating loop.

**P0606\_PSW Sequence Fail f(Loop Time) - Part 1**

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	5	3	5	3	5	3	5	3

**P0606\_PSW Sequence Fail f(Loop Time) - Part 2**

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	5	3	5	3	5	5	5	5

**Initial Supporting table - P0606 PSW Sequence Sample f(Loop Time)**

**Description:** Sample threshold for PSW per operating loop.

**P0606\_PSW Sequence Sample f(Loop Time) - Part 1**

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	4	4	4	4	4	4	4	4

**P0606\_PSW Sequence Sample f(Loop Time) - Part 2**

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventASeq	CePISR_e_EventBSeq	CePISR_e_EventCSeq
1	4	4	4	4	4	4	4	4



**Initial Supporting table - 1st\_FireAftrMisfr\_Acel**

**Description:** Used for P0300 - P0308, Multiplier for establishing the expected acceleration of the cylinder after the misfire

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,600	3,000	3,500	4,000
8	0.70	0.68	0.71	0.73	0.75	0.86	0.74	0.81	0.68	0.69	0.77	0.74	0.66	0.71	0.75	0.75	0.75
12	0.61	0.56	0.64	0.68	0.67	1.03	0.80	0.93	0.79	0.77	0.87	0.85	0.88	0.85	0.92	0.92	0.92
16	0.51	0.42	0.50	0.55	0.55	0.98	0.83	0.71	0.63	0.65	0.75	0.67	0.84	0.65	0.71	0.71	0.71
20	0.43	0.35	0.40	0.48	0.47	0.78	0.58	0.52	0.49	0.57	0.62	0.61	0.69	0.52	0.56	0.56	0.56
24	0.38	0.29	0.33	0.42	0.42	0.71	0.53	0.48	0.46	0.47	0.49	0.55	0.52	0.47	0.46	0.46	0.46
30	0.31	0.23	0.27	0.35	0.36	0.80	0.52	0.47	0.39	0.40	0.40	0.44	0.47	0.46	0.50	0.33	0.42
40	0.24	0.19	0.23	0.30	0.31	0.67	0.47	0.50	0.32	0.35	0.37	0.34	0.36	0.41	0.42	0.36	0.40
60	0.16	0.14	0.18	0.24	0.27	0.56	0.40	0.44	0.31	0.29	0.36	0.31	0.31	0.40	0.42	0.44	0.52
100	0.12	0.10	0.13	0.20	0.23	0.45	0.39	0.48	0.36	0.23	0.37	0.29	0.28	0.38	0.37	0.54	0.52

## Initial Supporting table - 1st\_FireAftrMisfr\_Jerk

**Description:** Used for P0300 - P0308, Multiplier for establishing the expected Jerk of the cylinder after the misfire

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,600	3,000	3,500	4,000
8	-1.04	-0.86	-0.86	-0.82	-0.60	-0.84	-0.85	-0.61	-0.74	-0.83	-0.84	-0.86	-0.80	-0.95	-0.77	-0.77	-0.77
12	-1.29	-1.08	-0.85	-0.79	-0.85	-1.14	-0.95	-0.66	-0.90	-0.97	-0.66	-0.97	-1.00	-1.06	-1.27	-1.27	-1.27
16	-1.45	-1.23	-1.10	-0.91	-1.04	-1.76	-0.93	-0.96	-0.97	-1.11	-1.07	-1.09	-1.31	-1.32	-1.50	-1.50	-1.50
20	-1.71	-1.32	-1.28	-1.08	-1.12	-1.67	-1.36	-1.17	-1.19	-1.23	-1.11	-1.22	-1.34	-1.48	-1.71	-1.71	-1.71
24	-1.83	-1.33	-1.44	-1.30	-1.16	-1.83	-1.67	-1.25	-1.38	-1.35	-1.22	-1.26	-1.33	-1.54	-1.67	-1.67	-1.67
30	-1.89	-1.20	-1.36	-1.35	-1.18	-2.54	-2.01	-1.29	-1.65	-1.40	-1.41	-1.31	-1.45	-1.45	-1.46	-1.17	-1.88
40	-1.97	-1.09	-1.18	-1.32	-1.26	-2.95	-1.76	-1.16	-1.59	-1.49	-1.31	-1.35	-1.48	-1.35	-1.42	-1.23	-1.29
60	-2.04	-0.98	-1.03	-1.21	-1.27	-3.10	-1.72	-0.97	-1.36	-1.16	-0.98	-1.39	-1.52	-1.24	-1.27	-1.17	-1.17
100	-2.15	-0.89	-0.93	-1.09	-1.22	-3.01	-1.99	-0.81	-1.20	-0.98	-0.86	-1.40	-1.51	-1.23	-1.14	-1.08	-0.98

### Initial Supporting table - IstFireAfterMisJerkAFM

**Description:** Used for P0300 - P0308, Multiplier for establishing the expected jerk of the cylinder after the misfire if Active Fuel Management cylinder deact mode is active

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1	1	1	1	1	1	1	1	1
12	1	1	1	1	1	1	1	1	1
16	1	1	1	1	1	1	1	1	1
20	1	1	1	1	1	1	1	1	1
24	1	1	1	1	1	1	1	1	1
30	1	1	1	1	1	1	1	1	1
40	1	1	1	1	1	1	1	1	1
60	1	1	1	1	1	1	1	1	1
100	1	1	1	1	1	1	1	1	1

### Initial Supporting table - IstFireAftrMisAcelAFM

**Description:** Used for P0300 - P0308, Multiplier for establishing the expected acceleration of the cylinder after the misfire if Active Fuel Management cylinder deact mode is active

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1	1	1	1	1	1	1	1	1
12	1	1	1	1	1	1	1	1	1
16	1	1	1	1	1	1	1	1	1
20	1	1	1	1	1	1	1	1	1
24	1	1	1	1	1	1	1	1	1
30	1	1	1	1	1	1	1	1	1
40	1	1	1	1	1	1	1	1	1
60	1	1	1	1	1	1	1	1	1
100	1	1	1	1	1	1	1	1	1

**Initial Supporting table - Abnormal Cyl Mode**

**Description:** Used for P0300-P0308. Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Cylinder Mode Equation)

**Value Units:** Number of consecutive number of decelerating cylinders (integer)

**X Unit:** thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	4	4	4	4	4	4	4	4	4

### Initial Supporting table - Abnormal Rev Mode

**Description:** Used for P0300-P0308. Abnormal Rev Mode Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Rev Mode Equation)

**Value Units:** Number of consecutive number of decelerating cylinders (integer)

**X Unit:** thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00

**Initial Supporting table - Abnormal SCD Mode**

**Description:** Used for P0300-P0308. Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (SCD Mode Equation)

**Value Units:** Number of consecutive number of decelerating cylinders (integer)

**X Unit:** thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	4	4	4	4	4	4	4	4	4

## Initial Supporting table ■ Bank\_SCD\_Decel

**Description:** Used for P0300 - P0308, Multiplier to SCD decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
12	0.75	0.68	0.75	0.91	0.80	0.81	0.80	0.82	0.87
16	0.75	0.61	0.70	0.82	0.75	0.77	0.74	0.92	0.73
18	0.69	0.56	0.66	0.73	0.70	0.65	0.66	0.99	0.46
20	0.64	0.54	0.64	0.64	0.66	0.54	0.52	0.79	0.38
24	0.64	0.54	0.64	0.64	0.66	0.54	0.52	0.79	0.38
30	0.64	0.54	0.64	0.64	0.66	0.54	0.52	0.79	0.38
40	0.64	0.54	0.64	0.64	0.66	0.54	0.52	0.79	0.38
60	0.64	0.54	0.64	0.64	0.66	0.54	0.52	0.79	0.38
98	0.64	0.54	0.64	0.64	0.66	0.54	0.52	0.79	0.38



### Initial Supporting table - Bank\_SCD\_Jerk

**Description:** Used for P0300 - P0308, Multitplier to Medres SCD jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
12	0.81	1.14	1.71	1.65	1.39	1.26	1.22	1.26	1.51
16	0.90	1.30	1.92	1.97	1.50	1.37	1.33	1.39	1.26
18	0.72	1.28	1.90	1.97	1.94	1.65	1.28	1.55	0.78
20	0.61	1.26	1.38	1.27	1.43	1.35	1.09	1.15	0.61
24	0.61	1.26	1.38	1.27	1.43	1.35	1.09	1.15	0.61
30	0.61	1.26	1.38	1.27	1.43	1.35	1.09	1.15	0.61
40	0.61	1.26	1.38	1.27	1.43	1.35	1.09	1.15	0.61
60	0.61	1.26	1.38	1.27	1.43	1.35	1.09	1.15	0.61
98	0.61	1.26	1.38	1.27	1.43	1.35	1.09	1.15	0.61

### Initial Supporting table - BankCylModeDecel

**Description:** Used for P0300 - P0308, Multiplier to Lores Decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,600	3,000	3,500	4,000
12	0.71	0.58	0.63	0.58	0.59	0.76	0.87	1.07	0.92	0.97	0.82	0.90	0.88	0.90	1.00	1.00	1.00
16	0.56	0.44	0.48	0.39	0.50	0.72	0.79	0.79	0.79	0.80	0.80	0.81	0.87	0.75	0.71	0.71	0.71
18	0.52	0.40	0.43	0.35	0.46	0.61	0.57	0.59	0.67	0.63	0.71	0.67	0.78	0.68	0.56	0.56	0.56
20	0.50	0.38	0.39	0.34	0.43	0.61	0.46	0.48	0.65	0.54	0.61	0.57	0.61	0.64	0.50	0.50	0.50
24	0.48	0.37	0.42	0.38	0.44	0.65	0.35	0.37	0.67	0.74	0.69	0.71	0.67	0.70	0.46	0.46	0.46
30	0.45	0.37	0.43	0.41	0.44	0.72	0.30	0.46	0.65	0.76	0.71	0.67	0.64	0.68	0.50	0.61	0.58
40	0.41	0.35	0.40	0.42	0.44	0.65	0.33	0.37	0.60	0.81	0.84	0.69	0.61	0.74	0.61	0.64	0.60
60	0.36	0.33	0.37	0.42	0.44	0.60	0.39	0.78	0.86	0.92	1.12	0.91	0.60	0.97	0.98	0.78	0.48
98	0.32	0.31	0.35	0.43	0.42	0.56	0.46	0.58	0.73	0.95	1.62	1.19	0.70	1.08	1.31	1.00	0.52

## Initial Supporting table -BankCylModeJerk

**Description:** Used for P0300 - P0308, Multiplier to Lores Jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,600	3,000	3,500	4,000
12	1.48	1.33	1.46	1.43	1.46	1.90	1.59	1.76	1.54	1.46	1.36	1.87	1.93	2.17	2.36	2.36	2.36
16	1.23	1.08	1.17	1.01	1.21	2.03	1.73	1.73	1.55	1.52	1.48	1.58	1.83	1.72	1.92	1.92	1.92
18	1.20	1.02	1.13	0.98	1.08	1.77	1.71	1.73	1.39	1.45	1.39	1.53	1.64	1.74	1.83	1.83	1.83
20	1.23	0.96	1.09	0.98	1.00	1.63	1.68	1.80	1.26	1.34	1.38	1.49	1.49	1.62	1.64	1.64	1.64
24	1.21	0.89	1.04	0.94	0.88	1.65	1.80	1.69	1.54	1.46	1.50	1.60	1.31	1.60	1.56	1.56	1.56
30	1.20	0.79	0.87	0.81	0.83	1.96	1.96	1.24	2.52	1.76	1.66	1.84	1.41	1.55	1.31	1.40	1.88
40	1.18	0.72	0.76	0.68	0.82	1.92	1.22	0.35	3.89	2.55	1.75	2.75	1.46	1.41	1.66	1.45	2.75
60	1.17	0.64	0.67	0.62	0.76	1.73	1.34	1.49	2.88	2.81	1.89	4.76	1.60	1.44	1.55	3.38	2.69
98	1.16	0.58	0.62	0.59	0.71	1.50	1.42	1.15	2.66	3.00	2.19	4.11	1.73	1.27	1.67	3.14	2.55

### Initial Supporting table - Catalyst\_Damage\_Misfire\_Percentage

**Description:** Catalyst Damaging Misfire Percentage" Table whenever secondary conditions are met.

**Value Units:** percent misfire over 200 revolutions (%)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000
0	11.2	11.2	11.2	11.2	9.8	4.8	4.8	4.8
10	11.2	11.2	11.2	11.2	9.8	4.8	4.8	4.8
20	11.2	11.2	11.2	9.8	8.1	4.8	4.8	4.8
30	11.2	11.2	9.8	9.8	8.1	4.8	4.8	4.8
40	11.2	11.2	9.8	8.1	5.4	4.8	4.8	4.8
50	9.8	9.8	8.1	7.0	5.4	4.8	4.8	4.8
60	9.8	9.8	8.1	7.0	4.8	4.8	4.8	4.8
70	8.1	8.1	8.1	6.1	4.8	4.8	4.8	4.8
80	6.1	6.1	6.1	4.8	4.8	4.8	4.8	4.8
90	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
100	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8

### Initial Supporting table - ClyAfterAFM\_Decel

**Description:** Used for P0300 - P0308, Multiplier to Lores decel to account for different pattern of misfire after a deactivated cylinder. Similar to the second cylinder of consecutive cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

Initial Supporting table -  $\phi_{yBeforeAFM\_Jerk}$ 

**Description:** Used for P0300 - P0308, Multiplier to Lores decel to account for different pattern of misfire before a deactivated cylinder, but after an active cylinder that follows an deactive cylinder on engine that supports cylinder deactivation in non even fire patterns.. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

### Initial Supporting table - CombustModelIdleTbl

**Description:** Used for P0300 - P0308, Only used on Diesel engines. Combustion modes that will force use of Idle table. A value of CeCMBR\_i\_CombModesMax means not selected.

**Value Units:** Enumerated value of different combustion modes (enumeration)

**X Unit:** Current Combustion Mode (enumeration)

#### CombustModelIdleTbl - Part 1

y/x	0	1	2	3	4	5
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max

#### CombustModelIdleTbl - Part 2

y/x	6	7	8	9	10	11
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max

#### CombustModelIdleTbl - Part 3

y/x	12	13	14	15	16	
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	

### Initial Supporting table - (ConsecCylModDecel)

**Description:** Used for P0300 - P0308, Multiplier to Lores decel to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,600	3,000	3,500	4,000
8	1.26	1.43	1.28	1.16	1.23	1.22	1.24	1.24	1.22	1.27	1.18	1.28	1.17	1.21	1.56	1.56	1.56
12	1.39	1.18	1.22	1.25	1.19	1.47	1.27	1.30	1.27	1.35	1.10	1.23	1.22	1.15	1.46	1.46	1.46
16	1.47	1.09	1.18	1.17	1.19	1.88	1.44	1.10	1.19	1.09	1.02	0.98	1.03	0.90	1.00	1.00	1.00
20	1.42	1.09	1.17	1.16	1.24	1.81	1.05	1.00	1.04	0.93	0.85	0.80	0.83	0.84	0.78	0.78	0.78
24	1.42	1.07	1.14	1.13	1.28	1.89	0.98	1.06	0.89	0.95	0.76	0.82	0.79	0.87	0.79	0.79	0.79
30	1.36	1.08	1.08	1.07	1.21	2.11	1.06	1.06	0.59	0.71	0.48	0.65	0.79	0.84	0.77	0.83	1.00
40	1.32	1.08	1.03	1.04	1.17	1.95	1.13	0.97	0.42	0.62	0.39	0.47	0.63	0.78	0.81	0.77	0.67
60	1.24	1.07	0.98	1.00	1.11	1.71	1.09	0.76	0.52	0.76	0.89	0.68	0.78	0.90	0.92	0.93	1.00
98	1.19	1.07	0.96	1.00	1.05	1.53	1.17	0.75	0.75	0.97	1.60	0.76	0.80	1.07	1.08	1.06	1.00



**Initial Supporting table - ConsecCylModeJerk**

**Description:** Used for P0300 - P0308, Multitplier to Lores Jerk to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,600	3,000	3,500	4,000
8	0	0	0	0	0	0	0	0	0	0	0	0	0	-1	0	0	0
12	0	0	0	0	0	0	0	0	0	0	0	0	0	-1	-1	-1	-1
16	0	0	0	0	0	0	0	0	0	-1	-1	-1	-1	-1	-2	-2	-2
20	0	0	0	0	0	0	0	-1	-1	-1	-1	-1	-1	-1	-2	-2	-2
24	0	0	0	0	0	0	-1	-1	-1	-1	-1	-1	-1	-1	-1	-1	-1
30	0	0	0	0	0	0	-1	-1	-2	-2	-2	-1	-1	-1	-1	-1	-1
40	0	0	0	0	0	0	0	-1	-3	-4	-3	-3	-1	-1	-1	-1	-4
60	0	0	0	0	0	0	0	-1	-2	-7	-3	-6	-1	-1	-1	-4	-4
98	0	0	0	0	0	0	0	-1	-1	-8	-2	-4	-1	-1	-1	-3	-3

### Initial Supporting table - ConsecSCD\_Decel

**Description:** Used for P0300 - P0308, Multiplier to medres decel to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	1.04	1.12	1.22	1.14	1.20	1.20	1.32	1.03
12	1.00	1.10	1.15	1.13	1.10	1.20	1.06	1.42	0.93
16	1.00	1.36	1.46	1.29	1.25	1.28	1.21	1.42	0.68
20	1.00	1.64	1.81	1.40	1.39	1.30	1.25	1.09	0.63
24	1.00	1.64	1.81	1.40	1.39	1.30	1.25	1.09	0.63
30	1.00	1.64	1.81	1.40	1.39	1.30	1.25	1.09	0.63
40	1.00	1.64	1.81	1.40	1.39	1.30	1.25	1.09	0.63
60	1.00	1.64	1.81	1.40	1.39	1.30	1.25	1.09	0.63
98	1.00	1.64	1.81	1.40	1.39	1.30	1.25	1.09	0.63

## Initial Supporting table ■ ConsecSCD\_Jerk

**Description:** Used for P0300 - P0308, Multiplier to medres Jerk to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	-0.07	-0.09	-0.14	-0.19	-0.22	-0.29	-0.21	-0.12	-0.12
12	-0.06	-0.08	-0.14	-0.18	-0.20	-0.21	-0.16	-0.23	-0.27
16	-0.04	-0.06	-0.10	-0.12	-0.14	-0.12	-0.06	-0.28	-0.19
20	-0.02	-0.04	-0.05	-0.06	-0.06	-0.03	0.02	-0.20	-0.17
24	-0.02	-0.04	-0.05	-0.06	-0.06	-0.03	0.02	-0.20	-0.17
30	-0.02	-0.04	-0.05	-0.06	-0.06	-0.03	0.02	-0.20	-0.17
40	-0.02	-0.04	-0.05	-0.06	-0.06	-0.03	0.02	-0.20	-0.17
60	-0.02	-0.04	-0.05	-0.06	-0.06	-0.03	0.02	-0.20	-0.17
98	-0.02	-0.04	-0.05	-0.06	-0.06	-0.03	0.02	-0.20	-0.17

**Initial Supporting table - CylAfterAFM Jerk**

**Description:** Used for P0300 - P0308, Multitplier to Lores Jerk to account for different pattern of misfire after a deactivated cylider. Similar to the second cylinder of consecutive cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1	1	1	1	1	1	1	1	1
12	1	1	1	1	1	1	1	1	1
16	1	1	1	1	1	1	1	1	1
20	1	1	1	1	1	1	1	1	1
24	1	1	1	1	1	1	1	1	1
30	1	1	1	1	1	1	1	1	1
40	1	1	1	1	1	1	1	1	1
60	1	1	1	1	1	1	1	1	1
98	1	1	1	1	1	1	1	1	1

## Initial Supporting table - QylBeforeAFM\_Decel

**Description:** Used for P0300 - P0308, Multiplier to Lores decel to account for different pattern of misfire before a deactivated cylinder, but after an active cylinder that follows an inactive cylinder on engine that supports cylinder deactivation in non even fire patterns.. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## Initial Supporting table - CylModeDecel

**Description:** Used for P0300-P0308. Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

**Value Units:** Delta time per cylinder (usec)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

## CylModeDecel - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	2,050	1,500	950	544	350	243	179	158	121	70	53	39	30
6	1,880	1,365	850	507	344	234	175	144	109	68	51	37	27
8	1,897	1,401	837	507	348	244	170	135	101	65	47	36	25
10	2,021	1,498	884	532	370	266	166	128	90	61	41	33	23
12	2,189	1,631	1,012	586	413	295	158	123	84	57	36	30	20
14	2,414	1,800	1,187	675	490	325	151	114	91	57	38	30	19
16	2,566	1,958	1,350	786	569	365	174	117	100	58	40	30	21
18	2,790	2,139	1,488	891	640	402	201	156	110	60	45	32	23
20	2,952	2,296	1,641	1,018	710	450	226	181	125	67	50	36	26
22	3,171	2,465	1,812	1,131	777	498	246	203	134	77	56	43	29
24	3,353	2,610	2,001	1,238	847	540	261	223	145	85	61	48	33
26	3,530	2,743	2,175	1,362	914	600	273	238	156	95	66	54	37
30	3,783	3,111	2,505	1,583	1,064	696	285	266	178	113	76	62	45
30	3,783	3,111	2,505	1,583	1,064	696	285	266	178	113	76	62	45
40	4,736	4,047	3,245	2,117	1,382	928	401	368	242	152	94	71	58
60	6,829	6,126	4,726	3,146	2,040	1,381	645	594	446	225	133	81	69
97	11,810	9,820	7,617	5,005	3,173	2,305	1,119	953	690	357	216	94	87

## CylModeDecel - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	22	17	14	12	10	6	6	4	4	3	3	2	2
6	22	16	13	11	9	6	6	4	4	3	3	2	2
8	21	15	12	10	8	6	6	4	4	3	3	2	2
10	18	14	11	9	7	6	6	4	4	3	3	2	2
12	16	12	10	9	7	6	5	4	4	3	3	2	2
14	16	12	10	8	7	7	5	4	4	3	3	2	2
16	16	12	10	8	7	7	5	4	4	4	3	3	3
18	16	13	11	9	8	7	5	4	4	4	3	3	3
20	18	14	13	11	9	8	6	4	4	4	3	2	2
22	21	16	14	12	11	9	6	5	4	4	3	2	2
24	24	18	15	13	12	10	7	5	4	4	3	3	3

**Initial Supporting table - CylModeDecel**

26	27	20	17	14	13	11	7	5	5	4	3	3	3
30	33	24	19	16	15	14	9	6	6	4	3	3	3
30	33	24	19	16	15	15	9	6	4	4	4	4	4
40	44	33	23	19	18	18	11	8	5	5	5	5	5
60	60	50	30	25	20	20	14	11	9	9	9	9	9
97	83	77	44	35	26	26	18	16	12	12	12	12	12

**Initial Supporting table - CylModeJerk**

**Description:** Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

**Value Units:** Change in Delta time per cylinder from last cylinder (usec)

**Y Units:** percent load of max indicated torque (%)

**CylModeJerk - Part 1**

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	1,914	1,327	740	425	311	245	172	132	108	82	52	37	27
6	1,799	1,265	730	413	291	245	162	122	94	74	47	34	24
8	1,694	1,234	697	413	289	249	156	118	85	68	43	32	22
10	1,729	1,290	675	413	306	245	144	114	76	63	40	32	21
12	1,931	1,425	773	471	358	241	120	111	77	56	38	30	19
14	2,141	1,656	969	577	452	274	110	108	81	54	40	30	21
16	2,327	1,831	1,181	673	522	317	128	117	84	60	42	30	22
18	2,567	2,002	1,370	765	584	359	153	125	85	65	47	34	23
20	2,692	2,127	1,535	881	625	399	178	131	85	72	51	36	24
22	2,810	2,251	1,671	989	680	450	199	132	88	78	55	39	25
24	2,955	2,383	1,829	1,115	750	504	205	130	93	77	58	42	28
26	3,074	2,501	1,999	1,256	834	578	205	130	101	70	59	44	29
30	3,390	2,772	2,319	1,525	1,030	732	221	130	122	64	60	49	31
30	3,390	2,772	2,319	1,525	1,030	732	221	130	122	64	60	49	31
40	4,115	3,421	3,018	2,132	1,550	1,067	309	211	186	58	57	57	28
60	5,504	4,681	4,446	3,292	2,400	1,712	510	284	260	122	78	74	23
97	8,118	7,038	7,044	5,351	3,970	2,887	906	456	423	217	123	104	44

**CylModeJerk - Part 2**

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	22	16	13	10	8	0	0	0	0	0	0	0	0
6	19	15	11	9	7	0	0	0	0	0	0	0	0
8	18	14	11	8	7	0	0	0	0	0	0	0	0
10	16	13	10	7	6	0	0	0	0	0	0	0	0
12	15	11	9	7	6	0	0	0	0	0	0	0	0
14	14	11	9	7	6	0	0	0	0	0	0	0	0
16	15	11	9	8	6	0	0	0	0	0	0	0	0
18	17	12	10	8	6	0	0	0	0	0	0	0	0
20	19	14	11	9	7	0	0	0	0	0	0	0	0
22	21	16	12	10	9	0	0	0	0	0	0	0	0
24	24	18	13	10	9	0	0	0	0	0	0	0	0



**Initial Supporting table - CylModeJerk**

26	26	20	14	11	11	0	0	0	0	0	0	0	0
30	29	23	17	14	13	0	0	0	0	0	0	0	0
30	29	23	17	14	13	13	8	4	3	3	3	3	3
40	38	29	23	20	15	15	10	4	3	3	3	3	3
60	52	41	33	30	22	22	7	7	4	4	4	4	4
97	80	69	61	58	32	32	11	11	8	8	8	8	8

## Initial Supporting table - DeacCylInversionDecel

**Description:** Used for P0300 - P0308, Negative Torque can cause crank readings to invert (active cylinders appear weak & deactivated cylinders appear "strong" If deactivated cylinders don't decelerate at least this amount then the crank signal is inverting. Function of speed and load.

**Value Units:** Delta time per cylinder (usec)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
12	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
16	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
20	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
24	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
30	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
40	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
60	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
98	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384

### Initial Supporting table - DeacCylInversionJerk

**Description:** Used for P0300 - P0308, Negative Torque can cause crank readings to invert (active cylinders appear weak & deactivated cylinders appear "strong" If deactivated cylinders don't jerk at least this amount then the crank signal is inverting. Function of speed and load.

**Value Units:** Change in Delta time per cylinder from last cylinder (usec)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
12	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
16	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
20	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
24	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
30	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
40	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
60	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
98	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384

**Initial Supporting table - EngineOverSpeedLimit**

**Description:** Engine OverSpeed Limit versus gear

**Value Units:** RPM

**X Unit:** Enumeration of transmission gear state (enumeration)

**EngineOverSpeedLimit - Part 1**

y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6	CeTGRR_e_TransGr9
1	4,530	4,530	4,530	4,530	4,530	4,530	4,530

**EngineOverSpeedLimit - Part 2**

y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGrN	CeTGRR_e_TransGrR	CeTGRR_e_TransGrP	CeTGRR_e_TransGr7	CeTGRR_e_TransGr8	
1	4,530	4,000	4,530	4,000	4,530	4,530	

### Initial Supporting table - InfrequentRegen

**Description:** Used for P0300-P0308. Only used on Diesel engines. Initiates a misfire delay when the current combustion mode matches a selection in the table. A value of CeCMBR\_i\_CombModesMax means not selected.

**Value Units:** Enumerated value of different combustion modes (enumeration)

**X Unit:** Current Combustion Mode (enumeration)

#### InfrequentRegen - Part 1

y/x	0	1	2	3	4	5
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max

#### InfrequentRegen - Part 2

y/x	6	7	8	9	10	11
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max

#### InfrequentRegen - Part 3

y/x	12	13	14	15	16	
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	

**Initial Supporting table - Number of Normals**

**Description:** Used for P0300-P0308. Number of Normals for the Driveline Ring Filter  
 After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

**Value Units:** Number of Engine cycles after isolated misfire (Engine cycles)

**X Unit:** thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	3	3	3	3	3	3	3	3	3

**Initial Supporting table - P00C6 - High Pressure Pump Control Mode timeout**

**Description:** High Pressure Pump Control Mode timeout

**Value Units:** Time (Seconds)

**X Unit:** Coolant Temperature (Deg C)

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1	10.0	10.0	10.0	10.0	10.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

Supporting table - P00C6 - maximum acceptable counts of fuel rail pressure below KtFHPD\_p\_HPS\_PressFallLoThrsh after High Pressure Start

**Description:** The maximum acceptable counts of fuel rail pressure below KtFHPD\_p\_HPS\_PressFallLoThrsh after High Pressure Start (HPS) is executed but before engine is in run mode.  
**Value Units:** maximum acceptable counts of fuel rail pressure below KtFHPD\_p\_HPS\_PressFallLoThrsh after High Pressure Start (Count)  
**X Unit:** Coolant Temperature (Deg C)  
**Y Units:** Ethanol Precent (%)

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
13	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
25	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
38	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
50	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
63	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
75	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
88	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
100	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0



**Initial Supporting table - P00C6 - Minimum acceptable value of fuel rail pressure after High Pressure Start**

**Description:** The minimum acceptable value of fuel rail pressure after High Pressure Start (HPS) is executed. This ensures the pressure does not fall off drastically after High Pressure Start (HPS) is executed, but before engine is in run mode.

**Value Units:** Minimum acceptable value of fuel rail pressure after High Pressure Start (Mpa)

**X Unit:** Coolant Temperature (Deg C)

**Y Units:** Ethanol Precent (%)

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	2.0	2.0	2.0	2.0	2.0	1.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
13	2.0	2.0	2.0	2.0	2.0	1.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
25	2.0	2.0	2.0	2.0	2.0	1.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
38	2.0	2.0	2.0	2.0	2.0	1.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
50	2.0	2.0	2.0	2.0	2.0	1.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
63	2.0	2.0	2.0	2.0	2.0	1.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
75	2.0	2.0	2.0	2.0	2.0	1.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
88	2.0	2.0	2.0	2.0	2.0	1.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
100	2.0	2.0	2.0	2.0	2.0	1.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6

**Initial Supporting table - P00C6 - Minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery**

**Description:** This calibration is the minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery

**Value Units:** Minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery

**X Unit:** Coolant Temperature (Deg C)

**Y Units:** Ethanol Percent (%)

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	15.0	15.0	12.0	12.0	12.0	8.5	5.0	4.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
13	15.0	15.0	12.0	12.0	12.0	8.5	5.0	4.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
25	14.0	14.0	13.0	13.0	12.0	8.5	5.0	4.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
38	14.0	14.0	14.0	14.0	12.5	9.1	5.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
50	14.0	14.0	14.0	14.0	12.5	9.1	5.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
63	14.0	14.0	14.0	14.0	12.5	9.1	6.0	5.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
75	14.0	14.0	14.0	14.0	12.5	9.1	6.0	5.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
88	14.0	14.0	14.0	14.0	12.5	9.1	7.0	6.0	5.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
100	14.0	14.0	14.0	14.0	12.5	9.1	7.5	7.0	6.0	5.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0

### Initial Supporting table - P0420\_BestFailingOSCTableB1

**Description:** This table is a 9x17 table of baseline Best Failing (e.g. threshold converter) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the BestFailing OSC value is found within this table for the measured temp and airflow and is used along with the OSC\_TimeRaw (and the WorstPassing value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the identified BPU converter that is used for MIL illumination across the specific temp and airflow range for a given program.

y/x	13.55	14.20	14.84	15.49	16.14	16.79	17.44	18.09	18.73	19.38	20.03	20.68	21.33	21.98	22.63	23.27	23.92
475.00	1.33	1.25	1.14	1.08	1.03	0.98	0.93	0.90	0.87	0.84	0.80	0.77	0.75	0.74	0.72	0.70	0.69
528.00	1.46	1.37	1.25	1.19	1.13	1.08	1.03	0.99	0.95	0.92	0.88	0.85	0.83	0.81	0.79	0.77	0.75
581.00	1.61	1.51	1.38	1.31	1.24	1.19	1.13	1.09	1.05	1.01	0.96	0.93	0.91	0.88	0.86	0.84	0.83
634.00	1.78	1.66	1.53	1.44	1.37	1.31	1.24	1.20	1.15	1.11	1.06	1.03	1.00	0.97	0.95	0.93	0.91
687.00	1.96	1.84	1.69	1.60	1.52	1.45	1.37	1.32	1.27	1.23	1.17	1.13	1.10	1.07	1.04	1.02	1.00
740.00	2.17	2.03	1.87	1.77	1.68	1.60	1.52	1.46	1.40	1.35	1.29	1.25	1.21	1.18	1.15	1.13	1.10
793.00	2.41	2.25	2.07	1.96	1.86	1.77	1.68	1.61	1.55	1.50	1.43	1.38	1.34	1.31	1.27	1.24	1.21
846.00	2.67	2.49	2.30	2.17	2.06	1.96	1.86	1.78	1.72	1.66	1.58	1.53	1.49	1.44	1.41	1.37	1.34
900.00	2.97	2.77	2.56	2.42	2.29	2.18	2.07	1.98	1.91	1.84	1.76	1.70	1.65	1.60	1.56	1.52	1.49

## Initial Supporting table - P0420\_WorstPassingOSCTableBI

**Description:** This table is a 9x17 table of WorstPassing (e.g. 120k) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the WorstPassing OSC value is found within this table for the measured temp and airflow and is used along with the OSC\_TimeRaw (and the BestFailing OSC value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the WPA part across the temp and airflow range.

y/x	13.55	14.20	14.84	15.49	16.14	16.79	17.44	18.09	18.73	19.38	20.03	20.68	21.33	21.98	22.63	23.27	23.92
475.00	3.46	3.20	2.98	2.80	2.69	2.61	2.50	2.41	2.34	2.27	2.19	2.13	2.08	2.04	1.99	1.96	1.92
528.00	3.51	3.25	3.03	2.84	2.74	2.66	2.55	2.46	2.39	2.32	2.24	2.18	2.13	2.09	2.04	2.01	1.97
581.00	3.55	3.29	3.08	2.89	2.79	2.71	2.60	2.51	2.44	2.37	2.29	2.24	2.19	2.14	2.10	2.06	2.03
634.00	3.59	3.34	3.12	2.94	2.84	2.76	2.65	2.57	2.50	2.43	2.35	2.29	2.25	2.20	2.16	2.12	2.09
687.00	3.63	3.38	3.17	2.99	2.89	2.81	2.71	2.62	2.55	2.48	2.41	2.35	2.30	2.26	2.22	2.18	2.15
740.00	3.69	3.45	3.24	3.06	2.96	2.88	2.78	2.69	2.62	2.56	2.48	2.43	2.38	2.33	2.29	2.26	2.22
793.00	3.76	3.51	3.30	3.13	3.03	2.95	2.85	2.77	2.70	2.63	2.56	2.50	2.46	2.41	2.37	2.34	2.30
846.00	3.82	3.57	3.37	3.20	3.10	3.02	2.92	2.84	2.77	2.71	2.63	2.58	2.54	2.49	2.45	2.42	2.39
900.00	3.89	3.65	3.45	3.28	3.18	3.11	3.01	2.93	2.86	2.80	2.73	2.68	2.63	2.59	2.55	2.51	2.48

### Initial Supporting table - P0430\_BestFailingOSCTableB2

**Description:** This table is a 9x17 table of baseline Best Failing (e.g. threshold converter) OSC times for catalyst Bank 2. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the BestFailing OSC value is found within this table for the measured temp and airflow and is used along with the OSC\_TimeRaw (and the WorstPassing value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the identified BPU converter that is used for MIL illumination across the specific temp and airflow range for a given program.

y/x	13.55	14.20	14.84	15.49	16.14	16.79	17.44	18.09	18.73	19.38	20.03	20.68	21.33	21.98	22.63	23.27	23.92
475.00	1.33	1.25	1.14	1.08	1.03	0.98	0.93	0.90	0.87	0.84	0.80	0.78	0.75	0.74	0.72	0.70	0.69
528.00	1.46	1.37	1.25	1.19	1.13	1.08	1.03	0.99	0.95	0.92	0.88	0.85	0.83	0.81	0.79	0.77	0.75
581.00	1.61	1.51	1.38	1.31	1.24	1.19	1.13	1.09	1.05	1.01	0.96	0.93	0.91	0.88	0.86	0.84	0.83
634.00	1.78	1.66	1.53	1.44	1.37	1.31	1.24	1.20	1.15	1.11	1.06	1.03	1.00	0.97	0.95	0.93	0.91
687.00	1.96	1.84	1.69	1.60	1.51	1.45	1.37	1.32	1.27	1.23	1.17	1.13	1.10	1.07	1.04	1.02	1.00
740.00	2.17	2.03	1.87	1.77	1.68	1.60	1.52	1.46	1.40	1.35	1.29	1.25	1.21	1.18	1.15	1.13	1.10
793.00	2.41	2.25	2.07	1.96	1.86	1.77	1.68	1.61	1.55	1.50	1.43	1.38	1.34	1.31	1.27	1.24	1.21
846.00	2.67	2.49	2.30	2.17	2.06	1.96	1.86	1.78	1.72	1.66	1.58	1.53	1.49	1.45	1.41	1.37	1.34
900.00	2.97	2.77	2.56	2.42	2.29	2.18	2.07	1.98	1.91	1.84	1.76	1.70	1.65	1.60	1.56	1.52	1.49

### Initial Supporting table - P0430\_WorstPassingOSCTableB2

**Description:** This table is a 9x17 table of WorstPassing (e.g. 120k) OSC times for catalyst Bank 2. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the WorstPassing OSC value is found within this table for the measured temp and airflow and is used along with the OSC\_TimeRaw (and the BestFailing OSC value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the WPA part across the temp and airflow range.

y/x	13.55	14.20	14.84	15.49	16.14	16.79	17.44	18.09	18.73	19.38	20.03	20.68	21.33	21.98	22.63	23.27	23.92
475.00	3.37	3.10	2.88	2.70	2.59	2.51	2.40	2.31	2.24	2.17	2.09	2.03	1.98	1.93	1.89	1.86	1.82
528.00	3.43	3.17	2.95	2.76	2.65	2.57	2.47	2.38	2.30	2.24	2.15	2.10	2.05	2.00	1.96	1.92	1.88
581.00	3.50	3.24	3.02	2.83	2.73	2.64	2.54	2.45	2.38	2.31	2.22	2.17	2.12	2.07	2.03	1.99	1.96
634.00	3.58	3.32	3.10	2.92	2.81	2.73	2.62	2.53	2.46	2.39	2.31	2.25	2.20	2.15	2.11	2.07	2.04
687.00	3.67	3.41	3.19	3.01	2.90	2.82	2.71	2.62	2.55	2.48	2.40	2.34	2.29	2.24	2.20	2.16	2.13
740.00	3.78	3.51	3.29	3.11	3.00	2.92	2.81	2.72	2.65	2.58	2.50	2.44	2.39	2.35	2.30	2.27	2.23
793.00	3.89	3.63	3.41	3.22	3.11	3.03	2.93	2.84	2.76	2.70	2.61	2.56	2.51	2.46	2.42	2.38	2.34
846.00	4.02	3.75	3.54	3.35	3.24	3.16	3.05	2.97	2.89	2.82	2.74	2.68	2.63	2.59	2.54	2.51	2.47
900.00	4.16	3.90	3.68	3.50	3.39	3.31	3.20	3.11	3.04	2.97	2.89	2.83	2.78	2.73	2.69	2.65	2.62

### Initial Supporting table - Pair\_SCD\_Decel

**Description:** Used for P0300 - P0308, Multiplier to SCD\_Decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	0.70	0.81	0.95	0.93	0.95	0.96	0.90	0.96
12	1.00	0.69	0.83	0.91	0.96	1.04	0.88	0.91	0.77
16	0.95	0.65	0.81	1.02	1.11	1.12	0.84	0.93	0.50
20	0.92	0.58	0.84	1.03	1.16	1.11	0.67	0.78	0.48
24	0.92	0.58	0.84	1.03	1.16	1.11	0.67	0.78	0.48
30	0.92	0.58	0.84	1.03	1.16	1.11	0.67	0.78	0.48
40	0.92	0.58	0.84	1.03	1.16	1.11	0.67	0.78	0.48
60	0.92	0.58	0.84	1.03	1.16	1.11	0.67	0.78	0.48
98	0.92	0.58	0.84	1.03	1.16	1.11	0.67	0.78	0.48

## Initial Supporting tablej - Pair\_SCD\_Jerk

**Description:** Used for P0300 - P0308, Multplier to P0300\_SCD\_Jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	1.05	1.29	1.39	1.24	1.25	1.11	1.16	1.31
12	1.07	1.05	1.46	1.59	1.32	1.30	1.15	1.10	1.07
16	1.00	0.93	1.48	1.66	1.77	1.69	1.14	1.06	0.63
20	1.00	0.92	1.16	1.19	1.45	1.45	1.00	0.85	0.58
24	1.00	0.92	1.16	1.19	1.45	1.45	1.00	0.85	0.58
30	1.00	0.92	1.16	1.19	1.45	1.45	1.00	0.85	0.58
40	1.00	0.92	1.16	1.19	1.45	1.45	1.00	0.85	0.58
60	1.00	0.92	1.16	1.19	1.45	1.45	1.00	0.85	0.58
98	1.00	0.92	1.16	1.19	1.45	1.45	1.00	0.85	0.58



## Initial Supporting table -PairCylModeDecel

**Description:** Used for P0300 - P0308, Multitplier to Cyl Mode Deceleration to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multitplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,600	3,000	3,500	4,000
8	0.97	0.94	0.83	0.81	0.78	0.96	0.93	0.78	0.90	0.89	0.99	1.00	0.85	1.04	1.06	1.06	1.06
12	1.14	0.83	0.82	0.84	0.87	1.02	0.89	0.82	0.94	1.04	0.98	0.98	0.97	1.05	1.15	1.15	1.15
16	1.25	0.76	0.83	0.83	0.94	1.08	0.88	0.67	0.71	0.79	0.85	0.83	0.90	0.85	1.00	1.00	1.00
20	1.21	0.80	0.84	0.84	0.92	1.03	0.70	0.55	0.52	0.60	0.75	0.76	0.86	0.84	0.94	0.94	0.94
24	1.21	0.79	0.84	0.86	0.90	1.07	0.76	0.53	0.47	0.55	0.60	0.69	0.85	0.93	0.88	0.88	0.88
30	1.16	0.80	0.82	0.85	0.86	1.27	0.83	0.49	0.42	0.55	0.59	0.61	1.00	1.14	0.97	1.11	1.08
40	1.13	0.82	0.79	0.84	0.80	1.23	0.73	0.43	0.35	0.54	0.62	0.60	1.31	1.37	1.17	1.27	1.20
60	1.06	0.82	0.76	0.79	0.76	1.14	0.63	0.72	0.68	0.68	0.81	0.86	1.66	1.77	1.70	1.63	1.38
98	0.77	0.79	0.75	0.77	0.70	1.05	0.63	0.50	0.50	0.64	0.85	0.98	2.12	2.13	2.21	2.11	1.55

**Initial Supporting table - PairCylModeJerk**

**Description:** Used for P0300 - P0308, Multiplier to P0300\_CylModeJerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,600	3,000	3,500	4,000
8	1.30	1.20	1.25	1.26	1.03	1.18	1.31	1.36	1.13	1.20	1.33	1.39	1.14	1.33	1.31	1.31	1.31
12	1.33	1.15	1.16	1.04	1.23	1.72	1.31	1.16	1.21	1.25	1.24	1.26	1.24	1.28	1.45	1.45	1.45
16	1.32	1.05	1.07	0.96	1.21	2.15	1.32	1.07	0.95	1.07	1.07	0.93	0.93	1.06	1.08	1.08	1.08
20	1.37	1.02	1.05	1.04	1.22	1.89	1.48	1.11	0.65	0.80	0.83	0.85	0.81	1.14	0.93	0.93	0.93
24	1.43	1.03	1.00	1.06	1.20	2.07	1.92	1.05	0.52	0.62	0.68	0.69	0.85	1.04	1.00	1.00	1.00
30	1.45	1.01	0.91	0.97	1.06	2.51	2.26	0.87	0.50	0.51	0.55	0.60	0.98	1.09	1.04	1.20	1.50
40	1.48	1.00	0.85	0.84	0.95	2.48	1.45	0.59	0.69	0.67	0.53	0.82	1.14	1.39	1.41	1.40	2.38
60	1.54	0.99	0.77	0.81	0.89	2.28	1.90	1.51	1.30	1.39	0.82	2.22	1.45	1.68	1.68	3.69	2.54
98	1.62	0.98	0.74	0.77	0.86	2.12	2.09	1.09	1.01	1.28	0.92	1.84	1.68	1.67	2.14	3.82	2.64

**Initial Supporting table - Random\_SCD\_Decel**

**Description:** Used for P0300 - P0308, Multitplier to SCD\_Decel to account for different patternri of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.15	1.10	1.05	1.03	1.03	1.03	1.03	1.03	1.03
12	1.15	1.10	1.09	1.08	1.05	1.05	1.05	1.05	1.05
16	1.15	1.15	1.15	1.15	1.13	1.13	1.13	1.15	1.15
20	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
24	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
30	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
40	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
60	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
98	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15

## Initial Supporting table - Random\_SCD\_Jerk

**Description:** Used for P0300 - P0308, Multplier to Random\_SCD\_Jerk to account for differerit pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**Initial Supporting table - RandomAFM\_Decl**

**Description:** Used for P0300 - P0308, Multiplier to CylinderJDecel while in Cylinder Deactivation mode to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**Initial Supporting table - RandomAFM\_Jerk**

**Description:** Used for P0300 - P0308, Multiplier to Cylinder\_Jerk while in Cylinder Deactivation mode to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## Initial Supporting table - RandomCylModDecel

**Description:** Used for P0300 - P0308. Multiplier to CylMode\_Decel. account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** Multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,600	3,000	3,500	4,000
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.08	1.09	1.06	1.00	1.10	1.02	1.04	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.04	1.00	1.21	1.00	1.00	1.13	1.35	1.16	1.15	1.23	1.23	1.23
16	1.00	1.00	1.00	1.00	1.00	1.00	1.06	1.10	1.00	1.00	1.25	1.12	1.29	1.35	1.36	1.36	1.36
20	1.00	1.00	1.00	1.00	1.00	1.08	1.00	1.20	1.41	1.39	1.28	1.25	1.50	1.32	1.33	1.33	1.33
24	1.00	1.00	1.00	1.00	1.00	1.04	1.00	1.20	1.30	1.36	1.14	1.15	1.33	1.30	1.21	1.21	1.21
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.20	1.20	1.40	1.23	1.18	1.24	1.32	1.20	1.33	1.33
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.16	1.18	1.55	1.50	1.29	1.22	1.41	1.33	1.50	1.53
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.19	1.67	2.03	1.65	1.34	1.67	1.80	1.89	1.71
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.01	1.21	1.68	2.90	2.15	1.59	1.92	2.29	2.57	1.97

**Initial Supporting table - RandomCylModJerk**

**Description:** Used for P0300 - P0308, Multiplier to CylMode\_Jerk to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,600	3,000	3,500	4,000
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.10	1.06	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.28	1.00	1.00	1.07	1.04	1.11	1.10	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.45	1.08	1.03	1.07	1.13	1.06	1.12	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.42	1.44	1.25	1.15	1.31	1.10	1.15	1.00	1.20	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.27	2.01	1.76	1.30	2.04	1.16	1.17	1.24	1.10	1.75
60	1.00	1.00	1.00	1.00	1.00	1.00	1.23	1.39	1.57	2.32	1.49	3.87	1.30	1.32	1.27	2.77	1.85
98	1.00	1.00	1.00	1.00	1.00	1.00	1.21	1.44	1.52	2.48	1.71	3.34	1.38	1.24	1.52	2.86	2.09



## Initial Supporting table - FandomRevModDecl

**Description:** Used for P0300 - P0308, Multplier to RevMode\_Decel to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	3,001	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

**Initial Supporting table - RepetSnapDecayAdjst**

**Description:** Used for P0300 - P0308, If misfire is present in consecutive engine cycles, this multiplier is applied to the misfire jerk threshold and compared to a crankshaft snap value after the misfire has taken place.. Table lookup as a function of engine rpm.

**Value Units:** multiplier

**X Unit:** RPM

y/x	900	1,100	1,400	1,600	1,800	2,000	2,600	3,000	4,000
1	1.00	1.00	1.15	1.25	2.14	1.20	1.03	1.00	1.00

**Initial Supporting table - RevMode\_Decel**

**Description:** Used for P0300-P0308. Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

**Value Units:** Delta time between revolutions (usec)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	90	58	47	34	28	20	20	20
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	88	56	45	32	26	20	20	20
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	86	56	44	30	26	20	20	20
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	85	57	45	30	26	20	20	20
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	86	59	45	32	27	20	20	20
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	86	63	46	34	29	21	21	21
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	94	68	47	36	33	22	22	22
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	105	72	49	39	36	25	25	25
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	115	77	52	42	40	29	29	29
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	123	82	55	45	43	32	32	32
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	132	86	60	49	47	34	34	34
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	141	91	64	51	51	37	37	37
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	155	99	74	60	60	43	42	42
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
40	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
97	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**Initial Supporting table - Ring Filter**

**Description:** Used for P0300-P0308. Driveline Ring Filter  
 After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

**Value Units:** Number of Engine cycles after isolated misfire (Engine cycles)

**X Unit:** thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	7	4	7	7	7	7	7	7	7

**Initial Supporting table - SCD\_Decel**

**Description:** Used for P0300-P0308 Crankshaft decel threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

**Value Units:** Delta time per cylinder (usec)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	607	607	344	214	148	100	77	58	48	32,767	32,767	32,767	32,767
6	590	576	318	198	138	95	70	55	48	32,767	32,767	32,767	32,767
8	610	586	337	197	136	95	69	54	50	32,767	32,767	32,767	32,767
10	658	617	353	212	146	98	73	51	49	32,767	32,767	32,767	32,767
12	734	668	382	231	157	106	80	51	55	32,767	32,767	32,767	32,767
14	858	722	415	254	172	117	87	51	66	32,767	32,767	32,767	32,767
16	1,195	789	449	278	188	132	96	52	75	32,767	32,767	32,767	32,767
18	1,586	858	480	310	205	151	111	61	82	32,767	32,767	32,767	32,767
20	2,066	941	520	347	226	172	126	74	92	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
40	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
97	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

## Initial Supporting table - SCD\_Jerk

**Description:** Used for P0300-P0308. Crankshaft jerk threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

**Value Units:** Change in Delta time per cylinder from last cylinder (usec)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	886	554	303	185	126	95	73	54	43	32,767	32,767	32,767	32,767
6	766	520	264	160	117	84	71	50	37	32,767	32,767	32,767	32,767
8	716	508	270	160	117	82	70	50	37	32,767	32,767	32,767	32,767
10	666	506	264	159	123	88	70	52	40	32,767	32,767	32,767	32,767
12	752	518	260	156	128	94	74	55	45	32,767	32,767	32,767	32,767
14	873	574	256	149	130	94	82	58	62	32,767	32,767	32,767	32,767
16	1,278	659	328	197	132	103	90	64	80	32,767	32,767	32,767	32,767
18	1,618	740	422	265	158	129	102	82	91	32,767	32,767	32,767	32,767
20	2,032	825	538	357	212	157	123	104	110	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
40	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
97	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**Initial Supporting table - SnapDecayAfterMisfire**

**Description:** Used for P0300 - P0308, multiplier times the dtjerk value used to detect misfire at that speed and load to see if size of disturbance has died down as expected of real misfire. Table lookup as a function of engine rpm and trans gear ratio.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** gear ratio

y/x	900	1,100	1,400	1,600	1,800	2,000	2,600	3,000	4,000
1	1.00	3.20	3.72	2.59	2.00	1.93	2.55	3.38	3.38
1	0.89	2.46	2.91	2.83	2.52	3.27	2.28	3.27	3.27
1	1.13	2.30	2.22	2.06	2.06	2.53	2.09	2.04	2.75
1	0.97	1.70	1.51	1.57	1.62	1.87	2.43	2.79	2.57
2	1.15	1.39	1.07	1.06	1.23	1.55	2.21	2.75	3.75
3	1.29	1.60	1.34	1.20	1.03	1.21	1.89	2.33	2.75
5	1.25	1.34	1.20	1.28	1.19	1.42	1.72	2.08	2.08
6	1.25	1.34	1.20	1.28	1.19	1.42	1.72	2.08	2.08
7	1.25	1.34	1.20	1.28	1.19	1.42	1.72	2.08	2.08

**Initial Supporting table - TGSSRoughRoadThres**

**Description:** Used for P0300-P0308. Only used if Rough Road source = TOSS: dispersion value on Transmission Output Speed Sensor above which rough road is indicated present

**Value Units:** change in rpm per sec (rpm)

**X Unit:** Engine Speed (RPM)

**Y Units:** Transmission Speed (RPM)

y/x	600	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000
100	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
300	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
500	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
700	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
900	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,100	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,300	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0



**Initial Supporting table - WaitToStart**

**Description:** Used for P0300-P0308. Number of engine cycles to delay if diesel engine is cranked before wait to start lamp is extinguished. This lookup table determines the delay length by taking into account the coolant temperature.

**Value Units:** Number of Engine Cycles (integer)

**X Unit:** Engine Coolant (deg C)

y/x	-20	-10	0	10	20	30	40	50	60
1	0	0	0	0	0	0	0	0	0

**Initial Supporting table - WSSRoughRoadThres**

**Description:** Used for P0300-P0308. Only used if Wheel speed from ABS is used. If difference between wheel speed readings is larger than this limit, rough road is present

**Value Units:** acceleration  
**X Unit:** Vehicle Speed (KPH)

y/x	0	12	24	36	48	60	72	85	97	109	121	133	145	157	169	181	193
1	0.40002	0.42004	0.43994	0.45996	0.47998	0.50000	0.52002	0.54004	0.56006	0.57996	0.59998	0.62000	0.64001	0.66003	0.68005	0.69995	0.71997

**Initial Supporting table - ZeroTorqueAFM**

**Description:** Used for P0300-P0308. Zero torque engine load while in Active Fuel Management. %of Max Brake Torque along the Neutral rev line, as a function of RPM and Baro

**Value Units:** Percent of Maximum Brake torque (%)

**X Unit:** RPM

**Y Units:** Barometric Pressure (kPa)

**ZeroTorqueAFM - Part 1**

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
65	-3.50	-3.50	-3.50	-2.50	-2.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00
75	-3.50	-3.50	-3.50	-2.50	-2.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00
85	-3.50	-3.50	-3.50	-2.50	-2.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00
95	-3.50	-3.50	-3.50	-2.50	-2.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00
105	-3.50	-3.50	-3.50	-2.50	-2.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00

**ZeroTorqueAFM - Part 2**

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
65	-1.00	-1.00	-1.00	-1.00	-1.00	-0.15	2.35	4.85	7.35	9.85	12.35	14.85	17.35
75	-1.00	-1.00	-1.00	-1.00	-1.00	-0.15	2.35	4.85	7.35	9.85	12.35	14.85	17.35
85	-1.00	-1.00	-1.00	-1.00	-1.00	-0.15	2.35	4.85	7.35	9.85	12.35	14.85	17.35
95	-1.00	-1.00	-1.00	-1.00	-1.00	-0.15	2.35	4.85	7.35	9.85	12.35	14.85	17.35
105	-1.00	-1.00	-1.00	-1.00	-1.00	-0.15	2.35	4.85	7.35	9.85	12.35	14.85	17.35

**Initial Supporting table - ZeroTorqueEngLoad**

**Description:** Used for P0300-P0308. %of Max Brake Torque that represents Zero Brake torque along the Neutral rev line, as a function of RPM and Baro

**Value Units:** Percent of Maximum Brake torque (%)

**X Unit:** RPM

**Y Units:** Barometric Pressure (kPa)

**ZeroTorqueEngLoad - Part 1**

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
65	-2.50	-2.50	-2.50	-2.31	-2.12	-1.93	-1.75	-1.56	-1.38	0.00	-0.10	-0.55	-1.00
75	-2.25	-2.25	-2.25	-2.06	-1.87	-1.68	-1.50	-1.31	-1.13	0.25	0.15	-0.30	-0.75
85	-2.00	-2.00	-2.00	-1.81	-1.62	-1.44	-1.25	-1.06	-0.88	0.50	0.40	-0.05	-0.50
95	-1.75	-1.75	-1.75	-1.56	-1.37	-1.19	-1.00	-0.81	-0.63	0.75	0.65	0.20	-0.25
105	-1.50	-1.50	-1.50	-1.31	-1.12	-0.94	-0.75	-0.56	-0.38	1.00	0.90	0.45	0.00

**ZeroTorqueEngLoad - Part 2**

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
65	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	6.57	14.13	21.70	29.26	36.83	44.39	59.52
75	-0.75	-0.75	-0.75	-0.75	-0.75	-0.75	6.82	14.38	21.95	29.51	37.08	44.64	59.77
85	-0.50	-0.50	-0.50	-0.50	-0.50	-0.50	7.07	14.63	22.20	29.76	37.33	44.89	60.02
95	-0.25	-0.25	-0.25	-0.25	-0.25	-0.25	7.32	14.88	22.45	30.01	37.58	45.14	60.27
105	0.00	0.00	0.00	0.00	0.00	0.00	7.57	15.13	22.70	30.26	37.83	45.39	60.52

### Initial Supporting table - Closed Loop Enable Clarification - KaFCLP U SphrIntgIOfst Thrsh

**Description:** Integral Offset voltage thresholds (bank and cell specific calcs) used with KeFCLP\_Pct\_CatAccuSphrPostDsbl to check for sulphur poisoning.

**Value Units:** millivolts

**X Unit:** Post Catalyst Number

y/x	CiOXYR_O2_PostCat1	CiOXYR_O2_PostCat2
CiFCLP_Decel	1,000	1,000
CiFCLPJdle	1,000	1,000
CiFCLP_Cruise	1,000	1,000
CiFCLP_LightAccel	1,000	1,000
CiFCLP_HeavyAccel	1,000	1,000

**Initial Supporting table - Closed Loop Enable Clarification - KcFCLP\_Cnt\_O2RdyCyclesThrsh****Description:** Number of times a post oxygen sensor value must be in range before declaring it ready**Value Units:** Time (events \* 12.5 milliseconds)

y/x	
1	10

**Initial Supporting table - Closed Loop Enable Clarification - KcFULC\_O2\_SensorReadyEvents****Description:** Number of times a pre oxygen sensor value must be in range before declaring it ready**Value Units:** Time (events \* 12.5 milliseconds)

y/x	
1	10

**Initial Supporting table - Closed Loop Enable Clarification - KeEOSDURichThrsh**

**Description:** The oxygen sensor voltage above which a sensor will be considered failing during a Rich Test.

**Value Units:** Volts

y/x	1
1	1,050



**Initial Supporting table - Closed Loop Enable Clarification - KeFCLP\_dm\_IntegrationAirflowMax**

**Description:** Maximum allowed estimated airflow for post 02 integral terms to be updated.

**Value Units:** Grams per Second

y/x	1
1	512

**Initial Supporting table - Closed Loop Enable Clarification - KeFCLP Pct CatAccuSlphrPostDsbl**

**Description:** Sulphur percent threshold above which post integral learning is disabled if the threshold criteria KaFCLP\_U\_SlphrIntglOfst\_Thrsh is also met.

**Value Units:** Percent

y/x	1
1	75

**Initial Supporting table - Closed Loop Enable Clarification - KeFCLP\_T\_IntegrationCatalystMax**

**Description:** Maximum allowed estimated catalytic converter temperature for post 02 integral terms to be updated.

**Value Units:** Celcius

y/x	1
1	950

**Initial Supporting table - Closed Loop Enable Clarification - KeFCLP\_T\_IntegrationCatalystMin**

**Description:** Minimum allowed estimated catalytic converter temperature to begin using post 02 integration correction terms. Converter temperature must remain above this threshold to ramp-in the post 02 integration adjustments. Once the ramp-in has started, a converter temperature below this threshold will freeze the ramp-in multiplier. Post 02 integration will not be allowed below this converter temperature

**Value Units:** Celcius

y/x	1
1	500

**Initial Supporting table - Closed Loop Enable Clarification - KeFULC T WRAF SensorReadyThrsh**

**Description:** Pumping cell temperature threshold above which the wideband oxygen sensor will be considered ready for use

**Value Units:** Degrees Celcius

y/x	1
1	700

**Initial Supporting table - Closed Loop Enable Clarification - KeWRSC T HtrCntrlCL**

**Description:** WRAF heater temperature enabling threshold for transition from Open Loop to Closed Loop

**Value Units:** Degrees Celcius

y/x	1
1	628

**Initial Supporting table - Closed Loop Enable Clarification - KeWRSI T PumpCurrentEnable**

**Description:** WRAF heater temperature threshold for enabling the sensor pump current

**Value Units:** Degrees Celcius

y/x	1
1	628

**Initial Supporting table - Closed Loop Enable Clarification - KfFCLL T AdaptiveLoCoolant**

**Description:** LTM learning is inhibited if the engine coolant temperature is below this calibration.

**Value Units:** Degrees Celcius

y/x	1
1	39



**Initial Supporting table - Closed Loop Enable Clarification - KfFCLP\_U\_O2ReadyThrshLo****Description:** Voltage limit checked against when determining if a post converter oxygen sensor is in range**Value Units:** millivolts

y/x	
1	1,100

**Initial Supporting table - Closed Loop Enable Clarification - KfFULC\_U\_O2\_SensorReadyThrshLo**

**Description:** Voltage limit checked against when determining if a pre converter oxygen sensor is in range

**Value Units:** millivolts

y/x	1
1	1,795

**Initial Supporting table - Closed Loop Enable Clarification - KtFCLL p AdaptiveLowMAP Limit**

**Description:** Long term fuel learning is disabled below this MAP limit as a function of barometric pressure.

**Value Units:** KPa

**X Unit:** KPa

y/x	65	70	75	80	85	90	95	100	105
1	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

**Initial Supporting table - Closed Loop Enable Clarification - KtFCLP t PostIntgIDisableTime**

**Description:** Disable integral offset after engine start for this amount of time as a function of start up coolant temperature.

**Value Units:** Time in seconds

**X Unit:** Degrees Celcius

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	150.0	150.0	150.0	150.0	150.0	150.0	150.0	150.0	150.0	150.0	150.0	150.0	150.0	150.0	150.0	150.0	150.0

**Initial Supporting table - Closed Loop Enable Clarification - KtFCLPtPostIntgIRamplnTime**

**Description:** Time required to ramp integral offset to desired value as a function of start up coolant temperature.

**Value Units:** Time in seconds

**X Unit:** Degrees Celcius

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	60.0	60.0	60.0	60.0	60.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0

**Initial Supporting table - Closed Loop Enable Clarification - KtFSTA\_t\_ClosedLoopAutostart**

**Description:** Engine run time following an autostart, as a function of begin run coolant, which must be exceeded to enable CLOSED LOOP.

**Value Units:** Time in seconds

**X Unit:** Degrees Celcius

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
0	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	10.0	10.0	10.0	10.0	10.0
25	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	10.0	10.0	10.0	10.0	10.0
50	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	10.0	10.0	10.0	10.0	10.0
75	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	10.0	10.0	10.0	10.0	10.0
100	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	10.0	10.0	10.0	10.0	10.0

**Initial Supporting table - Closed Loop Enable Clarification - KtFSTA\_t\_ClosedLoopTime**

**Description:** Engine run time, as a function of startup coolant temperature, which must be exceeded to enable CLOSED LOOP.

**Value Units:** Time in seconds

**X Unit:** Degrees Celcius

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
0	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	10.0	10.0	10.0	10.0	10.0
25	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	10.0	10.0	10.0	10.0	10.0
50	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	10.0	10.0	10.0	10.0	10.0
75	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	10.0	10.0	10.0	10.0	10.0
100	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	10.0	10.0	10.0	10.0	10.0

**Initial Supporting table - P0442 Volatility Time as a Function of Estimate of Ambient Temperature**

**Description:** EONV volatility time as a function of estimated ambient temperature

**Value Units:** Volatility time (seconds)

**X Unit:** Estimated Ambient Temperature (Deg C)

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30



**Initial Supporting table - P0442 Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature**

**Description:** Maximum engine off time before vehicle off time as a function of estimated ambient temperature (EAT)

**Value Units:** Maximum Engine Off Time Before Vehicle Off Time (seconds)

**X Unit:** Estimated Ambient Temperature (Deg C)

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30

### Initial Supporting table - P0442 EON)V Pressure Threshold (Pascals)

**Description:** EONV pressure threshold as a function of fuel level and estimated ambient temperature (EAT)

**Value Units:** EONV Pressure Threshold (Pascals)

**X Unit:** Fuel Level (percent) from 0 to 100 with step size 6.25

**Y Units:** Estimated Ambient Temperature (deg C) from -10 to 80 with step size 5.625

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
2	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
3	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
4	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
6	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
7	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
8	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
9	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
10	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
11	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
12	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
13	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
14	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
15	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
16	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
17	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5

**Initial Supporting table - P0496 Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level**

**Description:** Purge valve leak test engine vacuum test time as a function of fuel level

**Value Units:** Purge Valve Leak Test Engine Vacuum Test Time (seconds)

**X Unit:** Fuel Level (percent)

y/x	0	6	12	19	25	31	37	44	50	56	62	69	75	81	87	94	100
1	75	72	70	67	65	62	59	57	54	52	49	46	44	41	39	36	33

**Initial Supporting table - P057B KtBRKI K CmpltTestPointWeight**

**Description:**

y/x	0.000	0.010	0.020	0.026	0.050	0.250	0.500	0.750	1.000
1	0	0	0	1	1	1	1	1	1

**Initial Supporting table - P057B KtBRKI K FastTestPointWeight**

Description:									
y/x	0.000	0.010	0.020	0.026	0.050	0.250	0.500	0.750	1.000
1	0	0	0	1	1	1	1	1	1

**Initial Supporting table - DFCO CoolEnbIHi Temp**

**Description:**

y/x	-40	0	25
1	30.0	30.0	30.0

**Initial Supporting table - DFCODelayAfterStartTime**

Description:					
y/x	-30	20	55	70	90
1	30.0	30.0	30.0	30.0	30.0

**Initial Supporting table - DFCO DrvrReqZPTEnbIOf**

**Description:****DFCO\_DrvrReqZPTEnbIOf - Part 1**

y/x	CeDTRR_e_TrqShapingRateA	CeDTRR_e_TrqShapingRateB	CeDTRR_e_TrqShapingRateC	CeDTRR_e_TrqShapingRateD	CeDTRR_e_TrqShapingRateE
CeTCOR_e_Exh_Normal	12	12	12	12	12
CeTCOR_e_Exh_Sport	12	12	12	12	12
CeTCOR_e_Exh_Track	12	12	12	12	12

**DFCO\_DrvrReqZPTEnbIOf - Part 2**

y/x	CeDTRR_e_TrqShapingRateF	CeDTRR_e_TrqShapingRateG	CeDTRR_e_TrqShapingRateH	CeDTRR_e_TrqShapingRateI	CeDTRR_e_TrqShapingRateJ
CeTCOR_e_Exh_Normal	12	12	12	12	12
CeTCOR_e_Exh_Sport	12	12	12	12	12
CeTCOR_e_Exh_Track	12	12	12	12	12



<b>Initial Supporting table - DFCO_DsbILo_Vehicle_Speed</b>
---

<b>Description:</b>		
y/x	CeTCOR_e_NonEcoMode	CeTCOR_e_EcoMode
CeTGRR_e_TransGr1	0	0
CeTGRR_e_TransGr2	0	0
CeTGRR_e_TransGr3	0	0
CeTGRR_e_TransGr4	0	0
CeTGRR_e_TransGr5	0	0
CeTGRR_e_TransGr6	0	0
CeTGRR_e_TransGr9	0	0
CeTGRR_e_TransGr10	0	0
CeTGRR_e_TransGrNeut	0	0
CeTGRR_e_TransGrRvrs	0	0
CeTGRR_e_TransGrPark	0	0
CeTGRR_e_TransGr7	0	0
CeTGRR_e_TransGr8	0	0

## Initial Supporting table - DFCO EnblHi Vehicle Speed

Description:		
y/x	CeTCOR_e_NonEcoMode	CeTCOR_e_EcoMode
CeTGRR_e_TransGr1	20.0	20.0
CeTGRR_e_TransGr2	28.2	28.2
CeTGRR_e_TransGr3	0.0	0.0
CeTGRR_e_TransGr4	0.0	0.0
CeTGRR_e_TransGr5	0.0	0.0
CeTGRR_e_TransGr6	0.0	0.0
CeTGRR_e_TransGr9	0.0	0.0
CeTGRR_e_TransGr10	0.0	0.0
CeTGRR_e_TransGrNeut	0.0	0.0
CeTGRR_e_TransGrRvrs	0.0	0.0
CeTGRR_e_TransGrPark	0.0	0.0
CeTGRR_e_TransGr7	0.0	0.0
CeTGRR_e_TransGr8	0.0	0.0

**Initial Supporting table - DFCO EngSpdEnblOfst**

Description:									
y/x	-2,500	-2,150	-1,500	-500	-200	-150	-100	-8	0
1	500	100	50	0	0	0	0	0	0

## Initial Supporting table - DFCO MinRunImmDsblOf

## Description:

## DFCO\_MinRunImmDsblOf - Part 1

y/x	CeDTRR_e_TrqShapingRateA	CeDTRR_e_TrqShapingRateB	CeDTRR_e_TrqShapingRateC	CeDTRR_e_TrqShapingRateD	CeDTRR_e_TrqShapingRateE
CeTCOR_e_Exh_Normal	65,535	65,535	65,535	65,535	65,535
CeTCOR_e_Exh_Sport	65,535	65,535	65,535	65,535	65,535
CeTCOR_e_Exh_Track	65,535	65,535	65,535	65,535	65,535

## DFCO\_MinRunImmDsblOf - Part 2

y/x	CeDTRR_e_TrqShapingRateF	CeDTRR e TrqShapingRate G	CeDTRR_e_TrqShapingRateH	CeDTRR_e_TrqShapingRateI	CeDTRR_e_TrqShapingRateJ
CeTCOR_e_Exh_Normal	65,535	65,535	65,535	65,535	65,535
CeTCOR_e_Exh_Sport	65,535	65,535	65,535	65,535	65,535
CeTCOR_e_Exh_Track	65,535	65,535	65,535	65,535	65,535

**Initial Supporting table - DFCO ZeroPedAxITrqDisblOfst**

**Description:****DFCO\_ZeroPedAxITrqDisblOfst - Part 1**

y/x	CeDTRR_e_TrqShapingRateA	CeDTRR_e_TrqShapingRateB	CeDTRR_e_TrqShapingRateC	CeDTRR_e_TrqShapingRateD	CeDTRR_e_TrqShapingRateE
CeTCOR_e_Exh_Normal	20	20	20	20	20
CeTCOR_e_Exh_Sport	20	20	20	20	20
CeTCOR_e_Exh_Track	20	20	20	20	20

**DFCO\_ZeroPedAxITrqDisblOfst - Part 2**

y/x	CeDTRR_e_TrqShapingRateF	CeDTRR_e_TrqShapingRateG	CeDTRR_e_TrqShapingRateH	CeDTRR_e_TrqShapingRateI	CeDTRR_e_TrqShapingRateJ
CeTCOR_e_Exh_Normal	20	20	20	20	20
CeTCOR_e_Exh_Sport	20	20	20	20	20
CeTCOR_e_Exh_Track	20	20	20	20	20

### Initial Supporting table - P0068\_Delta MAF Threshold f(TPS)

**Description:** Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

**Value Units:** Delta MAF Values (dm)

**X Unit:** Desired Throttle Position (Pct)

y/x	10.00	15.00	20.00	25.00	30.00	35.00	40.00	45.00	100.00
1.00	55.48	61.44	67.30	73.12	255.00	255.00	255.00	255.00	255.00

**Initial Supporting table - P0068\_Delta MAP Threshold f(TPS)**

**Description:** Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

**Value Units:** Delta MAP Values (kPa)

**X Unit:** Desired Throttle Position (Pct)

y/x	10.00	15.00	20.00	25.00	30.00	35.00	40.00	45.00	100.00
1.00	48.61	46.87	39.48	34.73	255.00	255.00	255.00	255.00	255.00

**Initial Supporting table - P0068\_Maximum MAF f(RPM)**

**Description:** Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

**Value Units:** Delta MAF Values (dm)

**X Unit:** Engine Speed (RPM)

y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
1.00	30.00	68.00	112.00	155.00	207.00	262.00	298.00	305.00	305.00



**Initial Supporting table - P0068\_Maximum MAF f(Volts)**

**Description:** Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.

**Value Units:** Delta MAF Values (dm)

**X Unit:** System Voltage (V)

y/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00
1.00	69.70	180.36	376.20	511.99	511.99	511.99	511.99	511.99	511.99

**Initial Supporting table - P0326\_P0331\_AbnormalNoise\_Thresh\_AFM**

**Description:** Fail threshold for the Knock Performance Abnormal Noise Diagnostic when engine IS in AFM mode

**Value Units:** Filtered background engine noise. Unit-less term from the Knock Detection Fast Fourier Transform (FFT) for a selected frequency range.

**X Unit:** Engine Speed (RPM)

**Y Units:** N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.064	0.064	0.064	0.064	0.068	0.100	0.152	0.243	0.718	0.851	1.855	1.855	1.855	1.855	1.855	1.855	1.855

### Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

**Value Units:** Max Time for Last Seed Timeout (ms)

**X Unit:** Operating Loop Sequence (enum)

#### P0606\_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000	200.000

#### P0606\_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	200.000	500.000	500.000	1,000.000	8,191.875	8,191.875	8,191.875	8,191.875

### Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)

**Description:** Fail threshold for PSW per operating loop.

**Value Units:** Fail threshold for PSW (count)

**X Unit:** Operating Loop (enum)

#### P0606\_PSW Sequence Fail f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	5	3	5	3	5	3	5	3

#### P0606\_PSW Sequence Fail f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventASeq	CePISR_e_EventBSeq	CePISR_e_EventCSeq
1	5	3	5	3	5	5	5	5

**Initial Supporting table - P0606 PSW Sequence Sample f(Loop Time)**

**Description:** Sample threshold for PSW per operating loop.

**Value Units:** Sample threshold for PSW (count)

**X Unit:** Operating Loop (enum)

**P0606\_PSW Sequence Sample f(Loop Time) - Part 1**

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	4	4	4	4	4	4	4	4

**P0606\_PSW Sequence Sample f(Loop Time) - Part 2**

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	4	4	4	4	4	4	4	4

**Initial Supporting table - P1682 PT Relay Pull-in Run/Crank Voltage f(IAT)**

**Description:** The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

**Value Units:** Run/Crank Voltages required to pull in PT Relay (V)

**X Unit:** Induction Air Temperature (deg C)

y/x	23.0	85.0	95.0	105.0	125.0
1	7.000	8.699	9.000	9.199	10.000

**Initial Supporting table - P16A7 PT Relay Pull-in Run/Crank Voltage f(IAT)**

**Description:** The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

**Value Units:** Run/Crank Voltages required to pull in PT Relay (V)

**X Unit:** Induction Air Temperature (deg C)

y/x	23.0	85.0	95.0	105.0	125.0
1	7.000	8.699	9.000	9.199	10.000

**Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)**

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

**Value Units:** Max Time for Last Seed Timeout (ms)

**X Unit:** Operating Loop Sequence (enum)

**P0606\_Last Seed Timeout f(Loop Time) - Part 1**

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000	200.000

**P0606\_Last Seed Timeout f(Loop Time) - Part 2**

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	200.000	500.000	500.000	1,000.000	8,191.875	8,191.875	8,191.875	8,191.875



**Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)**

**Description:** Fail threshold for PSW per operating loop.

**Value Units:** Fail threshold for PSW (count)

**X Unit:** Operating Loop (enum)

**P0606\_PSW Sequence Fail f(Loop Time) - Part 1**

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	5	3	5	3	5	3	5	3

**P0606\_PSW Sequence Fail f(Loop Time) - Part 2**

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventASeq	CePISR_e_EventBSeq	CePISR_e_EventCSeq
1	5	3	5	3	5	5	5	5

**Initial Supporting table - P0606 PSW Sequence Sample f(Loop Time)**

**Description:** Sample threshold for PSW per operating loop.

**Value Units:** Sample threshold for PSW (count)

**X Unit:** Operating Loop (enum)

**P0606\_PSW Sequence Sample f(Loop Time) - Part 1**

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	4	4	4	4	4	4	4	4

**P0606\_PSW Sequence Sample f(Loop Time) - Part 2**

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	4	4	4	4	4	4	4	4

**Initial Supporting table - P060C\_Delta MAP Threshold f(Desired Engine Torque)**

**Description:** Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

**Value Units:** Torque Security Threshold for Engine Sync and Time Based Delta Pressure (kPa)

**X Unit:** Desired Engine Torque (Nm)

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	34.73	34.73	34.73	34.73	34.73	34.73

### Initial Supporting table - P060C\_Speed Control External Load f(Oil Temp, RPM)

**Description:** Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

**Value Units:** External Load Table for SPDR (Nm)

**X Unit:** Engine Oil Temperature (deg C)

**Y Units:** Engine Speed (RPM)

y/x	-40.00	-15.00	5.00	32.00	55.00	90.00
350.00	439.00	439.00	439.00	434.28	412.25	256.54
450.00	439.00	439.00	439.00	353.08	333.68	210.57
570.00	439.00	388.61	349.08	248.10	230.94	154.38
650.00	422.36	370.44	335.83	240.40	224.49	136.36
750.00	400.06	351.40	323.93	250.50	234.14	118.05
850.00	398.50	356.58	332.39	271.68	255.33	138.64
950.00	400.59	359.12	332.62	287.61	265.17	145.41
1,050.00	392.72	351.60	323.18	289.73	262.24	150.96
1,150.00	349.22	309.95	282.61	238.46	213.69	126.20
1,350.00	285.43	248.11	222.07	176.68	155.25	115.00
1,600.00	198.80	166.04	141.72	97.85	80.07	87.00
2,150.00	140.94	109.38	87.12	44.66	31.23	25.00
2,400.00	120.41	89.25	67.68	26.87	14.88	3.20
3,100.00	85.47	54.94	34.45	-4.41	-14.11	-21.86
4,000.00	63.09	32.84	12.84	-24.15	-32.82	-42.54
4,900.00	48.80	18.55	-1.45	-38.44	-47.10	-56.85
5,800.00	33.49	3.24	-16.76	-53.56	-62.22	-72.79

**Initial Supporting table - P'129F Threshold High**

**Description:** P129F Filtered Fuel Pump Speed Error High Threshold [over-performing motor]  
Instantaneously calculated filtered pump speed error measured is higher than commanded

**Value Units:** revs / min

**X Unit:** revs / min [commanded pump speed]

**Y Units:** kiloPascals [requested fuel pressure]

y/x	200.0	300.0	400.0	500.0	600.0
1,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
2,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
3,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
4,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
5,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
6,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
7,000.0	-1,200.0	-1,200.0	-1,200.0	-1,200.0	-1,200.0

**Initial Supporting table - P>129F Threshold Low**

**Description:** P129F Filtered Fuel Pump Speed Error Low Threshold [under-performing motor]  
Instantaneously calculated filtered pump speed error measured is lower than commanded

**Value Units:** revs / min

**X Unit:** revs / min [commanded pump speed]

**Y Units:** kiloPascals [requested fuel pressure]

y/x	200.0	300.0	400.0	500.0	600.0
1,000.0	675.0	675.0	675.0	675.0	675.0
2,000.0	675.0	675.0	675.0	675.0	675.0
3,000.0	675.0	675.0	675.0	675.0	675.0
4,000.0	675.0	675.0	675.0	675.0	675.0
5,000.0	675.0	675.0	675.0	675.0	675.0
6,000.0	675.0	675.0	675.0	675.0	675.0
7,000.0	1,200.0	1,200.0	1,200.0	1,200.0	1,200.0

## Initial Supporting table - P3187\_Threshold

**Description:** P3187 Filtered Fuel Pressure Error Threshold [under-performing pump]

**Value Units:** kilo Pascals

**X Unit:** kPa [commanded fuel pressure]

**Y Units:** grams / sec [fuel flow]

y/x	250.00	300.00	350.00	400.00	450.00	500.00	550.00	600.00	700.00
0.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
1.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
3.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
4.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
6.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
7.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
9.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
10.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
12.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
13.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
15.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
16.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
18.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
19.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
21.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
22.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
24.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
25.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
27.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
28.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
30.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
31.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
33.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
34.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
36.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
37.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
39.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
40.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
42.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
43.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
45.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00

Initial Supporting table • P3187_Threshold									
46.50	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00
48.00	30.00	37.50	45.00	52.50	60.00	67.50	75.00	82.50	90.00



## Initial Supporting table - P3188\_Threshold

**Description:** P3188 Filtered Fuel Pressure Error Threshold [over-performing pump]

**Value Units:** kilo pascals [kPa]

**X Unit:** kPa [commanded fuel pressure]

**Y Units:** grams/sec [fuel flow]

y/x	250.00	300.00	350.00	400.00	450.00	500.00	550.00	600.00	700.00
0.00	-260.00	-210.00	-160.00	-110.00	-60.00	-67.50	-75.00	-82.50	-90.00
1.50	-145.00	-125.00	-102.50	-81.25	-60.00	-67.50	-75.00	-82.50	-90.00
3.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
4.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
6.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
7.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
9.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
10.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
12.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
13.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
15.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
16.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
18.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
19.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
21.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
22.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
24.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
25.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
27.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
28.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
30.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
31.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
33.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
34.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
36.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
37.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
39.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
40.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
42.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
43.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
45.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00

Initial Supporting table • P3188_Threshold									
46.50	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00
48.00	-30.00	-37.50	-45.00	-52.50	-60.00	-67.50	-75.00	-82.50	-90.00

### Initial Supporting table - Minimum Non-Purge Samples for Purge Vapor Fuel

**Description:** Number of Fuel Trim Monitor sample counts required to allow the Purge Vapor Fuel value to inhibit the Intrusive Rich test

**Value Units:** Sample Counts per loop rate of 100ms (divide by 10 to get seconds)

**X Unit:** Long Term Fuel Trim Cell I.D. (no units) (Only PurgeOff cells are used)

#### Minimum Non-Purge Samples for Purge Vapor Fuel - Part 1

y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	65,535	65,535	65,535	65,535

#### Minimum Non-Purge Samples for Purge Vapor Fuel - Part 2

y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	65,535	65,535	65,535	65,535

#### Minimum Non-Purge Samples for Purge Vapor Fuel - Part 3

y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell 10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	305	305	305	305

#### Minimum Non-Purge Samples for Purge Vapor Fuel - Part 4

y/x	CeFADR_e_Cell 12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell1 5_PurgOffDecel
1	305	305	70	70

### Initial Supporting table - P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage

**Description:** Identifies which Long Term Fuel Trim Cell I.D.s are used for diagnosis. Only cells identified as "CeFADD\_e\_NonSelectedCeH" are not used for diagnosis.

#### P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage - Part 1

y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_8electedPurgeCell	CeFADD_e_SelectedPurgeCell

#### P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage - Part 2

y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell

#### P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage - Part 3

y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell

#### P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage - Part 4

y/x	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell

**Initial Supporting table - Startup Engine Coolant adjustment to Minimum accumulation time**

**Description:** Time offset added to the minimum accumulation time based on Startup Coolant.

**Value Units:** Counts (10 counts equals 1 second)

**X Unit:** Degree C

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	500	500	500	500	300	0	0	0	0	0	0	0	0	0	0	0	0

**Initial Supporting table - RufCyl Decel**

**Description:** Used for P0300-P0308. Crankshaft decel threshold during Idle or GPF regen. Thresholds are a function of rpm and % engine Load.

**Value Units:** Delta time per cylinder (usec)

**X Unit:** rpm

**Y Units:** percent load of max indicated torque (%)

**RufCyl\_Decel - Part 1**

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	1,650	1,500	943	575	400	282	219	189	134	93	49	28	20
6	1,650	1,500	925	575	400	260	189	175	132	93	46	28	20
8	1,760	1,600	925	600	425	292	201	166	132	95	47	30	20
10	1,980	1,800	962	635	451	320	206	157	126	85	49	35	28
12	2,200	1,986	1,033	663	472	347	217	161	116	89	50	42	33
14	2,750	2,173	1,114	699	503	366	236	188	129	92	59	53	40
16	3,025	2,326	1,256	783	546	390	262	204	137	87	69	62	46
18	3,135	2,508	1,412	915	631	423	282	223	153	103	90	73	52
20	3,245	2,665	1,568	1,030	721	468	304	250	182	115	103	86	59
22	3,410	2,837	1,700	1,136	793	497	330	275	204	125	110	97	65
24	3,575	2,985	1,800	1,237	859	518	358	294	235	139	126	108	75
26	3,740	3,142	1,900	1,332	935	549	388	316	265	164	149	118	84
28	3,850	3,284	1,994	1,429	1,002	614	419	337	298	190	174	129	90
30	3,960	3,431	2,084	1,526	1,075	680	451	357	319	215	196	138	95
32	4,228	3,568	2,183	1,632	1,152	742	482	378	337	253	225	145	101
34	4,498	3,695	2,287	1,750	1,236	811	514	403	365	291	249	154	108
36	4,765	3,822	2,412	1,875	1,326	876	548	426	390	328	271	165	114

**RufCyl\_Decel - Part 2**

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**Initial Supporting table - RufCyl Decel**

26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**Initial Supporting table - RufCyl Jerk**

**Description:** Crankshaft jerk threshold during Idle or GPF regen. Thresholds are a function of rpm and % engine Load.

**Value Units:** Delta time per cylinder (usec)

**X Unit:** rpm

**Y Units:** percent load of max indicated torque (%)

**RufCyl\_Jerk - Part 1**

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	1,650	1,500	925	575	444	292	168	143	120	98	50	40	24
6	1,650	1,500	925	575	446	288	171	126	112	91	49	39	23
8	1,760	1,600	894	600	446	290	164	114	106	84	47	39	22
10	1,980	1,800	818	587	449	292	151	83	68	62	48	39	28
12	2,200	1,961	731	538	449	292	155	92	59	56	52	45	34
14	2,522	2,129	706	527	449	300	187	116	99	73	60	54	38
16	2,796	2,267	853	612	460	337	218	115	107	88	71	63	43
18	2,983	2,406	1,003	766	534	423	250	145	131	109	92	73	52
20	3,187	2,561	1,152	897	635	475	274	168	156	136	110	83	59
22	3,410	2,716	1,333	997	727	533	297	193	184	164	130	93	65
24	3,575	2,879	1,578	1,086	779	591	325	224	215	190	152	105	74
26	3,740	3,054	1,824	1,204	830	644	353	256	245	225	170	116	82
28	3,901	3,189	2,027	1,307	899	705	383	284	275	254	190	126	88
30	4,083	3,348	2,261	1,396	967	771	416	314	299	276	205	134	95
32	4,265	3,490	2,398	1,510	1,030	834	452	342	327	303	219	142	101
34	4,497	3,617	2,540	1,617	1,093	900	490	377	352	328	236	150	108
36	4,674	3,763	2,695	1,717	1,150	963	523	415	380	356	254	160	114

**RufCyl\_Jerk - Part 2**

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767



**Initial Supporting table - RufCyl Jerk**

26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**Initial Supporting table - RufSCD Decel**

**Description:** Used for P0300-P0308. Crankshaft decel threshold while in SCD mode during Idle or GPF regen. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load. Note: Misfire's Load term is %, but not PID\$04. PID \$04 is not robust to temperature and altitude shifts, (especially decel and jerk thresholds since they track actual air trapped in cylinder)

**Value Units:** Delta time per cylinder (usec)

**X Unit:** rpm

**Y Units:** percent load of max indicated torque (%)

**RufSCD\_Decel - Part 1**

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	607	607	344	214	148	100	77	58	48	32,767	32,767	32,767	32,767
6	590	576	318	198	138	95	70	55	48	32,767	32,767	32,767	32,767
8	610	586	337	197	136	95	69	54	50	32,767	32,767	32,767	32,767
10	658	617	353	212	146	98	73	51	49	32,767	32,767	32,767	32,767
12	734	668	382	231	157	106	80	51	55	32,767	32,767	32,767	32,767
14	858	722	415	254	172	117	87	51	66	32,767	32,767	32,767	32,767
16	1,195	789	449	278	188	132	96	52	75	32,767	32,767	32,767	32,767
18	1,586	858	480	310	205	151	111	61	82	32,767	32,767	32,767	32,767
20	2,066	941	520	347	226	172	126	74	92	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**RufSCD\_Decel - Part 2**

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**Initial Supporting table - RufSCD Decel**

22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**Initial Supporting table - RufSCD Jerk**

**Description:** Used for P0300-P0308. Crankshaft jerk threshold while in SCD mode during Idle or GPF regen. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

**Value Units:** Delta time per cylinder (usec)

**X Unit:** rpm

**Y Units:** percent load of max indicated torque (%)

**RufSCD\_Jerk - Part 1**

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	886	554	303	185	126	95	73	54	43	32,767	32,767	32,767	32,767
6	766	520	264	160	117	84	71	50	37	32,767	32,767	32,767	32,767
8	716	508	270	160	117	82	70	50	37	32,767	32,767	32,767	32,767
10	666	506	264	159	123	88	70	52	40	32,767	32,767	32,767	32,767
12	752	518	260	156	128	94	74	55	45	32,767	32,767	32,767	32,767
14	873	574	256	149	130	94	82	58	62	32,767	32,767	32,767	32,767
16	1,278	659	328	197	132	103	90	64	80	32,767	32,767	32,767	32,767
18	1,618	740	422	265	158	129	102	82	91	32,767	32,767	32,767	32,767
20	2,032	825	538	357	212	157	123	104	110	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**RufSCD\_Jerk - Part 2**

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**Initial Supporting table - RufSCD Jerk**

24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

**Initial Supporting table - Misfire\_IMEP\_BinID\_Load\_Axis**

**Description:** Cylinder LOAD for defining Y AXIS in Misfire\_IMEP\_BinID\_versus\_Speed\_and\_Load

**Value Units:** Indicated Mean Effective Pressure

**X Unit:** Bin ID row number

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0	200	400	600	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,200

**Initial Supporting table - Misfire\_IMEP\_BinID\_RPM\_Axis**

**Description:** Cylinder RPM for defining the X AXIS in Misfire\_IMEP\_BinID\_versus\_Speed\_and\_Load

**Value Units:** RPM

**X Unit:** BinID Column number

y/x	1	2	3	4	5	6	7	8	9
1	0	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000

### Initial Supporting table - Misfire\_IMEP\_BinID\_vs\_RPM\_Load

**Description:** Misfire calibrations used with Crankshaft Based IMEP (Indicated Mean Effective Pressure) estimation do not interpolate versus speed and load. Instead they use unique calibrations within each small speed load "bin". Each Bin has its own "bin ID". This Bin ID keeps all the Crank Based IMEP estimate calculations and various Misfire calibrations synchronized while minimizing through put. Each speed load range defines a unique "Bin ID" in this Bin ID table. The BinID tables Y axis is cylinder load, and X axis is rpm as defined in Misfire\_IMEP\_BinID\_Load\_Axis and Misfire\_IMEP\_BinID\_RPM\_Axis tables

**Value Units:** Bin ID

**X Unit:** RPM range

**Y Units:** Cylinder Load Range

y/x	0	1	2	3	4	5	6	7	8
0	0	17	34	51	68	85	102	119	136
1	1	18	35	52	69	86	103	120	137
2	2	19	36	53	70	87	104	121	138
3	3	20	37	54	71	88	105	122	139
4	4	21	38	55	72	89	106	123	140
5	5	22	39	56	73	90	107	124	141
6	6	23	40	57	74	91	108	125	142
7	7	24	41	58	75	92	109	126	143
8	8	25	42	59	76	93	110	127	144
9	9	26	43	60	77	94	111	128	145
10	10	27	44	61	78	95	112	129	146
11	11	28	45	62	79	96	113	130	147
12	12	29	46	63	80	97	114	131	148
13	13	30	47	64	81	98	115	132	149
14	14	31	48	65	82	99	116	133	150
15	15	32	49	66	83	100	117	134	151
16	16	33	50	67	84	101	118	135	152



**Initial Supporting table - Misfire\_IMEP\_Thresh\_vs\_BinID**

**Description:** Crankshaft Indicated Mean Effective Pressure (IMEP) Estimate that below which will be considered misfire. Misfire calibrations used with Crankshaft Based IMEP (Indicated Mean Effective Pressure) estimation do not interpolate versus speed and load. Instead they use unique calibrations within each small speed load region or "bin". Each Bin has its own "BinID". This BinID keeps all the Crank Based IMEP estimate calculations and various Misfire calibrations synchronized while minimizing through put. Each speed load range defines a unique "Bin ID" in this Bin ID table. The BinID table's Y axis is cylinder load, and X axis is rpm as defined in Misfire\_IMEP\_BinID\_Load\_Axis and Misfire\_IMEP\_BinID\_RPM\_Axis tables

**Value Units:** KPa  
**XUnit:** BinID

**Misfire\_IMEP\_Thresh\_vs\_BinID - Part 1**

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**Misfire\_IMEP\_Thresh\_vs\_BinID - Part 2**

y/x	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**Misfire\_IMEP\_Thresh\_vs\_BinID - Part 3**

y/x	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**Misfire\_IMEP\_Thresh\_vs\_BinID - Part 4**

y/x	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**Misfire\_IMEP\_Thresh\_vs\_BinID - Part 5**

y/x	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**Misfire\_IMEP\_Thresh\_vs\_BinID - Part 6**

y/x	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100	101
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**Misfire\_IMEP\_Thresh\_vs\_BinID - Part 7**

y/x	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**Misfire\_IMEP\_Thresh\_vs\_BinID - Part 8**

y/x	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

**Misfire\_IMEP\_Thresh\_vs\_BinID - Part 9**

y/x	136	137	138	139	140	141	142	143	144	145	146	147	148	149	150	151	152
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

**Initial Supporting table - Misfire\_IMEP\_Thresh\_vs\_BinID**

1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

**Initial Supporting table - P0191 - High fail limit of fuel control due to high pressure sensor skewed High**

**Description:** High fail limit of fuel control due to high pressure sensor skewed High error as Function of desired pressure

**Value Units:** Ratio

**X Unit:** Desired Pressure (Mpa)

y/x	1.50	3.00	4.00	15.00	20.00	25.00	27.50	32.00	36.00
1.00	1.20	1.20	1.20	1.20	1.20	1.20	1.20	1.09	1.05

**Initial Supporting table - P0191 - Low fail limit of fuel control due to pressure sensor skewed low**

**Description:** Low fail limit of fuel control due to pressure sensor skewed low error as Function of desired pressure

**Value Units:** Ratio

**X Unit:** Desired Pressure (Mpa)

y/x	1.50	3.00	4.00	15.00	20.00	25.00	27.50	32.00	36.00
1.00	0.86	0.86	0.86	0.86	0.86	0.86	0.86	0.92	0.95

**Initial Supporting table - P228C P2C1F - High Pressure Pump Control (HPC) fail threshold of pressure too low**

**Description:** The High Pressure Pump Control (HPC) fail threshold of pressure too low test as a function of desired fuel pressure.

**Value Units:** Pressure Error - Desired pressure - Actual Pressure (Mpa)

**X Unit:** Desired Pressure (Mpa)

y/x	2	3	4	15	20	25	28	32	36
1	0	2	3	3	3	3	3	3	3

**Initial Supporting table - P228D P2C20 - High Pressure Pump Control (HPC) fail threshold for pressure too high**

**Description:** The High Pressure Pump Control (HPC) fail threshold for pressure too high test as a function of desired fuel pressure.

**Value Units:** Pressure Error - Desired pressure - Actual Pressure (Mpa)

**X Unit:** Desired Pressure (Mpa)

y/x	1.50	3.00	4.00	15.00	20.00	25.00	27.50	32.00	36.00
1	-3.00	-3.00	-3.00	-3.00	-3.00	-3.00	-3.00	-3.00	-3.00

- P2B00 P2B01 P2B02 P2B03 P2B04 P2B05 P2B06 P2B07 P2B96 P2B08 P2B09 P2B0A P2B0B P2B0C P2B0D P2B0E P2B0F - kaFULO\_n RP

**Description:** Max Engine Speed to allow Multipulse function of injector energy profile

**Value Units:** Max Engine Speed to allow Multipulse

**X Unit:** Injector Energy Profile

**Y Units:** Multipulse Mode (0 = Double Pulse, 1 = Triple Pulse)

y/x	0	1	2	3
0	3,600	3,600	3,600	3,600
1	3,000	3,000	3,000	3,000

**Initial Supporting table - P0324\_PerCyl\_ExcessiveKnock\_Threshold**

**Description:** Fail threshold for the Knock Performance per-cylinder Excessive Knock Diagnostic

**Value Units:** Filtered Knock Intensity. Unit-less term scaled from 0.0 (no knock) to 5.0 (maximum/large knock)

**X Unit:** Engine Speed (RPM)

**Y Units:** N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19



**Initial Supporting table - P0325\_P0330\_OpenCktThrshMax (20 kHz)**

**Description:** Knock Open Circuit Diagnostic Maximum Threshold when using the 20 kHz method (see "OpenMethod" description)

**Value Units:** Unit-less, filtered term from the Knock Detection Fast Fourier Transform (FFT) for the 20 kHz frequency range.

**X Unit:** Engine Speed (RPM).

**Y Units:** N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	5.7148	5.7148	5.6797	5.6719	5.5723	5.5879	5.5508	5.5508	5.5410	5.1797	4.6504	4.1230	4.1230	4.1230	4.1230	4.1230	4.1230

**Initial Supporting table - P0325\_P0330\_OpenCktThrshMax (Normal Noise)**

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

**Value Units:** Filtered background engine noise. Unit-less term from the Knock Detection Fast Fourier Transform (FFT) for a selected frequency range.

**X Unit:** Engine Speed (RPM)

**Y Units:** N/A

y/x	2,700	2,900	3,000	3,250	3,500	3,750	4,000	4,250	4,500	4,750	5,000	5,500	6,000	6,500	7,000	7,500	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

**Initial Supporting table - P0325\_P0330\_OpenCktThrshMin (20 kHz)**

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the 20 kHz method (see "OpenMethod" description)

**Value Units:** Unit-less, filtered term from the Knock Detection Fast Fourier Transform (FFT) for the 20 kHz frequency range.

**X Unit:** Engine (RPM)

**Y Units:** N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	2.6348	2.6211	2.6074	2.5996	2.5703	2.5605	2.5273	2.4941	2.4902	2.4219	2.2539	2.2539	2.2539	2.2539	2.2539	2.2539	2.2539

**Initial Supporting table - P0325\_P0330\_OpenCktThrshMin (Normal Noise)**

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

**Value Units:** Filtered background engine noise. Unit-less term from the Knock Detection Fast Fourier Transform (FFT) for a selected frequency range.

**X Unit:** Engine Speed (RPM)

**Y Units:** N/A

y/x	2,700	2,900	3,000	3,250	3,500	3,750	4,000	4,250	4,500	4,750	5,000	5,500	6,000	6,500	7,000	7,500	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

### Initial Supporting table - P0325\_P0330\_OpenMethod\_2

**Description:** Defines which Knock Open Circuit Diagnostic method to use.

**Value Units:** Identifies one of two diagnostic methods (either 20 kHz or Normal Noise) used (as a function of engine speed) for Open Circuit detection

**X Unit:** Engine Speed Index, 500 to 8500 (RPM) by 500 rpm increments (Index 0, 1, 2.... 16 = 500, 1000, 1500.... 8500 RPM)

**Y Units:** N/A

#### P0325\_P0330\_OpenMethod\_2 - Part 1

y/x	0	1	2	3	4
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz

#### P0325\_P0330\_OpenMethod\_2 - Part 2

y/x	5	6	7	8	9
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz

#### P0325\_P0330\_OpenMethod\_2 - Part 3

y/x	10	11	12	13	14
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz

#### P0325\_P0330\_OpenMethod\_2 - Part 4

y/x	15	16			
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz			

### Initial Supporting table - P0326\_P0331\_AbnormalNoise\_CylsEnabled

**Description:** Specifies which cylinders will be used for the Abnormal Noise portion of the performance diagnostics (1 = cylinder used, 0 = cylinder not used)

**Value Units:** Boolean that indicates which engine cylinders are being used for the per-sensor Knock Performance diagnostic (0 = not used, 1 = used)

**X Unit:** Cylinder number in firing order (i.e. Cyl 0 = first cylinder in firing order, Cyl 1 = second cylinder in firing order....)

**Y Units:** N/A

y/x	0	1	2	3	4	5	6	7
1	1	1	1	1	1	1	1	1

**Initial Supporting table - P0326\_P0331\_AbnormalNoise\_Threshold**

**Description:** Fail threshold for the Knock Performance Abnormal Noise Diagnostic when engine is NOT in AFM mode

**Value Units:** Filtered background engine noise. Unit-less term from the Knock Detection Fast Fourier Transform (FFT) for a selected frequency range.

**X Unit:** Engine Speed (RPM)

**Y Units:** N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.064	0.064	0.064	0.064	0.068	0.100	0.152	0.243	0.718	0.851	1.855	1.855	1.855	1.855	1.855	1.855	1.855

### Initial Supporting table - P06B6\_P06B7\_OpenTestCktThrshMax

**Description:** Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

**Value Units:** Unit-less, filtered term from the Knock Detection Fast Fourier Transform (FFT) for the 20 kHz frequency range.

**X Unit:** Engine Speed (RPM)

**Y Units:** N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.254	0.254	0.240	0.242	0.268	0.338	0.383	0.506	0.643	0.844	0.998	1.150	1.150	1.150	1.150	1.150	1.150



### Initial Supporting table - P06B6\_P06B7\_OpenTestCktThrshMin

**Description:** Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

**Value Units:** Unit-less, filtered term from the Knock Detection Fast Fourier Transform (FFT) for the 20 kHz frequency range.

**X Unit:** Engine Speed (RPM).

**Y Units:** N/A

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.127	0.127	0.129	0.129	0.131	0.146	0.189	0.221	0.326	0.426	0.541	0.541	0.541	0.541	0.541	0.541	0.541

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	IMIL Illum
<b>Transmission Fluid Temperature</b>								
Transmission Fluid Temperature Sensor Circuit Performance	P0711	TFT Performance Test The first case Startup delta test monitors the sump temperature sensor to determine if it is changing too little for the operating environment of the transmission. The diagnostic makes sure that temperature is changing and not stuck at a value. The first case runs to completion once each drive cycle. The Noise Test compares the sample to a noise calibration and then fails if there is enough fail counts in a given sampling period.	Case 1: Stuck Sensor The test takes a sample of temperature at startup and uses that as an index into tables to set limits on how much of a change in temperature is required over a period of time	0 - 17g69deg C 100 - 1200 seconds	Not Test Failed This Key On	P0711 P0712 P0713 P0715 P0716 P0717 P0720 P0721 P0722	2.5 seconds frequency 250 ms	Two Trips
			Case 2: Noise Test Change from previous	>= 20 deg. C for 14 events	Battery Voltage between 9 V and 18 V TCM and Engine has been running for at least 2 seconds Engine speed >= 450 RPM Output speed >=100 RPM			
		TFT Performance Delta Test This diagnostic test monitors the sump temperature sensor to determine if it is changing too little for the operating environment of the transmission. The diagnostic makes sure that temperature is changing and not stuck at a value. The diagnostic test runs to completion once each drive cycle.	Case 3: Short Term Delta Temp This test samples the initial sump temperature every 6 seconds THEN compares the absolute value of the difference between the initial sump temperature and the value at the end of 6 seconds to compare the absolute value difference between the two values absolute value difference >= 40		Not Test Failed This Key On Battery Voltage between 9 V and 18 V Engine speed >= 450 RPM Output speed >=100 RPM	P0711 P0712 P0713 frequency 250 ms	6 seconds	

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Transmission Fluid Temperature Sensor Circuit Low	P0712	Out of range low.	Transmission Fluid Temperature for a time	$\geq 150$ deg. C > 2.5 seconds.	Not Test Failed This Key On  Battery Voltage between	P0711 P0712 P0713  9 V and 18 V	2.5 seconds  frequency 250 ms	Two Trips
Transmission Fluid Temperature Sensor Circuit High	P0713	Out of range high.	Transmission Fluid Temperature for a time	$\leq -45$ deg. C > 2.5 seconds	Not Test Failed This Key On  Battery Voltage between  IF Engine run time  OR Engine Coolant Temperature for a time	P0711 P0712 P0713  9 V and 18 V  $\geq 600$ seconds  OR $\geq 20$ deg. C $\geq 20$ seconds	2.5 seconds  frequency 250 ms	Two Trips
<b>Speed Sensors</b>								
Turbine Speed Sensor Circuit	P0715	This test detects a Turbine Speed Sensor circuit short to battery, ground, or open.	Turbine speed sensor circuit hardware monitor state for	= Fault for 100 samples	Not Test Failed This Key On	P0715	2 seconds  frequency 20 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Turbine Shaft Speed Sensor Circuit Performance	P0716	Turbine Speed Sensor Performance Test  This test detects large changes in Turbine Speed and noisy Turbine Speed by comparing to calibration values.			Not Test Failed This Key On          No Fault Pending DTCs for this drive cycle.	P0715 P0716 P0717 P0720 P0721 P0722  P0720 P0721 P0722	frequency 20 ms	One Trip
			Case 1: (Unrealistically large changes in turbine speed) If Turbine Speed Change $\geq 800$ RPM for $\geq 0.15$ seconds		0.15 seconds			
			Case 2: (Noisy Turbine Speed) For sample size 80 IF the change in Turbine Speed $\leq -800$ RPM THEN the Low Counter is incremented  IF the change in Turbine Speed $\geq 800$ RPM THEN the High Counter is incremented  This test fails if both the Low Counter and the High Counter $\geq 5$ OR Low Counter $\geq 5$ OR High Counter $\geq 5$		1.6 seconds			
			Case 3: (Wires to speed sensors electromagnetically coupled) Fault Pending will be set when turbine speed change $\geq 8192$ AND Last Valid Speed $\geq 200$  This test fails when Fault pending is set AND turbine speed $< 61$ When range is attained if: Speed sensor wires electromagnetically coupled counter $\geq 4$	Turbine speed $> 200$ RPM for a time $\geq 0.5$ seconds   AND Shift is completed	0.14 seconds			

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
			AND Turbine speed change OR for a time AND Speed sensor wires electromagnetically coupled fail counter	> High Limit <= Low limit < 2 counts >= 3				



24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Output Shaft Speed Sensor Circuit	P0720	This test detects a Hall Effect output speed sensor short to battery, short to ground, or open circuit failure. This test verifies that the Hall Effect output speed sensor circuit current is between a low and high threshold. Tests for rapid direction change and error.	All Cases		Not Test Failed This Key On	P0720	frequency 20 ms	One Trip
			Case 1 (Circuit Test) Output speed sensor current > 17 A OR Output speed sensor current <= 5 A for 0.4 sec		Range Attained	= Forward, Reverse, or Neutral	0.4 seconds	
			Case 2 (Direction Change) Direction Change Mismatch Time > 0.1 sec		Transmission in range or Neutral Output Speed	>= 50	0.1 second	
			Case 3 (Direction Error) HE Output Speed Sensor direction is Error for 0.25 sec		Transmission in range or Neutral Output Speed	>= 50	0.25 seconds	

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Output Shaft Speed Sensor Circuit Performance	P0721	This test detects a noisy output speed sensor or circuit by detecting large changes in output speed.	All Cases		Not Test Failed This Key On	P0715 P0716 P0717 P0720 P0721 P0722	frequency 20 ms	One Trip
					No Fault Pending DTCs for this drive cycle	P0715 P0716 P0717		
					Shift complete AND range attained NOT neutral			
			Case 1: (Unrealistically large change in output speed) Change in output speed $\geq 500$ RPM for a time $\geq 0.15$ seconds				0.15 seconds	
		Case 2: (Noisy output speed) For sample size 80 IF the change in output speed $\leq -500$ RPM THEN the Low Counter is incremented. IF the change in output speed $\geq 500$ RPM THEN the High Counter is incremented.  Test fails if both the Low Counter and the High Counter $\geq 5$ OR the Low Counter $\geq 5$ OR the High Counter $\geq 5$				1.6 seconds		
		Case 3: (Wires to speed sensors electromagnetically coupled) Fault Pending will be set when output speed change $\geq 8192$ AND Last Valid Speed $\geq 200$  This test fails when Fault pending is set AND output speed $< 61$ When range is attained if: Speed sensor swapped counter $\geq 4$ AND			Output Speed $> 200$ RPM for a time $\geq 0.5$ seconds	0.14 seconds		



24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
			Output speed change OR for a time AND Speed sensor swapped fail counter	> High Limit <= Low limit < 2 counts >= 3				

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Output Shaft Speed Sensor Circuit No Signal	P0722	This test detects unrealistically low value of output speed or unrealistically large change in output speed.	All Cases		Not Test Failed This Key On	P0720 P0721 P0722		One Trip
			Case 1: (Rapid Deceleration)  Failure pending if change in output speed Failure sets if fail pending and range attained is Neutral	$\geq 500$ RPM	Transmission output speed for a time  Test disabled when output speed for a time	$\geq 500$ RPM $\geq 2$ seconds  $\leq 500$ RPM $> 1$ seconds	2 seconds	
			Case 2: (No Activity or Gear Disengagement)  Failure pending if output speed Failure sets if fail pending AND (net engine torque OR net engine torque) for a time	$< 61$ RPM  $> 80$ Nm  $< -50$ Nm $> 1$ second	Not Test Failed This Key On  Not Test Failed This Key On  No Fault Pending DTCs for this drive cycle  Engine is running Shift not in process Range attained is not Neutral Reverse to Neutral shift not in process  Transmission input speed  PRNDL State is in a valid forward range AND Manual Selector Valve is verified in drive	P0731 P0732 P0733 P0734 P0735 P0729 P0736  P0715 P0716 P0717  P0715 P0716 P0717     $\geq 1050$ RPM	1 seconds	

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Engine Speed Input Circuit	P0725	This test detects an engine speed sensor circuit failure.	Engine speed sensor circuit hardware monitor state	= Fault for 2 seconds	Not Test Failed This Key On	P0725	2 seconds frequency 20 ms	Two Trips

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum	
Engine Speed Sensor Circuit Performance	P0726	This test detects large changes in Engine Speed and noisy Engine Speed by comparing to calibration values.	All Cases		Not Test Failed This Key On	P0715 P0716 P0717 P0726 P0727	frequency 20 ms	Two Trips	
					No Fault Pending this drive cycle	P0715 P0716 P0717			
			Case 1: (Large change in Engine Speed)					0.15 seconds	
			Change in engine speed $\geq$ 600 RPM for a time $\geq$ 0.15 seconds						
		Case 2: (Noisy Engine Speed)					1.6 seconds		
		For sample size 80 If the change in engine speed $\leq$ -650 RPM then the Low Counter is incremented. If the change in engine speed $\geq$ 650 RPM, then the High Counter is incremented.  This test fails if both the Low Counter and the High Counter $\geq$ 5 OR Low Counter $\geq$ 5 OR High Counter $\geq$ 5							
		Case 3: (Wires to speed sensors electromagnetically coupled)							
		Fault Pending will be set when engine speed change $\geq$ 8192 AND Last Valid Speed $\geq$ 600  This test fails when Fault pending is set AND engine speed $<$ 61 When range is attained if: Speed sensor swapped counter $\geq$ 4 AND Engine speed change $>$ High Limit OR $\leq$ Low limit for a time $<$ 2 counts			Engine speed $>$ 600 RPM for a time $\geq$ 1 second				

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
			AND Speed sensor swapped fail counter	>= 3				

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Engine Speed Sensor Circuit No Signal	P0727	This test detects unrealistically low value of engine speed or unrealistically large change in engine speed.	All Cases:		Not Test Failed This Key On	P0726 P0727	frequency 20 ms	Two Trips
			Case 1: (Unrealistically large change in engine speed) Failure pending if change in engine speed	$\geq 1140$ RPM				
			Case 2: (Unrealistically low value for engine speed) engine speed for a time	$< 60$ RPM $\geq 4$ seconds	Not Test Failed This Key On OR Fault Pending  Turbine speed AND Ignition Key in RUN position AND Ignition Key is not being cycled AND Vehicle is not coasting with engine off.	P0715 P0716 P0717  $\geq 400$ RPM	4 seconds	
Output Shaft Direction Plausibility	P27B4	This test detects implausible behavior from the output speed sensor by comparing the measured output direction signal to the equivalent output shaft direction derived from solenoid and pressure switch states.	Sensed direction  for 1 second	$\neq$ equivalent direction	Not Failed This Key On and No Fault Pending  Not Fault Active  Not Failed This Key On and No	Solenoid Faults (table 1)  P0721 P0720 P0722  P0842 P0843 P0847 P0848 P0872 P0873 P0877 P0878 P0751 P0752 P0756 P0757 P0761 P0762  HSD Faults	1 second  frequency 20 ms	One Trip
					Not Failed This Key On and No	P0729		

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
					Battery Voltage NOT between 9 V and 18 V Output speed >50	P0731 P0732 P0733 P0734 P0735 P0736		
Output Shaft Speed Sensor Plausibility	P27B6	This test detects implausible behavior from the output speed sensor by comparing the measured output speed signal to the equivalent output speed derived from the turbine speed sensor and the current gear ratio.	$ \text{Raw Output Speed} - \text{Equivalent Output Speed}  \geq 10$ for a time $\geq 10$ seconds		Not Failed This Key On and No Fault Pending  Not Failed This Key On  Not Failed This Key On and No Fault Pending  Battery Voltage NOT between 9 V and 18 V Output speed $\geq 50$ Transmission Range NOT Neutral Transmission NOT shifting	P0720 P0721 P0722  P0731 P0732 P0733 P0734 P0735 P0729 P0736  P0715 P0716 P0717	10 seconds  frequency 20 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
<b>Range Verification</b>								
Gear 1 Incorrect Ratio	P0731	This test verifies the transmission is maintaining proper ratio while in First range by comparing computed gear ratio to the commanded gear ratio.	<p>Test Error is indicated when the transmission is in first range AND output speed <math>\geq</math> 100 RPM AND gear slip <math>&gt;</math> 100 RPM</p> <p>When test error is indicated the pass timer is cleared and the fail timer starts accumulating.</p> <p>Fault pending is set when fail timer <math>&gt;</math> 0</p> <p>Diagnostic code set when fail timer <math>\geq</math> 2 seconds</p>		<p>Not Failed This Key On</p> <p>Not responding to Test Failed This Key On</p> <p>No Fault Pending DTC for this drive cycle.</p> <p>No hydraulic default Gears are commanded</p> <p>No range switch failure response active</p> <p>TCM not initializing or shutting down</p> <p>Output speed <math>\geq</math> 200 RPM</p>	<p>P0731 P0877 P0878</p> <p>P0715 P0716 P0717 P0720 P0721 P0722</p> <p>P0715 P0717 P0720 P0722</p>	<p>2 seconds</p> <p>frequency 20 ms</p>	One Trip



24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Gear 2 Incorrect Ratio	P0732	This test verifies the transmission is maintaining proper ratio while in Second range by comparing computed gear ratio to the commanded gear ratio.	<p>Test Error is indicated when the transmission is in second range  AND  output speed <math>\geq</math> 100 RPM  AND  gear slip <math>&gt;</math> 100 RPM</p> <p>When test error is indicated the pass timer is cleared and the fail timer starts accumulating.</p> <p>Fault pending is set when fail timer <math>&gt; 0</math></p> <p>Diagnostic code set when fail timer <math>\geq</math> 2 seconds</p>		<p>Not Failed This Key On</p> <p>Not responding to Test Failed This Key On</p> <p>No Fault Pending DTC for this</p> <p>No hydraulic default Gears are commanded  No Range Shift is in process</p> <p>No range switch failure response active</p> <p>TCM not initializing or shutting down</p> <p>Output speed <math>\geq</math> 200 RPM</p>	<p>P0732  P0877  P0878</p> <p>P0715  P0716  P0717  P0720  P0721  P0722</p> <p>P0715  P0717  P0720  P0722</p>	<p>2 seconds</p> <p>frequency  20 ms</p>	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Gear 3 Incorrect Ratio	P0733	This test verifies the transmission is maintaining proper ratio while in Third range by comparing computed gear ratio to the commanded gear ratio.	<p>Test Error is indicated when the transmission is in third range</p> <p>AND</p> <p>output speed <math>\geq</math> 100 RPM</p> <p>AND</p> <p>gear slip <math>&gt;</math> 100 RPM</p> <p>When test error is indicated the pass timer is cleared and the fail timer starts accumulating.</p> <p>Fault pending is set when fail timer <math>&gt;</math> 0</p> <p>Diagnostic code set when fail timer <math>\geq</math> 2 seconds</p>		<p>Not Failed This Key On</p> <p>Not responding to Test Failed This Key On</p> <p>No Fault Pending DTC for this</p> <p>No hydraulic default Gears are commanded</p> <p>No Range Shift is in process</p> <p>No range switch failure response active</p> <p>TCM not initializing or shutting down</p> <p>Output speed <math>\geq</math> 200 RPM</p>	<p>P0733</p> <p>P0877</p> <p>P0878</p> <p>P0715</p> <p>P0716</p> <p>P0717</p> <p>P0720</p> <p>P0721</p> <p>P0722</p> <p>P0715</p> <p>P0717</p> <p>P0720</p> <p>P0722</p>	<p>2 seconds</p> <p>frequency</p> <p>20 ms</p>	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Gear 4 Incorrect Ratio	P0734	This test verifies the transmission is maintaining proper ratio while in Fourth range by comparing computed gear ratio to the commanded gear ratio.	<p>Test Error is indicated when the transmission is in fourth range</p> <p>AND</p> <p>output speed <math>\geq</math> 100 RPM</p> <p>AND</p> <p>gear slip <math>&gt;</math> 100 RPM</p> <p>When test error is indicated the pass timer is cleared and the fail timer starts accumulating.</p> <p>Fault pending is set when fail timer <math>&gt;</math> 0</p> <p>Diagnostic code set when fail timer <math>\geq</math> 2 seconds</p>		<p>Not Failed This Key On</p> <p>Not responding to Test Failed This Key On</p> <p>No Fault Pending DTC for this</p> <p>No hydraulic default Gears are commanded</p> <p>No Range Shift is in process</p> <p>No range switch failure response active</p> <p>TCM not initializing or shutting down</p> <p>Output speed <math>\geq</math> 200 RPM</p>	<p>P0734</p> <p>P0877</p> <p>P0878</p> <p>P0715</p> <p>P0716</p> <p>P0717</p> <p>P0720</p> <p>P0721</p> <p>P0722</p> <p>P0715</p> <p>P0717</p> <p>P0720</p> <p>P0722</p>	<p>2 seconds</p> <p>frequency</p> <p>20 ms</p>	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Gear 5 Incorrect Ratio	P0735	This test verifies the transmission is maintaining proper ratio while in Fifth range by comparing computed gear ratio to the commanded gear ratio.	<p>Test Error is indicated when the transmission is in fifth range</p> <p>AND</p> <p>output speed <math>\geq</math> 100 RPM</p> <p>AND</p> <p>gear slip <math>&gt;</math> 100 RPM</p> <p>When test error is indicated the pass timer is cleared and the fail timer starts accumulating.</p> <p>Fault pending is set when fail timer <math>&gt;</math> 0</p> <p>Diagnostic code set when fail timer <math>\geq</math> 2 seconds</p>		<p>Not Failed This Key On</p> <p>Not responding to Test Failed This Key On</p> <p>No Fault Pending DTC for this</p> <p>No hydraulic default Gears are commanded</p> <p>No Range Shift is in process</p> <p>No range switch failure response active</p> <p>TCM not initializing or shutting down</p> <p>Output speed <math>\geq</math> 200 RPM</p>	<p>P0735</p> <p>P0877</p> <p>P0878</p> <p>P0715</p> <p>P0716</p> <p>P0717</p> <p>P0720</p> <p>P0721</p> <p>P0722</p> <p>P0715</p> <p>P0717</p> <p>P0720</p> <p>P0722</p>	<p>2 seconds</p> <p>frequency</p> <p>20 ms</p>	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Gear 6 Incorrect Ratio	P0729	This test verifies the transmission is maintaining proper ratio while in Sixth range by comparing computed gear ratio to the commanded gear ratio.	<p>Test Error is indicated when the transmission is in sixth range</p> <p>AND</p> <p>output speed <math>\geq</math> 100 RPM</p> <p>AND</p> <p>gear slip <math>&gt;</math> 100 RPM</p> <p>When test error is indicated the pass timer is cleared and the fail timer starts accumulating.</p> <p>Fault pending is set when fail timer <math>&gt;</math> 0</p> <p>Diagnostic code set when fail timer <math>\geq</math> 2 seconds</p>		<p>Not Failed This Key On</p> <p>Not responding to Test Failed This Key On</p> <p>No Fault Pending DTC for this</p> <p>No hydraulic default Gears are commanded</p> <p>No Range Shift is in process</p> <p>No range switch failure response active</p> <p>TCM not initializing or shutting down</p> <p>Output speed <math>\geq</math> 200 RPM</p>	<p>P0729</p> <p>P0877</p> <p>P0878</p> <p>P0715</p> <p>P0716</p> <p>P0717</p> <p>P0720</p> <p>P0721</p> <p>P0722</p> <p>P0715</p> <p>P0717</p> <p>P0720</p> <p>P0722</p>	<p>2 seconds</p> <p>frequency</p> <p>20 ms</p>	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Reverse Incorrect Ratio	P0736	This test verifies the transmission is maintaining proper ratio while in Reverse range by comparing computed gear ratio to the commanded gear ratio.	<p>Test Error is indicated when the transmission is in reverse range</p> <p>AND</p> <p>output speed <math>\geq</math> 100 RPM</p> <p>AND</p> <p>gear slip <math>&gt;</math> 100 RPM</p> <p>When test error is indicated the pass timer is cleared and the fail timer starts accumulating.</p> <p>Fault pending is set when fail timer <math>&gt;</math> 0</p> <p>Diagnostic code set when fail timer <math>\geq</math> 2 seconds</p>		<p>Not Failed This Key On</p> <p>Not responding to Test Failed This Key On</p> <p>No Fault Pending DTC for this</p> <p>No hydraulic default Gears are commanded</p> <p>No Range Shift is in process</p> <p>No range switch failure response active</p> <p>TCM not initializing or shutting down</p> <p>Output speed <math>\geq</math> 200 RPM</p>	<p>P0736</p> <p>P0877</p> <p>P0878</p> <p>P0715</p> <p>P0716</p> <p>P0717</p> <p>P0720</p> <p>P0721</p> <p>P0722</p> <p>P0715</p> <p>P0717</p> <p>P0720</p> <p>P0722</p>	<p>2 seconds</p> <p>frequency</p> <p>20 ms</p>	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	(Enable Conditions	Time Required	(MIL Illum
<b>Torque Converter</b>								
Torque Converter Clutch (TCC) System Stuck Off	P0741	This test detects the torque converter being stuck off (unlocked) by comparing TCC slip speed to a calibration value.	TCC Slip for a time	>= 80 RPM >= 15 seconds.	Not Test Failed This Key On  No Fault Pending DTCs for this drive cycle.  Battery Voltage between  Engine Speed between for Must be in forward range  Accelerator position  Transmission fluid temperature  Time Since Range Change AND Lockup apply is in process or complete AND Commanded TCC pressure	P2761 P2763 P2764 P0720 P0721 P0722 P0715 P0716 P0717 P0741  P2761 P2763 P2764 P0720 P0721 P0722 P0715 P0716 P0717  9 V and 18 V  200 RPM and 8500 RPM 5 seconds  >= 10 % and <= 3.40282x10 <sup>-38</sup> %  >= 5 deg. C and <= 130 deg. C  >= 6 seconds	15 seconds  frequency 100 ms	Two Trips

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Torque Converter Clutch (TCC) System Stuck On	P0742	This test detects the torque converter being stuck on (locked) by comparing TCC slip speed to a calibration value.	Case 1: (High Torque and high throttle fast fail)	Accelerator Position $\geq 70\%$ AND net engine torque $\geq 2200$ Nm for a time $\geq 2$ seconds	Not Test Failed This Key On	P2761 P2763 P2764 P0715 P0716 P0717 P0720 P0721 P0722 U0100	frequency 100 ms  Case 1: 2 Seconds	Two Trips
			Case 2: (High Output Shaft Acceleration fast fail)	output shaft acceleration $\geq 100$ RPM/second for a time $\geq 5$ seconds				
			Case 3: (Accel/Decel/Accel condition)	Report malfunction when output acceleration event is followed by output deceleration event and followed by another output acceleration event. An output acceleration event occurs when output shaft acceleration $\geq 40$ RPM/second for a time $\geq 4$ seconds  An output deceleration event occurs when output shaft acceleration is $\leq -40$ RPM/second for a time $\geq 2.5$ seconds.	Battery Voltage between 9 V and 18 V  Engine Speed between 200 RPM and 8500 RPM for 5 seconds  Must be in forward range  TCC is commanded off  Engine Speed is not defaulted  TCC Slip $\geq -20$ RPM and $\leq 20$ RPM  Accelerator position $\geq 25\%$ Net Engine Torque $\geq 175$ Nm Turbine speed $\leq 3500$ RPM Engine speed $\leq 3500$ RPM Output speed $\geq 100$ RPM	Case 3: 4 Seconds		



24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	(Enable Conditions	Time Required	(MIL Illum
<b>Pressure Switches</b>								
Transmission Fluid Pressure Switch 1 Circuit Low	P0842	This test compares the commanded valve position to the pressure switch PS1 feedback, (part of S1 valve integrity test)	<p>Pending failure occurs when PS1 pressure switch indicates stroked for a time</p> <p>In response to the pending failure, S1 valve is retried by triggering S1 valve command to stroked and back to destroyed. If PS1 pressure switch continues to indicate stroked, then one of three malfunction cases exists:</p> <p>For Case 1 (electrical malfunction), SS1 Circuit Low reports failure, also.</p> <p>For Case 2 (mechanical malfunction), Shift Solenoid 1 (SS1) Valve Performance - Stuck On reports failure, also.</p> <p>For Case 3 (intermittent malfunction), SS1 valve retry attempted AND PS1 pressure switch continues to indicate stroked.</p>	<p><math>\geq 0.125</math> seconds</p> <p>P0973</p> <p>P0752</p> <p>15 times</p>	<p>Not Test Failed This Key On</p> <p>S1 valve is destroyed</p> <p>NOT system initialization in Cold Mode where Transmission Fluid Temperature</p> <p>Shutdown is NOT in process</p>	P0842	0.125 seconds	One Trip
Shift Solenoid 1 Valve Performance - Stuck Off	P0751	This test compares the change of state of the valve command to the change of state of the PS1 pressure switch feedback, (part of the S1 valve timeout test)	<p>S1 valve is commanded from destroyed to stroked and the PS1 pressure switch indication remains destroyed for a time</p> <p>WITH transmission fluid temperature</p> <p>(Time increases as temperature decreases with maximum time at transmission fluid temperature)</p>	<p><math>\geq 5</math> seconds</p> <p><math>\geq 0</math> deg. C</p> <p>11.95 seconds</p> <p><math>\leq -40</math> deg. C</p>	<p>Not Test Failed This Key On</p> <p>S1 valve commanded from destroyed to stroked and SS1 solenoid pressurized</p>	P0751	5 seconds	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Shift Solenoid 1 (SS1) Valve Performance - Stuck On	P0752	This test compares the change of state of the valve command to the change of state of the PS1 pressure switch feedback, (part of the S1 valve timeout test).	S1 valve commanded from stroked to destroked and the PS1 pressure switch indication remains stroked for a time WITH transmission fluid temperature  (Time increases as temperature decreases with maximum time at transmission fluid temperature)	> 6.8496 seconds  >= 0 deg. C.  11 seconds  <= -40 deg. C	Not Test Failed This Key On  S1 valve changes from stroked to destroked and the solenoid must be commanded to exhaust	P0752	6.8496 seconds  frequency 20 ms	One Trip
Transmission Fluid Pressure Switch 1 Circuit High	P0843	This test compares the commanded valve position to the pressure switch PS1 feedback, (part of S1 valve integrity test)	Pending failure occurs when PS1 pressure switch indicates destroked for a time  In response to the pending failure, S1 valve is retried by triggering S1 valve command to destroked and back to stroked. If the PS1 pressure switch continues to indicate destroked, then one of three malfunction cases exists.  For Case 1 (electrical malfunction),  SS1 Control Circuit Low reports failure, also.  For Case 2 (mechanical malfunction), Shift Solenoid 1 (SS1) Valve Performance - Stuck Off reports failure, also.  For Case 3 (intermittent malfunction), S1 valve retry attempted AND PS1 pressure switch continues to indicate destroked.	>= .070313 seconds      P0973   P0751   15 times	Not Test Failed This Key On  S1 valve is stroked  NOT system initialization in Cold Mode where Transmission Fluid Temperature  Shutdown NOT in process	P0843	0.070313 seconds  frequency 20 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Pressure Switch Solenoid 2 Circuit Low	P0847	This test compares the commanded valve position to the PS2 pressure switch feedback (part of the S2 valve integrity test).	<p>Pending failure occurs when PS2 pressure switch indicates stroked for a time</p> <p>In response to the pending failure, S2 valve is retried by triggering S2 valve command to stroked and back to destroked. If PS2 pressure switch continues to indicate stroked, then one of three malfunction cases exists.</p> <p>For Case 1 (electrical malfunction),</p> <p>SS2 Control Circuit Low reports failure, also.</p> <p>For Case 2 (mechanical malfunction),</p> <p>Shift Solenoid 2 Valve Performance - Stuck On reports failure, also.</p> <p>For Case 3 (intermittent malfunction),</p> <p>S2 valve retry attempted</p> <p>AND</p> <p>PS2 pressure switch continues to indicate stroked.</p>	<p><math>\geq .039063</math> seconds</p> <p>P0976</p> <p>P0757</p> <p>2 times</p> <p>AND</p> <p>11.95 seconds</p>	<p>Not Test Failed This Key On</p> <p>S2 valve is destroked</p> <p>NOT system initialization in Cold Mode where Transmission Fluid Temperature</p> <p>Shutdown NOT in process</p>	<p>P0847</p> <p><math>&lt; -25</math> deg. C</p>	<p>0.039063 seconds</p> <p>frequency 20 ms</p>	One Trip
Shift Solenoid 2 Valve Performance - Stuck Off	P0756	This test compares the change of state of the valve command to the change of state of the PS2 pressure switch feedback (part of the S2 valve timeout test).	<p>If the S2 valve is commanded from destroked to stroked and the PS2 pressure switch indication remains destroked for a time</p> <p>WITH</p> <p>transmission fluid temperature</p> <p>(Time increases as temperature decreases with maximum time at transmission fluid temperature)</p>	<p><math>\geq 5</math> seconds</p> <p><math>\geq 0</math> deg. C.</p> <p>11.95 seconds</p> <p><math>\leq -40</math> deg. C.</p>	<p>Not Test Failed This Key On</p> <p>S2 valve commanded from destroked to stroked and SS2 solenoid pressurized</p>	<p>P0756</p>	<p>5 seconds</p> <p>frequency 20 ms</p>	One Trip



24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Pressure Switch Solenoid 3 Circuit Low	P0872	This test compares the commanded valve position to the pressure switch PS3 feedback, (part of S3 valve integrity test)	<p>Pending failure occurs when PS3 pressure switch indicates stroked for a time</p> <p>In response to the pending failure, S3 valve is retried by triggering S3 valve command to stroked and back to destroyed. If PS3 pressure switch continues to indicate stroked, then one of three malfunction cases exists.</p> <p>For Case 1 (electrical malfunction), SS3 Control Circuit Low reports failure, also. P0979</p> <p>For Case 2 (mechanical malfunction), Shift Solenoid 3 Valve Performance - Stuck On reports failure, also. P0762</p> <p>For Case 3 (intermittent malfunction), S3 valve retry attempted 2 times AND PS3 pressure switch continues to indicate stroked.</p>	<p>&gt; 0.0195 seconds</p>	<p>Not Test Failed This Key On</p> <p>S3 valve is destroyed</p> <p>NOT system initialization in Cold Mode where Transmission Fluid Temperature &lt; -25 deg. C</p> <p>Shutdown NOT in process</p>	P0872	0.0195 seconds  frequency 20 ms	One Trip
Shift Solenoid 3 Valve Performance - Stuck Off	P0761	This test compares the change of state of the valve command to the change of state of the PS3 pressure switch feedback, (part of the S3 valve timeout test)	<p>If the S3 valve is commanded from destroyed to stroked and the PS3 pressure switch indication remains destroyed for a time</p> <p>WITH transmission fluid temperature</p> <p>(Time increases as temperature decreases with maximum time at transmission fluid temperature)</p>	<p>&gt;= 5 seconds</p> <p>&gt;= 0 deg. C.</p> <p>11.95 seconds</p> <p>&lt;= -40 deg. C.</p>	<p>Not Test Failed This Key On</p> <p>S3 valve commanded from destroyed to stroked and SS3 solenoid pressurized</p>	P0761	5 seconds  frequency 20 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Shift Solenoid 3 Valve Performance - Stuck On	P0762	This test compares the commanded valve position to the PS3 pressure switch feedback (part of the S3 valve timeout test).	S3 valve commanded from stroked to destroked and the PS3 pressure switch does not indicate destroked for a time WITH transmission fluid temperature (Time increases as temperature decreases with maximum time at transmission fluid temperature)	> 6.5996 seconds >= 0 deg. C. 21.95 seconds >= -40 deg. C.	Not Test Failed This Key On S3 valve changes from stroked to destroked and the solenoid must be commanded to exhaust	P0762	6.5996 seconds frequency 20 ms	One Trip
Pressure Switch Solenoid 3 Circuit High	P0873	This test compares the commanded valve position to the pressure switch PS3 feedback, (part of S3 valve integrity test)	Pending failure occurs when PS3 pressure switch indicates destroked for a time In response to the pending failure, S3 valve is retried by triggering S3 valve command to destroked and back to stroked. If PS3 pressure switch continues to indicate destroked, then one of the three malfunction cases exists. For Case 1 (electrical malfunction), SS3 Control Circuit Low reports failure, also. For Case 2 (mechanical malfunction), Shift Solenoid 3 Valve Performance - Stuck Off reports failure, also. For Case 3 (intermittent malfunction), S3 valve retry attempted AND PS3 pressure switch continues to indicate destroked.	> 0.30078 seconds P0979 P0761 2 times	Not Test Failed This Key On S3 valve is stroked NOT system initialization in Cold Mode where Transmission Fluid Temperature Shutdown NOT in process	P0873	0.30078 seconds frequency 20 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Transmission Fluid Pressure Switch 4 Circuit Low	P0877	This test detects Reverse Pressure Switch closed indication by comparing the Reverse Pressure Switch (ps4) state to the PRNDL switch state.	Case 1: (Forward range)	For a sample size 100 samples (if dropout suspected use sample size) 255 samples	All Cases Not Test Failed This Key On  No Fault Pending DTCs for this drive cycle  Engine Speed between 200 RPM and 8500 RPM for 5 seconds	P0877 P0878 P0708  P0708	1 second frequency 50 ms	One Trip
			PRNDL is P, D1, D2, D3, D4, D5, D6, T8, or T4 AND RPS indicates Reverse for a time $\geq 1$ seconds (if dropout suspected use time) 30 seconds	Case 2: (Forward range indefinite)				

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Transmission Fluid Pressure Switch 4 Circuit High	P0878	This test detects the Reverse Pressure switch (PS4) being stuck in the open position by comparing to the PRNDL switch state and detects the Reverse Pressure switch stuck open at shutdown.	All Cases		Not Test Failed This Key On	P0878	frequency 50 ms	One Trip
			Case 1: (RPS State and PRNDL State do not agree) For sample size 40 samples PRNDL is REVERSE AND RPS indicates NOT REVERSE after a time $\geq 1$ second		PRNDL State is in reverse		1 second	
			For Case 2: (RPS Shutdown Test)  If RPS indicates not Reverse for a time $\geq 5-30$ seconds  This time varies with transmission fluid temperature		Transmission Fluid Temperature $\geq 0$ deg. C  Ignition state is OFF  Engine was cranking or running this ignition cycle		5-30 seconds	
			For Case 3: (High Ratio Test) If current transmission ratio is within the reverse range ratio for a time $\geq 0.5$ seconds AND net engine torque $\geq 100$ Nm for a time 1 second		1st range attained and RPS State in forward  Output speed is $\geq 100$ RPM		1 second	



24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	(Enable Conditions)	Time Required	(MIL Illum)
<b>On-coming/Off-going</b>								
Pressure Control Solenoid (PCS) 1 Stuck Off	P2723	This test determines if the on-coming clutch energized by Pressure Control Solenoid 1 engages during a forward range shift.	<p>Pending failure occurs when accumulated event timer</p> <p>Timer accumulates when transmission is shifting</p> <p>AND</p> <p>output speed</p> <p>AND commanded gear slip speed (For rough road conditions, use)</p> <p>In response of pending failure, a diagnostic response range is commanded. During this command, this test fails if fail timer</p> <p>and output speed</p>	<p>&gt; 0 seconds</p> <p>output speed <math>\geq</math> 60 RPM</p> <p>slip speed <math>\geq</math> 75 RPM</p> <p>150 RPM.</p> <p><math>\geq</math> 2 seconds</p> <p><math>\geq</math> 300 RPM</p>	<p>Not Test Failed This Key On</p> <p>Output Speed</p> <p>Turbine Speed</p> <p>Normal powertrain shutdown not in process</p> <p>Normal or Cold powertrain initialization is complete</p> <p>No range switch failure response active</p> <p>No Cold Mode operation</p> <p>On-coming clutch control enabled</p> <p>Power downshift abort to previous range NOT active</p> <p>Range shift in process</p>	<p>P2723</p> <p>P0720</p> <p>P0721</p> <p>P0722</p> <p>P0715</p> <p>P0716</p> <p>P0717</p> <p>P0708</p> <p>P0877</p> <p>P0878</p> <p><math>\geq</math> 125 RPM</p> <p><math>\geq</math> 60 RPM</p>	<p>2 seconds</p> <p>frequency</p> <p>20 ms</p>	<p>One Trip</p>

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Pressure Control Solenoid (PCS) 2 Stuck Off	P0776	This test determines if the on-coming clutch energized by Pressure Control Solenoid 2 engages during a forward range shift.	<p>Pending failure occurs when accumulated event timer</p> <p>Timer accumulates when transmission is shifting, output speed AND commanded gear slip speed</p> <p>(For rough road conditions, use)</p> <p>In response of pending failure, a diagnostic response range is commanded. During this command, this test fails if fail timer</p> <p>and output speed</p>	<p>&gt;= 0 seconds</p> <p>&gt;= 60 RPM</p> <p>&gt; 75 RPM</p> <p>150 RPM.</p> <p>&gt;= 2 seconds</p> <p>&gt;= 300 RPM</p>	<p>Not Test Failed This Key On</p> <p>Output Speed &gt;= 125 RPM</p> <p>Turbine Speed &gt;= 60 RPM</p> <p>Normal powertrain shutdown not in process</p> <p>Normal or Cold powertrain initialization is complete</p> <p>No range switch failure response active</p> <p>No Cold Mode operation</p> <p>On-coming clutch control enabled</p> <p>Power downshift abort to previous range NOT active</p> <p>Range shift in process</p>	<p>P0776</p> <p>P0720</p> <p>P0721</p> <p>P0722</p> <p>P0715</p> <p>P0716</p> <p>P0717</p> <p>P0708</p> <p>P0877</p> <p>P0878</p>	<p>2 seconds</p> <p>frequency</p> <p>20 ms</p>	<p>One Trip</p>

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Pressure Control Solenoid (PCS) 1 Stuck On	P2724	This test determines if the off-going clutch energized by (PCS1) Pressure Control solenoid 1 remains engaged during a forward range shift.	<p>Accumulated fail timer for 1-to-2 upshifts; OR accumulated fail timer for other forward range upshifts; OR accumulated fail timer for forward range closed throttle downshift; OR accumulated fail timer for forward downshifts above closed throttle.</p> <p>Fail timer accumulates during range to range shifts when attained gear slip speed</p>	<p><math>\geq 0.2998</math> seconds</p> <p><math>\geq 0.5</math> seconds</p> <p><math>\geq 0.5</math> seconds</p> <p><math>\geq 1.0</math> second</p> <p><math>\leq 25</math> RPM</p>	<p>Not Test Failed This Key On</p> <p>Output Speed <math>\geq 200</math> RPM Turbine Speed <math>\geq 200</math> RPM</p> <p>Normal powertrain shutdown not in process</p> <p>Normal or Cold powertrain initialization is complete</p> <p>No range switch failure response active</p> <p>No Cold Mode operation</p> <p>Offgoing clutch shift in progress controlled by PCS1</p> <p>Range Shift in process</p> <p>Transmission fluid temperature <math>&gt; -25</math> deg C</p>	<p>P2724 P0720 P0721 P0722 P0715 P0716 P0717 P0877 P0878 P0777 P0708</p>	<p>1 second</p> <p>frequency 20 ms</p>	<p>One Trip</p>

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Pressure Control Solenoid (PCS) 2 Stuck On	P0777	This test determines if the off-going clutch energized by (PCS2) Pressure Control solenoid 2 remains engaged during a forward range shift.	<p>Accumulated fail timer 1-to-2 upshifts; OR accumulated fail timer for other forward range upshifts; OR accumulated fail timer for forward range closed throttle downshift; OR accumulated fail timer for forward downshifts above closed throttle.</p> <p>Fail timer accumulates during range to range shifts when attained gear slip speed</p>	<p><math>\geq 0.2998</math> seconds</p> <p><math>\geq 0.5</math> seconds</p> <p><math>\geq 0.5</math> seconds</p> <p><math>\geq 1.0</math> second</p> <p><math>\leq 25</math> RPM</p>	<p>Not Test Failed This Key On</p> <p>Output Speed <math>\geq 200</math> RPM Turbine Speed <math>\geq 200</math> RPM</p> <p>Normal powertrain shutdown not in process</p> <p>Normal or Cold powertrain initialization is complete</p> <p>No range switch failure response active</p> <p>No Cold Mode operation</p> <p>No abusive garage shift to 1st range detected</p> <p>Offgoing clutch shift in progress controlled by PCS2</p> <p>Range Shift in process</p> <p>Transmission fluid temperature <math>&gt; -25</math> deg C</p>	<p>P2724 P0720 P0721 P0722 P0715 P0716 P0717 P0877 P0878 P0777 P0708</p>	<p>1 second frequency 20 ms</p>	<p>One Trip</p>

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	IMIL Illum
<b>PRNDL/IMS</b>								
Transmission Range Sensor High	P0708	Illegal Range Test This test monitors the transmission range switch for invalid input conditions and parity errors occurring over consecutive ignition cycles.	(No Information): Illegal PRNDL state for a time	>= 1 second	Not Test Failed This Key On P0708  Battery Voltage between 9 V and 18 V  Engine Speed between 200 RPM and 8500 RPM for 5 seconds		Case 1: 1 second  Case 2: 1.5 seconds  frequency 100 ms	One Trip
		Long Term Range Switch Test The PRNDL encoding into the TCM has multiple valid and invalid states. This diagnostic checks the parity of the diagnostic to detect failures in parity over multiple drive cycles	(Long-term Parity): There are 3 counters for long-term parity. These counters are updated at the end of each drive cycle, immediately prior to TCM shutdown.  For Counter 1, increment counter IF Parity Error Detected; decrement counter IF No Parity Error Detected AND No Motion Detected.  IF Counter 1 >= 15 counts THEN report failure.  For Counter 2, increment counter IF Parity Error Detected AND (No Valid Drive Detected OR No Valid Park/Neutral Detected) AND Output Speed > 200 RPM decrement counter IF No Parity Error Detected AND Valid Park/Neutral Detected AND Valid Drive Detected AND Motion Detected.  IF Counter 2 >= 5 counts THEN report failure.  For Counter 3, increment Counter 3 IF Parity Error Detected while in Reverse AND No Valid Reverse Detected AND Motion Detected.					

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
			<p>Decrement Counter 3 IF No Parity Error Detected AND Valid Reverse Detected AND Output Speed &gt; 200 RPM IF Counter 3 &gt;= 5 counts THEN report failure.</p> <p>Where . . . . Parity Error Detected is defined as a failure of the 4-bit PRNDL input such that the sum of those bits yields an odd result for a time;</p> <p>Motion Detected is defined as output speed &gt;= 200 RPM for a time; &gt;= 10 seconds</p> <p>Valid Drive Detected is defined as the 4-bit DL indicates Valid Drive for a time; &gt;= 3 seconds</p> <p>Valid Park Detected is defined as the 4-bit PRNDL indicates Valid Park for a time &gt;= 0.2 seconds and output speed; &lt;= 20 RPM</p> <p>Valid Reverse Detected is defined as the 4-bit PRNDL indicates Valid Reverse for a time; &gt;= 15 seconds;</p> <p>Valid Neutral Detected is defined as the 4-bit PRNDL indicates Valid Neutral for a time &gt;= 0.2 seconds and output speed &lt;= 20 RPM OR for a time. &gt;= 3 seconds</p>					







24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Main Pressure Modulation Solenoid Control Circuit Low	P0962	This test detects solenoid electrical ground circuit malfunctions.	<p>Fault pending is set at single solenoid driver hardware detection of a low fault</p> <p>IF hardware fault is present for a sample size <math>\geq 3</math> samples</p> <p>THEN initiate intrusive test by opening low side driver.</p> <p>If hardware indicates low fault for a sample size <math>\geq 3</math> samples</p> <p>THEN report malfunction</p> <p>Fault pending is set at single solenoid driver hardware detection of a low fault</p> <p>IF hardware fault is present for a sample size <math>\geq 3</math> samples</p>	$\geq 3$ samples	<p>Not Test Failed This Key On</p> <p>Battery voltage between 9V and 18V</p> <p>If Engine Cranking, then Crank Time <math>&lt; 4</math> seconds AND Battery Voltage <math>&gt; 10</math> V</p> <p>High Side Driver 1 Enabled</p>	<p>P0962</p> <p>P0960</p> <p>P0657</p> <p>P0658</p> <p>P0659</p>	120 ms frequency 20 ms	One Trip
Main Pressure Modulation Solenoid Control Circuit High	P0963	This test detects solenoid electrical short to power circuit malfunctions.	<p>If hardware fault short to power is present for a sample size <math>\geq 3</math> consecutive samples</p> <p>THEN report malfunction</p>	$\geq 3$ consecutive samples	<p>Not Test Failed This Key On</p> <p>If Engine Cranking, then Crank Time <math>&lt; 4</math> seconds AND Battery Voltage <math>&gt; 10</math> V</p> <p>High side driver 1 enabled</p>	<p>P0963</p> <p>P0657</p> <p>P0658</p> <p>P0659</p>	60 ms frequency 20 ms	One Trip
Pressure Control Solenoid (PCS) 2 Control Circuit Open	P0964	This test detects solenoid electrical open circuit malfunctions.	<p>Fault pending is set at single solenoid driver hardware detection of a low fault</p> <p>IF hardware fault is present for a sample size <math>\geq 3</math> samples</p> <p>THEN initiate intrusive test by opening low side driver</p> <p>IF hardware indicates open fault for a sample size <math>\geq 3</math> samples</p> <p>THEN report malfunction</p>	$\geq 3$ samples	<p>Not Test Failed This Key On</p> <p>Battery voltage between 9V and 18V</p> <p>If Engine Cranking, then Crank Time <math>&lt; 4</math> seconds AND Battery Voltage <math>&gt; 10</math> V</p> <p>High Side Driver 2 Enabled</p>	<p>P0964</p> <p>P0966</p> <p>P2669</p> <p>P2670</p> <p>P2671</p>	120 ms frequency 20 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Pressure Control Solenoid (PCS) 2 Control Circuit Performance	P0965	This test detects the performance of the solenoid by comparing desired current to current as measured by the solenoid control integrated circuit. This test monitors if the low side switching frequencies fall within their desired range, and if they are operating properly per their commanded state.	All Cases				frequency 100 ms	One Trip
			Case 1 (Performance) If abs(Measured current - Commanded current) $\geq$ 100 milliamps for a time $\geq$ 1 sec  THEN report malfunction		Not Test Failed This Key On  No Fault Pending  Battery voltage between 9V and 18V  If Engine Cranking, then Crank Time $<$ 4 seconds AND Battery Voltage $>$ 10 V  High Side Driver 2 Enabled  Transmission not shifting  LU clutch is not engaging or dis-engaging  Neutral at Stop is not in process	P2671 P2670 P2669 P0964 P0966 P0967  P0964 P0966 P0967	1 sec	
			Case 2 (Frequency) If the solenoid is energized and frequency is $<$ 3000 Hz OR $>$ 5000 Hz OR the solenoid is not energized and frequency is $>$ 3000 Hz  THEN report malfunction		Not Fault Pending  Not Test Failed This Key On  Not Fault Pending  Not Test Failed This Key On  Battery voltage between 9V and 18V  Lockup Shift Complete $>$ 0.5 sec  Range Shift Complete $>$ 0.5 sec	Solenoid Faults (table 1)  Solenoid Faults (table 1)  HSD Faults (table 2)  HSD Faults (table 2)		

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
					RELS inactive, RELS override inactive, C2 backfill inactive, Neutral antidrags inactive, Device Control inactive, & EOS inactive	> 0.5 sec		
			Case 3 (Plausibility)  Adler IC commanded - TCM measured duty cycle   for  THEN report malfunction	>= 10  >= 1 second	Not Fault Pending  Not Test Failed This Key On  Not Fault Pending  Not Test Failed This Key On  Battery voltage between  High Side Driver 2 Enabled	Solenoid Faults (table 1)  Solenoid Faults (table 1)  HSD Faults (table 2)  HSD Faults (table 2)  9V and 18V	1 second	
Pressure Control Solenoid (PCS) 2 Control Circuit Low	P0966	This test detects solenoid electrical ground circuit malfunctions.	Fault pending is set at single solenoid driver hardware detection of a low fault  IF hardware fault is present for a sample size  THEN initiate intrusive test by opening low side driver  IF hardware indicates short to ground fault for a sample size  THEN report malfunction.	>= 3 samples  >= 3 samples	Not Test Failed This Key On  Battery Voltage between  If Engine Cranking, then Crank Time AND Battery Voltage  High Side Driver 2 Enabled	P0966 P0964 P2669 P2670 P2671  9 V and 18 V  < 4 seconds	120 ms  frequency 20 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Pressure Control Solenoid (PCS) 2 Control Circuit High	P0967	This test detects solenoid electrical short to power circuit malfunctions.	If hardware fault short to power is present for a sample size  THEN report malfunction	$\geq 3$ consecutive samples	Not Test Failed This Key On  If Engine Cranking, then Crank Time AND Battery Voltage  High Side Driver 2 Enabled	P0967 P2669 P2670 P2671	60 ms  frequency 20 ms	One Trip
Pressure Control Solenoid (PCS) 1 Control Circuit Open	P2727	This test detects solenoid electrical open circuit malfunctions.	Fault pending is set at single solenoid driver hardware detection of a low fault  IF hardware fault is present for a sample size  THEN initiate intrusive test by opening low side driver.  IF hardware indicates open fault for a sample size  THEN report malfunction	$\geq 3$ samples  $\geq 3$ samples	Not Test Failed This Key On  Battery Voltage between  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 1 enabled	P2727 P2729 P0657 P0658 P0659	120 ms  frequency 20 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Pressure Control Solenoid (PCS) 1 Control Circuit Performance	P2728	This test detects the performance of the solenoid by comparing desired current to current as measured by the solenoid control integrated circuit. This test monitors if the low side switching frequencies fall within their desired range, and if they are operating properly per their commanded state.	Case 1 (Performance)	If abs(Measured current - Commanded current) $\geq$ 100 milliamps for a time $\geq$ 1 sec  THEN report malfunction	Not Test Failed This Key On  No Fault Pending  Battery voltage between 9V and 18V  If Engine Cranking, then Crank Time $<$ 4 seconds AND Battery Voltage $>$ 10 V  High Side Driver 1 Enabled  Transmission not shifting  LU clutch is not engaging or dis-engaging  Neutral at Stop is not in process	P0659 P0658 P0657 P2727 P2729 P2730  P2727 P2729 P2730	1 sec  frequency 100 ms	One Trip
			Case 2 (Frequency)	If the solenoid is energized and frequency is $<$ 3000 Hz OR $>$ 5000 Hz OR the solenoid is not energized and frequency is $>$ 3000 Hz  THEN report malfunction	Not Fault Pending  Not Test Failed This Key On  Not Fault Pending  Not Test Failed This Key On  Battery voltage between 9V and 18V  Lockup Shift Complete $>$ 0.5 sec  Range Shift Complete $>$ 0.5 sec	Solenoid Faults (table 1)  Solenoid Faults (table 1)  HSD Faults (table 2)  HSD Faults (table 2)	frequency 20 ms	

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
					RELS inactive, RELS override inactive, C2 backfill inactive, Neutral antidrags inactive, Device Control inactive, & EOS inactive	> 0.5 sec		
			Case 3 (Plausibility)  Adler IC commanded - TCM measured duty cycle   for  THEN report malfunction	$\geq 10$  $\geq 1$ second	Not Fault Pending  Not Test Failed This Key On  Not Fault Pending  Not Test Failed This Key On  Battery voltage between  High Side Driver 1 Enabled	Solenoid Faults (table 1)  Solenoid Faults (table 1)  HSD Faults (table 2)  HSD Faults (table 2)  9V and 18V	1 second  frequency 20 ms	
Pressure Control Solenoid (PCS) 1 Control Circuit Low	P2729	This test detects solenoid electrical ground circuit malfunctions.	Fault pending is set at single solenoid driver hardware detection of a low fault  IF hardware fault is present for a sample size  THEN initiate intrusive test by opening low side driver.  IF hardware indicates low fault for a sample size  THEN report malfunction	$\geq 3$ samples  $\geq 3$ samples	Not Test Failed This Key On  Battery Voltage between  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 1 enabled	P2729 P2727 P0657 P0658 P0659  9 V and 18 V  < 4 seconds AND > 10 V	120 ms  frequency 20 m	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Pressure Control Solenoid (PCS) 1 Control Circuit High	P2730	This test detects solenoid electrical short to power circuit malfunctions.	If hardware fault short to power is present for a sample size  THEN report malfunction	$\geq 3$ consecutive samples	Not Test Failed This Key On  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 1 enabled	P2730 P0657 P0658 P0659	60 ms  frequency 20 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Shift Solenoid 1 Control Circuit Open	P097A	This test detects solenoid electrical open circuit malfunctions.	<p>Fault pending is set at single solenoid driver hardware detection of a low fault</p> <p>IF hardware fault is present for a sample size <math>\geq 3</math> samples</p> <p>THEN initiate intrusive test by opening low side driver.</p> <p>If hardware indicates open fault for a sample size <math>\geq 3</math> samples</p> <p>THEN report malfunction</p>	$\geq 3$ samples	<p>Not Test Failed This Key On</p> <p>Battery Voltage between 9 V and 18 V</p> <p>If Engine Cranking, then Crank Time <math>&lt; 4</math> seconds AND Battery Voltage <math>&gt; 10</math> V</p> <p>High side driver 2 enabled</p>	<p>P097A P0973 P2669 P2670 P2671</p>	120 ms frequency 20 ms	One Trip
Shift Solenoid 1 Control Circuit Low	P0973	This test detects solenoid electrical ground circuit malfunctions.	<p>Fault pending is set at single solenoid driver hardware detection of a low fault</p> <p>IF hardware fault is present for a sample size <math>\geq 3</math> samples</p> <p>THEN initiate intrusive test by opening low side driver</p> <p>IF hardware indicates low fault for a sample size <math>\geq 3</math> samples</p> <p>THEN report malfunction.</p>	$\geq 3$ samples	<p>Not Test Failed This Key On</p> <p>Battery Voltage between 9 V and 18 V</p> <p>If Engine Cranking, then Crank Time <math>&lt; 4</math> seconds AND Battery Voltage <math>&gt; 10</math> V</p> <p>High side driver 2 enabled</p>	<p>P0973 P097A P2669 P2670 P2671</p>	120 ms frequency 20 ms	One Trip



24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Shift Solenoid 1 Control Circuit High	P0974	This test detects solenoid electrical short to power circuit malfunctions.	If hardware fault short to power is present for a sample size  THEN report malfunction	$\geq 3$ consecutive samples	Not Test Failed This Key On  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 2 enabled	P0974 P2669 P2670 P2671	60 ms  frequency 20 ms	One Trip
Shift Solenoid 2 Control Circuit Open	P097B	This test detects solenoid electrical open circuit malfunctions.	Fault pending is set at single solenoid driver hardware detection of a low fault  IF hardware fault is present for a sample size  THEN initiate intrusive test by opening low side driver.  IF hardware indicates open fault for a sample size  THEN report malfunction	$\geq 3$ samples  $\geq 3$ samples	Not Test Failed This Key On  Battery Voltage between  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 2 enabled	P097B P0976 P2669 P2670 P2671	120 ms  frequency 20 ms	One Trip
Shift Solenoid 2 Control Circuit Low	P0976	This test detects solenoid electrical ground circuit malfunctions.	Fault pending is set at single solenoid driver hardware detection of a low fault  IF hardware fault is present for a sample size  THEN initiate intrusive test by opening low side driver.  IF hardware indicates low fault for a sample size  THEN report malfunction	$\geq 3$ samples  $\geq 3$ samples	Not Test Failed This Key On  Battery Voltage between  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 2 enabled	P0976 P097B P2669 P2670 P2671	120 ms  frequency 20 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Shift Solenoid 2 Control Circuit High	P0977	This test detects solenoid electrical short to power circuit malfunctions.	If hardware fault short to power is present for a sample size  THEN report malfunction	$\geq 3$ consecutive samples	Not Test Failed This Key On  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 2 enabled	P0977 P2669 P2670 P2671	60 ms  frequency 20 ms	One Trip
Shift Solenoid 3 Control Circuit Open	P097C	This test detects solenoid electrical open circuit malfunctions.	Fault pending is set at single solenoid driver hardware detection of a low fault  IF hardware fault is present for a sample size  THEN initiate intrusive test by opening low side driver.  IF hardware indicates open fault for a sample size  THEN report malfunction	$\geq 3$ samples	Not Test Failed This Key On  Battery Voltage between  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 2 enabled	P097C P0979 P2669 P2670 P2671	120 ms  frequency 20 ms	One Trip
Shift Solenoid 3 Control Circuit Low	P0979	This test detects solenoid electrical ground circuit malfunctions.	Fault pending is set at single solenoid driver hardware detection of a low fault  IF solenoid driver hardware fault is present for a sample size  THEN initiate intrusive test by opening low side driver.  IF hardware indicates low fault for a sample size  THEN report malfunction	$\geq 3$ samples	Not Test Failed This Key On  Battery Voltage between  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 2 enabled	P0979 P097C P2669 P2670 P2671	120 ms  frequency 20 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Shift Solenoid 3 Control Circuit High	P0980	This test detects solenoid electrical short to power circuit malfunctions.	If hardware fault short to power is present for a sample size  THEN report malfunction	$\geq 3$ consecutive samples	Not Test Failed This Key On  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 2 enabled	P0980 P2669 P2670 P2671	60 ms  frequency 20 ms	One Trip
Actuator Supply Circuit Voltage 1 Open (HSD1)	P0657	This test detects if the voltage measured at the HSD1 detection circuit shows that multiple low side detection circuits indicate open, but the high side detection circuit indicates high voltage.	Report malfunction when the number of failure events  A failure event occurs when the number of failed solenoids connected to HSD1 AND HSD1 voltage	$\geq 2$  $\geq 2$  $\geq 6V$	Not Test Failed This Key On  HSD1 is commanded ON  If Engine Cranking, then Crank Time AND Battery Voltage	P0657	40 ms  frequency 20 ms	One Trip
Actuator Supply Circuit Voltage 1 Low(HSD1)	P0658	This test detects low voltage when high voltage is expected indicating a short to ground at the circuit.	Report malfunction when short to ground is detected for a number of events	$\geq 3$ times	Not Test Failed This Key On  HSD1 is commanded ON  If Engine Cranking, then Crank Time AND Battery Voltage	P0658	60 ms  frequency 20 ms	One Trip
Actuator Supply Circuit Voltage 1 High(HSD1)	P0659	This test detects if the voltage measured at the HSD 1 detection circuit indicates high during initialization (when the circuit is off)	During initialization, report malfunction when the number of failure events  A failure event occurs when HSD1 voltage	$\geq 3$ times  $\geq 6V$	During initialization		60 ms  frequency 20 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Actuator Supply Circuit Voltage 2 Open (HSD2)	P2669	This test detects if the voltage measured at the HSD2 detection circuit shows that multiple low side detection circuits indicate open, but the high side detection circuit indicates high voltage.	Report malfunction when the number of failure events  A failure event occurs when the number of failed solenoids connected to HSD2  AND HSD2 voltage	$\geq 2$  $\geq 2$  $\geq 6V$	Not Test Failed This Key On  HSD2 is commanded ON  If Engine Cranking, then Crank Time AND Battery Voltage	P2669  $< 4$ seconds  $> 10 V$	40 ms  frequency 20 ms	One Trip
Actuator Supply Circuit Voltage 2 Low (HSD2)	P2670	This test detects low voltage when high voltage is expected indicating a short to ground at the circuit.	Report malfunction when short to ground is detected for a number of events	$\geq 3$ times	Not Test Failed This Key On  HSD2 is commanded ON  If Engine Cranking, then Crank Time AND Battery Voltage	P2670  $< 4$ seconds  $> 10 V$	60 ms	One Trip
Actuator Supply Circuit Voltage 2 High (HSD2)	P2671	This test detects if the voltage measured at the HSD 2 detection circuit indicates high during initialization (when the circuit is off)	During initialization, report malfunction when the number of failure events  A failure event occurs when HSD2 voltage	$\geq 3$ times  $\geq 6V$	During initialization		60 ms  frequency 20 ms	One Trip
Torque Converter Clutch (TCC) Pressure Control Solenoid (PCS) Control Circuit Open	P2761	This test detects torque converter solenoid electrical open circuit malfunctions.	Fault pending is set at single solenoid driver hardware detection of a low fault  IF hardware fault is present for a  THEN initiate intrusive test by  IF hardware indicates open fault for  THEN report malfunction	$\geq 3$ samples  $\geq 3$ samples	Not Test Failed This Key On  Battery Voltage between  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 1 enabled	P2761 P2764 P0657 P0658 P0659  9 V and 18 V  $< 4$ seconds  $> 10 V$	120 ms  frequency 20 ms	Two Trips

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Torque Converter Clutch (TCC) Pressure Control Solenoid (PCS) Control Circuit Performance	P2762	This test detects the performance of the solenoid by comparing desired current to current as measured by the solenoid control integrated circuit. This test monitors if the low side switching frequencies fall within their desired range, and if they are operating properly per their commanded state.	Case 1 (Performance)		Not Test Failed This Key On	P0659 P0658 P0657 P2761 P2763 P2764	1 sec frequency 100 ms	One Trip
			If abs(Measured current - Commanded current) $\geq$ 100 milliamps for a time  THEN report malfunction		No Fault Pending P2761 P2763 P2764  Battery voltage between 9V and 18V  If Engine Cranking, then Crank Time < 4 seconds AND Battery Voltage > 10 V  High Side Driver 1 Enabled  Transmission not shifting  LU clutch is not engaging or dis-engaging  Neutral at Stop is not in process Not Fault Pending Solenoid Faults			
			Case 2 (Frequency)		Not Test Failed This Key On	Solenoid Faults	frequency 20 ms	
			If the solenoid is energized and frequency is < 3000 Hz OR > 5000 Hz OR the solenoid is not energized and frequency is > 3000 Hz  THEN report malfunction		Not Fault Pending HSD Faults  Not Test Failed This Key On HSD Faults  Battery voltage between 9V and 18V  Lockup Shift Complete > 0.5 sec  Range Shift Complete > 0.5 sec  RELS inactive, RELS override inactive, C2 backfill inactive, Neutral antidrag inactive, Device Control inactive, & EOS inactive > 0.5 sec			

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
			Case 3 (Plausibility) [Adler IC commanded - TCM measured duty cycle]	$\geq 10$  for $\geq 1$ second	Not Fault Pending  Not Test Failed This Key On  Not Fault Pending  Not Test Failed This Key On  Battery voltage between  High Side Driver 1 Enabled	Solenoid Faults (table 1)  Solenoid Faults (table 1)  HSD Faults (table 2)  HSD Faults (table 2)  9V and 18V	1 second  frequency 20 ms	
Torque Converter Clutch (TCC) Pressure Control Solenoid (PCS) Control Circuit High	P2763	This test detects torque converter solenoid electrical short to power circuit malfunctions.	If hardware fault short to power is present for a sample size  THEN report malfunction	$\geq 3$ consecutive samples	Not Test Failed This Key On  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 1 enabled	P2763 P0657 P0658 P0659  < 4 seconds	60 ms  frequency 20 ms	Two Trips

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Torque Converter Clutch (TCC) Pressure Control Solenoid (PCS) Control Circuit Low	P2764	This test detects torque converter solenoid electrical ground circuit malfunctions.	Fault pending is set at single solenoid driver hardware detection of a low fault  IF hardware fault is present for a sample size  THEN initiate intrusive test by opening low side driver  IF intrusive test indicates short to ground exists for a sample size THEN report malfunction	$\geq 3$ samples          $\geq 3$ samples	Not Test Failed This Key On   Battery Voltage between  If Engine Cranking, then Crank Time AND Battery Voltage  High side driver 1 enabled	P2764 P2761 P0657 P0658 P0659  9 V and 18 V  < 4 seconds	120 ms  frequency 20 ms	One Trip
<b>Miscellaneous</b>								
CAN Communication Bus 2 Bus Off	U0074	This test detects if the GMLAN bus is off for a calibration duration.	GMLAN bus is off for a time	$\geq 3$ seconds	Not Test Failed This Key On  Ignition Voltage between Battery Voltage between	U0074  9V and 18 V 9 V and 18 V	3 seconds  frequency 100 ms	Two Trips
Lost Communication with ECM "A"	U0100	This test detects GMLAN bus failures by detecting the loss of certain message information from the GMLAN Bus.	For all of the signals being monitored on the GMLAN bus, the diagnostic keeps track of the calibration number of timeout, and/or error/invalid states for each message  If the number of timeout, and/or error/invalid states  Report failure	$> 500$ counts out of 600 samples	Ignition Voltage between Battery Voltage between  The can bus is active (not failed)  Enable criteria must be met for a time	9V and 18 V 9 V and 18 V   > 3 seconds	0.5 seconds  frequency 10 ms	Two Trips
Sensor Reference Voltage "B" Circuit Fault	P0652	Tests whether the output voltage of the associated 5 Volt (VREF) reference is enabled and within the expected output voltage range. If found to be disabled, attempts are made to re-enable it.	If Power Supply is not enabled OR Voltage OR Voltage for	$> 5.25$ V  $< 4.75$ V 2 seconds	Battery Voltage between	9 V and 18 V	2 seconds  frequency 50 ms	One Trip

24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum
Brake Switch Circuit	P0703	This test counts how many acceleration events occur while the brake switch input indicates "ON". Failure is reported when the number of events exceeds a calibration value. In some applications, in addition, this test counts how many deceleration events occur while the brake switch input indicates "OFF" and the engine running time while in range. Failure is reported when the number of events exceeds a calibration and the engine running time exceeds a calibration.	case 1 The number of vehicle accelerations with the Neutral at Stop input "ON" $\geq 3$  case 2 The number of vehicle decelerations with the Neutral at Stop input "Off" and the engine run time > 0 while in range with Neutral at Stop input "off". Time and counts are carried to the next key cycle $\geq 20$		Not Test Failed This Key On  Not Test Failed This Key On  Not Fault Pending  Battery Voltage between  Primary Input Speed between  for 5 seconds  The stuck off section of the test is enabled when Pump mode, Fire Truck pump mode, Direct hold, PTO1, PTO2 are off and NEUTRAL AT STOP: Emissions Credit is enabled.	P0703  P0720 P0721 P0722  P0720 P0721 P0722  9 V and 18 V  200 RPM and 8500 RPM	frequency 150 ms	No MIL
Ignition Switch Run/Start Circuit Low	P2534	This test detects circuit low and open faults associated with the Run/Crank input to the TOM	Run/Crank input is not active for  THEN report malfunction	$\geq 5$ sec		Engine Speed $\geq 350$ rpm for $\geq 2$ sec  Output Speed $\geq 0$ rpm	5 sec  frequency 100ms	One Trip



24OBDG06B HD TCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	(Enable Conditions	Time Required	(MIL Illum
<b>Controller Memory</b>								
Internal SPI Diagnostics	P0600	This test detects faults associated with the communication between the microprocessor and the solenoid control integrated circuits internal to the TCM. The diagnostic reads the SPI Range Check Status message as reported by HWIO to determine which devices are being commanded outside of a valid calibration range. The diagnostic reads the SPI Bus Status message as reported by HWIO to determine the validity of SPI data and devices.	If a static bit within SPI messages is not in the proper state for  THEN report malfunction	>= 1 sec (in steady state range) OR >= 100 ms (during shift)	Battery voltage between  If Engine Cranking, then Crank Time AND Battery Voltage	9V and 18V  < 4 seconds > 10 V	1 sec in steady state range OR 100ms during shifts  frequency 20 ms	One Trip
Internal Control Module Transmission Range Control Performance	P27B2	This test verifies the transmission is in a valid range by monitoring the states of both the solenoids and pressure switches.	Actual Solenoid or Pressure Switch State for	/= Expected State for 1 second	Not Failed This Key On and No Fault Pending  Not Failed This Key On and No Fault Pending  Not Failed This Key On and No Fault Pending  Not Failed This Key On and No	Solenoid Faults (table 1)  P0842 P0843 P0847 P0848 P0872 P0873 P0877 P0878 P0751 P0752 P0756 P0757 P0761 P0762  HSD Faults (table 2)	1 second  frequency 20 ms	One Trip
								P0729

