

14 OBDG06B FSCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Rail Pressure (FRP) Sensor Performance (rationality)	P018B	This DTC detects a fuel pressure sensor response stuck within the normal operating range	Absolute value of fuel pressure change as sensed during intrusive test.	<= 30 kPa	<p>1. FRP Circuit Low DTC (P018C) 2. FRP Circuit High DTC (P018D) 3. FuelPump Circuit Low DTC (P0231)</p> <p>4. FuelPump Circuit High DTC (P0232) 5. FuelPump Circuit Open DTC (P023F)</p> <p>6. Reference Voltage DTC (P0641) 7. Fuel Pump Control Module Driver Over-temperature DTC (P064A) 8. Control Module Internal Performance DTC (P0606)</p>	<p>Frequency: Continuous; 12.5 ms loop. 60 seconds between intrusive tests that pass</p> <p>Intrusive test requested if fuel system is clamped for >= 5 seconds or fuel pressure error variance <= typically (0.3 to 0.6) (calculated over a 2.5sec period); otherwise report pass</p> <p>Not active Not active</p>	<p>Duration of intrusive test is fueling related (5 to 12 seconds).</p> <p>Intrusive test is run when fuel flow is below Max allowed fuel flow rate (Typical values in the range of 11 to 50 g/s)</p>	DTC Type A 1 trip

14 OBDG06B FSCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					9. Engine run time 10. Emissions fuel level low (PPEI \$3FB) 11. Fuel pump control 12. Fuel pump control state 13. Engine fuel flow 14. ECM fuel control system failure (PPEI \$1E7)	>=5 seconds Not low Enabled Normal or FRP rationality control > 0.047 g/s Not failed		
Fuel Rail Pressure (FRP) Sensor Circuit Low Voltage	P018C	This DTC detects if the fuel pressure sensor circuit is shorted low	FRP sensor voltage	< 0.14 V	Ignition	Run or Crank	72 failures out of 80 samples 1 sample/12.5 ms	DTC Type A 1 trip
Fuel Rail Pressure (FRP) Sensor Circuit High Voltage	P018D	This DTC detects if the fuel pressure sensor circuit is shorted high	FRP sensor voltage	> 4.86 V	Ignition	Run or Crank	72 failures out of 80 samples 1 sample/12.5 ms	DTC Type A 1 trip
Fuel Pump Control Circuit Low Voltage	P0231	This DTC detects if the fuel pump control circuit is shorted to low	Fuel Pump Current	> 14.48A	Ignition switch OR Ignition switch OR Fuel Pump Control AND Ignition Run/Crank Voltage	Run or Crank Accessory enabled 9V < voltage < 32V	72 test failures in 80 test samples if Fuel Pump Current <100A 1 sample/12.5 ms	DTC Type A 1 trip
Fuel Pump Control Circuit High Voltage	P0232	This DTC detects if the fuel pump control circuit is shorted to high	Voltage measured at fuel pump circuit	> 3.86 V	Commanded fuel pump output	0% duty cycle (off)	36 test failures in 40 test samples; 1 sample/12.5ms	DTC Type A 1 trip

14 OBDG06B FSCM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					Fuel pump control enable Time that above conditions are met	False >=4.0 seconds	Pass/Fail determination made only once per trip	
Fuel Pump Control Circuit (Open)	P023F	This DTC detects if the fuel pump control circuit is open	Fuel Pump Current AND Fuel Pump Duty Cycle	<=0.5A >20%	Ignition switch OR Ignition switch OR Fuel Pump Control AND Ignition Run/Crank Voltage	Run or Crank Accessory enabled 9V < voltage < 32V	72 test failures in 80 test samples; 1 sample/12.5ms	DTC Type A 1 trip
Fuel System Control Module Enable Control Circuit	P025A	This DTC detects if there is a fault in the fuel pump control enable circuit	PPEI (Powertrain Platform Electrical Interface) Fuel System Request (\$1E7)	# Fuel Pump Control Module Enable Control Circuit	Ignition AND PPEI Fuel System Request (\$1E7)	Run or Crank valid	72 failures out of 80 samples 1 sample/12.5 ms	DTC Type A 1 trip
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if any software or calibration check sum is incorrect	Calculated Checksum (CRC16)	# stored checksum for any of the parts (boot, software, application calibration, system calibration)	Ignition switch OR Ignition switch OR Fuel Pump Control	Run or Crank Accessory enabled	1 failure if it occurs during the first ROM test of the ignition cycle, otherwise 5 failures Frequency: Runs continuously in the background	DTC Type A 1 trip
Control Module Not Programmed	P0602	Indicates that the ECU needs to be programmed	KeMEMD_b_NoStartCal	Calibration = TRUE	Ignition switch OR	Run or Crank	Runs once at power up	DTC Type A 1 trip

14 OBDG06B FSCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					Ignition switch OR Fuel Pump Control	Accessory enabled		
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power-up	# checksum at power-down	Ignition switch OR Ignition switch OR Fuel Pump Control	Run or Crank Accessory enabled	1 failure Frequency: Once at power-up	DTC Type A 1 trip
Control Module Random Access Memory (RAM)	P0604	Indicates that control module is unable to correctly write and read data to and from RAM	Data read	# Data written	Ignition switch OR Ignition switch OR Fuel Pump Control	Run or Crank Accessory enabled	1 failure if it occurs during the first RAM test of the ignition cycle, otherwise 5 failures Frequency: Runs continuously in the background.	DTC Type A 1 trip
Control Module Internal Performance	P0606	Indicates the ECU has detected an internal processor fault or external watchdog fault (PID \$2032 discriminates the source of fault)			Ignition switch OR Ignition switch OR Fuel pump control	Run or Crank Accessory Enabled		DTC Type A 1 trip
1. Main Processor Configuration Register Test			1. I/O configuration register faults: •Register contents	=Incorrect value	1. For all I/O configuration register faults: Calibration •KeMEMD_b_ProcFltCfgRegEnbl	TRUE	1. 1 failure Frequency: Continuously (12.5ms)	

14 OBDG06B FSCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
2. Processor clock test			2. Processor Clock Fault: <ul style="list-style-type: none">• EE latch flag in EEPROM OR• RAM latch flag.	0x5A5A 0x5A	2. For Processor Clock Fault: Calibration •KeMEMD_b_ProcFltCLKDiagEnbl	TRUE	2. 1 failure Frequency: Continuously (12.5ms)	
3. External watchdog test			3. External Watchdog Fault: <ul style="list-style-type: none">• Software control of fuel pump driver	Control Lost	3. For External Watchdog Fault: Calibration •KeFRPD_b_FPExtWDogDiagEnbl AND •Control Module ROM(P0601) AND •Control Module RAM(P0604)	TRUE Not active Not active	3. 3 failures out of 15 samples 1 sample/12.5 ms	
Control Module Long Term Memory (EEPROM) Performance	P062F	Indicates that the NVM Error flag has not been cleared	Last EEPROM write	Did not complete	Ignition switch OR Ignition switch OR Fuel pump control	Run or Crank Accessory Enabled	1 test failure Once on controller power-up	DTC Type A 1 trip
5Volt Reference Circuit (Short High/Low/Out of Range)	P0641	Detects continuous short or out of range on the #1 5V sensor reference circuit	(Reference voltage AND Output) OR (Reference voltage AND Output) OR (Reference voltage AND Output) OR	(>= 0.5V inactive) (>= 5.5V active) (<= 4.5V active)	Ignition	Run or Crank	15 failures out of 20 samples 1 sample/12.5 ms	DTC Type A 1 trip
			Reference voltage	> 105% nominal OR < 95% nominal (i.e., > 5.25v OR < 4.75v)				

14 OBDG06B FSCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Pump Control Module Driver 1 Over-temperature	P064A	Detects if an internal fuel pump driver overtemperature condition exists under normal operating conditions	Pump Driver Temp	> 150C	Ignition switch OR Ignition switch OR Fuel pump control KeFRPD_b_FPOverTempDiagEnbl	Run or Crank Accessory Enabled TRUE	3 failures out of 15 samples 1 sample/12.5 ms	DTC Type B 2 trips
Ignition 1 Switch Circuit Low Voltage	P2534	This DTC detects if the Ignition1 Switch circuit is shorted to low or open	Ignition 1 voltage	<= 6 V	Engine	Running	180 failures out of 200 samples 1 sample/25.0 ms	DTC Type A 1 trip
Ignition 1 Switch Circuit High Voltage	P2535	Detects if the Ignition1 Switch circuit is shorted to vehicle supply voltage	Ignition 1 voltage	> 11.7 V	Ignition Run_Crank terminal	Off	180 failures out of 200 samples 1 sample/25.0 ms	DTC Type A 1 trip

14 OBDG06B FSCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
Fuel Pump Flow Performance (rationality)	P2635	Detects degradation in the performance of the electronically regulated fuel system	Filtered fuel rail pressure error	<p><= Low Threshold (tabulated function of desired fuel rail pressure and fuel flow rate -- 15% of requested Target Pressure)</p> <p>OR</p> <p>>= High Threshold (tabulated function of desired fuel rail pressure and fuel flow rate -- 15% of requested Target Pressure)</p> <p>(See Supporting Tables tab)</p>			<p>Filtered fuel rail pressure error Time Constant = 12.5 seconds</p> <p>Frequency: Continuous 12.5 ms loop</p>	DTC Type B 2 trips

14 OBDG06B FSCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumination
					11. Barometric pressure signal (PPEI \$4C1) 12. Engine run time 13. Emissions fuel level (PPEI \$3FB) 14. Fuel pump control 15. Fuel pump control state 16. Battery Voltage 17. Fuel flow rate (See Supporting Tables tab)	Valid (for absolute fuel pressure sensor) >= 30 seconds Not low Enabled Normal 11V<=voltage=<32V > 0.047 g/s AND <= Max allowed fuel flow rate as a function of desired rail pressure & Vbatt (Typical values in the range of 11 to 50 g/s)		
					18. Fuel Pressure Control System	Is not responding to an over-pressurization due to pressure build during DFCO or a decreasing desired pressure command.		
Control Module Communication Bus "A" Off	U0073	Detects that a CAN serial data bus shorted condition has occurred to force the CAN device driver to enter a bus-off	Bus Status	Off	Power mode	Run/Crank	5 failures out of 5 samples (5 seconds)	DTC Type B 2 trips
Lost Communication With ECM/PCM "A"	U0100	Detects that CAN serial data communication has been lost with the ECM	Message \$0C9	Undetected	1. Power mode 2. Ignition Run/Crank Voltage 3. U0073	Run/Crank 11V<voltage<32V not active	12 failures out of 12 samples (12 seconds)	DTC Type B 2 trips

14 OBDG06B FSCM Supporting Tables

P2635 Fuel Pump Performance Maximum Fuel Flow map (grams / s)

X-axis= Desired Fuel Pressure (kiloPascals)

Y-axis= Battery voltage (volts)

	200	250	300	350	400	450	500	550	600
4.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
6	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
7.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
9	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
10.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
12	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
13.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
15	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
16.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
18	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
19.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
21	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5

14 OBDG06B FSCM Supporting Tables

22.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
24	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
25.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
27	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5
28.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5	17.5

P2635 Fuel Pump Performance Filtered Pressure Error Fault Threshold High map (kiloPascals)

X-axis= Target Fuel Pressure (kiloPascals)

Y-axis= Fuel Flow (grams / s)

	200	250	300	350	400	450	500	550	600
0	30	37.5	45	52.5	60	67.5	75	82.5	90
1.5	30	37.5	45	52.5	60	67.5	75	82.5	90
3	30	37.5	45	52.5	60	67.5	75	82.5	90
4.5	30	37.5	45	52.5	60	67.5	75	82.5	90
6	30	37.5	45	52.5	60	67.5	75	82.5	90
7.5	30	37.5	45	52.5	60	67.5	75	82.5	90
9	30	37.5	45	52.5	60	67.5	75	82.5	90

14 OBDG06B FSCM Supporting Tables

10.5	30	37.5	45	52.5	60	67.5	75	82.5	90
12	30	37.5	45	52.5	60	67.5	75	82.5	90
13.5	30	37.5	45	52.5	60	67.5	75	82.5	90
15	30	37.5	45	52.5	60	67.5	75	82.5	90
16.5	30	37.5	45	52.5	60	67.5	75	82.5	90
18	30	37.5	45	52.5	60	67.5	75	82.5	90
19.5	30	37.5	45	52.5	60	67.5	75	82.5	90
21	30	37.5	45	52.5	60	67.5	75	82.5	90
22.5	30	37.5	45	52.5	60	67.5	75	82.5	90
24	30	37.5	45	52.5	60	67.5	75	82.5	90
25.5	30	37.5	45	52.5	60	67.5	75	82.5	90
27	30	37.5	45	52.5	60	67.5	75	82.5	90
28.5	30	37.5	45	52.5	60	67.5	75	82.5	90
30	30	37.5	45	52.5	60	67.5	75	82.5	90
31.5	30	37.5	45	52.5	60	67.5	75	82.5	90
33	30	37.5	45	52.5	60	67.5	75	82.5	90
34.5	30	37.5	45	52.5	60	67.5	75	82.5	90
36	30	37.5	45	52.5	60	67.5	75	82.5	90
37.5	30	37.5	45	52.5	60	67.5	75	82.5	90
39	30	37.5	45	52.5	60	67.5	75	82.5	90

14 OBDG06B FSCM Supporting Tables

40.5	30	37.5	45	52.5	60	67.5	75	82.5	90
42	30	37.5	45	52.5	60	67.5	75	82.5	90
43.5	30	37.5	45	52.5	60	67.5	75	82.5	90
45	30	37.5	45	52.5	60	67.5	75	82.5	90
46.5	30	37.5	45	52.5	60	67.5	75	82.5	90
48	30	37.5	45	52.5	60	67.5	75	82.5	90

P2635 Fuel Pump Performance Filtered Pressure Error Fault RePass Threshold High map (kiloPascals)

X-axis= Target Fuel Pressure (kiloPascals)

Y-axis= Fuel Flow (grams / s)

	200	250	300	350	400	450	500	550	600
0	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
1.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
3	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
4.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
6	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
7.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
9	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5

14 OBDG06B FSCM Supporting Tables

10.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
12	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
13.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
15	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
16.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
18	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
19.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
21	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
22.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
24	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
25.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
27	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
28.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
30	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
31.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
33	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
34.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
36	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
37.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5
39	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5

14 OBDG06B FSCM Supporting Tables

40.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5	
42	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5	
43.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5	
45	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5	
46.5	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5	
48	25.5	31.875	38.25	44.625	51	57.375	63.75	70.125	76.5	

P2635 Fuel Pump Performance Filtered Pressure Error Fault Threshold Low map (kiloPascals)

X-axis= Target Fuel Pressure (kiloPascals)

Y-axis= Fuel Flow (grams / s)

	200	250	300	350	400	450	500	550	600	
0	-260	-210	-160	-110	-60	-67.5	-75	-82.5	-90	
1.5	-145	-125	-102.5	-81.25	-60	-67.5	-75	-82.5	-90	
3	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90	
4.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90	
6	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90	
7.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90	
9	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90	
10.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90	

14 OBDG06B FSCM Supporting Tables

12	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
13.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
15	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
16.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
18	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
19.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
21	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
22.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
24	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
25.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
27	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
28.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
30	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
31.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
33	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
34.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
36	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
37.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
39	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
40.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90

14 OBDG06B FSCM Supporting Tables

42	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
43.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
45	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
46.5	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90
48	-30	-37.5	-45	-52.5	-60	-67.5	-75	-82.5	-90

P2635 Fuel Pump Performance Filtered Pressure Error Fault RePass Threshold Low map (kiloPascals)

X-axis= Target Fuel Pressure (kiloPascals)

Y-axis= Fuel Flow (grams / s)

	200	250	300	350	400	450	500	550	600
0	-221	-178.5	-136	-93.5	-51	-57.375	-63.75	-70.125	-76.5
1.5	-123.25	-106.25	-87.125	-69.0625	-51	-57.375	-63.75	-70.125	-76.5
3	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
4.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
6	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
7.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
9	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
10.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
12	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5

14 OBDG06B FSCM Supporting Tables

13.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
15	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
16.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
18	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
19.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
21	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
22.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
24	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
25.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
27	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
28.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
30	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
31.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
33	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
34.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
36	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
37.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
39	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
40.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
42	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5

14 OBDG06B FSCM Supporting Tables

43.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
45	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
46.5	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5
48	-25.5	-31.875	-38.25	-44.625	-51	-57.375	-63.75	-70.125	-76.5