

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Open – Bank 1	P0010	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 1	P0011	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Intake cam Bank 1) Cam Position Error > (P0011_CamPosErrorLimlc1) deg	System Voltage Engine Running Power Take Off (PTO) active Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs Bundle: IntakeVVT_Enabled	> 11.00 Volts = TRUE = FALSE > 0 deg > (P0011_CamPosErrorLimlc1) deg AND < (P0011_PerfMaxlc1) deg < 5.00 Deg for (P0011_P05CC_StablePositionTimeIc1) sec P0010 P2088 P2089 = TRUE (Reference Supporting Tables: P0011_P0021_P05CC_P05CD_HiEngSpdHiDsbllc P0011_P0021_P05CC_P05CD_HiEngSpdLoEnbllc P0011_P0021_P05CC_P05CD_LoRpmHiEnbllc P0011_P0021_P05CC_P05CD_LoRpmLoDsbllc P0011_P0021_P05CC_P05CD_LoPresHiEnbllc P0011_P0021_P05CC_P05CD_LoPresLoDsbllc	300.00 failures out of 400.00 samples 100 ms /sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P0011_P0021_P05CC_P 05CD_EngOilPressEnbl c P0011_P0021_P05CC_P 05CD_P0014_P0024_P0 5CE_P05CF_ColdStartE ngRunning Reference Fault Bundles: IntakeVVT_Enabled CrankIntakeCamCorrFA IntakeCamSensorTFTK O CrankSensorTFTKO CamLctnIntFA)		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Open – Bank 1	P0013	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Performance – Bank 1	P0014	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Exhaust cam Bank 1) Cam Position Error > (P0014_CamPosErrorLimEc1) deg	System Voltage Engine Running Power Take Off (PTO) active Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs Bundle: ExhaustVVT_Enabled	> 11.00 Volts = TRUE = FALSE > 0 deg > (P0014_CamPosErrorLimEc1) deg AND < (P0014_PerfMaxEc1) deg < 5.00 Deg for (P0014_P05CE_StablePositionTimeEc1) sec P0013 P2090 P2091 = TRUE (Reference Supporting Tables: P0014_P0024_P05CE_P05CF_HiEngSpdHiDsblEc P0014_P0024_P05CE_P05CF_HiEngSpdLoEnblEc P0014_P0024_P05CE_P05CF_LoRpmHiEnblEc P0014_P0024_P05CE_P05CF_LoRpmLoDsblEc P0014_P0024_P05CE_P05CF_LoPresHiEnblEc P0014_P0024_P05CE_P	300.00 failures out of 400.00 samples 100 ms /sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						05CF_LoPresLoDsbIEc P0014_P0024_P05CE_P 05CF_EngOilPressEnbl Ec P0011_P0021_P05CC_P 05CD_P0014_P0024_P0 5CE_P05CF_ColdStartE ngRunning Reference Fault Bundles: ExhaustVVT_Enabled CrankExhaustCamCorrF A ExhaustCamSensorTFT KO CrankSensorTFTKO CamLctnExhFA)		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 1	P0030	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0031 may also set

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0031	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground).	Short to ground: $\leq 0.5 \Omega$ impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0030 may also set

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0032	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 2	P0036	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit).	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0037 may also set

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0037	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground).	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0036 may also set

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0038	Diagnoses the Heater Output low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power).	Short to power: $\leq 0.5 \Omega$ impedance between signal and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 1	P0053	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$3.1 < \Omega < 9.1$	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P262B IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 255.0 < 32.0 volts < 0.10 seconds	Once per valid cold start	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0054	Detects an oxygen sensor heater having an incorrect or out of range resistance value.	Heater Resistance outside of the expected range of	$3.1 < \Omega < 9.1$	No Active DTC's Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time	ECT_Sensor_FA P262B IAT_SensorFA < 8.0 °C > 28,800 seconds -30.0 < °C < 255.0 < 32.0 volts < 0.10 seconds	Once per valid cold start	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
MAP / MAF / Throttle Position Correlation	P0068	Detect when MAP and MAF do not match estimated engine airflow as established by the TPS	<p>Difference between MAP and estimated MAP exceeds threshold (kPa), or P0651 (5 Volt Ref), or P0107 (MAP circuit low), or P0108 (MAP circuit high) have failed this key cycle, then MAP portion of diagnostic fails</p> <p>Absolute difference between MAF and estimated MAF exceed threshold (grams/sec), or P0102 (MAF circuit low), or P0103 (MAF circuit hi) have failed this key cycle, or maximum MAF versus RPM (Table) is greater than or equal to maximum MAF versus battery voltage, then MAF portion of diagnostic fails</p>	<p>Table, f(TPS). See supporting tables: Delta MAP Threshold f(TPS)</p> <p>Table, f(TPS). See supporting tables: Delta MAF Threshold f(TPS)</p> <p>Table, f(RPM). See supporting tables: Maximum MAF f (RPM)</p> <p>Table, f(Volts). See supporting tables: Maximum MAF f (Volts)</p>	Engine Speed	<p>> 800 RPM</p> <p>Run/Crank voltage > 6.41</p>	<p>Continuously fail MAP and MAF portions of diagnostic for 0.1875 s</p> <p>Continuous in MAIN processor</p>	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp Sensor Circuit Low Voltage	P00B3	This DTC detects a short to ground in the RCT signal circuit or the RCT sensor.	RCT Resistance (@ 150°C)	< 55 Ohms	Engine run time OR IAT min	> 10.0 seconds ≤ 70.3 °C	5 failures out of 10 samples 1 sec/ sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temp Sensor Circuit High Voltage	P00B4	Circuit Continuity This DTC detects a short to high or open in the RCT signal circuit or the RCT sensor.	RCT Resistance (@ -60°C)	> 148,600 Ohms	Engine run time OR IAT min	> 60.0 seconds ≥ -7.0 °C	5 failures out of 10 samples 1 sec/ sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Flow Insufficient	P00B7	This DTC detects a Insufficient Flow Condition (i.e.. Stuck Closed Thermostat)	Engine Coolant Temp (ECT) is greater than 117 Deg C and Difference between ECT and RCT is greater than 45 Deg C. When above is present for more than 5 seconds, fail counts start.		No Active DTC's Engine run time AND Engine Coolant Temp	THMR_RCT_Sensor_Ckt _FA THMR_ECT_Sensor_Ckt _FA > 300 seconds > 90.0 Deg C	30 failures out of 600 samples 1 sec/ sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (naturally aspirated)	P0101	Determines if the MAF sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 250 kPa*(g/s) > 12.0 grams/sec > 20.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,500 RPM >= -7 Deg C <= 125 Deg C >= -20 Deg C <= 100 Deg C >= 0.50 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM See Residual Weight Factor tables. No Active DTCs: MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA No Pending DTCs: EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit Low Frequency	P0102	Detects a continuous short to low or a open in either the signal circuit or the MAF sensor	MAF Output	<= 900 Hertz (~ 0.09 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 10.0 Volts >= 1.0 seconds	200 failures out of 250 samples 1 sample every cylinder firing event	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit High Frequency	P0103	Detects a high frequency output from the MAF sensor	MAF Output	$\geq 14,500$ Hertz (~ 126.8 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds ≥ 300 RPM ≥ 10.0 Volts ≥ 1.0 seconds	200 failures out of 250 samples 1 sample every cylinder firing event	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (naturally aspirated)	P0106	Determines if the MAP sensor is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 250 kPa*(g/s)	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,500 RPM >= -7 Deg C <= 125 Deg C >= -20 Deg C <= 100 Deg C >= 0.50 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM See Residual Weight Factor tables.	Continuous Calculations are performed every 12.5 msec	Type B, 2 Trips
			Manifold Pressure OR	< 50.0 kPa	Time between current ignition cycle and the last	999 failures out of 0 samples		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Manifold Pressure	> 115.0 kPa	time the engine was running Engine is not rotating No Active DTCs: No Pending DTCs:	> 10.0 seconds EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA MAP_SensorCircuitFP AAP_SnsrCktFP	1 sample every 12.5 msec	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low	P0107	Detects a continuous short to low or open in either the signal circuit or the MAP sensor.	MAP Voltage	< 3.0 % of 5 Volt Range (This is equal to 0.15 Volts or 3.5 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit High	P0108	Detects an open sensor ground or continuous short to high in either the signal circuit or the MAP sensor.	MAP Voltage	> 90.0% of 5 Volt Range (This is equal to 4.50 Volts, or 115.0 kPa)	Continuous		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Performance (no humidity or manifold temperature sensors)	P0111	Detects an IAT sensor that has stuck in range by comparing to engine coolant temperature at startup	ABS(Power Up IAT - Power Up ECT)	> 50 deg C	Time between current ignition cycle and the last time the engine was running Power Up ECT No Active DTCs:	> 28,800 seconds < 60 deg C ECT_Sensor_Ckt_FA IAT_SensorCircuitFA	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Low	P0112	Detects a continuous short to ground in the IAT signal circuit or the IAT sensor	Raw IAT Input	< 58 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit High	P0113	Detects a continuous open circuit in the IAT signal circuit or the IAT sensor	Raw IAT Input	> 142,438 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Intermittent In-Range	P0114	Detects a noisy or erratic IAT signal circuit or IAT sensor	String Length Where: "String Length" = sum of "Diff" calculated over And where: "Diff" = ABS(current IAT reading - IAT reading from 100 milliseconds previous)	> 80.00 DegC 10 consecutive IAT samples	Continuous		4 failures out of 5 samples Each sample takes 1.0 seconds	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit Low	P0117	Circuit Continuity This DTC detects a short to ground in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ 150°C)	< 55 Ohms			5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit High	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT signal circuit or the ECT sensor.	ECT Resistance (@ -60°C)	> 148,600 Ohms	Engine run time OR IAT min	> 10.0 seconds ≥ 0.0 °C	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent	P0119	Circuit Continuity This DTC detects large step changes in the ECT signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample.	ECT temperature step change: 1) positive step change is greater than calculated high limit OR 2) negative step change is lower than calculated low limit. The calculated high and low limits for the next reading use the following calibrations: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit *****Generic Example***** If the last ECT reading was 90 Deg C, the Time constant was calibrated at 10 seconds, the low limit was calibrated to -80 Deg C and the high limit was calibrated to 200 Deg C the calculated limits are 101 Deg C and 73 Deg C. The next reading (after the 90 Deg C reading) must be between 73 Deg C and 101 Deg C to be valid.	15.0 seconds -80.0 Deg C 200.0 Deg C	No Active DTC's	ECT_Sensor_Ckt_FP	3 failures out of 4 samples 1 sec/ sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (naturally aspirated)	P0121	Determines if the Throttle Position Sensor input is stuck within the normal operating range	Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	> 250 kPa*(g/s) > 12.0 grams/sec <= 20.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,500 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 100 Deg C >= 0.50 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor based on MAF Est See Residual Weight Factor tables. No Active DTCs: MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA No Pending DTCs: EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit Low	P0122	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage <	0.3250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit High	P0123	Detects a continuous or intermittent short or open in TPS1 circuit	TPS1 Voltage >	4.750		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Below Stat Regulating Temperature) (energy based "Deluxe" method	P0128	This DTC detects if the engine coolant temperature rises too slowly due to an ECT or Cooling system fault	<p>Energy is accumulated after the first combustion event using Range #1 or #2 below:</p> <p>Thermostat type is divided into normal (non-heated) and electrically heated.</p> <p>For this application the "type" cal (KeTHMG_b_TMS_ElectHstEquipped) = 1 If the type cal is equal to one, the application has an electrically heated t-stat, if equal to zero the the application has a non heated t-stat. See appropriate section below.</p> <p>***** Type cal above = 1 (Electrically heated t-stat) == == == == Range #1 (Primary) ECT reaches Commanded temperature minus 11 °C when Ambient min is ≤ 52 °C and > 10 °C. Note: Warm up target for range #1 will be at least 89 °C == == == == Range #2 (Alternate) ECT reaches Commanded temperature minus 31 °C when Ambient min is ≤ 10 °C and > -7 °C. Note: Warm up target for range #2 will be at least</p>	<p>See the two tables named: P0128_Maximum Accumulated Energy for Start-up ECT conditions - Primary and P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate in the Supporting tables section.</p> <p>This diagnostic models the net energy into and out of the cooling</p>	<p>No Active DTC's</p> <p>Engine not run time (soaking time before current trip)</p> <p>Engine run time</p> <p>Fuel Condition</p> <p>Distance traveled</p> <p>***** If Engine RPM is continuously greater than for this time period</p> <p>The diagnostic test for this key cycle will abort *****</p> <p>***** If T-Stat Heater commanded duty cycle for this time period</p> <p>The diagnostic test for this</p>	<p>ECT_Sensor_Ckt_FA ECT_Sensor_Perf_FA VehicleSpeedSensor_FA OAT_PtEstFiltFA IAT_SensorCircuitFA MAF_SensorFA THMR_AWP_AuxPumpFA THMR_AHV_FA THMR_SWP_Control_FA THMR_SWP_NoFlow_FA THMR_SWP_FlowStuckOn_FA ETQR_IndTorqInaccurate</p> <p>≥ 1,800 seconds</p> <p>10 ≤ Eng Run Tme ≤ 1,500 seconds</p> <p>Ethanol ≤ 80 %</p> <p>≥ 1.55 miles</p> <p>*****</p> <p>9,999 rpm 5.0 seconds</p> <p>*****</p> <p>> 100.0 % duty cycle > 5.0 seconds</p>	<p>1 failure to set DTC</p> <p>1 sec/ sample</p> <p>Once per ignition key cycle</p>	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>69 °C</p> <p>*****</p> <p>Type cal above = 0 (non - heated t-stat)</p> <p>== == == ==</p> <p>Range #1 (Primary) ECT reaches 64 °C when Ambient min is ≤ 52 °C and > 10 °C.</p> <p>== == == ==</p> <p>Range #2 (Alternate) ECT reaches 64 °C when Ambient min is ≤ 10 °C and > -7 °C.</p> <p>*****</p>	<p>system during the warm-up process.</p> <p>The five energy terms are: heat from combustion, heat from after-run, heat loss to enviroment, heat loss to cabin and heat loss to DFCO.</p>	<p>key cycle will abort</p> <p>*****</p> <p>ECT at start run</p>	<p>*****</p> <p>-40 ≤ ECT ≤ 84 °C</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 1	P0131	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 40.0 mVolts	No Active DTC's AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State All of the above met for	TPS_ThrottleAuthorityDefaulted MAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA = Not active = Not active = Not active = Not active 10.0 < Volts = Not active = Not active = Not active = Not active = False 0.9912 < ratio < 1.0137 50 < mgram < 500 = Closed Loop = TRUE Enabled (On) Ethanol ≤ 88 % DFCO not active > 5.0 seconds	285 failures out of 356 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1	P0132	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	No Active DTC's System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum Low Fuel Condition Diag Initial delay after Open Test Criteria met (cold start condition) Initial delay after Open Test Criteria met (not cold start condition) Equivalence Ratio All of the above met for	TPS_ThrottleAuthority Defaulted MAF_SensorFA MAP_SensorFA ExcessPurgePsb1_FA FuelInjectorCircuit_FA EthanolCompositionSens or_FA AIR System FA 10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds = False > 40.0 seconds when engine soak time > 28,800 seconds > 40.0 seconds when engine soak time ≤ 28,800 seconds 0.9912 ≤ ratio ≤ 1.0137 > 5.0 seconds	100 failures out of 125 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater on for Learned Htr resistance Engine Coolant IAT Engine run Accum Time since any AFM status change Time since Purge On to Off change Time since Purge Off to On change Engine airflow Engine speed Fuel Condition Baro Air Per Cylinder Fuel Control State Closed Loop Active LTM fuel cell Transient Fuel Mass Baro Fuel Control State Fuel State Commanded Proportional Gain ===== All of the above met for	in Supporting Tables tab. ≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 60 °C > -40 °C > 30 seconds > 2.0 seconds > 1.0 seconds > 2.0 seconds 12 ≤ grams/second ≤ 35 1,300 ≤ RPM ≤ 3,500 < 88 % Ethanol > 70 kpa ≥ 130 mGrams = Closed Loop = TRUE = Enabled ≤ 100.0 mgrams = Not Defaulted not = Power Enrichment DFCO not active ≥ 0.0 % ===== > 2.0 seconds		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 1	P0135	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.5 < Amps < 3.5	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA 10.0 < Volts = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 30 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0137	This DTC determines if the O2 sensor circuit is shorted to low.	Oxygen Sensor Signal	< 40 mvolts	No Active DTC's AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active All Fuel Injectors for active Cylinders Fuel Condition Fuel State All of the above met for	TPS_ThrottleAuthority DefaultedMAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA = Not active = Not active = Not active = Not active 10.0 < Volts = Not active = Not active = Not active = Not active = False 0.9912 ≤ ratio ≤ 1.0137 50 ≤ mgrams ≤ 500 = Closed Loop = TRUE Enabled (On) Ethanol ≤ 88 %DFCO not active > 5.0 seconds	323 failures out of 405 samples Frequency: Continuous in 100 milli - second loop	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0138	This DTC determines if the O2 sensor circuit is shorted to high.	Oxygen Sensor Signal	> 1,050 mvolts	<p>No Active DTC's</p> <p>System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum</p> <p>Low Fuel Condition Diag</p> <p>Initial delay after Open Test Criteria met (cold start condition)</p> <p>Initial delay after Open Test Criteria met (not cold start condition)</p> <p>Equivalence Ratio Fuel Control State</p> <p>All of the above met for</p>	<p>TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA ExcessPurgePsbI_FA FuelInjectorCircuit_FA EthanolCompositionSens or_FA AIR System_FA</p> <p>10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds</p> <p>= False</p> <p>> 80.0 seconds when engine soak time > 28,800 seconds</p> <p>> 80.0 seconds when engine soak time ≤ 28,800 seconds</p> <p>0.9912 ≤ ratio ≤ 1.0137 not = Power Enrichment</p> <p>> 5.0 seconds</p>	<p>100 failures out of 125 samples</p> <p>Frequency: Continuous in 100 milli - second loop</p>	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 1 Sensor 2	P013A	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Rich to Lean voltages range during Rich to Lean transition. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.5 units > 57.7 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Low Fuel Condition Diag Post fuel cell (Decel) Crankshaft Torque	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013B, P013E, P013F, P2270 or P2271 10.0 < Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. = False = enabled < 100.0 Nm	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					DTC's Passed ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	P2270 (and P2272 if applicable) P013E (and P014A if applicable) =====		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	This DTC determines if the post catalyst O2 sensor has Slow Response in a predefined Lean to Rich voltages range during Lean to Rich transition. The diagnostic is an intrusive test which increases the delivered A/F ratio to achieve the required rich threshold.	The EWMA of the Post O2 sensor normalized integral value OR The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)	> 8.5 units > 179 grams (lower voltage threshold is 300 mvolts and upper voltage threshold is 600 mvolts)	No Active DTC's B1S2 DTC's Not Active this key cycle System Voltage Learned heater resistance ICAT MAT Burnoff delay Green O2S Condition Green Cat System Condition	TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA EthanolCompositionSensor_FA P013A, P013E, P013F, P2270 or P2271 10.0 < Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. = Not Valid, System is not valid until accumulated airflow is greater than	Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.	Type A, 1 Trips EWMA

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Low Fuel Condition Diag Post fuel cell</p> <p>DTC's Passed</p> <p>=====</p> <p>After above conditions are met: Fuel Enrich mode continued.</p> <p>=====</p> <p>During this test the following must stay TRUE or the test will abort: 0.96 ≤ Fuel EQR ≤ 1.10</p>	<p>360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False = enabled</p> <p>P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable) P013F (and P014B if applicable)</p> <p>=====</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Crankshaft Torque DTC's Passed Number of fueled cylinders ===== After above conditions are met: DFCO mode entered (wo driver initiated pedal input).	< 100.0 Nm P2270 (and P2272 if applicable) ≤ 5 cylinders =====		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Low Fuel Condition Diag Post fuel cell</p> <p>DTC's Passed</p> <p>Number of fueled cylinders =====</p> <p>After above conditions are met: Fuel Enrich mode entered. =====</p> <p>During this test the following must stay TRUE or the test will abort: 0.96 ≤ Fuel EQR ≤ 1.10</p>	<p>360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False = enabled</p> <p>P2270 (and P2272 if applicable) P013E (and P014A if applicable) P013A (and P013C if applicable) P2271 (and P2273 if applicable)</p> <p>≥ 1 cylinders =====</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0141	This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit.	Heater Current outside of the expected range of	0.5 > amps > 3.5	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA 10.0 < Volts = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 2 tests per trip 30 seconds delay between tests and 1 second execution rate.	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 1	P015A	This DTC determines if the pre catalyst O2 sensor has an initial delayed response to an A/F change from Rich to Lean. The diagnostic is an intrusive test which runs in a DFCO mode to achieve the required response.	The EWMA of the Pre O2 sensor normalized R2L time delay value OR [The Accumulated time monitored during the R2L Delayed Response Test (Gross failure). AND Pre O2 sensor voltage is	> 1.3 EWMA (sec) ≥ 2.0 Seconds > 550 mvolts	No Active DTC's System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control Low Fuel Condition Diag Green O2S Condition	TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA P0131, P0132, P0134 10.0 < Volts = Not active = Not active = Not active = Not active = False = Not Valid, See definition of Multiple DTC Use_Green Sensor Delay Criteria - Airflow and Multiple DTC Use_Green Sensor Delay Criteria - Limit for	Frequency: Once per trip Note: if NaESPD_b_FastInitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed	Type A, 1 Trips EWMA

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					O2 Heater (pre sensor) on for Learned Htr resistance Engine Coolant IAT Engine run Accum Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State	the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. ≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") > 60 °C > -40 °C > 30 seconds 1,100 ≤ RPM ≤ 3,500 1,050 ≤ RPM ≤ 3,650 2 ≤ gps ≤ 12 37.9 ≤ MPH ≤ 80.8 28.0 ≤ MPH ≤ 83.3 0.90 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled = not active = not active ≥ 80.0 sec 650 ≤ °C ≤ 900 = DFCO possible		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>=====</p> <p>All of the above met for at least 2.0 seconds, and then the Force Cat Rich intrusive stage is requested.</p> <p>=====</p> <p>Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders</p> <p>=====</p> <p>After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).</p>	<p>=====</p> <p>≥ 690 mvolts = DFCO active</p> <p>≤ 5 cylinders</p> <p>=====</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>O2 Heater (pre sensor) on for Learned Htr resistance</p> <p>Engine Coolant IAT Engine run Accum</p> <p>Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)</p> <p>Closed loop integral Closed Loop Active Evap Ethanol Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp</p>	<p>the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab.</p> <p>≥ 40 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>> 60 °C > -40 °C > 30 seconds</p> <p>1,100 ≤ RPM ≤ 3,500</p> <p>1,050 ≤ RPM ≤ 3,650</p> <p>2 ≤ gps ≤ 12</p> <p>37.9 ≤ MPH ≤ 80.8</p> <p>28.0 ≤ MPH ≤ 83.3</p> <p>0.90 ≤ C/L Int ≤ 1.08 = TRUE not in control of purge not in estimate mode = enabled = not active = not active ≥ 80.0 sec</p> <p>650 ≤ °C ≤ 900</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Fuel State Number of fueled cylinders ===== When above conditions are met: Fuel Enrich mode is entered. ===== During this test: Engine Airflow must stay between: and the delta Engine Airflow over 12.5msec must be :	= DFCO inhibit ≥ 1 cylinders ===== ===== 0 ≤ gps ≤ 30 ≤ 30.0 gps		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Device Control EVAP Diag. No active DTC:	Not Active "tank pull down" Not Active IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR_System FA EvapExcessPrgePsbL_FA Ethanol Comp Snsr FA FuelInjectorCkt_FA EngMisfireDetected_FA EGRValvePerf_FA EGRValveCkt_FA MAP_EngVacuumStatus AmbPresDfltStatus TC_BoostPresSnsrFA O2Snsr_B1_Snsr_1_FA		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 1	P0172	<p>Determines if the fuel control system is in a rich condition, based on the filtered long-term fuel trim metric.</p> <p>There are two methods to determine a Rich fault. They are Passive and Intrusive. A Passive Test decision can be made up until the time that purge is first enabled. From that point forward, rich faults can only be detected by turning purge off intrusively.</p> <p>Intrusive Test: If the filtered Purge Long Term Fuel Trim metric > 0.720 , the test passes without intrusively checking the filtered Non-Purge Long Term Fuel Trim metric. However if the filtered Purge Long Term Fuel Trim metric is <= 0.720 , purge is ramped off to determine if excess purge vapor is the cause of the rich condition.</p> <p>Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions,</p>	<p>Passive Test: The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>Intrusive Test: For 2 out of 3 intrusive segments, the filtered Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>Segment Def'n: Segments can last up to 35 seconds and are separated by the lesser of 30 seconds of purge-on time or enough time to</p>	<p><= 0.705</p> <p><= 2.000</p> <p><= 0.720</p> <p><= 0.705</p> <p><= 2.000</p>		<p>Secondary Parameters and Enable Conditions are identical to those for P0171, with the exception that fuel level is not considered.</p>	<p>Frequency: 100 ms Continuous Loop</p>	<p>Type B, 2 Trips</p>

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and the execution frequency of other diagnostics.	purge 18 grams of vapor. A maximum of 3 completed segments or 25 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 300 seconds to allow sufficient time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge Long Term Fuel Trim metric > 0.720 for at least 150 seconds, indicating that the canister has been purged.					

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit - (PFI)	P0201	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0261 may also set (Injector 1 Short to Ground)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit - (PFI)	P0202	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0264 may also set (Injector 2 Short to Ground)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Open Circuit - (PFI)	P0203	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0267 may also set (Injector 3 Short to Ground)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit - (PFI)	P0204	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0270 may also set (Injector 4 Short to Ground)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage <	0.250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit High	P0223	Detects a continuous or intermittent short or open in TPS2 circuit	TPS2 Voltage >	4.590		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground (PFI)	P0261	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0201 may also set (Injector 1 Open Circuit)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to power (PFI)	P0262	This DTC Diagnoses Injector 1 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground (PFI)	P0264	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0202 may also set (Injector 2 Open Circuit)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power (PFI)	P0265	This DTC Diagnoses Injector 2 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to ground (PFI)	P0267	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0203 may also set (Injector 3 Open Circuit)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to power (PFI)	P0268	This DTC Diagnoses Injector 3 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground (PFI)	P0270	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage low during driver off state indicates short- to-ground or open circuit	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0204 may also set (Injector 4 Open Circuit)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to power (PFI)	P0271	This DTC Diagnoses Injector 4 low side driver circuit for circuit faults.	Voltage high during driver on state indicates short to power	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage within range for a duration Engine Running	>= 11 Volts >= 1 Seconds >= 0 Seconds	50 failures out of 63 samples 100 ms /sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Random Misfire Detected	P0300	These DTC's will determine if a random or a cylinder specific misfire is occurring by monitoring various terms derived from crankshaft velocity. The rate of misfire over an interval is compared to both emissions and catalyst damaging thresholds. The pattern of crankshaft acceleration after the misfire is checked to differentiate between real misfire and other sources of crank shaft noise.	Crankshaft Deceleration Value(s) vs. Engine Speed and Engine load		Engine Run Time	> 2 crankshaft revolution	Emission Exceedence = any (5) failed 200 rev blocks out of (16) 200 rev block tests Failure reported for (1) Exceedence in 1st (16) 200 rev block tests, or (4) Exceedences thereafter. OR when Early Termination Reporting = Enabled and engine rev > 1,000 revs and < 3,200 revs at end of trip any Catalyst Exceedence = (1) 200 rev block as data supports for catalyst damage.	Type B, 2 Trips (Mil Flashes with Catalyst damage level of Misfire)
Cylinder 1 Misfire Detected	P0301		The equation used to calculate deceleration value is tailored to specific vehicle operating conditions. The selection of the equation used is based on the 1st single cylinder continuous misfire threshold tables encountered that are not max of range. If all tables are max of range at a given speed/load, that speed load region is an Undetectable region see Algorithm Description Document for additional details.		Engine Coolant Temp Or If ECT at startup Then ECT	-7 °C < ECT < 125 °C < -7 °C 21 °C < ECT < 125 °C		
Cylinder 2 Misfire Detected	P0302				System Voltage + Throttle delta - Throttle delta	9.00 < volts < 32.00 < 95.00 % per 25 ms < 95.00 % per 25 ms		
Cylinder 3 Misfire Detected	P0303							
Cylinder 4 Misfire Detected	P0304							
				- see details of thresholds on Supporting Tables Tab (P0300 Section)	Early Termination option: (used on plug ins that may not have enough engine run time at end of trip for normal interval to complete.)	Not Enabled		
			SINGLE CYLINDER CONTINUOUS MISFIRE((Medres_Decel Medres_Jerk	> IdleSCD_Decel AND > IdleSCD_Jerk)				
			OR (Medres_Decel Medres_Jerk	>SCD_Decel AND > SCD_Jerk)				
			OR (Lores_Decel Lores_Jerk	>IdleCyl_Decel AND > IdleCyl_Jerk)				
			OR (Lores_Decel Lores_Jerk	>CylModeDecel AND > CylModeJerk)				
			OR RevBalanceTime	>RevMode_Decel				

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Other patterns of misfire use adjustments to the single cylinder continuous misfire threshold tables:</p> <p>RANDOM MISFIRE Use random misfire thresholds If no misfire for</p>	<p>> 6 Engine Cycles</p> <p>(Medres_Decel > IdleSCD_Decel * Random_SCD_Decel AND Medres_Jerk) > IdleSCD_Jerk * Random_SCD_Jerk</p> <p>OR (Medres_Decel > SCD_Decel * Random_SCD_Decel AND Medres_Jerk) > SCD_Jerk * Random_SCD_Jerk</p> <p>OR (Lores_Decel > IdleCyl_Decel * RandomCylModDecel AND Lores_Jerk) > IdleCyl_Jerk * RandomCylModeJerk</p> <p>OR (Lores_Decel > CylModeDecel * RandomCylModDecel AND Lores_Jerk) > CylModeJerk * RandomCylModeJerk</p> <p>OR RevBalanceTime > RevMode_Decel * RandomRevModDecl</p>			<p>Catalyst Failure reported with (1 or 3) Exceedences in FTP, or (1) Exceedence outside FTP.</p> <p>Continuous</p>	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>PAIRED CYLINDER MISFIRE If a cylinder & it's pair are above PAIR thresholds</p> <p>(Medres_Decel</p> <p style="padding-left: 40px;">AND</p> <p style="padding-left: 40px;">Medres_Jerk)</p> <p>OR (Medres_Decel</p> <p style="padding-left: 40px;">AND</p> <p style="padding-left: 40px;">Medres_Jerk)</p> <p>OR (Lores_Decel</p> <p style="padding-left: 40px;">AND</p> <p style="padding-left: 40px;">Lores_Jerk)</p> <p>OR (Lores_Decel</p> <p style="padding-left: 40px;">AND</p> <p style="padding-left: 40px;">Lores_Jerk)</p> <p>OR (Revmode Active AND (within one engine cycle: 2nd largest Lores_Decel)</p> <p style="padding-left: 40px;">AND</p> <p style="padding-left: 40px;">Above TRUE for)</p>	<p>> IdleSCD_Decel * Pair_SCD_Decel</p> <p>> IdleSCD_Jerk * Pair_SCD_Jerk</p> <p>> SCD_Decel * Pair_SCD_Decel</p> <p>> SCD_Jerk * Pair_SCD_Jerk</p> <p>> IdleCyl_Decel * PairCylModeDecel</p> <p>> IdleCyl_Jerk * PairCylModeJerk</p> <p>> CylModeDecel * PairCylModeDecel</p> <p>> CylModeJerk * PairCylModeJerk</p> <p>> CylModeDecel * PairCylModeDecel</p> <p>> 80 engine cycles out of 100 engine cycles</p>				

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>BANK MISFIRE Cylinders above Bank Thresholds</p> <p>(Medres_Decel</p> <p>AND Medres_Jerk)</p> <p>OR (Medres_Decel</p> <p>AND Medres_Jerk)</p> <p>OR (Lores_Decel</p> <p>AND Lores_Jerk)</p> <p>OR (Lores_Decel</p> <p>AND Lores_Jerk)</p> <p>CONSECUTIVE CYLINDER MISFIRE 1st cylinder uses single cyl continuous misfire thresholds; 2nd Cylinder uses:</p> <p>(Medres_Decel</p>	<p>>= 3 cylinders</p> <p>> IdleSCD_Decel * Bank_SCD_Decel</p> <p>> IdleSCD_Jerk * Bank_SCD_Jerk</p> <p>> SCD_Decel * Bank_SCD_Decel</p> <p>> SCD_Jerk * Bank_SCD_Jerk</p> <p>> IdleCyl_Decel * BankCylModeDecel</p> <p>> IdleCyl_Jerk * BankCylModeJerk</p> <p>> CylModeDecel * BankCylModeDecel</p> <p>> CylModeJerk * BankCylModeJerk</p> <p>> IdleSCD_Decel * ConsecSCD_Decel</p>				

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>AND Medres_Jerk)</p> <p>OR (Medres_Decel</p> <p>AND Medres_Jerk)</p> <p>OR (Lores_Decel</p> <p>AND Lores_Jerk)</p> <p>OR (Lores_Decel</p> <p>AND Lores_Jerk)</p> <p>CYLINDER DEACTIVATION MODE (Active Fuel Managment)</p> <p>AFM: SINGLE CYLINDER CONTINUOUS MISFIRE (CylAfterDeacCyl_Decel</p> <p>AND CylAfterDeacCyl_Jerk)</p> <p>OR</p>	<p>> IdleSCD_Jerk * ConsecSCD_Jerk</p> <p>> SCD_Decel * ConsecSCD_Decel</p> <p>> SCD_Jerk * ConsecSCD_Jerk</p> <p>> IdleCyl_Decel * ConsecCylModDecel</p> <p>> IdleCyl_Jerk * ConsecCylModeJerk</p> <p>> CylModeDecel * ConsecCylModDecel</p> <p>> CylModeJerk * ConsecCylModeJerk</p> <p>> CylModeDecel * ClyAfterAFM_Decel</p> <p>> CylModeJerk * CylAfterAFM_Jerk</p> <p>> CylModeDecel *</p>				

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			(CylBeforeDeacCylDecel AND CylBeforeDeacCyl_Jerk)	CylBeforeAFM_Decel > CylModeJerk * ClyBeforeAFM_Jerk				
		AFM: RANDOM MISFIRE Use random misfire thresholds If no misfire for	(CylAfterDeacCyl_Decel AND CylAfterDeacCyl_Jerk)	> 6 Engine Cycles > CylModeDecel * ClyAfterAFM_Decel * RandomAFM_Decl > CylModeJerk * CylAfterAFM_Jerk * RandomAFM_Jerk				
			(CylBeforeDeacCylDecel AND CylBeforeDeacCyl_Jerk)	> CylModeDecel * ClyAfterAFM_Decel * RandomAFM_Decl > CylModeJerk * CylAfterAFM_Jerk * RandomAFM_Jerk				
				- see details on Supporting Tables Tab (P0300 Section)				
		Misfire Percent Emission Failure Threshold		≥ 1.21 % P0300				

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Misfire Percent Catalyst Damage</p> <p>When engine speed and load are less than the FTP calcs (3) catalyst damage exceedences are allowed.</p>	<p>> Catalyst_Damage_Misfire_Percentage in Supporting Tables whenever secondary conditions are met.</p> <p>≤ 0 FTP rpm AND ≤ 0 FTP % load</p> <p>disable conditions:</p>	<p>(at low speed/loads, one cylinder may not cause cat damage)</p> <p>Engine Speed Engine Load Misfire counts</p> <p>Engine Speed</p> <p>No active DTCs:</p>	<p>> 1,500 rpm AND > 20 % load AND < 180 counts on one cylinder</p> <p>500 < rpm < ((Engine Over Speed Limit) - 400)</p> <p>Engine speed limit is a function of inputs like Gear and temperature</p> <p>see EngineOverSpeedLimit in supporting tables</p> <p>TPS_FA EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO ECT_Sensor_Ckt_TFTKO 5VoltReferenceB_FA CrankSensorTFTKO CrankSensorFA</p>	<p>4 cycle delay</p> <p>4 cycle delay</p>	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						CamLctnIntFA CamLctnExhFA CamSensorAnyLctnTFTK O AnyCamPhaser_FA AnyCamPhaser_TFTKO AmbPresDfltStatus		
					P0315 & engine speed	> 1,000 rpm	4 cycle delay	
					Fuel Level Low	LowFuelConditionDiagnostic	500 cycle delay	
					Cam and Crank Sensors	in sync with each other	4 cycle delay	
					Misfire requests TCC unlock	Not honored because Transmission in hot mode or POPD intrusive diagnostic running	4 cycle delay	
					Fuel System Status	≠ Fuel Cut	4 cycle delay	
					Active FuelManagement	Transition in progress	0 cycle delay	
					Undetectable engine speed and engine load region	Undetectable region from Malfunction Criteria	4 cycle delay	
					Abusive Engine Over Speed	> 8,192 rpm	0 cycle delay	
					Below zero torque (except CARB approved 3000 rpm to redline triangle.)	< ZeroTorqueEngLoad in Supporting Tables	4 cycle delay	
					Below zero torque: TPS Vehicle Speed	≤ 1 % > 318 mph	4 cycle delay	
					EGR Intrusive test	Active	0 cycle delay	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Manual Trans</p> <p>Accel Pedal Position AND Automatic transmission shift</p> <p>After Fuel resumes on Automatic shift containing Fuel Cut</p> <p>DRIVELINE RING FILTER After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.</p> <p>Filter Driveline ring:</p> <p>Stop filter early:</p> <p>ABNORMAL ENGINE SPEED OSCILLATION: (checks each "misfire" candidate in 100 engine Cycle test to see if it looks like some disturbance like rough road (abnormal).)</p> <p>Used Off Idle, and while not shifting,</p>	<p>Clutch shift</p> <p>> 98.00 %</p> <p>> "Ring Filter" # of engine cycles after misfire in Supporting Tables</p> <p>> "Number of Normals" # of engine cycles after misfire in Supporting Tables tab</p> <p>TPS > 3 % Engine Speed > 1,000 rpm Veh Speed > 3 mph Auto Transmission not shifting</p>	<p>0 cycle delay</p> <p>7 cycle delay</p> <p>2 Cylinder delay</p>	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>individual candidate deemed abnormal if number of consecutive decelerating cylinders after "misfire": (Number of decels can vary with misfire detection equation)</p> <p>Consecutive decels while in SCD Mode Cyl Mode Rev Mode</p> <p>At the end of 100 engine cycle test, the ratio of abnormal/candidate is checked to confirm if real misfire is present within the 100 engine cycles.</p> <p>abnormal candidates/ total candidates</p> <p>MISFIRE CRANKSHAFT PATTERN RECOGNITION checks each "misfire" candidate in 100 engine Cycle test to see if overall crankshaft pattern looks like real misfire (recognized), or some disturbance like rough road (unrecognized).</p>	<p>> Abnormal SCD Mode > Abnormal Cyl Mode > Abnormal Rev Mode in Supporting Tables</p> <p>> 0.50 ratio</p>	<p>discard 100 engine cycle test</p>	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present within the 100 engine cycles. Typically used for checking a single misfire per engine cycle but can support some other patterns on some packages</p> <p>Pattern Recog Enabled:</p> <p>Pattern Recog Enabled during Cylinder Deac</p> <p>Pattern Recog Enabled consecutive cyl patrn</p> <p>Engine Speed Veh Speed</p> <p>The 1st check for "recognized" is the 1st fired cylinder after the misfire candidate should both accelerate and jerk an amount based acceleration and jerk of Single Cylinder Misfire thresholds in effect at that speed and load.</p> <p>(CylAfter_Accel AND CylAfter_Jerk)</p>	<p>Enabled</p> <p>Not Enabled</p> <p>Enabled</p> <p>500 < rpm < 6,000 > 3.1 mph</p> <p>> Misfire_decel * 1st_FireAftrMisfr_Acel</p> <p>> Misfire_Jerk * 1st_FireAftrMisfr_Jerk</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Additionally, the crankshaft is checked again a small calibratable number of cylinders later to see if the disturbance is still large like rough road, or has calmed down like real misfire. The size of disturbance is compared to a multiplier times the ddt_jerk value used to detect misfire at that speed and load. If there is repetitive misfire on consecutive engine cycles, the expected snap is adjusted due to the higher expected disturbance.</p> <p>Num of Cylinders after misfire to start check of crankshaft snap</p> <p>"misfire" recognized if: Crankshaft snap after: isolated "misfire"</p> <p>repetative "misfire"</p> <p>At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present.</p> <p>Ratio of Unrecog/Recog</p>	<p>2 Cylinders</p> <p>< Misfire_Jerk * SnapDecayAfterMisfire</p> <p>< Misfire_Jerk * SnapDecayAfterMisfire * RepetSnapDecayAdjst in Supporting Tables</p>	<p>discard 100 engine cycle test</p>	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					: NON-CRANKSHAFT BASED ROUGH ROAD: Rough Road Source IF Rough Road Source = WheelSpeedInECM ABS/TCS Wheel speed noise VSES IF Rough Road Source = "FromABS" ABS/TCS RoughRoad VSES IF Rough Road Source = "TOSS" TOSS dispersion AND No Active DTCs	Disabled TOSS active > WSSRoughRoadThres active active detected active > TOSSRoughRoadThres in supporting tables Transmission Output Shaft Angular Velocity Validity TransmissionEngagedStat e_FA (Auto Trans only) Clutch Sensor FA (Manual Trans only)	discard 100 engine cycle test discard 100 engine cycle test discard 100 engine cycle test 4 cycle delay	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position System Variation Not Learned	P0315	Monitor for valid crankshaft error compensation factors	Sum of Compensation factors. Each Cylinder pair shares one compensation factor. A perfect factor would be 1.0000. Unlearned factors are defaulted out of range so the sum of factors would be out of range.	≥ 2.0040 OR ≤ 1.9960	OBD Manufacturer Enable Counter	MEC = 0	0.50 seconds Frequency Continuous100 msec	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Knock Sensor (KS) Performance Per Cylinder	P0324	This diagnostic checks for knock sensor performance out of the normal expected range on a per cylinder basis due to: 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria (Applies to all 3 parts of the performance diag)		Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow ECT IAT	Yes ≥ 2.0 seconds ≤ 8,500 RPM ≥ 40 mg/cylinder and ≤ 2,000 mg/cylinder ≥ -40 deg's C ≥ -40 deg's C	First Order Lag Filters with Weight Coefficients	Type B, 2 Trips	
			Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag: -----						
			1. Excessive Knock Diag: Filtered Knock Intensity VaKNKD_k_PerfCylKnock IntFilt (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock) -----	> 2.00 (no units)	Engine Speed Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 570 RPM ≥ 100 Revs			Excessive Knk Weight Coefficient = 0.0400 Updated each engine event
2. Abnormal Noise Diag: Filtered FFT Intensity (where 'FFT Intensity' = Non-knocking, background noise)	< AbnormalNoise_Thre shold (see Supporting Tables)	Individual Cylinders enabled for Abnormal Noise Engine Speed Cumulative Number of Engine Revs Above Min Eng Speed (per key	See AbnormalNoise_ CylsEnabled (Supporting Tables) ≥ 8,500 RPM ≥ 400 Revs	Abn Noise Weight Coefficient = 0.0100 Updated each engine event					

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			----- 3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock) VaKNKD_k_PerfCylFlatFil tInt	< 0.008 (no units)	cycle) ----- Engine Speed Cumulative Number of Engine Revs Above Min Eng Speed (per keycycle)	----- ≥ 8,500 RPM ≥ 400 Revs	----- Flat Signal Weight Coefficient = 0.010 Updated each engine event	

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 1	P0325	<p>This diagnostic checks for an open in the knock sensor circuit.</p> <p>There are two possible methods used:</p> <ol style="list-style-type: none"> 1. 20 kHz 2. Normal Noise <p>See Supporting Tables for method definition: P0325_P0330_OpenMethod</p> <p>Typical implementations:</p> <ol style="list-style-type: none"> A. Use 20 kHz method at all RPM (used when acceptable separation achieved at all RPM) or B. Use 20 kHz method at low/medium RPM and Normal Noise at high RPM 	Filtered FFT Output	<p>> OpenCktThrshMin and < OpenCktThrshMax</p> <p>See Supporting Tables</p> <p>Thresholds for OpenMethod = 20 kHz: OpenCktThrshMin (20 kHz) & OpenCktThrshMax (20 kHz)</p> <p>Thresholds for OpenMethod = NormalNoise: OpenCktThrshMin (Normal Noise) & OpenCktThrshMax (Normal Noise)</p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)</p> <p>Engine Air Flow</p> <p>ECT</p> <p>IAT</p>	<p>Yes</p> <p>≥ 2.0 seconds</p> <p>≥ 600 RPM and ≤ 8,500 RPM</p> <p>≥ 100 revs</p> <p>≥ 40 mg/cylinder and ≤ 2,000 mg/cylinder</p> <p>≥ -40 deg's C</p> <p>≥ -40 deg's C</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p>Weight Coefficient = 0.0100</p> <p>Updated each engine event</p>	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Knock Sensor (KS) Performance Bank 1	P0326	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis, due to 1. Excessive knock or 2. Abnormal engine noise or 3. Flat signal	Common Enable Criteria (Applies to all 3 parts of the performance diag)		Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow ECT IAT	Yes ≥ 2.0 seconds ≤ 8,500 RPM ≥ 40 mg/cylinder and ≤ 2,000 mg/cylinder ≥ -40 deg's C ≥ -40 deg's C	First Order Lag Filters with Weight Coefficients	Type B, 2 Trips	
			Specific Enable Criteria and Thresholds for 3 individual parts of the performance diag:						
			1. Excessive Knock Diag: Filtered Knock Intensity (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)	> 2.00 (no units)	Engine Speed Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	≥ 8,500 RPM ≥ 100 Revs			Excessive Knk Weight Coefficient = 0.0100 Updated each engine event
2. Abnormal Noise Diag: Filtered FFT Intensity: (where 'FFT Intensity' = Non-knocking, background noise)	< AbnormalNoise_Threshold (see Supporting Tables)	Individual Cylinders enabled for Abnormal Noise Engine Speed Cumulative Number of Engine Revs Above Min Eng Speed (per key	See AbnormalNoise_CylsEnabled (Supporting Tables) ≥ 3,500 RPM ≥ 100 Revs	Abnormal Noise Weight Coefficient = 0.0100 Updated each engine event					

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			----- 3. Flat Signal Diag: Filtered Signal Delta (Current FFT Intensity - Ave_Intensity_No-Knock)	----- < 0.008 (no units)	cycle) ----- Engine Speed Cumulative Number of Engine Revs Above Min Eng Speed (per keycycle)	----- ≥ 8,500 RPM ≥ 100 Revs	----- Flat Signal Weight Coefficient = 0.010 Updated each engine event	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 1	P0327	This diagnostic checks for an out of range low knock sensor signal	Sensor Input or Return Signal Line	< 8.0 Percent (of 5 V reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 1	P0328	This diagnostic checks for an out of range high knock sensor signal	Sensor Input or Return Signal Line	> 39.0 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Circuit	P0335	Determines if a fault exists with the crank position sensor signal	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	Starter engaged AND (cam pulses being received OR (MAF_SensorFA AND Engine Air Flow	= FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			No crankshaft pulses received	>= 1.0 seconds	Engine is Running Starter is not engaged	Continuous every 12.5 msec		
			No crankshaft pulses received		Engine is Running OR Starter is engaged No DTC Active:	P0365 P0366	2 failures out of 10 samples One sample per engine revolution	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Performance	P0336	Determines if a performance fault exists with the crank position sensor signal	Time in which 10 or more crank re-synchronizations occur	< 10.0 seconds	Engine Air Flow Cam-based engine speed No DTC Active:	>= 3.0 grams/second > 450 RPM P0335	Continuous every 250 msec	Type B, 2 Trips
			No crankshaft synchronization gap found	>= 0.4 seconds	Engine is Running Starter is not engaged		Continuous every 12.5 msec	
			Time since starter engaged without detecting crankshaft synchronization gap	>= 1.5 seconds	Starter engaged AND (cam pulses being received OR (MAF_SensorFA AND Engine Air Flow	= FALSE > 3.0 grams/second))	Continuous every 100 msec	
			Crank pulses received in one engine revolution OR Crank pulses received in one engine revolution	< 51 > 65	Engine is Running OR Starter is engaged No DTC Active:	P0365 P0366	8 failures out of 10 samples One sample per engine revolution	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor A	P0340	Determines if a fault exists with the cam position bank 1 sensor A signal	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (crank pulses being received OR (MAF_SensorFA AND Engine Air Flow	= FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips	
			OR						
			Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds					
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged		Continuous every 100 msec		
			No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	CrankSensor_FA	Continuous every MEDRES event		
The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle					

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor A	P0341	Determines if a performance fault exists with the cam position bank 1 sensor A signal	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 OR > 10	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 OR > 402	Crankshaft is synchronized No DTC Active:	CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT	P0351	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	≥ 30 k Ω impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT	P0352	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	≥ 30 k Ω impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT	P0353	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	≥ 30 k Ω impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT	P0354	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	≥ 30 k Ω impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor B	P0365	Determines if a fault exists with the cam position bank 1 sensor B signal	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (crank pulses being received OR (MAF_SensorFA AND Engine Air Flow	= FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips	
			OR						
			Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds					
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged		Continuous every 100 msec		
			No camshaft pulses received during first 12 MEDRES events (There are 12 MEDRES events per engine cycle		Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	CrankSensor_FA	Continuous every MEDRES event		
The number of camshaft pulses received during 100 engine cycles	= 0	Crankshaft is synchronized No DTC Active:	CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle					

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor B	P0366	Determines if a performance fault exists with the cam position bank 1 sensor B signal	The number of camshaft pulses received during first 12 MEDRES events is OR (There are 12 MEDRES events per engine cycle)	< 4 OR > 10	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	CrankSensorFA	Continuous every MEDRES event	Type B, 2 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 OR > 402	Crankshaft is synchronized No DTC Active:	CrankSensorFA	8 failures out of 10 samples Continuous every engine cycle	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420	<p>NOTE: The information contained below applies to applications that use the Idle Catalyst Monitor Algorithm</p> <p>The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Lean and Rich A/F excursions</p> <p>Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration table (based on temp and exhaust gas flow)</p>	Normalized Ratio OSC Value (EWMA filtered)	< 0.32	<p>There must be a valid idle period. The criteria are:</p> <p>Driver must be off the accel pedal. This checks that the final accel pedal position (comprehending deadband and hysteresis) is essentially zero.</p> <p>Idle Speed Control System Is Active</p> <p>Vehicle Speed</p> <p>Engine speed</p> <p>Engine run time</p> <p>Tests attempted this trip</p> <p>The catalyst diagnostic has not yet completed for the current trip.</p> <p>Catalyst Idle Conditions Met Criteria is satisfied which includes the General Enable met and the Valid Idle Period</p>	<p>< 1.24 MPH</p> <p>> 1,050 RPM for a minimum of 5 seconds since end of last idle period.</p> <p>> CatmonMinEngineRunTimeToEnable This is a function of Coolant Temperature, please see "Supporting Tables" for details.</p> <p>< 255</p>	<p>1 test attempted per valid idle period</p> <p>Minimum of 1 test per trip</p> <p>Maximum of 8 tests per trip</p> <p>Frequency: Fueling Related : 12.5 ms</p> <p>OSC Measurements: 100 ms</p> <p>Temp Prediction: 12.5ms</p>	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>3. WorstPassing OSC value (based on temp and exhaust gas flow)</p> <p>Normalized Ratio Calculation = (1-2) / (3-2)</p> <p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part. The Catalyst Monitoring Test is done during idle. Several conditions must be met in order to execute this test. These conditions and their related values are listed in the secondary parameters area of this document.</p> <p>Refer to the P0420_WorstPassing OSCTableB1 and P0420_BestFailingOSCTableB1 table in the Supporting Tables tab for details</p>			<p>Criteria met, as well as:</p> <p>Green Converter Delay</p> <p>Induction Air</p> <p>Intrusive test(s): Fueltrim Post O2 EVAP EGROther vehicle functions:</p> <p>Power Take Off RunCrank Voltage Ethanol Estimation</p> <p>ECT</p> <p>Barometric Pressure</p> <p>Idle Time before going intrusive is</p> <p>Idle time is incremented if Vehicle speed</p> <p>Short Term Fuel Trim</p>	<p>Not Active</p> <p>> -20 ° C < 250 ° C</p> <p>Not Active</p> <p>Not Active > 10.90 Volts NOT in Progress</p> <p>> 40 ° C < 126 ° C</p> <p>> 70 KPA</p> <p>< 50 Seconds</p> <p>< 1.24 MPH and the drivers foot is off accel pedal and the idle speed control system is active as identified in the Valid Idle Period Criteria section.</p> <p>> 0.80 < 1.25</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed loop fueling (Please see "Closed Loop Enable Criteria" section of the "Supporting Tables" tab for details.) PRNDL Idle Stable Criteria: MAF Predicted catalyst temperature Engine Fueling Criteria at Beginning of Idle Period The following fueling related must also be met from between 4 and 7 seconds after the Catalyst Idle Conditions Met Criteria has been met for at least 4 seconds prior to allowing intrusive control: Number of pre-O2 switches Short Term Fuel Trim Avg Rapid Step Response	Enabled in Drive Range on an Auto Transmission vehicle. Must hold true from after Catalyst Idle Conditions Met to the end of test > 1.29 g/s < 10.00 g/s < 900 degC >= 2 > 0.96 < 1.04		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>(RSR) feature will initiate multiple tests:</p> <p>If the difference between current EWMA value and the current OSC Normalized Ratio value is</p> <p>and the current OSC Normalized Ratio value is</p> <p>Maximum RSR tests to detect failure when RSR is enabled.</p> <p>The diagnostic will not be enabled until the following has been met:</p> <p>PTO</p> <p>General Enable DTC's Not Set</p>	<p>> 0.44</p> <p><0.10</p> <p>24</p> <p>Not Active</p> <p>MAF_SensorFA MAF_SensorTFTKO AmbPresDfltStatus IAT_SensorCircuitFA IAT_SensorCircuitTFTKO ECT_Sensor_FA O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA FuelTrimSystemB1_FA FuelTrimSystemB1_TFTKO</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						FuelTrimSystemB2_FA FuelTrimSystemB2_TFTK O EngineMisfireDetected_FA EvapPurgeSolenoidCircuit_FA IAC_SystemRPM_FA EGRValvePerformance_FA EGRValveCircuit_FA CamSensorAnyLocationFA CrankSensorFA TPS_Performance_FA EnginePowerLimited		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>the pressure drops (-62.27) Pa from peak pressure, the vent is then opened for 60 seconds to normalize the system pressure. The vent is again closed to begin the vacuum portion of the test (phase-2). As the fuel temperature continues to fall, a vacuum will begin forming. The vacuum will continue until it reaches a vacuum peak. When the pressure rises 62.27 Pa from vacuum peak, the test then completes. If the key is turned on while the diagnostic test is in progress, the test will abort.</p>			<p>Startup delta deg C (ECT-IAT)</p> <p>OR</p> <p>2. Short Soak and Previous EAT Valid</p> <p>Previous time since engine off</p> <p>OR</p> <p>3. Less than a short soak and Previous EAT Not Valid</p> <p>Previous time since engine off</p> <p>AND</p> <p>Vehicle Speed</p> <p>AND</p> <p>Mass Air Flow</p> <p>Must expire Estimate of Ambient Temperature Valid Conditioning Time. P0442: Estimate of Ambient Temperature Valid Conditioning Time Table in Supporting Tables.</p> <p>OR</p> <p>4. Not a Cold Start and greater than a Short Soak</p> <p>Previous time since engine off</p> <p>AND</p> <p>Vehicle Speed</p> <p>AND</p> <p>Mass Air Flow</p>	<p>≤ 8 °C</p> <p>≤ 7,200 seconds</p> <p>≤ 7,200 seconds</p> <p>≥ 32 mph</p> <p>≥ 7 g/sec</p> <p>> 7,200 seconds</p> <p>≥ 32 mph</p> <p>≥ 7 g/sec</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Must expire maximum value in Estimate of Ambient Temperature Valid Conditioning Time. Please see P0442: Estimate of Ambient Temperature Valid Conditioning Time in Supporting Tables.</p> <p>*****</p> <p>1. High Fuel Volatility</p> <p>During the volatility phase, pressure in the fuel tank is integrated vs. volatility time. If the integrated pressure is then test aborts and unsuccessful attempts is incremented. This value equates to an average integrated fuel tank pressure > 1,245 Pa. Please see P0442: Volatility Time as a Function of Estimate of Ambient Temperature in Supporting Tables.</p> <p>OR</p> <p>2. Vacuum Refueling Detected</p> <p>See P0454 Fault Code for information on vacuum refueling algorithm.</p> <p>OR</p> <p>3. Fuel Level Refueling</p>	<p>*****</p> <p>< -5</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Detected</p> <p>See P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>4. Vacuum Out of Range and No Refueling</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>5. Vacuum Out of Range and Refueling Detected</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>6. Vent Valve Override Failed</p> <p>Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test</p> <p>OR</p> <p>7. Key up during EONV test</p>	<p>0.50 seconds</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs:	MAF_SensorFA ECT_Sensor_FA IAT_SensorFA VehicleSpeedSensor_FA IgnitionOffTimeValid AmbientAirDefault P0443 P0446 P0449 P0452 P0453 P0455 P0496		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Circuit (ODM) (No ELCP - Conventional EVAP Diagnostic - For 3 DTC Implementati on Only)	P0443	Diagnoses the canister purge solenoid low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0458 may also set (Caniste r Purge Solenoid Short to Ground)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent System Performance (No ELCP - Conventional EVAP Diagnostic)	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister. This test runs with normal purge and vent valve is open.	Vent Restriction Prep Test: Vented Vacuum for OR Vented Vacuum for Vent Restriction Test: Tank Vacuum for before Purge Volume After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time.	< -623 Pa 60 seconds > 1,245 Pa 60 seconds > 2,989 Pa 5 seconds ≥ 10 liters	Fuel Level System Voltage Startup IAT Startup ECT BARO No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C ≥ 70 kPa MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454	Once per Cold Start Time is dependent on driving conditions Maximum time before test abort is 1,000 seconds	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM) (No ELCP - Conventional EVAP Diagnostic - For 3 DTC Implementati on Only)	P0449	Diagnoses the vent solenoid low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground			20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0498 may also set (Vent Solenoid Short to Ground)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Performance (No ELCP - Conventional EVAP Diagnostic)	P0451	The DTC will be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test.	<p>The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts)</p> <p>Upper voltage threshold (voltage addition above the nominal voltage)</p> <p>Lower voltage threshold (voltage subtraction below the nominal voltage)</p> <p>The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail).</p> <p>When EWMA is</p> <p>the DTC light is illuminated.</p> <p>The DTC light can be turned off if the EWMA is</p> <p>and stays below the EWMA fail threshold for 3 additional consecutive trips.</p>	<p>0.2 volts</p> <p>0.2 volts</p> <p>> 0.73 (EWMA Fail Threshold),</p> <p>≤ 0.40 (EWMA Re-Pass Threshold)</p>	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.	Type A, 1 Trips EWMA Average run length: 6 Run length is 2 trips after code clear or non-volatile reset

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage (No ELCP - Conventional EVAP Diagnostic)	P0452	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too low out of range.	FTP sensor signal The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~3736 Pa).	< 0.15 volts (3.0 % of Vref or ~ 1,681 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit High Voltage (No ELCP - Conventional EVAP Diagnostic)	P0453	This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too high out of range.	FTP sensor signal The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~ -3736 Pa).	> 4.85 volts (97 % of Vref or ~ -4,172 Pa)	Time delay after sensor power up for sensor warm-up is	0.10 seconds	640 failures out of 800 samples 12.5 ms / sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Intermittent (No ELCP - Conventional EVAP Diagnostic)	P0454	This DTC will detect intermittent tank vacuum sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	If an abrupt change in tank vacuum is detected the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that a refueling event occurred. If a refueling is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An abrupt change is defined as a change in vacuum: in the span of 1.0 seconds. But in 12.5 msec. A refueling event is confirmed if the fuel level has a persistent change of for 30 seconds during a 600 second refueling rationality test.	> 112 Pa < 249 Pa > 10 %	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes and the canister vent solenoid is closed		This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures. 12.5 ms / sample	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Large Leak Detected (No ELCP - Conventional EVAP Diagnostic)	P0455	This DTC will detect a weak vacuum condition (large leak or purge blockage) in the EVAP system. Purge valve is controlled (to allow purge flow) and vent valve is commanded closed.	Purge volume while Tank vacuum After setting the DTC for the first time, 2 liters of fuel must be consumed before setting the DTC for the second time. Weak Vacuum Follow-up Test (fuel cap replacement test) Weak Vacuum Test failed. Passes if tank vacuum Note: Weak Vacuum Follow-up Test can only report a pass.	> 10 liters $\leq 2,740$ Pa $\geq 2,740$ Pa	Fuel Level System Voltage BARO Purge Flow No active DTCs: Cold Start Test If ECT > IAT, Startup temperature delta (ECT-IAT): Cold Test Timer Startup IAT Startup ECT Weak Vacuum Follow-up Test This test can run following a weak vacuum failure or on a hot restart.	10 % \leq Percent \leq 90 % 11 volts \leq Voltage \leq 32 volts ≥ 70 kPa ≥ 4.50 % MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454 ≤ 8 °C $\leq 1,000$ seconds 4 °C \leq Temperature ≤ 30 °C ≤ 35 °C	Once per cold start Time is dependent on driving conditions Maximum time before test abort is 1,000 seconds Weak Vacuum Follow-up Test With large leak detected, the follow-up test is limited to 1,300 seconds. Once the MIL is on, the follow-up test runs indefinitely.	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit Low (No ELCP - Conventional EVAP Diagnostic)	P0458	Diagnoses the canister purge solenoid low side driver circuit for circuit faults	Voltage low during driver off state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0443 may also set (Caniste r Purge Solenoid Open Circuit)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit High (No ELCP - Conventional EVAP Diagnostic)	P0459	Diagnoses the canister purge solenoid low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	PT Relay Voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance (For use on vehicles with a single fuel tank)	P0461	This DTC will detect a fuel sender stuck in range in the primary fuel tank.	Delta fuel volume change over an accumulated 186 miles.	< 3 liters	Engine Running No active DTCs:	VehicleSpeedSensor_FA	250 ms / sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Low Voltage	P0462	This DTC will detect a fuel sender stuck out of range low in the primary fuel tank.	Fuel level Sender % of 5V range	< 10 %			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit High Voltage	P0463	This DTC will detect a fuel sender stuck out of range high in the primary fuel tank.	Fuel level Sender % of 5V range	> 60 %			100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Intermittent (No ELCP - Conventional EVAP Diagnostic)	P0464	This DTC will detect intermittent fuel level sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.	<p>If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, if a refueling event is not confirmed, then the test sample is considered failing which indicates an intermittent signal problem.</p> <p>An intermittent fuel level signal problem is defined as:</p> <p>The fuel level changes by and does not remain for 30 seconds during a 600 second refueling rationality test.</p>	<p>> 10 % > 10 %</p>	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		<p>This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.</p> <p>100 ms / sample</p>	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Open (ODM) (Not used on EREV)	P0480	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controllers P0691 may also set (Fan 1 Short to Ground).

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Open (ODM)	P0481	Diagnoses the cooling fan 2 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controllers P0693 may also set (Fan 2 Short to Ground)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Flow During Non- Purge (No ELCP - Conventional EVAP Diagnostic)	P0496	This DTC will determine if the purge solenoid is leaking to engine manifold vacuum. This test will run with the purge valve closed and the vent valve closed.	Tank Vacuum for Test time	> 2,491 Pa 5 seconds ≤ refer to P0496: Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level Table in Supporting Tables.	Fuel Level System Voltage BARO Startup IAT Startup ECT Engine Off Time No active DTCs:	10 % ≤ Percent ≤ 90 % 11 volts ≤ Voltage ≤ 32 volts ≥ 70 kPa 4 °C ≤ Temperature ≤ 30 °C ≤ 35 °C ≥ 28,800.0 seconds MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454	Once per cold start Cold start: max time is 1,000 seconds	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit Low (No ELCP - Conventional EVAP Diagnostic)	P0498	Diagnoses the vent solenoid low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground			20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0449 may also set (Vent Solenoid Open Circuit)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit High (No ELCP - Conventional EVAP Diagnostic)	P0499	Diagnoses the vent solenoid low side driver circuit for circuit faults. If the P0499 is active, an intrusive test is performed with the vent solenoid commanded closed for 15 seconds.	Voltage low during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power			20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Output Speed Sensor (TOSS)	P0502	No activity in the TOSS circuit	TOSS Raw Speed	≤ 60 RPM	Engine Torque Minimum Throttle opening Engine Speed Ignition voltage PTO EngineTorquereInaccurate	90.0 ≤ N-M ≤ 8,191.8 ≥ 8.0 % 1,500 ≤ RPM ≤ 6,500 9.0 ≤ Volts ≤ 18.00 not active KeETQC_b_MinTransRemedial = TRUE: MSFR_b_EngMisfDtctd_FA, MAFR_b_MAF_SnsrTFTKO, MAPR_b_MAP_SnsrTFTKO KeETQC_b_MinTransRemedial = FALSE: FULR_b_FuellnjCkt_TFTKO, MAFR_b_MAF_SnsrTFTKO, XOYR_b_SecurityFlt,	≥ 4.5 sec	Type X, No MIL
					P0503	Not failed this key cycle		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Output Speed Sensor (TOSS)	P0503	TOSS Signal Intermittent	Loop-to-Loop change in TOSS	≥ 350 RPM	Raw Output Speed Output Speed change Time since transfer case range change Ignition voltage Engine Speed Vehicle Speed PTO	> 200 RPM for ≥ 2.0 sec ≤ 150 RPM for ≥ 2.0 sec ≥ 6.0 sec $9.0 \leq$ Volts ≤ 18.00 $200 \leq$ RPM $\leq 7,500$ for ≥ 5.0 seconds ≤ 200.00 MPH for ≥ 5.0 sec not active	≥ 3.3 sec	Type X, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Low Engine Speed Idle System	P0506	This DTC will determine if a low idle exists	Filtered Engine Speed Error	> 91.00 rpm	Baro	> 70 kPa	Diagnostic runs in every 12.5 ms loop	Type B, 2 Trips
			filter coefficient	0.00300	Coolant Temp	> KeSPDD_T_EnblECT_Mi n (60 °C) and < KfECTI_T_EngCoolHotHi Thresh (125 °C) Must verify KfECTI_T_EngCoolHotLo Thresh (120) is less than KfECTI_T_EngCoolHotHi Thresh (125)		
					Engine run time	≥ 60 sec		
					Ignition voltage	32 ≥ volts ≥ 11		
					Time since gear change	≥ 3 sec		
					Time since a TCC mode change	> 3 sec		
					IAT	> -20 °C		
					Vehicle speed	≤ 1.24 mph		
					Commanded RPM delta	≤ 25 rpm		
					Idle time	> 10 sec		
					For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 88.00 pct < 25.00 pct		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	PTO not active Transfer Case not in 4WD LowState Off-vehicle device control (service bay control) must not be active. following conditions not TRUE: (VeTESR_e_EngSpdReqI ntvType = CeTESR_e_EngSpdMinLi mit AND VeTESR_e_EngSpdReqR espType = CeTESR_e_NoSuggestio n) Clutch is not depressed TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A IgnitionOutputDriver FA		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFault LowFuelConditionDiagnos tic Clutch Sensor FA AmbPresDfIttdStatus P2771 > 10 sec The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Engine Speed Idle System	P0507	This DTC will determine if a high idle exists	Filtered Engine Speed Error filter coefficient	< -182.00 rpm 0.00300	Baro Coolant Temp Engine run time Ignition voltage Time since gear change Time since a TCC mode change IAT Vehicle speed Commanded RPM delta For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa > KeSPDD_T_EnbIECT_Mi n (60 °C) and < KfECTI_T_EngCoolHotHi Thresh (125 °C) Must verify KfECTI_T_EngCoolHotLo Thresh (120) is less than KfECTI_T_EngCoolHotHi Thresh (125) ≥ 60 sec 32 ≥ volts ≥ 11 ≥ 3 sec > 3 sec > -20 °C ≤ 1.24 mph ≤ 25 rpm > 88.00 pct or < 25.00 pct	Diagnostic runs in every 12.5 ms loop Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	PTO not active Transfer Case not in 4WD LowState Off-vehicle device control (service bay control) must not be active. following conditions not TRUE: (VeTESR_e_EngSpdReql ntvType = CeTESR_e_EngSpdMinLi mit AND VeTESR_e_EngSpdReqR espType = CeTESR_e_NoSuggestio n) Clutch is not depressed TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_F A IAT_SensorCircuitFA EvapFlowDuringNonPurg e_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_F A IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	FuelLevelDataFaultLow FuelConditionDiagnostic Clutch SensorFA AmbPresDfItDStatus P2771 > 10 sec The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi-Function Switch Circuit	P0564	Detect when cruise control multi-function switch circuit (analog) voltage is in an illegal range	Cruise Control analog circuit voltage must be in an "illegal range" or "between ranges" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 0.500 seconds	MIL: Type C, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control On Switch Circuit	P0565		Cruise Control On switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	MIL Type C, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Resume Circuit	P0567	Detects a failure of the cruise resume switch in a continuously applied state	Cruise Control Resume switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	MIL: Type C, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Set Circuit	P0568	Detects a failure of the cruise set switch in a continuously applied state	Cruise Control Set switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	MIL: Type C, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Cancel Switch Circuit	P056C		Cruise Control Cancel switch remains applied for greater than a calibratable period of time for architecture where cruise switch states are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	MIL: Type C, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Input Circuit	P0575	Detects rolling count or protection value errors in Cruise Control Switch Status serial data signal	If x of y rolling count / protection value faults occur, disable cruise for duration of fault		Cruise Control Switch Serial Data Error Diagnostic Enable	1.00	10 / 16 counts	MIL: Type C, No MIL

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Range/Performance	P057B	This diagnostic monitors the Brake Pedal Position Sensor for a stuck in range failure	.		Brake Pedal Position Sensor Circuit Range / Performance Diagnostic Enable	1.00 ignition voltage > 10.00		MIL: Type A, 1 Trips
			Calculated EWMA value must be greater than calibratable threshold after calibratable number of tests have completed to report a "test passed" for P057B	EWMA value looked up in supporting table P057B KtBRKI_K_FastTestPointWeight as a function of calculated brake pedal position delta EWMA value is > 0.80	calculated brake pedal position delta sample counter > 50.00 for fast test OR calculated brake pedal position delta sample counter > 1,000.00 for slow test	calculated brake pedal position delta > 8.00 OR (for slow test) shift lever has been in park once this key cycle vehicle speed >= 10.00 accelerator pedal position < 5.00	total number of EWMA tests > 20.00	
			Calculated EWMA Value must be less than calibratable threshold after calibratable number of tests have completed to report a "test failed" for P057B. This test runs once per key cycle	EWMA value looked up in supporting table P057B KtBRKI_K_CmpltTestPointWeight as a function of calculated brake pedal position delta EWMA value is less than 0.40	no DTC's active (P057C, P057D)	shift lever has been in park once this key cycle vehicle speed >= 10.00 accelerator pedal position < 5.00	total number of EWMA tests > 2.00	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Low	P057C	detects short to ground for brake pedal position sensor	If x of y samples are observed below failure threshold, default brake pedal position to zero percent.	5.00	Brake Pedal Position Sensore Low Voltage Diagnostic Enable	1.00	20 / 32.00 counts	MIL: Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit High	P057D	detects open circuit for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	95.00	Brake Pedal Position Sensore High Voltage Diagnostic Enable	1.00	20.00/ 32.00 counts	MIL: Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- function Circuit Low Voltage	P0580	detects short to ground failure for cruise multi-function switch circuit	Cruise Control analog circuit voltage must be in an "Open Short To Ground" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- function Circuit High Voltage	P0581		Cruise Control analog circuit voltage must be in an "Short To Power" for greater than a calibratable period of time for cruise switch states that are received over serial data		CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	MIL: Type C, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Open Circuit	P0597	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω impedance between signal and controller ground.	Run Crank Ignition in Range Engine not cranking Run Crank active == Above is true and == Last Open Circuit Test	= True = True = True =====	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips Note: In certian controlle rs P0598 may also set

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Circuit Low	P0598	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run Crank Ignition in Range Engine not cranking Run Crank active == Above is true and == Last Ground Short Circuit Test	= True = True = True =====	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips Note: In certian controlle rs P0597 may also set

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Thermostat Heater Control Circuit High	P0599	Diagnoses the T-stat Heater low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power.	Run Crank Ignition in Range Engine not cranking Run Crank active == Above is true and == Last Power Short Circuit Test	= True = True = True ===== = not Indeterminate	15 failures out of 30 samples 1 sec/ sample Continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ColdStrtA_C CamPstnB1	P05CC	Detects a VVT system error during Cold Starts by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Intake cam Bank 1) Cam Position Error > 3.00 deg.	System Voltage Engine Running Power Take Off (PTO) active CSER Active Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs Bundle: IntakeVVT_Enabled	> 11.00 Volts = TRUE = FALSE = TRUE > 0 deg > 3.00 deg AND < 23.00 deg < 5.00 Deg for (P0011_P05CC_StablePositionTimeIc1) sec P0010 P2088 P2089 = TRUE (Reference Supporting Tables: P0011_P0021_P05CC_P05CD_HiEngSpdHiDsbllc P0011_P0021_P05CC_P05CD_HiEngSpdLoEnbllc P0011_P0021_P05CC_P05CD_LoRpmHiEnbllc P0011_P0021_P05CC_P05CD_LoRpmLoDsbllc P0011_P0021_P05CC_P05CD_LoPresHiEnbllc P0011_P0021_P05CC_P05CD_LoPresLoDsbllc P0011_P0021_P05CC_P	30 failures out of 100 samples 100 ms /sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						05CD_EngOilPressEnbl c P0011_P0021_P05CC_P 05CD_P0014_P0024_PO 5CE_P05CF_ColdStartE ngRunning Reference Fault Bundles: IntakeVVT_Enabled CrankIntakeCamCorrFA IntakeCamSensorTFTK O CrankSensorTFTKO CamLctnIntFA)		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ColdStrtB_C amPstnB1	P05CE	Detects a VVT system error during Cold Starts by comparing the desired and actual cam positions when VVT is activated	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	(Exhaust cam Bank 1) Cam Position Error > 4.00 deg.	System Voltage Engine Running Power Take Off (PTO) active CSER Active Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs Bundle: ExhaustVVT_Enabled	> 11.00 volts = TRUE = FALSE = TRUE > 0 deg > 4.00 deg AND < 22.00 deg < 5.00 Deg for (P0014_P05CE_StablePositionTimeEc1) sec. P0013 P2090 P2091 = TRUE (Reference Supporting Tables: P0014_P0024_P05CE_P05CF_HiEngSpdHiDsblEc P0014_P0024_P05CE_P05CF_HiEngSpdLoEnblEc P0014_P0024_P05CE_P05CF_LoRpmHiEnblEc P0014_P0024_P05CE_P05CF_LoRpmLoDsblEc P0014_P0024_P05CE_P05CF_LoPresHiEnblEc P0014_P0024_P05CE_P05CF_LoPresLoDsblEc P0014_P0024_P05CE_P	30 failures out of 100 samples 100 ms /sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						05CF_EngOilPressEnbl Ec P0011_P0021_P05CC_P 05CD_P0014_P0024_P0 5CE_P05CF_ColdStartE ngRunning Reference Fault Bundles: ExhaustVVT_Enabled CrankExhaustCamCorrF A ExhaustCamSensorTFT KO CrankSensorTFTKO CamLctnExhFA)		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
			The Primary Processor's calculated checksum does not match the stored checksum value for a selected subset of the calibrations.	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
			The Secondary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	
				In all cases, the failure count is cleared when controller shuts down				

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the ECU is a service part that has not been programmed.	Service (reflash) controller calibration present	= 1		none	Diagnostic runs at powerup and once per second continuously after that	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Long Term Memory Reset	P0603	Non-volatile memory checksum error at controller power-up	Checksum at power-up does not match checksum at power-down				Diagnostic runs at powerup Diagnostic reports a fault if 1 failure occurs	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604	Indicates that the ECM has detected a RAM fault	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips
			Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.45522 s			When dual store updates occur.	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	65,534 counts			Diagnostic runs continuously (background loop)	
			Indicates that the secondary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault	Loss or invalid message of SPI communication from the Secondary Processor at initialization detected by the Primary Processor or loss or invalid message of SPI communication from the Secondary Processor after a valid message was received by the Primary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received		Run/Crank voltage >= 6.41 or Run/Crank voltage >= 11.00 , else the failure will be reported for all conditions	In the primary processor, 159 / 399 counts intermittent or 39 counts continuous; 39 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	Type A, 1 Trips
			Loss or invalid message of SPI communication from the Primary Processor at initialization detected by the Secondary Processor or loss or invalid message of SPI communication from the Primary Processor after a valid message was received by the Secondary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received			In the secondary processor, 20 / 200 counts intermittent or 0.1875 s continuous; 0.4750 s continuous @ initialization. 12.5 ms /count in the ECM secondary processor	
			Checks for stack over or underflow in secondary processor by looking for corruption of known pattern at stack boundaries. Checks number of stack over/ under flow since last powerup reset >=	3		KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1 . (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			MAIN processor is verified by responding to a seed sent from the secondary with a key response to secondary. Checks number of incorrect keys	2 incorrect seeds within 8 messages, 0.2000 seconds		ignition in Run or Crank	150 ms for one seed continually failing	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			received > or Secondary processor has not received a new within time limit					
			Time new seed not received exceeded			always running	0.450 seconds	
			MAIN processor receives seed in wrong order			always running	3 / 17 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the Secondary processor's ALU check			KePISD_b_ALU_TestEnbl d == 1 Value of KePISD_b_ALU_TestEnbl d is: 1 . (If 0, this test is disabled)	25 ms	
			2 fails in a row in the Secondary processor's configuration register masks versus known good data			KePISD_b_ConfigRegTes tEnbl d == 1 Value of KePISD_b_ConfigRegTes tEnbl d is: 1 . (If 0, this test is disabled)	12.5 to 25 ms	
			Secondary processor detects an error in the toggling of a hardware discrete line controlled by the MAIN processor: number of discrete changes > = or < = over time window(50ms)	7 17		KePISD_b_MainCPU_SO H_FltEnbl d == 1 Value of KePISD_b_ConfigRegTes tEnbl d is: 0 . (If 0, this test is disabled) time from initialization >= 0.4875 seconds	50 ms	
			Software background task first pass time to complete exceeds			Run/Crank voltage > 6.41	360.000 seconds	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			2 fails in a row in the MAIN processor's ALU check			KePISD_b_ALU_TestEnbl == 1 Value of KePISD_b_ALU_TestEnbl is: 1. (If 0, this test is disabled)	25 ms	
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			KePISD_b_ConfigRegTestEnbl == 1 Value of KePISD_b_ConfigRegTestEnbl is: 1. (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	3		KeMEMD_b_StackLimitTestEnbl == 1 Value of KeMEMD_b_StackLimitTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		KePISD_b_A2D_CnvtrTestEnbl == 1 Value of KePISD_b_A2D_CnvtrTestEnbl is: 1. (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		KeMEMD_b_FlashECC_CktTestEnbl == 1 Value of KeMEMD_b_FlashECC_CktTestEnbl is: 1. (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	
			Checks for ECC (error	3 (results in MIL),		KeMEMD_b_RAM_ECC_	variable,	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	5 (results in MIL and remedial action)		CktTestEnbl == 1 Value of KeMEMD_b_RAM_ECC_CktTestEnbl is: 1. (If 0, this test is disabled)	depends on length of time to write flash to RAMvariable, depends on length of time to write flash to RAM	
			MAIN processor DMA transfer from Flash to RAM has 1 failure			KePISD_b_DMA_XferTestEnbl == 1 Value of KePISD_b_DMA_XferTestEnbl is: 0. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	
			Safety critical software is not executed in proper order.	>= 1 incorrect sequence.		Table, f(Loop Time). See supporting tables: Program Sequence Watch Enable f(Loop Time) (If 0, this Loop Time test is disabled)	Fail Table, f(Loop Time). See supporting tables: PSW Sequence Fail f(Loop Time) / Sample Table, f(Loop Time)See supporting tables: PSW Sequence Sample f(Loop Time) counts 50 ms/count in the ECM main processor	
			MAIN processor	Previous seed value		KePISD b SeedUpdKey	Table, f(Loop	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			determines a seed has not changed within a specified time period within the 50ms task.	equals current seed value.		StorFltEnbl == 1 Value of KePISD_b_SeedUpdKey StorFltEnbl is: 1. (If 0, this test is disabled)	Time). See supporting tables: Last Seed Timeout f (Loop Time)	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Relay Control Circuit Low Voltage	P0628	Diagnoses the fuel pump relay control high side driver circuit for circuit faults	Voltage low during driver on state (indicates short to ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage Engine Speed	Voltage ≥ 11 volts ≥ 0 RPM	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module EEPROM Error	P062F	Indicates that the NVM Error flag has not been cleared	The next write to NVM will not succeed or the assembly calibration integrity check failed.		Ignition State	= unlock/accessory, run, or crank	1 test failure Diagnostic runs once at powerup	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks that the VIN is correctly written	At least one of the programmed VIN digits	= 00 or FF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on the 5 volt reference circuit #1	ECM Vref1 < or ECM Vref1 > or the difference between ECM filtered Vref1 and Vref1 >	4.875 5.125 0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Open	P0650	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	50 failures out of 63 samples 50 ms / sample	Type B, No MIL NO MIL Note: In certain controllers P263A may also set (MIL Control Short to Ground)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #2 Circuit	P0651	Detects a continuous or intermittent short on the 5 volt reference circuit #2	ECM Vref2 < or ECM Vref2 > or the difference between ECM filtered Vref2 and Vref2 >	4.875 5.125 0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Open	P0685	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates open circuit)	Open Circuit: ≥ 200 K Ω ohms impedance between signal and controller ground	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0686 may also set (Powertr ain Relay Control Short to Ground).

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Low	P0686	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0685 may also set (Powertr ain Relay Control Open Circuit).

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) High	P0687	Diagnoses the powertrain relay control low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage	Voltage ≥ 11 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Feedback Circuit High	P0690	This DTC is a check to determine if the Powertrain relay is functioning properly.	Powertrain Relay Voltage	>= 4.00 volts will increment the fail counter	Powertrain relay commanded "OFF" No active DTCs:	>= 2.00 seconds PowertrainRelayStateOn_ FA	50 failures out of 63 samples 100ms / Sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit Low Voltage (ODM)	P0691	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0480 may also set (Fan 1 Open Circuit).

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Relay Control Circuit High Voltage (ODM)	P0692	Diagnoses the cooling fan 1 relay control low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit Low Voltage (ODM)	P0693	Diagnoses cooling fan 2 relay control low side driver circuit for circuit faults	Voltage low during driver off state (indicates short- to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0481 may also set (Fan 2 Open Circuit).

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 2 Relay Control Circuit High Voltage (ODM)	P0694	Diagnoses the cooling fan 2 relay control low side driver circuit for circuit faults	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Powertrain Relay Voltage	Voltage ≥ 11.00 volts	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #3 Circuit	P0697	Detects a continuous or intermittent short on the 5 volt reference circuit #3	ECM Vref3 < or ECM Vref3 > or the difference between ECM filtered Vref3 and Vref3 >	4.875 5.125 0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #4 Circuit	P06A3	Detects a continuous or intermittent short on the 5 volt reference circuit #4	ECM Vref4 < or ECM Vref4 > or the difference between ECM filtered Vref4 and Vref4 >	4.875 5.125 0.0495		Run/Crank voltage > 6.41	19 / 39 counts or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 1 Performance	P06B6	This diagnostic checks for a fault with the internal test circuit used only for the '20 kHz' method of the Open Circuit Diagnostic	FFT Diagnostic Output	> OpenTestCktThrshMin and < OpenTestCktThrshMax See Supporting Tables	Diagnostic Enabled? Engine Run Time Engine Speed Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above) Engine Air Flow	Yes ≥ 2.0 seconds > 600 RPM and < 6,750 RPM ≥ 200 Revs ≥ 40 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient Weight Coefficient = 0.0100 Updated each engine event	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Module (TCM) Requested MIL Illumination	P0700	Monitors the TCM MIL request line to determine when the TCM has detected a MIL illuminating fault.	Transmission Emissions-Related DTC set			Time since power-up \geq 3 seconds	Continuous	Type A, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Range / Performance	P0806	Detects if Clutch Pedal Position Sensor is Stuck in a range indicative of a vehicle NOT in gear, when the vehicle is determined to be in gear. Gear determination is made by verifying that the ratio of engine RPM versus Transmission Output Speed (N/TOS) represents a valid gear.	Filtered Clutch Pedal Position Error when the vehicle is determined to be in gear	> 5 %	N/TOS Ratio: Transfer Case: Vehicle speed: Engine Torque: Clutch Pedal Position: OR No Active DTCs:	Must match actual gear (i.e. vehicle in gear) Not in 4WD Low range > 3.1 MPH > EngTorqueThreshold (see Supporting Tables) < ResidualErrEnableLow (see Supporting Tables) > ResidualErrEnableHigh (see Supporting Tables) ClutchPstnSnsrCktHi FA ClutchPstnSnsrCktLo FA CrankSensor_FA Transmission Output Shaft Angular Velocity Validity VehicleSpeedSensor_FA	25 ms loop Continuous	Type X, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit Low	P0807	Detects Continuous Circuit Out-of-Range Low or Open	Clutch Position Sensor Circuit for	< 4 % of Vref 200 counts out of 250 samples	Engine Not Cranking System Voltage No active DTCs:	> 9.0 Volts	25 ms loop Continuous	Type X, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Sensor Circuit High	P0808	Detects Continuous Circuit Out-of-Range High	Clutch Position Sensor Circuit for	> 96 % of Vref 200 counts out of 250 samples	Engine Not Cranking System Voltage No active DTCs:	> 9.0 Volts	25 ms loop Continuous	Type X, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Clutch Pedal Position Not Learned	P080A	Detects Invalid Clutch Pedal Fully Applied Learn Position values	Fully Applied Learn Position OR	< 7.0 % > 33.0 %	OBD Manufacturer's Enable Counter	= 0	250 ms loop Continuous	Type X, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Traction Control Torque Request Circuit	P0856	Determines if torque request from the EBTCM is valid	<p>Serial Communication 2's complement message - (\$1C7/\$1C9 for engine torque, \$1CA/\$1C6 for axle torque)</p> <p>OR</p> <p>Serial Communication message (\$1C7/\$1C9 for engine torque, \$1CA/\$1C6 for axle torque) rolling count index value</p> <p>OR</p> <p>Too many minimum limit torque request transitions occur from TRUE to FALSE to TRUE within a time period</p> <p>OR</p> <p>Torque request greater than torque request diagnostic maximum threshold</p>	<p>Message <> 2's complement of message</p> <p>Message rolling count value <> previous message rolling count value plus one</p> <p>Requested torque intervention type toggles from not increasing request to increasing request</p> <p>> 250 Nm for engine torque based traction torque system, OR > 4,000 Nm for axle torque based traction torque system</p>	<p>Serial communication to EBTCM (U0108)</p> <p>Power Mode Engine Running</p> <p>Status of traction in GMLAN message (\$4E9)</p>	<p>No loss of communication</p> <p>= Run = True</p> <p>= Traction Present</p>	<p>>= 6 failures out of 10</p> <p>Performed on every received message</p> <p>6 rolling count failures out of 10 samples</p> <p>Performed on every received message</p> <p>>= 3 multi-transitions out of 5 samples.</p> <p>Performed every 200 ms</p> <p>>= 4 out of 10 samples</p> <p>Performed on every received message</p>	Type C, No MIL Safety Special Type C

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (naturally aspirated)	P1101	Determines if there are multiple air induction problems affecting airflow and/or manifold pressure.	Filtered Throttle Model Error AND (ABS(Measured Flow – Modeled Air Flow) Filtered OR ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered	<= 250 kPa*(g/s) > 12.0 grams/sec > 20.0 kPa) > 20.0 kPa	Engine Speed Engine Speed Coolant Temp Coolant Temp Intake Air Temp Intake Air Temp Minimum total weight factor (all factors multiplied together)	>= 400 RPM <= 6,500 RPM > -7 Deg C < 125 Deg C > -20 Deg C < 100 Deg C >= 0.50 Filtered Throttle Model Error multiplied by TPS Residual Weight Factor based on RPM Modeled Air Flow Error multiplied by MAF Residual Weight Factor based on RPM and MAF Residual Weight Factor Based on MAF Est MAP Model 1 Error multiplied by MAP1 Residual Weight Factor based on RPM MAP Model 2 Error multiplied by MAP2 Residual Weight Factor based on RPM See Residual Weight Factor tables. MAP_SensorCircuitFA EGRValvePerformance_FA A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA	Continuous Calculation are performed every 12.5 msec	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Pending DTCs:	IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Sensor Not Plausible) (TSRD)	P111E	This DTC detects a difference between ECT and two other temp sensors after a soak condition.	<p>Sensor usage definitions:</p> <p>Sensor1 = CeECTD_e_ECT_Snsr (Sensor1 is the temp sensor most impacted by the block heater (if equipped))</p> <p>Sensor2 = CeECTD_e_IAT_Snsr</p> <p>Sensor3 = CeECTD_e_RCT_Snsr</p> <p>=====</p> <p>A failure will be reported if any of the following occur:</p> <p>1) Sensor1 power up absolute temp difference to Sensor2 and Sensor3 is (Sensor1 fast fail) .</p> <p>2) Sensor1 power up temp is greater than Sensor2 and Sensor3 in this range: (and a block heater has not been detected)</p> <p>3) Sensor1 power up temp is lower than Sensor2 and Sensor3 by this amount:</p> <p>4) Sensor1 power up temp is \geq Sensor2 and</p>	<p>$\geq 60.0^{\circ}\text{C}$</p> <p>$\geq 19.0$ and $< 60.0^{\circ}\text{C}$</p> <p>≤ 19.0 Deg $^{\circ}\text{C}$</p>	<p>No Active DTC's</p> <p>Engine Off Soak Time Propulsion Off Soak Time Non-volatile memory initialization</p> <p>Test complete this trip Test aborted this trip Test disabled this trip Ambient LowFuelCondition Diag</p> <p>=====</p> <p>Block Heater detection is enabled when either of the following occurs:</p> <p>1) Sensor1 power up temp is greater than Sensor2 and Sensor3 in this range:</p> <p>2) Cranking time</p> <p>=====</p> <p>Block Heater is detected and diagnostic is aborted</p>	<p>VehicleSpeedSensor_FA IAT_SensorCircuitFA THMR_RCT_Sensor_Ckt_FA ECT_Sensor_Ckt_FA EngModeNotRunTmErr EngineModeNotRunTimer_FA OAT_PtEstFiltFA OAT_PtEstRawFA PSAR_PropSysInactiveCr_s_FA DRER_DiagSystemDsbl</p> <p>> 28,800 seconds > 0 seconds = Not occurred</p> <p>= False = False = False $\geq -7^{\circ}\text{C}$ = False</p> <p>=====</p> <p>$\geq 19.0^{\circ}\text{C}$ and $< 60.0^{\circ}\text{C}$</p> <p>< 10.0Seconds</p> <p>=====</p>	<p>1 failure to set DTC</p> <p>1 sec/ sample</p> <p>Once per valid cold start</p>	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Sensor3 by 19.0°C and the time spent cranking the engine without starting is ≥ 10.0 seconds with the LowFuelConditionDiag	= False	when 1) or 2) occurs. 1a) IAT monitoring is enabled after the following Vehicle drive constraints 1b) Drive time 1c) Vehicle speed 1d) Additional Vehicle drive time is provided to 1b when Vehicle speed is below 1c as follows: 1e) IAT drops from power up IAT 2a) ECT monitoring is enabled after engine start in the following engine run time window 2b) Sensor1 temp derivative during the test is: 2c) Consecutive samples of 2b) being true are: ===== Diagnostic is aborted when 3) or 4) occurs: 3) Engine run time with vehicle speed below 1b 4) Engine off time (i.e. auto stop) during Block heater detection	> 400 Seconds with > 12.4 MPH and 0.50 times the seconds with vehicle speed below 1b ≥ 3.3°C 10.0 ≤ seconds ≤ 50.0 < -0.10°C/sec ≥ 4 samples ===== ≥ 1,800 Seconds ≥ 180.0 Seconds		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Radiator Coolant Temperature Sensor Not Plausible) (TSRD)	P112F	This DTC detects a difference between RCT and two other temp sensors after a soak condition.	<p>Sensor usage definitions:</p> <p>Sensor1 = CeECTD_e_ECT_Snsr (Sensor1 is the temp sensor most impacted by the block heater (if equipped))</p> <p>Sensor2 = CeECTD_e_IAT_Snsr</p> <p>Sensor3 = CeECTD_e_RCT_Snsr</p> <p>=====</p> <p>A failure will be reported if (based on the above calibrations):</p> <p>1) Sensor2 (if RCT is Sensor2)power up absolute temp difference to Sensor1 and Sensor3 is:</p> <p>OR (based on usage)</p> <p>2) Sensor3 (if RCT is Sensor3) power up absolute temp difference to Sensor1 and Sensor2 is:</p>	<p>≥ 19.0°C</p> <p>≥ 19.0°C</p>	<p>No Active DTC's</p> <p>Engine Off Soak Time Propulsion Off Soak Time Non-volatile memory initialization</p> <p>Test complete this trip Test aborted this trip Test disabled this trip Ambient LowFuelCondition Diag</p>	<p>VehicleSpeedSensor_FA IAT_SensorCircuitFA THMR_RCT_Sensor_Ckt_FA ECT_Sensor_Ckt_FA EngineModeNotRunTimer Error EngineModeNotRunTimer_FA OAT_PtEstFiltFA OAT_PtEstRawFA PSAR_PropSysInactiveCr s_FA DRER_DiagSystemDsbl</p> <p>> 28,800 seconds > 0 seconds = Not occurred</p> <p>= False = False = False ≥ -7°C = False</p>	<p>1 failure to set DTC</p> <p>1 sec/ sample</p> <p>Once per valid cold start</p>	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Emissions Reduction System Fault	P1400	Model based test computes power from exhaust flow and thermal energy resulting from elevated idle speed and retarded spark advance. Detects if the cold start emission reduction system has failed resulting in the delivered power being out of range.	<p>Average desired accumulated exhaust power - Average actual accumulated exhaust power (too much energy delivered to catalyst)</p> <p>Average desired accumulated exhaust power - Average actual accumulated exhaust power (too little energy delivered to catalyst)</p> <p>(EWMA filtered)</p> <p>Average Power = output of P1400_EngineSpeedResidual_Table * output of P1400_SparkResidual_Table</p> <p>NOTE: Desired accumulated power would use the desired catalyst light off spark and desired engine speed and the actual accumulated power would use the final commanded spark and actual engine speed. Refer to the Supporting Tables for details</p>	<p>< -32.00 KJ/s (high RPM failure mode)</p> <p>> 4.40 KJ/s (low RPM failure mode)</p>	<p>To enable the diagnostic, the Cold Start Emission Reduction Strategy must be Active per the following:</p> <p>Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure</p> <p>The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:</p> <p>Catalyst Temperature AND Engine Run Time</p> <p>OR</p> <p>Engine Run Time</p> <p>OR</p> <p>Barometric Pressure</p>	<p>< 350.00 degC</p> <p>> 10.00 degC</p> <p><= 50.00 degC</p> <p>>= 70.00 KPa</p> <p>>= 420.00 degC</p> <p>>= 30.00 seconds</p> <p>> CatalystLightOffExtendedEngineRunTimeExit</p> <p>This Extended Engine run time exit is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.</p> <p>< 70.00 KPa</p>	<p>Runs once per trip when the cold start emission reduction strategy is active</p> <p>Frequency: 100ms Loop</p> <p>Test completes after 14 seconds of accumulated qualified data.</p>	EWMA Based - Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Other Enable Criteria:</p> <p>OBD Manufacturer Enable Counter</p> <p>Vehicle Speed</p> <p>Allow diagnostic to calculate residual in an off-idle state. If the value of the OffIdleEnable is equal to 1 then the "DriverOffAccelPedal" will not be checked. However, if the value of OffIdleEnable is 0 then driver must be off the accel pedal</p> <p>A change in throttle position (tip-in/tip-out) will initiate a delay in the calculation of the average qualified residual value. Therefore when the:</p> <p>Pedal Close Delay Timer</p> <p>the diagnostic will continue the calculation.</p> <p>A change in gear will initiate a delay in the calculation of the average qualified residual value to allow time for the actual</p>	<p>0</p> <p>< 1.24 MPH</p> <p>0</p> <p>(A value of 1 allows diagnostic to run and calculate the residual while off idle. A value of 0 requires calculation of the residual at idle)</p> <p>> 5.00 seconds</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>engine speed and actual final commanded spark to achieve their desired values. Therefore, when the:</p> <p>Gear Shift Delay Timer</p> <p>the diagnostic will continue the calculation</p> <p>For Manual Transmission vehicles:</p> <p>Clutch Pedal Position</p> <p>Clutch Pedal Position</p> <p>The diagnostic will delay calculation of the residual value and potentially weight the residual calculation differently based on engine run time. This is to ensure the diagnostic is operating in idle speed control as well as during the peak catalyst light off period.</p> <p>The time weighting factor must be :</p>	<p>> 2.00 seconds</p> <p>> 88.00 %</p> <p>< 25.00 %</p> <p>> 0 These are scalar values that are a function of engine run time. Refer to ColdStartDiagnosticDelayBasedOnEngineRunTime</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>General Enable:</p> <p>DTC's Not Set:</p>	<p>and the cal axis, ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis in the "Supporting Tables" for details.</p> <p>AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFP CrankSensorFaultActive FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA EngineMisfireDetected_FA Clutch Sensor FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA 5VoltReferenceMAP_OOR_Flt TransmissionEngagedState_FA EngineTorqueEstInaccuracy</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Engine Speed Request Circuit	P150C	Determines if engine speed request from the TCM is valid	Serial Communication rolling count value	+ 1 from previous \$19D message (PTEI3)	Diagnostic enable bit	1	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips
			Transmission engine speed protection	not equal to 2's complement of transmission engine speed request + Transmission alive rolling count	Engine run time	0.50 sec		
					# of Protect Errors	10 protect errors within the sample period 20		
					# of Alive Rolling Errors	6 rolling count errors out of 10 samples		
					No idle diagnostic 506/507 code	IAC_SystemRPM_FA		
					No Serial communication loss to TCM	(U0101)		
					Engine Running	= TRUE		
		Power mode	Run Crank Active					

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Steady State Actuation Fault	P1516	Detect an inability to maintain a steady state throttle position	The absolute difference between desired and indicated throttle position is >	2.00 percent		Run/Crank voltage > 6.41 Ignition voltage failure is false (P1682) TPS minimum learn is not active and Throttle is being Controlled Throttle is considered in a steadystate condition when the desired throttle position over a 12.5 ms period is < 0.25 percent for a settling time period > 4.00 s	0.49 ms	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Switch State Undertermin ed	P155A	Detects when cruise switch state cannot be determined, such as low voltage conditions	cruise switch state remains undetermined for greater than a calibratable time				fail continuously for greater than 0.5 seconds	MIL: Type C, No MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage	Run/Crank – PT Relay Ignition >	3.00 Volts		Powertrain commanded on AND (Run/Crank voltage > Table, f(IAT). See supporting tables: PT Relay Pull-in Run/Crank Voltage f(IAT) OR PT Relay Ignition voltage > 5.50) AND Run/Crank voltage > 5.50 .	240 / 480 counts or 0.1750 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Redundant Memory Performance	P16F3	<p>Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures</p> <p>For all of the following cases: If the individual diagnostic threshold is equal to 2048 ms, this individual case is not applicable. If any of the following cases are X out of Y diagnostics and the fail (x) is greater than the sample (Y), this individual case is also not applicable.</p>	Desired Throttle Area calculated does not equal its redundant calculation	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	Type A, 1 Trips
			Equivalence Ratio torque compensation exceeds threshold	-43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between Equivalence Ratio torque compensation and its dual store out of bounds given by threshold	43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	78.37 mg	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	16.50 degrees		Engine speed >0rpm	Up/down timer 125 ms continuous, 0.5 down time multiplier	
			Torque Learn offset is out of bounds given by threshold range	High Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold 0.00 Nm			multiplier	
			One step ahead calculation of air-per-cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed > 670 rpm	Up/down timer 443 ms continuous, 0.5 down time multiplier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	16.49 degrees	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 587.77 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 587.77 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Arbitrated Air-Per-Cylinder filter coefficient is out of bounds given by threshold range	High Threshold 1.000 Low Threshold 0.074	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Launch spark is active but the launch spark redundant path indicates it should not be active	N/A		Engine speed < 7,000.00 or 7,200.00 rpm (hysteresis pair)	Up/down timer 143 ms continuous, 0.5 down time multiplier	
			Rate limited vehicle speed and its dual store do not equal	N/A		Time since first CAN message with vehicle speed >= 0.500 sec	10 / 20 counts; 25.0msec/count	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Preload Throttle Area and its dual store do not equal	N/A	Ignition State	Accessory, run or crank AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to fast actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to slow actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			TOS to wheel speed conversion factor is out of bounds given by threshold	High Threshold: 1.10	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			range	T/C Range Hi 0.10 T/C Range Lo Low Threshold: 1.10 T/C Range Hi 0.10 T/C Range Lo				
			Cylinders active greater than commanded	3 cylinders		Engine run flag = TRUE > 2.00 s Number of cylinder events since engine run > 24 No fuel injector faults active	Up/down timer 143 ms continuous, 0.5 down time multiplier	
			Transfer case neutral request from four wheel drive logic does not match	N/A	Ignition State	Accessory, run or crank	14 / 16 counts; 25.0msec/count	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			with operating conditions			Transfer case range valid and not over-ridden FWD Apps only		
			Driver progression mode and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Predicted torque for uncorrected zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). See supporting tables + 43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	42.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	42.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Positive Torque Offset is greater than its redundant calculation plus threshold OR Positive Torque Offset is less than its redundant calculation minus threshold	43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, down time multiplier 0.5	
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Hybrid	4,096.00	Ignition State	Accessory, run or crank	Up/down timer	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Immediate Crankshaft Request is less than its redundant calculation minus threshold	Nm			2,048 ms continuous, 0.5 down time multiplier	
			Regeneration Brake Assist is not within a specified range	Brake Regen Assist < 0 Nm or Brake Regen Assist > 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	16.49 degrees	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			1. Cylinder Torque Offset exceeds step size threshold OR 2. Sum of Cylinder Torque Offset exceeds sum threshold	1. 43.33 Nm 2. 43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold	43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 143 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Speed Lores Intake Firing timing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 143 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: Speed Control External Load f(Oil Temp, RPM) + 43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: Speed Control External Load f(Oil Temp, RPM) + 43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference between Driver Requested Immediate Torque primary path and its secondary exceeds threshold	587.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Driver Immediate Request is less than its redundant calculation minus threshold	587.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Request is greater than its redundant calculation plus threshold	587.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			OR					
			Commanded Immediate					

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Request is less than its redundant calculation minus threshold					
			Commanded Immediate Response Type is set to Inactive	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Difference between Cruise Axle Torque Arbitrated Request and Cruise Axle Torque Request exceeds threshold	73.47 Nm		Cruise has been engaged for more than 4.00 seconds	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Desired engine torque request greater than	42.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 475	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			redundant calculation plus threshold				ms continuous, 0.5 down time multiplier	
			Engine min capacity above threshold	43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 122 ms continuous, 0.5 down time multiplier	
			No fast unmanaged retarded spark above the applied spark plus the threshold	Table, f(RPM,APC). See supporting tables: Delta Spark Threshold f (RPM,APC)		Engine speed greater than 0rpm	Up/down timer 125 ms continuous, 0.5 down time multiplier	
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s	Ignition State	Accessory, run or crank	Up/down timer 167 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Absolute difference of redundant calculated engine speed above threshold	500 RPM		Engine speed greater than 0 RPM	Up/down timer 143 ms continuous, 0.5 down time multiplier	
			After throttle blade pressure and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Speed Control's Predicted Torque Request and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine oil temperature and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 391 ms continuous,	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							0.5 down time multiplier	
			Desired throttle position greater than redundant calculation plus threshold	10.00 percent	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	0.06 kpa	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Throttle desired torque above desired torque plus threshold	43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired filtered throttle torque exceeds the higher of desired throttle torque or modeled throttle torque	43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque feedback proportional term is out of allowable range or its dual store copy does not match	High Threshold 21.67 Nm Low Threshold -21.67 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque feedback integral term magnitude or rate of change is out of allowable range or its dual store copy do not match	High Threshold 40.62 Nm Low Threshold	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				-43.33 Nm Rate of change threshold 2.71 Nm/loop				
			Difference of Final Torque feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	High Threshold 43.33 Nm Low Threshold - 43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of torque desired throttle area and its redundant calculation is out of bounds given by threshold range	High Threshold 0.50 %	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold -0.50 %			multiplier	
			Difference of torque model coefficients and its redundant calculation is out of bounds given by threshold range	High Threshold 0.0003160 Low Threshold - 0.0003160	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 43.33 Nm Low Threshold - 43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 43.33 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			AC friction torque is greater than commanded by AC control software or less than threshold limit	High Threshold 40.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 43.33 Nm Low Threshold	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				-43.33 Nm				
			Generator friction torque is out of bounds given by threshold range	High Threshold 43.33 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Supercharger friction torque is out of bounds given by threshold range	High Threshold 43.33 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Torque error magnitude or its increase rate of change is out of allowable range or its dual store copy do not match	High Threshold 43.33 Nm Low Threshold -43.33 Nm Rate of change threshold 2.71 Nm/loop		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque error compensation is out of bounds given by threshold range	High Threshold 43.33 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Delta Torque Baro compensation is out of bounds given by threshold range	High Threshold 2.43 Nm Low Threshold -2.30 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			1. Difference of reserve torque value and its redundant calculation exceed threshold OR 2. Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation exceed threshold OR 3. Rate of change of reserve torque exceeds threshold, increasing direction only	1. 42.33 Nm 2. N/A 3. 42.33 Nm 4. 42.33 Nm	3. & 4.: Ignition State	1. & 2.: Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 43.33 Nm 3. & 4.: Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR 4. Reserve engine torque above allowable capacity threshold					
			Engine Vacuum and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated Intake Manifold Pressure during engine event versus during time event is greater than threshold	Table, f(Desired Engine Torque). See supporting tables: Delta MAP Threshold f(Desired Engine Torque)		Engine speed >0rpm	Up/down timer 143 ms continuous, 0.5 down time multiplier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Driver Predicted Request	587.77	Ignition State	Accessory, run or crank	Up/down timer	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>is greater than its redundant calculation plus threshold</p> <p>OR</p> <p>Driver Predicted Request is less than its redundant calculation minus threshold</p>	Nm			475 ms continuous, 0.5 down time multiplier	
			Cold Delta Friction Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Predicted torque for zero pedal determination is greater than calculated limit.	Table, f(Oil Temp, RPM). See supporting tables: Speed Control External Load f(Oil Temp, RPM) + 43.33 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded Predicted Axle Torque and its dual store do not match	1 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Steady State Estimated Engine Torque and its dual store are not equal	N/A		AFM not changing from Active to Inactive and preload torque not changing and one loop after React command Engine speed >0rpm	Up/down timer 1,988 ms continuous, 0.5 down time multiplier	
			Difference of Weighting factor for number of cylinders fueled and its redundant calculation is above threshold	0.26		Engine run flag = TRUE > 10.00 s	Up/down timer 175 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of minimum spark advance limit and its redundant calculation is out of bounds given by threshold range	16.50 degrees	Ignition State	Accessory, run or crank	Up/down timer 143 ms continuous, 0.5 down time multiplier	
			Difference of commanded spark advance and adjusted delivered is out of bounds given by threshold range	16.50 degrees		Engine speed >0rpm	Up/down timer 125 ms continuous, 0.5 down time multiplier	
			Absolute difference between Estimated Engine Torque and its dual store are above a threshold	43.33 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between Estimated Engine Torque without reductions due to torque	43.33 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control and its dual store are above a threshold				down time multiplier	
			Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	16.50 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 43.33 Nm	Up/down timer 443 ms continuous, 0.5 down time multiplier	
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range	43.33 Nm		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			One step ahead calculation of air-per-cylinder greater than two	Threshold: Dynamically calculated based on current		Engine speed > 670 rpm	Up/down timer 443 ms continuous.	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			step ahead calculation by threshold for time	engine conditions Fault Pending Threshold: 100 ms			0.5 down time multiplier	
			Rate limited cruise axle torque request and its dual store do not match within a threshold	73.47 Nm	Ignition State	Accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time multiplier	
			1. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its redundant calculation is out of bounds given by threshold range OR 2. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions	1. 5.00 % 2. N/A 3. N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			and its dual store do not equal OR 3. Absolute difference of Calculated accelerator pedal position and its dual store do not equal					
			Commanded axle torque is greater than its redundant calculation by threshold	587.77 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded axle torque is less than its redundant calculation by threshold	881.66 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Preload timer and its redundant calculation do	N/A	Ignition State	Accessory, run or crank	Up/down timer 2.048	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			not equal			AFM apps only	ms continuous, 0.5 down time multiplier	
			AC friction torque is greater than commanded by AC control software	40.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (time based) calculation does not equal its redundant calculation	N/A		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated spark offset for equivalence ratio and its redundant cacluation is greater than a threshold	16.50 degrees		Engine speed >0rpm	Up/down timer 143 ms continuous, 0.5 down time multiplier	
			Transmission Torque	N/A		Run or Crank = TRUE >	16 / 32	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Request cacluations do not equal their dual stores			0.50 s	counts; 25.0msec/count	
			Absolute difference of the predicted motor torque ACS and its redundant cacluation is greater than a threshold	0.01 Nm			Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of maximum throttle area and its redundant cacluation is greater than a threshold	15 mm ²			Up/down timer 167 ms continuous, 0.5 down time multiplier	
			Absolute difference of Desired TIAP and its redundant cacluation is greater than a threshold	5.00 kPa			Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Pedal learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Throttle learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Desired Throttle Position and its redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Low- Bank 1	P2088	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.	Short to ground: ≤ 0.5 Ω to a voltage source within the Vehicle Ground Voltage Range relative to PWRGND	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit High – Bank 1	P2089	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Low – Bank 1	P2090	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match.	Short to ground: ≤ 0.5 Ω to a voltage source within the Vehicle Ground Voltage Range relative to PWRGND	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit High – Bank 1	P2091	Diagnoses the VVT system high side driver circuit for circuit faults.	The ECM detects that voltage is high during driver off state (indicates short to power or open circuit)	Short to power: ≤ 0.5 Ω impedance between signal and controller power Open Circuit: ≥ 200 K Ω impedance between signal and controller ground	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Low Limit Bank 1 (Too Rich)	P2096	Determines if the post catalyst O2 sensor based fuel control system has utilized all or most of its low limit authority, indicating a rich emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too rich, the post catalyst O2 integral offset control is decreased. This results in lean bias fuel control in an attempt to correct the rich condition. A perfectly balanced control system (no rich or lean bias required) is represented by an integral offset value of "0" and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean). An integral offset value < 0 is indicative of the control system reacting to a rich post catalyst O2 sensor. If the failure is such that the control system utilizes all or most of its available authority, then P2096 will set.	Rich Fail counter High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18% for >= 5.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14% for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	>= 350 counts per 675 sample counts Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp. PTO Intrusive diag. fuel control Long Term Secondary Fuel Trim Enabled (see " Long Term Secondary Fuel Trim Enable Criteria " in Supporting Tables) High Vapor Conditions No Fault Active for:	No No Yes Yes Yes >= 70 kPa >= 0.0 g/s <= 10,000.0 >= 0 kPa <= 200 >= -20 deg. C <= 200 >= -20 deg. C Not Active Not Active Not Present AmbientAirDefault AIR System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorFA CamSensorAnyLocationFA EvapEmissionSystem_FA EvapFlowDuringNonPurge_FA FuelTankPressureSnrCkt_FA	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EvapPurgeSolenoidCircuit_FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorTFTKO MAP_SensorFA MAP_EngineVacuumStatus EngineMisfireDetected_FA A/F Imbalance Bank1 O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA		
					The above general enable conditions must be true for: Minimum accumulated counts in each cell required before counters will increment for that cell: Deceleration Idle Cruise Light Acceleration Heavy Acceleration	> 5.0 seconds 400 400 400 600 600		
					(Note: A value in any of the above operating "cells" that is an order of magnitude (or more) higher than other cells is an indication that the diagnostic is not capable of diagnosing in that cell). For the cells identified as			

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions column), the fail counter will increment if the sample counter increments AND Post oxygen sensor control integral offset (in mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration (Note: A value in any of the above operating "cells" that is greater than 900mV is an indication that the diagnostic is not capable of diagnosing in that cell).	<= -100 (control min.= -100) -100 (control min.= -100) -485 (control min.= -500) -500 (control min.= -500) -500 (control min.= -500) > 760 mV 760 mV 760 mV 760 mV 760 mV		

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System High Limit Bank 1 (Too Lean)	P2097	Determines if the post catalyst O2 sensor based fuel control system has utilized all or most of its high limit authority, indicating a lean emissions/exhaust gas condition. Note: If the post catalyst O2 voltage is too lean, the post catalyst O2 integral offset control is increased. This results in rich bias fuel control in an attempt to correct the lean condition. A perfectly balanced control system (no rich or lean bias required) is represented by an integral offset value of "0" and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean). An integral offset value > 0 is indicative of the control system reacting to a lean post catalyst O2 sensor. If the failure is such that the control system utilizes all or most of its available authority, then P2097 will set.	Lean Fail counter High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 18% for >= 5.0 seconds. Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 14% for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.	>= 350 counts per 675 sample counts Note: Counters increment at a rate of 10 per second when enable conditions are met. If the fail count threshold is reached, a fail is reported and the diagnostic will not report again until the next trip. If the sample count threshold is reached before a fail is reported, a pass is reported, the counters are reset to 0, and evaluation starts again.	Same as P2096 except for the following: For the cells identified as enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions for P2096), the fail counter will increment if the sample counter increments AND Post oxygen sensor control integral offset (in mV) is Deceleration Idle Cruise Light Acceleration Heavy Acceleration AND Post O2 Voltage is Deceleration Idle Cruise Light Acceleration Heavy Acceleration (Note: A value in any of the above operating "cells" that is less than 100mV is an indication that the diagnostic is not capable of diagnosing in that cell).	>= 100 (control max.= 100) 100 (control max.= 100) 485 (control max.= 500) 500 (control max.= 500) 500 (control max.= 500) < 650 mV 650 mV 650 mV 650 mV 650 mV	Frequency: Continuous Monitoring in 100ms loop. Counters increment when enable conditions are met. When sample count threshold is reached or fail threshold is reached, counters are reset to 0 and start over.	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Throttle Actuator Position Performance	P2101	1) Detect a throttle positioning error2) Throttle control is driving the throttle in the incorrect direction3) Throttle control exceeds the reduced power limit	Difference between measured throttle position and modeled throttle position >	10.00 percent	TPS minimum learn is not active and Throttle is being Controlled and (Engine Running or Ignition Voltage > or Ignition Voltage >) Ignition voltage failure is false (P1682)	Run/Crank voltage > 6.41 Ignition voltage failure is false (P1682) TPS minimum learn is not active and Throttle is being Controlled AND ((Engine Running AND Ignition Voltage > 5.50) OR Ignition Voltage > 8.41)	15 counts; 12.5 ms/count in the primary processor	Type A, 1 Trips
			OR					
			Difference between modeled throttle position and measured throttle position >	10.00 percent				
			Throttle Position >	39.52 percent		Powertrain Relay voltage > 6.41 TPS minimum learn is active	11 counts; 12.5 ms/count in the primary processor	
			Throttle Position >	38.52 percent		Powertrain Relay voltage > 6.41 Reduced Power is True	11 counts; 12.5 ms/count in the primary processor	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage <	0.4625		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Hi	P2123	Detect a continuous or intermittent short or open in the APP sensor #1 on Main processor	APP1 Voltage >	4.7500		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P06A3)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage <	0.3250		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P0697)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detect a continuous or intermittent short or open in the APP sensor #2 on Main processor	APP2 Voltage >	2.6000		Run/Crank voltage > 6.41 No 5V reference error or fault for # 4 5V reference circuit (P0697)	19 / 39 counts or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position (TP) Sensor 1-2 Correlation	P2135	Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	Difference between TPS1 displaced and TPS2 displaced >	6.775 % offset at min. throttle position with a linear threshold to 9.623 % at max. throttle position		Run/Crank voltage > 6.41 No TPS sensor faults (P0122, P0123, P0222, P0223) No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min TPS1) and (normalized min TPS2) >	5.000 % Vref		Run/Crank voltage > 6.41 No TPS sensor faults (P0122, P0123, P0222, P0223) No 5V reference error or fault for # 4 5V reference circuit (P06A3)	79 / 159 counts or 58 counts continuous; 3.125 ms/count in the main processor	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >	5.000 % offset at min. pedal position with a linear threshold to 10.001 % at max. pedal position		Run/Crank voltage > 6.41 No APP sensor faults (P2122, P2123,P2127, P2128) No 5V reference errors or faultst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19 / 39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min APP1) and (normalized min APP2) >	5.000 % Vref		Run/Crank voltage > 6.41 No APP sensor faults (P2122, P2123,P2127, P2128) No 5V reference errors or faultst for # 3 & # 4 5V reference circuits (P06A3, P0697)	19 / 39 counts intermittent or 15 counts continuous, 12.5 ms/count in the main processor	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Minimum Throttle Position Not Learned	P2176	TP sensors were not in the minimum learn window after multiple attempts to learn the minimum.	During TPS min learn on the Main processor, TPS Voltage > AND Number of learn attempts >	0.7170 10 counts		Run/Crank voltage > 6.41 TPS minimum learn is active No previous TPS min learn values stored in long term memory	2.0 secs	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling System Performance	P2181	This DTC detects thermostat malfunction (i.e. stuck open)	<p>This diagnostic can be calibrated to fail in <u>one</u> of two methods based on the following calibration. This application has been calibrated as a Type 0 .</p> <p><u>Type 0 - Airflow Method:</u> Engine Coolant Temp (ECT) is \leq commanded temperature minus 11 Deg C and normalized ratio is \leq than 2.00 . When above is present for more than 5 seconds, fail counts start. == Ratio Definition:=== Current temp difference between ECT and RCT minus PwrUp difference divided by total airgrams. Note: Minimum total airgrams is 800.0 grams.</p> <p><u>Type 1 - Energy Method:</u> Engine Coolant Temp (ECT) is \leq commanded temperature minus 11 Deg C and normalized ratio is \leq than 0.01 . When above is present for more than 5 seconds, fail counts start. == Ratio Definition:=== Current temp difference between ECT and RCT minus PwrUp difference divided by predicted energy.</p>		<p>No Active DTC's</p> <p>Engine not run time</p> <p>Engine run time</p> <p>Fuel Condition ECT at Power Up IAT min T-Stat Heater duty cycle commanded</p> <p>Type 0: Airflow range to accumulate</p> <p>Type 1: Minimum energy to enable</p>	<p>MAF_SensorFA IAT_SensorFA THMR_RCT_Sensor_Ckt_FA THMR_ECT_Sensor_Ckt_FA THMR_AHV_FA $\geq 7,200$ seconds</p> <p>120 \leq Time \leq 1,200 seconds</p> <p>Ethanol \leq 100 % $-40.0 \leq$ ECT \leq 45.0 °C $-7 \text{ }^\circ\text{C} \leq$ IAT \leq 60 °C.</p> <p>$\leq 20 \%$</p> <p>8.0 \leq Airflow \leq 100.0 gps</p> <p>10.0 kJ</p>	<p>320 failures out of 400 samples</p> <p>1 sec/ sample</p> <p>Once per ignition key cycle</p>	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 1 Air-Fuel Ratio Imbalance	P219A	This monitor determines if a cylinder-to-cylinder air-fuel ratio imbalance is present on bank 1.	<p>Filtered Ratio ></p> <p>Note: The input to this metric is the pre catalyst oxygen sensor voltage. This voltage is used to generate a Variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without). Multiple samples are collected in making a decision.</p> <p>The observed Variance is dependant on engine speed and load and so each result is normalized for speed and load by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric.</p> <p>The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (Supporting Table "Variance Threshold Bank1") and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table</p>	0.32	<p>System Voltage</p> <p>Fuel Level</p> <p>Engine Coolant Temperature</p> <p>Cumulative engine run time</p> <p>Diagnostic enabled at Idle (regardless of other operating conditions)</p> <p>Engine speed range</p> <p>Engine speed delta during a short term sample period</p> <p>Mass Airflow (MAF) range</p> <p>Cumulative delta MAF during a short term sample period</p> <p>Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF = 0.050</p> <p>Air Per Cylinder (APC)</p> <p>APC delta during short term sample period</p> <p>Filtered APC delta between samples</p>	<p>no lower than 11.0 Volts for more than 0.2 seconds</p> <p>> 10.0 percent AND no fuel level sensor fault</p> <p>> -20 degrees C</p> <p>> 0.0 seconds</p> <p>No</p> <p>1,200 to 7,000 RPM</p> <p>< 150 RPM</p> <p>0 to 200 g/s</p> <p>< 2 g/s</p> <p>< 0.25 g/s</p> <p>100 to 500 mg/cylinder</p> <p>< 50 mg/cylinder</p> <p>< 0.30 percent</p>	<p>Minimum of 1 test per trip, up to 6 tests per trip during RSR or FIR.</p> <p>The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example, 14.40 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such significantly more operating time is required than is indicated above. Generally, a report will be</p>	Type A, 1 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>(Supporting Table "Normalizer Bank1"). This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (Supporting Table "Quality Factor Bank1"). This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used.</p> <p>Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered Ratio.</p> <p>The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific.</p> <p>Some applications may need to command a unique cam phaser value before performing the</p>		<p>Note: first order lag filter coefficient applied to APC = 0.050</p> <p>Spark Advance</p> <p>Throttle Area (percent of max)</p> <p>Intake Cam Phaser Angle</p> <p>Exhaust Cam Phaser Angle</p> <p>Quality Factor (QF) QF calibrations are located in a 17x17 lookup table versus engine speed and load (Supporting Table "Quality Factor Bank1"). QF values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data.</p> <p>Fuel Control Status Closed Loop and Long Term FT Enabled for:</p> <p>AIR pump not on CASE learn not active EGR - no device control, no intrusive diagnostics EVAP - no device control, no intrusive diagnostics Engine OverSpeed</p>	<p>5 to 55 degrees</p> <p>3 to 200 percent</p> <p>0 to 25 degrees</p> <p>0 to 25 degrees</p> <p>>= 0.99</p> <p>>= 1.2 seconds (Please see "Closed Loop Enable Criteria" and "Long Term FT Enable Criteria" in Supporting Tables)</p>	<p>made within 5 minutes of operation.</p> <p>For RSR or FIR, 6 tests must complete before the diagnostic can report.</p>	

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use this feature.</p>		<p>Protection Not Active Idle speed control normal PTO Not Active Injector base pulse width above min limit O2 Learned htr resistance</p> <p>Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is AND it exceeds the last Filtered ratio by</p> <p>Once triggered, the filtered ratio is reset to:</p> <p>Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to:</p> <p>No Fault Active for:</p>	<p>= Valid (the O2 heater resistance has learned since NVM reset)</p> <p>>= 0.32</p> <p>>= 0.52</p> <p>0.00</p> <p>0.00</p> <p>EngineMisfireDetected_FA MAP_SensorFA MAF_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDefaulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbl_FA CamSensorAnyLocationFA FuelTrimSystemB1_FA</p>		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						O2S_Bank_1_Sensor_1_ FA O2S_Bank_1_Sensor_2_ FA WRAF_Bank_1_FA		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Post fuel cell (Decel) Crankshaft Torque EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ===== All of the above met for at least 0.0 seconds, and then check the following Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled) Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) ===== All of the above met for at least 2.0 seconds, and then the Force Cat Rich intrusive stage is requested. ===== During Stuck Lean test the following must stay TRUE or the test will abort: Commanded Fuel Crankshaft Torque	= enabled < 100.0 Nm = not active = not active ≥ 80.0 sec 650 ≤ °C ≤ 900 = DFCO possible ===== ===== 1,100 ≤ RPM ≤ 3,500 1,050 ≤ RPM ≤ 3,650 37.9 ≤ MPH ≤ 80.8 28.0 ≤ MPH ≤ 83.3 ===== 0.96 ≤ EQR ≤ 1.10 < 110.0 Nm		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Take Off EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State DTC's Passed ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	= not active = not active = not active ≥ 80.0 sec 650 ≤ °C ≤ 900 DFCO possible = P2270 (and P2272 if applicable) = P013E (and P014A if applicable) = P013A (and P013C if applicable) =====		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT LOW	P2300	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT High	P2301	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT Low	P2303	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT High	P2304	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT Low	P2306	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT High	P2307	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT Low	P2309	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT High	P2310	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 5.00 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Torque Request Circuit	P2544	Determines if the torque request from the TCM is valid	Protect error - Serial Communication message 2's complement not equal (\$189/\$199)	Message <> two's complement of message	Diagnostic Status	Enabled	>= 16 failures out of 20 samples. Performed on every received message >= 6 Rolling count errors out of 10 samples. Performed on every received message >= 6 range errors out of 10 samples. Performed on every received message >= 3 multi-transitions out of 5 samples. Performed every 200 msec	Type B, 2 Trips
			OR Rolling count error - Serial Communication message (\$189/\$199) rolling count index value	Message <> previous message rolling count value + one	Power Mode	= Run		
			OR Range Error - Serial Communication message - (\$189/\$199) TCM Requested Torque Increase	> 350 Nm	Ignition Voltage	> 6.41 volts		
			OR Multi-transition error - Trans torque intervention type request change	Requested torque intervention type toggles from not increasing request to increasing request	Engine Running	= True		
					Run/Crank Active	> 0.50 Sec		
				No Serial communication loss to TCM (U0101)	No loss of communication			

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Off Timer Performance	P262B	<p>This DTC determines if the hardware timer does not initialize or count properly. There are two tests to ensure proper functioning of the timer: Count Up Test (CUT) and Range Test (RaTe).</p> <p>Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment.</p> <p>Range Test (RaTe): When the run/crank is not active both the hardware and mirror timers are started. The timers are compared when module shutdown is initiated or run/crank becomes active.</p>	<p>Count Up Test: Time difference between the current read and the previous read of the timer</p> <p>Range Test: The variation of the HWIO timer and mirror timer is</p>	<p>> 1.50 seconds</p> <p>> 24.87 %.</p>			<p>Count Up Test: 4 failures out of 20 samples</p> <p>1 sec / sample</p> <p>Continuous while run/crank is not active and until controller shutdown is initiated.</p> <p>Range Test: Once per trip when controller shutdown is initiated or run/crank becomes active.</p>	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Low	P263A	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between signal and controller ground	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	50 failures out of 63 samples 50 ms / sample	Type B, No MIL NO MIL Note: In certain controllers P0650 may also set (MIL Control Open Circuit)

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) High	P263B	Diagnoses the malfunction indicator lamp control low side driver circuit for circuit faults.	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between signal and controller power	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11 volts	4 failures out of 5 samples 50 ms / sample	Type B, No MIL NO MIL

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communicati on Bus A Off	U0073	This DTC monitors for a BUS A off condition	Bus off failures exceeds before the sample time of is reached	5 counts (equivalent to 0.06 seconds) 0.56 seconds	General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds CAN hardware is bus OFF for	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or >= 6.41 = run = 0 (1 indicates enabled) = Active > 11.00 > 0.1125 seconds	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With TCM	U0101	This DTC monitors for a loss of communication with the transmission control module	Message is not received from controller for		General Enable Criteria:		Diagnostic runs in 12.5 ms loop	Type B, 2 Trips
			Message \$0AB	≥ 10.0 seconds	U0073	Not Active on Current Key Cycle		
			Message \$0BD	≥ 2.0 seconds	Normal CAN transmission on Bus A	Enabled		
			Message \$0C7	≥ 10.0 seconds	Device Control	Not Active		
			Message \$0F9	≥ 2.0 seconds	High Voltage Virtual Network Management	Not Active		
			Message \$189	≥ 2.0 seconds	Ignition Voltage Criteria:			
			Message \$199	≥ 2.0 seconds	Ignition voltage	≥ 11.00 or ≥ 6.41		
			Message \$19D	≥ 2.0 seconds				
			Message \$1AF	≥ 2.0 seconds	Power Mode	= run		
			Message \$1BE	≥ 10.0 seconds	Off Cycle Enable Criteria:			
			Message \$1BF	≥ 10.0 seconds	KeCAND_b_OffKeyCycle DiagEnbl	= 0 (1 indicates enabled)		
			Message \$1F5	≥ 2.0 seconds				
			Message \$4C9	≥ 2.0 seconds	Ignition Accessory Line and Battery Voltage	= Active > 11.00		
			General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds					
			Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is					

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for U0101 TCM	> 0.4000 seconds Not Active on Current Key Cycle is present on the bus		

15 OBDG03 ECM Summary Tables

Component/System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Anti-Lock Brake System (ABS) Control Module	U0121	This DTC monitors for a loss of communication with the Anti-Lock Brake System (ABS) Control Module (Non-OBD Module ID 243).	Message is not received from controller for		General Enable Criteria: U0073	Not Active on Current Key Cycle	Diagnostic runs in 12.5 ms loop	Type C, No MIL "Special Type C"
			Message \$0C1	≥ 10.0 seconds	Normal CAN transmission on Bus A	Enabled		
			Message \$0C5	≥ 10.0 seconds	Device Control	Not Active		
			Message \$0D1	≥ 10.0 seconds	High Voltage Virtual Network Management	Not Active		
			Message \$1C6	≥ 10.0 seconds	Ignition Voltage Criteria:			
			Message \$1C7	≥ 10.0 seconds	Ignition voltage	≥ 11.00 or ≥ 6.41		
			Message \$1E9	≥ 10.0 seconds	Power Mode	= run		
			Message \$2F1	≥ 10.0 seconds	Off Cycle Enable Criteria:			
			Message \$2F9	≥ 10.0 seconds	KeCAND_b_OffKeyCycle DiagEnbl	= 0 (1 indicates enabled)		
					Ignition Accessory Line and Battery Voltage	= Active > 11.00		
					General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds			
					Power Mode is in accessory or run or crank and High Voltage Virtual			

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Network Management is not active for U0121 Anti-Lock Brake System Control Module	> 0.4000 seconds Not Active on Current Key Cycle is present on the bus		

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Body Control Module	U0140	This DTC monitors for a loss of communication with the Body Control Module.	Message is not received from controller for		General Enable Criteria: U0073 Normal CAN transmission on Bus A Device Control High Voltage Virtual Network Management Ignition Voltage Criteria: Ignition voltage Power Mode Off Cycle Enable Criteria: KeCAND_b_OffKeyCycle DiagEnbl Ignition Accessory Line and Battery Voltage General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 3.0000 seconds Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is	Not Active on Current Key Cycle Enabled Not Active Not Active >= 11.00 or >= 6.41 = run = 0 (1 indicates enabled) = Active > 11.00 > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Type C, No MIL "Special Type C"

15 OBDG03 ECM Summary Tables

Component/ System	Fault Code	Monitor Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					not active for U0140 Body Control Module	Not Active on Current Key Cycle is present on the bus		

Closed Loop Enable Clarification: Calibration values are in the Supporting Tables

Engine run time greater than

KtFSTA_t_ClosedLoopAutostart (HYBRID ONLY)

AutoStart Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Close Loop Enable Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

and

KtFSTA_t_ClosedLoopTime

Start-Up Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Close Loop Enable Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

and pre converter O2 sensor voltage less than

KfFULC_U_O2_SensorReadyThresh

Lo

Voltage < milliVolts

for

KcFULC_O2_SensorReadyEvents

Time (events * 12.5 milliseconds) > events

and

COSC (Converter Oxygen Storage Control) not enabled

and

Consumed AirFuel Ratio is stoichiometry i.e. not in component protection

and

POPD or Catalyst Diagnostic not intrusive

and

Turbo Scavenging Mode not enabled

and

All cylinders whose valves are active also have their injectors enabled

and

O2S_Bank_1_TFTKO, O2S_Bank_2_TFTKO, FuelInjectorCircuit_FA and CylinderDeacDriverTFTKO = False

Long Term FT Enable Criteria

Closed Loop Enable Clarification: Calibration values are in the Supporting Tables

**Closed Loop Enable and
Coolant greater than
KfFCLL_T_AdaptiveLoCoolant**

Coolant > XXXXCelcius

**or less than
KfFCLL_T_AdaptiveHiCoolant**

Coolant < XXXXCelcius

**and
KtFCLL_p_AdaptiveLowMAP_Limit**

Barometric Pressure	X1	X2	X3	X4	X5	X6	X7	X8	X9
Manifold Air Pressure	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9

**and
TPS_ThrottleAuthorityDefaulted =
False**

**and
Flex Fuel Estimate Algorithm is not active**

**and
Excessive fuel vapors boiling off from the engine oil algorithm (BOFR) is not
enabled**

**and
Catalyst or EVAP large leak test not
intrusive**

**Secondary Fuel Trim Enable
Criteria**

**Closed Loop Enable and
KfFCLP_U_O2ReadyThrshLo**

Voltage < XXXXmilliVolts

**for
KcFCLP_Cnt_O2RdyCyclesThrsh**

Time (events * 12.5 milliseconds) > XXXXevents

**Long Term Secondary Fuel Trim
Enable Criteria**

KtFCLP_t_PostIntglDisableTime

Closed Loop Enable Clarification: Calibration values are in the Supporting Tables

Start-Up Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Enable Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

Plus

KtFCLP_t_PostIntglRampInTime

Start-Up Coolant	X1	X2	X3	X4	X5	X6	X7	X8	X9	X10	X11
Post Integral Ramp In Time	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y8	Y9	Y10	Y11

and

KeFCLP_T_IntegrationCatalystMax

Modeled Catalyst Temperature < XXXXXCelcius

and

KeFCLP_T_IntegrationCatalystMin

Modeled Catalyst Temperature > XXXXXCelcius

and

PO2S_Bank_1_Snsr_2_FA and

PO2S_Bank_2_Snsr_2_FA = False

and

(KeFCLP_Pct_CatAccuSlphrPostDsbl

Modeled converter sulfur percent < XXXX Percent

and

Post Integral < KaFCLP_U_SlphrIntglOfst_Thrsh)

X axis: Post O2 Sensor

Y axis: Post O2 Mode

Z: Post Integral threshold

15 OBDG03 ECM Supporting Tables

Initial Supporting table - Multiple DTC Use_Green Sensor Delay Criteria - Airflow

Description: This Calibration is the airflow (in gps) above which the green airflow is accumulated to expire the condition.

Notes: Used for: P0133, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P0153, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273. The specific diagnostic (from summary table) will not be enabled until the next ignition cycle after the airflow criteria below (by sensor location) has been met:

y/x	1
1	7

15 OBDG03 ECM Supporting Tables

Initial Supporting table - Multiple DTC Use_Green Sensor Delay Criteria - Limit

Description: This Calibration is the accumulated airflow (in grams) limit above which the green condition is expired

Notes: Used for: P0133, P013A, P013B, P013C, P013D, P013E, P013F, P014A, P014B, P0153, P015A, P015B, P015C, P015D, P1133, P1153, P2270, P2271, P2272 and P2273. Note: This feature is only enabled when the vehicle is new and cannot be enabled in service

y/x	CiOXYR_O2_Bank1_Sensor1	CiOXYR_O2_Bank1_Sensor2	CiOXYR_O2_Bank2_Sensor1	CiOXYR_O2_Bank2_Sensor2
1	120,000	120,000	120,000	120,000

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM

Notes:

y/x	750	1,850	2,350	2,650	2,950	3,150	3,250	3,400	3,600	3,850	4,100	4,350	4,750	5,250	5,750	6,250	6,750
1	0.850	0.850	0.850	0.900	0.950	0.950	0.950	0.950	0.950	0.950	0.950	0.950	0.950	0.950	0.950	0.950	0.950

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

Notes:

y/x	750	1,850	2,350	2,650	2,950	3,150	3,250	3,400	3,600	3,850	4,100	4,350	4,750	5,250	5,750	6,250	6,750
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM

Notes:

y/x	750	1,850	2,350	2,650	2,950	3,150	3,250	3,400	3,600	3,850	4,100	4,350	4,750	5,250	5,750	6,250	6,750
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0133_KnEOSD_t_ST_LRC_LimRS1

Description: KnEOSD_t_ST_LRC_LimRS1. X Table Axis (in sec) for P0133, L2R Reponse time breakpoints for table

Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.020	0.040	0.060	0.080	0.100	0.120	0.140	0.160	0.180	0.200	0.220	0.240	0.260	0.280	0.300	1.000

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0133_KnEOSD_t_ST_RLC_LimRS1

Description: KnEOSD_t_ST_RLC_LimRS1. Y Table Axis (in sec) for P0133, R2L Reponse time breakpoints for table

Notes:

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0.000	0.020	0.040	0.060	0.080	0.100	0.120	0.140	0.160	0.180	0.200	0.220	0.240	0.260	0.280	0.300	1.000

Initial Supporting table - P0133_O2S Slow Response Bank 1 Sensor 1 "Pass/Fail Threshold table"

Description: KaEOSD_x_ST_ResponseLimRS1[x][y]

Notes: X axis is Lean to Rich response time (in sec), Please see the table below named "KnEOSD_t_ST_LRC_LimRS1" for the 17 X axis table breakpoints. Y axis is Rich to Lean response time (sec), Please see the cal table below named "KnEOSD_t_ST_RLC_LimRS1" for the 17 Y axis table breakpoints. Z axis is the pass/fail result, Note: If the cell contains a "0" then the fault is indicated, if it contains a "1" a fault is not indicated.

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
2	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
3	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
4	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0	0
5	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0	0
6	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
7	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
8	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
9	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
10	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
11	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
12	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0	0	0
13	0	0	0	1	1	1	1	1	1	1	1	1	0	0	0	0	0
14	0	0	0	0	1	1	1	1	1	1	1	1	0	0	0	0	0
15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0068_Delta MAF Threshold f(TPS)

Description: Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

Notes: P0068, KtTPSD_dm_MAF_DesThrDelt

y/x	10.00	15.00	20.00	25.00	30.00	35.00	40.00	45.00	100.00
1.00	5.25	10.01	12.76	16.22	20.24	255.00	255.00	255.00	255.00

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0068_Delta MAP Threshold f(TPS)

Description: Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

Notes: P0068, KtTPSD_p_MAP_DesThrDelt

y/x	10.00	15.00	20.00	25.00	30.00	35.00	40.00	45.00	100.00
1.00	36.73	45.02	42.28	35.51	32.73	255.00	255.00	255.00	255.00

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0068_Maximum MAF f(RPM)

Description: Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

Notes: P0068, KtTPSD_dm_MaxMAF_VsRPM

y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
1.00	3.00	16.00	16.00	17.00	18.00	45.00	45.00	50.00	60.00

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0068_Maximum MAF f(Volts)

Description: Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.

Notes: P0068, KtTPSD_dm_MaxMAF_VsVoltage

y/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00
1.00	278.00	278.00	278.00	278.00	278.00	278.00	278.00	278.00	278.00

Initial Supporting table - P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage

Description: Identifies which Long Term Fuel Trim Cell I.D.s are used for diagnosis. Only cells identified as "CeFADD_e_NonSelectedCell" are not used for diagnosis.

Notes: DTCs: P0171, P0172, P0174, P0175; Calibration Name: KaFADD_e_SelectCellSet; Axis is Long Term Fuel Trim Cell I.D.

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 1

y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 2

y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_NonSelectedCell

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 3

y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 4

y/x	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_NonSelectedCell

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0606_Last Seed Timeout f(Loop Time)

Description: The max time for the Last Seed Timeout as a function of operating loop time sequence.

Notes: P0606, KaPISD_t_LastSeedTimeout[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	0.175	0.175	0.175	409.594

Initial Supporting table - P0606_Program Sequence Watch Enable f(Loop Time)

Description: The enabling flags for the program sequence watch as a function of operating loop time sequence.

Notes: P0606, KaPISD_b_ProgSeqWatchEnbl

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	1	1	1	1

Initial Supporting table - P0606_PSW Sequence Fail f(Loop Time)

Description: Fail threshold for PSW per operating loop.

Notes: P0606, KaPISD_Cnt_SequenceFail[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	3	3	3	3

Initial Supporting table - P0606_PSW Sequence Sample f(Loop Time)

Description: Sample threshold for PSW per operating loop.

Notes: P0606, KaPISD_Cnt_SequenceSmp[x]

y/x	CePISR_e_6p25msSeq	CePISR_e_12p5msSeq	CePISR_e_25msSeq	CePISR_e_LORES_C
1	4	4	4	4

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P1682_PT Relay Pull-in Run/Crank Voltage f(IAT)

Description: The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

Notes: P1682, KtEROR_U_PT_RelayPullInEnbl

y/x	23.00	85.00	95.00	105.00	125.00
1.00	7.00	8.70	9.00	9.20	10.00

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P16F3_Delta MAP Threshold f(Desired Engine Torque)

Description: Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

Notes: P16F3, KtMAPI_p_ES_TB_MAP_DeltaThresh

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	32.73	32.73	32.73	32.73	32.73	32.73

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P16F3_Delta Spark Threshold f(RPM,APC)

Description: Threshold for determining when the difference between commanded spark and applied spark exceeds the torque security requirement. It is a function of engine rpm and APC.

Notes: P16F3, KtSPRK_phi_DeltTorqueScrtAdv

y/x	500.00	980.74	1,461.48	1,942.23	2,422.97	2,903.71	3,384.45	3,865.20	4,345.94	4,826.68	5,307.42	5,788.16	6,268.91	6,749.65	7,230.39	7,711.13	8,191.88
80.00	125.00	30.72	33.22	33.52	28.98	30.06	29.61	28.42	27.59	26.19	24.13	25.00	26.34	26.34	26.34	26.34	26.34
160.00	125.00	28.72	29.81	31.02	27.41	28.81	27.92	26.17	25.77	24.97	23.75	23.73	23.97	23.97	23.97	23.97	23.97
240.00	125.00	26.95	27.03	28.88	25.14	25.00	24.70	23.86	23.63	22.95	21.80	21.75	21.94	21.94	21.94	21.94	21.94
320.00	125.00	25.41	24.73	26.50	21.89	21.61	21.52	20.77	20.52	19.86	18.77	18.48	18.41	18.41	18.41	18.41	18.41
400.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50
480.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50
560.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50
640.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50
720.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50
800.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50
880.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50
960.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50
1,040.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50
1,120.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50
1,200.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50
1,280.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50
1,360.00	125.00	24.53	23.48	25.02	20.05	19.92	19.84	19.08	18.91	18.31	17.25	16.78	16.50	16.50	16.50	16.50	16.50

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P16F3_Speed Control External Load f(Oil Temp, RPM)

Description: Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

Notes: P16F3, KtSPDC_M_ExternalLoad

y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
200.00	187.50	187.50	187.50	187.50	187.50	187.50
500.00	5,120.00	5,120.00	5,120.00	5,120.00	5,120.00	5,120.00
600.00	5,120.00	5,120.00	5,120.00	5,120.00	5,120.00	5,120.00
670.00	5,120.00	5,120.00	5,120.00	5,120.00	250.00	250.00
850.00	5,120.00	5,120.00	5,120.00	5,120.00	218.75	218.75
900.00	187.50	187.50	187.50	187.50	187.50	187.50
1,000.00	131.25	131.25	131.25	131.25	49.35	32.59
1,100.00	131.25	131.25	131.25	131.25	62.70	43.92
1,200.00	203.77	192.05	159.79	127.52	103.52	58.30
1,350.00	193.04	181.32	146.79	112.66	64.91	63.04
1,500.00	157.39	146.98	113.49	56.77	56.77	54.89
1,700.00	120.95	111.83	54.23	47.82	47.82	45.95
2,000.00	50.99	44.48	39.27	32.86	32.86	30.99
2,500.00	29.45	22.94	17.74	11.33	11.33	9.45
3,000.00	8.41	1.90	-1.99	-5.83	-5.83	-6.95
3,500.00	-3.25	-7.15	-10.28	-14.12	-14.12	-15.25
4,500.00	-3.98	-7.88	-11.01	-14.85	-14.85	-15.98

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P219A Normalizer Bank1 Table

Description: Bank 1 Normalizer table used in the calculation of the Ratio for the current sample period.

Notes: DTCs: P219A; Calibration Name: KtFABD_U_Normalizer1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	700	900	1,100	1,300	1,500	1,700	1,900	2,100	2,300	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000
90	400.00	400.00	400.00	400.00	400.00	400.00	92.50	92.50	109.25	126.00	126.00	400.00	400.00	400.00	400.00	400.00	400.00
135	400.00	400.00	100.00	100.00	107.25	125.75	97.25	92.50	100.00	126.00	85.25	36.50	23.75	23.75	400.00	400.00	400.00
180	400.00	400.00	100.00	100.00	107.25	125.75	102.00	82.00	81.50	67.50	44.75	36.50	23.75	23.75	32.00	32.00	400.00
225	400.00	400.00	111.25	111.25	115.00	151.50	138.25	116.00	85.25	63.00	59.00	47.00	34.50	37.00	32.00	32.00	400.00
270	400.00	400.00	111.25	111.25	135.50	156.25	154.00	141.75	134.75	90.75	80.00	69.00	57.50	44.25	38.25	32.00	400.00
315	400.00	400.00	400.00	400.00	164.00	164.00	168.00	161.50	146.00	117.00	102.25	106.00	101.25	72.75	44.25	400.00	400.00
360	400.00	400.00	400.00	400.00	164.00	164.00	168.00	161.50	146.00	117.00	102.25	106.00	101.25	101.25	400.00	400.00	400.00
405	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
450	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
495	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
540	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
585	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
630	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
675	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
720	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
900	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00
1,080	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00	400.00

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P219A Quality Factor Bank1 Table

Description: Bank 1 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

Notes: DTCs: P219A; Calibration Name: KtFABD_K_QualFactor1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	700	900	1,100	1,300	1,500	1,700	1,900	2,100	2,300	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000
90	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
135	0.00	0.00	0.00	0.00	0.00	0.00	0.00	1.00	0.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
180	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
225	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	1.00	0.00	0.00
270	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
315	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
360	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
405	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
450	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
495	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
540	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
585	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
630	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
675	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
720	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
900	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
1,080	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P219A Variance Threshold Bank1 Table

Description: Bank 1 lookup table of Variance metric used to calculate the Ratio for the current sample period

Notes: DTCs: P219A; Calibration Name: KtFABD_U_VarThresh1; Horizontal axis is RPM; Vertical Axis is Air Per Cylinder (APC) in mg/cylinder

y/x	700	900	1,100	1,300	1,500	1,700	1,900	2,100	2,300	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000
90	200.00	200.00	200.00	200.00	200.00	200.00	47.50	47.50	44.00	40.75	40.75	200.00	200.00	200.00	200.00	200.00	200.00
135	200.00	200.00	39.00	39.00	45.75	43.00	51.75	47.50	43.00	40.75	33.00	33.75	32.50	32.50	200.00	200.00	200.00
180	200.00	200.00	39.00	39.00	45.75	43.00	56.25	48.50	41.25	33.00	25.50	33.75	32.50	32.50	22.75	22.75	200.00
225	200.00	200.00	60.50	60.50	87.75	63.50	54.75	51.25	48.25	31.50	30.25	33.00	36.50	32.75	22.75	22.75	200.00
270	200.00	200.00	60.50	60.50	72.00	56.25	60.00	63.50	55.50	50.50	49.50	40.50	43.50	38.75	30.75	22.75	200.00
315	200.00	200.00	200.00	200.00	61.00	61.00	58.25	50.25	60.25	48.75	38.00	32.00	28.50	33.50	38.75	200.00	200.00
360	200.00	200.00	200.00	200.00	61.00	61.00	58.25	50.25	60.25	48.75	38.00	32.00	28.50	28.50	200.00	200.00	200.00
405	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
450	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
495	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
540	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
585	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
630	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
675	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
720	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
900	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00
1,080	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00	200.00

Initial Supporting table - Closed Loop Enable Clarification - KaFCLP_U_SlphrIntglOfst_Thrsh

Description: Integral Offset voltage thresholds (bank and cell specific calcs) used with KeFCLP_Pct_CatAccuSlphrPostDsbl to check for sulphur poisoning.

Notes: millivolts

y/x	CiOXYR_O2_PostCat1	CiOXYR_O2_PostCat2
CiFCLP_Decel	2,048	2,048
CiFCLP_Idle	2,048	2,048
CiFCLP_Cruise	2,048	2,048
CiFCLP_LightAccel	2,048	2,048
CiFCLP_HeavyAccel	2,048	2,048

Initial Supporting table - Closed Loop Enable Clarification - KcFCLP_Cnt_O2RdyCyclesThrsh

Description: Number of post catalyst oxygen sensor samples which must be outside not ready window before post oxygen sensor is READY.

Notes: Time (events * 12.5 milliseconds)

y/x	1
1	80

Initial Supporting table - Closed Loop Enable Clarification - KcFULC_O2_SensorReadyEvents**Description:** Number of times an oxygen sensor value must be in range before declaring it ready**Notes:** Time (events * 12.5 milliseconds)

y/x	
1	20

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_Pct_CatAccuSlphrPostDsbl

Description: Sulphur percent threshold above which post integral learning is disabled if the threshold criteria KaFCLP_U_SlphrIntglOfst_Thrsh is also met.

Notes: Percent

y/x	1
1	255

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMax

Description: Maximum allowed estimated catalytic converter temperature for post O2 integral terms to be updated.

Notes: Modeled catalyst Temperature in Celcius

y/x	1
1	900

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMin

Description: Minimum allowed estimated catalytic converter temperature to begin using post O2 integration correction terms. Converter temperature must remain above this threshold to ramp-in the post O2 integration adjustments. Once the ramp-in has started, a converter temperature below this threshold will freeze the ramp-in multiplier. Post O2 integration will not be allowed below this converter temperature

Notes: Modeled catalyst Temperature in Celcius

y/x	1
1	350

Initial Supporting table - Closed Loop Enable Clarification - KfFCLL_T_AdaptiveHiCoolant

Description: LTM learning is inhibited if the engine coolant temperature is above this calibration.

Notes: Degrees Celcius

y/x	1
1	255

Initial Supporting table - Closed Loop Enable Clarification - KfFCLL_T_AdaptiveLoCoolant

Description: LTM learning is inhibited if the engine coolant temperature is below this calibration.

Notes: Degrees Celcius

y/x	
1	40

Initial Supporting table - Closed Loop Enable Clarification - KfFCLP_U_O2ReadyThrshLo**Description:** Lower threshold defining not ready window for post oxygen sensor voltage.**Notes:** Voltage in millivolts

y/x	1
1	1,100

Initial Supporting table - Closed Loop Enable Clarification - KfFULC_U_O2_SensorReadyThrshLo

Description: Lower limit checked against when determining if an oxygen sensor is in range

Notes: Voltage in millivolts

y/x	1
1	1,100

15 OBDG03 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFCLL_p_AdaptiveLowMAP_Limit

Description: KtFCLL_p_AdaptiveLowMAP_Limit

Notes: MAP in KPa

y/x	65	70	75	80	85	90	95	100	105
1	17.0	17.0	17.0	17.0	17.5	18.0	18.5	19.0	19.0

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP_t_PostIntglDisableTime

Description: Disable integral offset after engine start for this amount of time.

Notes: Time in seconds

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	100.0	100.0	100.0	100.0	100.0	100.0	75.0	50.0	50.0	50.0	50.0	40.0	40.0	25.0	25.0	25.0	25.0

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP_t_PostIntglRampInTime

Description: Time required to ramp integral offset to desired value.

Notes: Time in seconds

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

15 OBDG03 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA_t_ClosedLoopAutostart

Description: Engine run time following an autostart, as a function of begin run coolant, which must be exceeded to enable CLOSED LOOP.

Notes: Time in seconds: Hybrid use Only

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	200.0	135.0	50.0	25.0	25.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0

15 OBDG03 ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA_t_ClosedLoopTime

Description: Engine run time, as a function of startup coolant temperature, which must be exceeded to enable CLOSED LOOP.

Notes: Time in seconds

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	200.0	135.0	45.0	25.0	25.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0420_BestFailingOSCTableB1

Description: This table is a 9x17 table of baseline Best Failing (e.g. threshold converter) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow,the BestFailing OSC value is found within this table for the measured temp and airflow and is used along with the OSC_TimeRaw (and the WorstPassing value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the identified BPU converter that is used for MIL illumination across the specific temp and airflow range for a given program.

Notes: KtCATD_t_1_OSC_BestFailing - Used for norm ratio calculation of P0420

y/x	1.29	1.84	2.40	2.95	3.50	4.05	4.60	5.16	5.71	6.27	6.81	7.37	7.92	8.48	9.02	9.58	10.13
467.45	2.13	1.03	0.70	0.55	0.46	0.41	0.37	0.35	0.33	0.31	0.30	0.29	0.28	0.27	0.27	0.26	0.26
522.63	2.39	1.15	0.78	0.61	0.52	0.46	0.42	0.39	0.37	0.35	0.34	0.32	0.31	0.31	0.30	0.29	0.29
577.78	2.67	1.29	0.87	0.68	0.58	0.51	0.47	0.43	0.41	0.39	0.38	0.36	0.35	0.34	0.33	0.33	0.32
632.95	2.99	1.44	0.98	0.77	0.65	0.57	0.52	0.49	0.46	0.44	0.42	0.41	0.39	0.38	0.38	0.37	0.36
688.11	3.34	1.61	1.09	0.86	0.72	0.64	0.58	0.54	0.51	0.49	0.47	0.45	0.44	0.43	0.42	0.41	0.40
743.28	3.74	1.80	1.22	0.96	0.81	0.72	0.65	0.61	0.57	0.55	0.53	0.51	0.49	0.48	0.47	0.46	0.45
798.45	4.18	2.02	1.37	1.07	0.91	0.80	0.73	0.68	0.64	0.61	0.59	0.57	0.55	0.54	0.53	0.51	0.51
853.61	4.68	2.26	1.53	1.20	1.01	0.90	0.82	0.76	0.72	0.68	0.66	0.63	0.62	0.60	0.59	0.58	0.57
908.78	5.23	2.53	1.71	1.34	1.13	1.00	0.92	0.85	0.80	0.77	0.74	0.71	0.69	0.67	0.66	0.64	0.63

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0420_P0430_CatmonMinAirflowForWarmCatalystDetermination

Description: This is a 1x3 table with the axis being engine coolant temperature. The implementation of this cal value as a table also included some changes to the way that the WarmedUpEvents counter increments and resets. To summarize, whenever WarmedUpEvents resets to 0 (this could be either at startup, if the closed throttle time exceeds a cal value, or if the predicted exhaust temperature falls below the ExhWarmMin cal value), the appropriate MinAirflowToWrmupCat value is chosen from the table based on engine coolant at the time the WarmedUpEvents counter reset to 0. This cal value is used along with the min exhaust temp to increment the WarmedUpEvents counter.

Notes: KtCATD_dm_MinAirFlowToWrmCat - Used for P0420 and P0430. Axis is the engine coolant and the output is the minimum airflow required to warmup the catalyst.

y/x	0	45	90
1	12	8	4

Initial Supporting table - P0420_P0430_CatmonMinEngineRunTimeToEnable

Description: This cal value is a 1x5 array of minimum engine run time values based on powerup coolant temperatures. When the appropriate required minimum engine run time value is chosen based on the coolant temperature at powerup, this value is the minimum time from engine start before stabilized conditions are met. Used in determining if a ValidIdleIsMet condition exists.

Notes: KtCATD_t_EngRunTimeMin - Used for P0420 and P0430. Axis is the coolant and the output is the min engine run time

y/x	40	50	60	70	80
1	0	0	0	0	0

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P0420_WorstPassingOSCTableB1

Description: This table is a 9x17 table of WorstPassing (e.g. 120k) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the WorstPassing OSC value is found within this table for the measured temp and airflow and is used along with the OSC_TimeRaw (and the BestFailing OSC value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the WPA part across the temp and airflow range.

Notes: KtCATD_t_1_OSC_WorstPassing - Used for norm ratio calculation of P0420

y/x	1.29	1.84	2.40	2.95	3.50	4.05	4.60	5.16	5.71	6.27	6.81	7.37	7.92	8.48	9.02	9.58	10.13
467.45	27.73	14.87	10.64	8.65	7.49	6.75	6.24	5.87	5.58	5.35	5.17	5.02	4.90	4.79	4.70	4.62	4.55
522.63	29.98	16.08	11.50	9.36	8.10	7.30	6.75	6.34	6.03	5.79	5.59	5.43	5.29	5.18	5.08	4.99	4.92
577.78	32.42	17.38	12.44	10.11	8.76	7.89	7.30	6.86	6.52	6.26	6.05	5.87	5.72	5.60	5.49	5.40	5.32
632.95	35.05	18.80	13.45	10.94	9.47	8.53	7.89	7.41	7.05	6.76	6.54	6.35	6.19	6.05	5.94	5.84	5.75
688.11	37.90	20.32	14.54	11.82	10.24	9.23	8.53	8.02	7.62	7.31	7.07	6.86	6.69	6.54	6.42	6.31	6.22
743.28	40.97	21.97	15.72	12.78	11.07	9.98	9.22	8.67	8.24	7.91	7.64	7.42	7.23	7.08	6.94	6.82	6.72
798.45	44.30	23.76	17.00	13.82	11.97	10.79	9.97	9.37	8.91	8.55	8.26	8.02	7.82	7.65	7.51	7.38	7.27
853.61	47.90	25.69	18.38	14.94	12.94	11.66	10.78	10.13	9.63	9.24	8.93	8.67	8.46	8.27	8.12	7.98	7.86
908.78	51.79	27.77	19.87	16.16	14.00	12.61	11.66	10.95	10.42	9.99	9.66	9.38	9.14	8.94	8.77	8.63	8.49

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P1400_ColdStartDiagnosticDelayBasedOnEngineRunTime

Description: Quality weight-based on engine run time. This allows adjustment of the weighting factors at various engine run times in order to prevent the updating of the cumulative quality timer or to change the value of the average qualified residual energy calculation to prevent false Fails of the diagnostic under circumstances inappropriate to update the calculation of the average qualified residual value.

Notes: KtCSED_K_TimeWght - This is used for P1400.

y/x	0	2	3	5	11	16	21	27	32
1	0	0	1	1	1	1	1	1	1

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P1400_ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis

Description: This is the x-axis for the KtCSED_K_TimeWght calibration table. Refer to the description for KtCSED_K_TimeWght for details.

Notes: KnCSED_t_TimeWght - This is used for P1400.

y/x	1	2	3	4	5	6	7	8	9
1	0	2	3	5	11	16	21	27	32

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P1400_EngineSpeedResidual_Axis

Description: This calibration is used as the x-axis for KtCSED_dm_Exh. An engine speed value will be chosen from this axis based on the value of VeSPDR_n_EngDsrd or actual engine speed. Subsequently, the engine speed value chosen from KnCSED_n_Exh determines the appropriate exhaust airflow value from the KtCSED_dm_Exh calibration table.

Notes: KnCSED_n_Exh - This is used for P1400

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0	300	600	900	1,200	1,500	1,800	2,100	2,400	2,700	3,000	3,300	3,600	3,900	4,200	4,500	4,800

Initial Supporting table - P1400_EngineSpeedResidual_Table

Description: This 1x17 table of engine exhaust flow values is used to calculate both the desired and the actual engine exhaust flow based on desired and actual engine speed. The desired engine exhaust flow is gathered from the desired engine speed (VeSPDR_n_EngDsrd). The value used for the actual engine exhaust flow is based on the actual engine RPM value.

Notes: KtCSED_dm_Exh - This is used for P1400

y/x	0	300	600	900	1,200	1,500	1,800	2,100	2,400	2,700	3,000	3,300	3,600	3,900	4,200	4,500	4,800
1	0	3	6	9	12	15	18	21	24	27	30	33	36	39	42	45	48

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P1400_SparkResidual_Axis

Description: Calibratable axis into KtCSED_E_ExhEngyPerUnitMass. This is a table of spark values. Spark value used for desired spark is the desired spark during cat light off. Actual spark value used is the final commanded spark.

Notes: KnCSED_phi_ExhEngyPerUnitMass - Used for P1400

y/x	1.00	2.00	3.00	4.00	5.00	6.00	7.00	8.00	9.00
1	-20	-16	-12	-8	-4	0	4	8	12

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P1400_SparkResidual_Table

Description: Predicted engine-out energy potential based on either the desired cold start spark advance value or the actual spark advance value. ExhEngyPerUnitMass calibration is used to calculate both desired exhaust energy and actual energy. The desired and actual exhaust energy per unit mass values are used in part to calculate the desired exhaust energy per unit time and actual exhaust energy per unit time. Both desired and actual go into the residual exhaust energy per unit time calculation.

Notes: KtCSED_E_ExhEngyPerUnitMass

y/x	-20	-16	-12	-8	-4	0	4	8	12
1	1.30	1.26	1.22	1.18	1.14	1.10	0.70	0.65	0.60

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P057B KtBRKI_K_CmpltTestPointWeight

Description:

Notes:

y/x	0.000	0.050	0.080	0.250	0.350	0.450	0.550	0.750	1.000
1	0	1	1	1	1	1	1	1	1

15 OBDG03 ECM Supporting Tables

Initial Supporting table - P057B KtBRKI_K_FastTestPointWeight

Description:

Notes:

y/x	0.000	0.050	0.080	0.250	0.350	0.450	0.550	0.750	1.000
1	0	1	1	1	1	1	1	1	1

15 OBDG03 Fault Bundle Definitions

Bundle Name: 5VoltReferenceA_FA
P0641
Bundle Name: 5VoltReferenceB_FA
P0651
Bundle Name: 5VoltReferenceMAP_OOR_Fit
P0697
Bundle Name: A/F Imbalance Bank1
P219A
Bundle Name: A/F Imbalance Bank2
P219B
Bundle Name: AAP_SnsrCktFA
Naturally aspirated: P2228, P2229. Turbocharged: P0237, P0238
Bundle Name: AAP_SnsrCktFP
Naturally aspirated: P2228, P2229. Turbocharged: P0237, P0238
Bundle Name: AAP_SnsrFA
Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.
Bundle Name: AAP_SnsrTFTKO
Naturally Aspirated: P2227, P2228, P2229, P2230. Turbocharged: P0237, P0238.
Bundle Name: AAP2_SnsrCktFA
P2228, P2229
Bundle Name: AAP2_SnsrCktFP
P2228, P2229
Bundle Name: AAP2_SnsrFA
P2227, P2228, P2229, P2230
Bundle Name: AAP2_SnsrTFTKO
P2227, P2228, P2229, P2230
Bundle Name: AAP3_SnsrCktFA
P222C, P222D
Bundle Name: AAP3_SnsrCktFP
P222C, P222D
Bundle Name: AccCktLo_FA
P2537
Bundle Name: AcceleratorPedalFailure
P2122, P2123, P2127, P2128, P2138, P0697, P06A3
Bundle Name: ACCMLostComm
U016B
Bundle Name: ACFailedOnSD
See ACCM Document

15 OBDG03 Fault Bundle Definitions

Bundle Name: ACHighSidePressSnsrCktFA
P0532, P0533
Bundle Name: ACThrmIRefrigSpdVld
See ACCM Document
Bundle Name: AfterThrottlePressTFTKO
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.
Bundle Name: AfterThrottlePressureFA
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.
Bundle Name: AfterThrottleVacuumTFTKO
Naturally Aspirated or Turbocharged: P0106, P0107, P0108. Supercharged: P012B, P012C, P012D.
Bundle Name: AIR System FA
P0411, P2440, P2444
Bundle Name: AIRPumpControlCircuit FA
P0418, P2257, P2258
Bundle Name: AIRSystemPressureSensor FA
P2430, P2431, P2432, P2433, P2435, P2436, P2437, P2438
Bundle Name: AIRValveControlCircuit FA
P0412, P041F, P044F
Bundle Name: AmbientAirDefault
Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P0123, P012B, P012C, P012D, P0222, P0223, P1221
Bundle Name: AmbPresDfltStatus
Baro Sensor Present: P2227, P2228, P2229, P2230. No Baro Sensor Present: P0101, P0102, P0103, P0106, P0107, P0108, P0111, P0112, P0113, P0114, P0121, P0122, P0123, P012B, P012C, P012D, P0222, P0223, P1221
Bundle Name: AmbPresSnsr2_CktFA
P222C, P222D
Bundle Name: AmbPresSnsrCktFA
P2228, P2229
Bundle Name: AmbPresSnsrCktFP
P2228, P2229
Bundle Name: AnyCamPhaser_FA
P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, P2088, P2089, P2090, P2091, P2092, P2093, P2094, P2095
Bundle Name: AnyCamPhaser_TFTKO
P0010, P0011, P0013, P0014, P0020, P0021, P0023, P0024, P2088, P2089, P2090, P2091, P2092, P2093, P2094, P2095
Bundle Name: BrakeBoosterSensorFA
P0556, P0557, P0558
Bundle Name: BrakeBoosterVacuumValid

15 OBDG03 Fault Bundle Definitions

P0556, P0557, P0558
Bundle Name: BSTR_b_ExcsvBstFA
P226B
Bundle Name: BSTR_b_ExcsvBstTFTKO
P226B
Bundle Name: BSTR_b_IC_Pmp_EffPerfTFTKO
P026A
Bundle Name: BSTR_b_IC_PmpCktFA
P023A, P023C
Bundle Name: BSTR_b_PCA_CktFA
P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250
Bundle Name: BSTR_b_PCA_CktLoFA
P0034, P0047, P0245, P0249
Bundle Name: BSTR_b_PCA_CktLoTFTKO
P0034, P0047, P0245, P0249
Bundle Name: BSTR_b_PCA_CktTFTKO
P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P0247, P0249, P0250
Bundle Name: BSTR_b_PCA_FA
P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250
Bundle Name: BSTR_b_PCA_PstnSnsrFA
P003A, P2564, P2565
Bundle Name: BSTR_b_PCA_PstnSnsrTFTKO
P003A, P2564, P2565
Bundle Name: BSTR_b_PCA_TFTKO
P0234, P0299, P0033, P0034, P0035, P0045, P0047, P0048, P0243, P0245, P0246, P2261, P0247, P0249, P0250
Bundle Name: BSTR_b_PresCntrlTooHiFA
P0234
Bundle Name: BSTR_b_PresCntrlTooHiTFTKO
P0234
Bundle Name: BSTR_b_PresCntrlTooLoFA
P0299
Bundle Name: BSTR_b_PresCntrlTooLoTFTKO
P0299
Bundle Name: BSTR_b_PstnCntrlFA
P166D, P166E
Bundle Name: BSTR_b_PstnCntrlTooHiFA
P166E
Bundle Name: BSTR_b_PstnCntrlTooHiTFTKO

15 OBDG03 Fault Bundle Definitions

P166E
Bundle Name: BSTR_b_PstnCntrlTooLoFA
P166D
Bundle Name: BSTR_b_PstnCntrlTooLoTFTKO
P166D
Bundle Name: BSTR_b_TurboBypassCktFA
P0033, P0034, P0035, P00C0, P00C1, P00C2
Bundle Name: BSTR_b_TurboBypassCktTFTKO
P0033, P0034, P0035, P00C0, P00C1, P00C2
Bundle Name: BSTR_b_TurboBypB_CktFA
P00C0, P00C1, P00C2
Bundle Name: BSTR_b_TurboBypB_CktTFTKO
P00C0, P00C1, P00C2
Bundle Name: CamLctnExhFA
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: CamLctnIntFA
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: CamSensor_FA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensor_TFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorAnyLctnTFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorAnyLocationFA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorFA
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CamSensorTFTKO
P0016, P0017, P0018, P0019, P0340, P0341, P0345, P0346, P0365, P0366, P0390, P0391
Bundle Name: CatalystSysEfficiencyLoB1_FA
P0420
Bundle Name: CatalystSysEfficiencyLoB2_FA
P0430
Bundle Name: Clutch Sensor FA
P0806, P0807, P0808
Bundle Name: ClutchPositionSensorCircuitHi FA
P0808
Bundle Name: ClutchPositionSensorCircuitLo FA

15 OBDG03 Fault Bundle Definitions

P0807
Bundle Name: ClutchPstnSnsr FA
P0806, P0807, P0808
Bundle Name: ClutchPstnSnsrCktHi FA
P0808
Bundle Name: ClutchPstnSnsrCktLo FA
P0807
Bundle Name: ClutchPstnSnsrNotLearned
P080A
Bundle Name: CommBusAOff_VICM_FA
U0073
Bundle Name: CommBusBOff_VICM_FA
U0074
Bundle Name: CoolingFanSpeedTooHigh_FA
P0495
Bundle Name: CrankCamCorrelationTFTKO
P0016, P0017, P0018, P0019
Bundle Name: CrankExhaustCamCorrelationFA
P0017, P0019
Bundle Name: CrankExhaustCamCorrFA
P0017, P0019
Bundle Name: CrankIntakeCamCorrelationFA
P0016, P0018
Bundle Name: CrankIntakeCamCorrFA
P0016, P0018
Bundle Name: CrankSensor_FA
P0335, P0336
Bundle Name: CrankSensor_TFTKO
P0335, P0336
Bundle Name: CrankSensorFA
P0335, P0336
Bundle Name: CrankSensorFaultActive
P0335, P0336
Bundle Name: CrankSensorTestFailedTKO
P0335, P0336
Bundle Name: CrankSensorTFTKO
P0335, P0336
Bundle Name: CylDeacDriverFault

15 OBDG03 Fault Bundle Definitions

P3401, P03403, P03404, P3409, P03411, P03412, P3417, P3419, P3420, P3425, P3427, P3428, P3433, P3435, P3436, P3441, P3443, P3444, P3449, P3451, P3452, P3457, P3459, P3460
Bundle Name: CylDeacSystemTFTKO
P3400
Bundle Name: CyInderDeacDriverTFTKO
P3401, P3403, P3404, P3409, P3411, P3412, P3417, P3419, P3420, P3425, P3427, P3428, P3433, P3435, P3436, P3441, P3443, P3444, P3449, P3451, P3452, P3457, P3459, P3460
Bundle Name: ECT_Sensor_Ckt_FA
P0117, P0118, P0119
Bundle Name: ECT_Sensor_Ckt_FP
P0117, P0118
Bundle Name: ECT_Sensor_Ckt_High_FP
P0118
Bundle Name: ECT_Sensor_Ckt_Low_FP
P0117
Bundle Name: ECT_Sensor_Ckt_TFTKO
P0117, P0118, P0119
Bundle Name: ECT_Sensor_Ckt_TPTKO
P0117, P0118, P0019
Bundle Name: ECT_Sensor_DefaultDetected
P0117, P0118, P0116, P0125
Bundle Name: ECT_Sensor_FA
P0117, P0118, P0116, P0125, P0128
Bundle Name: ECT_Sensor_Perf_FA
P0116
Bundle Name: ECT_Sensor_TFTKO
P0117, P0118, P0116, P0125, P0119
Bundle Name: EGRValve_FP
P0405, P0406, P042E
Bundle Name: EGRValveCircuit_FA
P0403, P0404, P0405, P0406
Bundle Name: EGRValveCircuit_TFTKO
P0403, P0404, P0405, P0406
Bundle Name: EGRValvePerformance_FA
P0401, P042E
Bundle Name: EGRValvePerformance_TFTKO
P0401, P042E
Bundle Name: ELCP_PumpCircuit_FA

15 OBDG03 Fault Bundle Definitions

P2400, P2401, P2402
Bundle Name: ELCP_SwitchCircuit_FA
P2418, P2419, P2420
Bundle Name: ELCP_Circuit_FA
P24BA, P24BB
Bundle Name: EngineMetalOvertempActive
P1258
Bundle Name: EngineMisfireDetected_FA
P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308
Bundle Name: EngineMisfireDetected_TFTKO
P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308
Bundle Name: EngineModeNotRunTimer_FA
P2610
Bundle Name: EngineModeNotRunTimerError
P2610
Bundle Name: EnginePowerLimited
P0068, P00C8, P00C9, P00CA, P0090, P0091, P0092, P0122, P0123, P0191, P0192, P0193, P0222, P0223, P0601, P0604, P0606, P0697, P06A3, P06DB, P06DE, P0A1D, P1104, P127A, P127C, P127D, P15F2, P160D, P160E, P1682, P16A0, P16A1, P16A2, P16F3, P2100, P2101, P2102, P2103, P2122, P2123, P2127, P2128, P2135, P2138, P215B, P2176, P228C, P228D, U0073, U0074, U0293, U1817
Bundle Name: EngineTorqueEstInaccurate
EngineMisfireDetected_FA, FuelInjectorCircuit_FA, FuelInjectorCircuit_TFTKO, FuelTrimSystemB1_FA, FuelTrimSystemB2_FA, MAF_SensorTFTKO, MAP_SensorTFTKO, EGRValuePerformance_FA
Bundle Name: EngModeNotRunTmErr
P2610
Bundle Name: EngOilModeledTempValid
ECT_Sensor_FA, IAT_SensorCircuitFA
Bundle Name: EngOilPressureSensorCktFA
P0522, P0523
Bundle Name: EngOilPressureSensorFA
P0521, P0522, P0523
Bundle Name: EngOilTempFA
EngOilTempSensorCircuitFA, EngOilModeledTempValid, P16F3
EngOilTempFA - Other Definitions:
P16F3 with GetXOYR_b_SecurityFlt(CeXOYR_e_EOTR_SecurityFlt)
Bundle Name: EngOilTempSensorCircuitFA
P0197, P0198
Bundle Name: Ethanol Composition Sensor FA
P0178, P0179, P2269
Bundle Name: EvapEmissionSystem_FA

15 OBDG03 Fault Bundle Definitions

P0455, P0446
Bundle Name: EvapExcessPurgePsbl_FA
ELCP sealed/vented fuel system, P0442, P0455, P0458 OR Conventional fuel system, P0442, P0455, P0458, P0496
Bundle Name: EvapFlowDuringNonPurge_FA
P0496
Bundle Name: EvapPurgeSolenoidCircuit_FA
P0443, P0458, P0459
Bundle Name: EvapReducedPurgePsbl_FA
ELCP sealed/vented fuel system, P0443, P0446, P0449, P0459, P0497, P0499, P1463, P2419, P2422 OR Conventional fuel system, P0443, P0446, P0455, P0459, P0498
Bundle Name: EvapSmallLeak_FA
P0442
Bundle Name: EvapVentSolenoidCircuit_FA
P0449, P0498, P0499
Bundle Name: ExhaustCamSensor_FA
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: ExhaustCamSensor_TFTKO
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: ExhaustCamSensorFA
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: ExhaustCamSensorTFTKO
P0017, P0019, P0365, P0366, P0390, P0391
Bundle Name: FanOutputDriver_FA
P0480, P0481, P0482, P0691, P0692, P0693, P0694, P0695, P0696, P1485 (EREV), P1486 (EREV), P1487 (EREV)
Bundle Name: FHPD_b_HPC_PresErrNeg_FA
P228D
Bundle Name: FHPD_b_HPC_PresErrNeg_TFTKO
P228D
Bundle Name: FHPD_b_HPC_PresErrPos_FA
P228C
Bundle Name: FHPD_b_HPC_PresErrPos_TFTKO
P228C
Bundle Name: FHPD_b_HPC_Windup_TFTKO
P0089
Bundle Name: FHPD_b_HPC_Windup_FA
P0089
Bundle Name: FHPD_b_PumpCurr_FA
P163A
Bundle Name: FHPD_b_PumpCurr_TFTKO

15 OBDG03 Fault Bundle Definitions

P163A
Bundle Name: FHPR_b_FRP_SnsrCkt_FA
P0192, P0193, P127C, P127D
Bundle Name: FHPR_b_FRP_SnsrCkt_TFTKO
P0192, P0193, , P127C, P127D
Bundle Name: FHPR_b_FRP_SnsrPerfDiag_FA
P0191, P127A
Bundle Name: FHPR_b_FRP_SnsrPerfDiag_TFTKO
P0191, P127A
Bundle Name: FHPR_b_PumpCkt_FA
P0090, P0091, P0092, P00C8, P00C9, P00CA
Bundle Name: FHPR_b_PumpCkt_TFTKO
P0090, P0091, P0092, P00C8, P00C9, P00CA
Bundle Name: FourWheelDriveLowStateInvalid
P2771
Bundle Name: FTP_SensorCircuit_FA
P0452, P0453
Bundle Name: FuelInjectorCircuit_FA
PFI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283 SIDI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F
Bundle Name: FuelInjectorCircuit_TFTKO
PFI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283 SIDI: P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0261, P0264, P0267, P0270, P0273, P0276, P0279, P0282, P0262, P0265, P0268, P0271, P0274, P0277, P0280, P0283, P2147, P2150, P2153, P2156, P216B, P216E, P217B, P217E, P2148, P2151, P2154, P2157, P216C, P216F, P217C, P217F, P1248, P1249, P124A, P124B, P124C, P124D, P124E, P124F
Bundle Name: FuelLevelDataFault
P0461, P0462, P0463, P2066, P2067, P2068
Bundle Name: FuelTankPressureSnsrCkt_FA
P0452, P0453
Bundle Name: FuelTrimSystemB1_FA
P0171, P0172
Bundle Name: FuelTrimSystemB1_TFTKO
P0171, P0172
Bundle Name: FuelTrimSystemB2_FA
P0174, P0175
Bundle Name: FuelTrimSystemB2_TFTKO
P0174, P0175

15 OBDG03 Fault Bundle Definitions

Bundle Name: HumidityFA
P0097, P0098, P11C2, P11C3, P2227, P2228, P2229, P2230
Bundle Name: HumTempSnsrCktFA
P0097, P0098
Bundle Name: HumTempSnsrCktFP
P0097, P0098
Bundle Name: HumTempSnsrFA
P0096, P0097, P0098, P0099
Bundle Name: IAC_SystemRPM_FA
P0506, P0507
Bundle Name: IAT_ContCorrFA
P2199
Bundle Name: IAT_SensorCircuitFA
P0112, P0113
Bundle Name: IAT_SensorCircuitFP
P0112, P0113
Bundle Name: IAT_SensorCircuitTFTKO
P0112, P0113
Bundle Name: IAT_SensorFA
P0111, P0112, P0113, P0114
Bundle Name: IAT_SensorTFTKO
P0111, P0112, P0113, P0114
Bundle Name: IAT2_SensorCircuitFA
P0097, P0098, P0112, P0113
Bundle Name: IAT2_SensorcircuitFP
P0097, P0098, P0112, P0113
Bundle Name: IAT2_SensorCktTFTKO
P0097, P0098, P0112, P0113
Bundle Name: IAT2_SensorFA
P0096, P0097, P0098, P0111, P0112, P0113
Bundle Name: IAT2_SensorTFTKO
P0096, P0097, P0098, P0111, P0112, P0113
Bundle Name: IgnitionOffTimer_FA
P2610
Bundle Name: IgnitionOffTimeValid
P2610
Bundle Name: IgnitionOutputDriver_FA
P0351, P0352, P0353, P0354, P0355, P0356, P0357, P0358, P2300, P2301, P2303, P2304, P2306, P2307, P2309, P2310, P2312, P2313, P2315, P2316,

15 OBDG03 Fault Bundle Definitions

P2318, P2319, P2321, P2322
Bundle Name: IntakeCamSensor_FA
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntakeCamSensor_TFTKO
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntakeCamSensorFA
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntakeCamSensorTFTKO
P0016, P0018, P0340, P0341, P0345, P0346
Bundle Name: IntkCamPhaser_FA
P0010, P0011, P0020, P0021, P2088, P2089, P2092, P2093
Bundle Name: KS_Ckt_Perf_B1B2_FA
P0324, P0325, P0326, P0327, P0328, P0330, P0332, P0333, P06B6, P06B7
Bundle Name: LostCommBCM_FA
U0140
Bundle Name: LostCommBusB_VICM_FA
U182D
Bundle Name: LowFuelConditionDiagnostic
LowFuelConditionDiagnostic - Other Definitions: Flag set to TRUE if the fuel level < 10.0% AND No Active DTCs: FuelLevelDataFault, P0462, P0463 for at least 30.0 seconds
Bundle Name: MAF_SensorCircuitFA
P0102, P0103, P010C, P010D
Bundle Name: MAF_SensorCircuitTFTKO
P0102, P0103, P010C, P010D
Bundle Name: MAF_SensorFA
P0101, P0102, P0103, P010C, P010D
Bundle Name: MAF_SensorFP
P0102, P0103, P010C, P010D
Bundle Name: MAF_SensorPerfFA
P0101
Bundle Name: MAF_SensorPerfTFTKO
P0101
Bundle Name: MAF_SensorTFTKO
P0101, P0102, P0103, P010C, P010D
Bundle Name: MAF_Snsr1_FA
P0101, P0102, P0103

15 OBDG03 Fault Bundle Definitions

Bundle Name: MAF_Snsr2_FA
P010B, P010C, P010D
Bundle Name: MAF_SnsrCktFA
P0102, P0103, P010C, P010D
Bundle Name: MAF_SnsrCktTFTKO
P0102, P0103, P010C, P010D
Bundle Name: MAP_EngineVacuumStatus
P0106, P0107, P0108 Fault Active OR P0107, P0108 Fault Pending
Bundle Name: MAP_SensorCircuitFA
P0107, P0108
Bundle Name: MAP_SensorCircuitFP
P0107, P0108
Bundle Name: MAP_SensorFA
P0106, P0107, P0108
Bundle Name: MAP_SensorPerfFA
P0106
Bundle Name: MAP_SensorPerfTFTKO
P0106
Bundle Name: MAP_SensorTFTKO
P0106, P0107, P0108
Bundle Name: MnfdTempSensorCktFA
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
Bundle Name: MnfdTempSensorCktFP
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
Bundle Name: MnfdTempSensorCktTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112C, P112D. Turbocharged or Supercharged, without Humidity sensor: P0097, P0098. Naturally Aspirated: P0112, P0113.
Bundle Name: MnfdTempSensorFA
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
Bundle Name: MnfdTempSensorTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
Bundle Name: ModuleOffTime_FA
P2610
Bundle Name: ModuleOffTimeErr
P2610
Bundle Name: O2S_Bank_1_TFTKO
P0131, P0132, P0134, P2A00

15 OBDG03 Fault Bundle Definitions

Bundle Name: O2S_Bank_2_TFTKO
P0151, P0152, P0154, P2A03
Bundle Name: O2S_Bank_1_Sensor_1_FA
P2A00, P0131, P0132, P0133, P0134, P0135, P0053, P1133, P015A, P015B, P0030
Bundle Name: O2S_Bank_1_Sensor_2_FA
P013A, P013B, P013E, P013F, P2270, P2271, P0137, P0138, P0140, P0141, P0054, P0036
Bundle Name: O2S_Bank_2_Sensor_1_FA
P2A03, P0151, P0152, P0153, P0154, P0155, P0059, P1153, P015C, P015D, P0050
Bundle Name: O2S_Bank_2_Sensor_2_FA
P013C, P013D, P014A, P014B, P2272, P2273, P0157, P0158, P0160, P0161, P0060, P0056
Bundle Name: OAT_AmbientFilteredFA
ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected, MAF_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.
Bundle Name: OAT_AmbientSensorFA
ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: not applicable. All other cases: not applicable.
Bundle Name: OAT_EstAmbTemp_FA
ELCP sealed/vented fuel system, P0071, P0072, P0073, P0502, P0503, P0722, P0723 OR Conventional fuel system, P0071, P0072, P0073, P0074, P2610
Bundle Name: OAT_PtEstFiltFA
ECM OAT: P0071, P0072, P0073, P0074, EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected, MAF_SensorFA. VIMC OAT: P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: VehicleSpeedSensor_FA, IAT_SensorFA, MAF_SensorFA. All other cases: EngModeNotRunTmErr, VehicleSpeedSensor_FA, IAT_SensorFA, ECT_Sensor_DefaultDetected.
Bundle Name: OAT_PtEstRawFA
ECM OAT: P0071, P0072, P0073, P0074. VIMC OAT: P0071, P0072, P0073, EngModeNotRunTmErr, VehicleSpeedSensor_FA, ECT_Sensor_DefaultDetected. IAT-Based OAT: IAT_SensorFA. All other cases: IAT_SensorFA, ECT_Sensor_DefaultDetected.
Bundle Name: OilPmpCktFA
P06DA, P06DB, P06DC
OilPmpCktFA - Other Definitions: Output Driver Codes
Bundle Name: OilPmpFA
P06DA, P06DB, P06DC, P06DD, P06DE
OilPmpFA - Other Definitions: FA only for Output Driver and rationality
Bundle Name: OilPmpStuckHigh
P06DA, P06DB, P06DD
OilPmpStuckHigh - Other Definitions: TFTKO and FA
Bundle Name: OilPmpStuckLow
P06DC, P06DE
OilPmpStuckLow - Other Definitions:

15 OBDG03 Fault Bundle Definitions

TFTKO and FA
Bundle Name: OilPmpTFTKO
P06DA, P06DB, P06DC, P06DD, P06DE
OilPmpTFTKO - Other Definitions: TFTKO only for Output Driver and rationality
Bundle Name: PO2S_Bank_1_Snsr_2_FA
P0137, P0138, P0140, P0036, P0054, P0141, P2270, P2271
Bundle Name: PO2S_Bank_2_Snsr_2_FA
P0157, P0158, P0160, P0056, P0060, P0161, P2272, P2273
Bundle Name: PostCatFuelTrimHiB1
P2097
Bundle Name: PostCatFuelTrimHiB2
P2099
Bundle Name: PostCatFuelTrimLoB1
P2096
Bundle Name: PostCatFuelTrimLoB2
P2098
Bundle Name: PowertrainRelayFault
P1682
Bundle Name: PowertrainRelayStateOn_Error
P0685
Bundle Name: PowertrainRelayStateOn_FA
P0685
Bundle Name: PPS1_OutOfRange
P2122, P2123
Bundle Name: PPS1_OutOfRange_Composite
P2122, P2123, P06A3
Bundle Name: PPS2_OutOfRange
P2127, P2128
Bundle Name: PPS2_OutOfRange_Composite
P2127, P2128, P0697
Bundle Name: SCIAP_SensorCircuitFA
P012C, P012D
Bundle Name: SCIAP_SensorCircuitFP
P012C, P012D
Bundle Name: SCIAP_SensorFA
P012B, P012C, P012D
Bundle Name: SCIAP_SensorPerfFA

15 OBDG03 Fault Bundle Definitions

P012B
Bundle Name: SCIAP_SensorPerfTFTKO
P012B
Bundle Name: SCIAP_SensorTFTKO
P012B, P012C, P012D
Bundle Name: SuperchargerBypassValveFA
P2261
Bundle Name: SystemVoltageHigh_FA
P0563
Bundle Name: SystemVoltageLow_FA
P0562
Bundle Name: TC_BoostPresSnsrCktFA
P0237, P0238
Bundle Name: TC_BoostPresSnsrFA
P0236, P0237, P0238
Bundle Name: TCM_EngSpdReqCkt
P150C
Bundle Name: THMR_AHV_FA
P2681, P26A3, P26A6, P26A7, P26A9
Bundle Name: THMR_AWP_AuxPumpFA
B2920, B2923, B2922
Bundle Name: THMR_ECT_Sensor_Ckt_FA
P0116, P0117, P0118, P00B6
Bundle Name: THMR_Insuff_Flow_FA
P00B7
Bundle Name: THMR_RCT_Sensor_Ckt_FA
P00B3, P00B4
Bundle Name: THMR_SWP_Control_FA
P261D, P261A, P261C
Bundle Name: THMR_SWP_FlowStuckOn_FA
P261A, P261D, P261E
Bundle Name: THMR_SWP_NoFlow_FA
P261B, P261C
Bundle Name: THMR_Therm_Control_FA
P0597, P0598, P0599
Bundle Name: ThrotTempSensorFA
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.

15 OBDG03 Fault Bundle Definitions

Bundle Name: ThrotTempSensorTFTKO
Turbocharged or Supercharged, with Humidity sensor: P112B, P112C, P112D, P112E. Turbocharged or Supercharged, without Humidity sensor: P0096, P0097, P0098, P0099. Naturally Aspirated: P0111, P0112, P0113, P0114.
Bundle Name: ThrottlePositionSnsrPerfFA
P0121
Bundle Name: ThrottlePositionSnsrPerfTFTKO
P0121
Bundle Name: TIAP_SensorPerfFA
P0236
Bundle Name: TPS_FA
P0122, P0123, P0222, P0223, P2135
Bundle Name: TPS_FaultPending
P0122, P0123, P0222, P0223, P2135
Bundle Name: TPS_Performance_FA
P0068, P0121, P1104, P2100, P2101, P2102, P2103
Bundle Name: TPS_Performance_TFTKO
P0068, P0121, P1104, P2100, P2101, P2102, P2103
Bundle Name: TPS_TFTKO
P0122, P0123, P0222, P0223, P2135
Bundle Name: TPS_ThrottleAuthorityDefaulted
P0068, P0122, P0123, P0222, P0223, P16F3, P1104, P2100, P2101, P2102, P2103, P2135
Bundle Name: TPS1_OutOfRange_Composite
P0122, P0123, P06A3
Bundle Name: TPS2_OutOfRange_Composite
P0222, P0223, P06A3
Bundle Name: Trans Output Rotations Rolling Count Validity
P0722, P0723, P077C, P077D
Bundle Name: TransActualGearValidity
P182E, P1915
Bundle Name: Transfer Pump is Commanded On
Transfer Pump is Commanded On - Other Definitions: Fuel Volume in Primary Fuel Tank < 0.0 liters AND Fuel Volume in Secondary Fuel Tank ≥ 0.0 liters AND Transfer Pump on Time < P0461, P2066, P2636: Transfer Pump Enable (see supporting table for numeric value) AND Transfer Pump had been Off for at least 0.0 seconds AND Evap Diagnostic (Purge Valve Leak Test, Large Leak Test, and Waiting for Purge) is not running AND Engine Running
Bundle Name: Transmission Actual Gear Validity

15 OBDG03 Fault Bundle Definitions

P182E, P1915
Bundle Name: Transmission Engaged State Validity
P182E, P1915
Bundle Name: Transmission Estimated Gear Validity
P182E, P1915
Bundle Name: Transmission Gear Ratio Validity
P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0
Bundle Name: Transmission Gear Selector Position Validity
P182E, P1915
Bundle Name: Transmission Oil Temperature Validity
P0667, P0668, P0669, P0711, P0712, P0713
Bundle Name: Transmission Output Shaft Angular Velocity Validity
P0722, P0723, P077C, P077D
Bundle Name: Transmission Overall Actual Torque Ratio Validity
P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P182E, P1915
Bundle Name: Transmission Overall Estimated Torque Ratio Validity
P0716, P0717, P0722, P0723, P077C, P077D, P07BF, P07C0, P182E, P1915
Bundle Name: Transmission Shift Lever Position Validity
P182E, P1915
Bundle Name: Transmission Turbine Angular Velocity Validity
P0716, P0717, P07BF, P07C0
Bundle Name: TransmissionEngagedState_FA
P182E, P1915
Bundle Name: TransmissionGearDefaulted
P182E, P1915
Bundle Name: TransmissionOutputRotationalStatusValidity
P0722, P0723, P077C, P077D
Bundle Name: TransmissionRatioControlSystemFault
P0751, P0752, P0756, P0757, P0973, P0974, P0976, P0977
Bundle Name: VCER_TorqueSecurity
P16F3
VCER_TorqueSecurity - Other Definitions: P16F3 with GetXOYR_b_SecurityFlt(CeXOYR_e_AFM_PreloadAreaFlt, CeXOYR_e_AFM_PreloadTimerFlt, CeXOYR_e_AFM_DualPreloadAreaFlt, CeXOYR_e_CDAR_SecurityFlt)
Bundle Name: VehicleSpeedSensor_FA
P0502, P0503, P0722, P0723
Bundle Name: VehicleSpeedSensorError
P0502, P0503, P0722, P0723
Bundle Name: VentCircuit_FA

15 OBDG03 Fault Bundle Definitions

ELCP sealed/vented fuel system, P0449, P0498, P0499

Bundle Name: VICM_WakeupDiag_FA

P06E4

Bundle Name: VICM_WakeupDiag_TFTKO

P06E4
