

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Steering Wheel Angle Sensor Signal Message Counter Incorrect	C1211	This DTC monitors for an error in the Steering Wheel Angle Sensor Signal Message Counter	Communication of the Alive Rolling Count or Protection Value from the Steering Wheel Angle Sensor over CAN bus is incorrect for  out of total samples	   ≥ 15.00 counts  ≥ 16.00 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage	= Is available  ≥ 3,000.00 milliseconds  = Run  ≥ 11.00 Volts  ≥ 11.00 Volts	Executes in 10ms loop.	Type C, No SVS "Safety Emissio ns Neutral Diagnost ic"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Open – Bank 1	P0010	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground.	<p>System supply voltage</p> <p>Output driver is commanded on</p> <p>Ignition switch is in crank or run position</p>	> 11.00 Volts	<p>20 failures out of 25 samples</p> <p>250 ms /sample, continuous</p>	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 1	P0011	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated.	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive.	(Intake cam Bank 1)  Cam Position Error > ( <b>P0011_CamPosErrorLimlc1</b> ) deg	<b>Intake Cam Phsr Enable</b>  System Voltage  Engine Running  Power Take Off (PTO) active  Desired cam position  Desired AND Measured cam position          Desired cam position variation          No Active DTCs	= TRUE  > 11.00 Volts  = TRUE  = FALSE  > 0 deg  > ( <b>P0011_CamPosErrorLimlc1</b> ) deg AND < ( <b>CalculatedPerfMaxlc1</b> ) deg  < 3.00 deg for ( <b>P0011_P05CC_StablePositionTimeIc1</b> ) seconds  P0010 P2088 P2089	135.00 failures out of 150.00 samples  100 ms /sample	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Open – Bank 1	P0013	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground.	<p>System supply voltage</p> <p>Output driver is commanded on</p> <p>Ignition switch is in crank or run position</p>	> 11.00 Volts	<p>20 failures out of 25 samples</p> <p>250 ms /sample, continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Performance – Bank 1	P0014	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated.	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive.	(Exhaust cam Bank 1)  Cam Position Error > ( <b>P0014_CamPosErrorLimEc1</b> ) deg	<b>Exhaust Cam Phsr Enable</b>  System Voltage  Engine Running  Power Take Off (PTO) active  Desired cam position  Desired AND Measured cam position          Desired cam position variation          No Active DTCs	= TRUE  > 11.00 Volts  = TRUE  = FALSE  > 0 deg  > ( <b>P0014_CamPosErrorLimEc1</b> ) deg AND < ( <b>CalculatedPerfMaxEc1</b> ) deg  < 3.00 deg for ( <b>P0014_P05CE_StablePositionTimeEc1</b> ) seconds  P0013 P2090 P2091	135.00 failures out of 150.00 samples  100 ms /sample	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 Sensor A	P0016	Detects cam to crank misalignment by monitoring if the cam sensor pulse for bank 1 sensor A occurs during the incorrect crank position, diagnostic passes when the cam sensor pulse is in the expected range	Out of range cam edge measurements in one engine cycle  Out of range values are:  cam edge measurement OR cam edge measurement from the expected nominal cam position	 >= 4 cam edges   <div> <div>&lt; -7.9 Crank Degrees</div> <div>&gt; 12.1 Crank Degrees</div> </div>	Crankshaft and camshaft position signals are synchronized  Engine is Spinning  Cam phaser control indicates the phaser is 'parked'  No Active DTCs:  Time since last execution of a test  IntCamECC_OilPresLow	Test is Enabled       CrankSensor_FA P0340, P0341  <div> <div>&gt; 1.0 sec</div> <div>= FALSE</div> </div>	4 cam edge measurements and 1 test sample per engine cycle  Test failure is 4 fails in 5 samples  Diagnostic failure is 2 failed tests out of 3  If the first test fails, the next test is delayed to confirm the phaser 'parked'  This delay time is defined by <b>P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold</b>  For mid-park phasers, an additional delay <b>P0016-0019 Mid-Park Phaser Delay</b> is applied	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 Sensor B	P0017	Detects cam to crank misalignment by monitoring if the cam sensor pulse for bank 1 sensor B occurs during the incorrect crank position, diagnostic passes when the cam sensor pulse is in the expected range	Out of range cam edge measurements in one engine cycle  Out of range values are:  cam edge measurement OR cam edge measurement from the expected nominal cam position	 >= 4 cam edges   <div> <div>&lt; -7.9 Crank Degrees</div> <div>&gt; 12.1 Crank Degrees</div> </div>	Crankshaft and camshaft position signals are synchronized  Engine is Spinning  Cam phaser control indicates the phaser is 'parked'  No Active DTCs:  Time since last execution of a test  ExhCamECC_OilPresLow	Test is Enabled          CrankSensor_FA P0365, P0366  > 1.0 sec  = FALSE	4 cam edge measurements and 1 test sample per engine cycle  Test failure is 4 fails in 5 samples  Diagnostic failure is 2 failed tests out of 3  If the first test fails, the next test is delayed to confirm the phaser 'parked'  This delay time is defined by <b>P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold</b>  For mid-park phasers, an additional delay <b>P0016-0019 Mid-Park Phaser Delay</b> is applied	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 1	P0030	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>≥ 200 K Ω impedance between output and controller ground.</p>	<p>Ignition Voltage Engine Speed</p>	<p>= Crank or Run &gt; 11.0 volts &gt; 400 RPM</p>	<p>20 failures out of 25 samples</p> <p>250 ms / sample</p> <p>Continuous</p>	<p>Type B, 2 Trips Note: In certain controllers P0031 may also set</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0031	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	<p>≤ 0.5 Ω impedance between output and controller ground.</p>	<p>Ignition Voltage Engine Speed</p>	<p>= Crank or Run &gt; 11.0 volts &gt; 400 RPM</p>	<p>20 failures out of 25 samples</p> <p>250 ms / sample</p> <p>Continuous</p>	<p>Type B, 2 Trips Note: In certain controllers P0030 may also set</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0032	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	<p>≤ 0.5 Ω impedance between output and controller power.</p>	<p>Ignition Voltage Engine Speed</p>	<p>= Crank or Run &gt; 11.0 volts &gt; 400 RPM</p>	<p>20 failures out of 25 samples</p> <p>250 ms / sample</p> <p>Continuous</p>	<p>Type B, 2 Trips</p>



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve A Control Circuit	P0033	<p>Controller specific output driver circuit diagnostic, diagnosing the 'compressor recirculation valve 'A' actuator' low sided driver for an open circuit failure, when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>In series applications, turbocharger 'A' is the first turbocharger in the direction of exhaust flow. In parallel applications, turbocharger 'A' is associated with engine bank 1.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>≥ 200 K Ω impedance between output and controller ground</p>	<p>Diagnostic enabled *****</p> <p>Powertrain relay voltage *****</p> <p>Engine does not crank</p> <p>Diagnostic system not disabled</p>	<p>True *****</p> <p>≥ 11.0 Volts *****</p>	<p>80 failures out of 100 samples</p> <p>PWM CRV: 100ms / sample eCRV: 12.5ms / sample</p>	<p>Type A, 1 Trips</p> <p>Note: In certain controllers P0034 may also set turbo/ super charger bypass valve control circuit low</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve A Control Circuit Low	P0034	<p>Controller specific output driver circuit diagnostic, diagnosing the 'compressor recirculation valve 'A' actuator' low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>In series application, turbocharger 'A' is the first turbocharger in the direction of exhaust flow. In parallel applications, turbocharger 'A' is associated with engine bank 1.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p> <p>In certain controllers this diagnosis runs only when the HWIO-output is driven by the application S/W.</p>	<p>≤ 0.5 Ω impedance between output and controller ground</p>	<p>Diagnostic Enabled *****</p> <p>Powertrain relay voltage *****</p> <p>Engine does not crank</p> <p>Diagnostic system not disabled</p>	<p>True *****</p> <p>≥ 11.0 Volts *****</p>	<p>80 failures out of 100 samples</p> <p>PWM CRV: 100ms / sample eCRV: 12.5ms / sample</p>	<p>Type A, 1 Trips Note: In certain controllers P0033 may also set turbo/super charger bypass valve control circuit</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve A Control Circuit High	P0035	<p>Controller specific output driver circuit diagnostic, diagnosing the 'compressor recirculation valve 'A' actuator' low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>In series application, turbocharger 'A' is the first turbocharger in the direction of exhaust flow. In parallel applications, turbocharger 'A' is associated with engine bank 1.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p> <p>In certain controllers this diagnosis runs only when the HWIO-output is driven by the application S/W.</p>	<p>≤ 0.5 Ω impedance between output and controller power.</p>	<p>Diagnostic enabled *****</p> <p>Powertrain relay voltage *****</p> <p>Engine does not crank Diagnostic system not disabled</p>	<p>True *****</p> <p>≥ 11.0 Volts *****</p>	<p>80 failures out of 100 samples</p> <p>PWM CRV: 100ms / sample eCRV: 12.5ms / sample</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 2	P0036	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	≥ 200 K Ω impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	<p>20 failures out of 25 samples</p> <p>250 ms / sample</p> <p>Continuous</p>	Type B, 2 Trips Note: In certain controllers P0037 may also set

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0037	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	<p>≤ 0.5 Ω impedance between output and controller ground.</p>	<p>Ignition Voltage Engine Speed</p>	<p>= Crank or Run &gt; 11.0 volts &gt; 400 RPM</p>	<p>20 failures out of 25 samples</p> <p>250 ms / sample</p> <p>Continuous</p>	<p>Type B, 2 Trips Note: In certain controllers P0036 may also set</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0038	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	<p>≤ 0.5 Ω impedance between output and controller power.</p>	<p>Ignition Voltage Engine Speed</p>	<p>= Crank or Run &gt; 11.0 volts &gt; 400 RPM</p>	<p>20 failures out of 25 samples</p> <p>250 ms / sample</p> <p>Continuous</p>	<p>Type B, 2 Trips</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0054	<p>Detects an oxygen sensor heater having an incorrect or out of range resistance value. This test calculates the heater's resistance (using voltage and current) at engine start after a soak condition and compares it to the expected values for the released sensor.</p> <p>This fault is set if the heater resistance is outside the expected range.</p>	Heater Resistance outside of the expected range of	3.8 < ohms < 10.5	<p>No Active DTC's</p> <p>Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time</p>	<p>ECT_Sensor_FA P262B IAT_SensorFA &lt; 8.0 °C &gt; 28,800 seconds ≥ -30.0 °C &lt; 32.0 volts &lt; 0.15 seconds</p>	Once per valid cold start	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
MAP / MAF / Throttle Position Correlation	P0068	Detect when MAP and MAF do not match estimated engine airflow as established by the TPS	<p>Difference between MAP and estimated MAP exceeds threshold (kPa), or P0651 (5 Volt Ref), or P0107 (MAP circuit low), or P0108 (MAP circuit high) have failed this key cycle, then MAP portion of diagnostic fails</p> <p>Absolute difference between MAF and estimated MAF exceed threshold (grams/sec), or P0102 (MAF circuit low), or P0103 (MAF circuit hi) have failed this key cycle, or maximum MAF versus RPM (Table) is greater than or equal to maximum MAF versus battery voltage, then MAF portion of diagnostic fails</p>	<p>Table, f(TPS). See supporting tables: <b>P0068_Delta MAP Threshold f(TPS)</b></p> <p>Table, f(TPS). See supporting tables: <b>P0068_Delta MAF Threshold f(TPS)</b></p> <p>Table, f(RPM). See supporting tables: <b>P0068_Maximum MAF f(RPM)</b></p> <p>Table, f(Volts). See supporting tables: <b>P0068_Maximum MAF f(Volts)</b></p>	<p>Engine Speed</p> <p>Run/Crank voltage</p>	<p>&gt; 800 RPM</p> <p>&gt; 6.41 Volts</p>	<p>Continuously fail MAP and MAF portions of diagnostic for 0.1875 s</p> <p>Continuous in MAIN processor</p>	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit Performance (OAT wired to ECM)	P0071	<p>Detects an Outside Air Temperature (OAT) sensor that is stuck in range. There are two components to the test: an engine off component, and an engine running component.</p> <p>If the engine has been off for a long enough period of time, and the coolant temperature and Intake Air Temperature (IAT) values are similar, then the air temperature values in the engine compartment of the vehicle are considered to have equalized. In this case, the engine off component of the diagnostic can be enabled.</p> <p>If the IAT and the OAT values are similar, then the OAT Performance Diagnostic passes. If the IAT and OAT values are not similar, the diagnostic will continue to monitor the IAT and the OAT as the vehicle starts to move.</p> <p>For applications that have ability to move without engaging the internal combustion</p>	<p><b><u>Engine Off:</u></b></p> <p>If IAT &gt;= OAT: IAT - OAT</p> <p>If IAT &lt; OAT: OAT - IAT</p> <p>If either of the following conditions are met, this diagnostic will pass:</p> <p>If IAT &gt;= OAT: IAT - OAT</p> <p>If IAT &lt; OAT: OAT - IAT</p>	<p>&gt; 15.0 deg C</p> <p>&gt; 15.0 deg C</p> <p>&lt;= 15.0 deg C</p> <p>&lt;= 15.0 deg C</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is not running</p> <p>Vehicle Speed</p> <p>Coolant Temperature - IAT</p> <p>IAT - Coolant Temperature</p> <p>OAT-to-IAT engine off equilibrium counter</p> <p>The "OAT-to-IAT engine off equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is off. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared. The value that is added or subtracted to the counter every 100 msec is contained in table</p> <p><b>P0071: OAT Performance Drive Equilibrium Engine Off</b></p> <p>No Active DTCs:</p>	<p>&gt;= 28,800.0 seconds</p> <p>&gt;= 12.4 MPH</p> <p>&lt; 15.0 deg C</p> <p>&lt; 15.0 deg C</p> <p>&gt;= 300.0 counts</p> <p>VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngineModeNotRunTimer Error</p>	Executed every 100 msec until a pass or fail decision is made	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>engine, the engine off test will continue. If the vehicle has been moving quickly enough for a long enough period of time, the IAT and OAT values should have reached an equilibrium. This period of time is defined by the "OAT-to-IAT engine off equilibrium counter". The "OAT-to-IAT engine off equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is off. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared.</p> <p>While the "OAT-to-IAT engine off equilibrium counter" is counting, IAT and OAT are monitored for similarity. If they are similar, the OAT Performance Diagnostic passes. If the counter reaches an equilibrium and the IAT and OAT values are not similar, the OAT Performance Diagnostic will fail.</p>	<p><b>Engine Running:</b></p> <p>If IAT &gt;= OAT: IAT - OAT</p> <p>If IAT &lt; OAT: OAT - IAT</p> <p>If either of the following conditions are met, this diagnostic will pass:</p> <p>If IAT &gt;= OAT: IAT - OAT</p> <p>If IAT &lt; OAT: OAT - IAT</p>	<p>&gt; 15.0 deg C</p> <p>&gt; 15.0 deg C</p> <p>&lt;= 15.0 deg C</p> <p>&lt;= 15.0 deg C</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is running</p> <p>Vehicle Speed</p> <p>Engine air flow</p> <p>OAT-to-IAT engine running equilibrium counter</p> <p>The "OAT-to-IAT engine running equilibrium counter" is a counter that is incremented or decremented based on vehicle speed and engine air flow when the engine is running. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared. The value that is added or subtracted to the counter every 100 msec is contained in table</p> <p><b>P0071: OAT Performance Drive Equilibrium Engine Running</b></p> <p>No Active DTCs:</p>	<p>&gt;= 28,800.0 seconds</p> <p>&gt;= 12.4 MPH</p> <p>&gt;= 10.0 grams/second</p> <p>&gt;= 300.0 counts</p> <p>VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngineModeNotRunTimer Error</p>	<p>Executed every 100 msec until a pass or fail decision is made</p>	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>If the engine off component of the diagnostic was enabled, but did not make a pass or fail decision, the engine running component will begin executing when the internal combustion engine starts to run.</p> <p>If the vehicle has been moving quickly enough for a long enough period of time, the IAT and OAT values should have reached an equilibrium. This period of time is defined by the "OAT-to-IAT engine running equilibrium counter". The "OAT-to-IAT engine running equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is running. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared.</p> <p>While the "OAT-to-IAT engine running equilibrium counter" is counting, IAT and OAT are monitored for</p>						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		similarity. If they are similar, the OAT Performance Diagnostic passes. If the counter reaches an equilibrium and the IAT and OAT values are not similar, the OAT Performance Diagnostic will fail.						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit Low	P0072	Detects a continuous short to ground in the Outside Air Temperature (OAT) signal circuit by monitoring the OAT sensor output resistance and failing the diagnostic when the OAT resistance is too low. The OAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A lower resistance is equivalent to a higher temperature.	Raw OAT Input	<= 46 Ohms (~150 deg C)	Continuous		40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit High	P0073	Detects a continuous open circuit in the Outside Air Temperature (OAT) signal circuit by monitoring the OAT sensor output resistance and failing the diagnostic when the OAT resistance is too high. The OAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A higher resistance is equivalent to a lower temperature.	Raw OAT Input	$\geq 427,757$ Ohms ( $\sim 60$ deg C)	Continuous		40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Intermittent In-Range	P0074	<p>Detects a noisy or erratic signal in the OAT circuit by monitoring the OAT sensor and failing the diagnostic when the OAT signal has a noisier output than is expected.</p> <p>When the value of the OAT signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of OAT readings. The result of this summation is called a "string length".</p> <p>Since the OAT signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic OAT signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where:</p> <p>"String Length" = sum of "Diff" calculated over</p> <p>And where:</p> <p>"Diff" = ABS(current OAT reading - OAT reading from 100 milliseconds previous)</p>	<p>&gt; 100 deg C</p> <p>10 consecutive OAT readings</p>		Continuous	<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump min/ max authority	P0089	This DTC determines when the high pressure pump control has reached to its max or min authority	High Pressure Fuel Pump Delivery Angle  OR  High Pressure Fuel Pump Delivery Angle	 >= 101 °    ≤ 0 °	High Pressure Pump Performance Diagnostic Enable  Battery Voltage  Low Side Fuel Pressure          Barometric Pressure Inlet Air Temp    Fuel Temp   Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) andCam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In	True  ≥ 11 Volts  > 0.275 MPa   Enabled when a code clear is not active or not exiting device control  Engine is not cranking   ≥ 70.0 KPA ≥ -12.0 degC  -12 ≤ Temp degC ≤ 128	Windup High/ Low  10.00 seconds failures out of 12.50 Seconds samples	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active			

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Control Solenoid Enable Low Side Open Circuit	P0090	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	       ≥ 200 KOhms impedance between signal and controller ground	Engine Speed  Battery Voltage	≥ 50 RPM  ≥ 11 Volts  Not in pump device control Enabled when a code clear is not active or not existing device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Control Solenoid Enable Low Side Short to Ground	P0091	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	<= 0.1 Amps between signal and controller ground	<p>Engine Speed</p> <p>Battery Voltage</p>	<p>&gt;= 50 RPM</p> <p>&gt;= 11 Volts</p> <p>Not in pump device control Enabled when a code clear is not active or not exiting device control</p>	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Cntrl Solenoid Enable Low Side Short to Power	P0092	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1.1 or 15 Amps selectable threshold based on High pressure Pump .	Engine Speed  Battery Voltage	>= 50 RPM  >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor and manifold temperature sensor)	P0096	Detects an Intake Air Temperature 2 (IAT2) sensor value that is stuck in range by comparing the IAT2 sensor value against the IAT and IAT3 sensor values and failing the diagnostic if the IAT2 value is more different than the IAT and IAT3 values than is expected. If the engine has been off for a long enough period of time, the air temperature values in the engine compartment of the vehicle are considered to have equalized, and the diagnostic can be enabled.  The diagnostic will fail if the IAT and IAT3 values are similar, and the IAT2 value is not similar to the IAT and IAT3 values. The diagnostic will also fail if none of the three sensor values are similar to each other, and the IAT2 value is furthest from the sensor value that is in the middle of the three sensor values.  This diagnostic is executed once per	<b><u>Good Correlation Between IAT and IAT3:</u></b>		Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips
			ABS(Power Up IAT - Power Up IAT2)	> 30 deg C	Powertrain Relay Voltage for a time	>= 11.0 Volts >= 0.9 seconds		
			AND		No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error		
			ABS(Power Up IAT - Power Up IAT3)	<= 25 deg C				
			AND					
			ABS(Power Up IAT2 - Power Up IAT3)	> 25 deg C				
		<b><u>Not Good Correlation. IAT in middle:</u></b>		Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met		
Power Up IAT is between Power Up IAT2 and Power Up IAT3		Powertrain Relay Voltage for a time	>= 11.0 Volts >= 0.9 seconds					
AND		No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error					
ABS(Power Up IAT2 - Power Up IAT3)	> 25 deg C							
AND								
ABS(Power Up IAT - Power Up IAT2) > ABS(Power Up IAT - Power Up IAT3)								
		<b><u>Not Good Correlation. IAT3 in middle:</u></b>		Time between current ignition cycle and the last time the engine was running	> 28,800 seconds	Executes once at the beginning of each ignition cycle if enable conditions are met		
Power Up IAT3 is between Power Up IAT and Power Up IAT2		Powertrain Relay Voltage for a time	>= 11.0 Volts >= 0.9 seconds					

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		ignition cycle if the enable conditions are met.	AND ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT3 - Power Up IAT2) > ABS(Power Up IAT3 - Power Up IAT)	> 30 deg C	No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 Low (applications with humidity)	P0097	<p>Detects a continuous short to ground in the Intake Air Temperature 2 (IAT2) signal circuit or an IAT2 sensor that is outputting a frequency signal that is too low. The diagnostic monitors the IAT2 sensor output frequency and fails the diagnostic when the IAT2 frequency is too low.</p> <p>The IAT2 sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is converted by the sensor to a frequency value in Hertz. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the frequency of the square wave signal and converts that frequency to a temperature value. A lower frequency is equivalent to a lower temperature.</p> <p>This diagnostic is enabled if the Powertrain Relay voltage is high enough.</p>	Raw IAT 2 Input	< 13 Hertz (~60 deg C)	<p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p>	<p>&gt;= 11.0 Volts &gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 High (applications with humidity)	P0098	<p>Detects an Intake Air Temperature 2 (IAT2) sensor that is outputting a frequency signal that is too high. The diagnostic monitors the IAT2 sensor output frequency and fails the diagnostic when the IAT2 frequency is too high.</p> <p>The IAT2 sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is converted by the sensor to a frequency value in Hertz. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the frequency of the square wave signal and converts that frequency to a temperature value. A higher frequency is equivalent to a higher temperature.</p> <p>This diagnostic is enabled if the Powertrain Relay voltage is high enough.</p>	Raw IAT 2 Input	> 390 Hertz (~150 deg C)	<p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p>	<p>&gt;= 11.0 Volts &gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Intermittent In-Range (applications with humidity)	P0099	<p>Detects a noisy or erratic signal in the Intake Air Temperature 2 (IAT2) circuit by monitoring the IAT2 sensor and failing the diagnostic when the IAT2 signal has a noisier output than is expected.</p> <p>When the value of the IAT2 signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of IAT2 readings. The result of this summation is called a "string length". Since the IAT2 signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic IAT2 signal. The diagnostic will fail if the string length is too high.</p> <p>This diagnostic is enabled if the Powertrain Relay voltage is high enough.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current IAT 2 reading - IAT 2 reading from 100 milliseconds previous)</p>	<p>&gt; 100.00 deg C</p> <p>10 consecutive IAT 2 readings</p>	<p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p>	<p>&gt;= 11.0 Volts &gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Start Diagnostic	P00C6	The DTC Diagnoses the high side fuel pressure during engine cranking.	<p>The ECM detects that the fuel pressure is not rising or has fallen beyond acceptable limits during engine cranking</p> <p>Pressure Rise Test: Sensed High Pressure Fuel Rail Pressure value</p> <p>Pressure Fall Test: Sensed High Pressure Fuel Rail Pressure value</p>	<p>&lt; <b>P00C6 - Minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery</b> (see Supporting Table)</p> <p>&lt;= <b>P00C6 - Minimum acceptable value of fuel rail pressure after High Pressure Start</b> (see Supporting Table)</p>	<p>High Pressure Rise Diagnostic During Start</p> <p>High Pressure Fall Diagnostic During Start</p> <p>Low side feed fuel pressure</p> <p>Engine Run Time Run/Crank Voltage Engine Coolant</p> <p>For each engine start, only 1 diagnostic is performed. The pressure rise test will run if High side fuel pressure is less than KtFHPC_p_HighPressStart, otherwise, the pressure fall diagnostic will run when the engine is cranking.</p>	<p>Enabled</p> <p>Disabled</p> <p>&gt;= 0 KPA</p> <p>&lt; = 1 sec &gt; 8 Volts -100 &lt;= °C &lt;= 128</p> <p>All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT, IAT2 and ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control</p>	<p>Pressure Rise Test: Crank Time &gt;= <b>P00C6 - High Pressure Pump Control Mode timeout</b> (see Supporting Table) 6.25 ms per sample</p> <p>Pressure Fall Test: Injected cylinder events &gt;= <b>P00C6 - maximum acceptable counts of fuel rail pressure below KtFHPD_p_HPS_PressFallLoThresh after High Pressure Start</b> (see Supporting Table)</p> <p>4 samples per engine rotation</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Barometric Pressure Inlet Air Temp	commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active >= 70.0 KPA >= -12.0 DegC		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Pressure Measuremen t System - Multiple Sensor Correlation (single turbo)	P00C7	<p>Detects an inconsistency between pressure sensors in the induction system in which a particular sensor cannot be identified as the failed sensor.</p> <p>If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The Manifold Pressure (MAP), Turbocharger Boost Pressure and Barometric Pressure (BARO) sensors values are checked to see if they are within the normal expected atmospheric pressure range. If they are, then MAP, Turbocharger Boost Pressure and BARO are compared to see if their values are similar.</p> <p>If two of these three sensors are similar, but the third is not, then a performance diagnostic for the specific sensor with the dissimilar value will fail.</p> <p>If there is no combination of two of</p>	<p>ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)</p> <p>OR</p> <p>ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)</p> <p>OR</p> <p>ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)</p>	<p>&gt; 10.0 kPa</p> <p>&lt;= 10.0 kPa</p> <p>&lt;= 10.0 kPa</p> <p>&lt;= 10.0 kPa</p> <p>&gt; 10.0 kPa</p> <p>&lt;= 10.0 kPa</p> <p>&lt;= 10.0 kPa</p> <p>&gt; 10.0 kPa</p> <p>&lt;= 10.0 kPa</p> <p>&gt; 10.0 kPa</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is not rotating</p> <p>Manifold Pressure Manifold Pressure Baro Pressure Baro Pressure Turbocharger Boost Pressure Turbocharger Boost Pressure</p> <p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>&gt; 10.0 seconds</p> <p>&gt;= 50.0 kPa &lt;= 115.0 kPa &gt;= 50.0 kPa &lt;= 115.0 kPa</p> <p>&gt;= 50.0 kPa &lt;= 115.0 kPa</p> <p>EngineModeNotRunTimer Error MAP_SensorFA AAP_SnsrFA AAP2_SnsrFA</p> <p>MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP</p>	<p>4 failures out of 5 samples</p> <p>1 sample every 12.5 msec</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		these three sensors that is similar, then the failed sensor cannot be uniquely identified. The Multiple Pressure Sensor Correlation Diagnostic will fail in this case.	Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	> 10.0 kPa  > 10.0 kPa				

## 20 OBDG03A ECM Summary Tables

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Strategy Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Fuel Press Regulator Solenoid Supply Voltage Control High Side Circuit Short to ground	P00C9	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1.1 or 15 Amps selectable threshold based on High pressure Pump.	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control High Side Circuit Short to power	P00CA	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	          ≤ 0.1 Amps between signal and controller power	Engine Speed Battery Voltage	≥ 50 RPM ≥ 11 Volts  Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 3 Circuit Performance (applications with humidity sensor and manifold temperature sensor)	P00E9	<p>Detects an Intake Air Temperature 3 (IAT3) sensor value that is stuck in range by comparing the IAT3 sensor value against the IAT and IAT2 sensor values and failing the diagnostic if the IAT3 value is more different than the IAT and IAT2 values than is expected. If the engine has been off for a long enough period of time, the air temperature values in the engine compartment of the vehicle are considered to have equalized, and the diagnostic can be enabled.</p> <p>The diagnostic will fail if the IAT and IAT2 values are similar, and the IAT3 value is not similar to the IAT and IAT2 values. The diagnostic will also fail if none of the three sensor values are similar to each other, and the IAT3 value is furthest from the sensor value that is in the middle of the three sensor values.</p> <p>This diagnostic is executed once per</p>	<p><b><u>Good Correlation Between IAT and IAT2:</u></b></p> <p>ABS(Power Up IAT - Power Up IAT2)</p> <p>AND</p> <p>ABS(Power Up IAT - Power Up IAT3)</p> <p>AND</p> <p>ABS(Power Up IAT2 - Power Up IAT3)</p>	<p>&lt;= 30 deg C</p> <p>&gt; 25 deg C</p> <p>&gt; 25 deg C</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p>	<p>&gt; 28,800 seconds</p> <p>&gt;= 11.0 Volts</p> <p>&gt;= 0.9 seconds</p> <p>PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error</p>	<p>Executes once at the beginning of each ignition cycle if enable conditions are met</p>	Type B, 2 Trips
			<p><b><u>Not Good Correlation. IAT in Middle:</u></b></p> <p>Power Up IAT is between Power Up IAT2 and Power Up IAT3</p> <p>AND</p> <p>ABS(Power Up IAT2 - Power Up IAT3)</p> <p>AND</p> <p>ABS(Power Up IAT - Power Up IAT3) &gt; ABS(Power Up IAT - Power Up IAT2)</p>	<p>&gt; 25 deg C</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p>	<p>&gt; 28,800 seconds</p> <p>&gt;= 11.0 Volts</p> <p>&gt;= 0.9 seconds</p> <p>PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error</p>	<p>Executes once at the beginning of each ignition cycle if enable conditions are met</p>	
			<p><b><u>Not Good Correlation. IAT2 in Middle:</u></b></p> <p>Power Up IAT2 is between Power Up IAT and Power Up IAT3</p>		<p>Time between current ignition cycle and the last time the engine was running</p> <p>Powertrain Relay Voltage for a time</p>	<p>&gt; 28,800 seconds</p> <p>&gt;= 11.0 Volts</p> <p>&gt;= 0.9 seconds</p>	<p>Executes once at the beginning of each ignition cycle if enable conditions are met</p>	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		ignition cycle if the enable conditions are met.	AND ABS(Power Up IAT - Power Up IAT3) AND ABS(Power Up IAT2 - Power Up IAT3) > ABS(Power Up IAT2 - Power Up IAT)	> 25 deg C	No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 3 Low (applications with manifold temperature and humidity)	P00EA	Detects a continuous short to ground in the Intake Air Temperature 3 (IAT3) signal circuit by monitoring the IAT3 sensor output resistance and failing the diagnostic when the IAT3 resistance is too low. The IAT3 sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A lower resistance is equivalent to a higher temperature.	Raw IAT 3 Input	< 56.50 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 3 High (applications with manifold temperature and humidity)	P00EB	Detects a continuous open circuit in the Intake Air Temperature 3 (IAT3) signal circuit by monitoring the IAT3 sensor output resistance and failing the diagnostic when the IAT3 resistance is too high. The IAT3 sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A higher resistance is equivalent to a lower temperature.	Raw IAT 3 Input	> 162,529 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 3 Intermittent In-Range	P00EC	<p>Detects a noisy or erratic signal in the Intake Air Temperature 3 (IAT3) circuit by monitoring the IAT3 sensor and failing the diagnostic when the IAT3 signal has a noisier output than is expected.</p> <p>When the value of the IAT3 signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of IAT3 readings. The result of this summation is called a "string length".</p> <p>Since the IAT3 signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic IAT3 signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current IAT 3 reading - IAT 3 reading from 100 milliseconds previous)</p>	<p>&gt; 80.00 deg C</p> <p>10 consecutive IAT 3 readings</p>	Continuous		<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Low	P00F4	<p>Detects a continuous short to ground in the humidity signal circuit or a humidity sensor that is outputting a duty cycle that is too low. The diagnostic monitors the humidity sensor duty cycle output and fails the diagnostic when the humidity duty cycle is too low.</p> <p>The humidity sensor converts the capacitance across the sensor to a relative humidity. The relative humidity value is converted by the sensor to a duty cycle value in %. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the duty cycle of the square wave signal and converts that duty cycle to a relative humidity value in % through a transfer function.</p> <p>This diagnostic is enabled if the Powertrain Relay voltage is high enough.</p>	Humidity Duty Cycle	<= 5.0 %	<p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p>	<p>&gt;= 11.0 Volts &gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit High	P00F5	<p>Detects a humidity sensor that is outputting a duty cycle signal that is too high. The diagnostic monitors the humidity sensor duty cycle output and fails the diagnostic when the humidity duty cycle is too high.</p> <p>The humidity sensor converts the capacitance across the sensor to a relative humidity. The relative humidity value is converted by the sensor to a duty cycle value in %. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the duty cycle of the square wave signal and converts that duty cycle to a relative humidity value in % through a transfer function.</p> <p>This diagnostic is enabled if the Powertrain Relay voltage is high enough.</p>	Humidity Duty Cycle	>= 95.0 %	<p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p>	<p>&gt;= 11.0 Volts &gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Intermittent	P00F6	<p>Detects a noisy or erratic signal in the humidity circuit by monitoring the humidity sensor and failing the diagnostic when the humidity signal has a noisier output than is expected.</p> <p>When the value of relative humidity in % is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of humidity readings. The result of this summation is called a "string length".</p> <p>Since the humidity signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic humidity signal. The diagnostic will fail if the string length is too high.</p> <p>This diagnostic is enabled if the Powertrain Relay voltage is high enough.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current Humidity reading - Humidity reading from 100 milliseconds previous)</p>	<p>&gt; 80 %</p> <p>10 consecutive Humidity readings</p>	<p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p>	<p>&gt;= 11.0 Volts &gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (single turbo)	P0101	<p>Detects a performance failure in the Mass Air Flow (MAF) sensor, such as when a MAF value is stuck in range.</p> <p>This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Manifold Pressure (MAP) sensor, Turbocharger Boost Pressure sensor and Throttle Position sensor (TPS).</p> <p>These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAF sensor. In this case, the MAF Performance diagnostic</p>	<p>See table <b>P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix</b> for combinations of model failures that can set this DTC.</p> <p>MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered</p> <p>MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered</p> <p>MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered</p> <p>MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered</p> <p>TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered</p> <p>TPS model fails when Filtered Throttle Model Error</p> <p>TIAP Correlation model fails when High Engine Air Flow is TRUE AND</p>	<p>&gt; 20.0 grams/sec</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 300 kPa*(g/s)</p>	<p>Engine Speed Engine Speed</p> <p>(Coolant Temp OR OBD Coolant Enable Criteria</p> <p>(Coolant Temp OR OBD Max Coolant Achieved</p> <p>Intake Air Temp Intake Air Temp</p> <p>Minimum total weight factor (all factors multiplied together)</p> <p>See Residual Weight Factor tables.</p>	<p>&gt;= 400 RPM &lt;= 6,000 RPM</p> <p>&gt;= -9 Deg C</p> <p>= TRUE)</p> <p>&lt;= 130 Deg C</p> <p>= FALSE)</p> <p>&gt;= -20 Deg C &lt;= 125 Deg C</p> <p>&gt;= 0.50</p> <p>Modeled Air Flow Error multiplied by <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM</b> and <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est</b></p> <p>MAP Model 1 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM</b></p>	<p>Continuous</p> <p>Calculation are performed every 12.5 msec</p>	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		will fail.	<p>Measured TIAP - measured MAP - offset as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP- MAP Correlation Offset</b></p> <p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP- Baro Correlation Offset</b></p> <p>TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p> <p>-</p>	<p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 1.0 seconds</p> <p>&gt; 1.0 seconds</p> <p>&gt; a threshold in gm/sec as a function of engine speed. See table</p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>MAP Model 2 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM</b></p> <p>MAP Model 3 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM</b></p> <p>TIAP Model 1 Error multiplied by <b>P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM</b></p> <p>Filtered Throttle Model Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM</b></p> <p>MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>AND Manifold Pressure</p> <p>AND Filtered Mass Air Flow - Mass Air Flow</p> <p>Low Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND Mass Air Flow - Filtered Mass Air Flow</p>	<p><b>P0101, P0106, P0121, P0236, P1101: TIAP- MAP Correlation Min Air Flow</b></p> <p>&gt; a threshold in kPa as a function of engine speed. See table</p> <p><b>P0101, P0106, P0121, P0236, P1101: TIAP- MAP Correlation Min MAP</b></p> <p>&lt; 3.0 gm/sec</p> <p>&lt; a threshold in gm/sec as a function of engine speed. See table</p> <p><b>P0101, P0106, P0121, P0236, P1101: TIAP- Baro Correlation Max Air Flow</b></p> <p>&lt; a threshold in kPa as a function of engine speed. See table</p> <p><b>P0101, P0106, P0121, P0236, P1101: TIAP- Baro Correlation Max MAP</b></p> <p>&lt; 2.0 gm/sec</p>		MnfdTempSensorCktFP		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit Low Frequency	P0102	<p>Detects a continuous short to ground in the MAF sensor circuit or a MAF sensor that is outputting a frequency that is too low. The diagnostic monitors the MAF sensor frequency output and fails the diagnostic when the MAF frequency is too low.</p> <p>The MAF sensor monitors the temperature of a circuit in the air flow of the engine. The temperature of this circuit is related to the air velocity across the sensor. The MAF sensor converts this air velocity to a mass air flow value. The mass air flow value is converted by the sensor to a frequency value in Hertz. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the frequency of the square wave signal and converts that frequency to a mass air flow value in grams/second through a transfer function.</p>	MAF Output	<= 750 Hertz (~ 0.34 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 11.0 Volts >= 1.0 seconds	200 failures out of 250 samples  1 sample every cylinder firing event	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit High Frequency	P0103	<p>Detects a MAF sensor that is outputting a frequency signal that is too high. The diagnostic monitors the MAF sensor frequency output and fails the diagnostic when the MAF frequency is too high.</p> <p>The MAF sensor monitors the temperature of a circuit in the air flow of the engine. The temperature of this circuit is related to the air velocity across the sensor. The MAF sensor converts this air velocity to a mass air flow value. The mass air flow value is converted by the sensor to a frequency value in Hertz. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the frequency of the square wave signal and converts that frequency to a mass air flow value in grams/second through a transfer function.</p>	MAF Output	>= 13,350 Hertz (~ 489.9 gm/sec)	Engine Run Time Engine Speed Ignition Voltage Above criteria present for a period of time	> 1.0 seconds >= 300 RPM >= 11.0 Volts >= 1.0 seconds	200 failures out of 250 samples 1 sample every cylinder firing event	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (single turbo)	P0106	<p>Detects a performance failure in the Manifold Pressure (MAP) sensor, such as when a MAP value is stuck in range.</p> <p>If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The MAP sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the MAP performance diagnostic will fail.</p> <p>If the MAP sensor value is within the normal expected atmospheric range, then MAP, Turbocharger Boost Pressure, and Barometric Pressure (BARO) are compared to see if their values are similar. If the Turbocharger Boost Pressure and BARO sensor values are similar, but the MAP value is not similar, then a MAP performance diagnostic will fail.</p>	<p><b><u>Engine Running:</u></b></p> <p>See table <b>P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix</b> for combinations of model failures that can set this DTC.</p> <p>MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered</p> <p>MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered</p> <p>MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered</p> <p>MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered</p> <p>TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered</p> <p>TPS model fails when Filtered Throttle Model Error</p> <p>TIAP Correlation model fails when</p> <p>High Engine Air Flow is TRUE</p>	<p>&gt; 20.0 grams/sec</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 300 kPa*(g/s)</p>	<p>Engine Speed Engine Speed</p> <p>(Coolant Temp OR OBD Coolant Enable Criteria</p> <p>(Coolant Temp OR OBD Max Coolant Achieved</p> <p>Intake Air Temp Intake Air Temp</p> <p>Minimum total weight factor (all factors multiplied together)</p> <p>See Residual Weight Factor tables.</p>	<p>&gt;= 400 RPM &lt;= 6,000 RPM</p> <p>&gt;= -9 Deg C</p> <p>= TRUE)</p> <p>&lt;= 130 Deg C</p> <p>= FALSE)</p> <p>&gt;= -20 Deg C &lt;= 125 Deg C</p> <p>&gt;= 0.50</p> <p>Modeled Air Flow Error multiplied by <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM</b> and <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est</b></p> <p>MAP Model 1 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM</b></p> <p>MAP Model 2 Error</p>	<p>Continuous</p> <p>Calculation are performed every 12.5 msec</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>The engine running portion of this diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Mass Air Flow (MAF) sensor, Turbocharger Boost Pressure sensor and Throttle Position sensor (TPS).</p> <p>These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAP sensor. In this case, the MAP Performance diagnostic will fail.</p>	<p>AND Measured TIAP - measured MAP - offset as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP- MAP Correlation Offset</b></p> <p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP- Baro Correlation Offset</b></p> <p>TIAP Correlation is valid when</p> <p>High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p>	<p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 1.0 seconds</p> <p>&gt; 1.0 seconds</p> <p>&gt; a threshold in gm/sec as a function of engine speed See table</p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM</b></p> <p>MAP Model 3 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM</b></p> <p>TIAP Model 1 Error multiplied by <b>P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM</b></p> <p>Filtered Throttle Model Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM</b></p> <p>MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>AND Manifold Pressure</p> <p>AND Filtered Mass Air Flow - Mass Air Flow</p> <p>Low Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND Mass Air Flow - Filtered Mass Air Flow</p> <p><b><u>Engine Not Rotating:</u></b></p> <p>Manifold Pressure</p>	<p><b>P0101, P0106, P0121, P0236, P1101: TIAP- MAP Correlation Min Air Flow</b></p> <p>&gt; a threshold in kPa as a function of engine speed See table</p> <p><b>P0101, P0106, P0121, P0236, P1101: TIAP- MAP Correlation Min MAP</b></p> <p>&lt; 3.0 gm/sec</p> <p>&lt; a threshold in gm/sec as a function of engine speed See table</p> <p><b>P0101, P0106, P0121, P0236, P1101: TIAP- Baro Correlation Max Air Flow</b></p> <p>&lt; a threshold in kPa as a function of engine speed See table</p> <p><b>P0101, P0106, P0121, P0236, P1101: TIAP- Baro Correlation Max MAP</b></p> <p>&lt; 2.0 gm/sec</p> <p>&lt; 50.0 kPa</p>		MnfdTempSensorCktFP		
					Time between current ignition cycle and the last time the engine was		4 failures out of 5 samples	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR Manifold Pressure  OR ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	> 115.0 kPa   > 10.0 kPa  > 10.0 kPa  <= 10.0 kPa	running  Engine is not rotating  No Active DTCs:   No Pending DTCs:	> 10.0 seconds  EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA AAP2_SnsrCktFA  MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP	1 sample every 12.5 msec	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low (Gen III)	P0107	Detects a continuous short to ground in the Manifold Absolute Pressure (MAP) signal circuit by monitoring the MAP sensor output voltage and failing the diagnostic when the MAP voltage is too low. The MAP sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	MAP Voltage	< 9.0 % of 5 Volt Range (This is equal to -11.2 kPa)	Continuous		320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit High (Gen III)	P0108	Detects a continuous short to power or open circuit in the Manifold Absolute Pressure (MAP) signal circuit by monitoring the MAP sensor output voltage and failing the diagnostic when the MAP voltage is too high. The MAP sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	MAP Voltage	> 78.0 % of 5 Volt Range (This is equal to 299.0 kPa)	Continuous		320 failures out of 400 samples  1 sample every 12.5 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor and manifold temperature sensor)	P0111	<p>Detects an Intake Air Temperature (IAT) sensor value that is stuck in range by comparing the IAT sensor value against the IAT2 and IAT3 sensor values and failing the diagnostic if the IAT value is more different than the IAT2 and IAT3 values than is expected. If the engine has been off for a long enough period of time, the air temperature values in the engine compartment of the vehicle are considered to have equalized, and the diagnostic can be enabled.</p> <p>The diagnostic will fail if the IAT2 and IAT3 values are similar, and the IAT value is not similar to the IAT2 and IAT3 values. The diagnostic will also fail if none of the three sensor values are similar to each other, and the IAT value is furthest from the sensor value that is in the middle of the three sensor values.</p> <p>This diagnostic is executed once per</p>	<p><b><u>Good Correlation Between IAT2 and IAT3</u></b></p> <p>ABS(Power Up IAT - Power Up IAT2)</p> <p>AND</p> <p>ABS(Power Up IAT - Power Up IAT3)</p> <p>AND</p> <p>ABS(Power Up IAT2 - Power Up IAT3)</p>	<p>&gt; 30 deg C</p> <p>&gt; 25 deg C</p> <p>&lt;= 25 deg C</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p>	<p>&gt; 28,800 seconds</p> <p>&gt;= 11.0 Volts</p> <p>&gt;= 0.9 seconds</p> <p>PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error</p>	<p>Executes once at the beginning of each ignition cycle if enable conditions are met</p>	Type B, 2 Trips
			<p><b><u>Not Good Correlation. IAT2 in Middle:</u></b></p> <p>Power Up IAT2 is between Power Up IAT and Power Up IAT3</p> <p>AND</p> <p>ABS(Power Up IAT - Power Up IAT3)</p> <p>AND</p> <p>ABS(Power Up IAT2 - Power Up IAT) &gt; ABS(Power Up IAT2 - Power Up IAT3)</p>	<p>&gt; 25 deg C</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p>	<p>&gt; 28,800 seconds</p> <p>&gt;= 11.0 Volts</p> <p>&gt;= 0.9 seconds</p> <p>PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error</p>	<p>Executes once at the beginning of each ignition cycle if enable conditions are met</p>	
			<p><b><u>Not Good Correlation. IAT3 in Middle:</u></b></p> <p>Power Up IAT3 is between Power Up IAT and Power Up IAT2</p>		<p>Time between current ignition cycle and the last time the engine was running</p> <p>Powertrain Relay Voltage for a time</p>	<p>&gt; 28,800 seconds</p> <p>&gt;= 11.0 Volts</p> <p>&gt;= 0.9 seconds</p>	<p>Executes once at the beginning of each ignition cycle if enable conditions are met</p>	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		ignition cycle if the enable conditions are met.	AND ABS(Power Up IAT - Power Up IAT2) AND ABS(Power Up IAT3 - Power Up IAT) > ABS(Power Up IAT3 - Power Up IAT2)	> 30 deg C	No Active DTCs:	PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA MnfdTempSensorCktFA HumTempSnsrCktFA EngineModeNotRunTimer Error		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Low	P0112	Detects a continuous short to ground in the Intake Air Temperature (IAT) signal circuit by monitoring the IAT sensor output resistance and failing the diagnostic when the IAT resistance is too low. The IAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A lower resistance is equivalent to a higher temperature.	Raw IAT Input	< 58.00 Ohms (~150 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit High	P0113	Detects a continuous open circuit in the Intake Air Temperature (IAT) signal circuit by monitoring the IAT sensor output resistance and failing the diagnostic when the IAT resistance is too high. The IAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A higher resistance is equivalent to a lower temperature.	Raw IAT Input	> 142,438 Ohms (~-60 deg C)	Engine Run Time	> 0.00 seconds	40 failures out of 50 samples  1 sample every 100 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Intermittent In-Range	P0114	<p>Detects a noisy or erratic signal in the Intake Air Temperature (IAT) circuit by monitoring the IAT sensor and failing the diagnostic when the IAT signal has a noisier output than is expected.</p> <p>When the value of the IAT signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of IAT readings. The result of this summation is called a "string length".</p> <p>Since the IAT signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic IAT signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current IAT reading - IAT reading from 100 milliseconds previous)</p>	<p>&gt; 80.00 deg C</p> <p>10 consecutive IAT readings</p>	Continuous		<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Performance	P0116	This DTC detects an ECT (Engine Coolant temperature) sensor that is biased high or stuck above the thermostat monitoring diagnostic. This check is performed after a soak condition.	<p>A failure will be reported if any of the following occur:</p> <p>1) ECT at power up &gt; IAT at power up by an IAT based table lookup value after a minimum 25,200 second soak (fast fail).</p> <p>2) ECT at power up &gt; IAT at power up by 15.8 °C after a minimum 25,200 second soak and a block heater has not been detected.</p> <p>3) ECT at power up &gt; IAT at power up by 15.8 C after a minimum 25,200 seconds soak and the time spent cranking the engine without starting is greater than 10.0 seconds with the LowFuelConditionDiag</p>	<p>See <b>P0116_Fail if power up ECT exceeds IAT by these values</b> in the Supporting tables section</p> <p>= False</p>	<p>No Active DTC's</p> <p>Non-volatile memory initialization</p> <p>Test complete this trip Test aborted this trip IAT LowFuelCondition Diag</p> <p>=====</p> <p>Block Heater detection is enabled when either of the following occurs:</p> <p>1) ECT at power up &gt; IAT at power up by</p> <p>2) Cranking time</p> <p>=====</p> <p>Block Heater is detected and diagnostic is aborted when 1) or 2) occurs:</p> <p>1a) Vehicle drive time</p> <p>1b) Vehicle speed</p> <p>1c) Additional Vehicle drive time is provided to 1a when Vehicle speed is below 1b as follows:</p>	<p>VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA IgnitionOffTimeValid TimeSinceEngineRunning Valid</p> <p>= Not occurred</p> <p>= False = False ≥ -9 °C</p> <p>= False</p> <p>=====</p> <p>&gt; 15.8 °C</p> <p>&lt; 10.0 seconds</p> <p>=====</p> <p>&gt; 400 seconds</p> <p>with &gt; 15 MPH</p> <p>0.50 times the seconds with vehicle speed below 1b</p>	<p>1 failure</p> <p>500 msec/ sample</p> <p>Once per valid cold start</p>	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					1d) IAT drops from power up IAT  2a) ECT drops from power up ECT  2b) Engine run time  ===== Diagnostic is aborted when 3) or 4) occurs:  3) Engine run time with vehicle speed below 1b  4) Minimum IAT during test	≥ 5.3 °C  ≥ 1 °C  Within ≤ 60 seconds  =====  > 1800 seconds  ≤ -9 °C		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit Low	P0117	Circuit Continuity This DTC detects a short to ground in the ECT (Engine Coolant temperature) signal circuit or the ECT sensor. This is accomplished by monitoring the resistance of the circuit. If the resistance goes out of the expected range the DTC is set.	ECT Resistance (@ 150°C)	< 38 Ohms			5 failures out of 6 samples  1 sec/ sample  Continuous	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit High	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT (Engine Coolant temperature) signal circuit or the ECT sensor. This is accomplished by monitoring the resistance of the circuit. If the resistance goes out of the expected range the DTC is set.	ECT Resistance (@ -60°C)	> 320,000 Ohms	Engine run time OR IAT min	> 10.0 seconds  ≥ -9.0 °C	5 failures out of 6 samples  1 sec/ sample  Continuous	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent	P0119	Circuit Erratic This DTC detects large step changes in the ECT (Engine Coolant temperature) signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample and sensor time constant. If the sensor responds faster than should be possible the DTC is set.	ECT temperature step change:  1) positive step change is greater than calculated high limit  OR  2) negative step change is lower than calculated low limit.  The calculated high and low limits for the next reading use the following calibrations: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit  *****Generic Example*****  If the last ECT reading was 90 Deg C, the Time constant was calibrated at 10 seconds, the low limit was calibrated to -80 Deg C and the high limit was calibrated to 200 Deg C the calculated limits are 101 Deg C and 73 Deg C.  The next reading (after the 90 Deg C reading) must be between 73 Deg C and 101 Deg C to be valid.  *****	7.4 seconds -60.0 Deg C 200.0 Deg C	No Active DTC's	ECT_Sensor_Ckt_FP	3 failures out of 4 samples  1 sec/ sample  Continuous	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Sensor Performance (single turbo)	P0121	<p>Detects a performance failure in the Throttle Position sensor (TPS) sensor, such as when a TPS value is stuck in range.</p> <p>This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Manifold Pressure (MAP) sensor, Turbocharger Boost Pressure sensor and Mass Air Flow (MAF) sensor.</p> <p>These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the TPS sensor. In this case, the TPS</p>	<p>See table <b>P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix</b> for combinations of model failures that can set this DTC.</p> <p>MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered</p> <p>MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered</p> <p>MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered</p> <p>MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered</p> <p>TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered</p> <p>TPS model fails when Filtered Throttle Model Error</p> <p>TIAP Correlation model fails when</p> <p>High Engine Air Flow is TRUE AND Measured TIAP -</p>	<p>&gt; 20.0 grams/sec</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 300 kPa*(g/s)</p>	<p>Engine Speed Engine Speed</p> <p>(Coolant Temp OR OBD Coolant Enable Criteria</p> <p>(Coolant Temp OR OBD Max Coolant Achieved</p> <p>Intake Air Temp Intake Air Temp</p> <p>Minimum total weight factor (all factors multiplied together)</p> <p>See Residual Weight Factor tables.</p>	<p>&gt;= 400 RPM &lt;= 6,000 RPM</p> <p>&gt;= -9 Deg C</p> <p>= TRUE)</p> <p>&lt;= 130 Deg C</p> <p>= FALSE)</p> <p>&gt;= -20 Deg C &lt;= 125 Deg C</p> <p>&gt;= 0.50</p> <p>Modeled Air Flow Error multiplied by <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM</b> and <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est</b></p> <p>MAP Model 1 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM</b></p>	<p>Continuous</p> <p>Calculation are performed every 12.5 msec</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Performance diagnostic will fail.	<p>measured MAP - offset as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset</b></p> <p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset</b></p> <p>TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND</p>	<p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 1.0 seconds</p> <p>&gt; 1.0 seconds</p> <p>&gt; a threshold in gm sec as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow</b></p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>MAP Model 2 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM</b></p> <p>MAP Model 3 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM</b></p> <p>TIAP Model 1 Error multiplied by <b>P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM</b></p> <p>Filtered Throttle Model Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM</b></p> <p>MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP</p>		

## 20 OBDG03A ECM Summary Tables

[illegible]

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit Low	P0122	Detects a continuous or intermittent short low or open in TPS1 circuit by monitoring the TPS 1 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too low. This diagnostic only runs when battery voltage is high enough.	TPS1 % Vref <	0.3250 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P06A3	79 / 159 counts;  57 counts continuous;  3.125 ms /count in the ECM main processor	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit High	P0123	Detects a continuous or intermittent short high in TPS1 circuit by monitoring the TPS 1 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too high. This diagnostic only runs when battery voltage is high enough.	TPS1 % Vref >	4.750 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P06A3	79 / 159 counts;  57 counts continuous;  3.125 ms /count in the ECM main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Below Stat Regulating Temperature	P0128	This DTC detects if the ECT (EngineCoolant temperature) does not achieve the required target temperature after an allowed energy accumulation by the engine. This can be caused by an ECT sensor biased low or a cooling system that is not warming up correctly because of a stuck open thermostat or other fault.	<p>Energy is accumulated after the first combustion event using Range #1 or #2 below:</p> <p>Thermostat type is divided into normal (non-heated) and electrically heated.</p> <p>For this application the "type" cal (KeTHMG_b_TMS_ElecThstEquipped) = 0 If the type cal is equal to one, the application has an electrically heated t-stat, if equal to zero the the application has an non heated t-stat. See appropriate section below.</p> <p>***** Type cal above = 1 (Electrically heated t-stat) == == == == Range #1 (Primary) ECT reaches Commanded temperature minus 19 °C when Ambient min is ≤ 52 °C and &gt; 10 °C. Note: Warm up target for range #1 will be at least 71 °C == == == == Range #2 (Alternate) ECT reaches Commanded temperature minus 50 °C when Ambient min is ≤ 10 °C and &gt; -9 °C. Note: Warm up target for range #2 will be at least</p>	<p>See the two tables named: <b>P0128_Maximum Accumulated Energy for Start-up ECT conditions - Primary</b> and <b>P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate</b> in the Supporting tables section.</p> <p>This diagnostic models the net energy into and out of the cooling</p>	<p>No Active DTC's</p> <p>Engine not run time (soaking time before current trip)</p> <p>Engine run time</p> <p>Fuel Condition</p> <p>Distance traveled</p> <p>***** If Engine RPM is continuously greater than for this time period</p> <p>The diagnostic test for this key cycle will abort *****</p> <p>***** If T-Stat Heater commanded duty cycle for this time period</p>	<p>ECT_Sensor_Ckt_FA ECT_Sensor_Perf_FA VehicleSpeedSensor_FA OAT_PtEstFiltFA IAT_SensorCircuitFA MAF_SensorFA THMR_AWP_AuxPumpFA THMR_AHV_FA THMR_SWP_Control_FA THMR_SWP_NoFlow_FA THMR_SWP_FlowStuckOn_FA EngineTorqueEstInaccuracy</p> <p>≥ 1,800 seconds</p> <p>30 ≤ Eng Run Tme ≤ 1,450 seconds</p> <p>Ethanol ≤ 87 %</p> <p>≥ 0.93 miles</p> <p>*****</p> <p>9,999 rpm 5.0 seconds</p> <p>*****</p> <p>*****</p> <p>&gt; 20.0 % duty cycle &gt; 5.0 seconds</p>	<p>1 failure to set DTC</p> <p>1 sec/ sample</p> <p>Once per ignition key cycle</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			55 °C ***** Type cal above = 0 (non - heated t-stat) == == == == Range #1 (Primary) ECT reaches 71 °C when Ambient min is ≤ 52 °C and > 10 °C. == == == == Range #2 (Alternate) ECT reaches 55 °C when Ambient min is ≤ 10 °C and > -9 °C. *****	system during the warm-up process.  The five energy terms are: heat from combustion (with AFM correction), heat from after-run, heat loss to enviroment, heat loss to cabin and heat loss to DFCO.	The diagnostic test for this key cycle will abort  ***** ECT at start run	***** -40 ≤ ECT ≤ 52 °C		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 1 (For use with WRAF - E80)	P0131	<p>This DTC determines if the WRAF O2 sensor signal circuit is shorted low. This DTC will detect a short to ground fault to the Pump Current, Reference Cell Voltage and Reference Ground circuits. When enabled, the diagnostic monitors the three different failure counters it receives from the WRAF Application-Specific Integrated Circuit (ASIC).</p> <p>The individual diagnostic failure counters are incremented based on the message received from the ASIC. The DTC is set based on any of the three individual fail and sample counters.</p>	<p>B1S1 WRAF ASIC indicates a ground short to any of the following WRAF signals:</p> <p>A) Pump Current - short to ground fail counts are accumulated to determine fault status.</p> <p>B) Reference Cell Voltage - short to ground fail counts are accumulated to determine fault status.</p> <p>C) Reference Ground - short to ground fail counts are accumulated to determine fault status.</p> <p><u>Note:</u> This ASIC is referred to as C2WRAF (Delphi).</p> <p><u>Note:</u> A ground short on the Pump Current or Reference Voltage signal may also set a P223C DTC.</p>	<p>The ASIC provides a fault indication when the pump current pin is between -150 mV and +175 mV.</p> <p>The ASIC provides a fault indication when the Reference Cell Voltage pin &lt; 225 mV.</p> <p>The ASIC provides a fault indication when during the intrusive test the Reference Cell impedance change is <math>\leq</math> 90 ohms.</p> <p><u>Note:</u> Signal A &amp; B faults must exist for 24 ASIC clock cycles to qualify for a fail flag.</p> <p>The three fault signals have individual X out of Y calibrations. When the X out of Y is reached in any region this DTC is set.</p>	<p>B1S1 DTC's Not active this key cycle</p> <p>Measure Valid status (ASIC)</p> <p>Controller status (ASIC)</p> <p>Engine Run or Auto stop</p> <p>*****</p> <p>Heater Warm-up delay Then WRAF circuit diagnostic delay (since heater Warm-up delay is complete) *****</p>	<p>P0135, P0030, P0031 or P0032</p> <p>= Valid</p> <p>= Ready</p> <p>= True</p> <p>= Complete</p> <p><math>\geq</math> 20.0 seconds</p>	<p>Signal A: 128 failures out of 160 samples</p> <p>OR</p> <p>Signal B: 128 failures out of 160 samples</p> <p>OR</p> <p>Signal C: 3 failures out of 1 samples</p> <p>Frequency for Signal A &amp; B: Continuous in 25 milli - second loop</p> <p>Frequency for Signal C: Tested during an intrusive event performed every 60 seconds. During each event the impedance is measured 3 times once every 12.5 msec.</p> <p><u>Note:</u> If the fail count value is greater than the sample count value that individual</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							monitor is disabled.	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1 (For use with WRAF - E80)	P0132	<p>This DTC determines if the WRAF O2 sensor signal circuit is shorted high. This DTC will detect a short to power fault to the Pump Current (and Trim circuit), Reference Cell Voltage and Reference Ground circuit. When enabled, the diagnostic monitors the three different failure counters it receives from the WRAF Application-Specific Integrated Circuit (ASIC).</p> <p>The individual diagnostic failure counters are incremented based on the message received from the ASIC. The DTC is set based on any of the three individual fail and sample counters.</p>	<p>B1S1 WRAF ASIC indicates a short to power on any of the following WRAF signals:</p> <p>A) Pump Current - short to power fail counts are accumulated to determine fault status.</p> <p>B) Reference Cell Voltage - short to power fail counts are accumulated to determine fault status.</p> <p>C) Reference Ground - short to power fail counts are accumulated to determine fault status.</p> <p><u>Note:</u> This ASIC is referred to as C2WRAF (Delphi).</p>	<p>The ASIC provides a fault indication when the pump current pin &gt; 2.8 V.</p> <p>The ASIC provides a fault indication when the Reference Cell Voltage pin &gt; 3.3 V.</p> <p>The ASIC provides a fault indication when the Reference Ground pin &gt; 225 mV.</p> <p><u>Note:</u> The above faults must exist for 21 ASIC clock cycles to qualify for a fail flag.</p> <p>The three fault signals have individual X out of Y calibrations. When the X out of Y is reached in any region this DTC is set.</p>	<p>B1S1 DTC's Not active this key cycle</p> <p>Measure Valid Status (ASIC)</p> <p>Controller status (ASIC)</p> <p>Engine Run or Auto stop</p> <p>*****</p> <p>Heater Warm-up delay Then WRAF circuit diagnostic delay (since heater Warm-up delay is complete) *****</p>	<p>P0135, P0030, P0031 or P0032</p> <p>= Valid</p> <p>= Ready</p> <p>= True</p> <p>= Complete</p> <p>≥ 20.0 seconds</p>	<p>Signal A: 128 failures out of 160 samples</p> <p>OR</p> <p>Signal B: 128 failures out of 160 samples</p> <p>OR</p> <p>Signal C: 128 failures out of 160 samples</p> <p>Frequency: Continuous in 25 milli - second loop</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 1	P0135	<p>This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor.</p> <p>The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.</p>	Heater Current outside of the expected range of	0.3 < Amps < 4.0	<p>No Active DTC's</p> <p>System Voltage Heater Warm-up delay O2S Heater device control</p> <p>B1S1 O2S Heater Duty Cycle</p> <p>All of the above met for</p>	<p>ECT_Sensor_FA</p> <p>&gt; 10.0 Volts = Complete</p> <p>= Not active</p> <p>&gt; zero</p> <p>&gt; 120 seconds</p>	<p>8 failures out of 10 samples</p> <p>Frequency: 3 tests per trip 30 seconds delay between tests and 1 second execution rate</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

[illegible]



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition  Ethanol Estimation in Progress  Fuel State  All of the above met for	Enabled (On) Ethanol ≤ 87 %  = Not Active (Please see “ <b>Ethanol Estimation in Progress</b> ” in Supporting Tables).  DFCO not active  > 5.0 seconds		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0138	<p>This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	> 1,050 mvolts	<p>No Active DTC's</p> <p>System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>*****</p> <p>Secondary delay after above conditions are complete (cold start condition)</p> <p>Secondary delay after above conditions are complete (not cold start condition)</p> <p>Commanded Equivalence Ratio</p> <p>*****</p> <p>All of the above met for</p>	<p>TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA EvapExcessPurgePsbl_FA FuelInjectorCircuit_FA Ethanol Composition Sensor FA AIR System FA</p> <p>10.0 &lt; Volts = All Cylinders active = Complete &gt; 5.0 seconds &gt; 30.0 seconds</p> <p>= False = False</p> <p>*****</p> <p>&gt; 175.0 seconds when engine soak time &gt; 28,800 seconds</p> <p>&gt; 175.0 seconds when engine soak time ≤ 28,800 seconds</p> <p>≤ 1.040 EQR</p> <p>*****</p> <p>&gt; 5.0 seconds</p>	<p>100 failures out of 125 samples</p> <p>Frequency: Continuous in 100 milli - second loop</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 1 Sensor 2	P013A	<p>The P013A diagnostic is the third in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, &amp; P013B. This DTC determines if the secondary O2 sensor has an slow response to an A/F change from Rich to Lean and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>Note: The Primary method is used when the secondary O2 sensor signal transitions from above the upper threshold to below the lower threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P013A diagnostic measures the secondary O2 sensor voltage response rate</p>	<p>Primary Method: The EWMA of the Post O2 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient.</p> <p>OR</p> <p>Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)</p>	<p>&gt; 8.0 units ≤ 7.2 units</p> <p>&gt; 51.7 grams (upper voltage threshold is 450 mvolts and lower voltage threshold is 150 mvolts)</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013B, P013E, P013F, P2270 or P2271</p> <p>&gt; 10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" ) = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.</p>	<p>Type A, 1 Trips EWMA</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>between an upper and lower voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized integral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTC P013A is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p>Secondary method:</p>			<p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>Crankshaft Torque</p> <p>DTC's Passed</p> <p>=====</p> <p>After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).</p>	<p>= False</p> <p>= False</p> <p>= Enabled, refer to <b>Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests</b> for additional info. &lt; 100.0 Nm</p> <p>P2270 (and P2272 if applicable) P013E (and P014A if applicable)</p> <p>=====</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required lower voltage threshold before the accumulated mass air flow threshold is reached.						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	<p>The P013B diagnostic is the sixth in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, &amp; P013B. This DTC determines if the secondary O2 sensor has an slow response to an A/F change from Lean to Rich and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>Note: The Primary method is used when the secondary O2 sensor signal transitions from below the lower threshold to above the upper threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P013B diagnostic measures the secondary O2 sensor voltage response rate</p>	<p>Primary Method: The EWMA of the Post O2 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient.</p> <p>OR</p> <p>Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)</p>	<p>&gt; 8.0 units ≤ 7.2 units</p> <p>&gt; 99 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 600 mvolts)</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013A, P013E, P013F, P2270 or P2271</p> <p>&gt; 10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.</p>	<p>Type A, 1 Trips EWMA</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>between an lower and upper voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized intregral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTC P013B is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p>Secondary method:</p>			<p>Green Cat System Condition</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>DTC's Passed</p> <p>=====</p> <p>After above conditions are met: Fuel Enrich mode continued.</p> <p>=====</p>	<p>is above 22.0 grams/sec.</p> <p>= Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False</p> <p>= False</p> <p>= Enabled, refer to <b>Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests</b> for additional info.</p> <p>P2270 P013E P013A P2271 P013F</p> <p>=====</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required upper voltage threshold before the accumulated mass air flow threshold is reached.			During this test the following must stay TRUE or the test will abort: 0.960 ≤ Base Commanded EQR ≤ 1.080			



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 2	P013E	<p>The P013E diagnostic is the second in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, &amp; P013B. This DTC determines if the secondary O2 sensor has an initial delayed response to an A/F change from Rich to Lean and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary O2 sensor does not achieve the required voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post O2 sensor voltage</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Delayed Response Test under DFCO</p> <p>DFCO begins after: 1) Catalyst has been rich for a minimum of AND 2) Catalyst Rich Accumulation Air Flow is</p>	<p>&gt; 450 mvolts</p> <p>&gt; 42 grams</p> <p>&gt; 1 secs</p> <p>≥ 11.0 grams</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013A, P013B, P013F, P2270 or P2271</p> <p>&gt; 10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>Crankshaft Torque</p> <p>DTC's Passed</p> <p>Number of fueled cylinders =====</p> <p>After above conditions are met: DFCO mode entered (wo driver initiated pedal input).</p>	<p>is above 22.0 grams/sec.</p> <p>= False</p> <p>= False</p> <p>= Enabled, refer to <b>Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests</b> for additional info. &lt; 100.0 Nm</p> <p>P2270</p> <p>≤ 3 cylinders =====</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 2	P013F	<p>The P013F diagnostic is the fifth in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, &amp; P013B. This DTC determines if the secondary O2 sensor has an initial delayed response to an A/F change from Lean to Rich and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary O2 sensor does not achieve the required voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post O2 sensor voltage</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Delayed Response Test</p>	<p>&lt; 350 mvolts</p> <p>&gt; 346 grams</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013A, P013B, P013E, P2270 or P2271</p> <p>&gt; 10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Green Cat System Condition</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>DTC's Passed</p> <p>Number of fueled cylinders =====</p> <p>After above conditions are met: Fuel Enrich mode entered. =====</p> <p>During this test the</p>	<p>is above 22.0 grams/sec.</p> <p>= Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False</p> <p>= False</p> <p>= Enabled, refer to <b>Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests</b> for additional info.</p> <p>P2270 P013E P013A P2271</p> <p>≥ 1 cylinders =====</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					following must stay TRUE or the test will abort: 0.960 ≤ Base Commanded EQR ≤ 1.080			

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 2) (For Single Bank Exhaust Only	P0141	<p>This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor.</p> <p>The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.</p>	Heater Current outside of the expected range of	0.3 > amps > 2.5	<p>No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle</p> <p>All of the above met for</p>	<p>ECT_Sensor_FA &gt; 10.0 Volts = Complete</p> <p>= Not active</p> <p>&gt; zero</p> <p>&gt; 120 seconds</p>	<p>8 failures out of 10 samples</p> <p>Frequency: 3 tests per trip 30 seconds delay between tests and 1 second execution rate.</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 1) (For use with WRAF	P015A	<p>DTC P015A detects that the primary WRAF oxygen sensor for Bank 1 has delayed response when the air fuel ratio transitions from rich to lean condition. This diagnostic runs simultaneously with the intrusive secondary O2 monitor rich to lean tests (P013E / P013A / P2271), which commands fuel cut off.</p> <p>Note: The Primary method is used when the primary WRAF O2 sensor signal transitions from above to below the O2 measured EQR threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P015A diagnostic measures the primary WRAF O2 sensor response time between a rich condition above a starting measured EQR threshold and a lower measured EQR threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro,</p>	<p>Primary method: The EWMA of the Pre O2 sensor normalized R2L time delay value. The EWMA repass limit is The EWMA calculation uses a 0.20 coefficient. This method calculates the result when the WRAF O2 sensor measured EQR is</p> <p>OR</p> <p>Secondary Method: The Accumulated time monitored during the R2L Delayed Response Test.</p> <p>AND</p> <p>Pre WRAF O2 sensor measured EQR is</p>	<p>&gt; 0.50 EWMA (sec) ≤ 0.41 EWMA (sec)</p> <p>&lt; 0.800 EQR</p> <p>≥ 3.6 Seconds</p> <p>&gt; 0.300 EQR</p>	<p>No Active DTC's</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA WRAF_Bank_1_FA P0131, P0132, P013A, P013B, P013E, P013F, P2270, P2271</p> <p>&gt; 10.0 Volts = Not active = Not active = Not active = Not active</p> <p>= False = False</p> <p>= Not Valid,</p>	<p>Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed</p>	<p>Type A, 1 Trips EWMA</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>and intake air temperature resulting in a normalized delay value. The normalized delay is fed into a 1st order lag filter to update the final EWMA result. DTC P015A is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p><u>Secondary method:</u> This fault is set if the primary WRAF O2 sensor does not achieve the required lower measured EQR</p>			<p>O2 Heater (pre sensor) on for</p> <p>Engine Coolant ( Or OBD Coolant Enable Criteria</p> <p>IAT</p> <p>Engine run Accum</p> <p>Engine Speed to initially enable test</p> <p>Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow</p> <p>Vehicle Speed to initially enable test</p> <p>Vehicle Speed range to keep test enabled (after initially enabled)</p> <p>Closed loop integral</p> <p>Closed Loop Active</p>	<p>Green O2S condition is considered valid until the accumulated air flow is greater than</p> <p><b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b></p> <p>for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p> <p>≥ 20 seconds</p> <p>&gt; 62 °C</p> <p>= TRUE )</p> <p>&gt; -40 °C</p> <p>&gt; 30 seconds</p> <p>950 ≤ RPM ≤ 2,950</p> <p>900 ≤ RPM ≤ 3,050</p> <p>2.0 ≤ gps ≤ 15.0</p> <p>40.4 ≤ MPH ≤ 77.7</p> <p>35.4 ≤ MPH ≤ 82.0</p> <p>0.80 ≤ C/L Int ≤ 1.07</p> <p>= TRUE</p> <p>(Please see “<b>Closed Loop Enable Clarification</b>” in Supporting Tables).</p>		



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		threshold before a delay time threshold is reached.			Evap  Ethanol Estimation in Progress  Baro Post fuel cell  EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State  ===== All of the above met for at least 2.0 seconds, and then the Force Cat Rich intrusive stage is requested. ===== Pre O2S EQR B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders  ===== After above conditions are met: DFCO Mode is entered (wo driver initiated pedal input).	not in control of purge  = Not Active (Please see " <b>Ethanol Estimation in Progress</b> " in Supporting Tables).  > 70 kpa = enabled  = not active  = not active  ≥ 80.0 sec 500 ≤ °C ≤ 900 = DFCO possible  =====  =====  ≥ 1.080 EQR = DFCO active  ≤ 3 cylinders  ===== =====		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 1) (For use with WRAF	P015B	<p>DTC P015B detects that the primary WRAF oxygen sensor for Bank 1 has delayed response when the air fuel ratio transitions from lean to rich condition. This diagnostic runs simultaneously with the intrusive secondary O2 monitor lean to rich tests (P013F / P013B), which commands fuel enrichment.</p> <p>Note: The Primary method is used when the primary WRAF O2 sensor signal transitions from lean condition to above the O2 measured EQR threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P015B diagnostic measures the primary WRAF O2 sensor response time between a lean condition and a higher measured EQR threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air temperature resulting in</p>	<p>Primary method: The EWMA of the Pre O2 sensor normalized L2R time delay value. The EWMA repass limit is The EWMA calculation uses a 0.20 coefficient.</p> <p>OR</p> <p>Secondary method: The Accumulated time monitored during the L2R Delayed Response Test.</p> <p>AND</p> <p>Pre WRAF O2 sensor measured EQR is</p> <p>OR</p> <p>At end of Cat Rich stage the Pre WRAF O2 sensor measured EQR is</p>	<p>&gt; 0.50 EWMA (sec) ≤ 0.47 EWMA (sec)</p> <p>≥ 3.8 Seconds</p> <p>&lt; 1.000 EQR</p> <p>&lt; 1.080 EQR</p>	<p>No Active DTC's</p> <p>P015A test is complete and</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p>	<p>TPS_ThrottleAuthorityDefault MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA WRAF_Bank_1_FA P0131, P0132, P013A, P013B, P013E, P013F, P015A, P2270, P2271</p> <p>= Passed</p> <p>&gt; 10.0 Volts = Not active = Not active = Not active = Not active</p> <p>= False</p> <p>= False</p>	<p>Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResponsesActive = TRUE, multiple tests per trip are allowed</p>	<p>Type A, 1 Trips EWMA</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>a normalized delay value. The normalized delay is fed into a 1st order lag filter to update the final EWMA result. DTC P015B is set when the EWMA value exceeds the EWMA threshold.</p> <p>Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p><u>Secondary method:</u> This fault is set if the primary WRAF O2 sensor does not achieve the required higher measured EQR threshold before a delay time threshold is</p>			<p>Green O2S Condition</p> <p>O2 Heater (pre sensor) on for</p> <p>Engine Coolant ( Or OBD Coolant Enable Criteria</p> <p>IAT</p> <p>Engine run Accum</p> <p>Engine Speed to initially enable test</p> <p>Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow</p> <p>Vehicle Speed to initially enable test</p> <p>Vehicle Speed range to keep test enabled (after initially enabled)</p> <p>Closed loop integral</p> <p>Closed Loop Active</p>	<p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than</p> <p><b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b></p> <p>for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p> <p>≥ 20 seconds</p> <p>&gt; 62 °C</p> <p>= TRUE )</p> <p>&gt; -40 °C</p> <p>&gt; 30 seconds</p> <p>950 ≤ RPM ≤ 2,950</p> <p>900 ≤ RPM ≤ 3,050</p> <p>2.0 ≤ gps ≤ 15.0</p> <p>40.4 ≤ MPH ≤ 77.7</p> <p>35.4 ≤ MPH ≤ 82.0</p> <p>0.80 ≤ C/L Int ≤ 1.07</p> <p>= TRUE</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		reached.			<p>Evap</p> <p>Ethanol Estimation in Progress</p> <p>Baro Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on time</p> <p>Predicted Catalyst temp Fuel State Number of fueled cylinders</p> <p>=====</p> <p>When above conditions are met: Fuel Enrich mode is entered.</p> <p>=====</p> <p>During this test: Engine Airflow must stay between: and the delta Engine Airflow over 12.5msec must be :</p>	<p>(Please see “<b>Closed Loop Enable Clarification</b>” in Supporting Tables).</p> <p>not in control of purge</p> <p>= Not Active (Please see “<b>Ethanol Estimation in Progress</b>” in Supporting Tables).</p> <p>&gt; 70 kpa = enabled = not active = not active</p> <p>≥ 80.0 sec</p> <p>500 ≤ °C ≤ 900 = DFCO inhibit</p> <p>≥ 1 cylinders</p> <p>=====</p> <p>=====</p> <p>1 ≤ gps ≤ 20</p> <p>≤ 2.0 gps</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Lean Bank 1	P0171	<p>Determines if the primary fuel control system for Bank 1 is in a lean condition, based on the filtered long-term and short-term fuel trim. A normally operating system operates centered around long-term fuel trim metric of 1.0. For lean conditions extra fuel trim is required therefor values &gt; 1.0 indicate a Lean condition.</p> <p>A fault is determined, when the long term fuel metric exceeds the threshold value. In addition to the long-term fuel trim limit, the short-term fuel trim metric can be monitored and the fault sets once both threshold values are exceeded. The short-term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority.</p>	<p>The filtered long-term fuel trim metric</p> <p>AND</p> <p>The filtered short-term fuel trim metric (Note: any value below 0.95 effectively nullifies the short-term fuel trim criteria)</p>	<p>&gt;= 1.320</p> <p>&gt;= 0.100</p> <p>If a fault has been detected the long-term fuel trim metric must be &lt; 1.270 and the short-term fuel trim metric must be &lt; 2.000 to repass the diagnostic.</p>	<p>Engine speed BARO Coolant Temp</p> <p>Coolant Temp MAP Inlet Air Temp MAF Fuel Level</p> <p>Long Term Fuel Trim data accumulation:</p> <p>Sometimes, certain Long-Term Fuel Trim Cells are not utilized for control and/or diagnosis</p> <p>Closed Loop Long Term FT</p>	<p>400 &lt;rpm&lt; 6,500 &gt; 70 kPa &gt; -20 °C (or OBD Coolant Enable Criteria = TRUE) &lt; 150 °C 10 &lt;kPa&lt; 256 -20 &lt;°C&lt; 150 1 &lt;g/s&lt; 1,000 &gt; 10 % or if fuel sender is faulty the diagnostic will bypass the fuel level criteria.</p> <p>&gt; 55.0 seconds of data must accumulate on each trip, with at least 45.0 seconds of data in the current fuel trim cell before a pass or fail decision can be made.</p> <p>(Please see <b>P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage</b> in Supporting Tables for a list of cells utilized for diagnosis)</p> <p>Enabled Enabled (Please see "<b>Closed Loop Enable Clarification</b>" and "<b>Long Term FT Enable Criteria</b>" in Supporting Tables.)</p>	Frequency: 100 ms Continuous Loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					EGR Diag. Catalyst Diag. Post O2 Diag. Device Control EVAP Diag.  No active DTC:	Intrusive Test Not Active Intrusive Test Not Active Intrusive Test Not Active Not Active Large Leak Diagnostic (P0455) Not Active  IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR System FA EvapExcessPurgePsbl_F A Ethanol Composition Sensor FA FuelInjectorCircuit_FA EngineMisfireDetected_F A EGRValvePerformance_F A EGRValveCircuit_FA MAP_EngineVacuumStat us AmbPresDfltStatus TC_BoostPresSnsrFA O2S_Bank_1_Sensor_1_ FA		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 1	P0172	Determines if the fuel control system is in a rich condition, based on the filtered long-term fuel trim metric. A normally operating system operates centered around long-term fuel trim metric of 1.0. For rich conditions less fuel trim is required therefor values < 1.0 indicate a rich condition.	<b>Passive Test:</b> The filtered Non-Purge Long Term Fuel Trim metric  AND  The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)	<= 0.700   <= 2.000		Secondary Parameters and Enable Conditions are identical to those for P0171, with the exception that fuel level is not considered.	Frequency: 100 ms Continuous Loop	Type B, 2 Trips
		<p>There are two methods to determine a Rich fault. They are Passive and Intrusive.</p> <p>A Passive Test decision can be made up until the time that purge is first enabled. From that point forward, rich faults can only be detected by turning purge off intrusively. If during this period of time the filtered long-term fuel trim metric exceeds the threshold a fault will be set. In addition to the long-term fuel trim limit, the short-term fuel trim metric can be monitored and the fault sets once both threshold values are exceeded. The short-</p>	<p>*****</p> <b>Intrusive Test:</b> For 3 out of 5 intrusive segments  The filtered Purge Long Term Fuel Trim metric  AND  The filtered Non-Purge Long Term Fuel Trim metric  AND  The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)	   <= 0.705  <= 0.700  <= 2.000  If a fault has been detected (by the passive or intrusive test) the long-term fuel trim metric must be > 0.750 and the short-	   Purge Vapor Fuel	   <= 100.00 %  Intrusive Test is inhibited when Purge Vapor percentage is greater than this threshold. (Note: values greater than 50% indicate the Purge Vapor Fuel requirement is not being used)  A minimum number of accumulated Fuel Trim Data samples are required to adequately learn a correct Purge Vapor Fuel value. See the table <b>Minimum Non-Purge Samples for Purge (Vapor Fuel )</b> for the Purge Off cells used to validate the Purge Vapor Fuel parameter.	   <b>Segment Definition:</b> Segments can last up to 42 seconds and are separated by the lesser of 10.0 seconds of purge-on time or enough time to purge 10 grams of vapor. A maximum of 5 completed segments or 15 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 300 seconds to allow sufficient	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority.</p> <p>Once purge is enabled if the filtered Purge Long Term Fuel Trim metric &gt; 0.705, the test passes without intrusively checking the filtered Non-Purge Long Term Fuel Trim metric. However if the filtered Purge Long Term Fuel Trim metric is &lt;= 0.705, the Intrusive test is invoked. The purge is ramped off to determine if excess purge vapor is the cause of the rich condition. If during 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric &lt;= 0.700 the fault will set.</p> <p>Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions, and the execution frequency of other diagnostics. This is why the intrusive test is operated over several</p>		<p>term fuel trim metric must be &gt; 0.000 to repass the diagnostic. The intrusive test will be enabled at long-term fuel metric values &lt; 0.76 until the diagnostic repasses after a failure.</p>		<p>If the accumulated purge volume is &gt; 0.0 grams, the intrusive test will not be inhibited even if Purge Vapor Fuel is &gt; 100.0 %.</p>	<p>time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge Long Term Fuel Trim metric &gt; 0.705 for at least 120.0 seconds, indicating that the canister has been purged.</p>	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		segments allowing Purge to renable between segments. Likewise, for these reasons, if after the 5 intrusive segments the diagnostic continues to pass, there is a delay period of 300 seconds to allow sufficient time to purge excess vapors from the canister, before re-evaluating a Rich condition if it still exists.						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit Range/ Performance	P018B	<p>This DTC detects a fuel pressure sensor response stuck within the normal operating range using an intrusive test ( as follows)</p> <p>a] Intrusive Test Trigger: 1] Fuel Pump Duty Cycle Clamped Time ( min or max duty cycle) &gt;= 5 sec</p> <p>Or 2] Fuel Pres Err Variance &lt;= calibration value KeFDBR_cmp_FPSS_MinPres</p> <p>Variance ; Otherwise, Report status as Pass</p> <p>b] Intrusive test freq limit: 60 sec between intrusive tests that pass,</p> <p>c] Intrusive test Fuel Flow limit: Fuel Flow Actual &lt; Max allowed Fuel Flow rate</p>	Sensed fuel pressure change [absolute value, during intrusive test]	<= 30 kPa	<p>a) Diagnostic enabled [FDBR_b_FPSS_DiagEnbId]</p> <p>b) Timer Engine Running [FDBR_t_EngModeRunCoarse]</p> <p>c1) Fuel Flow Rate Valid</p> <p>c2) Fuel Pressure Sensor Fault Status [DTC P018C or P018D]</p> <p>c3) Reference Voltage Fault Status [DTC P0641]</p> <p>c4) Fuel Pump Control Circuit Fault Status [P1029, P102A, P102B, or P102C]</p> <p>c5) Fuel Control Enable Fault Active [DTC P12A6]</p> <p>c6) Fuel Pump Driver Module OverTemp Fault Active [DTC P1255]</p> <p>c7) Fuel Pump Speed Fault Active [DTC P129F]</p> <p>c8) CAN Sensor Bus message \$0C3 Comm Fault [CFMR_b_FTZM_Info1_UcodeCmFA DTC P165C]</p> <p>c9) CAN Sensor Bus Fuel Pmp Spd Command ARC and Checksum Comm Fault Code [CFMR_b_FTZM_Cmd1_</p>	<p>a) == TRUE</p> <p>b) &gt;= 5.00 seconds</p> <p>c1) == TRUE</p> <p>c2) &lt;&gt; TRUE</p> <p>c3) &lt;&gt; TRUE</p> <p>c4) &lt;&gt; TRUE</p> <p>c5) &lt;&gt; TRUE</p> <p>c6) &lt;&gt; TRUE</p> <p>c7) &lt;&gt; TRUE</p> <p>c8) &lt;&gt; TRUE</p> <p>c9) &lt;&gt; TRUE</p>	<p>1 sample / 12.5 millisc</p> <p>Intrusive Test Duration: Fuel Flow - related ( 5 to 12 sec)</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					UcodeCmFA DTC]  c10) Fuel Pump Duty Cycle Fault Active  c11) Sensor Configuration [FDBR_e_FuelPresSnsrC onfig]  c12) Sensor Bus Relay On  d) Emissions Fuel Level Low [Message \$3FB]  e) Fuel Control Enable  f) Fuel Pump Control State    g) Instantaneous Fuel Flow [FCBR_dm_InstFuelFlow]  h) Diagnostic System Disabled [DRER_b_DiagSysDsb]  j1) Fuel Pmp Speed Command Alive Rolling Count and Checksum Error [CAN Bus B \$0CE] [CFMR_b_FTZM_Cmd1_ ARC_ChkErr DTC]  j2) CAN Sensor Bus message \$0C3_Available  j3) Fuel Pres Sensor Ref Voltage Status Message	c10) <> TRUE   c11) == CeFDBR_e_WiredTo_FT ZM  c12) == TRUE   d) <> TRUE   e) == TRUE  f) == Normal Control OR == Fuel Pres Sensor Stuck Control  g) >= 0.05 gm/sec   h) <> TRUE   j1) <> TRUE   j2) == TRUE  j3) <> TRUE		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B \$0C3] [CFMR_b_FTZM_Info1_A RC_ChkErr DTC]			

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit Low	P018C	<p>This DTC detects if the fuel pressure sensor circuit is shorted low</p> <p>Values are analyzed as percent of sensor reference voltage <math>[(Abs [5.0V - SensorVoltsActual] / 5.0V) * 100\%]</math></p>	<p>Fuel Pressure Sensor output %</p> <p>[re. full range as percent of 5.0V reference]</p>	< 4.00 % or [0 kPa gauge]	<p>a) Diagnostic enabled [FDBR_b_FPSnsrCktLoDiagEnbl]</p> <p>b) Run_Crank Active [PMDR_b_RunCrankActive]</p> <p>c) Diagnostic System Disabled [DRER_b_DiagSysDsbl]</p> <p>d) Pressure Sensor Configuration [FDBR_e_FuelPresSnsrConfig]</p>	<p>a) == TRUE</p> <p>b) == TRUE</p> <p>c) &lt;&gt; TRUE</p> <p>d1) IF calibration CeFDBR_e_WiredTo_FT ZM == WiredTo ECM d2) IF NOT, then see Case2</p>	<p>64.00 failures / 80.00 samples</p> <p>1 sample/12.5 ms</p>	Type B, 2 Trips
			<p>Fuel Pressure Sensor output %</p> <p>[re. full range as percent of 5.0V reference]</p>	< 4.00 % or [0 kPa gauge]	<p>a) Diagnostic enabled [FDBR_b_FPSnsrCktLoDiagEnbl]</p> <p>b) Run_Crank Active [PMDR_b_RunCrankActive]</p> <p>c) Diagnostic System Disabled [DRER_b_DiagSysDsbl]</p> <p>d1) Pressure Sensor Configuration [FDBR_e_FuelPresSnsrConfig]</p> <p>d2) Sensor Bus Relay On</p> <p>d3) CAN Sensor Bus message \$0C3_Available</p> <p>d4) Fuel Pres Sensor Ref</p>	<p>a) == TRUE</p> <p>b) == TRUE</p> <p>c) &lt;&gt; TRUE</p> <p>d1) IF calibration CeFDBR_e_WiredTo_FT ZM == WiredTo FTZM d2) == TRUE d3) == TRUE d4) &lt;&gt; TRUE</p>	<p>64.00 failures / 80.00 samples</p> <p>1 sample/12.5 ms</p>	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B \$0C3] [CFMR_b_FTZM_Info1_A RC_ChkErr DTC]	d2) IF calibration CeFDBR_e_WiredTo_FT ZM <> WiredTo FTZM, then see Case1		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit High	P018D	<p>This DTC detects if the fuel pressure sensor circuit is shorted High</p> <p>Values are analyzed as percent of sensor reference voltage <math>[(Abs [5.0V - SensorVoltsActual] / 5.0V) * 100\%]</math></p>	<p>Fuel Pressure Sensor output %</p> <p>[re. full range as percent of 5.0V reference]</p>	> 96.00 % or [743 kPa ga]	<p>a) Diagnostic enabled [FDBR_b_FPSnsrCktLoDiagEnbl]</p> <p>b) Run_Crank Active [PMDR_b_RunCrankActive]</p> <p>c) Diagnostic System Disabled [DRER_b_DiagSysDsbl]</p> <p>d) Pressure Sensor Configuration [FDBR_e_FuelPresSnsrConfig]</p>	<p>a) == TRUE</p> <p>b) == TRUE</p> <p>c) &lt;&gt; TRUE</p> <p>d1) IF calibration CeFDBR_e_WiredTo_FT ZM == WiredTo ECM d2) IF NOT, then see Case2</p>	<p>64.00 failures / 80.00 samples</p> <p>1 sample/12.5 ms</p>	Type B, 2 Trips
			<p>Fuel Pressure Sensor output %</p> <p>[re. full range as percent of 5.0V reference]</p>	> 96.00 % or [743 kPa ga]	<p>a) Diagnostic enabled [FDBR_b_FPSnsrCktLoDiagEnbl]</p> <p>b) Run_Crank Active [PMDR_b_RunCrankActive]</p> <p>c) Diagnostic System Disabled [DRER_b_DiagSysDsbl]</p> <p>d1) Pressure Sensor Configuration [FDBR_e_FuelPresSnsrConfig]</p> <p>d2) Sensor Bus Relay On</p> <p>d3) CAN Sensor Bus message \$0C3_Available</p> <p>d4) Fuel Pres Sensor Ref</p>	<p>a) == TRUE</p> <p>b) == TRUE</p> <p>c) &lt;&gt; TRUE</p> <p>d1) IF calibration CeFDBR_e_WiredTo_FT ZM == WiredTo FTZM d2) == TRUE d3) == TRUE d4) &lt;&gt; TRUE</p>	<p>64.00 failures / 80.00 samples</p> <p>1 sample/12.5 ms</p>	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B \$0C3] [CFMR_b_FTZM_Info1_A RC_ChkErr DTC]	d2) IF calibration CeFDBR_e_WiredTo_FT ZM <> WiredTo FTZM, then see Case1		



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT SIDI High Pressure Sensor Performance	P0191	The DTC determines if there is a skewed control fuel rail sensor (Sensor1) via a comparison to diagnostic sensor (sensor2) continuously when the engine is running and the commanded pressure is steady.	<p>Primary sensor (P1) vs. Secondary sensor (P2) performance rationality</p> <p>((Low Limit fail Filtered Fuel Control Error )</p> <p>OR</p> <p>(High Limit Fail: Filtered Fuel Control Error))</p> <p>AND</p> <p>(Filtered Absolute delta between sensor1 and sensor2</p>	<p>&lt;=</p> <p><b>P0191 - Low fail limit of fuel control due to pressure sensor skewed low</b> (See supporting table)</p> <p>&gt;=</p> <p><b>P0191 - High fail limit of fuel control due to high pressure sensor skewed High</b> (see Supporting table)</p> <p>&gt;= 1.00 mpa</p> <p>Note: fuel control error is calculated based on the square root of sensor1 divided by sensor2, this value is filter to ensure proper failure detection.</p> <p>Absolute delta between sensor1 and sensor2 value is filter to ensure proper failure detection.</p>	<p>Commanded Pressure rate of change (increasing or decreasing)</p> <p>for a period of time</p>	<p>&lt; 3.00 mpa</p> <p>&gt;= 1.25 seconds</p> <p>Enabled when a code clear is not active or not exiting device control</p>	<p>Filter Fuel Control Error term and Absolute delta between sensor1 and sensor2 exceed Low or High Fail limit for a duration &gt;= 1.50 seconds</p> <p>This is diagnostic runs Continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure Sensor 1 Out of Range	P0192	<p>This DTC diagnose SENT high pressure sensor 1 that is too low out of range.</p> <p>If the sensor digital value (representing the reference voltage) is below the lower digital threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported. A pass is reported for this DTC if the low sample counter reaches its threshold.</p>	High Pressure Rail Sensor 1 SENT digital read value	=< 66			<p>Time Based: 400 Failuer out of 500 Samples 6.25 ms per Sample Continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit - (SID1)	P0201	<p>Controller specific output driver circuit diagnoses Injector 1 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 1 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p><math>\geq 200</math> KOhms impedance between signal and controller ground</p> <p><math>\geq 200</math> KOhms impedance between signal and controller ground</p>	<p>Battery Voltage Engine Run Time</p>	<p><math>\geq 11</math> Volts <math>\geq 5</math> Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit - (SID1)	P0202	<p>Controller specific output driver circuit diagnoses Injector 2 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 2 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p><math>\geq 200</math> KOhms impedance between signal and controller ground</p> <p><math>\geq 200</math> KOhms impedance between signal and controller ground</p>	<p>Battery Voltage</p> <p>Engine Run Time</p>	<p><math>\geq 11</math> Volts</p> <p><math>\geq 5</math> Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Open Circuit - (SID1)	P0203	<p>Controller specific output driver circuit diagnoses Injector 3 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 3 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>&gt;= 200 KOhms impedance between signal and controller ground</p> <p>&gt;= 200 KOhms impedance between signal and controller ground</p>	<p>Battery Voltage</p> <p>Engine Run Time</p>	<p>&gt;= 11 Volts</p> <p>&gt;= 5 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit - (SID1)	P0204	<p>Controller specific output driver circuit diagnoses Injector 4 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 4 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>&gt;= 200 KOhms impedance between signal and controller ground</p> <p>&gt;= 200 KOhms impedance between signal and controller ground</p>	<p>Battery Voltage</p> <p>Engine Run Time</p>	<p>&gt;= 11 Volts</p> <p>&gt;= 5 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short low or open in TPS2 circuit by monitoring the TPS 2 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too low. This diagnostic only runs when battery voltage is high enough.	TPS2 % Vref <	0.250 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P06A3	79 / 159 counts;  57 counts continuous;  3.125 ms /count in the ECM main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit High	P0223	Detects a continuous or intermittent short high in TPS2 circuit by monitoring the TPS 2 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too high. This diagnostic only runs when battery voltage is high enough.	TPS2 % Vref >	4.590 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P06A3	79 / 159 counts;  57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Engine Overboost Turbocharge r with wastegate. Not supercharge r with mechanical compressor	P0234	This DTC indicates an over boost failure. Two failure paths are considered. When pressure control closed loop control being active, a negative boost pressure deviation indicates overboost conditions at constant driving conditions. In case boost pressure close loop control not being active and with desired boost pressure below basic boost pressure, overboost conditions can be detected when actual boost pressure is higher than basic boost pressure plus a diagnostic offset.	Desired boost pressure - Actual boost pressure	< refer to <b>P0234: Overboost pressure deviation limit as a function of engine speed and desired boost pressure</b> - <b>P0234 P0299: Ambient pressure correction as a function of engine speed and ambient pressure</b> in Supporting tables.	Dev. diagnostic enable ***** Coolant temperature or OBD Coolant enable criteria and Coolant temperature  Intake air temperature is in range  Ambient air pressure is in range  Engine speed in range  Desired boost pressure in range  Desired boost pressure derivative in range ***** All conditions have to be fulfilled for:  ***** No active DTCs:  ***** Pressure control has to be in closed loop.	True ***** > -40.0 °C  = TRUE  < 130.0 °C  > -40.0 °C < 80.0 °C  > 60.0 kPa < 120.0 kPa  > 1,600 rpm < 6,000 rpm  > 140.0 kPa < 300.0 kPa  > -75.0 kPa/s < 75.0 kPa/s ***** > refer to <b>P0234 P0299: Boost deviation diagnostic enable delay as a function of engine speed</b> in Supporting tables. ***** BSTR_b_PCA_CktFA BSTR_b_TurboBypassCktFA ECT_Sensor_FA IAT_SensorFA BSTR_b_BoostSnsrFA AmbientAirDefault *****	15 failures out of 15 samples  100ms / sample	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No device control active for WG and compressor recirculation valve.			
			Actual boost pressure	> refer to <b>P0234: Overboost pressure limit below basic pressure as a function of engine speed and ambient pressure</b> in Supporting tables.  +Basic Pressure	Basic pressure diag enable and Dev. diagnostic enable ***** Coolant temperature or OBD Coolant enable criteria and Coolant temperature  Intake air temperature is in range  Ambient air pressure is in range  Engine speed in range  All conditions have to be fulfilled for: ***** No active DTCs:  ***** Pressure control has to be in open loop.	False  True ***** > -40.0 °C  = TRUE  < 130.0 °C  > -40.0 °C < 80.0 °C  > 60.0 kPa < 120.0 kPa  > 2,000 rpm < 3,500 rpm  > 2.00 Seconds ***** BSTR_b_PCA_CktFA BSTR_b_TurboBypassCktFA ECT_Sensor_FA IAT_SensorFA BSTR_b_BoostSnsrFA AmbientAirDefault BSTR_b_PCA_TFTKO *****	40 failures out of 50 samples  100ms / sample	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No device control active for WG and compressor recirculation valve.			

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Boost Pressure (TIAP) Sensor Performance (single turbo)	P0236	<p>Detects a performance failure in the Turbocharger Boost Pressure sensor, such as when a Turbocharger Boost Pressure value is stuck in range.</p> <p>If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The Turbocharger Boost Pressure sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the Turbocharger Boost Pressure performance diagnostic will fail.</p> <p>If the Turbocharger Boost Pressure sensor value is within the normal expected atmospheric range, then Manifold Pressure (MAP), Turbocharger Boost Pressure and Barometric Pressure (BARO) are compared to see if their values are similar. If the MAP and BARO sensor values are similar, but the Turbocharger Boost Pressure value is not</p>	<p><b><u>Engine Running:</u></b></p> <p>See table <b>P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix</b> for combinations of model failures that can set this DTC.</p> <p>MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered</p> <p>MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered</p> <p>MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered</p> <p>MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered</p> <p>TIAP1 model fails when ABS(Measured TIAP - TIAP Model 1) Filtered</p> <p>TPS model fails when Filtered Throttle Model Error</p> <p>TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP -</p>	<p>&gt; 20.0 grams/sec</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 300 kPa*(g/s)</p>	<p>Engine Speed Engine Speed</p> <p>(Coolant Temp OR OBD Coolant Enable Criteria</p> <p>(Coolant Temp OR OBD Max Coolant Achieved</p> <p>Intake Air Temp Intake Air Temp</p> <p>Minimum total weight factor (all factors multiplied together)</p> <p>See Residual Weight Factor tables.</p>	<p>&gt;= 400 RPM &lt;= 6,000 RPM</p> <p>&gt;= -9 Deg C</p> <p>= TRUE)</p> <p>&lt;= 130 Deg C</p> <p>= FALSE)</p> <p>&gt;= -20 Deg C &lt;= 125 Deg C</p> <p>&gt;= 0.50</p> <p>Modeled Air Flow Error multiplied by <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM</b> and <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est</b></p> <p>MAP Model 1 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM</b></p> <p>MAP Model 2 Error</p>	<p>Continuous</p> <p>Calculation are performed every 12.5 msec</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>similar, then a Turbocharger Boost Pressure performance diagnostic will fail.</p> <p>The engine running portion of this diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Mass Air Flow (MAF) sensor, Manifold Pressure (MAP) sensor and Throttle Position sensor (TPS).</p> <p>These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the Turbocharger Boost Pressure sensor. In this case, the Turbocharger Boost Pressure Performance</p>	<p>measured MAP - offset as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset</b></p> <p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset</b></p> <p>TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p>	<p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 1.0 seconds</p> <p>&gt; 1.0 seconds</p> <p>&gt; a threshold in gm/sec as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow</b></p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM</b></p> <p>MAP Model 3 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM</b></p> <p>TIAP Model 1 Error multiplied by <b>P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM</b></p> <p>Filtered Throttle Model Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM</b></p> <p>MAP_SensorCircuitFA EGRValvePerformance_FA A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP MnfdTempSensorCktFP</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		diagnostic will fail.	<p>AND Manifold Pressure</p> <p>&gt; a threshold in kPa as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP- MAP Correlation Min MAP</b></p> <p>AND Filtered Mass Air Flow - Mass Air Flow</p> <p>&lt; 3.0 gm/sec</p> <p>Low Engine Air Flow is TRUE when Mass Air Flow</p> <p>&lt; a threshold in gm/ sec as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP- Baro Correlation Max Air Flow</b></p> <p>AND Manifold Pressure</p> <p>&lt; a threshold in kPa as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP- Baro Correlation Max MAP</b></p> <p>AND Mass Air Flow - Filtered Mass Air Flow</p> <p>&lt; 2.0 gm/sec</p>					
			<p><b><u>Engine Not Rotating:</u></b></p> <p>Turbocharger Boost Pressure OR Turbocharger Boost</p>	<p>&lt; 50.0 kPa</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is not rotating</p>	<p>&gt; 10.0 seconds</p>	<p>4 failures out of 5 samples</p> <p>1 sample every 12.5 msec</p>	

## 20 OBDG03A ECM Summary Tables

[illegible]

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Boost Pressure Sensor Circuit Low (Gen III)	P0237	Detects a continuous short to ground in the Turbocharger Boost Pressure signal circuit by monitoring the Turbocharger Boost Pressure sensor output voltage and failing the diagnostic when the Turbocharger Boost Pressure voltage is too low. The Turbocharger Boost Pressure sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	Turbocharger Boost Pressure Voltage	< 19.4 % of 5 Volt Range (This is equal to 49.9 kPa)			320 failures out of 400 samples  1 sample every 12.5 msec	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Boost Pressure Sensor Circuit High (Gen III)	P0238	Detects a continuous short to power or open circuit in the Turbocharger Boost Pressure signal circuit by monitoring the Turbocharger Boost Pressure sensor output voltage and failing the diagnostic when the Turbocharger Boost Pressure voltage is too high. The Turbocharger Boost Pressure sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	Turbocharger Boost Pressure Voltage	> 78.0 % of 5 Volt Range (This is equal to 299.0 kPa)			320 failures out of 400 samples  1 sample every 12.5 msec	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Wastegate / Supercharger Boost Solenoid A Control Circuit	P0243	<p>Controller specific output driver circuit diagnostic, diagnosing the 'turbocharger boost solenoid'A' actuator' low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>In series applications, turbocharger 'A' is the first turbocharger in the direction of exhaust flow. In a parallel application, turbocharger 'A' is associated with engine bank 1.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>≥ 200 K Ω impedance between output and controller ground</p>	<p>Diagnostic enabled *****</p> <p>Powertrain relay voltage</p> <p>Ignition run crank voltage *****</p> <p>Engine does not crank</p> <p>Diagnostic system not disabled</p>	<p>True *****</p> <p>≥ 11.0 Volts</p> <p>&gt; 5.00 Volts *****</p>	<p>10 failures out of 20 samples</p> <p>100ms / sample</p>	<p>Type A, 1 Trips</p> <p>Note: In certain controllers P0245 may also set turbocharger wastegate / supercharger boost solenoid A control circuit low</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Wastegate / Supercharger Boost Solenoid A Control Circuit Low	P0245	<p>Controller specific output driver circuit diagnostic, diagnosing the 'turbocharger boost solenoid 'A' actuator' low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>In series applications, turbocharger 'A' is the first turbocharger in the direction of exhaust flow. In a parallel application, turbocharger 'A' is associated with engine bank 1.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p> <p>In certain controllers this diagnosis runs only when the HWIO-output is driven by the application S/W.</p>	<p>≤ 0.5 Ω impedance between output and controller ground</p>	<p>Diagnostic enabled *****</p> <p>Powertrain relay voltage</p> <p>Ignition run crank voltage *****</p> <p>Engine does not crank</p> <p>Diagnostic system not disabled</p>	<p>True *****</p> <p>≥ 11.0 Volts</p> <p>&gt; 5.00 Volts *****</p>	<p>10 failures out of 20 samples</p> <p>100ms / sample</p>	<p>Type A, 1 Trips</p> <p>Note: In certain controllers P0243 may also set turbocharger wastegate / supercharger boost solenoid A control circuit</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbocharger Wastegate / Supercharger Boost Solenoid A Control Circuit High	P0246	<p>Controller specific output driver circuit diagnostic, diagnosing the 'turbocharger boost solenoid 'A' actuator' low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>In series applications, turbocharger 'A' is the first turbocharger in the direction of exhaust flow. In a parallel application, turbocharger 'A' is associated with engine bank 1.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p> <p>In certain controllers this diagnosis runs only when the HWIO-output is driven by the application S/W.</p>	<p>≤ 0.5 Ω impedance between output and controller power</p>	<p>Diagnostic enabled *****</p> <p>Powertrain relay voltage</p> <p>Ignition run crank voltage *****</p> <p>Engine does not crank</p> <p>Diagnostic system not disabled</p>	<p>True *****</p> <p>≥ 11.0 Volts</p> <p>&gt; 5.00 Volts *****</p>	<p>10 failures out of 20 samples</p> <p>100ms / sample</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground (SIDI)	P0261	Controller specific output driver circuit diagnoses Injector 1 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	<p>&gt;= 11 Volts &gt;= 5 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to power (SIDI)	P0262	Controller specific output driver circuit diagnoses Injector 1 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground (SIDI)	P0264	Controller specific output driver circuit diagnoses Injector 2 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	<p>&gt;= 11 Volts &gt;= 5 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power (SIDI)	P0265	Controller specific output driver circuit diagnoses Injector 2 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to ground (SIDI)	P0267	Controller specific output driver circuit diagnoses Injector 3 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	<p>&gt;= 11 Volts &gt;= 5 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to power (SIDI)	P0268	Controller specific output driver circuit diagnoses Injector 3 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground (SIDI)	P0270	Controller specific output driver circuit diagnoses Injector 4 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to power (SIDI)	P0271	Controller specific output driver circuit diagnoses Injector 4 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Engine Underboost Turbocharge r with wastegate. Not supercharge r with mechanical compressor	P0299	This DTC indicates an under boost failure. Two failure paths are considered. At steady state engine operating conditions with boost pressure closed loop control being active, a positive boost pressure deviation indicates underboost conditions. During transient conditions, in case the boost pressure increase gradient is below a diagnostic threshold, underboost conditions will be detected.	Desired boost pressure - Actual boost pressure	<refr to <b>P0299: Underboost pressure deviation limit as a function of engine speed and desired boost pressure</b> + <b>P0234 P0299: Ambient pressure correction as a function of engine speed and ambient pressure</b> in Supporting tables.	Dev. Diagnostic enable ***** Coolant temperature or OBD Coolant Enable Criteria and Coolant temperature  Intake air temperature is in range  Ambient air pressure is in range  Engine speed in range  Desired boost pressure in range  Desired boost pressure derivative in range ***** All conditions haveto be fullfilled for:  ***** No active DTCs:  ***** Pressure control has to be in closed loop.	True ***** > -40.0 °C  = TRUE)  < 130.0 °C  > -40.0 °C < 80.0 °C  > 60.0 kPa < 120.0 kPa  > 1,600 rpm < 6,000 rpm  > 140.0 kPa < 300.0 kPa  > -75.0 kPa/s < 75.0 kPa/s ***** >refer to <b>P0234 P0299: Boost deviation diagnostic enable delay as a function of engine speed</b> in Supporting tables. ***** BSTR_b_PCA_CktFA BSTR_b_TurboBypassCkt FA ECT_Sensor_FA IAT_SensorFA BSTR_b_BoostSnsrFA AmbientAirDefault *****	15 failures out of 15 samples  100ms / sample	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No device control active for WG and compressor recirculation valve.			
			Actual boost pressure delta  the delta is limited by these tables: refer to Max: <b>P0299: Underboost high rate limit as a function of engine speed</b> Min: <b>P0299: Underboost low rate limit as a function of engine speed</b> in supporting tables.	< 10.00	Rate base diagnostic enable and Dev. Diagnostic enable ***** Coolant temperature or OBD Coolant enable criteria and Coolant temperature  Intake air temperature is in range  Ambient air pressure is in range  Desired boost pressure in range  Desired boost pressure derivative in hysteresis range  Engine speed is in range ***** All conditions have to be fulfilled for: ***** No active DTCs:	False  True ***** > -40.0 °C  = TRUE) < 130.0 °C  > -40.0 °C < 80.0 °C  > 60.0 kPa < 120.0 kPa  > 140.0 kPa < 300.0 kPa  Enable Limit: 20.0 Disable Limit: -20.0  > 2,000 rpm < 3,500 rpm ***** > 0.20 Seconds ***** BSTR_b_PCA_CktFA BSTR_b_TurboBypassCktFA ECT_Sensor_FA IAT_SensorFA BSTR_b_BoostSnrFA	40 failures out of 50 samples  100ms / sample	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>Pressure control has to be in closed loop.</p> <p>No device control active for WG and compresseor recirculation valve.</p>	<p>AmbientAirDefault</p> <p>*****</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Random Misfire Detected	P0300	These DTC's will determine if a random or a cylinder specific misfire is occurring by monitoring various terms derived from crankshaft velocity. The rate of misfire over an interval is compared to both emissions and catalyst damaging thresholds. The pattern of crankshaft acceleration after the misfire is checked to differentiate between real misfire and other sources of crank shaft noise.  Emissions Neutral Default Action: If consumed Emissions Neutral Default DTCs from other subsystems are set: Ignore Rough Road, Traction, Stability, and Antilock brake signals. If default action not activated, Misfire Monitor could complete less frequently or inaccurately. Default Action Latched for duration of Trip  Default Action: If Misfire P030x sets on some hybrid applications, the isolation damper	Crankshaft Deceleration Value(s) vs. Engine Speed and Engine load		Engine Run Time	> 2 crankshaft revolution	Emission Exceedence = any ( 5 ) failed 200 rev blocks out of ( 16 ) 200 rev block tests  Failure reported for ( 1 ) Exceedence in 1st ( 16 ) 200 rev block tests, or ( 4 ) Exceedences thereafter.	Type B, 2 Trips (Mil Flashes with Catalyst damage level of Misfire)
Cylinder 1 Misfire Detected	P0301		The equation used to calculate deceleration value is tailored to specific vehicle operating conditions. The selection of the equation used is based on the 1st single cylinder continuous misfire threshold tables encountered that are not max of range. If all tables are max of range at a given speed/load, that speed load region is an <b>Undetectable region</b> see Algorithm Description Document for additional details.		Engine Coolant Temp	"ECT" If OBD Max Coolant Achieved = FALSE -12 °C < ECT Or if OBD Max Coolant Achieved = TRUE -12 °C < ECT < 130 °C		
Cylinder 2 Misfire Detected	P0302				Or If ECT at startup Then	< -12 °C If OBD Max Coolant Achieved = FALSE 21 °C < ECT		
Cylinder 3 Misfire Detected	P0303					If OBD Max Coolant Achieved = TRUE 21 °C < ECT < 130 °C		
Cylinder 4 Misfire Detected	P0304							
				- see details of thresholds on Supporting Tables Tab	System Voltage + Throttle delta - Throttle delta	9.00 < volts < 32.00 < 95.00 % per 25 ms < 95.00 % per 25 ms		
			SINGLE CYLINDER CONTINUOUS MISFIRE( (Medres_Decel Medres_Jerk	> <b>RufSCD_Decel</b> AND > <b>RufSCD_Jerk</b> )	Early Termination option: (used on plug ins that may not have enough engine run time at end of trip for normal interval to complete.)	Not Enabled	OR when Early Termination Reporting = Enabled and engine rev > 1,000 revs and < 3,200 revs at end of trip	
			OR (Medres_Decel Medres_Jerk	> <b>SCD_Decel</b> AND > <b>SCD_Jerk</b> )				
			OR (Lores_Decel Lores_Jerk	> <b>RufCyl_Decel</b> AND > <b>RufCyl_Jerk</b> )				
			OR (Lores_Decel Lores_Jerk	> <b>CylModeDecel</b> AND > <b>CylModeJerk</b> )				
			OR RevBalanceTime	> <b>RevMode_Decel</b>				



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		between engine and transmission can go into extreme resonance. Default action is to move rpm out of the resonance zone. If default action not activated, significant hardware damage could occur rendering vehicle inoperable.	<p>*****</p> <p><b>**This Feature not used on Gasoline engines**</b></p> <p>Combustion Modes that force selection of Idle Tables</p> <p>*****</p> <p>Other patterns of misfire use adjustments to the single cylinder continuous misfire threshold tables:</p> <p>RANDOM MISFIRE Use random misfire thresholds If no misfire for</p> <p>(Medres_Decel</p> <p>AND</p> <p>Medres_Jerk)</p> <p>OR (Medres_Decel</p> <p>AND</p> <p>Medres_Jerk)</p> <p>OR (Lores_Decel</p> <p>AND</p> <p>Lores_Jerk)</p>	<p>*****</p> <p><b>**This Feature not used on Gasoline engines**</b></p> <p><b>CombustModelIdleTbl</b> in Supporting Tables</p> <p>*****</p> <p>&gt; 6 Engine Cycles</p> <p>&gt; <b>RufSCD_Decel * Random_SCD_Decel</b></p> <p>&gt;<b>RufSCD_Jerk * Random_SCD_Jerk</b></p> <p>&gt; <b>SCD_Decel * Random_SCD_Decel</b></p> <p>&gt; <b>SCD_Jerk * Random_SCD_Jerk</b></p> <p>&gt; <b>RufCyl_Decel * RandomCylModDecel</b></p> <p>&gt; <b>RufCyl_Jerk * RandomCylModJerk</b></p>			<p>any Catalyst Exceedence = ( 1 ) 200 rev block as data supports for catalyst damage.</p> <p>Catalyst Failure reported with (1 or 3) Exceedences in FTP, or (1) Exceedence outside FTP.</p> <p>Continuous</p>	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR (Lores_Decel AND Lores_Jerk)  OR RevBalanceTime  PAIRED CYLINDER MISFIRE If a cylinder & it's pair are above PAIR thresholds (Medres_Decel AND Medres_Jerk)  OR (Medres_Decel AND Medres_Jerk)  OR (Lores_Decel AND Lores_Jerk)  OR (Lores_Decel AND Lores_Jerk)	> CylModeDecel * RandomCylModDecel  > CylModeJerk * RandomCylModJerk  > RevMode_Decel * RandomRevModDecl  > RufSCD_Decel * Pair_SCD_Decel  > RufSCD_Jerk * Pair_SCD_Jerk  > SCD_Decel * Pair_SCD_Decel  > SCD_Jerk * Pair_SCD_Jerk  > RufCyl_Decel * PairCylModeDecel  > RufCyl_Jerk * PairCylModeJerk  > CylModeDecel * PairCylModeDecel  > CylModeJerk * PairCylModeJerk				

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR (Revmode Active AND (within one engine cycle: 2nd largest Lores_Decel)  AND Above TRUE for ) )  BANK MISFIRE Cylinders above Bank Thresholds  (Medres_Decel  AND Medres_Jerk)  OR (Medres_Decel  AND Medres_Jerk)  OR (Lores_Decel  AND Lores_Jerk)  OR (Lores_Decel  AND Lores_Jerk)	> <b>CylModeDecel</b> * <b>PairCylModeDecel</b>  > 80 engine cycles out of 100 engine cycles  >= 3 cylinders  > <b>RufSCD_Decel</b> * <b>Bank_SCD_Decel</b>  > <b>RufSCD_Jerk</b> * <b>Bank_SCD_Jerk</b>  > <b>SCD_Decel</b> * <b>Bank_SCD_Decel</b>  > <b>SCD_Jerk</b> * <b>Bank_SCD_Jerk</b>  > <b>RufCyl_Decel</b> * <b>BankCylModeDecel</b>  > <b>RufCyl_Jerk</b> * <b>BankCylModeJerk</b>  > <b>CylModeDecel</b> * <b>BankCylModeDecel</b>  > <b>CylModeJerk</b> * <b>BankCylModeJerk</b>				

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>CONSECUTIVE CYLINDER MISFIRE 1st cylinder uses single cyl continuous misfire thresholds; 2nd Cylinder uses: (Medres_Decel AND Medres_Jerk)</p> <p>OR (Medres_Decel AND Medres_Jerk)</p> <p>OR (Lores_Decel AND Lores_Jerk)</p> <p>OR (Lores_Decel AND Lores_Jerk)</p> <p>CYLINDER DEACTIVATION MODE (Active Fuel Managment)</p>	<p>&gt; RufSCD_Decel * ConsecSCD_Decel</p> <p>&gt; RufSCD_Jerk * ConsecSCD_Jerk</p> <p>&gt; SCD_Decel * ConsecSCD_Decel</p> <p>&gt; SCD_Jerk * ConsecSCD_Jerk</p> <p>&gt; RufCyl_Decel * ConsecCylModDecel</p> <p>&gt; RufCyl_Jerk * ConsecCylModeJerk</p> <p>&gt; CylModeDecel * ConsecCylModDecel</p> <p>&gt; CylModeJerk * ConsecCylModeJerk</p>				

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AFM: SINGLE CYLINDER CONTINUOUS MISFIRE (CylAfterDeacCyl_Decel AND CylAfterDeacCyl_Jerk)  OR (CylBeforeDeacCylDecel AND CylBeforeDeacCyl_Jerk)	> CylModeDecel * ClyAfterAFM_Decel  > CylModeJerk * CylAfterAFM_Jerk  > CylModeDecel * CylBeforeAFM_Decel  > CylModeJerk * ClyBeforeAFM_Jerk				
			AFM: RANDOM MISFIRE Use random misfire thresholds If no misfire for  (CylAfterDeacCyl_Decel AND CylAfterDeacCyl_Jerk)  (CylBeforeDeacCylDecel AND CylBeforeDeacCyl_Jerk)	> 6 Engine Cycles  > CylModeDecel * ClyAfterAFM_Decel * RandomAFM_Decl  > CylModeJerk * CylAfterAFM_Jerk * RandomAFM_Jerk  > CylModeDecel * CylBeforeAFM_Decel * RandomAFM_Decl  > CylModeJerk * ClyBeforeAFM_Jerk * RandomAFM_Jerk				
			- see details on Supporting Tables Tab					

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Misfire Percent Emission Failure Threshold</p> <p>Misfire Percent Catalyst Damage</p> <p>When engine speed and load are less than the FTP calcs (3) catalyst damage exceedences are allowed.</p>	<p>≥ 2.38 % P0300</p> <p>&gt; <b>Catalyst_Damage_Misfire_Percentage</b> in Supporting Tables whenever secondary conditions are met.</p> <p>≤ 1,513 FTP rpm AND ≤ 16 FTP % load</p>	<p>(at low speed/loads, one cylinder may not cause cat damage)</p> <p>Engine Speed Engine Load Misfire counts</p> <p>Engine Speed</p>	<p>&gt; 1,463 rpm AND &gt; 16 % load AND &lt; 180 counts on one cylinder</p> <p>500 &lt; rpm &lt; ((Engine Over Speed Limit) - 400 ) OR 8,191 )</p> <p>Engine speed limit is a function of inputs like Gear and temperature</p>	<p>4 cycle delay</p>	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						see <b>EngineOverSpeedLimit</b> in supporting tables		
					No active DTCs:	TPS_FA EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO ECT_Sensor_Ckt_TFTKO 5VoltReferenceB_FA CrankSensor_TFTKO CrankSensor_FA CamLctnIntFA CamLctnExhFA CamSensorAnyLctnTFTKO AnyCamPhaser_FA AnyCamPhaser_TFTKO AmbPresDfIdStatus	4 cycle delay	
					P0315 & engine speed	> 1,000 rpm	4 cycle delay	
					Fuel Level Low	LowFuelConditionDiagnostic	500 cycle delay	
					Cam and Crank Sensors	in sync with each other	4 cycle delay	
					Misfire requests TCC unlock	Not honored because Transmission in hot mode or POPD intrusive diagnostic running	4 cycle delay	
					Fuel System Status	≠ Fuel Cut	4 cycle delay	
					Active FuelManagement	Transition in progress	0 cycle delay	
					Undetectable engine	<b>Undetectable region</b>	4 cycle delay	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					speed and engine load region	from Malfunction Criteria		
					Abusive Engine Over Speed	> 8,192 rpm	0 cycle delay	
					Below zero torque (except CARB approved 3000 rpm to redline triangle.)	< <b>ZeroTorqueEngLoad</b> or < <b>ZeroTorqueAFM</b> if AFM is active in Supporting Tables	4 cycle delay	
					Below zero torque: TPS Vehicle Speed	≤ 1.3 % (≤ 1.3 % in AFM) > 30 mph (> 30 mph AFM)	4 cycle delay	
					NEGATIVE TORQ AFM If deactivated cylinders appear to make power, torque is negative: DeactivatedCyl_Decel AND DeactivatedCyl_Jerk AND # of Deact Cyls Inverted	< <b>DeacCylInversionDecel</b>  < <b>DeacCylInversionJerk</b>  > 4 cylinders	0 cycle delay	
					EGR Intrusive test	if Active	0 cycle delay	
					Manual Trans	Clutch shift	0 cycle delay	
					Accel Pedal Position AND Automatic transmission shift	> 98.00 %	7 cycle delay	
					After Fuel resumes on Automatic shift containing Fuel Cut		2 Cylinder delay	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Delay if PTO engaged       ***** **This Feature not used on Gasoline engines**  Combustion Mode  Driver cranks before Wait to Start lamp extinguishes  Brake Torque *****  DRIVELINE RING FILTER After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early. Filter Driveline ring:  Stop filter early:  ABNORMAL ENGINE SPEED OSCILLATION: (checks each "misfire" candidate in 100 engine	Enabled       *****       = <b>InfrequentRegen</b> value in Supporting Tables  IF TRUE  > 199.99 % Max Torque *****  > " <b>Ring Filter</b> " # of engine cycles after misfire in Supporting Tables  > " <b>Number of Normals</b> " # of engine cycles after misfire in Supporting Tables tab	4 cycle delay       *****       0 cycle delay  <b>WaitToStart</b> cycle delay  0 cycle delay *****	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Cycle test to see if it looks like some disturbance like rough road (abnormal). )</p> <p>Used Off Idle, and while not shifting,</p> <p style="text-align: right;">TPS Engine Speed Veh Speed Auto Transmission</p> <p>individual candidate deemed abnormal if number of consecutive decelerating cylinders after "misfire": (Number of decels can vary with misfire detection equation)</p> <p style="text-align: right;">Consecutive decels while in SCD Mode Cyl Mode Rev Mode</p> <p>At the end of 100 engine cycle test, the ratio of abnormal/candidate is checked to confirm if real misfire is present within the 100 engine cycles.</p> <p>abnormal candidates/ total candidates</p> <p>MISFIRE CRANKSHAFT</p>	<p>&gt; 3 % &gt; 1,000 rpm &gt; 3 mph not shifting</p> <p>&gt; <b>Abnormal SCD Mode</b> &gt; <b>Abnormal Cyl Mode</b> &gt; <b>Abnormal Rev Mode</b> in Supporting Tables</p> <p>&gt; 0.50 ratio</p>	discard 100 engine cycle test	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>PATTERN RECOGNITION checks each "misfire" candidate in 100 engine Cycle test to see if overall crankshaft pattern looks like real misfire (recognized), or some disturbance like rough road (unrecognized). At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present within the 100 engine cycles. Typically used for checking a single misfire per engine cycle but can support some other patterns on some packages</p> <p>Pattern Recog Enabled:</p> <p>Pattern Recog Enabled during Cylinder Deac</p> <p>Pattern Recog Enabled consecutive cyl patrn</p> <p>Engine Speed Veh Speed</p> <p>The 1st check for "recognized" is the 1st fired cylinder after the misfire candidate should both accelerate and jerk an amount based acceleration and jerk of Single Cylinder Misfire</p>	<p>Enabled</p> <p>Not Enabled</p> <p>Enabled</p> <p>900 &lt; rpm &lt; 6,500 &gt; 3.1 mph</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>thresholds in effect at that speed and load.  (CylAfter_Accel  AND  CylAfter_Jerk)</p> <p>Additionally, the crankshaft is checked again a small calibratable number of cylinders later to see if the disturbance is still large like rough road, or has calmed down like real misfire. The size of disturbance is compared to a multiplier times the ddt_jerk value used to detect misfire at that speed and load. If there is repetitive misfire on consecutive engine cycles, the expected snap is adjusted due to the higher expected disturbance.</p> <p>Num of Cylinders after misfire to start check of crankshaft snap</p> <p>"misfire" recognized if:  Crankshaft snap after:  isolated "misfire"</p>	<p>&gt; Misfire_decel *  <b>1st_FireAftrMisfr_Acel</b></p> <p>&gt; Misfire_Jerk *  <b>1st_FireAftrMisfr_Jerk</b></p> <p>Or if AFM mode is active:  &gt; Misfire_decel *  <b>1stFireAftrMisAcelAFM</b>  &gt; Misfire_Jerk *  <b>1stFireAfterMisJerkAFM</b></p> <p>2 Cylinders</p> <p>&lt; Misfire_Jerk *  <b>SnapDecayAfterMisfire</b></p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					repetative "misfire"  At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present.  Ratio of Unrecog/Recog	< Misfire_Jerk * <b>SnapDecayAfterMisfire *</b> <b>RepetSnapDecayAdjst</b> in Supporting Tables      > 0.80	    discard 100 engine cycle test	
					***** NON-CRANKSHAFT BASED ROUGH ROAD:  Rough Road Source ***** IF Rough Road Source = WheelSpeedInECM ABS/TCS Wheel speed noise VSES  AND No Emission Neutral Default Action DTCs	***** Disabled  CeRRDR_e_None ***** active > <b>WSSRoughRoadThres</b> active  ABS Failed Vehicle Dynamics Control System Status Driven Wheel Rotation Status Non Driven Wheel Rotation Status	*****   discard 100 engine cycle test	
					***** IF Rough Road Source = "FromABS" ABS/TCS	*****   active	*****   discard 100	

## 20 OBDG03A ECM Summary Tables

[illegible]

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position System Variation Not Learned	P0315	This DTC determines if the crankshaft sensor learn values that are stored in memory are valid. The angle between each tooth of the reluctor wheel is learned, and the sum of all angles together should sum to 360° (one revolution of the reluctor wheel). Default values, or corrupted values will not sum to 360°.	<p>The Crankshaft target wheel should be 360 degrees around in circumference. Loss or controller non-volatile memory or an error in memory will cause the values of individual teeth learn to be defaulted or incorrect.</p> <p>Set the DTC if the Difference between the sum of the reluctor wheel's teeth and 360 degrees is greater than:</p>	> 0.001 degrees	OBD Manufacturer Enable Counter	MEC = 0	0.50 seconds  Frequency Continuous100 msec	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Per Cylinder	P0324	This diagnostic checks for knock sensor performance out of the normal expected range on a per cylinder basis due to Excessive Knock (either real or false knock). In the knock detection algorithm, the term "Knock Intensity" (KI) is used to define the relative size of a knock event, and is calculated as (KI = current knock event - knock threshold). This results in a KI amplitude that is proportional to the size of the knock event (as seen by the knock sensor). In addition, Knock Intensity cannot be less than zero as it is forced/limited to be = 0 with no knock detected (i.e. whenever the current knock event < knock threshold, KI = 0). This diagnostic calculates a first-order lag filter version of the Knock Intensity and sets a fault when: (Filtered KI) > (Excessive Knock Diagnostic Threshold)	Filtered Knock Intensity  (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)	> <b>P0324_PerCyl_ExcessiveKnock_Threshold</b> (no units)	Diagnostic Enabled?  Engine Run Time  Engine Speed  Engine Air Flow  Engine Coolant Temperature  or  OBD Coolant Enable Criteria  Inlet Air Temperature  Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	Yes  ≥ 2.0 seconds  ≥ 400 RPM AND ≤ 8,500 RPM  ≥ 0 mg/cylinder AND ≤ 2,000 mg/cylinder  ≥ -40 deg's C  = TRUE  ≥ -40 deg's C  ≥ 400 revs	First Order Lag Filters with Weight Coefficient = 0.0400  Updated each engine event	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 1	P0325	<p>This diagnostic checks for an open in the knock sensor circuit Sensor 1/Bank 1. There are two possible methods used:</p> <p><b>1. 20 kHz Method:</b> This method injects a 20 kHz signal (internal to the ECU) onto one of the Knock Sensor inputs. For a normal/good circuit the 20 kHz signal will propagate through the Knock sensor and back to the ECU through the sensor return circuit. The 20 kHz signal is processed through the Fast Fourier Transform (FFT) and then filtered with a first-order lag filter. Since the Knock Detection algorithm uses a Differential Op-Amp to compare the input from the two knock sensor wires, the FFT 20 kHz diagnostic signal will have either: A. Low output with a good circuit (because the 20 kHz injected signal is detected on both of the sensor inputs) or B. High output for an Open Circuit (because</p>	<p>Open Circuit Method chosen (2 possible methods: 20 kHz or Normal Noise):</p> <p>Filtered FFT Output</p> <p>Filtered FFT Output</p>	<p>= <b>P0325_P0330_OpenMethod_2</b></p> <p><b>Case 1 (20 kHz Method):</b> &gt; <b>P0325_P0330_OpenCktThrshMin (20 kHz)</b> AND &lt; <b>P0325_P0330_OpenCktThrshMax (20 kHz)</b></p> <p><b>Case 2 (Normal Noise Method):</b> &gt; <b>P0325_P0330_OpenCktThrshMin (Normal Noise)</b> AND &lt; <b>P0325_P0330_OpenCktThrshMax (Normal Noise)</b></p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)</p> <p>Engine Air Flow</p> <p>Engine Coolant Temperature</p> <p>or</p> <p>OBD Coolant Enable Criteria</p> <p>Inlet Air Temperature</p>	<p>Yes</p> <p>≥ 2.0 seconds</p> <p>≥ 650 RPM and ≤ 8,500 RPM</p> <p>≥ 100 revs</p> <p>≥ 40 mg/cylinder and ≤ 2,000 mg/cylinder</p> <p>≥ -40 deg's C</p> <p>= TRUE</p> <p>≥ -40 deg's C</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p>Weight Coefficient = 0.0100</p> <p>Updated each engine event</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>the 20 kHz injected signal is detected only on one of the sensor inputs).</p> <p>The 20 kHz method is typically used for the entire operating region of the engine. However, some engines may not have adequate separation between good and bad circuits at high engine speed. In these cases the 20 kHz method is used at low and medium engine speeds, and the "Normal Noise" method is used at high engine speed only.</p> <p><b>2. Normal Noise:</b> The Normal Noise method monitors the background engine noise level for a selected frequency range output of the knock detection FFT. The background noise (i.e. Normal Noise) is filtered with a first-order lag filter. A good circuit is determined when the filtered Normal Noise signal is greater than the threshold.</p> <p>See Supporting Tables for method definition: <b>P0325 P0330 OpenM</b></p>						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<b>ethod</b> defines which of the two diagnostic methods is used as a function of engine speed (RPM). Typical implementations: A. Use 20 kHz method at all engine RPM (used when acceptable separation achieved at all RPM) or B. Use 20 kHz method at low/medium RPM and Normal Noise at high RPM						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Bank 1	P0326	This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis. This diagnostic is specifically designed to identify the fault condition where the knock sensor is properly attached electrically, but produces an abnormally low output due to being unattached (or loosely attached) with the mounting bolt (and thus unable to properly transfer the engine vibration energy from the engine block to the knock sensor). The term "Abnormal (engine) Noise" is used to define this diagnostic method. A fault condition is identified when a first-order lag filtered version of the Abnormal Noise signal falls below the diagnostic threshold.	<p>Filtered FFT Intensity</p> <p>(where 'FFT Intensity' = Non-knocking, background engine noise for a selected frequency)</p> <p>Filtered FFT Intensity</p>	<p><b>Case 1: Engine <u>not</u> in AFM mode</b></p> <p>&lt; <b>P0326_P0331_Abnor malNoise_Threshold</b> (Supporting Table)</p> <p>OR</p> <p><b>Case 2: Engine <u>is</u> in AFM mode</b></p> <p>&lt; <b>P0326_P0331_Abnor malNoise_Thresh_AF M</b> (Supporting Table; Engine <u>is</u> in AFM mode)</p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Engine Air Flow</p> <p>Engine Coolant Temperature</p> <p>or</p> <p>OBD Coolant Enable Criteria</p> <p>Inlet Air Temperature</p> <p>Individual Cylinders enabled for Abnormal Noise</p> <p>Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)</p>	<p>Yes</p> <p>≥ 2.0 seconds</p> <p>≥ 2,000 RPM (not in AFM mode) OR ≥ 2,000 (in AFM mode)</p> <p>AND ≤ 8,500 RPM</p> <p>≥ 0 mg/cylinder AND ≤ 2,000 mg/cylinder</p> <p>≥ -40 deg's C</p> <p>= TRUE</p> <p>≥ -40 deg's C</p> <p><b>P0326_P0331_Abnormal Noise_CylsEnabled</b> (Supporting Table)</p> <p>≥ 200 Revs</p>	<p>First Order Lag Filters with Weight Coefficient = 0.0100</p> <p>Updated each engine event</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 1	P0327	This diagnostic checks for an out of range low knock sensor signal. A 3-resistor bias network at each sensor input to the ECM provides a DC diagnostic voltage that will remain within a normal range when the external knock sensor circuit is free of short circuit faults. The diagnostic output is reported as a percentage (0 to 100%) when compared to the 5.0 volt reference voltage.	Sensor Input or Return Signal Line	< 8.0 Percent  (of 5.0 Volt reference)	Diagnostic Enabled?  Engine Speed	Yes  > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 1	P0328	This diagnostic checks for an out of range high knock sensor signal. A 3-resistor bias network at each sensor input to the ECM provides a DC diagnostic voltage that will remain within a normal range when the external knock sensor circuit is free of short circuit faults. The diagnostic output is reported as a percentage (0 to 100%) when compared to the 5.0 volt reference voltage.	Sensor Input or Return Signal Line	> 39.0 Percent  (of 5 Volt Reference)	Diagnostic Enabled?  Engine Speed	Yes  > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 2	P0330	<p>This diagnostic checks for an open in the knock sensor circuit Sensor 2/Bank 2. There are two possible methods used:</p> <p><b>1. 20 kHz Method:</b> This method injects a 20 kHz signal (internal to the ECU) onto one of the Knock Sensor inputs. For a normal/good circuit the 20 kHz signal will propagate through the Knock sensor and back to the ECU through the sensor return circuit. The 20 kHz signal is processed through the Fast Fourier Transform (FFT) and then filtered with a first-order lag filter. Since the Knock Detection algorithm uses a Differential Op-Amp to compare the input from the two knock sensor wires, the FFT 20 kHz diagnostic signal will have either:</p> <p>A. Low output with a good circuit (because the 20 kHz injected signal is detected on both of the sensor inputs) or B. High output for an</p>	<p><b>Individual Sensor Thresholds Enabled?</b></p> <p><b>Open Circuit Method chosen</b> (2 possible methods: 20 kHz or Normal Noise):</p> <p>Filtered FFT Output</p> <p>Filtered FFT Output</p>	<p>= 0.00 , Use Case 1 and 2</p> <p>=<b>OpenMethod_2</b> (supporting table)</p> <p><b><u>Case 1 (20 kHz Method):</u></b></p> <p>&gt; <b>OpenCktThrshMin (20 kHz)</b> <b>AND</b> &lt; <b>OpenCktThrshMax (20 kHz)</b></p> <p><b><u>Case 2 (Normal Noise Method):</u></b></p> <p>&gt; <b>OpenCktThrshMin (Normal Noise)</b> <b>AND</b> &lt; <b>OpenCktThrshMax (Normal Noise)</b></p> <p><b>Case 3 (20 kHz Method):</b></p> <p>&gt; <b>OpenCktThrshMin2 (20 kHz)</b></p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)</p> <p>Engine Air Flow</p> <p>Engine Coolant Temperature</p> <p>or</p> <p>OBD Coolant Enable Criteria</p> <p>Inlet Air Temperature</p>	<p>Yes</p> <p>≥ 2.0 seconds</p> <p>≥ 650 RPM and ≤ 8,500 RPM</p> <p>≥ 100 revs</p> <p>≥ 40 mg/cylinder and ≤ 2,000 mg/cylinder</p> <p>≥ -40 deg's C</p> <p>= TRUE</p> <p>≥ -40 deg's C</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p><b>Case 1 &amp; 2:</b> Weight Coefficient = 0.0100</p> <p>Updated each engine event</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>Open Circuit (because the 20 kHz injected signal is detected only on one of the sensor inputs).</p> <p>The 20 kHz method is typically used for the entire operating region of the engine. However, some engines may not have adequate separation between good and bad circuits at high engine speed. In these cases the 20 kHz method is used at low and medium engine speeds, and the "Normal Noise" method is used at high engine speed only.</p> <p><b>2. Normal Noise:</b> The Normal Noise method monitors the background engine noise level for a selected frequency range output of the knock detection FFT. The background noise (i.e. Normal Noise) is filtered with a first-order lag filter. A good circuit is determined when the filtered Normal Noise signal is greater than the threshold.</p> <p>See Supporting Tables</p>	<p>Filtered FFT Output</p> <p>Filtered FFT Output</p>	<p>AND</p> <p>&lt; <b>OpenCktThrshMax2 (20kHz)</b></p> <p><b>Case 4 (Normal Noise Method):</b></p> <p>&gt; <b>OpenCktThrshMin2 (NN)</b></p> <p>AND</p> <p>&lt; <b>OpenCktThrshMax2 (NN)</b></p>			<p><b>Case 3 &amp; 4</b> Weight Coefficient = 0.01</p> <p>Updated each engine event</p>	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>for method definition:  <b>P0325_P0330_OpenM  method</b> defines which of  the two diagnostic  methods is used as a  fuction of engine  speed (RPM).  Typical  implementations:  A. Use 20 kHz  method at all engine  RPM (used when  acceptable separation  achieved at all RPM) or  B. Use 20 kHz  method at low/medium  RPM and Normal Noise  at high RPM</p> <p>For each method the  failure thresholds can  be the same for both  sensors (in a 2 sensor  application), or the  failure thresholds can  be unique to each  sensor.</p>						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Bank 2	P0331	<p>This diagnostic checks for knock sensor performance out of the normal expected range, on a per sensor basis. This diagnostic is specifically designed to identify the fault condition where the knock sensor is properly attached electrically, but produces an Abnormally low output due to being unattached (or loosely attached) with the the mounting bolt (and thus unable to properly transfer the engine vibration energy from the engine block to the knock sensor). The term "Abnormal (engine) Noise" is used to define this diagnostic method. A fault condition is identified when a first-order lag filtered version of the Abnormal Noise signal falls below the diagnostic threshold.</p> <p>The failure thresholds can be the same for both sensors (in a 2 sensor application), or the failure thresholds can be unique to each sensor.</p>	<p>Individual Sensor Thresholds Enabled?</p> <p>Filtered FFT Intensity  (where 'FFT Intensity' = Non-knocking, background engine noise)</p> <p>Filtered FFT Intensity</p>	<p>= 0.00 , Use Case 1 and 2</p> <p><b>Case 1: Engine <u>not</u> in AFM mode</b> &lt; <b>AbnormalNoise_Threshhold</b> (Supporting Table)</p> <p>OR</p> <p><b>Case 2: Engine <u>is</u> in AFM mode</b> &lt; <b>AbnormalNoise_Thresh_AFM</b> (Supporting Table)</p> <p><b>Case 3: Engine not in AFM mode</b> &lt; <b>AbnormalLo2</b> (Supporting Table)</p> <p>OR</p> <p><b>Case 4: Engine is in AFM mode</b> &lt; <b>AbnormalLoAFM_2</b> (Supporting Table)</p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Engine Air Flow</p> <p>Engine Coolant Temperature</p> <p>or</p> <p>OBD Coolant Enable Criteria</p> <p>Inlet Air Temperature</p> <p>Individual Cylinders enabled for Abnormal Noise</p> <p>Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)</p>	<p>Yes ≥ 2.0 seconds</p> <p>≥ 2,000 RPM (not in AFM mode) OR ≥ 2,000 (in AFM mode)</p> <p>AND ≤ 8,500 RPM</p> <p>≥ 0 mg/cylinder AND ≤ 2,000 mg/cylinder</p> <p>≥ -40 deg's C</p> <p>= TRUE</p> <p>≥ -40 deg's C</p> <p><b>AbnormalNoise_CylsEnabled</b> (Supporting Table)</p> <p>≥ 200 Revs</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p><b>Case 1 &amp; 2:</b> Weight Coefficient = 0.0100</p> <p>Updated each engine event</p> <p><b>Case 3 &amp; 4:</b> Weight Coefficient = 0.01</p> <p>Updated each engine eventFirst</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 2	P0332	This diagnostic checks for an out of range low knock sensor signal. A 3-resistor bias network at each sensor input to the ECM provides a DC diagnostic voltage that will remain within a normal range when the external knock sensor circuit is free of short circuit faults. The diagnostic output is reported as a percentage (0 to 100%) when compared to the 5.0 volt reference voltage.	Sensor Input or Return Signal Line	< 8.0 Percent  (of 5 Volt Reference)	Diagnostic Enabled?  Engine Speed	Yes  > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 2	P0333	This diagnostic checks for an out of range high knock sensor signal. A 3-resistor bias network at each sensor input to the ECM provides a DC diagnostic voltage that will remain within a normal range when the external knock sensor circuit is free of short circuit faults. The diagnostic output is reported as a percentage (0 to 100%) when compared to the 5.0 volt reference voltage.	Sensor Input or Return Signal Line	> 39.00 Percent  (of 5 Volt Reference)	Diagnostic Enabled?  Engine Speed	Yes  > 0 RPM and < 8,500 RPM	50 Failures out of 63 Samples  100 msec rate	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Circuit	P0335	Diagnostic will fail if a crank sensor pulse was not received during a period of time; if crank sensor pulses are received the diagnostic will pass.	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	Starter engaged AND (cam pulses being received OR ( MAF_SensorFA AND Engine Air Flow	Test is Enabled  = FALSE  > 3.0 grams/second ) )	Continuous every 100 msec	Type A, 1 Trips
			No crankshaft pulses received	>= 1.0 seconds	Engine is Running  Starter is not engaged	Test is Enabled	Continuous every 12.5 msec	
			No crankshaft pulses received		Engine is Running OR Starter is engaged  No DTC Active:	Test is Enabled  P0365 P0366	2 failures out of 10 samples  One sample per engine revolution	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Performance	P0336	1. Fail counts will occur if the engine goes out of synchronization repeatedly over a period of time and will pass if the engine stays in synchronization. 2. Diagnostic will fail if synchronization gap is not found in a specified period of time and will pass if the synchronization gap is found. 3. Diagnostic will fail if the incorrect number of crank sensor teeth are detected in-between detecting the synchronization gap and will pass if the correct number of teeth are seen.	Time in which 10 or more crank re-synchronizations occur	< 10.0 seconds	Engine Air Flow  Cam-based engine speed  No DTC Active:	Test is Enabled  >= 3.0 grams/second  > 450 RPM  P0335	Continuous every 250 msec	Type A, 1 Trips
			No crankshaft synchronization gap found	>= 0.4 seconds	Engine is Running  Starter is not engaged	Test is Enabled	Continuous every 12.5 msec	
			Time since starter engaged without detecting crankshaft synchronization gap	>= 1.5 seconds	Starter engaged AND (cam pulses being received OR ( MAF_SensorFA AND Engine Air Flow	Test is Enabled   = FALSE  > 3.0 grams/second ) )	Continuous every 100 msec	
			Crank pulses received in one engine revolution OR Crank pulses received in one engine revolution	< 1 pulses  > 65,535 pulses	Engine is Running OR Starter is engaged  No DTC Active:	Test is Enabled     P0365 P0366	8 failures out of 10 samples  One sample per engine revolution	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor A	P0340	Diagnostic will fail if a cam sensor pulse was not received during a period of time; if cam sensor pulses are received the diagnostic will pass.	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (crank pulses being received OR ( MAF_SensorFA AND Engine Air Flow	Test is Enabled  = FALSE > 3.0 grams/second ) )	Continuous every 100 msec	Type A, 1 Trips
			OR Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds				
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running  Starter is not engaged	Test is Enabled	Continuous every 100 msec	
			No camshaft pulses received during 12 MEDRES events  (There are 12 MEDRES events per engine cycle)  Test begins when MEDRES region AND accumulated number of MEDRES events	= region 3  >= 0 counts	Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged  No DTC Active:	Test is Enabled   CrankSensor_FA	Continuous, every MEDRES event until test completes, one test at every start attempt	
			The number of camshaft pulses received during 100 engine cycles	= 0 pulses	Crankshaft is synchronized  No DTC Active:	Test is Enabled  CrankSensor_FA	8 failures out of 10 samples  Continuous every engine cycle	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor A	P0341	Diagnostic will fail if an incorrect number of cam sensor pulses are detected over a number of engine cycles and will pass if the number of cam pulses is correct.	The number of camshaft pulses received during 12 MEDRES events is OR  (There are 12 MEDRES events per engine cycle)  Test begins when MEDRES region AND accumulated number of MEDRES events	< 4 pulses > 10 pulses   = region 3 >= 0 counts	Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged  No DTC Active:	Test is Enabled    CrankSensor_FA	Continuous, every MEDRES event until test completes, one test at every start attempt	Type A, 1 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 pulses > 402 pulses	Crankshaft is synchronized  No DTC Active:	Test is Enabled  CrankSensor_FA	8 failures out of 10 samples  Continuous every engine cycle	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position Sensor - Crankshaft Start Position Incorrect	P034A	Monitors the position of the crankshaft during auto-start's to verify that the crankshaft is in the expected position-diagnostic will fail if the crankshaft is not in the expected range otherwise the diagnostic will pass	Crankshaft position is in error by a number of crankshaft wheel teeth	> 2 crankshaft teeth	Engine has started rotating during a hybrid auto-start  Crankshaft position is being verified  No Active DTCs:	Test is Enabled   CrankSensor_FA	2 failures out of 3 samples  a sample occurs at each hybrid auto-start	Type B, 2 Trips
			Crankshaft position is in error by at least one crankshaft wheel tooth		Engine has started rotating during a hybrid auto-start  Crankshaft position is being verified  No Active DTCs:	Test is Enabled   CrankSensor_FA	4 failures out of 5 samples  a sample occurs each hybrid auto-start	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position Sensor - Crankshaft Direction Incorrect	P034B	Detects if the crankshaft is not rotating in the correct direction- will fail if the engine is reported to be spinning backwards while the engine is running otherwise the diagnostic will pass.	Number of crankshaft sensor reversals  within a period of time	>= 3 pulses  <= 10.0 seconds	Engine Speed Engine Speed Engine Air Flow  Engine Movement Detected  No Active DTCs:	Test is Enabled  > 400 RPM < 2,000 RPM >= 3.0 grams/second    CrankSensor_FA	Continuous  Every 250 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT	P0351	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures  out of 63 Samples  100 msec rate	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT	P0352	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p><math>\geq 30 \text{ k}\Omega</math> impedance between signal and controller ground</p>	<p>Engine running</p> <p>Ignition Voltage</p>	> 11.0 Volts	<p>50 Failures out of 63 Samples</p> <p>100 msec rate</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT	P0353	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT	P0354	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for an Open Circuit fault. Controller specific output driver circuit diagnoses the low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running  Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples  100 msec rate	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor B	P0365	Diagnostic will fail if a cam sensor pulse was not received during a period of time; if cam sensor pulses are received the diagnostic will pass.	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (crank pulses being received OR ( MAF_SensorFA AND Engine Air Flow	Test is Enabled  = FALSE  > 3.0 grams/second ) )	Continuous every 100 msec	Type A, 1 Trips
			OR  Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds				
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running  Starter is not engaged	Test is Enabled	Continuous every 100 msec	
			No camshaft pulses received during 12 MEDRES events  (There are 12 MEDRES events per engine cycle) Test begins when MEDRES region AND accumulated number of MEDRES events	= region 3  >= 0 counts	Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged  No DTC Active:	Test is Enabled    CrankSensor_FA	Continuous, every MEDRES event until test completes, one test at every start attempt	
			The number of camshaft pulses received during 100 engine cycles	= 0 pulses	Crankshaft is synchronized  No DTC Active:	Test is Enabled  CrankSensor_FA	8 failures out of 10 samples  Continuous every engine cycle	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor B	P0366	Diagnostic will fail if an incorrect number of cam sensor pulses are detected over a number of engine cycles and will pass if the number of cam pulses is correct.	The number of camshaft pulses received during 12 MEDRES events is OR  (There are 12 MEDRES events per engine cycle)  Test begins when MEDRES region AND accumulated number of MEDRES events	< 4 pulses > 10 pulses   = region 3  >= 0 counts	Crankshaft is synchronized  Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged  No DTC Active:	Test is Enabled    CrankSensor_FA	Continuous, every MEDRES event until test completes, one test at every start attempt	Type A, 1 Trips
			The number of camshaft pulses received during 100 engine cycles OR	< 398 pulses > 402 pulses	Crankshaft is synchronized  No DTC Active:	Test is Enabled  CrankSensor_FA	8 failures out of 10 samples  Continuous every engine cycle	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420	<p>NOTE: The information below applies to applications that use the Decel Catalyst Monitor Algorithm</p> <p>Oxygen Storage. The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (I.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (I.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Rich (intrusive rich) and Lean (decel fuel cutoff) A/F excursions</p> <p>Normalized Ratio OSC Value Calculation Information and Definitions =</p> <ol style="list-style-type: none"> <li>1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time)</li> <li>2. BestFailing OSC value from a calibration</li> </ol>	Normalized Ratio OSC Value (EWMA filtered)	< 0.38	<p>All enable criteria associated with P0420 can be found under P2270 - (O2 Sensor Signal Stuck Lean Bank 1 Sensor 2)</p> <p>Rapid Step Response (RSR) feature will initiate multiple tests:</p> <p>If the difference between current EWMA value and the current OSC Normalized Ratio value is</p> <p>and the current OSC Normalized Ratio value is</p> <p>Maximum number of RSR tests to detect failure when RSR is enabled.</p> <p>MAF</p> <p>Predicted catalyst temperature</p> <p>Front O2 Sensor or Front WRAF</p> <p>Rear O2 Sensor</p> <p>General Enable Criteria</p> <p>In addition to the p-codes listed under P2270, the following DTC's shall also</p>	<p>&gt; 0.46</p> <p>&lt; 0.10</p> <p>6</p> <p>&gt; 2.00 g/s &lt; 20.00 g/s</p> <p>&lt; 850 ° C</p> <p>&gt; 825.00 mV or &gt; 1.08 EQR</p> <p>&gt; 825.00 mV</p>	<p>1 test attempted per valid decel period</p> <p>Minimum of 1 test per trip</p> <p>Maximum of 4 tests per trip</p> <p>Frequency: Fueling Related : 12.5 ms</p> <p>OSC Measurements: 100 ms</p> <p>Temp Prediction: 12.5ms</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow)</p> <p>Normalized Ratio Calculation = (1-2) / (3-2)</p> <p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part.</p> <p>Refer to the <b>P0420_WorstPassingOSCTableB1</b> and <b>P0420_BestFailingOSCTableB1</b> in Supporting Tables tab for details</p> <p>The Catalyst Monitoring Test is completed during a decel fuel cutoff event. This fuel cutoff event occurs following a rich intrusive fueling event initiated by the O2 Sensor Signal Stuck Lean Bank 1 Sensor 2 test (P2270). Several conditions must be met in order to execute this test.</p> <p>Additional conditions and their related values</p>			<p>not be set:</p> <p>For switching O2 sensors:</p> <p>For WRAF O2 sensors:</p>	<p>O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA</p> <p>WRAF_Bank_1_FA WRAF_Bank_2_FA</p> <p><b>P0420_WorstPassingOSCTableB1</b></p> <p><b>P0420_BestFailingOSCTableB1</b></p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		are listed in the "Secondary Parameters" and "Enable Conditions" section of this document for P2270 (O2 Sensor Signal Stuck Lean Bank 1 Sensor 2)						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Small Leak Detected  (No ELCP - Conventional EVAP Diagnostic - with EAT using OAT Sensor - with Fuel Tank Zone Module (FTZM))	P0442	This DTC will detect a small leak ( $\geq 0.020''$ ) in the EVAP system between the fuel fill cap and the purge solenoid. On some applications a small leak is defined as $\geq 0.025''$ , $0.030''$ , or $0.150''$ . The engine off natural vacuum method (EONV) is used. EONV is an evaporative system leak detection diagnostic that runs when the vehicle is shut off when enable conditions are met. Prior to sealing the system and performing the diagnostic, the fuel volatility is analyzed. In an open system (Canister Vent Solenoid [CVS] open) high volatility fuel creates enough flow to generate a measurable pressure differential relative to atmospheric. After the volatility check, the vent solenoid will close. After the vent is closed, typically a build up of pressure from the hot soak begins (phase-1). The pressure typically will peak and then begin to decrease as the fuel cools. When	The total delta from peak pressure to peak vacuum during the test is normalized against a calibration pressure threshold table that is based upon fuel level and ambient temperature. (Please see <b>P0442 EONV Pressure Threshold (Pascals)</b> in Supporting Tables). The normalized value is calculated by the following equation: $1 - (\text{peak pressure} - \text{peak vacuum}) / \text{pressure threshold}$ . The normalized value is entered into EWMA (with 0= perfect pass and 1= perfect fail).		Fuel Level Drive Time Drive length  (ECT  OR OBD Coolant Enable Criteria  Baro Distance since assembly plant Engine not run time before key off must be	$10\% \leq \text{Percent} \leq 90\%$ $\geq 600$ seconds $\geq 5.0$ miles  $\geq 63^\circ\text{C}$  = TRUE)  $\geq 70$ kPa $\geq 10.0$ miles  $\leq$ refer to <b>P0442 Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature</b> in Supporting Tables.	Once per trip, during hot soak (up to 2,400 sec.). No more than 2 unsuccessful attempts between completed tests.	Type A, 1 Trips  EWMA  Average run length is 8 to 12 trips under normal condition s  Run length is 3 to 6 trips after code clear or non-volatile reset
			When EWMA is the DTC light is illuminated.  The DTC light can be turned off if the EWMA is and stays below the EWMA fail threshold for 3 additional consecutive trips.	$> 0.59$ (EWMA Fail Threshold),  $\leq 0.35$ (EWMA Re-Pass Threshold)	Time since last complete test if normalized result and EWMA is passing  OR Time since last complete test if normalized result or EWMA is failing  Estimated Ambient Temperature (EAT) using OAT sensor at end of drive  Conditions for Estimated Ambient Temperature Using OAT Sensor to be	$\geq 8$ hours  $\geq 8$ hours  $0^\circ\text{C} \leq \text{Temperature} \leq 35^\circ\text{C}$		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		the pressure drops (-62 ) Pa from peak pressure, the vent is then opened for 60 seconds to normalize the system pressure. The vent is again closed to begin the vacuum portion of the test (phase-2). As the fuel temperature continues to fall, a vacuum will begin forming. The vacuum will continue until it reaches a vacuum peak. When the pressure rises 62 Pa from vacuum peak, the test then completes. If the key is turned on while the diagnostic test is in progress, the test will abort.			Valid ***** 1. Startup OAT is less than previous trip EAT  OR 2. Startup ECT - previous trip EAT  OR 3. Engine off time  OR 4. At startup, time since previous EAT valid and able to learn  OR 5. EAT - current OAT  OR 6. EAT < current OAT and speed timer and current OAT - EAT  Speed timer increments at 100 msec rate and increments vary based on vehicle speed as follows:  vehicle speed < 10 mph - 0.2 seconds 10 mph<speed< 35 mph 0.10 seconds 35 mph<speed< 124 0.20 seconds 124 mph<speed< 124 1.00 seconds  Speed timer can never be less than 0 seconds  ***** 1. High Fuel Volatility  During the volatility	*****   ≤ 0 °C  ≥ 7,200 seconds  ≤ 3,600 seconds  0 °C ≤ difference ≤ 2 °C  ≥ 240 seconds ≤ 2 °C    - 0.2 seconds 0.10 seconds 0.20 seconds 1.00 seconds     *****		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>phase, pressure in the fuel tank is integrated vs. volatility time. If the integrated pressure is then test aborts and unsuccessful attempts is incremented. This value equates to an average integrated fuel tank pressure &gt; 1,245 Pa. Please see <b>P0442 Volatility Time as a Function of Estimate of Ambient Temperature</b> in Supporting Tables.</p> <p>OR</p> <p>2. Vacuum Refueling Detected</p> <p>See P0454 Fault Code for information on vacuum refueling algorithm.</p> <p>OR</p> <p>3. Fuel Level Refueling Detected</p> <p>See P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>4. Vacuum Out of Range and No Refueling</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p>	< -5		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>OR</p> <p>5. Vacuum Out of Range and Refueling Detected</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>6. Vent Valve Override Failed</p> <p>Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test</p> <p>OR</p> <p>7. Key up during EONV test</p> <p>No active DTCs:</p> <p>No Active DTC's TFTKO</p>	<p>0.50 seconds</p> <p>MAF_SensorFA ECT_Sensor_FA IAT_SensorFA VehicleSpeedSensor_FA IgnitionOffTimeValid AmbientAirDefault FuelLevelDataFault</p> <p>P0443 P0446 P0449 P0452 P0453 P0455 P0458 P0459</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P0498 P0499 P0496 P1001 P1005 P11FF P130F U18A2		



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Circuit (ODM)  (No ELCP - Conventional EVAP Diagnostic)	P0443	Controller specific output driver circuit diagnoses the canister purge solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	     ≥ 200 K Ω impedance between output and controller ground.	Powertrain relay voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controlle rs P0458 may also set (Caniste r Purge Solenoid Short to Ground)

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent System Performance  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0446	<p>This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister.</p> <p>This diagnostic runs with normal purge control and canister vent solenoid commanded open. The diagnostic fails when the FTP sensor vacuum measurement is above a vacuum threshold before it accumulates purge volume above a threshold. The diagnostic passes when it accumulates purge volume above a threshold before the FTP sensor vacuum measurement is above a vacuum threshold.</p>	<p>Vent Restriction Prep Test: Vented Vacuum for OR Vented Vacuum for</p> <p>Vent Restriction Test: Tank Vacuum for before Purge Volume</p> <p>After setting the DTC for the first time, 0 liters of fuel must be consumed before setting the DTC for the second time.</p>	<p>&lt; -623 Pa 60 seconds</p> <p>&gt; 1,245 Pa 60 seconds</p> <p>&gt; 2,989 Pa 5 seconds ≥ 6 liters</p>	<p>Fuel Level System Voltage Startup IAT Startup ECT BARO</p> <p>No active DTCs:</p> <p>No Active DTC's TFTKO</p>	<p>10 % ≤ Percent ≤ 90 % ≥ 10.0 volts 4 °C ≤ Temperature ≤ 35 °C ≤ 35 °C ≥ 70 kPa</p> <p>MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited</p> <p>P0443 P0449 P0452 P0453 P0454 P0458 P0459 P0498 P0499 P1001 P1005 P11FF P130F U18A2</p>	<p>Once per Cold Start</p> <p>Time is dependent on driving conditions</p> <p>Maximum time before test abort is 1,400 seconds</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM)  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0449	Controller specific output driver circuit diagnoses the vent solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	$\geq 200\text{ K } \Omega$ impedance between output and controller ground	No active DTCs:	P1005 P130F U18A2	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controlle rs P0498 may also set (Vent Solenoid Short to Ground)

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Performance  (No ELCP - Conventional EVAP Diagnostic)	P0451	<p>The DTC will be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test.</p> <p>During the EONV test, the fuel tank vacuum sensor is re-zeroed. A re-zero occurs:</p> <ol style="list-style-type: none"> <li>1) At the transition from the volatility phase to the pressure phase.</li> <li>2) At the transition from the pressure phase to the vacuum phase.</li> </ol> <p>The re-zero test determines if the tank vacuum signal falls within a calibratable window about atmospheric pressure. If after some time, the tank vacuum signal does not fall to within the window, the re-zero test exits to the refueling rationality test.</p> <p>The refueling rationality test determines if a refueling event caused the re-zero problem. If so, the re-zero problem is ignored. If a refueling event is not</p>	<p>The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts)</p> <p>Upper voltage threshold (voltage addition above the nominal voltage)</p> <p>Lower voltage threshold (voltage subtraction below the nominal voltage)</p> <p>The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail).</p> <p>When EWMA is the DTC light is illuminated.</p> <p>The DTC light can be turned off if the EWMA is and stays below the EWMA fail threshold for 3 additional consecutive trips.</p>	<p>0.2 volts</p> <p>0.2 volts</p> <p>&gt; 0.73 (EWMA Fail Threshold),</p> <p>≤ 0.40 (EWMA Re-Pass Threshold)</p>	This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes		This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.	<p>Type A, 1 Trips</p> <p>EWMA</p> <p>Average run length: 6</p> <p>Run length is 2 trips after code clear or non-volatile reset</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>detected, then the results of the re-zero test are used to determine if there is a re-zero problem.</p> <p>1) An individual re-zero test generates a re-zero ratio. The ratio goes from 0.0 to 1.0.</p> <p>2) A 0.0 means that the re-zero pressure signal achieved exactly atmospheric pressure.</p> <p>3) A ratio of 1.0 means that the re-zero pressure did not get within the window.</p> <p>4) Re-zero pressure within the window generates values between 0.0 and 1.0.</p> <p>If a refueling event is not detected, then the resulting re-zero ratio is filtered using an exponentially weighted moving average (EWMA). When the EWMA exceeds a fail threshold, the vacuum re-zero test reports a failure. Once the vacuum re-zero test fails, the EWMA fall below a lower re-pass threshold before it can pass the vacuum re-zero test again.</p>						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0452	<p>This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too low out of range.</p> <p>The FTP sensor circuit out of range diagnostic compares the raw sensor voltage to a lower voltage threshold. It is an X out of Y diagnostic that runs continuously anytime the controller is awake.</p> <p>If the sensor voltage is below the lower voltage threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported for P0452 DTC. A pass is reported for P0452 DTC if the low sample counter reaches its threshold.</p>	<p>FTP sensor signal</p> <p>The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~3736 Pa).</p>	< 0.15 volts ( 3.0 % of Vref or ~ 1,495 Pa)	No active DTC's:	P1001 P1005 U18A2	<p>640 failures out of 800 samples</p> <p>12.5 ms / sample</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit High Voltage  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0453	<p>This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too high out of range.</p> <p>The FTP sensor circuit out of range diagnostic compares the raw sensor voltage to an upper voltage threshold. It is an X out of Y diagnostic that runs continuously anytime the controller is awake.</p> <p>If the sensor voltage is above the upper voltage threshold, the high fail counter then increments. If the high fail counter reaches its threshold then a fail is reported for P0453 DTC. A pass is reported for P0453 DTC if the high sample counter reaches its threshold.</p>	<p>FTP sensor signal</p> <p>The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~3736 Pa).</p>	> 4.85 volts ( 97.0 % of Vref or ~-3,985 Pa)	No active DTCs:	P1001 P1005 U18A2	<p>640 failures out of 800 samples</p> <p>12.5 ms / sample</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Intermittent  (No ELCP - Conventional EVAP Diagnostic)	P0454	<p>This DTC will detect intermittent tank vacuum sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.</p> <p>During the EONV test, an abrupt change in fuel tank vacuum is identified as a possible refueling event. If the abrupt change occurs while the vent valve is closed, the EONV small-leak test aborts and the refueling rationality test starts.</p> <p>If the refueling rationality test detects a refueling event, then the vacuum change is considered "rational." If the refueling rationality test does not detect a refueling event, then the vacuum change is considered "irrational."</p> <p>The vacuum change rationality diagnostic is an "X out of Y" test.  1) Each time the EONV test completes, the (Y) sample counter is incremented.  2) Each time the</p>	<p>If an abrupt change in tank vacuum is detected the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that a refueling event occurred. If a refueling is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An abrupt change is defined as a change in vacuum in the span of 1.0 seconds. But in 12.5 msec. A refueling event is confirmed if the fuel level has a persistent change of for 30 seconds during a 600 second refueling rationality test.</p>	<p>&gt; 112 Pa</p> <p>&lt; 249 Pa</p> <p>&gt; 15 %</p>	<p>This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes and the canister vent solenoid is closed</p>		<p>This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.</p> <p>12.5 ms / sample</p>	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		rationality test has an irrational result; the (X) fail counter is incremented. 3) If the (X) fail counter reaches the fail limit before the (Y) sample counter reaches the sample limit, the vacuum change rationality test fails. 4) If the (Y) sample counter reaches the limit before the (X) fail counter fails, the vacuum change rationality test passes.						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Large Leak Detected  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0455	<p>This DTC will detect a weak vacuum condition (large leak or purge blockage) in the EVAP system.</p> <p>This mode checks for large leaks and blockages when proper driving conditions are met. If these conditions are met, the diagnostic commands the vent valve closed and controls the purge duty cycle to allow purge flow to purge the fuel tank and canister system while monitoring the fuel tank vacuum level.</p> <p>The algorithm accumulates purge flow during the test to determine a displaced purge volume as the test proceeds.</p> <p>If the displaced purge volume reaches a threshold before the fuel tank vacuum level reaches its passing threshold, then a large leak failure is detected.</p> <p>On fuel systems with fuel caps</p> <p>If the first failure of</p>	<p>Purge volume while Tank vacuum</p> <p>After setting the DTC for the first time, 0 liters of fuel must be consumed before setting the DTC for the second time.</p> <p>Weak Vacuum Follow-up Test (fuel cap replacement test) Weak Vacuum Test failed.</p> <p>Passes if tank vacuum</p> <p>Note: Weak Vacuum Follow-up Test can only report a pass.</p>	<p>&gt; 15 liters</p> <p>≤ 1,993 Pa</p> <p>≥ 1,993 Pa</p>	<p>Fuel Level System Voltage BARO Purge Flow</p> <p>No active DTCs:</p> <p>No Active DTC's TFTKO</p> <p>If ECT &gt; IAT, Startup temperature delta (ECT-IAT): Startup IAT Startup ECT</p> <p>Weak Vacuum Follow-up Test This test can run following a weak vacuum failure or on a hot restart.</p>	<p>10 % ≤ Percent ≤ 90 % ≥ 10.0 volts ≥ 70 kPa ≥ 1.50 %</p> <p>MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited</p> <p>P0443 P0449 P0452 P0453 P0454 P0458 P0459 P0498 P0499 P1001 P1005 P11FF P130F U18A2</p> <p>≤ 8 °C 4 °C≤Temperature≤ 35 °C ≤ 35 °C</p>	<p>Once per cold start</p> <p>Time is dependent on driving conditions</p> <p>Maximum time before test abort is 1,400 seconds</p> <p>Weak Vacuum Follow-up Test</p> <p>With large leak detected, the follow-up test is limited to 0 seconds. Once the MIL is on, the follow-up test runs indefinitely.</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>P0455 occurred after a refueling event was detected and the MIL is off for P0455, the MIL will be commanded off after the first pass of P0455 is reported. If the first failure of P0455 did not occur after a refueling event was detected, the MIL will be commanded off on the ignition cycle after the third consecutive pass of P0455 is reported. the MIL will be commanded off on the ignition cycle after the third consecutive pass of P0455 is reported.</p> <p>On fuel systems without fuel caps</p> <p>The P0455 MIL will be commanded off on the ignition cycle after the third consecutive pass of P0455 is reported.</p>						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit Low  (No ELCP - Conventional EVAP Diagnostic)	P0458	Controller specific output driver circuit diagnoses the canister purge solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	$\leq 0.5 \Omega$ impedance between output and controller ground	Powertrain relay voltage	Voltage $\geq 11.0$ volts	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controllers P0443 may also set (Canister Purge Solenoid Open Circuit)

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit High  (No ELCP - Conventional EVAP Diagnostic)	P0459	Controller specific output driver circuit diagnoses the canister purge solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	$\leq 0.5 \Omega$ impedance between output and controller power	Powertrain relay voltage	Voltage $\geq 11.0$ volts	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Performance  (For use on vehicles with a single fuel tank)	P0461	This DTC will detect a primary fuel tank level sensor stuck in-range.	a) Sensed fuel volume change is b) while engine fuel consumption is	a) < 3 liters  b) ≥ 29.20 liters	1. Diagnostic Enabled  2. Engine Operational State	1. == True  2. == Running	250 ms / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Low Voltage	P0462	This DTC will detect a primary fuel tank sensor out-of-range low.	Fuel level Sender % of 5V range	< 10 % or 27.36 liters	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	100 failures out of 125 samples  100 ms / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit High Voltage	P0463	This DTC will detect a primary fuel tank level sensor out-of-range high.	Fuel level Sender % of 5V range	> 60 % or 2.97 liters	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	100 failures out of 125 samples  100 ms / sample	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Intermittent  (No ELCP - Conventional EVAP Diagnostic)	P0464	<p>This DTC will detect intermittent fuel level sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.</p> <p>During the EONV test, a change in fuel level is identified as a possible refueling event. If the change occurs while the vent valve is closed, the EONV small-leak test aborts and the refueling rationality test starts.</p> <p>If the refueling rationality test detects a refueling event, the fuel level change is considered "rational." If the refueling rationality test does not detect refueling, the fuel level change is considered "irrational."</p> <p>The fuel level change rationality diagnostic is an "X out of Y" test.  1) Each time the EONV test completes, the (Y) sample counter is incremented.  2) Each time the rationality test has an</p>	<p>If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, if a refueling event is not confirmed, then the test sample is considered failing which indicates an intermittent signal problem.</p> <p>An intermittent fuel level signal problem is defined as:</p> <p>The fuel level changes by &gt; 15 % and does not remain for 30 seconds during a 600 second refueling rationality test.</p>	<p>&gt; 15 % &gt; 15 %</p>	<p>This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes</p>		<p>This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.</p> <p>100 ms / sample</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		irrational result; the (X) fail counter is incremented. 3) If the (X) fail counter reaches the fail limit before the (Y) sample counter reaches the sample limit, the fuel level change rationality test fails. 4) If the (Y) sample counter reaches the limit before the (X) fail counter fails, the fuel level change rationality test passes.						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan Speed Low [LIN Bus Electric PWM Fans Only - Internal or External controller]	P0494	Measured actual fan speed is monitored against a calibrated lower acceptable limit for the cooling fan RPM under normal operating conditions. The diagnostic is set when the threshold is crossed. This diagnostic ensures that the fan is not under cooling.	Measured Fan Speed	<= Speed Low Limit [Supporting Table] <b>P0494_LIN_Threshold</b>	a] Diagnostic Enabled b] Configuration calibration for number of fans c] Diagnostic System Disabled d] Battery Voltage In-Range e] LIN Bus based Fan Operation Enabled f] LIN Bus Lost Communication Fault Active g] LIN Bus Continuous Operation Fault Active h] Vehicle Road Speed Validity	a] == 1.00 [True if 1; False if 0] b] >= 1 unit  c] <> True  d] > 11.00 volts  e] == TRUE  f] <> True  g] <> True  h] == TRUE	16.00 failures / 20.00 samples;  1000 millisec / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan Speed High [LIN Bus Electric PWM Fans Only - Internal or External controller]	P0495	Measured actual fan speed is monitored against a calibrated upper acceptable limit for the cooling fan RPM under normal operating conditions. Excepting any higher fan speeds caused by the wind-milling of the fan by ram airflow, then the diagnostic is set when the threshold is crossed. This diagnostic ensures that the fan is not over cooling.	Measured Fan Speed	>= Speed High Limit [Supporting Table] <b>P0495_LIN_Threshold</b> <b>d</b>	a] Diagnostic Enabled b] Configuration calibration for number of fans c] Diagnostic System Disabled d] Battery Voltage In Range e] LIN Bus based Fan Operation Enabled f] LIN Bus Lost Communication Fault Active g] LIN Bus Continuous Operation Fault Active h] Vehicle Road Speed data is valid	a] == 0.00 [True if 1; False if 0] b] >= 1 unit  c] <> True  d] > 11.00 volts  e] == TRUE  f] <> True  g] <> True  h] == TRUE	16.00 failures / 20.00 samples;  1000 millisec / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Flow During Non- Purge  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0496	<p>This DTC will determine if the purge solenoid is leaking to engine manifold vacuum.</p> <p>This test checks for purge valve leaks to intake manifold vacuum such that there would always be a small amount of purge flow present. It does this by sealing the EVAP system (purge and vent valve closed) and then monitors fuel tank vacuum level. The fuel tank vacuum level should not increase. If tank vacuum increases above a threshold, a malfunction is indicated.</p> <p>Additional Information</p> <p>This diagnostic test detects purge valve leaks to intake manifold vacuum. It is not intended to detect purge valve leaks to the atmosphere which are monitored by the EONV small leak diagnostic (P0442).</p> <p>The purge valve leak diagnostic exists to help service replace</p>	<p>Tank Vacuum for</p> <p>Test time</p>	<p>&gt; 2,491 Pa 5 seconds</p> <p>≤ refer to <b>P0496 Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level</b> in Supporting Tables.</p> <p>Test time only increments when engine vacuum ≥ 10.0 kPa.</p>	<p>Fuel Level System Voltage BARO Startup IAT</p> <p>Startup ECT Engine Off Time</p> <p>No active DTCs:</p> <p>No Active DTC's TFTKO</p>	<p>10 % ≤ Percent ≤ 90 % ≥ 10.0 volts ≥ 70 kPa 4 °C ≤ Temperature ≤ 35 °C</p> <p>≤ 35 °C ≥ 28,800.0 seconds</p> <p>MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited</p> <p>P0443 P0449 P0452 P0453 P0454 P0458 P0459 P0498 P0499 P1001 P1005 P11FF P130F U18A2</p>	<p>Once per cold start</p> <p>Cold start: max time is 1,400 seconds</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		leaking purge valves that could otherwise be detected with the EONV small leak diagnostic (P0442).						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit Low  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0498	Controller specific output driver circuit diagnoses the vent solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	$\leq 0.5 \Omega$ impedance between output and controller ground	No active DTC's:	P1005 P130F U18A2	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips  Note: In certain controlle rs P0449 may also set (Vent Solenoid Open Circuit)

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit High  (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0499	Controller specific output driver circuit diagnoses the vent solenoid low sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.  If the P0499 is active, an intrusive test is performed with the vent solenoid commanded closed for 15 seconds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	$\leq 0.5 \Omega$ impedance between output and controller power	No active DTC's:	P1005 P130F U18A2	20 failures out of 25 samples  250 ms / sample	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Low Engine Speed Idle System	P0506	This DTC indicates that actual engine speed is lower than desired engine speed at idle so that it is out of speed control capability. Testing is performed when basic conditions are met. If filtered engine speed error exceeds a calibrated threshold for a calibrated duration, code is set. This testing is performed continuously per trip if basic conditions are met	Filtered Engine Speed Error. It is calculated with a calibrated filter coefficient  Filter coefficient	> 95.00 rpm  0.00375	Baro  Coolant Temp  Engine run time Ignition voltage Time since gear change  Time since a TCC mode change  IAT Vehicle speed Commanded RPM delta Idle time  For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa  > 60 °C  ≥ 60 sec 32 ≥ volts ≥ 11 ≥ 3 sec  > 3 sec  > -20 °C ≤ 1.24 mph, 2kph ≤ 25 rpm > 10 sec  > 88.00 pct < 16.00 pct  PTO not active  Transfer Case not in 4WD LowState	Diagnostic runs in every 12.5 ms loop  Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	<p>Off-vehicle device control (service bay control) must not be active.</p> <p>following conditions not TRUE:            (VeTESR_e_EngSpdReqIntvType =            CeTESR_e_EngSpdMinLimit AND            VeTESR_e_EngSpdReqRespType =            CeTESR_e_NoSuggestion)</p> <p>Clutch is not depressed</p> <p>TC_BoostPresSnsrFA            ECT_Sensor_FA            EnginePowerLimited            EGRValveCircuit_FA            EGRValvePerformance_FA            IAT_SensorCircuitFA            EvapFlowDuringNonPurge_FA            FuelTrimSystemB1_FA            FuelTrimSystemB2_FA            FuelInjectorCircuit_FA            MAF_SensorFA            EngineMisfireDetected_FA            IgnitionOutputDriver_FA            TPS_FA            TPS_Performance_FA            VehicleSpeedSensor_FA            FuelLevelDataFault            LowFuelConditionDiagnostic            Clutch Sensor FA            AmbPresDfltStatus</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	P2771  > 10 sec  The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Engine Speed Idle System	P0507	This DTC indicates that actual engine speed is higher than desired engine speed at idle so that it is out of speed control capability. Testing is performed when basic conditions are met. If filtered engine speed error exceeds a calibrated threshold for a calibrated duration, code is set. This testing is performed continuously per trip if basic conditions are met	Filtered Engine Speed Error. It is calculated with a calibrated filter coefficient  Filter coefficient	< -190.00 rpm  0.00375	Baro  Coolant Temp  Engine run time Ignition voltage Time since gear change Time since a TCC mode change  IAT Vehicle speed Commanded RPM delta  For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa  > 60 °C  ≥ 60 sec 32 ≥ volts ≥ 11 ≥ 3 sec > 3 sec  > -20 °C ≤ 1.24 mph, 2kph ≤ 25 rpm  PTO not active  Transfer Case not in 4WD LowState  Off-vehicle device control (service bay control) must not be active.	Diagnostic runs in every 12.5 ms loop  Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	<p>following conditions not TRUE:            (VeTESR_e_EngSpdReqI            ntvType =            CeTESR_e_EngSpdMinLi            mit AND            VeTESR_e_EngSpdReqR            espType =            CeTESR_e_NoSuggestio            n)</p> <p>Clutch is not depressed</p> <p>TC_BoostPresSnsrFA            ECT_Sensor_FA            EnginePowerLimited            EGRValveCircuit_FA            EGRValvePerformance_F            A            IAT_SensorCircuitFA            EvapFlowDuringNonPurg            e_FA            FuelTrimSystemB1_FA            FuelTrimSystemB2_FA            FuelInjectorCircuit_FA            MAF_SensorFA            EngineMisfireDetected_F            A            IgnitionOutputDriver_FA            TPS_FA            TPS_Performance_FA            VehicleSpeedSensor_FA            FuelLevelDataFaultLow            FuelConditionDiagnostic            Clutch_SensorFA            AmbPresDfltStatus            P2771</p>		
					All of the above met	> 10 sec		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					for Idle time	The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Rough Idle	P050D	Monitors the combustion performance when the cold start emission reduction strategy is active by accumulating and determining the percentage of engine cycles that have less than complete combustion relative to the total number of engine cycles in which Dual Pulse is active.	<p>Deceleration index vs. Engine Speed Vs Engine load</p> <p>Deceleration index calculation is tailored to specific vehicle. Tables used are 1st tables encountered that are not max of range. Undetectable region at a given speed/load point is where all tables are max of range point.</p> <p>Incomplete combustion identified by P0300 threshold tables:</p>	<p>(&gt;Idle SCD AND &gt;Idle SCD ddt Tables) OR (&gt;Idle Cyl Mode AND &gt; Idle Cyl Mode ddt Tables)</p>	<p>Misfire Algorithm Enabled (Refer to P0300 for Enablement Requirements)</p> <p>OBD Manufacturer Enable Counter</p> <p>To enable the diagnostic, the Cold Start Emission Reduction Strategy Must Be Active per the following:</p> <p>Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure</p> <p>In addition, Dual Pulse Strategy Is Enabled and Active Per the following:</p> <p>Engine Speed</p> <p>Accel Position</p> <p>Engine Run Time</p> <p>For the engine speeds and loads in which Dual Pulse is active:</p>	<p>= 0</p> <p>&lt; 300.00 degC &gt; -12.00 degC &lt;= 66.00 degC &gt;= 72.00 KPa</p> <p>&gt;= 300.00 RPM &lt;= 2,600.00 RPM</p> <p>&lt;= 25.00 Pct</p> <p>&lt; 83 seconds</p>	<p>Runs once per trip when the cold start emission reduction strategy is active and Dual Pulse is enabled and active.</p> <p>Frequency: 100ms</p> <p>Test completes after Dual Pulse is no longer active OR The first 500 engine cycles have been reached</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Dual Pulse Error induced misfires percentage</p> <p>Dual Pulse Error induced misfires percentage</p> <p>Engine Cycles</p> <p>The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:</p> <p>Catalyst Temperature AND Engine Run Time</p> <p>OR</p> <p>Engine Run Time</p> <p>OR</p> <p>Barometric Pressure</p>	<p>&gt;= catalyst damaging misfire</p> <p>&lt; 90% of the maximum achievable catalyst damaging misfire.</p> <p>&gt;= 50 &lt; 501</p> <p>&gt;= 800.00 degC &gt;= 33.00 seconds</p> <p>&gt; <b>P050D_P1400_CatalystLightOffExtendedEngineRunTimeExit</b></p> <p>This Extended Engine run time exit table is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.</p> <p>&lt; 72.00 KPa</p>		



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Dual Pulse Strategy will exit per the following:</p> <p>Engine Speed OR Accel Position</p> <p>Engine Run Time</p> <p>Dual Pulse Strategy will also exit if the any of the "Additional Dual Pulse Enabling Criteria" is not satisfied:</p> <p>"Additional Dual Pulse Enabling Criteria":</p> <p>Green Engine Enrichment</p> <p>Misfire Converter Protection strategy</p> <p>Engine Metal Overtemp strategy</p> <p>Fuel control state</p> <p>Output State Control</p> <p>DOD Or DFCO</p> <p>Power Enrichment</p> <p>Dynamic Power Enrichment</p> <p>Piston Protection</p> <p>Hot Coolant Enrichment</p>	<p>&gt; 2,800.00 RPM</p> <p>&gt; 30.00 Pct</p> <p>&gt;= 83 seconds</p> <p>Not Enabled</p> <p>Not being requested</p> <p>Not being requested</p> <p>Open Loop</p> <p>Not being requested for fuel</p> <p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>Not Active</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Injector Flow Test  General Enable  DTC's Not Set:	Not Active   AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFA CrankSensor_FA FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA AnyCamPhaser_TFTKO ClutchPstnSnsr FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA FuelInjectorCircuit_TFTK O FHPR_b_FRP_SnsrCkt_F A FHPR_b_FRP_SnsrCkt_T FTKO FHPR_b_PumpCkt_FA FHPR_b_PumpCkt_TFTK O TransmissionEngagedStat e_FA EngineTorqueEstInaccura te FuelPumpRlyCktFA		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Assist Vacuum Too Low	P050F	Monitors for a brake booster vacuum leak	<p>Brake booster vacuum drift ratio (EWMA) reaches the fail threshold (based on engine running condition) before the sample count threshold is reached, a failure is reported.</p> <p>Engine Running Fail Threshold based on prior diagnostic state (description below)</p> <p>Diagnostic failed prior loop</p> <p>Diagnostic passed prior loop</p> <p>Before the sample counts</p> <p>Engine Stopped Fail Threshold based on prior diagnostic state (description below)</p> <p>Diagnostic failed prior loop</p> <p>Diagnostic passed prior loop</p> <p>Before the sample counts</p>	<p><math>\geq 0.60</math></p> <p><math>\geq 0.65</math></p> <p><math>&gt; 0.00</math> counts</p> <p><math>\geq 3.20</math></p> <p><math>\geq 3.30</math></p> <p><math>&gt; 0.00</math> counts</p>	<p>Diagnostic is enabled</p> <p>and the following conditions are met for engine run conditions:</p> <p>No brake booster vacuum sensor faults active</p> <p>No brake pedal position sensor faults active</p> <p>Brake pedal travel is</p> <p>No mass air flow faults</p> <p>No manifold air pressure faults</p> <p>Mass air flow estimate</p> <p>Manifold air pressure</p> <p>Engine vacuum stability time has reached</p> <p>Difference between brake booster vacuum and manifold air pressure is</p> <p>OR</p> <p>Diagnostic is enabled for the following engine auto off conditions:</p>	<p>Enabled</p> <p><math>&lt; 8.00</math> percent - 5.00 percent offset</p> <p><math>\geq 6.00</math> grams / second</p> <p><math>\leq 20.00</math> kPa</p> <p><math>\geq 0.70</math> seconds</p> <p><math>&gt; 10.00</math> kPa</p> <p>Enabled</p>	<p>Performed every 100 msecond</p> <p>Minimum time to pass:</p> <p>Engine Running 0.00 second</p> <p>Engine Stopped 0.00 second</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No brake booster vacuum sensor faults active  No brake pedal position sensor faults active  Brake pedal travel is  No engine movement detected  Engine is in AutoStop mode  OR  Diagnostic is enabled for the following key off conditions:  No brake booster vacuum sensor faults active  No brake pedal position sensor faults active  Brake pedal travel is  No engine movement detected  Engine is in KeyStop mode	< 8.00 percent - 5.00 percent offset          Disabled          < 8.00 percent - 5.00 percent offset		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Performance - Two Stage Oil Pump	P0521	<p>Determines if the Engine Oil Pressure (EOP) Sensor is stuck or biased in range. The engine oil pressure is compared against thresholds when engine is running and when engine is off. The engine oil pressure rationality diagnostic has two parts: engine running test and engine off test.</p> <p>The engine running test compares the measured oil pressure to threshold. If the measured oil pressure is out of the thresholds, then the error counter increments. The engine off test compares the measured oil pressure against thresholds after the engine has stopped rotating. If the measured oil pressure is out of the thresholds, then the error counter increments.</p>	<p><b>Two Stage Oil Pump EOP Sensor Test with Engine Running, High Pressure State</b></p> <p><u>To Fail when previously passing with the engine running:</u></p> <p>Filtered Engine Oil Pressure below expected threshold</p> <p>OR</p> <p>Filtered Engine Oil Pressure above expected threshold</p> <p><u>To pass when previously failing:</u></p> <p>Filtered Engine Oil Pressure above low threshold plus an offset</p> <p>OR</p>	<p>Filtered Oil Pressure &lt; ( <b>P0521_P06DD_P06D E_OP_HiStatePressure</b> * 1.00 - 133.0 kPa)</p> <p>OR</p> <p>Filtered Oil Pressure &gt; ( <b>P0521_P06DD_P06D E_OP_HiStatePressure</b> * 1.00 + 133.0 kPa)</p> <p>OR</p> <p>Filtered Oil Pressure &lt; (</p>	<p>Two Stage Oil Pump is Present = TRUE</p> <p>Pump is in high pressure state</p> <p>Engine Running Diagnostic Status</p> <p>Engine Off Rationality Test Diagnostic Reporting Status</p> <p>Oil Pressure Sensor In Use</p> <p>Engine Running</p> <p>Ambient Air Pressure</p> <p>Oil Aeration (= TRUE if engine speed &gt; 5,000 RPM for longer than 30.0 seconds)</p> <p>Filtered Engine Speed within range</p> <p>Modelled Oil Temperature within range</p> <p>Pump state change complete</p> <p>No active DTC's</p>	<p>TRUE</p> <p>Enabled</p> <p>Test not report a fail state</p> <p>Yes</p> <p>≥ 20.0 seconds</p> <p>≥ 70.0 kPa</p> <p>FALSE</p> <p>1,500 RPM ≤ Filtered Engine Speed ≤ 4,000 RPM</p> <p>40.0 deg C ≤ Oil Temp ≤ 120.0 deg C</p> <p>Time since state change &gt; 0.50 s</p> <p>Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA EngOilPressureSensorCkt FA AmbientAirDefault</p>	<p>≥ 40 errors out of 50 samples.</p> <p>Performed every 100 msec</p> <p>≥ 10 passes out of 50 samples.</p> <p>Performed every 100 msec</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Engine Oil Pressure below high threshold minus an offset	<b>P0521_P06DD_P06DE_OP_HiStatePressure</b> * 1.00 + 133.0 kPa - 10.0 kPa)  (Details on Supporting Tables Tab: <b>P0521_P06DD_P06DE_OP_HiStatePressure</b> )		EngOilTempFA CrankSensor_FA		
			<b>Two Stage Oil Pump EOP Sensor Test with Engine Running, Low Pressure State</b>  <u>To Fail when previously passing with the engine running:</u>  Filtered Engine Oil Pressure below expected threshold  OR  Filtered Engine Oil Pressure above expected threshold	Filtered Oil Pressure < ( <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> * 1.00 - 133.0 kPa)  OR  Filtered Oil Pressure > ( <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> * 1.00 + 133.0 kPa)	Two Stage Oil Pump is Present = TRUE  Pump is in low pressure state  Engine Running Diagnostic Status  Engine Off Rationality Test Diagnostic Reporting Status  Oil Pressure Sensor In Use  Engine Running  Ambient Air Pressure  Oil Aeration (= TRUE if engine speed > 5,000 RPM for longer than 30.0 seconds)  Filtered Engine Speed within range	TRUE  Enabled  Test not report a fail state  Yes  ≥ 20.0 seconds  ≥ 70.0 kPa  FALSE  1,500 RPM ≤ Filtered Engine Speed ≤ 4,000 RPM	≥ 40 errors out of 50 samples.  Performed every 100 msec	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p><u>To pass when previously failing:</u></p> <p>Filtered Engine Oil Pressure above low threshold plus an offset</p> <p>OR</p> <p>Filtered Engine Oil Pressure below high threshold minus an offset</p>	<p>Filtered Oil Pressure &gt; ( <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> * 1.00 - 133.0 kPa + 10.0 kPa)</p> <p>OR</p> <p>Filtered Oil Pressure &lt; ( <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> * 1.00 + 133.0 kPa - 10.0 kPa)</p> <p>(Details on Supporting Tables Tab: <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> )</p>	<p>Modelled Oil Temperature within range</p> <p>Pump state change complete</p> <p>No active DTC's</p>	<p>40.0 deg C ≤ Oil Temp ≤ 120.0 deg C</p> <p>Time since state change &gt; 0.50 s</p> <p>Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA EngOilPressureSensorCktFA AmbientAirDefault EngOilTempFA CrankSensor_FA</p>	<p>≥ 10 passes out of 50 samples.</p> <p>Performed every 100 msec</p>	
			<p><b>Two Stage Oil Pump EOP Sensor Test with Engine Off</b></p> <p>If enabled:</p> <p><u>To Fail when previously passing with the engine off:</u></p> <p>Filtered Engine Oil Pressure greater than threshold</p>	<p>Filtered Oil Pressure ≥ 40.0 kPa</p>	<p>Two Stage Oil Pump is Present = TRUE</p> <p>Engine Off Rationality Test Diagnostic Status</p> <p>Engine Running Rationality Test Diagnostic Status</p> <p>Modelled Oil Temperature No Engine Movement No active DTC's</p>	<p>TRUE</p> <p>Enabled</p> <p>Test not report a fail state</p> <p>≥ 70.0 deg C &gt; 4.0 seconds EngineModeNotRunTimer_FA EngOilTempFA</p>	<p>≥ 20 errors out of 40 samples.</p> <p>Run once per trip</p>	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngOilPressureSensorCkt FA CrankSensor_FA		



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Circuit Low Voltage	P0522	Determines if the Engine Oil Pressure (EOP) Sensor circuit voltage is too low. This diagnostic compares the EOP circuit voltage to the reference voltage.	(Engine Oil Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	< 5.00 percent  Deadband: < 5 percent or > 95 percent	Engine Speed Enable Engine Speed Disable  Oil Pressure Sensor In Use  Diagnostic Status	> 400 rpm < 350 rpm  Yes  Enabled	1,280 failures out of 1,600 samples  Performed every 6.25 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Circuit High Voltage	P0523	Determines if the Engine Oil Pressure (EOP) Sensor circuit voltage is too high. This diagnostic compares the EOP circuit voltage to the reference voltage.	(Engine Oil Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	<p>&gt; 95.00 percent</p> <p>Deadband: &lt; 5 percent or &gt; 95 percent</p>	<p>Oil Pressure Sensor In Use</p> <p>Diagnostic Status</p>	<p>Yes</p> <p>Enabled</p>	1,280 failures out of 1,600 samples Performed every 6.25 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Air Conditioning High Side Pressure Sensor (HSPS) Circuit Low Voltage	P0532	Determines if the Air Conditioning High Side Pressure Sensor circuit voltage is too low	(AC High Side Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	< 3 percent	AC HSP Sensor Present  Diagnostic Status	Yes  Enabled	80 failures out of 100 samples  Performed every 25 msec	Type C, No SVS

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Air Conditioning High Side Pressure Sensor (HSPS) Circuit High Voltage	P0533	Determines if the Air Conditioning High Side Pressure Sensor circuit voltage is too high	(AC High Side Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	> 95 percent	AC HSP Sensor Present  Diagnostic Status	Yes  Enabled	80 failures out of 100 samples  Performed every 25 msec	Type C, No SVS

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Booster Pressure Sensor Performance	P0556	Determines if the Brake Booster Vacuum Sensor is stuck or skewed within the normal operating range by comparing the engine vacuum to the brake booster vacuum when the engine is producing a large amount of vacuum	Engine vs brake booster vacuum sensor values are compared when % throttle < value for a time period. When throttle once again > calibrated value, min and max vacuum sensor values are normalized and subtracted from a 1st order lag filter value of 1. A properly operating vacuum sensor would have a normalized result of 1 or greater. If the normalized result is greater than 1 it is considered 1. The 1st order lag filter value would be 0 in a passing system.		Diagnostic enabled/ disabled  Type of vacuum source: CeBBVI_e_ManifoldVacu um  With a manifold vacuum source:  Throttle Area (with idle included) for time period of  Difference in Brake Booster Vacuum  For time period of AND Vacuum Delta  Diagnostic enabled/ disabled  No active DTC's  With a mechanical pump vacuum source:  No active DTC's  P057B  P057C	Enabled    ≤ 5.0 Percent for > 3.0 seconds  > 0.3 kPa  ≥ 0.2 Seconds ≥ 15.0 kPa  Enabled  Fault bundles: MAP_SensorFA TPS_FA BrakeBoosterSensorCktF A  Fault bundles: BrakeBoosterSensorCktF A  Not Active on Current Key Cycle  Not Active on Current Key	Pass counter incremented when enable conditions are met, pass achieved when counter ≥ 7  Performed every 100 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P057D  P057E  Brake pedal position  Engine mode  Difference in Brake Booster Vacuum  For time period of AND Unfiltered normalized value of measured brake booster vacuum	Cycle  Not Active on Current Key Cycle  Not Active on Current Key Cycle  <= 7.0 Percent for > 3.0 seconds  = Run for > 3.0 seconds  >= 0.3 kPa  >= 0.2 Seconds  <= <b>P0556_BBVS_VacLowFI ow</b> kPa (see supporting table)		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Booster Pressure Sensor Circuit Low Voltage	P0557	Determines if the Brake Booster Pressure Sensor circuit voltage is too low	(Brake Booster Pressure Sensor Voltage) ÷ 5 Volts *100	< 5.00 percent	Brake booster diagnostic enabled/disabled  Brake booster pressure sensor present	Enabled  Present	320 failures out of 400 samples  Performed every 12.5 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Booster Pressure Sensor Circuit High Voltage	P0558	Determines if the Brake Booster Pressure Sensor circuit voltage is too high	(Brake Booster Pressure Sensor Voltage) ÷ 5 Volts *100	> 95.00 percent	Brake booster diagnostic enabled/disabled  Brake booster pressure sensor present	Enabled  Present	2,000 failures out of 2,400 samples  Performed every 12.5 msec	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage Performance	P0561	Detects a low performing 12V battery system. This diagnostic reports the DTC when the absolute value of the difference between the battery voltage and the run/ crank voltage exceeds a calibrated value.	Run Crank voltage low and high	ABS(Battery voltage - Run Crank voltage) > 3.00	Battery voltage B+ line present = TRUE  Battery voltage low and high diag enable = TRUE  Run Crank voltage	1.00  1.00  Voltage ≥ 5.00 volts	50 failures out of 63 samples  100 ms / sample	Type C, No SVS

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage Low	P0562	Detects a low 12V battery system. This diagnostic reports the DTC when battery voltage is low. Monitoring occurs when the engine speed is above a calibrated value.	System voltage low	Battery voltage <= 9.00	System voltage low diag enable = TRUE  Run Crank voltage  Engine speed >=	1.00  Voltage ≥ 5.00 volts  400.00	400 failures out of 500 samples  12.5 ms / sample	Type C, No SVS

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage High	P0563	Detects a high 12V battery system. This diagnostic reports the DTC when battery voltage is high.	System voltage high	Battery voltage >= 18.00	System voltage high diag enable = TRUE	1.00	400 failures out of 500 samples	Type C, No SVS
					Run Crank voltage	Voltage ≥ 5.00 volts	12.5 ms / sample	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- Function Switch Circuit	P0564	<p>Detect when cruise control multi-function switch circuit (analog) voltage is in an invalid range.</p> <p>"Emissions Neutral Default Action : When the BCM tells the ECM that the cruise control analog input voltage is in an invalid range, ECM sets the code and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."Detect when cruise control multi-function switch circuit (analog) voltage is in an invalid range</p>	Cruise Control analog circuit voltage must be "between ranges" for greater than a calibratable period of time.	<p>The cruise control analog voltage A/D count ratio is considered to be "between ranges" when the ratio is measured in the following ranges:</p> <p>0.28 -0.31, 0.415-0.445, 0.585 - 0.615 0.78 - 0.81, 1.005 - 1.035</p>	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 0.500 seconds	<p>Type C, No SVS</p> <p>"Emissions Neutral Diagnostics – special type C"</p> <p>"Neutral Default State - When the BCM tells the ECM that the cruise control analog input voltage is in an invalid range, ECM sets the code and cruise control is disabled"</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control On Switch Circuit	P0565	<p>Detects a failure of the cruise on/off switch in a continuously applied state</p> <p>"Emissions Neutral Default Action - When the BCM tells the ECM that the cruise control analog input voltage is in the Momentary Cruise On/Off range for too long, the code is set and cruise control is disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails." Only applicable for vehicles with a momentary on/off cruise switch architecture.</p>	Cruise Control On switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 20.00 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Resume Circuit	P0567	<p>Detects a failure of the cruise resume switch in a continously applied state</p> <p>"Emissions Neutral Default Action : When the BCM tells the ECM that the cruise control analog input voltage is in the Resume range for too long, the code is set and cruise control is disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."</p>	Cruise Control Resume switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 89.000 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Set Circuit	P0568	<p>Detects a failure of the cruise set switch in a continuously applied state</p> <p>"Emissions Neutral Default Action : When the BCM tells the ECM that the cruise control analog input voltage is in the Set range for too long, the code is set and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."</p>	Cruise Control Set switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 89.000 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Cancel Switch Circuit	P056C	<p>Detects a failure of the cruise cancel switch in a continuously applied state</p> <p>"Emissions Neutral Default Action : When the BCM tells the ECM that the cruise control analog input voltage is in the Cancel range for too long, ECM sets the code and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."</p>	Cruise Control Cancel switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 20.00 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Input Circuit	P0575	Determines if cruise switch state received from the BCM is valid.  "Emissions Neutral Default Action : When the ECM determines that a serial communication fault from the BCM has occurred with frame \$1E1, ECM sets the code and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."	If x of y rolling count / protection value faults occur, disable cruise for duration of fault	Message <> 2's complement of message          Message rolling count<>previous message rolling count value plus one	Cruise Control Switch Serial Data Error Diagnostic Enable  Serial communication to BCM  Power Mode Engine Running	1.00   No loss of communication  = RUN = TRUE	9 failures out of / 17 samples  Performed on every received message     9 rolling count failures out of / 17 samples  Performed on every received messagw	Type C, No SVS , "Emissio ns Neutral Diagnost ics – special type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Range/ Performance	P057B	This diagnostic monitors the Brake Pedal Position Sensor for a stuck in range failure	.Brake pedal position sensor movement diagnostic cal is enabled 1.00	True	Brake Pedal Position Sensor Circuit Range / Performance Diagnostic Enable	1.00  ignition voltage > 10.00		MIL: Type A, 1 Trips
			Calculated EWMA value must be greater than calibratable threshold after calibratable number of tests have completed to report a "test passed" for P057B	EWMA value looked up in supporting table <b>P057B</b> <b>KtBRKI_K_FastTestP</b> <b>ointWeight</b> P057B as a function of calculated brake pedal position delta EWMA value is > 0.80	calculated brake pedal position delta sample counter > 50.00 for fast test  OR  calculated brake pedal position delta sample counter > 1,000.00 for slow test	calculated brake pedal position delta > 4.70  OR (for slow test)  shift lever has been in park once this key cycle  vehicle speed >= 5.00  accelerator pedal position < 5.00	total number of EWMA tests > 20.00	
			Calculated EWMA Value must be less than calibratable threshold after calibratable number of tests have completed to report a "test failed" for P057B. This test runs once per key cycle	EWMA value looked up in supporting table <b>P057B</b> <b>KtBRKI_K_CmpltTest</b> <b>PointWeight</b> P057B as a function of calculated brake pedal position delta EWMA value is less than 0.40	no DTC's active (P057C, P057D)	shift lever has been in park once this key cycle  vehicle speed >= 5.00  accelerator pedal position < 5.00	total number of EWMA tests > 2.00	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Low	P057C	detects short to ground for brake pedal position sensor	If x of y samples are observed below failure threshold, default brake pedal position to zero percent.	5.00	Brake Pedal Position Sensore Low Voltage Diagnostic Enable	1.00	20 / 32.00 counts	MIL: Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit High	P057D	detects open circuit for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	95.00	Brake Pedal Position Sensore High Voltage Diagnostic Enable	1.00	20.00 / 32.00 counts	MIL: Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Intermittent/ Erratic	P057E	detects noisy / erratic output for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	15.00	Brake Pedal Position Sensor Circuit Intermittent / Erratic Diagnostic Enable	1.00	5.00 /  20.00 counts	MIL: Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- function Circuit Low Voltage	P0580	detects short to ground failure for cruise multi-function switch circuit  "Emissions Neutral Default Action : When the BCM tells the ECM that the cruise switch circuit voltage is too low for too long, ECM sets the code and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails." Only applicable for vehicles with a momentary on/off cruise switch architecture.	Cruise Control analog circuit voltage must be in an "Open Short To Ground" range for greater than a calibratable period of time.	The cruise control analog voltage A/D count ratio is considered to be "open short to ground" when the ratio is measured in the following ranges:  0 - 0.185	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi- function Circuit High Voltage	P0581	detects short to power failure for cruise multi-function switch circuit  "Emissions Neutral Default Action : When the BCM tells the ECM that the cruise switch circuit voltage is too high for too long, ECM sets the code and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails." Only applicable for vehicles with a momentary on/off cruise switch architecture.	Cruise Control analog circuit voltage must be in "Short To Power" range for greater than a calibratable period of time.	The cruise control analog voltage A/D count ratio is considered to be "short to power" when the ratio is measured in the following range:  1.005 - 1.035	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Performance	P058A	This DTC monitors for a battery module internal fault	Battery Module signals an internal fault via LIN bus  VeVITR_e_IBS_InternalFault	= CeVITR_e_DiagFailed	The diagnostic is enabled  System Diagnostics Disabled  Power Mode  12V System Reference Voltage  LIN Bus Off or Battery Module Communication Faults Active  Outside Air Temperature  Outside Air Temperature Validity Bit	= 1 (1 indicates enabled)  = False  Not equal off  > 9.00 Volts  = False  > -20.00 Celsius and < 50.00 Celsius  = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Current Monitoring Performance	P058B	This DTC monitors for a battery module current fault	Battery Module signals an internal fault via LIN bus  VeVITR_e_BatCurrRatDia g	= CeVITR_e_DiagFailed	The diagnostic is enabled  System Diagnostics Disabled  Power Mode  12V System Reference Voltage  LIN Bus Off or Battery Module Communication Faults Active  Outside Air Temperature  Outside Air Temperature Validity Bit	= 1 (1 indicates enabled)  = False  Not equal off  > 9.00 Volts  = False  > -20.00 Celsius and < 50.00 Celsius  = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Temperature Monitoring Performance	P058C	This DTC monitors for a battery module temperature fault	Difference between Battery Module raw temperature values	> 10.00 Celsius	The historical mode diagnostic is enabled and / or The continuous mode diagnostic is enabled  System Diagnostics Disabled  Power Mode  12V System Reference Voltage  LIN Bus Off or Battery Module Communication Faults Active  Outside Air Temperature  Outside Air Temperature Validity Bit  For Historical Mode IBS Down Counter (over LIN bus) For Continuous Mode IBS Down Counter (over LIN bus)  IBS Temperature Data Available over LIN bus  Internal Temperature Circuit Low Fault Active (P16DE)  Internal Temperature	= 1 (1 indicates enabled)  = 1 (1 indicates enabled)  = False  Not equal off  > 9.00 Volts  = False  > -20.00 Celsius and < 50.00 Celsius  = True  Between 1 and 24  = Zero  = True  = False	8 failed samples within 10 total samples  Diagnostic runs in the 250 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Circuit High Fault Active (P16DF)  Battery Module Temperature Too High Fault Active (P058E)  Battery Module Temperature Too Low Fault Active (P058F)	= False  = False  = False		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Voltage Monitoring Performance	P058D	This DTC monitors for a battery module voltage fault	Difference between 12V System Reference Voltage and IBS 12V Battery Voltage values	> 5.00 Volts	The diagnostic is enabled  System Diagnostics Disabled  Power Mode  12V System Reference Voltage  LIN Bus Off or Battery Module Communication Faults Active  Outside Air Temperature  Outside Air Temperature Validity Bit  IBS Voltage and Current Data Available over LIN bus  Battery Monitor Module Circuit Low Voltage Fault Active (P16D4)  Battery Monitor Module Circuit High Voltage Fault Active (P16D5)	= 1 (1 indicates enabled)  = False  Not equal off  > 9.00 Volts  = False  > -20.00 Celsius and < 50.00 Celsius  = True  = True  = False  = False	32 failed samples within 40 total samples  Diagnostic runs in the 250 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Temperature Too High	P058E	This DTC monitors for a battery module temperature too high fault	Battery Module raw temperature 2 value	> 120.00 Celsius	<p>The historical mode diagnostic is enabled and / or The continuous mode diagnostic is enabled</p> <p>System Diagnostics Disabled</p> <p>Power Mode</p> <p>12V System Reference Voltage</p> <p>LIN Bus Off or Battery Module Communication Faults Active</p> <p>Outside Air Temperature</p> <p>Outside Air Temperature Validity Bit</p> <p>For Historical Mode IBS Down Counter (over LIN bus) For Continuous Mode IBS Down Counter (over LIN bus)</p> <p>IBS Measure Temperature Data Available over LIN bus</p>	<p>= 1 (1 indicates enabled)</p> <p>= 1 (1 indicates enabled)</p> <p>= False</p> <p>Not equal off</p> <p>&gt; 9.00 Volts</p> <p>= False</p> <p>&gt; -20.00 Celsius and &lt; 50.00 Celsius</p> <p>= True</p> <p>Between 1 and 24</p> <p>= zero</p> <p>= True</p>	<p>4 failed samples within 5 total samples</p> <p>Diagnostic runs in the 250 ms loop</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Temperature Too Low	P058F	This DTC monitors for a battery module temperature too low fault	Battery Module raw temperature 2 value	< -43.00 Celsius	<p>The historical mode diagnostic is enabled and / or The continuous mode diagnostic is enabled</p> <p>System Diagnostics Disabled</p> <p>Power Mode</p> <p>12V System Reference Voltage</p> <p>LIN Bus Off or Battery Module Communication Faults Active</p> <p>Outside Air Temperature</p> <p>Outside Air Temperature Validity Bit</p> <p>For Historical Mode IBS Down Counter (over LIN bus) For Continuous Mode IBS Down Counter (over LIN bus)</p> <p>IBS Measure Temperature Data Available over LIN bus</p>	<p>= 1 (1 indicates enabled)</p> <p>= 1 (1 indicates enabled)</p> <p>= False</p> <p>Not equal off</p> <p>&gt; 9.00 Volts</p> <p>= False</p> <p>&gt; -20.00 Celsius and &lt; 50.00 Celsius</p> <p>= True</p> <p>Between 1 and 24</p> <p>= Zero</p> <p>= True</p>	<p>4 failed samples within 5 total samples</p> <p>Diagnostic runs in the 250 ms loop</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Active Grill Air Shutter A Performance /Stuck OFF	P059F	A 2-part diagnostic. Part 1 continuously monitors for failure to achieve a commanded shutter actuator position [Suspect Stuck Condition] when X failures occur in Y samples after an electronic command latency delay. Part 1 failure enables Part 2 which makes a fixed number of repeat attempts to reach the commanded position [ReTry to clear obstruction]. The DTC is set when the calibrated fault threshold count of repeat attempts is reached without achieving the original commanded shutter position.	Smart Shutter Actuator 1 Position Response	<> Smart Shutter Actuator 1 Commanded Position percent	a. Ignition Run_Crank Active, b. Ignition Run_Crank AND Ignition Accessory AND ECU Awake, c. Command Shutter1 Enable	a. = TRUE,  b. = FALSE AND = FALSE AND = TRUE, c. = 1.00	1.00 failures out of 1.00 samples  1 sample / 100 milliseconds	Type B, 2 Trips
			AND  Shutter 1 Diagnostic Delay Threshold count  Shutter 1 Performance Test count	AND  Counter > 99.00 counts  = 5.00 counts	          a. Ignition Run_Crank Active, b. Ignition Run_Crank AND Ignition Accessory AND ECU Awake, c. Command Shutter1 Enable	          a. = TRUE,  b. = FALSE AND = FALSE AND = TRUE, c. = 1.00	          1-5 actuator cycles  [1 cycle typically requires 10-25 seconds]	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Cold Start Performance – Bank 1	P05CC	<p>Detects a VVT system error during Cold Starts by comparing the desired and actual cam positions when VVT is activated.</p> <p>This is the same type diagnostic as P0011 except this detects excessive deviations of position while the cold start phaser positions are being commanded.</p>	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	Cam Position Error > 6.00 deg.	<p><b>Intake Cam Phsr Enable</b></p> <p>System Voltage</p> <p>Engine Running</p> <p>Power Take Off (PTO) active</p> <p><b>Catalyst Warmup Enabled</b></p> <p>Desired cam position</p> <p>Desired AND Measured cam position</p> <p>Desired cam position variation</p> <p>No Active DTCs</p>	<p>= TRUE</p> <p>&gt; 11.00 Volts</p> <p>= TRUE</p> <p>= FALSE</p> <p>= TRUE</p> <p>&gt; 0 deg</p> <p>&gt; 6.00 deg AND &lt; 26.00 deg</p> <p>&lt; 3.00 deg for ( <b>P0011_P05CC_StablePo sitionTimeIc1</b> ) seconds</p> <p>P0010 P2088 P2089</p>	<p>65 failures out of 75 samples</p> <p>100 ms /sample</p>	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft System Cold Start Performance – Bank 1	P05CE	<p>Detects a VVT system error during Cold Starts by comparing the desired and actual cam positions when VVT is activated.</p> <p>This is the same type diagnostic as P0014 except this detects excessive deviations of position while the cold start phaser positions are being commanded.</p>	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive	Cam Position Error > 6.00 deg.	<p><b>Exhaust Cam Phsr Enable</b></p> <p>System Voltage</p> <p>Engine Running</p> <p>Power Take Off (PTO) active</p> <p><b>Catalyst Warmup Enabled</b></p> <p>Desired cam position</p> <p>Desired AND Measured cam position</p> <p>Desired cam position variation</p> <p>No Active DTCs</p>	<p>= TRUE</p> <p>&gt; 11.00 volts</p> <p>= TRUE</p> <p>= FALSE</p> <p>= TRUE</p> <p>&gt; 0 deg</p> <p>&gt; 6.00 deg AND &lt; 26.00 deg</p> <p>&lt; 3.00 deg for ( <b>P0014_P05CE_StablePo sitionTimeEc1</b> ) sec</p> <p>P0013 P2090 P2091</p>	<p>65 failures out of 75 samples</p> <p>100 ms /sample</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration checksum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5.00 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
			The Primary Processor's calculated checksum does not match the stored checksum value for a selected subset of the calibrations.	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
			The Secondary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	
				In all cases, the failure count is cleared when controller shuts down				

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the ECU is a service part that has not been programmed.	Service (reflash) controller calibration present	= 1		none	Diagnostic runs at powerup and once per second continuously after that	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM Long Term Memory Reset	P0603	This DTC detects an invalid NVM which includes a Static NVM, Perserved NVM, ECC ROM in NVM Flash Region, and Perserved NVM during shut down.	Static NVM region error detected during initialization				Diagnostic runs at controller power up.	Type A, 1 Trips
			Perserved NVM region error detected during initialization				Diagnostic runs at controller power up.	
			ECC ROM fault detected in NVM Flash region				Diagnostic runs at controller power up.	
			ECC ROM Error Count >	5				
			Perserved NVM region error detected during shut down.				Diagnostic runs at controller power down.	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604	Indicates that the ECM has detected a RAM fault. This includes Primary Processor System RAM Fault, Primary Processor Cache RAM Fault, Primary Processor TPU RAM Fault, Primary Processor Update Dual Store RAM Fault, Primary Processor Write Protected RAM Fault, and Secondary Processor RAM Fault. This diagnostic runs continuously.	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips
			Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.45384 s			When dual store updates occur.	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	0 counts			Diagnostic runs continuously (background loop)	
			Indicates that the secondary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault. These include diagnostics done on the SPI Communication as well as a host of diagnostics for both the primary and secondary processors.	Loss or invalid message of SPI communication from the Secondary Processor at initialization detected by the Primary Processor or loss or invalid message of SPI communication from the Secondary Processor after a valid message was received by the Primary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received	Run/Crank voltage  Run/Crank voltage	>= 6.41 Volts or >= 11.00 Volts, else the failure will be reported for all conditions	In the primary processor, 159 / 399 counts intermittent or 39 counts continuous; 39 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	Type A, 1 Trips
			Loss or invalid message of SPI communication from the Primary Processor at initialization detected by the Secondary Processor or loss or invalid message of SPI communication from the Primary Processor after a valid message was received by the Secondary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received			In the secondary processor, 64 / 161 counts intermittent or 0.1875 s continuous; 0.4875 s continuous @ initialization. 12.5 ms /count in the ECM secondary processor	
			Checks for stack over or underflow in secondary processor by looking for corruption of known pattern at stack boundaries. Checks number of stack over/ under flow since last powerup reset >=	5		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			MAIN processor is verified by responding to a seed sent from the secondary with a key response to secondary. Checks number of incorrect keys	2 incorrect seeds within 8 messages, 0.2000 seconds		ignition in Run or Crank	150 ms for one seed continually failing	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			received > or Secondary processor has not received a new within time limit					
			Time new seed not received exceeded			always running	0.450 seconds	
			MAIN processor receives seed in wrong order			always running	3 / 17 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the Secondary processor's ALU check			Test is Enabled: 1 (If 0, this test is disabled)	25 ms	
			2 fails in a row in the Secondary processor's configuration register masks versus known good data			Test is Enabled: 1 (If 0, this test is disabled)	12.5 to 25 ms	
			Secondary processor detects an error in the toggling of a hardware discrete line controlled by the MAIN processor: number of discrete changes > = or < = over time window(50ms)	7 17		Test is Enabled: 0 . (If 0, this test is disabled)  time from initialization >= 0.5000 seconds	50 ms	
			Software background task first pass time to complete exceeds			Run/Crank voltage > 6.41	360.000 seconds	
			2 fails in a row in the MAIN processor's ALU check			Test is Enabled: 1 (If 0, this test is disabled)	25 ms	
			2 fails in a row in the MAIN processor's			Test is Enabled: 1	12.5 to 25 ms	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			configuration register masks versus known good data			(If 0, this test is disabled)		
			Checks number of stack over/under flow since last powerup reset >=	3		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		Test is Enabled: 1 (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM variable, depends on length of time to write flash to RAM	
			MAIN processor DMA transfer from Flash to RAM has 1 failure			Test is Enabled: 0 (If 0, this test is disabled)	variable, depends on length of time to write flash to	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							RAM	
			Safety critical software is not executed in proper order.	>= 1 incorrect sequence.		Test is Enabled: 1 (If 0, this test is disabled)	Fail Table, f(Loop Time). See supporting tables: <b>P0606_PSW Sequence Fail f (Loop Time)</b> /  Sample Table, f (Loop Time)See supporting tables: <b>P0606_PSW Sequence Sample f(Loop Time)</b>  counts  50 ms/count in the ECM main processor	
			MAIN processor determines a seed has not changed within a specified time period within the 50ms task.	Previous seed value equals current seed value.		Test is Enabled: 1 (If 0, this test is disabled)	Table, f(Loop Time). See supporting tables: <b>P0606_Last Seed Timeout f (Loop Time)</b>	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Control Circuit Open (12VSS)	P0615	Controller specific output driver circuit diagnoses the Starter relay (12VSS) low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p><math>\geq 200 \text{ KOhms}</math> impedance between signal and controller ground.</p>	<p>Starter control diag enable</p> <p>Engine speed</p> <p>Run Crank voltage</p>	<p>Enabled</p> <p><math>\geq 0.00 \text{ RPM}</math></p> <p><math>\geq 11.00 \text{ volts}</math></p>	<p>40 failures out of 50 samples</p> <p>50 ms / sample</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Control Circuit Low Voltage (12VSS)	P0616	Controller specific output driver circuit diagnoses the Starter relay (12VSS) low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.	<= 0.5 Ohms impedance between signal and controller ground	Starter control diag enable	Enabled	8 failures out of 10 samples	Type B, 2 Trips
			Engine speed		>= 0.00 RPM	50 ms / sample		
			Run Crank voltage		>= 6.41 volts			

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Control Circuit High Voltage (12VSS)	P0617	Controller specific output driver circuit diagnoses the Starter relay low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 0.5 Ohms impedance between signal and controller power	Starter control diag enable	Enabled	40 failures out of 50 samples	Type B, 2 Trips
					Engine speed	>= 0.00 RPM	50 ms / sample	
					Run Crank voltage	>= 6.41 volts		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Internal Control Module Fuel Injector Control Performance	P062B	This DTC determines the internal fuel injector control module circuit is faulted. The faulted status is set on any failure that could potentially damage the drivers or injectors, or could result in uncontrolled fueling. The following general classes of failures shall be covered: Communication error with control circuit Internal corruption of control circuit values, Invalid interface values (from control circuit)	Internal ECU Boost Voltage	>= 90 Volts	Battery Voltage	>= 8 or >= 11  Enabled when a code clear is not active or not exiting device control Engine is not cranking Powertrain Relay Voltage within range	High Voltage - 160 failures out of 200 samples	Type A, 1 Trips	
			OR						Low Voltage - 160 failures out of 200 samples
			Internal ECU Boost Voltage	<= 40 Volts					Driver Status Not Ready- 160 failures out of 200 samples
			OR						Driver Status Uninitialized - Uninitialized state for >= 100 counts
			Driver Status	= Not Ready					
			OR						
			Driver Status	= Uninitialized			All at 12.5ms per sample		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Internal Control Module EEPROM Error	P062F	This DTC detects a NVM long term performance. There are two types of diagnostics that run during controller power up. One for HWIO reports that writing to NVM (at shutdown) will not succeed, and the other HWIO reports the assembly calibration integrity check has failed.	HWIO reports that writing to NVM (at shutdown) will not succeed				Diagnostic runs at controller power up.	Type B, 2 Trips
			HWIO reports the assembly calibration integrity check has failed				Diagnostic runs at controller power up.	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks that the VIN is correctly written	At least one of the programmed VIN digits	= 00 or FF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on the 5 volt reference circuit #1 by monitoring the reference percent Vref1 and failing the diagnostic when the percent Vref1 is too low or too high or if the delta between the filtered percent Vref1 and non-filtered percent Vref1 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref1 < or ECM percent Vref1 > or the difference between ECM filtered percent Vref1 and percent Vref1 >	4.875 % Vref1 5.125 % Vref1  0.0495 % Vref1	Diagnostic enabled  AND [ (Run/Crank voltage for Time period AND Starter engaged)  OR (Run/Crank voltage AND Starter engaged) ]	= 1          > 6.41 Volts = 0.02 Seconds = FALSE          > 8.41 Volts = TRUE	19 / 39 counts; or  0.1875 sec continuous;  12.5 ms/count in main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module O2 Sensor Processor Performance Bank 1) (For use with WRAF	P064D	<p>Diagnoses the WRAF Application-Specific Integrated Circuit (ASIC) for Controller Status and Measure Valid faults. These faults can impact closed loop fuel control. This DTC when enabled, monitors the two different failure counters it receives from the WRAF ASIC.</p> <p>The individual diagnostic failure counters are incremented based on the message received from the ASIC. The DTC is set based on any of the two individual fail and sample counters.</p>	B1S1 WRAF ASIC indicates control module faults	Controller Status fail counts and Measure Valid fail counts are accumulated to determine fault status	<p>Engine Run or Auto stop</p> <p>Heater Warm-up delay</p> <p>WRAF circuit diagnostic delay since power up</p>	<p>= True</p> <p>= Complete</p> <p>≥ 20.0 sec</p>	<p>128 controller status fail counts out of 160 samples</p> <p>OR</p> <p>128 measure valid fail counts out of 160 samples</p> <p>25 ms / sample</p> <p>Continuous</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Open	P0650	Detects an inoperative malfunction indicator lamp control low side driver circuit. This diagnostic reports the DTC when an open circuit is detected.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K $\Omega$ impedance between signal and controller ground	Run/Crank Voltage  Remote Vehicle Start is not active	Voltage ≥ 11.00 volts	1 failures out of 1 samples  50 ms / sample	Type B, No MIL  NO MIL  Note: In certain controlle rs P263A may also set (MIL Control Short to Ground)

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #2 Circuit	P0651	Detects a continuous or intermittent short on the 5 volt reference circuit #2 by monitoring the reference percent Vref2 and failing the diagnostic when the percent Vref2 is too low or too high or if the delta between the filtered percent Vref2 and non-filtered percent Vref2 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref2 < or ECM percent Vref2 > or the difference between ECM filtered percent Vref2 and percent Vref2 >	4.875 % Vref2 5.125 % Vref2  0.0495 % Vref2	Diagnostic enabled  AND [ (Run/Crank voltage for Time period AND Starter engaged)  OR  (Run/Crank voltage AND Starter engaged) ]	= 1   > 6.41 Volts = 0.02 Seconds = FALSE   > 8.41 Volts = TRUE	19 / 39 counts; or  0.1875 sec continuous;  12.5 ms/count in main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Open	P0685	Detects an open circuit in the Powertrain Relay driver. This diagnostic reports the DTC when an open circuit failure is present. Monitoring occurs when the output is powered off. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	Open Circuit: ≥ 200 K Ω ohms impedance between output and controller ground	Run/Crank Voltage	Voltage ≥ 11.00 volts	<p>8 failures out of 10 samples</p> <p>250 ms / sample</p>	<p>Type B, 2 Trips</p> <p>Note: In certain controlle rs P0686 may also set (Powertr ain Relay Control Short to Ground).</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Low	P0686	Detects a short to ground in the Powertrain Relay low side driver. This diagnostic reports the DTC when a short to ground failure is present. Monitoring occurs when the output is powered off. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	Short to ground: ≤ 0.5 Ω impedance between output and controller ground	Run/Crank Voltage	Voltage ≥ 11.00 volts	<p>8 failures out of 10 samples</p> <p>250 ms / sample</p>	<p>Type B, 2 Trips</p> <p>Note: In certain controlle rs P0685 may also set (Powertr ain Relay Control Open Circuit).</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) High	P0687	Detects a short to power in the Powertrain Relay low side driver. This diagnostic reports the DTC when a short to power failure is present. Monitoring occurs when the output is powered off. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	Short to power: $\leq 0.5 \Omega$ impedance between output and controller power	Run/Crank Voltage	Voltage $\geq 11.00$ volts	8 failures out of 10 samples  250 ms / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Relay Feedback Circuit Low Voltage	P0689	Detects low voltage in the control module relay feedback circuit. This diagnostic reports the DTC when low voltage is present. Monitoring occurs when run crank voltage is above a calibrated value.	Control module relay feedback circuit low voltage	Powertrain relay voltage <= 5.00	Powertrain relay short low diagnostic enable  Run Crank voltage  Powertrain relay state	= 1.00  > 9.00  = ON	5 failures out of 6 samples  1000 ms / sample	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Feedback Circuit High	P0690	Detects higher than expected voltage in the powertrain relay feedback circuit. This diagnostic reports the DTC when higher than expected voltage is present. For example, the powertrain relay could be stuck on. Monitoring occurs when the relay is commanded "off" for a calibrated duration.	Powertrain Relay Voltage	>= 4.00 volts will increment the fail counter	Powertrain relay commanded "OFF"  No active DTCs:	>= 2.00 seconds  PowertrainRelayStateOn_FA	50 failures out of 63 samples  100ms / Sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #3 Circuit	P0697	Detects a continuous or intermittent short on the 5 volt reference circuit #3 by monitoring the reference percent Vref3 and failing the diagnostic when the percent Vref3 is too low or too high or if the delta between the filtered percent Vref3 and non-filtered percent Vref3 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref3 < or ECM percent Vref3 > or the difference between ECM filtered percent Vref3 and percent Vref3 >	4.875 % Vref3 5.125 % Vref3  0.0495 % Vref3	Diagnostic enabled  AND [ (Run/Crank voltage for Time period AND Starter engaged)  OR  (Run/Crank voltage AND Starter engaged) ]	= 1  > 6.41 Volts = 0.02 Seconds = FALSE  > 8.41 Volts = TRUE	19 / 39 counts; or  0.1875 sec continuous;  12.5 ms/count in main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #4 Circuit	P06A3	Detects a continuous or intermittent short on the 5 volt reference circuit #4 by monitoring the reference percent Vref4 and failing the diagnostic when the percent Vref4 is too low or too high or if the delta between the filtered percent Vref4 and non-filtered percent Vref4 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref4 < or ECM percent Vref4 > or the difference between ECM filtered percent Vref4 and percent Vref4 >	4.875 % Vref4 5.125 % Vref4  0.0495 % Vref4	Diagnostic enabled  AND [ (Run/Crank voltage for Time period AND Starter engaged)  OR  (Run/Crank voltage AND Starter engaged) ]	= 1   > 6.41 Volts = 0.02 Seconds = FALSE   > 8.41 Volts = TRUE	19 / 39 counts; or  0.1875 sec continuous;  12.5 ms/count in main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 1 Performance	P06B6	This diagnostic checks for a fault with the internal test circuit (sensor #1) used only for the '20 kHz' method of the Open Circuit Diagnostic. A fault is present when the signal level from the 20 kHz range of the FFT output falls between the Open Test Circuit thresholds.	FFT Diagnostic Output	<b>&gt;</b> <b>P06B6_P06B7_OpenT</b> <b>estCktThrshMin</b>  <b>AND</b>  <b>&lt;</b> <b>P06B6_P06B7_OpenT</b> <b>estCktThrshMax</b>  <b>See Supporting</b> <b>Tables</b>	Diagnostic Enabled?  Engine Run Time  Engine Speed  Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)  Engine Air Flow	Yes  ≥ 2.0 seconds  > 650 RPM and < 8,500 RPM  ≥ 200 Revs  ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient  Weight Coefficient = 0.0100  Updated each engine event	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 2 Performance	P06B7	This diagnostic checks for a fault with the internal test circuit (sensor #2) used only for the '20 kHz' method of the Open Circuit Diagnostic. A fault is present when the signal level from the 20 kHz range of the FFT output falls between the Open Test Circuit thresholds.	Individual Sensor Threshold Enabled?      FFT Diagnostic Output	0.00 , Use Case 1   <b>Case 1:</b>  > <b>P06B6_P06B7_OpenTestCktThrshMin</b>  <b>AND</b>  < <b>P06B6_P06B7_OpenTestCktThrshMax</b>  <b>See Supporting Tables</b>   <b>Case 2:</b>  > <b>P06B7_OpenTestCktMin2</b>  <b>AND</b>  < <b>P06B7_OpenTestCktMax2</b>  <b>See Supporting Tables</b>	Diagnostic Enabled?  Engine Run Time  Engine Speed   Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)  Engine Air Flow	Yes  ≥ 2.0 seconds  > 650 RPM and < 8,500 RPM  ≥ 200 Revs   ≥ 10 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient  <b>Case 1 Weight Coefficient =</b>  0.0100  Updated each engine event   <b>Case 2 Weight Coefficient =</b> 0.0100  Updated each engine event	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #5 Circuit	P06D2	Detects a continuous or intermittent short on the 5 volt reference circuit #5 by monitoring the reference percent Vref5 and failing the diagnostic when the percent Vref5 is too low or too high or if the delta between the filtered percent Vref5 and non-filtered percent Vref5 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref5 < or ECM percent Vref5 > or the difference between ECM filtered percent Vref5 and percent Vref5 >	4.875 % Vref5 5.125 % Vref5  0.0495 % Vref5	Diagnostic enabled  AND [ (Run/Crank voltage for Time period AND Starter engaged)  OR  (Run/Crank voltage AND Starter engaged) ]	= 1   > 6.41 Volts = 0.02 Seconds = FALSE   > 8.41 Volts = TRUE	19 / 39 counts; or  0.1875 sec continuous;  12.5 ms/count in main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit Open	P06DA	Controller specific output driver circuit diagnoses the two stage oil pump low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	Open Circuit ≥ 200 k $\Omega$ impedance between output and controller ground	<p>Diagnostic Status</p> <p>Powertrain Relay Voltage</p> <p>Run/Crank Active</p> <p>Cranking State</p>	<p>Enabled</p> <p>≥ 11.00</p> <p>= True</p> <p>= False</p>	<p>≥ 40 errors out of 50 samples.</p> <p>Performed every 100 msec</p>	<p>Type B, 2 Trips</p> <p>Note: In certain controllers P06DB may also set (Two Stage Oil Pump Control Circuit Short To Ground)</p>

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit Short To Ground	P06DB	Controller specific output driver circuit diagnoses the two stage oil pump low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	Short to Ground Circuit ≤ 0.5 Ω impedance between output and controller ground	<p>Diagnostic Status</p> <p>Powertrain Relay Voltage</p> <p>Run/Crank Active</p> <p>Cranking State</p>	<p>Enabled</p> <p>≥ 11.00</p> <p>= True</p> <p>= False</p>	<p>≥ 40 errors out of 50 samples.</p> <p>Performed every 100 msec</p>	<p>Type A, 1 Trips</p> <p>Note: In certain controllers P06DA may also set (Two Stage Oil Pump Control Circuit Open)</p>



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit Short To Power	P06DC	Controller specific output driver circuit diagnoses the two stage oil pump low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	Short to Power $\leq 0.5 \Omega$ impedance between output and controller power	<p>Diagnostic Status</p> <p>Powertrain Relay Voltage</p> <p>Run/Crank Active</p> <p>Cranking State</p>	<p>Enabled</p> <p><math>\geq 11.00</math></p> <p>= True</p> <p>= False</p>	<p><math>\geq 40</math> errors out of 50 samples.</p> <p>Performed every 100 msec</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit Performance - Two Sided	P06DD	Diagnoses the two stage oil pump is stuck in the high pressure state. This diagnostic includes an intrusive test and a passive test. Intrusive test: The oil pump control is cycled off (high pressure) and on (low pressure) Y = 15 times at calibratable intervals. If a change in oil pressure above a calibration is not detected then the oil pressure is checked to determine if it is stuck. It takes X-out-of-Y failures to fail and set the appropriate code. Passive test: After the intrusive test passes, then a passive test will begin to run. The passive test will monitor the oil pressure changes associated with oil pump control state changes. If the passive test determines that the oil pressure change was less than desired then the intrusive test is retrigged.	<u>Fail from passing state:</u>  Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is above a threshold	Oil Pressure delta = ABS [ Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.5 seconds]  Oil Pressure delta < <b>P06DD_P06DE_OP_S tateChangeMin</b>  AND  Filtered Oil Pressure ≥ ( <b>P0521_P06DD_P06D E_OP_HiStatePressu re</b> + <b>P0521_P06DD_P06D E_OP_LoStatePressu re</b> ) ÷ 2  (see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_OP_S tateChangeMin</b> <b>P0521_P06DD_P06D E_OP_HiStatePressu re</b> <b>P0521_P06DD_P06D E_OP_LoStatePressu re</b> )	<u>Common Criteria:</u>  Two Stage Oil Pump is Present  Engine Running  Ambient Air Pressure  Oil Aeration (= TRUE if engine speed > 5,000 RPM for longer than 30.0 seconds)  No active DTC's for diagnosis enable:  Check oil pump TFTKO as a diagnostic enable when Enabled.  No active DTC's for control enable:  <u>Active Criteria:</u> One Sided Performance Test = Disabled	TRUE  ≥ 20.0 seconds  ≥ 70.0 kPa  FALSE  Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCkt FA AmbientAirDefault EngOilTempFA OilPmpTFTKO  Enabled : OilPmpTFTKO  Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccura te EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA  Disabled	≥ 12 errors out of 15 samples.  Run once per trip or activated by the Passive Test	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Oil Pump in Low State</p> <p>Modelled Oil Temperature within range</p> <p>Filtered Engine Speed within range</p> <p>Delta Filtered Engine Speed within a range</p> <p>Engine Torque within range</p> <p>Filtered Oil Pressure within range</p>	<p>&gt; 1.5 seconds</p> <p>70.0 deg C ≤ Oil Temp ≤ 115.0 deg C</p> <p>1,100 RPM ≤ Filtered Engine Speed ≤ 2,500 RPM</p> <p>ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds ] ≤ 150 RPM</p> <p><b>P06DD_P06DE_MinEnableTorque_OP</b> ≤ Indicated Requested Engine Torque ≤ <b>P06DD_P06DE_MaxEnableTorque_OP</b></p> <p>(see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_MinEnableTorque_OP</b> <b>P06DD_P06DE_MaxEnableTorque_OP</b> )</p> <p>Filtered Engine Oil Pressure &gt; <b>P06DD_P06DE_MinOilPressureThresh</b></p> <p>(see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_MinOilPressureThresh</b> )</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Expected Oil Pressure Delta within range</p> <p><u>Passive Criteria:</u></p> <p>Active Test Passed</p> <p>Filtered Engine Speed within range</p> <p>Modelled Oil Temperature within range</p> <p>Delta Filtered Engine Speed within a range</p> <p>Oil Pressure Delta within a range</p>	<p>96.0 kPa &lt; ABS [  <b>P0521_P06DD_P06DE_</b> <b>OP_HiStatePressure</b> - <b>P0521_P06DD_P06DE_</b> <b>OP_LoStatePressure</b> ] &lt; 200.0 kPa</p> <p>TRUE</p> <p>1,500 RPM ≤ Filtered Engine Speed ≤ 4,000 RPM</p> <p>40.0 deg C ≤ Oil Temp ≤ 120.0 deg C</p> <p>ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.50 seconds ] ≤ 450 RPM</p> <p>Oil Pressure Delta &lt; <b>P06DD_P06DE_OP_Stat</b> <b>eChangeMin</b> (see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_OP_Stat</b> <b>eChangeMin</b> )</p>		
			<p><u>Fast Pass Condition</u></p> <p>Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is</p>	<p>Oil Pressure delta =</p> <p>ABS [ Filtered Oil Pressure at beginning of state change -</p>	<p><u>Common Criteria:</u></p> <p>Two Stage Oil Pump is Present</p> <p>Engine Running</p>	<p>TRUE</p> <p>≥ 20.0 seconds</p>	<p>0 errors out of 5 samples.</p> <p>Run once per trip or activated by the Passive Test</p>	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			above a threshold	<p>filtered oil pressure after 1.5 seconds]</p> <p>Oil Pressure delta &lt; <b>P06DD_P06DE_OP_StateChangeMin</b></p> <p>AND</p> <p>Filtered Oil Pressure ≥ ( <b>P0521_P06DD_P06DE_OP_HiStatePressure - P0521_P06DD_P06DE_OP_LoStatePressure</b> ) ÷ 2</p> <p>(see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_OP_StateChangeMin</b> <b>P0521_P06DD_P06DE_OP_HiStatePressure</b> <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> )</p>	<p>Ambient Air Pressure</p> <p>Oil Aeration (= TRUE if engine speed &gt; 5,000 RPM for longer than 30.0 seconds)</p> <p>No active DTC's for diagnosis enable:</p> <p>Check oil pump TFTKO as a diagnostic enable when Enabled.</p> <p>No active DTC's for control enable:</p> <p><u>Active Criteria:</u> One Sided Performance Test = Disabled</p> <p>Oil Pump in Low State</p> <p>Modelled Oil Temperature within range</p> <p>Filtered Engine Speed within range</p>	<p>≥ 70.0 kPa</p> <p>FALSE</p> <p>Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA EngOilPressureSensorCkt FA AmbientAirDefault EngOilTempFA OilPmpTFTKO CrankSensor_FA</p> <p>Enabled : OilPmpTFTKO</p> <p>Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA</p> <p>Disabled</p> <p>&gt; 1.5 seconds</p> <p>70.0 deg C ≤ Oil Temp ≤ 115.0 deg C</p> <p>1,100 RPM ≤ Filtered Engine Speed ≤ 2,500</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Engine Torque within range</p> <p>Delta Filtered Engine Speed within a range</p> <p>Filtered Oil Pressure within range</p> <p>Expected Oil Pressure Delta within range</p>	<p>RPM</p> <p><b>P06DD_P06DE_MinEnableTorque_OP</b>  <math>\leq</math>  Indicated Requested Engine Torque  <math>\leq</math>  <b>P06DD_P06DE_MaxEnableTorque_OP</b>  (see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_MinEnableTorque_OP</b> <b>P06DD_P06DE_MaxEnableTorque_OP</b> )</p> <p>ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds ] <math>\leq</math> 150 RPM</p> <p>Filtered Engine Oil Pressure &gt;  <b>P06DD_P06DE_MinOilPressureThresh</b>  (see P06DD details on Supporting Tables Tab <b>P06DD_P06DE_MinOilPressureThresh</b> )</p> <p>96.0 kPa &lt; ABS [ <b>P0521_P06DD_P06DE_OP_HiStatePressure</b> - <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> ] &lt; 200.0 kPa</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit StuckOn - Two Sided	P06DE	<p>Diagnoses the two stage oil pump is stuck in the low pressure state. This diagnostic includes an intrusive test and a passive test.</p> <p>Intrusive test: The oil pump control is cycled off (high pressure) and on (low pressure) Y times at calibratable intervals. If a change in oil pressure above a calibration is not detected then the oil pressure is checked to determine if it is stuck. It takes X-out-of-Y failures to fail and set the appropriate code.</p> <p>Passive test: After the intrusive test passes, then a passive test will begin to run. The passive test will monitor the oil pressure changes associated with oil pump control state changes. If the passive test determines that the oil pressure change was less then desired then the intrusive test is retrigged.</p>	<p><u>Fail from a passing state:</u></p> <p>Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is below a threshold</p>	<p>Oil Pressure delta = ABS [ Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.5 seconds]</p> <p>Oil Pressure delta &lt; <b>P06DD_P06DE_OP_StateChangeMin</b> (see P06DE details on Supporting Tables Tab)</p> <p>Filtered Oil Pressure ≤ <b>P0521_P06DD_P06DE_OP_HiStatePressure</b> (see P0521_P06DD_P06DE_OP_LoStatePressure) ÷ 2 (see P06DE details on Supporting Tables Tab)</p>	<p><u>Common Criteria:</u></p> <p>Two Stage Oil Pump is Present</p> <p>Engine Running</p> <p>Ambient Air Pressure</p> <p>Oil Aeration (= TRUE if engine speed &gt; 5,000 RPM for longer than 30.0 seconds)</p> <p>No active DTC's for diagnosis enable:</p> <p>Check oil pump TFTKO as a diagnostic enable when Enabled.</p> <p>No active DTC's for control enable:</p> <p><u>Active Criteria:</u> One Sided Performance</p>	<p>TRUE</p> <p>≥ 20.0 seconds</p> <p>≥ 70.0 kPa</p> <p>FALSE</p> <p>Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCkt FA AmbientAirDefault EngOilTempFA</p> <p>Enabled : OilPmpTFTKO</p> <p>Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccuracy EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA</p> <p>Disabled</p>	<p>≥ 12 errors out of 15 samples.</p> <p>Run once per trip or activated by the Passive Test</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Test = Disabled  Oil Pump in Low State  Modelled Oil Temperature within range  Filtered Engine Speed within range  Engine Torque within range  Delta Filtered Engine Speed within a range  Filtered Oil Pressure within range  Expected Oil Pressure Delta within range	> 1.5 seconds  70.0 deg C ≤ Oil Temp ≤ 115.0 deg C  1,100 RPM ≤ Filtered Engine Speed ≤ 2,500 RPM  <b>P06DD_P06DE_MinEnableTorque_OP</b> ≤ Indicated Requested Engine Torque ≤ <b>P06DD_P06DE_MaxEnableTorque_OP</b> (see P06DE details on Supporting Tables Tab)  ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] ≤ 150 RPM  Filtered Engine Oil Pressure > <b>P06DD_P06DE_MinOilPressureThresh</b> (see P06DD details on Supporting Tables Tab)  96.0 kPa < ABS [ <b>P0521_P06DD_P06DE_OP_HiStatePressure</b> - <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> ] < 200.0 kPa		



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<u>Passive Criteria:</u>  Active Test Passed  Filtered Engine Speed within range  Modelled Oil Temperature within range  Delta Filtered Engine Speed within a range  Oil Pressure Delta < <b>P06DD_P06DE_OP_StateChangeMin</b> (see P06DE details on Supporting Tables Tab)	TRUE  1,500 RPM ≤ Filtered Engine Speed ≤ 4,000 RPM  40.0 deg C ≤ Oil Temp ≤ 120.0 deg C  ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.50 seconds ] ≤ 450 RPM  TRUE		
			<u>Fast Pass Condition</u>  Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is below a threshold	Oil Pressure delta = ABS [ Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.5 seconds]  Oil Pressure delta <	<u>Common Criteria:</u>  Two Stage Oil Pump is Present  Engine Running  Ambient Air Pressure  Oil Aeration (= TRUE if engine speed	TRUE  ≥ 20.0 seconds  ≥ 70.0 kPa  FALSE	0 errors out of 5 samples.  Run once per trip or activated by the Passive Test	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				<b>P06DD_P06DE_OP_StateChangeMin</b> (P06DD Performance Test Details on Supporting Tables Tab)  Filtered Oil Pressure ≤ <b>P0521_P06DD_P06DE_OP_HiStatePressure</b> (re - <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> ) / 2 (P06DD Performance Test Details on Supporting Tables Tab)	> 5,000 RPM for longer than 30.0 seconds)  No active DTC's for diagnsotic enable:          Check oil pump TFTKO as a diagnostic enable when Enabled.  No active DTC's for control :          <u>Active Criteria:</u> One Sided Performance Test = Disabled  Oil Pump in Low State  Modelled Oil Temperature within range  Filtered Engine Speed within range  Engine Torque within range	Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCktFA AmbientAirDefault EngOilTempFA  Enabled : OilPmpTFTKO   Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA  Disabled  > 1.5 seconds  70.0 deg C ≤ Oil Temp ≤ 115.0 deg C  1,100 RPM ≤ Filtered Engine Speed ≤ 2,500 RPM  <b>P06DD_P06DE_MinEnableTorque_OP</b> ≤		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Delta Filtered Engine Speed within a range</p> <p>Filtered Oil Pressure within range</p> <p>Expected Oil Pressure Delta within range</p>	<p>Indicated Requested Engine Torque ≤ <b>P06DD_P06DE_MaxEnableTorque_OP</b> (P06DD Performance Test Details on Supporting Tables Tab)</p> <p>ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] ≤ 150 RPM</p> <p>Filtered Engine Oil Pressure &gt; <b>P06DD_P06DE_MinOilPressureThresh</b> (see P06DD details on Supporting Tables Tab)</p> <p>96.0 kPa &lt; ABS [ <b>P0521_P06DD_P06DE_OP_HiStatePressure</b> - <b>P0521_P06DD_P06DE_OP_LoStatePressure</b> ] &lt; 200.0 kPa</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Module (TCM) Requested MIL Illumination	P0700	Monitors the TCM MIL request message to determine when the TCM has detected a MIL illuminating fault.	Transmission Control Module Emissions-Related DTC set and module is requesting MIL	Transmission Control Module Emissions-Related DTC set and module is requesting MIL		Time since power-up $\geq$ 3 seconds	Continuous	Type A, No MIL

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Traction Control Torque Request Circuit	P0856	Determines if torque request from the EBCM is valid	<p>Serial Communication 2's complement message - (\$1C7/\$1C9 for engine torque, \$1CA/\$1C6 for axle torque)</p> <p>OR</p> <p>Serial Communication message (\$1C7/\$1C9 for engine torque, \$1CA/\$1C6 for axle torque) rolling count index value</p> <p>OR</p> <p>Too many minimum limit torque request transitions occur from TRUE to FALSE to TRUE within a time period</p> <p>Torque request greater than torque request diagnostic maximum threshold</p>	<p>Message &lt;&gt; 2's complement of message</p> <p>Message rolling count value &lt;&gt; previous message rolling count value plus one</p> <p>Requested torque intervention type toggles from not increasing request to increasing request</p> <p>&gt; 250 Nm for engine torque based traction torque system, OR &gt; 4,000 Nm for axle torque based traction torque system</p>	<p>Active Communication</p> <p>Power Mode Engine Running</p> <p>Status of traction in GMLAN message (\$4E9)</p> <p>Ignition Voltage</p> <p>Run/Crank Active</p>	<p>Serial data has been received</p> <p>= Run = True</p> <p>= Traction Present</p> <p>&gt; 6.41 volts</p> <p>&gt; 0.50 seconds</p>	<p>&gt;= 8 failures out of 10</p> <p>Performed on every received message</p> <p>6 rolling count failures out of 10 samples</p> <p>Performed on every received message</p> <p>&gt;= 3 multi-transitions out of 5 samples.</p> <p>Performed every 200 ms</p> <p>&gt;= 4 out of 10 samples</p> <p>Performed on every received message</p>	Type C, No SVS Emissions Neutral Diagnostic - Type C

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Reset Signal Message Counter Incorrect	P1000	This DTC monitors for an error in communication with the Fuel Pump Driver Control Module Reset Signal	Communication of the Alive Rolling Count or Protection Value from the FPDCM over CAN bus is incorrect for  out of total samples	  >= 8 counts   >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage  And  Sensor Bus Relay	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts   = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Signals Message Counter Incorrect	P1001	This DTC monitors for an error in communication with the Evaporative Emission (EVAP) System Signal	Communication of the Alive Rolling Count or Protection Value from the EVAP System over CAN bus is incorrect for  out of total samples	  >= 8 counts  >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage  And  Sensor Bus Relay	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts   = On (if present)	Executes in 10ms loop.	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module System Voltage Performance (Only on applications that use an FTZM)	P1002	Detects low system voltage performance of the fuel pump driver control module system. This diagnostic reports the DTC when the absolute value of the difference between the fuel pump driver battery voltage and the fuel pump driver run/crank voltage exceeds a calibrated value.	Fuel Pump Driver Control Module Run Crank voltage low and high	ABS (Fuel Pump Driver Control Module Battery voltage - Fuel Pump Driver Control Module Run Crank voltage) > 3.00	Fuel Tank Zone Module (FTZM) is present on vehicle  Fuel Pump Driver Control Module System Voltage Performance diagnostic is enabled  Fuel Tank Zone Module (FTZM) serial messages are available  FTZM Run Crank Active is TRUE  Starter motor not engaged  Sensor Bus relay is commanded ON	= 1	50 failures out of 63 samples  12.5 ms / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Control System Signals Message Counter Incorrect	P1003	This DTC monitors for an error in communication with the Fuel Control System Signals	Communication of the Alive Rolling Count or Protection Value from the Fuel Control System over CAN bus is incorrect for  out of total samples	  >= 8 counts   >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage  And  Sensor Bus Relay	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts   = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Reset Error	P1005	This DTC monitors for a reset error in the Fuel Pump Driver Control Module	If the received value for the time since the last FPDCM reset has reset and the newly received value or previous value is  for  out of total samples	  ≤ 0.50 seconds  ≥ 2.00 counts  ≥ 400.00 counts	DTC is enabled  Sensor bus relay  Battery voltage  P1000  U18A2	1.00 (1 indicates enabled)  On  > 11.00 Volts  Not active  Not active	Diagnostic runs in 50 ms loop.	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit High (Only on applications that use an FTZM)	P1007	Detects high voltage of the fuel pump driver control module ignition switch circuit. This diagnostic reports the DTC when the fuel pump driver control module ignition switch circuit voltage exceeds a calibrated value.	Fuel Pump Driver Control Module Ignition switch Run/Start position circuit high	FTZM Run Crank Active is TRUE	Fuel Tank Zone Module (FTZM) is present on vehicle  Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit High diagnostic is enabled  Fuel Tank Zone Module (FTZM) serial messages are available  Run Crank Active  Sensor Bus relay is commanded ON	= 1      = FALSE	40 failures out of 50 samples  50 ms / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Temperature (Fuel Tank Zone Module) Too High Signal Message Counter Incorrect	P1009	This DTC monitors for an error in communication with the Fuel Pump Driver Control Module (FTZM) Temperature Too High Signal Message	Communication of the Alive Rolling Count or Protection Value from the Fuel Pump Driver Control Module over CAN bus is incorrect for  out of total samples	  >= 8 counts  >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage  Sensor Bus Relay	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts  = On (if present)	Executes in 100ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Temperature Erratic	P100C	This DTC monitors for an erratic Temperature signal via LIN bus from the Battery Monitor Module	Communication of the Temperature signal from the Battery Monitor Module has become erratic or is incorrect for  out of total samples	  >= 4 counts  >= 5 counts	The diagnostic is enabled  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage	= 1 (1 indicates enabled)  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts	LIN bus communication executes in 500ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Internal Temperature Circuit Erratic	P100D	This DTC monitors for an erratic Temperature Circuit signal via LIN bus from the Battery Monitor Module	Communication of the Temperature Circuit signal from the Battery Monitor Module has become erratic or is incorrect for  out of total samples	  >= 4 counts  >= 5 counts	The diagnostic is enabled  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage	= 1 (1 indicates enabled)  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts	LIN bus communication executes in 500ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V- W Circuit Open	P1029	<p>This DTC detects if any of the 3phase fuel pump control circuits is Open [system configuration "Brushless"]</p> <p>The diagnostic can detect open circuit faults when the fuel pump is not rotating. In the "stopped" state, small currents are injected into each motor phase circuit pair by an internal fixed source and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage falls into a specific range [adjusted for source voltage]. This process is completed in less than 1 millisecond. The FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are</p>	Phased-pair circuit voltage	3V <= V [back-EMF] <= 6V	<p>a) Sensed fuel pump speed</p> <p>b) Device configuration FCBR_e_ChassisFuelPre sSysType</p> <p>c) Diagnostic Enabled - KeFABR_b_OpenCktDiag Enbl</p> <p>d) CAN Sensor Bus message \$3EC_Avail</p> <p>e) Sensor Bus Relay On</p> <p>f) Sensor Bus B Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_A RC_ChkErr]</p>	<p>a) == 0 RPM</p> <p>b) CeFCBR_e_DSL_ECM_F TZM_BLDC_Sys</p> <p>c) == TRUE</p> <p>d) == TRUE</p> <p>e) == TRUE</p> <p>f) &lt;&gt; TRUE</p>	<p>40.00 failures / 80.00 samples</p> <p>1 sample / 12.5 ms</p>	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		active at any moment. Brushless fuel pump speed is inferred using the rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 milliseconds. This open circuit diagnostic follows "smart device" Component Technical Specifications.						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V- W Circuit Low	P102A	<p>This DTC detects if the fuel pump control circuit is shorted to low [Short to Ground]</p> <p>The diagnostic detects short-to-ground faults using 2 methods depending on whether the fuel pump is rotating. 1) In the "rotating" state, voltage drop across each phase-pair high-side drive is monitored, or 2) in the "stopped" state, small currents are injected into each motor phase circuit pair</p>	Phased-pair circuit voltage Difference	Vdelta > 0.145 V	<p>a) Device configuration FCBR_e_ChassisFuelPre sSysType</p> <p>b) Diagnostic KeFABR_b_GshtCktDiag Enbl</p> <p>c) CAN Sensor Bus message \$3EC_Avail</p> <p>d) Sensor Bus Relay On</p> <p>e) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_A RC_ChkErr]</p>	<p>a) == CeFCBR_e_DSL_ECM_F TzM_BLDc_Sys</p> <p>b) == TRUE</p> <p>c) == TRUE</p> <p>d) == TRUE</p> <p>e) &lt;&gt; TRUE</p>	<p>40.00 failures / 80.00 samples</p> <p>1 sample / 12.5 ms</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		by an internal fixed source and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage falls into a specific range [adjusted for source voltage]. The FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are active at any moment. Brushless fuel pump speed is inferred using the rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 milliseconds. This open circuit diagnostic follows "smart device" Component Technical Specifications.	Phased-pair circuit voltage	V [back-EMF] >= 6 V	a) Sensed fuel pump speed  b) Device configuration FCBR_e_ChassisFuelPre sSysType  c) Diagnostic KeFABR_b_GshtCktDiag Enbl  d) CAN Sensor Bus message \$3EC_Avail  e) Sensor Bus Relay On  f) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]	a) == 0 RPM  b) == CeFCBR_e_DSL_ECM_FTZM_BLDC_Sys  c) == TRUE  d) == TRUE  e) == TRUE  f) <> TRUE	40.00 failures / 80.00 samples  1 sample / 12.5 ms	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V- W Circuit High	P102B	<p>This DTC detects if the fuel pump control circuit is shorted to high voltage [Short to Battery]</p> <p>The diagnostic detects short-to-battery faults using 2 methods depending on whether the fuel pump is rotating. 1) In the "rotating" state, voltage drop across each phase-pair low-side current shunt is monitored, or 2) in the "stopped" state, small currents are injected</p>	Phased-pair circuit voltage Difference	Vdelta > 0.4 V	<p>a) Device configuration FCBR_e_ChassisFuelPre sSysType</p> <p>b) Diagnostic KeFABR_b_PshtCktDiag Enbl</p> <p>c) CAN Sensor Bus message \$3EC_Avail</p> <p>d) Sensor Bus Relay On</p> <p>e) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_A RC_ChkErr]</p>	<p>a) == CeFCBR_e_DSL_ECM_F TZM_BLDC_Sys</p> <p>b) == TRUE</p> <p>c) == TRUE</p> <p>d) == TRUE</p> <p>e) &lt;&gt; TRUE</p>	<p>40.00 failures / 80.00 samples</p> <p>1 sample / 12.5 ms</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>into each motor phase circuit pair by an internal fixed source and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage falls into a specific range [adjusted for source voltage].</p> <p>The FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are active at any moment. Brushless fuel pump speed is inferred using the rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 milliseconds.</p> <p>This open circuit diagnostic follows "smart device" Component Technical Specifications.</p>	Phased-pair circuit voltage	V[backEMF] > 6 V	<p>a) Sensed fuel pump speed</p> <p>b) Device configuration FCBR_e_ChassisFuelPre sSysType</p> <p>b) Diagnostic KeFABR_b_PshtCktDiag Enbl</p> <p>c) CAN Sensor Bus message \$3EC_Avail</p> <p>d) Sensor Bus Relay On</p> <p>e) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_A RC_ChkErr]</p>	<p>a) == 0 RPM</p> <p>b) == CeFCBR_e_DSL_ECM_FTZM_BLDC_Sys</p> <p>b) == TRUE</p> <p>c) == TRUE</p> <p>d) == TRUE</p> <p>e) &lt;&gt; TRUE</p>	<p>40.00 failures / 80.00 samples</p> <p>1 sample / 12.5 ms</p>	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Heater Supply Voltage Sense Circuit Range/ Performance	P103B	<p>The P103B diagnostic determines if the heater supply circuit is rational by comparing the heater supply voltage to the run crank voltage and calculating the difference.</p> <p>The heater supply voltage input is connected to the O2 heater supply circuit inside the vehicle relay center. It is representative of the voltage supplied to the O2 heaters. The O2 heater voltage is used by the HWIO to calculate the O2 heater resistance on switching type O2 sensors (non-WRAF). With a fault set, the resistance calculation is performed with run crank voltage.</p> <p>The diagnostic failure counter is incremented if the voltage difference is greater than the threshold. This DTC is set based on the fail and sample counters.</p>	The absolute value of Heater Supply Voltage delta from Run Crank voltage	> 2.00 volts	<p>Powertrain relay in range (Relay in range is defined as relay voltage</p> <p>Run Crank signal active</p>	<p>= True &gt; 11.00 volts )</p> <p>= True (Please see "<b>Run/Crank Active conditions</b>" in Supporting Tables)</p>	<p>8 failures out of 10 samples</p> <p>250 ms / sample</p> <p>Continuous</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Heater Supply Voltage Sense Circuit Low	P103C	<p>The P103C diagnostic determines if the heater supply circuit is low by comparing the heater supply voltage to the threshold.</p> <p>The heater supply voltage input is connected to the O2 heater supply circuit inside the vehicle relay center. It is representative of the voltage supplied to the O2 heaters. The O2 heater voltage is used by the HWIO to calculate the O2 heater resistance on switching type O2 sensors (non-WRAF). With a fault set, the resistance calculation is performed with run crank voltage.</p> <p>The diagnostic failure counter is incremented if the heater supply voltage is less than the threshold. This DTC is set based on the fail and sample counters.</p>	Heater Supply Voltage	< 6.00 volts	<p>Powertrain relay in range (Relay in range is defined as relay voltage</p> <p>Run Crank signal active</p>	<p>= True</p> <p>&gt; 11.00 volts )</p> <p>= True</p> <p>(Please see "<b>Run/Crank Active conditions</b>" in Supporting Tables)</p>	<p>8 failures out of 10 samples</p> <p>250 ms / sample</p> <p>Continuous</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Signal Message Counter Incorrect	P1100	This DTC monitors for an error in communication with the Fuel Pump Control Module (FTZM) Fuel Level Sensor 2 Signal Message Counter	Communication of the Fuel Level Sensor 2 Signal Message Counter from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for  out of total samples	  >= 8 counts  >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage  Sensor Bus Relay	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts  = On (if present)	Executes in 10ms loop.	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (single turbo)	P1101	<p>Detects a performance failure in the Manifold Pressure (MAP) sensor, Turbocharger Boost Pressure sensor, Throttle Position sensor (TPS) or Mass Air Flow (MAF) sensor that cannot be uniquely identified as a failure in one individual sensor. This diagnostic can set when more than one of these sensors has a performance concern.</p> <p>This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from these four sensors.</p> <p>These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with</p>	<p>See table <b>P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix</b> for combinations of model failures that can set this DTC.</p> <p>MAF model fails when ABS(Measured Flow – Modeled Air Flow) Filtered</p> <p>MAP1 model fails when ABS(Measured MAP – MAP Model 1) Filtered</p> <p>MAP2 model fails when ABS(Measured MAP – MAP Model 2) Filtered</p> <p>MAP3 model fails when ABS(Measured MAP – MAP Model 3) Filtered</p> <p>TIAP1 model fails when ABS(Measured TIAP – TIAP Model 1) Filtered</p> <p>TPS model fails when Filtered Throttle Model Error</p> <p>TIAP Correlation model fails when High Engine Air Flow is TRUE AND Measured TIAP -</p>	<p>&gt; 20.0 grams/sec</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 300 kPa*(g/s)</p>	<p>Engine Speed Engine Speed</p> <p>(Coolant Temp OR OBD Coolant Enable Criteria</p> <p>(Coolant Temp OR OBD Max Coolant Achieved</p> <p>Intake Air Temp Intake Air Temp</p> <p>Minimum total weight factor (all factors multiplied together)</p> <p>See Residual Weight Factor tables.</p>	<p>&gt;= 400 RPM &lt;= 6,000 RPM</p> <p>&gt;= -9 Deg C</p> <p>= TRUE)</p> <p>&lt;= 130 Deg C</p> <p>= FALSE)</p> <p>&gt;= -20 Deg C &lt;= 125 Deg C</p> <p>&gt;= 0.50</p> <p>Modeled Air Flow Error multiplied by <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM</b> and <b>P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est</b></p> <p>MAP Model 1 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM</b></p>	<p>Continuous</p> <p>Calculation are performed every 12.5 msec</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		the system, but no single failed sensor can uniquely be identified. In this case, the Inlet Airflow System Performance diagnostic will fail.	<p>measured MAP - offset as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset</b></p> <p>OR</p> <p>Low Engine Air Flow is TRUE AND Measured TIAP - measured Baro - offset as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset</b></p> <p>TIAP Correlation is valid when High Engine Air Flow has been TRUE for a period of time OR Low Engine Air Flow has been TRUE for a period of time</p> <p>High Engine Air Flow is TRUE when Mass Air Flow</p>	<p>&gt; 30.0 kPa</p> <p>&gt; 30.0 kPa</p> <p>&gt; 1.0 seconds</p> <p>&gt; 1.0 seconds</p> <p>&gt; a threshold in gm sec as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow</b></p>	<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>MAP Model 2 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM</b></p> <p>MAP Model 3 Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM</b></p> <p>TIAP Model 1 Error multiplied by <b>P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM</b></p> <p>Filtered Throttle Model Error multiplied by <b>P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM</b></p> <p>MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA MnfdTempSensorFA TC_BoostPresSnsrCktFA AmbientAirDefault</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>AND Manifold Pressure</p> <p>AND Filtered Mass Air Flow - Mass Air Flow</p> <p>Low Engine Air Flow is TRUE when Mass Air Flow</p> <p>AND Manifold Pressure</p> <p>AND Mass Air Flow - Filtered Mass Air Flow</p>	<p>&gt; a threshold in kPa as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP- MAP Correlation Min MAP</b></p> <p>&lt; 3.0 gm/sec</p> <p>&lt; a threshold in gm sec as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP- Baro Correlation Max Air Flow</b></p> <p>&lt; a threshold in kPa as a function of engine speed See table <b>P0101, P0106, P0121, P0236, P1101: TIAP- Baro Correlation Max MAP</b></p> <p>&lt; 2.0 gm/sec</p>		MnfdTempSensorCktFP		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module 5V Reference 1 Circuit	P1176	This DTC monitors for an error in the Fuel Pump Driver Control Module 5V Reference 1 Circuit	Raw Fuel Pump Driver Control Module 5V Reference 1 is  or  Raw Fuel Pump Driver Control Module 5V Reference 1 is  or  Absolute difference of the filtered Fuel Pump Driver Control Module 5V Reference 1 and Raw Fuel Pump Driver Control Module 5V Reference 1 is  For a non-continuous failure of  out of  For a continuous failure of	> 92.25 Percent          < 87.75 Percent          > 0.90 Percent    40.00 counts  80.00 counts  0.20 seconds	Diagnostic is enabled  Run/Crank Ignition Voltage  U0076  PT Sensor Bus Relay  Communication with the Fuel Tank Zone Module is not lost	1.00 (1 indicates enabled)  >= 11.00 Volts  Is not active  Commanded on (if present)	Executes in 12.5ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module 5V Reference 2 Circuit	P1177	This DTC monitors for an error in the Fuel Pump Driver Control Module 5V Reference 2 Circuit	Raw Fuel Pump Driver Control Module 5V Reference 2 is  or  Raw Fuel Pump Driver Control Module 5V Reference 2 is  or  Absolute difference of the filtered Fuel Pump Driver Control Module 5V Reference 2 and Raw Fuel Pump Driver Control Module 5V Reference 2 is  For a non-continuous failure of  out of  For a continuous failure of	> 92.25 Percent          40.00 counts  80.00 counts  0.20 seconds	Diagnostic is enabled  Run/Crank Ignition Voltage  U0076  PT Sensor Bus Relay  Communication with the Fuel Tank Zone Module is not lost	1.00 (1 indicates enabled)  >= 11.00 Volts  Is not active  Commanded on (if present)	Executes in 12.5ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Fuel Level Sensor 1 Internal Supply Circuit	P1178	This DTC monitors for an error in the Fuel Pump Driver Control Module Fuel Level Sensor 1 Internal Supply Circuit	Raw Fuel Pump Driver Control Module Fuel Level Sensor 1 Internal Supply Circuit is or Raw Fuel Pump Driver Control Module Fuel Level Sensor 1 Internal Supply Circuit is or Absolute difference of the filtered Fuel Pump Driver Control Module Fuel Level Sensor 1 Internal Supply Circuit and Raw Fuel Pump Driver Control Module Fuel Level Sensor 1 Internal Supply Circuit is For a non-continuous failure of out of For a continuous failure of	> 92.25 Percent       < 87.75 Percent       > 0.90 Percent   40.00 counts 80.00 counts  0.20 seconds	Diagnostic is enabled  Run/Crank Ignition Voltage  U0076  PT Sensor Bus Relay  Communication with the Fuel Tank Zone Module is not lost	1.00 (1 indicates enabled)  >= 11.00 Volts  Is not active  Commanded on (if present)	Executes in 50.0ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Fuel Level Sensor 2 Internal Supply Circuit	P1179	This DTC monitors for an error in the Fuel Pump Driver Control Module Fuel Level Sensor 2 Internal Supply Circuit	Raw Fuel Pump Driver Control Module Fuel Level Sensor 2 Internal Supply Circuit is  or  Raw Fuel Pump Driver Control Module Fuel Level Sensor 2 Internal Supply Circuit is  or  Absolute difference of the filtered Fuel Pump Driver Control Module Fuel Level Sensor 2 Internal Supply Circuit and Raw Fuel Pump Driver Control Module Fuel Level Sensor 2 Internal Supply Circuit is  For a non-continuous failure of  out of  For a continuous failure of	> 92.25 Percent          40.00 counts  80.00 counts  0.20 seconds	Diagnostic is enabled  Run/Crank Ignition Voltage  U0076  PT Sensor Bus Relay  Communication with the Fuel Tank Zone Module is not lost	1.00 (1 indicates enabled)  >= 11.00 Volts  Is not active  Commanded on	Executes in 50.0ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Command Signal Message Counter Incorrect	P11FF	This DTC monitors for an error in communication with the Fuel Pump Command Signals	Communication of the Alive Rolling Count or Protection Value from the Fuel Control System over CAN bus is incorrect for  out of total samples	  ≥ 15 counts  ≥ 16 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage  And  Sensor Bus Relay	= Is available  ≥ 3,000.00 milliseconds  = Run  ≥ 11.00 Volts  ≥ 11.00 Volts   = On (if present)	Executes in 10ms loop.	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Signal Message Counter Incorrect	P1200	This DTC monitors for an error in communication with the Fuel Pump Control Module (FTZM) Fuel Level Sensor 1 Signal Message Counter	Communication of the Fuel Level Sensor 1 Signal Message Counter from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for  out of total samples	  >= 8 counts  >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage  Sensor Bus Relay	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts  = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 low side circuit shorted to high side circuit	P1248	Controller specific output driver circuit diagnoses injector 1 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.</p>	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 low side circuit shorted to high side circuit	P1249	Controller specific output driver circuit diagnoses injector 2 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.</p>	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 low side circuit shorted to high side circuit	P124A	Controller specific output driver circuit diagnoses injector 3 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.</p>	25 amp >= through low side driver	Battery Voltage Engine Run Time	<p>&gt;= 11 Volts &gt;= 5 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 low side circuit shorted to high side circuit	P124B	Controller specific output driver circuit diagnoses injector 4 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Over Temperature	P1255	<p>To detect if an internal fuel pump driver over-temperature condition exists under normal operating conditions.</p> <p>The FTZM ERFS control may adjust the PWM slew rate or frequency as a self-protection method, but may not reduce pump rotational speed or impact pumping performance in any way due to an over-temperature condition.</p>	Fuel Pump Driver Temperature	T > 160 degC	<p>a) Diagnostic enabled [KeFABR_b_OvertempDiagEnbl]</p> <p>b) Sensor Bus Relay On</p> <p>c) CAN Sensor Bus message \$3EC_Available</p> <p>d) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]</p>	<p>a) == TRUE</p> <p>b) == TRUE</p> <p>c) == TRUE</p> <p>d) &lt;&gt; TRUE</p>	<p>5.00 failures / 10.00 samples</p> <p>1 sample / 100 millisec</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail High Pressure Sensor 2 Out of Range	P127C	<p>This DTC diagnose SENT high pressure sensor 2 that is too low out of range.</p> <p>If the sensor digital value (representing the reference voltage) is below the lower digital threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported. A pass is reported for this DTC if the low sample counter reaches its threshold.</p>	High Pressure Rail Sensor 2 SENT digital read value	=< 66			<p>Time Based: 400 Failuer out of 500 Samples 6.25 ms per Sample Continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure Sensor 1 Internal Performance	P128A	This DTC determines if there is internal error within the SENT pressure sensor 1 (i.e. Broken wire bond internal to the SENT Sensor). Once the internal error is detected a fixed faulted digital values is communicated to the ECU.	Digital pressure sesnor 1 value	>= 4,089	<p>SENT Fuel Rail Pressure Sensor Internal Performance Enable</p> <p>No Fault Pending</p>	<p>Enabled when a code clear is not active or not exiting device control</p> <p>True</p> <p>P16E4 P16E5 P128F</p>	<p>400 failures out of 500 samples</p> <p>6.25 ms per Sample Continuous</p>	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure Sensor 2 Internal Performance	P128B	This DTC determines if there is internal error within the SENT pressure sensor 2 (i.e. Broken wire bond internal to the SENT Sensor). Once the internal error is detected a fixed faulted digital values is communicated to the ECU.	Digital pressure sesnor 2 value	>= 4,089	<p>SENT Fuel Rail Pressure Sensor Internal Performance Enable</p> <p>No Fault Pending</p>	<p>Enabled when a code clear is not active or not exiting device control</p> <p>True</p> <p>P16E4 P16E5 P128F</p>	<p>400 failures out of 500 samples</p> <p>6.25 ms per Sample Continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure & Temperature Sensor Pressure Message Incorrect	P128F	This DTC determines if there is any SENT signal waveform for discrepancies (i.e. too many pulse, too few pulse, clock shift). The SENT HWIO Determines message waveform fault (i.e.too many pulse, too few pulse, clock shift) and if the message age is too long.	SENT HWIO Determines message fault (i.e.too many pulse, too few pulse, clock shift)  Message Age	= true  > 1.94 ms	SENT signal Serial waveform diagnostics enable  SENT power up delay    No Fault Active on	True  >= 0.00 seconds  Enabled when a code clear is not active or not exiting device control  P16E4 P16E5	400 failures out of 500 samples  6.25 ms per sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module System Voltage Low (Only on applications that use an FTZM)	P129B	Detects low voltage of the fuel pump driver control module. This diagnostic reports the DTC when the fuel pump driver control module voltage drops below a calibrated value.	Fuel Pump Driver Control Module System Voltage Low	Fuel Tank Zone Module (FTZM) Battery Voltage <= 9.00	Fuel Tank Zone Module (FTZM) is present on vehicle  Fuel Pump Driver Control Module System Voltage Low diagnostic is enabled  Fuel Tank Zone Module (FTZM) serial messages are available  Starter motor not engaged  Sensor Bus relay is commanded ON	= 1	400 failures out of 500 samples  12.5 ms / sample	Type C, No SVS

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module System Voltage High (Only on applications that use an FTZM)	P129C	Detects high voltage of the fuel pump driver control module. This diagnostic reports the DTC when the fuel pump driver control module voltage exceeds a calibrated value.	Fuel Pump Driver Control Module System Voltage High	Fuel Tank Zone Module (FTZM) Battery Voltage >= 18.00	Fuel Tank Zone Module (FTZM) is present on vehicle  Fuel Pump Driver Control Module System Voltage Low diagnostic is enabled  Fuel Tank Zone Module (FTZM) serial messages are available  Sensor Bus relay is commanded ON	= 1	400 failures out of 500 samples  12.5 ms / sample	Type C, No SVS

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit Low (Only on applications that use an FTZM)	P129D	Detects low voltage of the fuel pump driver control module ignition switch circuit. This diagnostic reports the DTC when the fuel pump driver control module ignition switch circuit voltage is below a calibrated value.	Fuel Pump Driver Control Module Ignition switch Run/Start position circuit low	FTZM Run Crank Active is FALSE	Fuel Tank Zone Module (FTZM) is present on vehicle  Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit High diagnostic is enabled  Fuel Tank Zone Module (FTZM) serial messages are available  Run Crank Active  Sensor Bus relay is commanded ON	= 1      = TRUE	40 failures out of 50 samples  50 ms / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Enable Circuit Performance	P12A6	The purpose of the Fuel Pump Driver Control Module Enable Circuit Performance diagnostic is to detect if the state of the fuel control enable circuit is valid. This is done by comparing the fuel control enable circuit state [high or low] sensed by the Fuel Tank Zone Module device to the commanded state of the fuel control enable signal from the ECM [in serial data]. When the sensed state does not match the commanded state, the fail counter increments.	Sensed Fuel Control Enable circuit state  [Fuel Tank Zone Module device]	<> Fuel Control Enable Active command  [serial data]	a) Diagnostic enabled [KeFABR_b_FuelCntrlEnbIDiagEnbl]  b) Sensor Bus message \$0CC Fuel Pump Command Message Signal Counter Incorrect [CFMR_b_FTZM_Info2_ARC_ChkErr]  c) CAN Sensor Bus message \$0CC_Available  d) Sensor Bus Relay On  e) Timer [FABR_t_RunCrankActive]	a) == TRUE  b) <> TRUE  c) == TRUE  d) == TRUE  e) >= 0.51 seconds	40.00 failures / 80.00 samples  1 sample / 12.5 millisec	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Module (Fuel Tank Zone Module) Control Signal Message Counter Incorrect	P12A8	This DTC monitors for an error in communication with the Fuel Pump Control Module (FTZM) Control Signal Message	Communication of the Alive Rolling Count or Protection Value from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for  out of total samples	   ≥ 8 counts  ≥ 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage  Sensor Bus Relay	= Is available  ≥ 3,000.00 milliseconds  = Run  ≥ 11.00 Volts  ≥ 11.00 Volts  = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Run/ Start Voltage Signal Message Counter Incorrect	P130F	This DTC monitors for an error in the Ignition Run/Start Voltage Signal Message Counter	Communication of the Alive Rolling Count or Protection Value from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for  out of total samples	   >= 8 counts  >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage  Sensor Bus Relay	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts  = On (if present)	Executes in 10ms loop.	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Coil Positive Voltage Circuit Group 1 * * SIDI ONLY * *	P135A	This diagnostic checks for minimum voltage at the fuse which supplies power to the Ignition Coils (applicable only for SIDI applications). A diagnostic failure indicates a blown fuse.	Ignition Module Supply Voltage.	< 2.5 Volts	Diagnostic Enabled?  Three possible Ignition Coil Power Sources (only 1 used):  Ignition Coil Power Source =  <u>Case 1: Battery</u> Delay starting at Key-On  <u>Case 2: Ignition Run/Crank</u> Ignition Run/Crank Voltage  <u>Case 3: PT Relay</u> PT Relay Voltage	Yes        PT Relay (Case 3)  5 Engine Revs  > 5.0 volts  > 11.0 volts	50 Failures out of 63 Samples  6.25 msec rate	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Status Signals Message Counter Incorrect	P135C	This DTC monitors for an error in communication with the Cooling Fan 1 Status Signals	Communication of the Alive Rolling Count or Protection Value of the Cooling Fan 1 Status Signals Message over LIN bus is incorrect for  out of total samples	   >= 8.00 counts  >= 10.00 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts	Executes in 10ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Emissions Reduction System Fault	P1400	Model based test computes power from exhaust flow and thermal energy resulting from elevated idle speed and retarded spark advance. Detects if the cold start emission reduction system has failed resulting in the delivered power being out of range.	<p>Average desired accumulated exhaust power - Average actual accumulated exhaust power (too much energy delivered to catalyst)</p> <p>Average desired accumulated exhaust power - Average actual accumulated exhaust power (too little energy delivered to catalyst)</p> <p>(EWMA filtered)</p> <p>Average Power = output of <b>P1400_EngineSpeedResidual_Table</b> * output of <b>P1400_SparkResidual_Table</b> NOTE: Desired accumulated power would use the desired catalyst light off spark and desired engine speed and the actual accumulated power would use the final commanded spark and actual engine speed. Refer to the Supporting Tables for details</p>	<p>&lt; -32.00 KJ/s (high RPM failure mode)</p> <p>&gt; 5.00 KJ/s (low RPM failure mode)</p>	<p>To enable the diagnostic, the Cold Start Emission Reduction Strategy must be Active per the following:</p> <p>Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure</p> <p>The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:</p> <p>Catalyst Temperature AND Engine Run Time</p> <p>OR</p> <p>Engine Run Time</p> <p>OR</p> <p>Barometric Pressure</p>	<p>&lt; 300.00 degC</p> <p>&gt; -12.00 degC</p> <p>&lt;= 66.00 degC</p> <p>&gt;= 72.00 KPa</p> <p>&gt;= 800.00 degC</p> <p>&gt;= 33.00 seconds</p> <p>&gt;</p> <p><b>P050D_P1400_CatalystLightOffExtendedEngineRunTimeExit</b></p> <p>This Extended Engine run time exit is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.</p> <p>&lt; 72.00 KPa</p>	<p>Runs once per trip when the cold start emission reduction strategy is active</p> <p>Frequency: 100ms Loop</p> <p>Test completes after 8 seconds of accumulated qualified data.</p>	EWMA Based - Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Other Enable Criteria:</p> <p>OBD Manufacturer Enable Counter</p> <p>Vehicle Speed</p> <p>Allow diagnostic to calculate residual in an off-idle state. If the value of the OffIdleEnable is equal to 1 then the "DriverOffAccelPedal" will not be checked. However, if the value of OffIdleEnable is 0 then driver must be off the accel pedal</p> <p>A change in throttle position (tip-in/tip-out) will initiate a delay in the calculation of the average qualified residual value. Therefore when the:</p> <p>Pedal Close Delay Timer</p> <p>the diagnostic will continue the calculation.</p> <p>A change in gear will initiate a delay in the calculation of the average qualified residual value to</p>	<p>0</p> <p>&lt; 1.86 MPH</p> <p>0</p> <p>(A value of 1 allows diagnostic to run and calculate the residual while off idle. A value of 0 requires calculation of the residual at idle)</p> <p>&gt; 5.00 seconds</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>allow time for the actual engine speed and actual final commanded spark to achieve their desired values. Therefore, when the:</p> <p>Gear Shift Delay Timer</p> <p>the diagnostic will continue the calculation</p> <p>For Manual Transmission vehicles:</p> <p>Clutch Pedal Position</p> <p>Clutch Pedal Position</p> <p>The diagnostic will delay calculation of the residual value and potentially weight the residual calculation differently based on engine run time. This is to ensure the diagnostic is operating in idle speed control as well as during the peak catalyst light off period.</p> <p>The time weighting factor must be :</p>	<p>&gt; 1.50 seconds</p> <p>&gt; 88.00 %</p> <p>&lt; 16.00 %</p> <p>&gt; 0 These are scalar values that are a function of engine run time. Refer to</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>General Enable:</p> <p>DTC's Not Set:</p>	<p><b>P1400_ColdStartDiagnosticDelayBasedOnEngineRunTime</b> and the cal axis, <b>P1400_ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis</b> in the "Supporting Tables" for details.</p> <p>AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFP CrankSensor_FA FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA EngineMisfireDetected_FA ClutchPstnSnsr FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA 5VoltReferenceMAP_OOR_Flt TransmissionEngagedState_FA EngineTorqueEstInaccurate</p>		

## 20 OBDG03A ECM Summary Tables

[illegible]

## 20 OBDG03A ECM Summary Tables

[illegible]



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Engine Speed Request Circuit	P150C	This DTC monitors for an error in communication with the Transmission Engine Speed Request signal in \$19D	Communication of the Alive Rolling Count or Protection Value in the Transmission Engine Speed signal over CAN bus is incorrect for  out of total samples	  >= 8 counts  >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts	Executes in 25ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position Steady State Actuation Fault	P1516	Detect an inability to maintain a steady state throttle position.	The absolute difference between desired and indicated throttle position is >	2.00 percent	Run/Crank voltage  TPS minimum learn is not active AND Throttle is being Controlled  Throttle is considered in a steady state condition when the desired throttle position over a 12.5 ms period is  For a settling time period  Ignition voltage failure is false	> 6.41 Volts      < 0.25 percent  > 4.00 seconds   P1682	0.49 ms	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Communicati on Error with Active Grill Air Shutter Module "A"	P151E	This DTC monitors for an internal error or error in communication with the Active Grill Air Shutter Module A	Communication of the Alive Rolling Count from the Shutter Module A over LIN bus is incorrect or the Shutter Module A signals has an internal error for  out of total samples	   <div>&gt;= 8.00 counts</div> <div>&gt;= 10.00 counts</div>	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage	<div>= Is available</div> <div>&gt;= 3,000.00 milliseconds</div> <div>= Run</div> <div>&gt;= 11.00 Volts</div> <div>&gt;= 11.00 Volts</div>	LIN bus communication executes in 500ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Adaptive Cruise Control Signal Circuit	P1553	<p>Detects rolling count or protection value errors in Adaptive Cruise Control Axle Torque Command serial data signal</p> <p>"Emissions Neutral Default Action : When the ECM determines that a serial communication fault has occurred with the EOCM or the ACC module in data frame \$2CB, the code is set and the Adaptive Control Cruise will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails." Only applicable for applications with ACC feature.</p>	If x of y rolling count / protection value faults occur, disable adaptive cruise control for duration of fault		Adaptive Cruise Control Command Serial Data Error Diagnostic Enable	1.00	9 / 17 counts	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Switch State Undertermin ed	P155A	<p>Detects when cruise switch state cannot be determined, such as low voltage conditions</p> <p>"Emissions Neutral Default Action : When the BCM tells the ECM that the cruise switch "Data Invalid" (latched on/off switch architectures) or "Indeterminate" (momentary on/off switch architectures) is detected for too long, ECM sets the code and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."</p>	cruise switch state is received as "undetermined" for greater than a calibratable time	fail continuously for greater than 3.0 seconds			fail continuously for greater than 3.0 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage Signal Message Counter Incorrect	P155E	This DTC monitors for an error in communication with the DC/DC Converter Actuator Voltage Signal	Communication of the Alive Rolling Count or Protection Value from the DC/DC Converter over CAN bus is incorrect for  out of total samples	  >= 8 counts  >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts	Executes in 10ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Ignition Switch Run/ Start Position Signal Message Counter Incorrect	P156D	This DTC monitors for an error in communication with the DC/DC Converter Run/ Crank Terminal Status Signal	Communication of the Alive Rolling Count or Protection Value from the DC/DC Converter over CAN bus is incorrect for  out of total samples	  >= 8 counts  >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts	Executes in 10ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Crank Control Signal Message Counter Incorrect	P156E	This DTC monitors for an error in communication with the DC/DC Converter Crank Control Terminal Signal	Communication of the Alive Rolling Count or Protection Value from the DC/DC Converter over CAN bus is incorrect for  out of total samples	  >= 8 counts  >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts	Executes in 10ms loop.	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Bus Relay Feedback Circuit High Voltage	P157A	This DTC checks that the Sensor Bus Relay output is not stuck high	The Sensor Bus Relay output is stuck high	>= KeSBRR_Cnt_SB_Rly StkHiFailThrsh within KeSBRR_Cnt_SB_Rly StkHiSmplThrsh samples	The Sensor Bus Relay output has been inactive	>= KeSBRR_t_SB_RelayCo mmandedOff		Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Calibration Incorrect	P158A	Type of cruise in Body Control Module does not match that in the Engine Control Module for 2.5 seconds  "Emissions Neutral Default Action : This diagnostic compares the BCM and the ECM configuration calibrations of whether No Cruise, Conventional Cruise Control, or ACC is available on the vehicle. If the calibration for the cruise system type in the ECM does not match the value in \$4E9 signal Vehicle Speed Control System Type, a P158A DTC is set and cruise control is disabled."	Type of cruise system in GMLAN \$4E9 does not match with that in the Engine Control Module for a fix time.	2.5 seconds	DID \$40 from BCM says cruise system is present (ECM receives programmable information from Body Control Module)  OR  ECM will not receive Programmable information for Cruise from Body Control Module	True	fail continuously for greater than 2.5 seconds.	Type C, No SVS "Emissions Neutral Diagnostics – Special Type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Front Object Detection Control Module Torque Request Signal Message Counter Incorrect	P15F6	<p>Detects rolling count or protection value errors in Collision Preparation System Axle Torque Command serial data signal</p> <p>"Emissions Neutral Default Action : When the ECM determines that a serial communication fault has occurred with the EOCM in frame \$2CD, the code is set and the Collision Preparation System is disabled." Only applicable for applications with Full Speed Range Adaptive Cruise Control and Collision Preparation System feature.</p>	If x of y rolling count / protection value faults occur, disable collision preparation system for duration of fault		Front Object Detection Module Torque Request Serial Data Error Diagnostic Enable	1.00	4 / 10 counts	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Automatic Braking Engine Torque Request Signal Message Incorrect	P15F8	<p>Detects rolling count or protection value errors Rear Virtual Bumper Axle Torque Command serial data signal</p> <p>"Emissions Neutral Default Action : When the ECM determines that a serial communication fault has occurred with the EOCM in frame \$2F9, the code is set and the auto braking feature is disabled for the remainder of the key cycle." Only applicable for applications with Full Speed Range Adaptive Cruise Control and Collision Preparation System feature.</p>	If x of y rolling count / protection value faults occur, disable rear virtual bumper or collision preparation system for duration of fault		Automatic Braking Engine Torque Request Serial Data Error Diagnostic Enable	1.00	4 / 10 counts	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Wheel Speed Sensor Sequence Number Incorrect	P15FD	This DTC monitors wheel speed signals for an incorrect sequence	<p>Communication of the wheel speed sequence numbers from the ABS / Brake Control Module is incorrect.</p> <p>A complete set of sequence numbers has not been received for</p> <p>and this state is continuous for</p> <p>out of a total sample time of</p>	<p>&gt; 10.00 seconds</p> <p>&gt; 4.00 seconds</p> <p>&gt; 5.00 seconds</p>	<p>Sequence Number Error DTC is enabled</p> <p>Power Mode</p> <p>Run/Crank Ignition Voltage</p> <p>Driven and non-driven wheel rotational status is currently being received and not failsoft.</p>	<p>= 1 (1 indicates enabled)</p> <p>= Run or Crank</p> <p>&gt;= 11.00 Volts</p>	Diagnostic executes in 25ms loop	Type C, No SVS

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Sensor Signal Message Counter Incorrect	P15FF	This DTC monitors for an internal error or error in communication with the Battery Monitor Signal	<p>Communication of the Alive Rolling Count from the Battery Monitor Module in frame 1E over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for</p> <p>out of total samples</p> <p>Or</p> <p>Communication of the Alive Rolling Count from the Battery Monitor Module in frame 15 over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for</p> <p>out of total samples</p> <p>Or</p> <p>Communication of the Alive Rolling Count from the Battery Monitor Module in frame 16 over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for</p> <p>out of total samples</p> <p>Or</p> <p>Communication of the Alive Rolling Count from</p>	<p>&gt;= 8.00 counts</p> <p>&gt;= 10.00 counts</p> <p>&gt;= 8.00 counts</p> <p>&gt;= 10.00 counts</p> <p>&gt;= 8.00 counts</p> <p>&gt;= 10.00 counts</p>	<p>Message frame</p> <p>All the following conditions are met for</p> <p>Power Mode</p> <p>Powertrain Relay Voltage</p> <p>Run/Crank Ignition Voltage</p>	<p>= Is available</p> <p>&gt;= 3,000.00 milliseconds</p> <p>= Run</p> <p>&gt;= 11.00 Volts</p> <p>&gt;= 11.00 Volts</p>	Fastest periodic communication rate to Battery Monitor Module on LIN bus executes at 250ms.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>the Battery Monitor Module in frame 17 over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for</p> <p>out of total samples</p> <p>Or</p> <p>Communication of the Alive Rolling Count from the Battery Monitor Module in frame 18 over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for</p> <p>out of total samples</p> <p>Or</p> <p>Communication of the Alive Rolling Count from the Battery Monitor Module in frame 19 over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for</p> <p>out of total samples</p> <p>Or</p> <p>Communication of the Alive Rolling Count from the Battery Monitor Module in frame 1D over LIN bus is incorrect or the</p>	<p>&gt;= 8.00 counts</p> <p>&gt;= 10.00 counts</p> <p>&gt;= 8.00 counts</p> <p>&gt;= 10.00 counts</p> <p>&gt;= 8.00 counts</p> <p>&gt;= 10.00 counts</p>				

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Battery Monitor Module signals it has an internal error for</p> <p>out of total samples</p> <p>Or</p> <p>Communication of the Alive Rolling Count from the Battery Monitor Module in frame 1A over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for</p> <p>out of total samples</p> <p>Or</p> <p>Communication of the Alive Rolling Count from the Battery Monitor Module in frame 1B over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for</p> <p>out of total samples</p> <p>Or</p> <p>Communication of the Alive Rolling Count from the Battery Monitor Module in frame 1C over LIN bus is incorrect or the Battery Monitor Module signals it has an internal error for</p>	<p>&gt;= 8.00 counts</p> <p>&gt;= 10.00 counts</p> <p>&gt;= 8.00 counts</p> <p>&gt;= 10.00 counts</p> <p>&gt;= 8.00 counts</p> <p>&gt;= 10.00 counts</p> <p>&gt;= 8.00 counts</p>				



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			out of total samples	>= 10.00 counts				

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump current monitor	P163A	This DTC Diagnoses the current from the control area and compares it with calibrated thresholds to set current high and low flags	SIDI fuel pump High Current Test  Current  SIDI fuel pump Low Current Test  Current	  >= 11.00 Amps     <= 0.10 Amps	Battery Voltage  Low Side Fuel Pressure  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA	>= 11 Volts  > 0.275 MPa  Enabled when a code clear is not active or not exiting device control Engine is not cranking	Current High/Low  10 seconds failures out of 12.50 seconds sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Ignition voltage out of correlation error(P1682) not active and  Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -12.0 degC -12 <= Temp degC <= 128		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Reference Voltage Status Message Counter Incorrect	P165C	This DTC monitors for an error in communication with the Sensor Reference Voltage Status Signals	Communication of the Alive Rolling Count or Protection Value from the Fuel Control System over CAN bus is incorrect for  out of total samples	  >= 8 counts  >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage  And  Sensor Bus Relay	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts   = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Voltage Signal Message Counter Incorrect	P167F	This DTC monitors for an error in the FTZM Battery Voltage Signal Message Counter	Communication of the Alive Rolling Count or Protection Value from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for  out of total samples	  >= 8 counts  >= 10 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage  Sensor Bus Relay	= Is available  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts  = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage and the Powertrain Relay Ignition Voltage. The diagnostic monitors the difference in voltage between Run/Crank Voltage and the Powertrain Relay Ignition Voltage and fails the diagnostic when the voltage difference is too high. This diagnostic only runs when the powertrain is commanded on and the Run/Crank Voltage is greater than a threshold based on IAT or the powertrain ignition voltage is high enough the Run/Crank voltage is high enough.	Run/Crank – PT Relay Ignition  >	3.00 Volts	Powertrain commanded on  AND  (Run/Crank voltage > Table, f(IAT). See supporting tables: <b>P1682_PT Relay Pull-in Run/Crank Voltage f(IAT)</b> OR PT Relay Ignition voltage)  AND  Run/Crank voltage	> 5.50 Volts          <div style="display: flex; justify-content: space-between;"> <span>&gt; 5.50 Volts</span> <span>&gt; 5.50 Volts</span> </div>	240 / 480 counts; or  0.175 sec continuous;  12.5 ms/count in main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit Low (Gasoline applications ONLY)	P16A0	Detects a continuous or intermittent short low or open fault in the TPS SENT Communication Circuit by monitoring the voltage and failing the diagnostic when the voltage for the wave pulse is below state threshold as defined by SAE J2716 SENT Protocol. This diagnostic only runs when battery voltage is high enough.	Voltage for wave pulse is below state threshold as defined by SAE J2716 SENT Protocol	0.5 V	Run/Crank voltage	> 6.41 Volts	79 / 159 counts;  57 counts continuous;  3.125 ms /count in the ECM main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit High (Gasoline applications ONLY)	P16A1	Detects a continuous or intermittent short high fault in the TPS SENT Communication Circuit by monitoring the voltage and failing the diagnostic when the voltage for the wave pulse is above state threshold as defined by SAE J2716 SENT Protocol. This diagnostic only runs when battery voltage is high enough. Detects a High Circuit Fault in the TPS SENT Communication Circuit	Voltage for wave pulse is above state threshold as defined by SAE J2716 SENT Protocol	4.1 V	Run/Crank voltage	> 6.41 Volts	79 / 159 counts;  57 counts continuous;  3.125 ms /count in the ECM main processor	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit Performance (Gasoline applications ONLY)	P16A2	Detects a message fault in the TPS SENT Communication Circuit by monitoring the message pulse time and failing the diagnostic when the time for the pulse is above a low time threshold or above a high time threshold or if the message age limit is greater than a time threshold. This diagnostic only runs when battery voltage is high enough. Detects a Message Fault in the TPS SENT Communication Circuit	Message Pulse < Message Pulse > or Message Age Limit >=  or Signal CRC fails	0.125977 ms 0.209991 ms  3.125 ms	Run/Crank voltage	> 6.41 Volts	79 / 159 counts;  57 counts continuous;  3.125 ms /count in the ECM main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation #2	P16A7	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage and the Powertrain Relay Ignition Voltage #2. The diagnostic monitors the difference in voltage between Run/Crank Voltage and the Powertrain Relay Ignition Voltage and fails the diagnostic when the voltage difference is too high. This diagnostic only runs when the powertrain is commanded on and the Run/Crank Voltage is greater than a threshold based on IAT or the powertrain ignition voltage is high enough the Run/Crank voltage is high enough. Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage #2.	Run/Crank – PT Relay Ignition  >	3.00 Volts	Powertrain commanded on  AND  (Run/Crank voltage >  Table, f(IAT). See supporting tables: <b>P1682_PT Relay Pull-in Run/Crank Voltage f(IAT)</b> OR PT Relay Ignition voltage)  AND  Run/Crank voltage	> 5.50 Volts          <div> <div>&gt; 5.50 Volts</div> </div>	240 / 480 counts; or  0.175 sec continuous;  12.5 ms/count in main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Controls Ignition Relay Feedback Circuit 2 Low Voltage - (GEN III Controllers ONLY)	P16AF	Detects low voltage in the engine controls ignition relay feedback circuit 2. This diagnostic reports the DTC when low voltage is present. Monitoring occurs when run crank voltage is above a calibrated value.	Engine controls ignition relay feedback circuit 2 low voltage	Relay voltage <= 5.00	Powertrain relay low diag enable  Powertrain relay voltage  Run Crank voltage  Powertrain relay state	= 1.00  >= 11.00  > 9.00  = ON	5 failures out of 6 samples  1000 ms / sample	Type C, No SVS

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Controls Ignition Relay Feedback Circuit 2 High Voltage - (GEN III Controllers ONLY)	P16B3	Detects high voltage in the engine controls ignition relay feedback circuit 2. This diagnostic reports the DTC when high voltage is present. Monitoring occurs when the relay state is inactive.	Engine controls ignition relay feedback circuit 2 high voltage	Relay voltage $\geq 4.00$	Powertrain relay high diag enable  Powertrain relay state	= 1.00  = INACTIVE	50 failures out of 63 samples  100 ms / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Circuit Low Voltage	P16D4	This DTC monitors for a battery module low voltage circuit fault	Battery Module signals a low voltage circuit fault via LIN bus  VeVITR_U_12VBattVolt	< 3.00 Volts for 200 fail counts out of 250 sample counts	The diagnostic is enabled  System Diagnostics Disabled  Power Mode  12V System Reference Voltage  LIN Bus Off or Battery Module Communication Faults Active  Outside Air Temperature  Outside Air Temperature Validity Bit	= 1 (1 indicates enabled)  = False  Not equal off  > 9.00 Volts  = False  > -20.00 Celsius and < 50.00 Celsius  = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Circuit High Voltage	P16D5	This DTC monitors for a battery module high voltage circuit fault	Battery Module signals a high voltage circuit fault via LIN bus  VeVITR_U_12VBattVolt	> 26.00 Volts for 200 fail counts out of 250 sample counts	The diagnostic is enabled  System Diagnostics Disabled  Power Mode  12V System Reference Voltage  LIN Bus Off or Battery Module Communication Faults Active  Outside Air Temperature  Outside Air Temperature Validity Bit	= 1 (1 indicates enabled)  = False  Not equal off  > 9.00 Volts  = False  > -20.00 Celsius and < 50.00 Celsius  = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Current Low	P16D6	This DTC monitors for a battery module current low fault	Battery Module signals a current low fault via LIN bus  VeVITR_I_12VBattCurrRaw	< -1400 Amps for 200 fail counts out of 250 sample counts	The diagnostic is enabled  System Diagnostics Disabled  Power Mode  12V System Reference Voltage  LIN Bus Off or Battery Module Communication Faults Active  Outside Air Temperature  Outside Air Temperature Validity Bit	= 1 (1 indicates enabled)  = False  Not equal off  > 9.00 Volts  = False  > -20.00 Celsius and < 50.00 Celsius  = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Bus Relay Control Circuit High	P16D9	This DTC checks that the Sensor Bus Relay output is not shorted to power	The Sensor Bus Relay output circuit is shorted to power	>= KeSBRD_Cnt_RlyPsht Fail within KeSBRD_Cnt_RlyPsht Smpl samples	The Sensor Bus Relay Commanded Output state	= On		Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Current High	P16DD	This DTC monitors for a battery module current high fault	Battery Module signals a current high fault via LIN bus  VeVITR_I_12VBattCurrRaw	> +1400 Amps for 200 fail counts out of 250 sample counts	The diagnostic is enabled  System Diagnostics Disabled  Power Mode  12V System Reference Voltage  LIN Bus Off or Battery Module Communication Faults Active  Outside Air Temperature  Outside Air Temperature Validity Bit	= 1 (1 indicates enabled)  = False  Not equal off  > 9.00 Volts  = False  > -20.00 Celsius and < 50.00 Celsius  = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Internal Temperature Circuit Low	P16DE	This DTC monitors for a battery module internal temperature circuit low fault	Battery Module raw temperature 1 value	> 120.00 Celsius	<p>The historical mode diagnostic is enabled and / or The continuous mode diagnostic is enabled</p> <p>System Diagnostics Disabled</p> <p>Power Mode</p> <p>12V System Reference Voltage</p> <p>LIN Bus Off or Battery Module Communication Faults Active</p> <p>Outside Air Temperature</p> <p>Outside Air Temperature Validity Bit</p> <p>For Historical Mode IBS Down Counter (over LIN bus) For Continuous Mode IBS Down Counter (over LIN bus)</p> <p>IBS Measure Temperature Data Available over LIN bus</p>	<p>= 1 (1 indicates enabled)</p> <p>= 1 (1 indicates enabled)</p> <p>= False</p> <p>Not equal off</p> <p>&gt; 9.00 Volts</p> <p>= False</p> <p>&gt; -20.00 Celsius and &lt; 50.00 Celsius</p> <p>= True</p> <p>Between 1 and 24 or zero</p> <p>= zero</p> <p>= True</p>	<p>4 failed samples within 5 total samples</p> <p>Diagnostic runs in the 250 ms loop</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Internal Temperature Circuit High	P16DF	This DTC monitors for a battery module internal temperature circuit high fault	Battery Module raw temperature 1 value	< -43.00 Celsius	The historical mode diagnostic is enabled and / or The continuous mode diagnostic is enabled  System Diagnostics Disabled  Power Mode  12V System Reference Voltage  LIN Bus Off or Battery Module Communication Faults Active  Outside Air Temperature  Outside Air Temperature Validity Bit  For Historical Mode IBS Down Counter (over LIN bus)  For Continuous Mode IBS Down Counter (over LIN bus)  IBS Measure Temperature Data Available over LIN bus	= 1 (1 indicates enabled)  = 1 (1 indicates enabled)  = False  Not equal off  > 9.00 Volts  = False  > -20.00 Celsius and < 50.00 Celsius  = True  Between 1 and 24  = zero  = True	4 failed samples within 5 total samples  Diagnostic runs in the 250 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Random Access Memory (RAM) Error	P16E1	This DTC monitors for a battery module RAM memory fault	Battery Module signals a RAM memory fault via LIN bus  VeVITR_e_IBS_IntRAM_Fault	= CeVITR_e_DiagFailed	The diagnostic is enabled  System Diagnostics Disabled  Power Mode  12V System Reference Voltage  LIN Bus Off or Battery Module Communication Faults Active  Outside Air Temperature  Outside Air Temperature Validity Bit	= 1 (1 indicates enabled)  = False  Not equal off  > 9.00 Volts  = False  > -20.00 Celsius and < 50.00 Celsius  = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Read Only Memory (ROM) Error	P16E2	This DTC monitors for a battery module ROM memory fault	Battery Module signals a ROM memory fault via LIN bus  VeVITR_e_IBS_IntROM_Fault	= CeVITR_e_DiagFailed	The diagnostic is enabled  System Diagnostics Disabled  Power Mode  12V System Reference Voltage  LIN Bus Off or Battery Module Communication Faults Active  Outside Air Temperature  Outside Air Temperature Validity Bit	= 1 (1 indicates enabled)  = False  Not equal off  > 9.00 Volts  = False  > -20.00 Celsius and < 50.00 Celsius  = True	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Monitor Module Data Incompatible	P16E3	This DTC monitors for a battery module data incompatible fault	<p>Battery Module data received over LIN bus is incompatible. (Measured by any of the following)</p> <p>Historical Test</p> <p>Absolute value of IBS battery capacity C20 data (IBS Return Nominal C20 - 70.00 Ah)</p> <p>or</p> <p>IBS Returns a battery type that is not equal to</p> <p>or</p> <p>Absolute value of (IBS Return Battery Calibration#1 U40@25 C - 12.08 V)</p> <p>or</p> <p>Absolute value of (IBS Return Battery Calibration#1 U80@25 C - 12.64 V)</p> <p>Continuous Test</p>	<p>Upon IBS wakeup, if any of the below Historical Test conditions are satisfied, the diagnostic fails.</p> <p>&gt; 5.00 Ah</p> <p>CeBSER_e_IBS_Cfg BatAGM</p> <p>&gt; 0.50 Volts</p> <p>&gt; 0.50 Volts</p> <p>If any of the below conditions are satisfied for 16.00 fail counts</p>	<p>The historical mode diagnostic is enabled and / or The continuous mode diagnostic is enabled</p> <p>System Diagnostics Disabled</p> <p>Power Mode</p> <p>12V System Reference Voltage</p> <p>LIN Bus Off or Battery Module Communication Faults Active</p> <p>Outside Air Temperature</p> <p>Outside Air Temperature Validity Bit</p> <p>IBS Configuration Data Available over LIN bus</p> <p>Historical Test Only Host Controller MEC Counter</p>	<p>= 1 (1 indicates enabled)</p> <p>= 1 (1 indicates enabled)</p> <p>= False</p> <p>Not equal off</p> <p>&gt; 9.00 Volts</p> <p>= False</p> <p>&gt; -20.00 Celsius and &lt; 50.00 Celsius</p> <p>= True</p> <p>= True</p> <p>&lt;= 0</p>	Diagnostic runs in the 250 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Absolute value of IBS battery capacity C20 data (IBS Return Nominal C20 - 70.00 Ah)</p> <p>or</p> <p>IBS Returns a battery type that is not equal to</p> <p>or</p> <p>Absolute value of (IBS Return Battery Calibration#1 U40@25 C - 12.08 V)</p> <p>or</p> <p>Absolute value of (IBS Return Battery Calibration#1 U80@25 C - 12.64 V)</p>	<p>out of 20.00 sample counts, the diagnostic fails.</p> <p>&gt; 5.00 Ah</p> <p>CeBSER_e_IBS_Cfg BatAGM</p> <p>&gt; 0.50 Volts</p> <p>&gt; 0.50 Volts</p>				

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure & Temperature Sensor Communicati on Circuit 3 Low Voltage	P16E4	This DTC determines if the SENT signal shorted low, this is determined by monitoring the number pulses on the SENT signal line received at the ECU and the SENT Signal Line State always indicating low.	The number pulses on the SENT signal line  SENT Signal Line State	<= 35  = Low	SENT Sensor Communication Circuit Diagnostic Enabled  SENT power up delay	True  >= 0.00 seconds  Enabled when a code clear is not active or not exiting device control	400 failures out of 500 samples  6.25 ms per sample Continuous	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure & Temperature Sensor Communicati on Circuit 3 High Voltage	P16E5	This DTC determines if the SENT signal shorted low, this is determined by monitoring the number pulses on the SENT signal line received at the ECU and the SENT Signal Line State always indicating high.	The number pulses on the SENT signal line  SENT Signal Line State	<= 35  = High	SENT Sensor Communication Circuit Diagnostic Enabled  SENT power up delay	True  >= 0.00 seconds  Enabled when a code clear is not active or not exiting device control	400 failures out of 500 samples  6.25 ms per sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 1	P16F0	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor before receiving a valid message.		Run/Crank voltage	> 6.41 Volts	39 / 399 counts continuous; 12.5 ms /count in the ECM main processor	Type A, 1 Trips
			This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor after receiving a valid message.		Run/Crank voltage	> 6.41 Volts	159 / 399  counts continuous; 12.5 ms /count in the ECM main processor	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Redundant Memory Performance (Gasoline applications ONLY)	P16F3	Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures  For all of the following cases: If the individual diagnostic threshold is equal to 2048 ms, this individual case is not applicable. If any of the following cases are X out of Y diagnostics and the fail (x) is greater than the sample (Y), this individual case is also not applicable.	Equivance Ratio torque compensation exceeds threshold	-65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	Type A, 1 Trips
			Absolute difference between Equivance Ratio torque compensation and its dual store out of bounds given by threshold	65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	126.20 mg	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	15.00 degrees		Engine speed >0rpm	Up/down timer 425 ms continuous, 0.5 down time multiplier	
			Torque Learn offset is out of bounds given by threshold range	High Threshold  0.00 Nm  Low Threshold  0.00	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Nm				
			One step ahead calculation of air-per-cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed > 650 rpm	Up/down timer 441 ms continuous, 0.5 down time multiplier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 779.30 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 779.30 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Arbitrated Air-Per-Cylinder filter coefficient is out of bounds given by threshold range	High Threshold 1.000  Low Threshold 0.074	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Launch spark is active but the launch spark redundant path indicates it should not be active	N/A		Engine speed < 7,000.00 or 7,200.00 rpm (hysteresis pair)	Up/down timer 141 ms continuous, 0.5 down time multiplier	
			Rate limited vehicle speed and its dual store do not equal	N/A		Time since first CAN message with vehicle speed >= 0.500 sec	10 / 20 counts; 25.0msec/count	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded engine torque due to fast actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to slow actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			TOS to wheel speed conversion factor is out of bounds given by threshold range	High Threshold:  1.10 T/C Range Hi  0.10 T/C Range Lo  Low Threshold:  1.10 T/C Range Hi  0.10 T/C Range Lo	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cylinders active greater than commanded	2 cylinders		Engine run flag = TRUE > 2.00 s Number of cylinder events since engine run > 24  No fuel injector faults active	Up/down timer 441 ms continuous, 0.5 down time multiplier	
			Transfer case neutral request from four wheel drive logic does not match with operating conditions	N/A	Ignition State	Accessory, run or crank  Transfer case range valid and not over-ridden  FWD Apps only	7.00 / 10.00 counts; 25.0msec/count	
			Driver progression mode and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Predicted torque for uncorrected zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). <b>P16F3_Speed Control External Load f(Oil Temp, RPM)</b> + 65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	64.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	64.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							down time multiplier	
			Positive Torque Offset is greater than its redundant calculation plus threshold  OR  Positive Torque Offset is less than its redundant calculation minus threshold	65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous,  down time	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier 0.5	
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Hybrid Immediate Crankshaft Request is less than its redundant calculation minus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Regeneration Brake Assist is not within a specified range	Brake Regen Assist < 0 Nm or Brake Regen Assist > 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			1. Cylinder Torque Offset exceeds step size threshold  OR	1. 65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			2. Sum of Cylinder Torque Offset exceeds sum threshold	2. 65.23 Nm				
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold	65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 141 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Speed Lores Intake Firing timing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 141 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: <b>P16F3_Speed Control External Load f(Oil Temp, RPM)</b> + 65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: <b>P16F3_Speed Control External Load f(Oil Temp, RPM)</b> +	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				65.23 Nm				
			Difference between Driver Requested Immediate Torque primary path and its secondary exceeds threshold	779.30 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Driver Immediate Request is less than its redundant calculation minus threshold	779.30 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Request is greater than its redundant calculation plus threshold	779.30 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR  Commanded Immediate Request is less than its redundant calculation minus threshold				multiplier	
			Commanded Immediate Response Type is set to Inactive	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Difference between Cruise Axle Torque Arbitrated Request and Cruise Axle Torque Request exceeds threshold	29.22 Nm		Cruise has been engaged for more than 4.00 seconds	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired engine torque request greater than redundant calculation plus threshold	64.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Engine min capacity above threshold	65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 126 ms continuous, 0.5 down time multiplier	
			No fast unmanaged retarded spark above the applied spark plus the threshold	15.00 Degree		Engine speed greater than 0rpm	Up/down timer 425 ms continuous, 0.5 down time multiplier	
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s	Ignition State	Accessory, run or crank	Up/down timer 172 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Absolute difference of redundant calculated engine speed above threshold	1,285 RPM		Engine speed greater than 0 RPM	Up/down timer 141 ms continuous, 0.5 down time multiplier	
			After throttle blade pressure and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Speed Control's Predicted Torque Request and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine oil temperature and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 403 ms continuous, 0.5 down time multiplier	
			Desired throttle position greater than redundant calculation plus threshold	10.00 percent	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	0.06 kpa	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Throttle desired torque above desired torque plus threshold	65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired filtered throttle torque exceeds the threshold plus the higher of desired throttle torque or modeled throttle torque	65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque feedback proportional term is out of allowable range or its dual store copy does not match	High Threshold  32.62 Nm   Low Threshold  -32.62 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque feedback integral term magnitude or rate of change is out of allowable range or its dual store	High Threshold  61.16 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			copy do not match	Low Threshold  -65.23 Nm  Rate of change threshold  4.08 Nm/loop			down time multiplier	
			Difference of Final Torque feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	High Threshold  65.23 Nm  Low Threshold  - 65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of torque desired throttle area and	High Threshold	Ignition State	Accessory, run or crank	Up/down timer 475	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			its redundant calculation is out of bounds given by threshold range	2.96 %  Low Threshold -2.96 %			ms continuous, 0.5 down time multiplier	
			Difference of torque model coefficients and its redundant calculation is out of bounds given by threshold range	High Threshold 0.0001858 Low Threshold -0.0001858	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold  65.23 Nm  Low Threshold  -65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 65.23 Nm  Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			AC friction torque is greater than commanded by AC control software or less than threshold limit	High Threshold 39.00 Nm  Low Threshold 0.00 Nm				
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 65.23 Nm			Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold  - 65.23 Nm				
			Generator friction torque is out of bounds given by threshold range	High Threshold  65.23 Nm  Low Threshold  0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between the Supercharger friction torque and its redundant calculation greater than threshold	65.23 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Filtered Torque error magnitude or its increase rate of change is out of	High Threshold  65.23		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous,	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			allowable range or its dual store copy do not match	Nm  Low Threshold  -65.23 Nm  Rate of change threshold  4.08 Nm/loop			0.5 down time multiplier	
			Torque error compensation is out of bounds given by threshold range	High Threshold  65.23 Nm  Low Threshold  0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Delta Torque Baro compensation is out of bounds given by threshold	High Threshold  2.20	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous,	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			range	Nm			0.5 down time multiplier	
			Low Threshold  -6.54 Nm					
			1. Difference of reserve torque value and its redundant calculation exceed threshold  OR  2. Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation exceed threshold  OR  3. Rate of change of reserve torque exceeds threshold, increasing direction only  OR  4. Reserve engine torque above allowable capacity threshold	1. 64.23 Nm  2. N/A  3. 64.23 Nm  4. 64.23 Nm	3. & 4.: Ignition State	1. & 2.: Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 65.23 Nm  3. & 4.: Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Vacuum and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated Intake Manifold Pressure during engine event versus during time event is greater than threshold	Table, f(Desired Engine Torque). See supporting tables: <b>P16F3_Delta MAP Threshold f(Desired Engine Torque)</b>		Engine speed >0rpm	Up/down timer 141 ms continuous, 0.5 down time multiplier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Driver Predicted Request is greater than its redundant calculation plus threshold  OR	779.30 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Driver Predicted Request is less than its redundant calculation minus threshold					
			Cold Delta Friction Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Predicted torque for zero pedal determination is greater than calculated limit.	Table, f(Oil Temp, RPM). See supporting tables: <b>Speed Control External Load f(Oil Temp, RPM) + 65.23 Nm</b>	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Predicted	1 Nm	Ignition State	Accessory, run or crank	Up/down timer	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Axle Torque and its dual store do not match				475 ms continuous, 0.5 down time multiplier	
			Steady State Estimated Engine Torque and its dual store are not equal	N/A		AFM not changing from Active to Inactive and preload torque not changing and one loop after React command  Engine speed >0rpm	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Difference of Weighting factor for number of cylinders fueled and its redundant calculation is above threshold	0.26		Engine run flag = TRUE > 10.00 s	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference of minimum spark advance limit and its redundant calculation is out of bounds given by threshold range	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 141 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of commanded spark advance and adjusted delivered is out of bounds given by threshold range	15.00 degrees		Engine speed >0rpm	Up/down timer 425 ms continuous, 0.5 down time multiplier	
			Absolute difference between Estimated Engine Torque and its dual store are above a threshold	65.23 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold	65.23 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	15.00 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 65.23 Nm	Up/down timer 441 ms continuous, 0.5 down time multiplier	
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range	65 Nm		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			One step ahead calculation of air-per-cylinder greater than two step ahead calculation by threshold for time	Threshold: Dynamically calculated based on current engine conditions Fault Pending Threshold:  100		Engine speed > 650 rpm	Up/down timer 441 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				ms				
			Rate limited cruise axle torque request and its dual store do not match within a threshold	29.22 Nm	Ignition State	Accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time multiplier	
			1. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its redundant calculation is out of bounds given by threshold range  OR  2. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its dual store do not equal	1. 5.00 % 2. N/A 3. N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			OR					

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			3. Absolute difference of Calculated accelerator pedal position and its dual store do not equal					
			Commanded axle torque is greater than its redundant calculation by threshold	779.30 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded axle torque is less than its redundant calculation by threshold	1,168.95 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Preload timer and its redundant calculation do not equal	N/A	Ignition State	Accessory, run or crank  AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AC friction torque is greater than commanded by AC control software	39.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (time based) calculation does not equal its redundant calculation	N/A		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated spark offset for equivalence ratio and its redundant calculation is greater than a threshold	15.00 degrees		Engine speed >0rpm	Up/down timer 141 ms continuous, 0.5 down time multiplier	
			Transmission Torque Request calculations do not equal their dual stores	N/A		Run or Crank = TRUE > 0.50 s	16 / 32 counts; 25.0msec/count	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of the predicted motor torque ACS and its redundant calculation is greater than a threshold	0.01 Nm			Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of maximum throttle area and its redundant calculation is greater than a threshold	15 mm2			Up/down timer 172 ms continuous, 0.5 down time multiplier	
			Absolute difference of Desired TIAP and its redundant calculation is greater than a threshold	5.00 kPa			Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Pedal learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Throttle learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired Throttle Position and its redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Range Signal Message Counter Incorrect	P188B	This DTC monitors for an error in communication with the Transmission Range Signal	Communication of the Alive Rolling Count or Protection Value of the Transmission Range Signal over CAN bus is incorrect for  out of total samples	   >= 8.00 counts  >= 10.00 counts	Message frame  All the following conditions are met for  Power Mode  Powertrain Relay Voltage  Run/Crank Ignition Voltage	= Is avaialble  >= 3,000.00 milliseconds  = Run  >= 11.00 Volts  >= 11.00 Volts	Executes in 250ms loop.	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Park Assistance System Performance	P18CB	Determines if Park assist active bit from EBCM is valid	Speed Error - APA active (\$1C6/\$1C7) above a vehicle speed threshold  OR Initialization Error - APA active (\$1C6/\$1C7) without an active torque request  OR Exit Error - APA transitions to inactive during active torque request above a vehicle speed threshold	> 10.00   APA active boolean transitions from False to True with Torque Intervention = No request   APA active boolean transitions from True to False with Torque Intervention <> No request when vehicle speed is > 1.00	Power Mode Engine Running  Status of traction in GMLAN message (\$4E9)  Ignition Voltage  Run/Crank Activ	= Run = True  = Traction Present  > 6.41 volts  > 0.50 seconds	>= 4 failures out of 10  Performed every 12.5ms   >= 4 failures out of 10  Performed every 12.5ms   When transition occurs, no number of samples  Performed every 12.5ms	Type C, No SVS Emissions Neutral Diagnostic - Type C



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Performance  (For use on vehicles with two fuel senders and mechanical transfer pump)	P2066	This DTC will detect a secondary fuel tank level sensor stuck in-range.	1) If Deadband diagnostic subtest Enabled AND 2a) If fuel volume in primary tank is and 2b) if fuel volume in secondary tank is and 2c) and if 2a and 2b indications do not change while fuel volume consumed by engine is	1) == Disabled status  2a) $\geq 1,024.0$ liters  2b) $< 2.0$ liters  2c) $\geq 18.0$ liters	1a) Diagnostic Enabled 1b) Engine Operational Status	1a) == True 1b) == Running	250 ms / sample	Type B, 2 Trips
			1) If Secondary sensor rationality diagnostic subtest enabled AND 2a) Volume in primary tank is 2b) and volume in secondary tank is 2c) and remains in this condition for	1) == Disabled status  2a) $< 1,024$ liters  2b) $> 2$ liters  2c) $\geq 1,800$ seconds	1a) Diagnostic Enabled  1b) Engine Operational Status Engine Running	1a) == True  1b) == Running	250 ms / sample	
			a) If indicated fuel volume change is b) while fuel consumed by the engine is	a) $\leq 3.00$ liters  b) $\geq 19$ liters	1a) Diagnostic Enabled  1b) Engine Operational Status Engine Running  2) Secondary tank volume [Not Empty] is	1a) == True  1b) == Running  2) $\geq 2.0$ liters	250 ms / sample	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Circuit Low Voltage  (For use on vehicles with two fuel senders)	P2067	This DTC will detect a fuel sender out-of- range low in the secondary fuel tank.	Fuel level Sender % of 5V range	< 10 % or 27.28 liters	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	100 failures out of 125 samples  100 ms / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Circuit High Voltage  (For use on vehicles with two fuel senders)	P2068	This DTC will detect a fuel level sensor out-of- range high in the secondary fuel tank.	Fuel level Sender % of 5V range	> 60 % or 1.08 liters	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True  b) == True  c) == True  d) <> True	100 failures out of 125 samples  100 ms / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Low— Bank 1	P2088	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	$\leq 0.5 \Omega$ impedance between signal and controller ground	<p>System supply voltage</p> <p>Output driver is commanded on</p> <p>Ignition switch is in crank or run position</p>	> 11.00 Volts	<p>20 failures out of 25 samples</p> <p>250 ms /sample, continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit High – Bank 1	P2089	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	$\leq 0.5 \Omega$ impedance between signal and controller power	<p>System supply</p> <p>Output driver is commanded on</p> <p>Ignition switch is in crank or run position</p>	> 11.00 Volts	<p>20 failures out of 25 samples</p> <p>250 ms /sample, continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit Low – Bank 1	P2090	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	$\leq 0.5 \Omega$ impedance between signal and controller ground	<p>System supply voltage</p> <p>Output driver is commanded on</p> <p>Ignition switch is in crank or run position</p>	> 11.00 Volts	<p>20 failures out of 25 samples</p> <p>250 ms /sample, continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Exhaust Camshaft Actuator Solenoid Circuit High – Bank 1	P2091	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	$\leq 0.5 \Omega$ impedance between signal and controller power	<p>System supply voltage</p> <p>Output driver</p> <p>Ignition switch</p>	<p>&gt; 11.00 Volts</p> <p>On</p> <p>Crank or Run</p>	<p>20 failures out of 25 samples</p> <p>250 ms /sample, continuous</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Lean Bank 1	P2096	<p>Determines if the post catalyst O2 sensor based fuel control system is indicating a lean exhaust gas condition. If the lean condition is such that the control system utilizes all or most of its available high limit authority (high limit = 100% authority), then P2096 will set.</p> <p>The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset.</p> <p>Note: When the post catalyst O2 voltage is too lean, the post catalyst O2 integral and proportional offset control is increased (positive % authority). This applies a lean bias to fuel control in an attempt to counteract the lean condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral</p>	<p>The Average Integral Offset % Authority</p> <p>AND</p> <p>The Average Total Offset % Authority</p> <p>(Note: any value greater than or equal to +100% effectively nullifies the Average Total Offset % Authority criteria)</p> <p>High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is &gt;= 30 % for &gt;= 5.0 seconds AND the % Authority metric is approaching the failure threshold.</p> <p>Diagnosis resumes if the purge valve is closed OR the percent vapor is &lt;= 25 % for &gt;= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.</p>	<p>&gt;= 75.0 %</p> <p>&gt;= 50.0 %</p> <p>If the P2096 is actively failing then the Average Integral Offset must be &lt; 75.0 % and the Average Total Offset must be &lt; 50.0 % for the diagnostic to report a pass.</p>	<p>The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration</p> <p>Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp.</p> <p>PTO Intrusive diag. fuel control Ethanol Estimation in Progress</p> <p>O2 Heater Learned Resistance</p> <p>Long Term Secondary Fuel Trim Enabled for (see "<b>Long Term Secondary Fuel Trim Enable Criteria</b>" in Supporting Tables)</p> <p>High Vapor Conditions</p> <p>Green Cat System Condition</p>	<p>No No Yes Yes Yes</p> <p>&gt;= 70 kPa &gt;= 0.0 g/s &lt;= 10,000.0 &gt;= 0 kPa &lt;= 256 &gt;= -20 deg. C &lt;= 200 &gt;= -20 deg. C (or OBD Coolant Enable Criteria = TRUE)</p> <p>Not Active Not Active Not Active</p> <p>= Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>&gt;= 2.0 seconds</p> <p>Not Present</p> <p>= Not Valid, Green Cat System condition is considered valid until the</p>	<p>Frequency: Continuous Monitoring in 100ms loop.</p> <p>The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 45.0 seconds ( 450 samples ) before comparing to their respective failure thresholds.</p>	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of "0" (i.e. 0% authority) and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean).			No Fault Active for:	accumulated air flow is greater than 360,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is above 22 grams/sec.  AmbientAirDefault AIR System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorFA CamSensorAnyLocationFA EvapEmissionSystem_FA EvapFlowDuringNonPurge_FA FuelTankPressureSnsrCkt_FA EvapPurgeSolenoidCircuit_FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorTFTKO MAP_SensorFA MAP_EngineVacuumStatus EngineMisfireDetected_FA A/F Imbalance Bank1 O2S_Bank_1_Sensor_1_FA		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>For the cells identified as enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions column), the minimum accumulated samples required before the fuel control metric is considered usable for that cell (1 sample = 100ms):</p> <p>Deceleration Idle Cruise Light Acceleration Heavy Acceleration</p> <p>(Note: A value in any of the above operating "cells" that is an order of magnitude (or more) higher than other cells is an indication that the diagnostic is not capable of diagnosing in that cell).</p>	<p>O2S_Bank_1_Sensor_2_FA</p> <p>250 250 100 550 250</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Rich Bank 1	P2097	<p>Determines if the post catalyst O2 sensor based fuel control system is indicating a rich exhaust gas condition. If the rich condition is such that the control system utilizes all or most of its available low limit authority (low limit = -100% authority), then P2097 will set.</p> <p>The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset.</p> <p>Note: When the post catalyst O2 voltage is too rich, the post catalyst O2 integral and proportional offset control is decreased (negative % authority). This applies a lean bias to fuel control in an attempt to counteract the rich condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral</p>	<p>The Average Integral Offset % Authority</p> <p>AND</p> <p>The Average Total Offset % Authority</p> <p>(Note: any value less than or equal to -100% effectively nullifies the Average Total Offset % Authority criteria)</p> <p>High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is &gt;= 30 % for &gt;= 5.0 seconds.</p> <p>Diagnosis resumes if the purge valve is closed OR the percent vapor is &lt;= 25 % for &gt;= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.</p>	<p>&lt;= -90.0 %</p> <p>&lt;= -50.0 %</p> <p>If the P2097 is actively failing then the Average Integral Offset must be &gt; -90.0 % and the Average Total Offset must be &gt; -50.0 % for the diagnostic to report a pass.</p>	Same as P2096	Same as P2096	<p>Frequency: Continuous Monitoring in 100ms loop.</p> <p>The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 45.0 seconds ( 450 samples) before comparing to their respective failure thresholds.</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of "0" (i.e. 0% authority) and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean).						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Throttle Actuator Position Performance	P2101	1) Detect a throttle positioning error. This is determined if the difference between measured throttle position and modeled throttle position is greater than a threshold or less than a threshold. This diagnostic only runs when the engine is running and the ignition voltage is high enough and there is not an ignition voltage failure and the throttle position minimum learn is not active and the throttle is being controlled 2) Throttle control is driving the throttle in the incorrect direction. This is determined if the throttle position is greater than a threshold percent and the powertrain relay voltage is high enough and the throttle position minimum learn is active 3) Throttle control exceeds the reduced power limit. This is determined if the throttle position is greater and a threshold and the powertrain relay voltage is high enough and reduced power is active.	Difference between measured throttle position and modeled throttle position >	10.00 percent	Run/Crank voltage  TPS minimum learn is not active and Throttle is being Controlled AND (Engine Running or Ignition Voltage) OR Ignition Voltage	> 6.41 Volts  > 5.50 Volts  > 8.41 Volts	15 counts;  12.5 ms/count in the primary processor	Type A, 1 Trips
			OR  Difference between modeled throttle position and measured throttle position >	10.00 percent	Ignition voltage failure is false (P1682)			
			Throttle Position >	36.00 percent	Powertrain Relay voltage  TPS minimum learn active	> 6.41 Volts  = TRUE	11 counts;  12.5 ms/count in the primary processor	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Return to Default Performance	P2119	Throttle unable to return to default throttle position after de-energizing ETC motor.	(Normalized TPS1 percent Vref > AND Normalilzed TPS2 percent Vref > On the main processor)	1.7560 % Vref  1.7590 % Vref	PT Relay Voltage  Throttle de-energized for Actuator, Controller, or Ignition Faults No TPS circuit faults	> 5.500 Volts  (P21104, P2100, P2101, P2102, P2103, P1682, P0068, P16F3)	0.4969 s	Type C, No SVS
			OR  (Normalized TPS1 percent Vref < AND Normalilzed TPS2 percent Vref < On the main processor)	1.4340 % Vref  1.4310 % Vref	No 5V reference error or fault for # 4 5V reference circuit	P06A3		
			(Normalized TPS1 Voltage > AND Normalilzed TPS2 Voltage > On the main processor)	1.7560  1.7590	Throttle de-energized for Battery Saver Mode  Engine not running No TPS circuit faults PT Relay Voltage	> 5.500 Volts	5.0000 s	
			OR  (Normalized TPS1 Voltage < AND Normalilzed TPS2 Voltage < On the main processor)	1.4340  1.4310	No 5V reference error or fault for # 4 5V reference circuit	P06A3		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detects a continuous or intermittent short low or open in the APP sensor #1 by monitoring the APP1 sensor percent Vref and failing the diagnostic when the APP1 percent Vref is too low. This diagnostic only runs when battery voltage is high enough. Detects a continuous or intermittent short low or open in the APP sensor #1 on the Main processor.	APP1 percent Vref	< 0.4625 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P06A3	19 / 39 counts; or  14 counts continuous;  12.5 ms/count in the main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Hi	P2123	Detects a continuous or intermittent short high in the APP sensor #1 by monitoring the APP1 sensor percent Vref and failing the diagnostic when the APP1 percent Vref is too high. This diagnostic only runs when battery voltage is high enough. Detect a continuous or intermittent short high in the APP sensor #1 on the Main processor.	APP1 percent Vref >	4.7500 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P06A3	19 / 39 counts; or  14 counts continuous;  12.5 ms/count in the main processor	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detects a continuous or intermittent short low or open in the APP sensor #2 by monitoring the APP2 sensor percent Vref and failing the diagnostic when the APP2 percent Vref is too low. This diagnostic only runs when battery voltage is high enough. Detects a continuous or intermittent short low or open in the APP sensor #2 on the Main processor.	APP2 percent Vref <	0.3250 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P0697	19 / 39 counts; or  14 counts continuous;  12.5 ms/count in the main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detects a continuous or intermittent short high in the APP sensor #2 by monitoring the APP2 sensor percent Vref and failing the diagnostic when the APP2 percent Vref is too high. This diagnostic only runs when battery voltage is high enough. Detect a continuous or intermittent short high in the APP sensor #2 on the Main processor.	APP2 percent Vref >	2.6000 % Vref	Run/Crank voltage  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  P0697	19 / 39 counts; or  14 counts continuous;  12.5 ms/count in the main processor	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position (TP) Sensor 1-2 Correlation	P2135	Detect a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor. 1.) The diagnostic monitors the difference in position between TPS1 and the TPS2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. 2.) The diagnostic monitors the difference in reference voltage between normalized min TPS1 and the normalized min TPS2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	Difference between TPS1 displaced and TPS2 displaced >	6.797 % offset at min. throttle position with a linear threshold to 9.720 % at max. throttle position	Run/Crank voltage  No TPS sensor faults  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  (P0122, P0123, P0222, P0223)  P06A3	79 / 159 counts; or  58 counts continuous;  3.125 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min TPS1 ) and (normalized min TPS2) >	5.000 % Vref	Run/Crank voltage  No TPS sensor faults  No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts  (P0122, P0123, P0222, P0223)  P06A3	79 / 159 counts; or  58 counts continuous;  3.125 ms/count in the main processor	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detect a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor. 1.) The diagnostic monitors the difference in position between APP1 and the APP2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. 2.) The diagnostic also monitors the difference in reference voltage between normalized min APP1 and the normalized min APP2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >	5.000 % offset at min. pedal position with a linear threshold to 10.001 % at max. pedal position	Run/Crank voltage  No APP sensor faults  No 5V reference errors or faultst for # 3 & # 4 5V reference circuits	> 6.41 Volts  (P2122, P2123,P2127, P2128)  (P06A3, P0697)	19 / 39 counts intermittent; or  15 counts continuous,  12.5 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min APP1 ) and (normalized min APP2) >	5.000 % Vref	Run/Crank voltage  No APP sensor faults  No 5V reference errors or faultst for # 3 & # 4 5V reference circuits	> 6.41 Volts  (P2122, P2123,P2127, P2128)  (P06A3, P0697)	19 / 39 counts intermittent; or  15 counts continuous,  12.5 ms/count in the main processor	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 high side circuit shorted to ground	P2147	Controller specific output driver circuit diagnoses Injector 1 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 high side circuit shorted to power	P2148	Controller specific output driver circuit diagnoses Injector 1 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 high side circuit shorted to ground	P2150	Controller specific output driver circuit diagnoses Injector 2 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 high side circuit shorted to power	P2151	Controller specific output driver circuit diagnoses Injector 2 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	<p>&gt;= 11 Volts &gt;= 5 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 high side circuit shorted to ground	P2153	Controller specific output driver circuit diagnoses Injector 3 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 high side circuit shorted to power	P2154	Controller specific output driver circuit diagnoses Injector 3 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	          ≤ 1 volt between signal and controller power	Battery Voltage Engine Run Time	≥ 11 Volts ≥ 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 high side circuit shorted to ground	P2156	Controller specific output driver circuit diagnoses Injector 4 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 high side circuit shorted to power	P2157	Controller specific output driver circuit diagnoses Injector 4 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	          ≤ 1 volt between signal and controller power	Battery Voltage Engine Run Time	≥ 11 Volts ≥ 5 Seconds  P062B not FA or TFTK	10.00 failures out of 20.00 samples  100 ms /sample Continuous	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Minimum Throttle Position Not Learned	P2176	Detect when the throttle position minimum learn on the main processor is not learned. This diagnostic detects this by monitoring if the throttle position is greater than a threshold and the number of learn attempts is greater than a threshold. This diagnostic only runs when the battery voltage is high enough and the throttle position minimum learn is active. Throttle position sensors were not in the minnum learn window after multiple attempts to learn the minimum.	During TPS min learn on the Main processor, TPS percent Vref >  AND  Number of learn attempts >	0.5740 % Vref   10 counts	Run/Crank voltage  TPS minimum learn is active  No previous TPS min learn values stored in long term memory	> 6.41 Volts  = TRUE	2.0 secs	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 1 / 2 Correlation	P2199	<p>Detects when the Intake Air Temperature (IAT) sensor and IAT2 sensor values do not correlate with each other. These two temperature sensors are both in the induction system, although they do have different sensor time constants and different positional relationships with components that produce heat. If these two temperature values differ by a large enough amount, the Intake Air Temperature 1 / 2 Correlation Diagnostic will fail.</p> <p>This diagnostic is enabled if the Powertrain Relay voltage is high enough.</p>	ABS (IAT - IAT2)	> 55.0 deg C	<p>Powertrain Relay Voltage for a time</p> <p>No Active DTCs:</p>	<p>&gt;= 11.0 Volts &gt;= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Bank 1 Air- Fuel Ratio Imbalance	P219A	<p>This monitor determines if there is an Air Fuel Imbalance in the fueling system for a cylinder on a Bank 1. Detection is based on a the pre catalyst oxygen sensor voltage. The pre catalyst O2 voltage is used to generate a variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without).</p> <p>The observed Variance is dependent on engine speed and load and is normalized by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric.</p> <p>The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (see Supporting Table</p>	<p>Filtered Ratio &gt;</p> <p>The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (see Supporting Table</p> <p><b>P219A Variance Threshold Bank1 Table</b>) and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table (see Supporting Table</p> <p><b>P219A Normalizer Bank1 Table</b> ). This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (see Supporting Table</p> <p><b>P219A Quality Factor Bank1 Table</b> ). This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used.</p>	0.45	<p>If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.19 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing when the Filtered Ratio remains near the initial failure threshold of 0.45 .</p>	<p>System Voltage</p> <p>Fuel Level</p> <p>Engine Coolant Temperature</p> <p>Cumulative engine run time</p> <p>Diagnostic enabled at Idle (regardless of other operating conditions)</p> <p>Engine speed range</p> <p>Engine speed delta during a short term sample period</p> <p>Mass Airflow (MAF) range</p> <p>Cumulative delta MAF during a short term sample period</p> <p>Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF = 0.050</p> <p>Air Per Cylinder (APC)</p>	<p>no lower than 11.0 Volts for more than 0.2 seconds</p> <p>&gt; 10.0 % The diagnostic will disregard the fuel level criteria if the fuel sender is faulty.</p> <p>&gt; -20 deg. C (or OBD Coolant Enable Criteria = TRUE)</p> <p>&gt; 0.0 seconds</p> <p>No</p> <p>900 to 6,000 RPM</p> <p>&lt; 150 RPM</p> <p>8 to 500 g/s</p> <p>&lt; 2 g/s</p> <p>&lt; 0.25 g/s</p> <p>200 to 800 mg/cylinder</p>	<p>Minimum of 1 test per trip, up to 5 tests per trip during RSR or FIR.</p> <p>The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example, 16.50 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such significantly more operating time is required than is indicated above. Generally, a report will be</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p><b>P219A Variance Threshold Bank1 Table</b> ) and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table (see Supporting Table <b>P219A Normalizer Bank1 Table</b> ). This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (see Supporting Table <b>P219A Quality Factor Bank1 Table</b> ). This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used.</p> <p>Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered</p>			<p>APC delta during short term sample period</p> <p>Filtered APC delta between samples Note: first order lag filter coefficient applied to APC = 0.100</p> <p>Spark Advance</p> <p>Throttle Area (percent of max)</p> <p>Intake Cam Phaser Angle</p> <p>Exhaust Cam Phaser Angle</p> <p>Quality Factor (QF) QF calibrations are located in a 17x17 lookup table versus engine speed and load (see Supporting Table <b>P219A Quality Factor Bank1 Table</b> ). QF values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data.</p> <p>Fuel Control Status Closed Loop and Long Term FT Enabled for:</p>	<p>&lt; 60 mg/cylinder</p> <p>&lt; 2.00 percent</p> <p>5 to 55 degrees</p> <p>2 to 200 percent</p> <p>0 to 25 degrees</p> <p>0 to 25 degrees</p> <p>&gt;= 0.99</p> <p>&gt;= 0.0 seconds (Please see "<b>Closed Loop Enable Clarification</b>" and "<b>Long Term FT Enable Criteria</b>" in Supporting Tables)</p>	<p>made within 5 minutes of operation.</p> <p>For RSR or FIR, 10 tests must complete before the diagnostic can report.</p>	



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>Ratio.</p> <p>The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific.</p> <p>Some applications may need to command a unique cam phaser value before performing the above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use this feature.</p>			<p>Device Control</p> <p>AIR pump</p> <p>CASE learn</p> <p>EGR</p> <p>EVAP</p> <p>Engine Over Speed Protection</p> <p>Idle speed control</p> <p>PTO</p> <p>Injector base pulse width</p> <p>O2 learned htr resistance</p> <p>Rapid Step Response (RSR):</p> <p>RSR will trigger if the Ratio result from the last test is</p> <p>AND it exceeds the last Filtered ratio by</p> <p>Once triggered, the filtered ratio is reset to:</p> <p>Fast Initial Response (FIR):</p> <p>FIR will trigger when an NVM reset or code clear occurs.</p> <p>Once triggered, the filtered ratio is reset to:</p> <p>No Fault Active for:</p>	<p>Not active</p> <p>Not on</p> <p>Not active</p> <p>Not intrusive</p> <p>Not intrusive</p> <p>Not Active</p> <p>Normal</p> <p>Not Active</p> <p>Above min pulse limit</p> <p>= Valid (the O2 heater resistance has learned since NVM reset)</p> <p>&gt;= 0.40</p> <p>&gt;= 0.35</p> <p>0.00</p> <p>0.00</p> <p>EngineMisfireDetected_F A MAP_SensorFA MAF_SensorFA</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						ECT_Sensor_FA TPS_ThrottleAuthorityDef aulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbl_F A CamSensorAnyLocationF A FuelTrimSystemB1_FA O2S_Bank_1_Sensor_1_ FA O2S_Bank_1_Sensor_2_ FA WRAF_Bank_1_FA		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Performance (single turbo)	P2227	Detects a performance failure in the Barometric Pressure (BARO) sensor, such as when a BARO value is stuck in range.	<b><u>Engine Running:</u></b>  Difference between Baro Pressure reading and Estimated Baro when distance since last Estimated Baro update  OR  Difference between Baro Pressure reading and Estimated Baro when distance since last Estimated Baro update	  > 15.0 kPa  <= 0.06 miles    > 20.0 kPa  > 0.06 miles	No Active DTCs:	AmbPresSnsrCktFA IAT_SensorFA MAF_SensorFA AfterThrottlePressureFA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA TC_BoostPresSnsrFA	320 failures out of 400 samples  1 sample every 12.5 msec	Type A, 1 Trips
		If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The BARO sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the BARO performance diagnostic will fail.  If the BARO sensor value is within the normal expected atmospheric range, then Manifold Pressure (MAP), Turbocharger Boost Pressure and BARO are compared to see if their values are similar. If the MAP and Turbocharger Boost Pressure sensor values are similar, but the BARO value is not similar, then a BARO performance diagnostic will fail.  When the engine is	<b><u>Engine Not Rotating:</u></b>  Barometric Pressure OR Barometric Pressure  OR  ABS(Manifold Pressure - Baro Pressure) AND ABS(Turbocharger Boost Pressure - Manifold Pressure) AND ABS(Turbocharger Boost Pressure - Baro Pressure)	  < 50.0 kPa  > 115.0 kPa    > 10.0 kPa  <= 10.0 kPa  > 10.0 kPa	Time between current ignition cycle and the last time the engine was running  Engine is not rotating  No Active DTCs:   No Pending DTCs:	  > 10.0 seconds   EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA AAP2_SnsrCktFA  MAP_SensorCircuitFP AAP_SnsrCktFP AAP2_SnsrCktFP	4 failures out of 5 samples  1 sample every 12.5 msec	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		running, there is an estimate of barometric pressure that is determined with the Turbocharger Boost Pressure sensor, engine air flow and engine speed. If the BARO value from the sensor is not similar to this barometric pressure estimate, then the BARO performance diagnostic will fail.						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (boosted applications, Gen III)	P2228	Detects a continuous short to ground in the Barometric Pressure (BARO) signal circuit by monitoring the BARO sensor output voltage and failing the diagnostic when the BARO voltage is too low. The BARO sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	BARO Voltage	< 39.3 % of 5 Volt Range (This is equal to 50.0 kPa)			320 failures out of 400 samples  1 sample every 12.5 msec	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (boosted applications, Gen III)	P2229	Detects a continuous short to power or open circuit in the Barometric Pressure (BARO) signal circuit by monitoring the BARO sensor output voltage and failing the diagnostic when the BARO voltage is too high. The BARO sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	BARO Voltage	> 90.0 % of 5 Volt Range (This is equal to 115.0 kPa)			320 failures out of 400 samples  1 sample every 12.5 msec	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Intermittent	P2230	<p>Detects a noisy or erratic signal in the barometric pressure (BARO) circuit by monitoring the BARO sensor and failing the diagnostic when the BARO signal has a noisier output than is expected.</p> <p>When the value of BARO in kilopascals (kPa) is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of BARO readings. The result of this summation is called a "string length".</p> <p>Since the BARO signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic BARO signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current BARO reading - BARO reading from 12.5 milliseconds previous)</p>	<p>&gt; 100 kPa</p> <p>80 consecutive BARO readings</p>			<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Pumping Current Performance Bank 1 (For use with WRAF - E80	P223C	<p>This DTC determines if the WRAF O2 sensor pumping current has an incorrect or out of range value. This DTC will detect open circuit faults to the Pump current, Ref Cell voltage, Ref Ground and Trim circuits. When enabled, the diagnostic monitors the pumping current in three different fault regions during DFCO.</p> <p>The individual diagnostic failure counters are incremented based on the diagnostic results in each region. The DTC is set based on any of the three individual fail and sample counters.</p>	<p>Fault condition present when the pump current is in any of the fault regions when this test is enabled during DFCO.</p> <p>Note: This ASIC is referred to as C2WRAF (Delphi).</p>	<p>The three pump current fault regions are:</p> <p>A) Pump current &gt; 4.18 ma</p> <p>B) Pump current <math>\leq 0.10</math> ma and <math>\geq -0.10</math> ma</p> <p>C) Pump current &lt; -0.10 ma</p> <p>The three fault regions have individual X out of Y calibrations. When the X out of Y is reached in any region this DTC is set.</p> <p>Note: A open circuit on the Pump current signal may also set a P0131 DTC.</p> <p>Note: A short to ground on the trim circuit can set P223C.</p>	<p>DTC's Not active this key cycle</p> <p>Measure Valid status (ASIC)</p> <p>Controller status (ASIC)</p> <p>Engine Run or Auto stop</p> <p>*****</p> <p>Heater Warm-up delay Then WRAF circuit diagnostic delay (since heater Warm-up delay is complete)</p> <p>*****</p> <p>Test starts when time in DFCO</p> <p>Test stops when time in DFCO</p>	<p>WRAF_Bank_1_FA P0135, P0030, P0031, P0032</p> <p>= Valid</p> <p>= Ready</p> <p>= True</p> <p>= Complete</p> <p><math>\geq 20.0</math> seconds</p> <p><math>\geq 5.0</math> seconds</p> <p>&gt; 12.0 seconds</p>	<p>Region A: 224 failures out of 280 samples</p> <p>OR</p> <p>Region B: 224 failures out of 280 samples</p> <p>OR</p> <p>Region C: 224 failures out of 280 samples</p> <p>Sample rate is 25 msec.</p> <p>Test enabled during DFCO.</p>	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Reference Resistance Out Of Range Bank 1	P223E	<p>This DTC determines if the WRAF O2 sensor reference cell has an incorrect or out of range resistance value. This test compares the element's resistance (from the WRAF sensor Application-Specific Integrated Circuit (ASIC)) to the expected values for the enabled condition. The element temperature is directly related to the element resistance based on the released sensor element specifications.</p> <p>The diagnostic failure counter is incremented if the element temperature is outside the expected range. This DTC is set based on the fail and sample counters.</p>	Measured Reference cell temperature	<p>&lt; 700 Deg C OR &gt; 1,000.0 Deg C</p>	<p>DTC's Not active this key cycle</p> <p>Measure Valid status (ASIC)</p> <p>Controller status (ASIC)</p> <p>Engine Run or Auto stop</p> <p>*****</p> <p>Heater Warm-up delay Then Delay after WRAF circuit diagnostic delay *****</p>	<p>WRAF_Bank_1_FA P0135, P0030, P0031, P0032</p> <p>= Valid</p> <p>= Ready</p> <p>= True</p> <p>= Complete</p> <p>≥ 30.0 seconds</p>	<p>128 failures out of 160 samples</p> <p>Sample rate is 25 msec</p> <p>Continuous</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Turbo/Super Charger Bypass Valve - Mechanical Turbocharge r with wastegate. Not supercharge r with mechanical compressor	P2261	This DTC indicates the compressor recirculation valve being stuck closed. This diagnostic is active at coast down let off conditions, where an airflow pulsation criteria is used as basis of this diagnostic.	When measuring time accumulated air mass flow derivate boost pressure is high pass filtered with filter frequency ***** A failure is detected when Acc. Filtered Air Mass Flow  or  Acc.Der.Filtered boost pressure	< 0.50 Second,   = 10.00 Hz *****  > 65.00 g/s      > 1,000.00 kPa/s	Diagnostic enabled ***** Engine speed ***** Bypass valve commanded open duty cycle For at least ***** Pressure ratio over the compressor relative limit   Condition keep true for x seconds extra ***** Negative transient -> TRUE Relative boost and Pressure derivate  Hysteresis negative transient -> FALSE Relative boost or Pressure derivate ***** No Active DTCs:	True ***** >= 1,500 rpm *****  > 6.00 % >= 0.25 s ***** > refer to <b>P00C4 P2261: Compressor Surge Line</b> in Supporting Tables  0.80 s ***** TRUE  >= 35.00 kPa <= -150.00 kPa/s    BSTR_b_TurboBypassCkt FA BSTR_b_BoostSnsrFA MAF_SensorFA	5 Failed tests out of 6 tests  25ms/ sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Lean Bank 1 Sensor 2	P2270	<p>The P2270 diagnostic is the first in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, &amp; P013B. This DTC determines if the secondary O2 sensor is stuck in a normal lean voltage range and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary O2 sensor does not achieve the required rich voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post O2 sensor signal</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Stuck Lean Voltage Test</p>	<p>&lt; 825 mvolts</p> <p>&gt; 84 grams</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013A, P013B, P013E, P013F, P2270 or P2271</p> <p>&gt; 10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Pedal position</p> <p>Engine Airflow</p> <p>Closed loop integral Closed Loop Active</p> <p>Decel Fuel Cut Off</p> <p>Evap</p> <p>Ethanol Estimation in Progress</p> <p>Post fuel cell</p> <p>Crankshaft Torque</p> <p>EGR Intrusive diagnostic All post sensor heater delays</p> <p>O2S Heater (post sensor) on Time</p> <p>Transmission Temp</p>	<p>is above 22.0 grams/sec.</p> <p>= False</p> <p>= False</p> <p>≤ 4.0 %</p> <p>2.0 ≤ gps ≤ 15.0</p> <p>0.80 ≤ C/L Int ≤ 1.07 = TRUE (Please see “<b>Closed Loop Enable Clarification</b>” in Supporting Tables).</p> <p>not inhibited</p> <p>not in control of purge</p> <p>= Not Active (Please see “<b>Ethanol Estimation in Progress</b>” in Supporting Tables).</p> <p>= Enabled, refer to <b>Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests</b> for additional info. &lt; 100.0 Nm</p> <p>= not active</p> <p>= not active</p> <p>≥ 80.0 sec</p> <p>≥ -40.0 °C</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Predicted Catalyst temp Fuel State  ===== All of the above met for at least 0.0 seconds, and then check the following  Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)  Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled) ===== All of the above met for at least 2.0 seconds, and then the Force Cat Rich intrusive stage is requested. ===== During Stuck Lean test the following must stay TRUE or the test will abort: Commanded Fuel Crankshaft Torque	500 ≤ °C ≤ 900 = DFCO possible  =====   950 ≤ RPM ≤ 2,950  900 ≤ RPM ≤ 3,050  40.4 ≤ MPH ≤ 77.7  35.4 ≤ MPH ≤ 82.0   0.96 ≤ EQR ≤ 1.08 < 70.0 Nm		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Rich Bank 1 Sensor 2	P2271	<p>The P2271 diagnostic is the fourth in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, &amp; P013B. This DTC determines if the secondary O2 sensor is stuck in a normal rich voltage range and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary O2 sensor does not achieve the required lean voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post O2 sensor signal</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Stuck Rich Voltage Test</p>	<p>&gt; 100 mvolts</p> <p>&gt; 40.0 grams</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013A, P013B, P013E, P013F or P2270</p> <p>&gt; 10.0 Volts = Valid ( the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's" )</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than <b>Multiple DTC Use_Green Sensor Delay Criteria - Limit</b> for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_Rap idResponseActiv e = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Fuel State</p> <p>DTC's Passed</p> <p>=====</p> <p>After above conditions are met: DFCO mode is continued (w/o driver initiated pedal input).</p>	<p>is above 22.0 grams/sec.</p> <p>= False</p> <p>= False</p> <p>= DFCO possible</p> <p>= P2270 = P013E = P013A</p> <p>=====</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance	P228C	This DTC determines if the high pressure pump is not able to maintain target pressure. The fault is set if the measured fuel rail pressure is lower than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	>= <b>P228C P2C1F - High Pressure Pump Control (HPC) fail threshold of pressure too low</b> Mpa (see supporting tables)	High Pressure Pump Performance Diagnostic Enable  Battery Voltage  Low Side Fuel Pressure   Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and	True  ≥ 11 Volts  > 0.275 MPa   Enabled when a code clear is not active or not exiting device control Engine is not cranking	Positive Pressure Error -  10.00 second failures out of 12.50 second samples	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine movement detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active  Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -12.0 degC -12 <=Temp degC <= 128		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance	P228D	This DTC determines if the high pressure pump is delivering high pressure that desired pressure. The fault is set if the measured fuel rail pressure is higher than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	<= <b>P228D P2C20 - High Pressure Pump Control (HPC) fail threshold for pressure too high</b> Mpa (see supporting tables)	High Pressure Pump Performance Diagnostic Enable  Battery Voltage  Low Side Fuel Pressure  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement	True  ≥ 11 Volts  > 0.275 MPa  Enabled when a code clear is not active or not exiting device control Engine is not cranking	Negative Pressure Error -  10.00 second failures out of 12.50 second samples	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active  Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -12.0 DegC -12 <= Temp degC <= 128		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT LOW	P2300	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	$\leq 100 \Omega$ impedance between signal and controller ground	<p>Engine running</p> <p>Ignition Voltage</p>	> 11.0	<p>50 Failures out of 63 Samples</p> <p>100 msec rate</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT High	P2301	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Power fault. Controller specific output driver circuit diagnoses the low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	<p><math>\leq 100\ \Omega</math> impedance between signal and controller power</p>	<p>Engine running</p> <p>Ignition Voltage</p>	> 11.0 Volts	<p>50 Failures out of 63 Samples</p> <p>100 msec rate</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT Low	P2303	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	<p>≤ 100 Ω impedance between signal and controller ground</p>	<p>Engine running</p> <p>Ignition Voltage</p>	> 11.0 Volts	<p>50 Failures out of 63 Samples</p> <p>100 msec rate</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT High	P2304	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Power fault	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	<p>≤ 100 Ω impedance between signal and controller power</p>	<p>Engine running</p> <p>Ignition Voltage</p>	> 11.0 Volts	<p>50 Failures out of 63 Samples</p> <p>100 msec rate</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT Low	P2306	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	<p><math>\leq 100 \Omega</math> impedance between signal and controller ground</p>	<p>Engine running</p> <p>Ignition Voltage</p>	> 11.0 Volts	<p>50 Failures out of 63 Samples</p> <p>100 msec rate</p>	Type A, 1 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT High	P2307	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Power fault	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	<p>≤ 100 Ω impedance between signal and controller power</p>	<p>Engine running</p> <p>Ignition Voltage</p>	> 11.0 Volts	<p>50 Failures out of 63 Samples</p> <p>100 msec rate</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT Low	P2309	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Ground fault. Controller specific output driver circuit diagnoses the low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	<p>≤ 100 Ω impedance between signal and controller ground</p>	<p>Engine running</p> <p>Ignition Voltage</p>	> 11.0 Volts	<p>50 Failures out of 63 Samples</p> <p>100 msec rate</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT High	P2310	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Power fault	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	<p>≤ 100 Ω impedance between signal and controller power</p>	<p>Engine running</p> <p>Ignition Voltage</p>	> 11.0 Volts	<p>50 Failures out of 63 Samples</p> <p>100 msec rate</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Torque Request Circuit	P2544	Determines if the torque request from the TCM is valid	Protect error - Serial Communication message 2's complement not equal (\$189/\$199)  OR Rolling count error - Serial Communication message (\$189/\$199) rolling count index value  OR  Range Error - Serial Communication message - (\$189/\$199) TCM Requested Torque Increase  OR  Multi-transition error - Trans torque intervention type request change	Message <> two's complement of message    Message <> previous message rolling count value + one    > 450 Nm    Requested torque intervention type toggles from not increasing request to increasing request	Diagnostic Status  Power Mode  Ignition Voltage  Engine Running Run/Crank Active   No Serial communication loss to TCM (U0101)	Enabled  = Run  > 6.41 volts  = True > 0.50 Sec   No loss of communication	>= 16 failures out of 20 samples.  Performed on every received message  >= 6 Rolling count errors out of 10 samples.  Performed on every received message  >= 6 range errors out of 10 samples.  Performed on every received message  >= 4 multi-transitions out of 5 samples. Performed every 200 msec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Hood Switch Performance	P257D	This DTC monitors the hood switch rationality	<p>Hood Switch position is in an invalid position.</p> <p>Type of Switch: CeHSWR_e_Enumerated</p> <p>With an enumerated type switch the hood switch reading is invalid in these ranges</p> <p>With a discrete type switch the hood switch reading is invalid when</p> <p>With a percentage type switch the hood switch reading is invalid in these ranges</p> <p>With a resistance type switch the hood switch reading is invalid in these ranges</p>	<p>1281 Ohms to 1404 Ohms</p> <p>Hood Switch 1 and Hood Switch 2 are in the same state (States not equal is proper function)</p> <p>71.50 % to 67.80 % or 45.70 % to 43.40 % or 17.20 % to 14.60 %</p> <p>6,775.00 Ohms to 2,350.00 Ohms or 2,280.00 Ohms to 750.00 Ohms or 720.00 Ohms to 300.00 Ohms</p>	<p>The diagnostic is enabled</p> <p>Enabled when Run/Crank is active only, otherwise Run/Crank is not used as an enable</p>	<p>= 1 (1 indicates enabled)</p> <p>= 1 (1 indicates Run/Crank active enabled)</p>	<p>80 failed samples within 100 total samples</p> <p>Diagnostic runs in the 12.5 ms loop</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Hood Switch Short to Ground / Low Voltage	P257E	This DTC monitors the hood switch for a short to ground or low voltage condition	<p>Hood Switch position reading is outside an expected bounds for</p> <p>Type of Switch: CeHSWR_e_Enumerated</p> <p>With an enumerated type switch the bound is hood switch reading</p> <p>With a discrete type switch the bounds are</p> <p>With a percentage type switch the bound is hood switch reading</p> <p>With a resistance type switch the bound is hood switch reading</p>	<p>&lt;= 325 Ohms</p> <p>Hood Switch 1 and Hood Switch 2 are in the same state (States not equal is proper function)</p> <p>&lt;= 14.60 %</p> <p>&lt;= 300.00 Ohms</p>	<p>The diagnostic is enabled</p> <p>Enabled when Run/Crank is active only, otherwise Run/Crank is not used as an enable</p>	<p>= 1 (1 indicates enabled)</p> <p>= 1 (1 indicates Run/Crank active enabled)</p>	<p>80 failed samples within 100 total samples</p> <p>Diagnostic runs in the 12.5 ms loop</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Hood Switch Short to Voltage / High Voltage	P257F	This DTC monitors the hood switch for a short to voltage or high voltage condition	<p>Hood Switch position reading is outside an expected bounds for</p> <p>Type of Switch: CeHSWR_e_Enumerate d</p> <p>With an enumerated type switch the bound is hood switch reading</p> <p>With a discrete type switch the bounds are</p> <p>With a percentage type switch the bound is hood switch reading</p> <p>With a resistance type switch the bound is hood switch reading</p>	<p>&gt;= 3620 Ohms</p> <p>Hood Switch 1 and Hood Switch 2 are in the same state (States not equal is proper function)</p> <p>&gt;= 71.50 %</p> <p>&gt;= 6,775.00 Ohms</p>	<p>The diagnostic is enabled</p> <p>Enabled when Run/Crank is active only, otherwise Run/Crank is not used as an enable</p>	<p>= 1 (1 indicates enabled)</p> <p>= 1 (1 indicates Run/ Crank active enabled)</p>	<p>80 failed samples within 100 total samples</p> <p>Diagnostic runs in the 12.5 ms loop</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Auxiliary Coolant Pump Relay Control Circuit	P2600	Controller specific output driver circuit diagnoses the Auxillary Coolant Pump Relay Control Circuit low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p><math>\geq 200\text{ K } \Omega</math> impedance between signal and controller ground.</p>	<p>Run Crank Ignition in Range</p> <p>Engine not cranking</p> <p>== Above is true and ==</p> <p>Last Open Circuit Test</p>	<p>= True</p> <p>= True</p> <p>=====</p> <p>not Indeterminate</p>	<p>5 failures out of 6 samples</p> <p>1 sec/ sample</p> <p>Continuous</p>	Type B, 2 Trips Note: In certian controlle rs P2602 may also set



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Auxiliary Coolant Pump Relay Control Circuit Low Voltage	P2602	Controller specific output driver circuit diagnoses the Auxiliary Coolant Pump Relay Control Circuit low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	$\leq 0.5 \Omega$ impedance between signal and controller ground	<p>Run Crank Ignition in Range</p> <p>Engine not cranking</p> <p>== Above is true and ==</p> <p>Last Open Circuit Test</p>	<p>= True</p> <p>= True</p> <p>=====</p> <p>not Indeterminate</p>	<p>5 failures out of 6 samples</p> <p>1 sec/ sample</p> <p>Continuous</p>	Type B, 2 Trips Note: In certian controllers P2600 may also set

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Auxiliary Coolant Pump Relay Control Circuit High Voltage	P2603	Controller specific output driver circuit diagnoses the Auxiliary Coolant Pump Relay Control Circuit low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	$\leq 0.5 \Omega$ impedance between signal and controller power.	<p>Run Crank Ignition in Range</p> <p>Engine not cranking</p> <p>== Above is true and ==</p> <p>Last Open Circuit Test</p>	<p>= True</p> <p>= True</p> <p>=====</p> <p>not Indeterminate</p>	<p>5 failures out of 6 samples</p> <p>1 sec/ sample</p> <p>Continuous</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position Signal Output Circuit Low	P2618	Controller specific output driver circuit diagnoses the crankshaft position output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure.	Short to ground: $\leq 0.5$ Ohms impedance between signal and controller ground  Open Circuit: $\geq 200$ K Ohms impedance between signal and controller ground	Powertrain Relay Voltage  Engine is not cranking  Crankshaft Position Output is commanded high	Test is Enabled  $\geq 11.0$ Volts	40 failures out of 50 samples  1 sample every 100 msec	Type C, No SVS  Note: In certain controllers P2617 may also set (Crankshaft Position Signal Output Circuit / Open)

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Off Timer Performance	P262B	<p>This DTC determines if the hardware timer does not initialize or count properly. There are two tests to ensure proper functioning of the timer: Count Up Test (CUT) and Range Test (RaTe).</p> <p>Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment.</p> <p>Range Test (RaTe): When the run/crank is not active both the hardware and mirror timers are started. The timers are compared when module shutdown is initiated or run/crank becomes active.</p>	<p>Count Up Test:</p> <p>Time difference between the current read and the previous read of the timer</p> <p>Range Test:</p> <p>The variation of the HWIO timer and mirror timer is</p>	<p>&gt; 1.50 seconds</p> <p>&gt; 0.25 %.</p>			<p>Count Up Test: 4 failures out of 20 samples</p> <p>1 sec / sample</p> <p>Continuous while run/crank is not active and until controller shutdown is initiated.</p> <p>Range Test: Once per trip when controller shutdown is initiated or run/crank becomes active.</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump "A" Low Flow / Performance	P2635	This DTC detects degradation in the performance of the electronically regulated fuel system by calculating the difference between the sensed, filtered system [line] pressure versus the ECM-commanded pressure [error calculation]. The calculated error is then compared to calibrated fault threshold tables for a fault decision.	Sensed Filtered Fuel System [line] pressure error	<= Low Threshold [Supporting Table] <b>P2635 Threshold Low</b>  OR  >= High Threshold [Supporting Table] <b>P2635 Threshold High</b>	a) Diagnostic enabled [FDBR_b_FSRD]  b) Timer Engine Running [FDBR_t_EngModeRunCoarse]  c1) Fuel Flow Rate Valid  c2) Ambient Air Pressure Value Defaulted  c3) Fuel Pressure Sensor Fault Status [DTC P018C or P018D]  c4) Reference Voltage Fault Status [DTC P0641]  c5) Exhaust AfterTreatment Fuel Injector A Control Circuit Short Low Fault [HCIR_b_GshtFA DTC P20CD]  c6) Fuel Pres Sensor Performance Fault Active [DTC P018B]  c7) Use Calculated Flow Performance Fault Thresholds [FDBR_b_UseCalcFSRD _FltThrshs]  c8) Engine Speed Status Valid  c9) Fuel Pump Control Circuit Fault Status [P1029, P102A, P102B, or P102C]	a) == TRUE  b) >= 30.00 seconds  c1) == TRUE  c2) <> TRUE  c3) <> TRUE  c4) <> TRUE  c5) <> TRUE  c6) <> TRUE  c7) <> TRUE  c8) == TRUE  c9) <> TRUE  c10) <> TRUE	1 sample / 12.5 millisec	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					c10) Fuel Control Enable Fault Active [DTC P12A6]  c11) Fuel Pump Driver Module OverTemp Fault Active [DTC P1255]  c12) Fuel Pump Speed Fault Active [DTC P129F]  c13) CAN Sensor Bus message \$0C3 Comm Fault [CFMR_b_FTZM_Info1_U codeCmFA DTC P165C]  c14) CAN Sensor Bus Fuel Pmp Spd Command ARC and Checksum Comm Fault Code [CFMR_b_FTZM_Cmd1_ UcodeCmFA DTC]  c15) Sensor Configuration [FDBR_e_FuelPresSnsrC onfig]  c16) Sensor Bus Relay On  d) Emissions Fuel Level Low [Message \$3FB]  e) Fuel Control Enable  f) Fuel Pump Control State  g) Run_Crank input circuit voltage	c11) <> TRUE  c12) <> TRUE  c13) <> TRUE  c14) <> TRUE  c15) == CeFDBR_e_WiredTo_FT ZM c16) == TRUE  d) <> TRUE  e) == TRUE  f) == NORMAL  g) 11.00 volts <= Run_Crank_V <= 32.00 volts h) <> TRUE		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					h) High Pres Fuel Pump Mode Management Enabled  j) High Pres Fuel Pump Control Mode  k) Instantaneous Fuel Flow [FCBR_dm_InstFuelFlow]	j) <> Disabled Mode AND a8b) <> ZeroFlow Mode  k) 0.05 grams/sec <= InstFuelFlow <= Max Allowed Flow [Supporting Table] <b>P2635 Max Fuel Flow</b>  m1) <> TRUE  m1) Fuel Pmp Speed Command Alive Rolling Count and Checksum Error [CAN Bus B \$0CE] [CFMR_b_FTZM_Cmd1_ ARC_ChkErr DTC]  m2) CAN Sensor Bus message \$0C3_Available  m3) Fuel Pres Sensor Ref Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B \$0C3] [CFMR_b_FTZM_Info1_A RC_ChkErr DTC]  n) Timer - Diagnostic Enable	m2) == TRUE  m3) <> TRUE  n) > 2.00 seconds	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Low	P263A	Detects an inoperative malfunction indicator lamp control circuit. This diagnostic reports the DTC when a short to ground is detected.	Voltage low during driver off state (indicates short- to-ground)	Short to ground: $\leq 0.5 \Omega$ impedance between output and controller ground	Run/Crank Voltage  Remote Vehicle Start is not active	Voltage $\geq 11.00$ volts	1 failures out of 1 samples  50 ms / sample	Type B, No MIL  NO MIL  Note: In certain controlle rs P0650 may also set (MIL Control Open Circuit)



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) High	P263B	Detects an inoperative malfunction indicator lamp control circuit. This diagnostic reports the DTC when a short to power is detected.	Voltage high during driver on state (indicates short to power)	Short to power: $\leq 0.5 \Omega$ impedance between output and controller power	Run/Crank Voltage  Remote Vehicle Start is not active	Voltage $\geq 11.00$ volts	4 failures out of 5 samples  50 ms / sample	Type B, No MIL  NO MIL

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Drive Pinion Circuit Open (12VSS)	P26E4	Controller specific output driver circuit diagnoses the Tandem Starter Pinion Relay high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.  Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	          ≥ 200 KOhms impedance between signal and controller ground.	Starter relay pinion diag enable  Engine speed  Run Crank voltage	Enabled  ≥ 0.00 RPM  ≥ 11.00 volts	40 failures out of 50 samples  50 ms / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Drive Pinion Circuit Low Voltage (12VSS)	P26E5	Controller specific output driver circuit diagnoses the Tandem Starter Pinion Relay high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	<p>&lt;= 0.5 Ohms impedance between signal and controller ground</p>	<p>Starter control diag enable</p> <p>Engine speed</p> <p>Run Crank voltage</p>	<p>Enabled</p> <p>&gt;= 0.00 RPM</p> <p>&gt;= 6.41 volts</p>	<p>8 failures out of 10 samples</p> <p>50 ms / sample</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Starter Relay Drive Pinion Circuit High Voltage (12VSS)	P26E6	Controller specific output driver circuit diagnoses the Tandem Starter Pinion Relay high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.</p>	<p>&lt;= 0.5 Ohms impedance between signal and controller power</p>	<p>Starter control diag enable</p> <p>Engine speed</p> <p>Run Crank voltage</p>	<p>Enabled</p> <p>&gt;= 0.00 RPM</p> <p>&gt;= 11.00 volts</p>	<p>40 failures out of 50 samples</p> <p>50 ms / sample</p>	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Sensor B Circuit Low	P2802	Controller specific PWM circuit diagnoses the internal range sensor (IRS) B for a short to ground failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates short to ground failure</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to ground</p>	$\leq 0.5 \Omega$ impedance between signal and controller ground	<p>diagnostic monitor enable</p> <p>battery voltage update battery voltage timer</p> <p>PWM % duty cycle when voltage directly proportional OR PWM % duty cycle when voltage inversely proportional</p> <p>circuit sensor type</p>	<p>= 1 Boolean</p> <p><math>\geq 9.00</math> volts</p> <p><math>\leq 8.79</math> %</p> <p><math>\geq 8.79</math> %</p> <p>CeTRGD_e_VoltDirctPro p</p>	<p>fail time <math>\geq 0.50</math> seconds out of sample time <math>\geq 1.00</math> seconds</p> <p>battery voltage timer <math>\geq 1.00</math> seconds</p>	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Sensor B Circuit High	P2803	Controller specific PWM circuit diagnoses the internal range sensor (IRS) B for a power short or open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates an open circuit or power short failure  Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit or power short	$\leq 0.5 \Omega$ impedance between signal and controller voltage source OR $\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	diagnostic monitor enable  battery voltage update battery voltage timer  PWM % duty cycle when voltage directly proportional OR PWM % duty cycle when voltage inversely proportional  circuit sensor type	= 1 Boolean  $\geq 9.00$ volts  $\geq 91.21 \%$  $\leq 91.21 \%$  CeTRGD_e_VoltDirctPro p	fail time $\geq 0.50$ seconds out of sample time $\geq 1.00$ seconds  battery voltage timer $\geq 1.00$ seconds	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump min/ max authority During Catalyst Warm Up	P2C1E	This DTC determines when the high pressure pump control has reached to its max or min authority during Catalyst Warm up	High Pressure Fuel Pump Delivery Angle  OR  High Pressure Fuel Pump Delivery Angle	$\geq 101^\circ$   $\leq 0^\circ$	Catalyst Warm Up High Pressure Pump Performance Diagnostic Enable  Battery Voltage  Low Side Fuel Pressure      Barometric Pressure Inlet Air Temp   Fuel Temp  Catalyst Warm up enabled (See Definition in Supporting Material below)  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or	True  $\geq 11$ Volts $> 0.275$ MPa  Enabled when a code clear is not active or not exiting device control  Engine is not cranking  $\geq 70.0$ KPA $\geq -12.0$ degC  $-12 \leq \text{Temp degC} \leq 128$  = True	Windup High/ Low  10.00 seconds failures out of 12.50 Seconds samples	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active			



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance During Catalyst Warm Up	P2C1F	This DTC determines if the high pressure pump is not able to maintain target pressure Catalyst Warm Up. The fault is set if the measured fuel rail pressure is lower than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	>= <b>P228C P2C1F - High Pressure Pump Control (HPC) fail threshold of pressure too low</b> Mpa (see supporting tables)	Catalyst Warm Up High Pressure Pump Performance Diagnostic Enable  Battery Voltage  Low Side Fuel Pressure  Catalyst Warm up enabled (See Definition in Supporting Material below)  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and	True  ≥ 11 Volts  > 0.275 MPa  = True  Enabled when a code clear is not active or not exiting device control Engine is not cranking	Positive Pressure Error -  10.00 second failures out of 12.50 second samples	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active  Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -12.0 degC -12 <=Temp degC <= 128		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance During Catalyst Warm Up	P2C20	This DTC determines if the high pressure pump is delivering high pressure that desired pressure Catalyst Warm Up. The fault is set if the measured fuel rail pressure is higher than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	<= <b>P228D P2C20 - High Pressure Pump Control (HPC) fail threshold for pressure too high</b> Mpa (see supporting tables)	Catalyst Warm Up High Pressure Pump Performance Diagnostic Enable  Battery Voltage  Low Side Fuel Pressure  Catalyst Warm up enabled (See Definition in Supporting Material below)  Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not	True  ≥ 11 Volts  > 0.275 MPa  = True  Enabled when a code clear is not active or not exiting device control Engine is not cranking	Negative Pressure Error -  10.00 second failures out of 12.50 second samples	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active  Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -12.0 DegC -12 <= Temp degC <= 128		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage Sensor Circuit 1 Low Voltage	P3051	Diagnoses the DC/DC Converter Actuator Voltage Sensor Circuit 1 for short to ground faults.	DC/DC Converter Actuator Voltage Raw Value 1	< 1 Volt	Diagnostic enabled  Run/Crank or Accessory  Battery Voltage	TRUE  TRUE  >= 6.60 Volts	640 failed samples out of 800 samples in 6.25 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage Sensor Circuit 2 Low Voltage	P3052	Diagnoses the DC/DC Converter Actuator Voltage Sensor Circuit 2 for short to ground faults.	DC/DC Converter Actuator Voltage Raw Value 2	< 1 Volt	Diagnostic enabled  Run/Crank or Accessory  Battery Voltage	TRUE  TRUE  >= 6.60 Volts	640 failed samples out of 800 samples in 6.25 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage Sensor Circuit 1 High Voltage	P3053	Diagnoses the DC/DC Converter Actuator Voltage Sensor Circuit 1 for short to battery faults.	DC/DC Converter Actuator Voltage Raw Value 1	> 28 Volt	Diagnostic enabled  Run/Crank or Accessory  Battery Voltage	TRUE  TRUE  >= 6.60 Volts	640 failed samples out of 800 samples in 6.25 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage Sensor Circuit 2 High Voltage	P3054	Diagnoses the DC/DC Converter Actuator Voltage Sensor Circuit 2 for short to battery faults.	DC/DC Converter Actuator Voltage Raw Value 2	> 28 Volt	Diagnostic enabled  Run/Crank or Accessory  Battery Voltage	TRUE  TRUE  >= 6.60 Volts	640 failed samples out of 800 samples in 6.25 ms loop	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
DC/DC Converter Actuator Voltage 1 Performance	P3055	Detects DC/DC Converter Actuator Voltage 1 Performance issues	Bypass Mode: Absolute value of voltage difference between DC/ DC Converter Actuator Voltage Raw Value 1 and ECM Run/Crank	> 1 Volt	Diagnostic enabled	TRUE	640 failed samples out of 800 samples in a 6.25 ms loop	Type B, 2 Trips	
					Run/Crank or Accessory	TRUE			
					Engine running OR Engine stopped	for > 160 loops in 6.25 ms loop for > 160 loops in 6.25 ms loop			
					Battery Voltage	>= 6.60 Volts			
			Stabilize Mode- Auto- Cranking: Absolute value of voltage difference between DC/ DC Converter Actuator Voltage Raw Value 1 and ECM Run/Crank	> 1 Volt	Diagnostic enabled	TRUE			16 failed samples out of 32 samples in a 6.25 ms loop
					Run/Crank or Accessory	TRUE			
		Engine auto-cranking			for > 0 loops in 6.25 ms loop				
		Stablize Mode-Auto- Cranking Events: Number of failed auto- cranking events exceeds threshold	> 2 failed auto- cranking events	Diagnostic enabled	TRUE	2 failed auto- crank events out of 3 consecutive auto-crank events			
				Run/Crank or Accessory	TRUE				
		Engine auto-cranking	has occurred						

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Actuator Voltage 2 Performance	P3056	Detects DC/DC Converter Actuator Voltage 2 Performance issues	Bypass Mode: Absolute value of voltage difference between DC/ DC Converter Actuator Voltage Raw Value 2 and ECM Run/Crank	> 1 Volt	Diagnostic enabled	TRUE	640 failed samples out of 800 samples in a 6.25 ms loop	Type B, 2 Trips
					Run/Crank or Accessory	TRUE		
					Engine running OR Engine stopped	for > 160 loops in 6.25 ms loop for > 160 loops in 6.25 ms loop		
					Battery Voltage	>= 6.60 Volts		
			Stabilize Mode- Auto- Cranking: Absolute value of voltage difference between DC/ DC Converter Actuator Voltage Raw Value 2 and ECM Run/Crank	> 1 Volt	Diagnostic enabled	TRUE	16 failed samples out of 32 samples in a 6.25 ms loop	
					Run/Crank or Accessory	TRUE		
Engine auto-cranking	for > 0 loops in 6.25 ms loop	Battery Voltage	>= 6.60 Volts					
Stablize Mode-Auto- Cranking Events: Number of failed auto- cranking events exceeds threshold	> 2 failed auto- cranking events	Diagnostic enabled	TRUE	2 failed auto- crank events out of 3 consecutive auto-crank events				
		Run/Crank or Accessory	TRUE					
Engine auto-cranking	has occurred							

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Ignition Switch Run/ Start Position Circuit High Voltage	P305B	Diagnoses the DC/DC Converter Ignition Switch Run/Start Position circuit for circuit high faults	DC/DC Converter Ignition Switch Run/Start Position	<> ECM Ignition Switch Run/Start Position	Diagnostic enabled  Run/Crank  Accessory  Battery Voltage	TRUE  FALSE  TRUE  >= 6.60 Volts	320 failed samples out of 400 samples in a 6.25 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Ignition Switch Run/ Start Position Circuit Low Voltage	P305C	Diagnoses the DC/DC Converter Switch Run/ Start Position circuit for circuit low faults	DC/DC Converter Ignition Switch Run/Start Position	<> ECM Ignition Switch Run/Start Position	Diagnostic enabled  Run/Crank  Accessory  Battery Voltage	TRUE  TRUE  TRUE  >= 6.60 Volts	640 failed samples out of 800 samples in a 6.25 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Crank Control Circuit High Voltage	P305D	Diagnoses the DC/DC Converter Crank Control Circuit for circuit high faults	DC/DC Converter Crank Control	<> ECM Crank Control	Diagnostic enabled  Run/Crank  ECM Crank Control  Battery Voltage	TRUE  TRUE  FALSE  >= 6.60 Volts	640 failed samples out of 800 samples in a 6.25 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
DC/DC Converter Crank Control Circuit Low Voltage	P305E	Diagnoses the DC/DC Converter Crank Control Circuit for circuit low faults	DC/DC Converter Crank Control	<> ECM Crank Control	Diagnostic enabled  Run/Crank or Accessory  ECM Crank Control  Battery Voltage	TRUE  TRUE  TRUE  >= 6.60 Volts	24 failed samples out of 32 samples in a 6.25 ms loop	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Out of Range Low [LIN Bus Electric PWM Fans Only - Internal or External controller]	P30EE	The reported actual fan speed in RPM exceeds an lower limit for the fan speed, indicating that there is a failure of the measurement of the fan speed	Measured LIN Fan1 Speed	< = -110.00 rpm	a] Diagnostic Enabled  b] Configuration calibration for number of fans  c] Diagnostic System Disabled  d] Battery Voltage In Range  e] LIN Bus based Fan Operation Enabled  f] LIN Serial data Lost communication Fault Active  g] LIN Serial data Continuous Operation Fault Active	a] == 1.00 [True if 1; False if 0]  b] >= 1 unit  c] <> True  d] > 11.00 volts  e] == TRUE  f] <> True  g] <> True	16.00 failures out of 20.00 samples;  1000 millisec / sample	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 Out of Range High [LIN Bus Electric PWM Fans Only - Internal or External controller]	P30EF	The reported actual fan speed in RPM exceeds an upper limit for the fan speed, indicating that there is a failure of the measurement of the fan speed	Measured LIN Fan1 Speed	> = 4,000.00 rpm	a] Diagnostic Enabled  b] Configuration calibration for number of fans  c] Diagnostic System Disabled  d] Battery Voltage In Range  e] LIN Bus based Fan Operation Enabled  f] LIN Bus Lost Communication Fault Active  g] LIN Bus serial data Continuous Operation Fault Active	a] == 1.00 [True if 1; False if 0]  b] >= 1 unit  c] <> True  d] > 11.00 volts  e] == TRUE  f] <> True  g] <> True	16.00 failures out of 20.00 samples;  1000 millisec / sample	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

[illegible]

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If EOBD: Run/Crank ignition voltage  If Secure: Starter motor engaged for Or Run/Crank ignition voltage  If Hybrid Secure: Run/Crank ignition voltage  If power mode = Accessory  Off key cycle diagnostics are enabled Or Controller is an OBD controller  Controller shutdown impending  Power Mode  Battery voltage	>= 9.00 Volts  > 15.00 milliseconds  > 8.41 Volts  >= 6.41 Volts  1.00 (1 indicates enabled)  OBD Controller  = False  = Not crank  >= 11.00 Volts		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communication Bus B Off	U0074	This DTC monitors for a BUS B off condition	Bus off failures equals or exceeds  before the sample time of is reached	5 counts (equivalent to 0.83 seconds)  0.83 seconds	General Enable Criteria:  Starter motor engaged for Or Run/Crank ignition voltage  All below criteria have been met for  Normal CAN transmission on Bus  Controller not in programming mode  If bus type = Sensor Bus:  Sensor bus relay is present  Otherwise:  If power mode = Run/Crank:  Power Mode  If calibratable low voltage disable mode is not Never Disabled  Low voltage disable mode: OBDII  If OBDII: Run/Crank ignition voltage	> 15.00 milliseconds  > 8.41 Volts  >= 5.00 milliseconds  Enabled      1.00 (1 indicates present)      = Run         >= 11.00 Volts	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If EOBD: Run/Crank ignition voltage  If Secure: Starter motor engaged for Or Run/Crank ignition voltage  If Hybrid Secure: Run/Crank ignition voltage  If power mode = Accessory  Off key cycle diagnostics are enabled Or Controller is an OBD controller  Controller shutdown impending  Power Mode  Battery voltage	>= 9.00 Volts  > 15.00 milliseconds  > 8.41 Volts  >= 6.41 Volts  1.00 (1 indicates enabled)  OBD Controller  = False  = Not crank  >= 11.00 Volts		

## 20 OBDG03A ECM Summary Tables

<b>Component/ System</b>	<b>Fault Code</b>	<b>Monitor Strategy Description</b>	<b>Malfunction Criteria</b>	<b>Threshold Value</b>	<b>Secondary Parameters</b>	<b>Enable Conditions</b>	<b>Time Required</b>	<b>MIL Illum.</b>
Control Module Communication Powertrain Sensor CAN Bus Off	U0076	This DTC monitors for a Powertrain Sensor Bus S off condition	Bus off failures equals or exceeds  before the sample time of is reached	5 counts (equivalent to 0.83 seconds)  0.83 seconds	General Enable Criteria:  Starter motor engaged for Or Run/Crank ignition voltage  All below criteria have been met for  Normal CAN transmission on Bus  Controller not in programming mode  If bus type = Sensor Bus:  Sensor bus relay is present  Otherwise:  If power mode = Run/Crank:  Power Mode  If calibratable low voltage disable mode is not Never Disabled  Low voltage disable mode: OBDII  If OBDII: Run/Crank ignition voltage	> 15.00 milliseconds  > 8.41 Volts  >= 5.00 milliseconds  Enabled     1.00 (1 indicates present)            = Run            >= 11.00 Volts	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If EOBD: Run/Crank ignition voltage  If Secure: Starter motor engaged for Or Run/Crank ignition voltage  If Hybrid Secure: Run/Crank ignition voltage  If power mode = Accessory  Off key cycle diagnostics are enabled Or Controller is an OBD controller  Controller shutdown impending  Power Mode  Battery voltage	>= 9.00 Volts  > 15.00 milliseconds  > 8.41 Volts  >= 6.41 Volts  1.00 (1 indicates enabled)  OBD Controller  = False  = Not crank  >= 11.00 Volts		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With TCM	U0101	This DTC monitors for a loss of communication with the Transmission Control Module.	<p>Message is not received from controller for</p> <p>Message \$0BD</p> <p>Message \$0C7</p> <p>Message \$0F9</p> <p>Message \$189</p> <p>Message \$199</p> <p>Message \$19D</p> <p>Message \$1AF</p> <p>Message \$1F5</p> <p>Message \$4C9</p>	<p>≥ 10.00 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 10.00 seconds</p>	<p>General Enable Criteria:</p> <p>If message is on Bus A: U0073</p> <p>If message is on Bus B: U0074</p> <p>If message is on Bus S: U0076</p> <p>Starter motor engaged for Or Run/Crank ignition voltage</p> <p>Bus is enabled for</p> <p>The following criteria have been enabled for</p> <p>Normal CAN transmission on Bus</p> <p>Transition from accessory mode to off is pending</p> <p>Controller not in programming mode</p> <p>If bus type = Sensor Bus:</p> <p>Sensor bus relay is present</p> <p>Battery voltage</p> <p>Sensor Bus Relay</p>	<p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>&gt; 15.00 milliseconds</p> <p>&gt; 8.41 Volts</p> <p>&gt;= 0.40 milliseconds</p> <p>&gt;= 5.00 milliseconds</p> <p>Enabled</p> <p>= False</p> <p>1.00 (1 indicates present)</p> <p>&gt; 11.00 Volts</p> <p>= On</p>	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Otherwise:</p> <p>If power mode = Run/ Crank:</p> <p>Power Mode = Run</p> <p>If calibratable low voltage disable mode is not Never Disabled</p> <p>Low voltage disable mode: OBDII</p> <p>If OBDII:</p> <p>Run/Crank ignition voltage &gt;= 11.00 Volts</p> <p>If EOBD:</p> <p>Run/Crank ignition voltage &gt;= 9.00 Volts</p> <p>If Secure:</p> <p>Starter motor engaged for Or Run/Crank ignition voltage &gt; 15.00 milliseconds &gt; 8.41 Volts</p> <p>If Hybrid Secure:</p> <p>Run/Crank ignition voltage &gt;= 6.41 Volts</p> <p>If power mode = Accessory</p>			



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Off key cycle diagnostics are enabled Or Controller is an OBD controller  Controller shutdown impending  Power Mode  Battery voltage	1.00 (1 indicates enabled)  OBD Controller  = False  = Not crank  >= 11.00 Volts		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Cruise Control Module	U0104	This DTC monitors for a loss of communication with the Cruise Control Module.	<p>Message is not received from controller for</p> <p>Message \$2CB</p> <p>Message \$2CD</p>	<p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p>	<p>General Enable Criteria:</p> <p>If message is on Bus A: U0073</p> <p>If message is on Bus B: U0074</p> <p>If message is on Bus S: U0076</p> <p>Starter motor engaged for Or Run/Crank ignition voltage</p> <p>Bus is enabled for</p> <p>The following criteria have been enabled for</p> <p>Normal CAN transmission on Bus A</p> <p>Transition from accessory mode to off is pending</p> <p>Controller not in programming mode</p> <p>If bus type = Sensor Bus: Sensor bus relay is present</p> <p>Battery voltage</p> <p>Sensor Bus Relay</p> <p>Otherwise: If power mode = Run/</p>	<p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>&gt; 15.00 milliseconds</p> <p>&gt; 8.41 Volts</p> <p>&gt;= 0.40 milliseconds</p> <p>&gt;= 5.00 milliseconds</p> <p>Enabled</p> <p>= False</p> <p></p> <p>1.00 (1 indicates present)</p> <p>&gt; 11.00 Volts</p> <p>= On</p>	Diagnostic runs in 12.5 ms loop	Type C, No SVS "Emissio ns Neutral Diagnost ics – Type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Crank:  Power Mode  If calibratable low voltage disable mode is not Never Disabled  Low voltage disable mode: OBDII  If OBDII: Run/Crank ignition voltage  If EOBD: Run/Crank ignition voltage  If Secure: Starter motor engaged for Or Run/Crank ignition voltage  If Hybrid Secure: Run/Crank ignition voltage  If power mode = Accessory  Off key cycle diagnostics are enabled Or Controller is an OBD controller  Controller shutdown impending	= Run          >= 11.00 Volts  >= 9.00 Volts  > 15.00 milliseconds > 8.41 Volts  >= 6.41 Volts   1.00 (1 indicates enabled)  OBD Controller   = False		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Mode Battery voltage	= Not crank >= 11.00 Volts		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Anti- Lock Brake System (ABS) Control Module	U0121	This DTC monitors for a loss of communication with the Anti-Lock Brake System (ABS) Control Module (Non-OBD Module ID 243).	<p>Message is not received from controller for</p> <p>Message \$0C1</p> <p>Message \$0C5</p> <p>Message \$1C7</p> <p>Message \$1E9</p> <p>Message \$2F1</p> <p>Message \$2F9</p>	<p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 10.00 seconds</p> <p>≥ 0.50 seconds</p>	<p>General Enable Criteria:</p> <p>If message is on Bus A: U0073</p> <p>If message is on Bus B: U0074</p> <p>If message is on Bus S: U0076</p> <p>Starter motor engaged for Or Run/Crank ignition voltage</p> <p>Bus is enabled for</p> <p>The following criteria have been enabled for</p> <p>Normal CAN transmission on Bus</p> <p>Transition from accessory mode to off is pending</p> <p>Controller not in programming mode</p> <p>If bus type = Sensor Bus:</p> <p>Sensor bus relay is present</p> <p>Battery voltage</p> <p>Sensor Bus Relay</p>	<p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>&gt; 15.00 milliseconds</p> <p>&gt; 8.41 Volts</p> <p>&gt;= 0.40 milliseconds</p> <p>&gt;= 5.00 milliseconds</p> <p>Enabled</p> <p>= False</p> <p></p> <p>1.00 (1 indicates present)</p> <p>&gt; 11.00 Volts</p> <p>= On</p>	Diagnostic runs in 12.5 ms loop	Type C, No SVS "Emissions Neutral Diagnostics – Type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Otherwise: If power mode = Run/ Crank:</p> <p>Power Mode</p> <p>If calibratable low voltage disable mode is not Never Disabled</p> <p>Low voltage disable mode: OBDII</p> <p>If OBDII: Run/Crank ignition voltage</p> <p>If EOBD: Run/Crank ignition voltage</p> <p>If Secure: Starter motor engaged for Or Run/Crank ignition voltage</p> <p>If Hybrid Secure: Run/Crank ignition voltage</p> <p>If power mode = Accessory</p> <p>Off key cycle diagnostics are enabled Or Controller is an OBD controller</p> <p>Controller shutdown</p>	<p>= Run</p> <p>&gt;= 11.00 Volts</p> <p>&gt;= 9.00 Volts</p> <p>&gt; 15.00 milliseconds</p> <p>&gt; 8.41 Volts</p> <p>&gt;= 6.41 Volts</p> <p>1.00 (1 indicates enabled)</p> <p>OBD Controller</p> <p>= False</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					impending Power Mode Battery voltage	= Not crank >= 11.00 Volts		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Power Steering Control Module	U0131	This DTC monitors for a loss of communication with the Power Steering Control Module	Message is not received from controller for  Message \$1E5	  ≥ 10.00 seconds	General Enable Criteria:  If message is on Bus A: U0073  If message is on Bus B: U0074  If message is on Bus S: U0076  Starter motor engaged for Or Run/Crank ignition voltage  Bus is enabled for  The following criteria have been enabled for  Normal CAN transmission on Bus  Transition from accessory mode to off is pending  Controller not in programming mode  If bus type = Sensor Bus:  Sensor bus relay is present  Battery voltage  Sensor Bus Relay   Otherwise:	  Not Active  Not Active  Not Active  > 15.00 milliseconds > 8.41 Volts  >= 0.40 milliseconds >= 5.00 milliseconds  Enabled  = False    1.00 (1 indicates present)  > 11.00 Volts  = On	Diagnostic runs in 12.5 ms loop	Type C, No SVS "Safety Emissio ns Neutral Diagnost ic"



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>If power mode = Run/ Crank:</p> <p>Power Mode</p> <p>If calibratable low voltage disable mode is not Never Disabled</p> <p>Low voltage disable mode: OBDII</p> <p>If OBDII: Run/Crank ignition voltage</p> <p>If EOBD: Run/Crank ignition voltage</p> <p>If Secure: Starter motor engaged for Or Run/Crank ignition voltage</p> <p>If Hybrid Secure: Run/Crank ignition voltage</p> <p>If power mode = Accessory</p> <p>Off key cycle diagnostics are enabled Or Controller is an OBD controller</p> <p>Controller shutdown impending</p>	<p>= Run</p> <p>&gt;= 11.00 Volts</p> <p>&gt;= 9.00 Volts</p> <p>&gt; 15.00 milliseconds &gt; 8.41 Volts</p> <p>&gt;= 6.41 Volts</p> <p>1.00 (1 indicates enabled)</p> <p>OBD Controller</p> <p>= False</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Mode Battery voltage	= Not crank >= 11.00 Volts		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Body Control Module	U0140	This DTC monitors for a loss of communication with the Body Control Module.	<p>Message is not received from controller for</p> <p>Message \$0F1</p> <p>Message \$12A</p> <p>Message \$1E1</p> <p>Message \$1F1</p> <p>Message \$1F3</p> <p>Message \$3C9</p> <p>Message \$3CB</p> <p>Message \$3F1</p> <p>Message \$451</p> <p>Message \$4D7</p> <p>Message \$4E1</p> <p>Message \$4E9</p>	<p>≥ 0.50 seconds</p> <p>≥ 1.00 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 10.00 seconds</p> <p>≥ 10.00 seconds</p> <p>≥ 10.00 seconds</p> <p>≥ 10.00 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 10.00 seconds</p> <p>≥ 10.00 seconds</p> <p>≥ 10.00 seconds</p>	<p>General Enable Criteria:</p> <p>If message is on Bus A: U0073</p> <p>If message is on Bus B: U0074</p> <p>If message is on Bus S: U0076</p> <p>Starter motor engaged for Or Run/Crank ignition voltage</p> <p>Bus is enabled for</p> <p>The following criteria have been enabled for</p> <p>Normal CAN transmission on Bus</p> <p>Transition from accessory mode to off is pending</p> <p>Controller not in programming mode</p> <p>If bus type = Sensor Bus:</p> <p>Sensor bus relay is present</p> <p>Battery voltage</p> <p>Sensor Bus Relay</p> <p>Otherwise:</p>	<p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>&gt; 15.00 milliseconds</p> <p>&gt; 8.41 Volts</p> <p>&gt;= 0.40 milliseconds</p> <p>&gt;= 5.00 milliseconds</p> <p>Enabled</p> <p>= False</p> <p>1.00 (1 indicates present)</p> <p>&gt; 11.00 Volts</p> <p>= On</p>	Diagnostic runs in 12.5 ms loop	Type C, No SVS "Emissio ns Neutral Diagnost ics – Type C"

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>If power mode = Run/ Crank:</p> <p>Power Mode</p> <p>If calibratable low voltage disable mode is not Never Disabled</p> <p>Low voltage disable mode: OBDII</p> <p>If OBDII: Run/Crank ignition voltage</p> <p>If EOBD: Run/Crank ignition voltage</p> <p>If Secure: Starter motor engaged for Or Run/Crank ignition voltage</p> <p>If Hybrid Secure: Run/Crank ignition voltage</p> <p>If power mode = Accessory</p> <p>Off key cycle diagnostics are enabled Or Controller is an OBD controller</p> <p>Controller shutdown impending</p>	<p>= Run</p> <p>&gt;= 11.00 Volts</p> <p>&gt;= 9.00 Volts</p> <p>&gt; 15.00 milliseconds &gt; 8.41 Volts</p> <p>&gt;= 6.41 Volts</p> <p>1.00 (1 indicates enabled)</p> <p>OBD Controller</p> <p>= False</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Mode Battery voltage	= Not crank >= 11.00 Volts		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Battery Monitor Module	U01B0	This DTC monitors for a loss of communication with the Battery Monitor Module on LIN bus	Communication failures equals or exceeds	3.00 counts	General Enable Criteria:  U1345  Subnet configuration not used Or Device is calibrated as present  The following criteria have been enabled for  Normal LIN transmission on Bus  Controller not in programming mode  If UCAP is present on bus, starter motor is not engaged  Power mode And Run/Crank ignition voltage Or Battery voltage  And the following criteria have been enabled for  LIN bus is awake  Power mode Or If controller is a non-OBD controller: LIN communications enabled during cranking	Not active this key cycle  1.00 (0 indicates not used)  38,960.00  >= 5.00 milliseconds  Enabled  0.00 (1 indicates present)  = Run >= 11.00 Volts >= 11.00 Volts >= 400.00 milliseconds  = Run or accessory  0.00 (1 indicates enabled)	Between 100ms and 175ms due to rate of LIN communication to Battery Monitor Module.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power mode  Controller type: OBD Controller	= Crank		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on with Active Grill Air Shutter Module A	U0284	This DTC monitors for a loss of communication on the LIN bus with Shutter Module A	Communication failures equals or exceeds	3.00 counts	General Enable Criteria:  U1345  Subnet configuration not used Or Device is calibrated as present  The following criteria have been enabled for  Normal LIN transmission on Bus  Controller not in programming mode  If UCAP is present on bus, starter motor is not engaged  Power mode And Run/Crank ignition voltage Or Battery voltage  And the following criteria have been enabled for  LIN bus is awake  Power mode Or If controller is a non-OBD controller: LIN communications enabled during cranking	Not active this key cycle  1.00 (0 indicates not used)  38,960.00  >= 5.00 milliseconds  Enabled  0.00 (1 indicates present)  = Run >= 11.00 Volts >= 11.00 Volts >= 400.00 milliseconds  = Run or accessory  0.00 (1 indicates enabled)	LIN bus communication executes in 500ms loop.	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power mode  Controller type: OBD Controller	= Crank		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cooling Fan 1 LIN Communication Failure	U0632	This DTC monitors for a loss of communication on the LIN bus with Cooling Fan 1	Communication failures equals or exceeds	3.00 counts	<p>General Enable Criteria:</p> <p>U1345</p> <p>Subnet configuration not used Or Device is calibrated as present</p> <p>The following criteria have been enabled for</p> <p>Normal LIN transmission on Bus</p> <p>Controller not in programming mode</p> <p>If UCAP is present on bus, starter motor is not engaged</p> <p>Power mode And Run/Crank ignition voltage Or Battery voltage</p> <p>And the following criteria have been enabled for</p> <p>LIN bus is awake</p> <p>Power mode Or If controller is a non-OBD controller: LIN communications enabled during cranking</p>	<p>Not active this key cycle</p> <p>1.00 (0 indicates not used)</p> <p>38,960.00</p> <p>&gt;= 5.00 milliseconds</p> <p>Enabled</p> <p>0.00 (1 indicates present)</p> <p>= Run</p> <p>&gt;= 11.00 Volts</p> <p>&gt;= 11.00 Volts</p> <p>&gt;= 400.00 milliseconds</p> <p>= Run or accessory</p> <p>0.00 (1 indicates enabled)</p>	LIN bus communication executes in 500ms loop.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power mode  Controller type: OBD Controller	= Crank		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Control Module LIN Bus 1	U1345	This DTC monitors for a LIN bus off condition on LIN Bus 1	Bus off failures equals or exceeds	3.00 counts	<p>General Enable Criteria:</p> <p>The following criteria have been enabled for</p> <p>Normal LIN transmission on Bus</p> <p>Controller not in programming mode</p> <p>If UCAP is present on bus, starter motor is not engaged</p> <p>Power mode And Run/Crank ignition voltage Or Battery voltage</p> <p>And the following criteria have been enabled for</p> <p>LIN bus is awake</p> <p>Power mode Or If controller is a non-OBD controller: LIN communications enabled during cranking</p> <p>Power mode</p> <p>Controller type: OBD Controller</p>	<p>&gt;= 5.00 milliseconds</p> <p>Enabled</p> <p>0.00 (1 indicates present)</p> <p>= Run</p> <p>&gt;= 11.00 Volts</p> <p>&gt;= 11.00 Volts</p> <p>&gt;= 400.00 milliseconds</p> <p>= Run or accessory</p> <p>0.00 (1 indicates enabled)</p> <p>= Crank</p>	Dependent on bus loading.	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Fuel Pump Driver Control Module on Bus S	U18A2	This DTC monitors for a loss of communication with the Fuel Pump Driver Control Module on Bus S.	<p>Message is not received from controller for</p> <p>Message \$0D5</p> <p>Message \$0D7</p>	<p>≥ 4.00 seconds</p> <p>≥ 4.00 seconds</p>	<p>General Enable Criteria:</p> <p>If message is on Bus A: U0073</p> <p>If message is on Bus B: U0074</p> <p>If message is on Bus S: U0076</p> <p>Starter motor engaged for Or Run/Crank ignition voltage</p> <p>Bus is enabled for</p> <p>The following criteria have been enabled for</p> <p>Normal CAN transmission on Bus</p> <p>Transition from accessory mode to off is pending</p> <p>Controller not in programming mode</p> <p>If bus type = Sensor Bus:</p> <p>Sensor bus relay is present</p> <p>Battery voltage</p> <p>Sensor Bus Relay</p> <p>Otherwise:</p>	<p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>&gt; 15.00 milliseconds</p> <p>&gt; 8.41 Volts</p> <p>&gt;= 0.40 milliseconds</p> <p>&gt;= 5.00 milliseconds</p> <p>Enabled</p> <p>= False</p> <p></p> <p>1.00 (1 indicates present)</p> <p>&gt; 11.00 Volts</p> <p>= On</p>	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>If power mode = Run/ Crank:</p> <p>Power Mode</p> <p>If calibratable low voltage disable mode is not Never Disabled</p> <p>Low voltage disable mode: OBDII</p> <p>If OBDII: Run/Crank ignition voltage</p> <p>If EOBD: Run/Crank ignition voltage</p> <p>If Secure: Starter motor engaged for Or Run/Crank ignition voltage</p> <p>If Hybrid Secure: Run/Crank ignition voltage</p> <p>If power mode = Accessory</p> <p>Off key cycle diagnostics are enabled Or Controller is an OBD controller</p> <p>Controller shutdown impending</p>	<p>= Run</p> <p>&gt;= 11.00 Volts</p> <p>&gt;= 9.00 Volts</p> <p>&gt; 15.00 milliseconds &gt; 8.41 Volts</p> <p>&gt;= 6.41 Volts</p> <p>1.00 (1 indicates enabled)</p> <p>OBD Controller</p> <p>= False</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Mode Battery voltage	= Not crank >= 11.00 Volts		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With DC/ DC Converter Control Module on Bus B	U18A7	This DTC monitors for a loss of communication with the DC/DC Converter Control Module on Bus B.	<p>Message is not received from controller for</p> <p>Message \$0A0</p> <p>Message \$1D2</p>	<p>≥ 10.00 seconds</p> <p>≥ 10.00 seconds</p>	<p>General Enable Criteria:</p> <p>If message is on Bus A: U0073</p> <p>If message is on Bus B: U0074</p> <p>If message is on Bus S: U0076</p> <p>Starter motor engaged for Or Run/Crank ignition voltage</p> <p>Bus is enabled for</p> <p>The following criteria have been enabled for</p> <p>Normal CAN transmission on Bus</p> <p>Transition from accessory mode to off is pending</p> <p>Controller not in programming mode</p> <p>If bus type = Sensor Bus:</p> <p>Sensor bus relay is present</p> <p>Battery voltage</p> <p>Sensor Bus Relay</p> <p>Otherwise:</p>	<p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>&gt; 15.00 milliseconds</p> <p>&gt; 8.41 Volts</p> <p>&gt;= 0.40 milliseconds</p> <p>&gt;= 5.00 milliseconds</p> <p>Enabled</p> <p>= False</p> <p></p> <p>1.00 (1 indicates present)</p> <p>&gt; 11.00 Volts</p> <p>= On</p>	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>If power mode = Run/ Crank:</p> <p>Power Mode</p> <p>If calibratable low voltage disable mode is not Never Disabled</p> <p>Low voltage disable mode: OBDII</p> <p>If OBDII: Run/Crank ignition voltage</p> <p>If EOBD: Run/Crank ignition voltage</p> <p>If Secure: Starter motor engaged for Or Run/Crank ignition voltage</p> <p>If Hybrid Secure: Run/Crank ignition voltage</p> <p>If power mode = Accessory</p> <p>Off key cycle diagnostics are enabled Or Controller is an OBD controller</p> <p>Controller shutdown impending</p>	<p>= Run</p> <p>&gt;= 11.00 Volts</p> <p>&gt;= 9.00 Volts</p> <p>&gt; 15.00 milliseconds &gt; 8.41 Volts</p> <p>&gt;= 6.41 Volts</p> <p>1.00 (1 indicates enabled)</p> <p>OBD Controller</p> <p>= False</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Mode Battery voltage	= Not crank >= 11.00 Volts		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on with Front Object Detection Control Module	U216A	This DTC monitors for a loss of communication with the Front Object Detection Control Module.	<p>Message is not received from controller for</p> <p>Message \$2CB</p> <p>Message \$2CD</p> <p>Message \$2CF</p> <p>Message \$370</p>	<p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 10.00 seconds</p>	<p>General Enable Criteria:</p> <p>If message is on Bus A: U0073</p> <p>If message is on Bus B: U0074</p> <p>If message is on Bus S: U0076</p> <p>Starter motor engaged for Or Run/Crank ignition voltage</p> <p>Bus is enabled for</p> <p>The following criteria have been enabled for</p> <p>Normal CAN transmission on Bus</p> <p>Transition from accessory mode to off is pending</p> <p>Controller not in programming mode</p> <p>If bus type = Sensor Bus:</p> <p>Sensor bus relay is present</p> <p>Battery voltage</p> <p>Sensor Bus Relay</p> <p>Otherwise:</p>	<p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>&gt; 15.00 milliseconds</p> <p>&gt; 8.41 Volts</p> <p>&gt;= 0.40 milliseconds</p> <p>&gt;= 5.00 milliseconds</p> <p>Enabled</p> <p>= False</p> <p>1.00 (1 indicates present)</p> <p>&gt; 11.00 Volts</p> <p>= On</p>	Diagnostic runs in 12.5 ms loop	Type C, No SVS

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>If power mode = Run/ Crank:</p> <p>Power Mode</p> <p>If calibratable low voltage disable mode is not Never Disabled</p> <p>Low voltage disable mode: OBDII</p> <p>If OBDII: Run/Crank ignition voltage</p> <p>If EOBD: Run/Crank ignition voltage</p> <p>If Secure: Starter motor engaged for Or Run/Crank ignition voltage</p> <p>If Hybrid Secure: Run/Crank ignition voltage</p> <p>If power mode = Accessory</p> <p>Off key cycle diagnostics are enabled Or Controller is an OBD controller</p> <p>Controller shutdown impending</p>	<p>= Run</p> <p>&gt;= 11.00 Volts</p> <p>&gt;= 9.00 Volts</p> <p>&gt; 15.00 milliseconds &gt; 8.41 Volts</p> <p>&gt;= 6.41 Volts</p> <p>1.00 (1 indicates enabled)</p> <p>OBD Controller</p> <p>= False</p>		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Mode Battery voltage	= Not crank >= 11.00 Volts		

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lateral Acceleration Sensor Circuit Low	C124F	Controller specific analog circuit diagnoses the raw lateral acceleration signal for a short to ground or open fault by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral acceleration signal = 0.0 g.	raw lateral acceleration signal when sensor type is directly proportional OR raw lateral acceleration signal when sensor type is inversely proportional  update raw lateral acceleration signal stability time, fail and sample time, 50 millisecond update rate	$\leq -3.8500 \text{ g}$  $\geq -3.8500 \text{ g}$  ( $\leq 0.5 \Omega$ impedance between signal and controller ground)	battery voltage run crank voltage diagnostic monitor enable  sensor type is either directly proportional or inversely proportional  U0073 fault active U0073 test fail this key on	$\geq 11.00 \text{ volts}$ $\geq 11.00 \text{ volts}$ = 1 Boolean  = CeLATR_e_VoltageDirec tProp  = FALSE = FALSE	raw lateral acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lateral Acceleration Sensor Circuit High	C1250	Controller specific analog circuit diagnoses the raw lateral acceleration signal for a short to power or open fault by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral acceleration signal = 0.0 g.	raw lateral acceleration signal when sensor type is directly proportional OR raw lateral acceleration signal when sensor type is inversely proportional  update raw lateral acceleration signal stability time, fail and sample time, 50 millisecond update rate	$\geq 3.8500 \text{ g}$  $\leq 3.8500 \text{ g}$  ( $\leq 0.5 \Omega$ impedance between signal and controller power)	battery voltage run crank voltage diagnostic monitor enable  sensor type is either directly proportional or inversely proportional  U0073 fault active U0073 test fail this key on	$\geq 11.00 \text{ volts}$ $\geq 11.00 \text{ volts}$ = 1 Boolean  = CeLATR_e_VoltageDirec tProp  = FALSE = FALSE	raw lateral acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lateral Acceleration Sensor Performance	C1251	<p>Controller specific analog circuit diagnoses the raw lateral acceleration signal for a signal value that is stuck in a valid range by comparing raw signal value to fail thresholds.</p> <p>Emission neutral default state sets lateral acceleration signal = 0.0 g.</p>	<p>ABS(raw lateral acceleration signal) AND ABS(raw lateral acceleration signal)</p> <p>update raw lateral acceleration signal fail, 50 millisecond update rate</p>	<p><math>\geq 0.5300</math> g</p> <p><math>\leq 3.8500</math> g</p>	<p>battery voltage run crank voltage diagnostic monitor enable</p> <p>update raw lateral acceleration signal stability time: TOSS vehicle speed automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable diagnostic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear</p> <p>ABS(raw lateral acceleration signal) update sample time</p> <p>U0073 fault active U0073 test fail this key on DTCs not fault active</p>	<p><math>\geq 11.00</math> volts <math>\geq 11.00</math> volts = 1 Boolean</p> <p><math>\geq 15.0</math> KPH = TRUE</p> <p>= TRUE = TRUE = FALSE</p> <p>= FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1st thru 10th</p> <p>&lt; 0.5300 g</p> <p>= FALSE = FALSE VehicleSpeedSensor_FA</p>	<p>raw lateral acceleration signal stability time <math>\geq 30.0</math> seconds, fail time <math>\geq 75.0</math> seconds out of sample time <math>\geq 120.0</math> seconds, 50 millisecond update rate</p>	<p>Emissions Neutral Diagnostic – Type C</p>



## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Longitudinal Acceleration Sensor Circuit Low	C1252	Controller specific analog circuit diagnoses the raw longitudinal acceleration signal for a short to ground or open fault by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral longitudinal acceleration signal = 0.0 g.	raw longitudinal acceleration signal when sensor type is directly proportional OR raw longitudinal acceleration signal when sensor type is inversely proportional  update raw longitudinal acceleration signal stability time, fail and sample time, 50 millisecond update rate	$\leq -3.8500 \text{ g}$  $\geq -3.8500 \text{ g}$  ( $\leq 0.5 \text{ } \Omega$ impedance between signal and controller ground)	battery voltage run crank voltage diagnostic monitor enable  sensor type is either directly proportional or inversely proportional  U0073 fault active U0073 test fail this key on	$\geq 11.00 \text{ volts}$ $\geq 11.00 \text{ volts}$ = 1 Boolean  = CeLATR_e_VoltageDirec tProp  = FALSE = FALSE	raw longitudinal acceleration signal stability time $\geq 15.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Longitudinal Acceleration Sensor Circuit High	C1253	Controller specific analog circuit diagnoses the raw longitudinal acceleration signal for a short to power or open fault by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral longitudinal acceleration signal = 0.0 g.	raw longitudinal acceleration signal when sensor type is directly proportional OR raw longitudinal acceleration signal when sensor type is inversely proportional  update raw longitudinal acceleration signal stability time, fail and sample time, 50 millisecond update rate	$\geq 3.8500 \text{ g}$  $\leq 3.8500 \text{ g}$  ( $\leq 0.5 \Omega$ impedance between signal and controller power)	battery voltage run crank voltage diagnostic monitor enable  sensor type is either directly proportional or inversely proportional  U0073 fault active U0073 test fail this key on	$\geq 11.00 \text{ volts}$ $\geq 11.00 \text{ volts}$ = 1 Boolean  = CeLATR_e_VoltageDirec tProp  = FALSE = FALSE	raw longitudinal acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Longitudinal Acceleration Sensor Performance	C1254	<p>Controller specific analog circuit diagnoses the raw longitudinal acceleration signal rationalized against the TOSS vehicle speed acceleration. The diagnostic monitor can be designed to detect an invalid longitudinal acceleration signal based on the TOSS vehicle speed windows and TOSS vehicle speed acceleration, 4 windows can be enabled. The delta between the TOSS vehicle speed acceleration and longitudinal acceleration signal is taken within each window to verify the delta is small, no failure indicated, or the delta is large indicating the longitudinal acceleration signal is in error.</p> <p>Emission neutral default state sets lateral longitudinal acceleration signal = 0.0 g.</p>	<p>ABS(TOSS vehicle speed acceleration - raw longitudinal acceleration signal)</p> <p>update raw longitudinal acceleration signal fail time, 50 millisecond update rate</p> <p>update raw longitudinal acceleration signal region 1 fail time, 50 millisecond update rate</p>	≥ 0.5300 g	<p>battery voltage run crank voltage diagnostic monitor enable region 1 specific enable</p> <p>update raw lateral longitudinal acceleration signal stability time: TOSS vehicle speed TOSS vehicle speed acceleration automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable diagnostic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear ABS(raw longitudinal acceleration signal) AND ABS(raw longitudinal acceleration signal)</p> <p>update region 1 sample time: brake pedal position engine torque TOSS vehicle speed acceleration TOSS vehicle speed TOSS vehicle speed</p>	<p>≥ 11.00 volts ≥ 11.00 volts = 1 Boolean = 0 Boolean</p> <p>≥ 15.0 KPH ≤ 0.5300 g</p> <p>= TRUE</p> <p>= TRUE = TRUE = FALSE</p> <p>= FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1st thru 10th ≥ 0.5300 g</p> <p>≤ 3.8500 g</p> <p>≤ 0.70 % ≥ 80.0 Nm ≥ 0.1500 g</p> <p>≥ 15.0 KPH ≤ 200.0 KPH</p>	<p>raw lateral longitudinal acceleration signal stability time ≥ 10.0 seconds</p> <p>fail time ≥ 75.0 seconds out of sample time ≥ 120.0 seconds, 50 millisecond update rate</p> <p>region 1 fail time ≥ 75.0 seconds out of region 1 sample time ≥ 120.0 seconds, 50 millisecond update rate</p>	Emissions Neutral Diagnostic – Type C

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					ABS(raw longitudinal acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	< 0.5300 g  = FALSE = FALSE VehicleSpeedSensor_FA VehicleSpeedSensorError		
			ABS(TOSS vehicle speed acceleration - raw longitudinal acceleration signal)  update raw longitudinal acceleration signal fail time, 50 millisecond update rate  update raw longitudinal acceleration signal region 2 fail time, 50 millisecond update rate	≥ 0.0000 g	battery voltage run crank voltage diagnostic monitor enable region 2 specific enable  update raw lateral longitudinal acceleration signal stability time: TOSS vehicle speed TOSS vehicle speed acceleration automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable diagnsotic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear ABS(raw longitudinal acceleration signal) AND ABS(raw longitudinal acceleration signal)	≥ 11.00 volts ≥ 11.00 volts = 1 Boolean = 0 Boolean  ≥ 15.0 KPH ≤ 0.5300 g  = TRUE  = TRUE = TRUE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1st thru 10th ≥ 0.5300 g  ≤ 3.8500 g	raw longitudinal acceleration signal stability time ≥ 10.0 seconds  raw longitudinal acceleration signal fail time ≥ 75.0 seconds out of sample time ≥ 120.0 seconds, 50 millisecond update rate  region 2 fail time ≥ 75.0 seconds out of region 2 sample time ≥ 120.0 seconds, 50 millisecond update rate	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					update region 2 sample time: brake pedal position engine torque TOSS vehicle speed acceleration TOSS vehicle speed TOSS vehicle speed  ABS(raw longitudinal acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	≤ 0.70 % ≥ 80.0 Nm ≥ 0.1500 g  ≥ 0.0 KPH ≤ 0.0 KPH  < 0.5300 g  = FALSE = FALSE VehicleSpeedSensor_FA VehicleSpeedSensorError		
			ABS(TOSS vehicle speed acceleration - raw longitudinal acceleration signal)  update raw longitudinal acceleration signal fail time, 50 millisecond update rate  update raw longitudinal acceleration signal region 3 fail time, 50 millisecond update rate	≥ 0.0000 g	battery voltage run crank voltage diagnostic monitor enable region 3 specific enable  update raw lateral longitudinal acceleration signal stability time: TOSS vehicle speed TOSS vehicle speed acceleration automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable diagnostic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on P07BF fault active P07BF test fail this key on	≥ 11.00 volts ≥ 11.00 volts = 1 Boolean = 0 Boolean  ≥ 15.0 KPH ≤ 0.5300 g  = TRUE  = TRUE = TRUE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE	raw longitudinal acceleration signal stability time ≥ 10.0 seconds  raw longitudinal acceleration signal fail time ≥ 75.0 seconds out of sample time ≥ 120.0 seconds, 50 millisecond update rate  region 3 fail time ≥ 75.0 seconds out of region 3 sample time ≥ 120.0 seconds, 50 millisecond update rate	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P07C0 fault active P07C0test fail this key on attained gear ABS(raw longitudinal acceleration signal) AND ABS(raw longitudinal acceleration signal)  update region 3 sample time: brake pedal position engine torque ABS(TOSS vehicle speed acceleration) TOSS vehicle speed  ABS(raw longitudinal acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	= FALSE = FALSE = 1st thru 10th ≥ 0.5300 g  ≤ 3.8500 g  ≤ 0.70 % ≥ 80.0 Nm ≤ 0.1000 g ≥ 0.0 KPH  < 0.5300 g		
			ABS(TOSS vehicle speed acceleration - raw longitudinal acceleration signal)  update raw longitudinal acceleration signal fail time, 50 millisecond update rate  update raw longitudinal acceleration signal region 4 fail time, 50 millisecond update rate	≥ 0.0000 g	battery voltage run crank voltage diagnostic monitor enable region 3 specific enable  update raw lateral longitudinal acceleration signal stability time: TOSS vehicle speed TOSS vehicle speed acceleration automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable	≥ 11.00 volts ≥ 11.00 volts = 1 Boolean = 0 Boolean  ≥ 15.0 KPH ≤ 0.5300 g  = TRUE  = TRUE = TRUE	raw longitudinal acceleration signal stability time ≥ 10.0 seconds  raw longitudinal acceleration signal fail time ≥ 75.0 seconds out of sample time ≥ 120.0 seconds, 50 millisecond update rate	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					diagnosic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear ABS(raw longitudinal acceleration signal) AND ABS(raw longitudinal acceleration signal)  update region 4 sample time: brake pedal position engine torque TOSS vehicle speed acceleration TOSS vehicle speed TOSS vehicle speed  ABS(raw longitudinal acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	= FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1st thru 10th ≥ 0.5300 g  ≤ 3.8500 g  ≤ 0.70 % ≤ 80.0 Nm ≤ 0.1500 g  ≥ 0.0 KPH ≤ 0.0 KPH  < 0.5300 g  = FALSE = FALSE VehicleSpeedSensor_FA VehicleSpeedSensorError	region 4 fail time ≥ 75.0 seconds out of region 4 sample time ≥ 120.0 seconds, 50 millisecond update rate	

## 20 OBDG03A ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Acceleration Sensor Signal Message Counter Incorrect	P175F	<p>The diagnostic monitor detects an alive rolling count error or checksum error in the CAN frame containing the lateral acceleration signal value and longitudinal acceleration sensor signal value.</p> <p>Emission neutral default state sets lateral longitudinal acceleration signal = 0.0 g.</p>	<p>rolling count value received from EBCM and expected TCM calculated value not equal OR checksum lateral and longitudinal acceleration CAN frame message value error</p> <p>50 millisecond update rate</p>	<p>= TRUE</p> <p>= TRUE</p>	<p>enable alive rolling count error detection: diagnostic monitor enable lateral and longitudinal acceleration CAN frame message received battery voltage run crank voltage</p> <p>enable checksum error detection: diagnostic monitor enable lateral and longitudinal acceleration CAN frame message received normal CAN battery voltage run crank voltage communication enabled</p> <p>DTCs not fault active</p>	<p>= 1 Boolean = TRUE</p> <p>≥ 11.0 volts ≥ 11.0 volts</p> <p>= 1 Boolean = TRUE</p> <p>≥ 11.0 volts ≥ 11.0 volts = TRUE</p> <p>U0073</p>	<p>alive rolling count errors ≥ 54 out of 9 sample counts 50 millisecond update rate</p> <p>checksum error time ≥ 54.00 seconds</p>	<p>Emissions Neutral Diagnostic – Type C</p>



## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0011\_CamPosErrorLimlc1

**Description:** Maximum Intake Cam 1 phase error as a function of engine speed and engine oil temperature.

**Value Units:** Maximum Intake Cam 1 phase error (degCAM)

**X Unit:** Engine Oil Temperature (degC)

**Y Units:** Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_EngOilPressEnbllc

**Description:** Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met

**Value Units:** Time (sec)  
**X Unit:** Engine Coolant Temperature (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	6	6	6	4	4	3	3	2	1	1	1	1	1	1	1	1	1

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_HiEngSpdHiDsbllc

**Description:** Minimum engine speed to disable Intake cam

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_HiEngSpdLoEnbllc

**Description:** Maximum engine speed to enable Intake cam - works as hysteresis.

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_LoPresHiEnbllc

**Description:** Intake cam is enabled when oil pressure exceeds this value

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_LoPresLoDsblc

**Description:** Intake cam is disabled when oil pressure falls below this value

**Value Units:** Engine Oil Pressure (kPa)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_LoRpmHiEnbllc

**Description:** Intake cam is enabled when engine speed exceeds this value.

**Value Units:** Engine Speed (rpm)  
**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	400	400	400	400	450	450	450	450	450	450	450	450	450	1,200	1,400	1,650	7,600

Initial Supporting table - P0011\_P0021\_P05CC\_P05CD\_LoRpmLoDsbllc

**Description:** Intake cam is disabled when engine speed is below this value.

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300	300	300	300	350	350	350	350	350	350	350	350	350	1,100	1,300	1,550	7,500



Initial Supporting table - P0011_P0021_P05CC_P05CD_P0014_P0024_P05CE_P05CF_ColdStartEngRunning																	
<b>Description:</b> Engine running time must be greater than this threshold during a cold start to enable cam phasing																	
<b>Value Units:</b> Time (sec) <b>X Unit:</b> Engine Oil Temp (degC)																	
y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	24	24	18	4	4	3	3	3	3	3	3	2	2	2	2	2	2

# 20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0011\_P05CC\_StablePositionTimeIc1

**Description:** Minimum time for Intake Cam 1 phase position to be stable to enable performance diagnostic.

**Value Units:** Minimum time (sec)

**X Unit:** Engine Oil Temperature (degC)

**Y Units:** Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
800	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
1,200	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
1,600	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
2,000	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
2,400	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
2,800	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
3,200	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
3,600	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
4,000	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
4,400	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
4,800	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
5,200	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
5,600	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
6,000	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
6,400	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
6,800	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0014\_CamPosErrorLimEc1

**Description:** Maximum Exhaust Cam 1 phase error as a function of engine speed and engine oil temperature.

**Value Units:** Maximum Exhaust Cam 1 phase error (degCAM)

**X Unit:** Engine Oil Temperature (degC)

**Y Units:** Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
1,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
2,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
3,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
4,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,200	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
5,600	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,000	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,400	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0
6,800	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_EngOilPressEnblEc

**Description:** Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met

**Value Units:** Time (sec)  
**X Unit:** Engine Coolant Temperature (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	7	7	7	5	5	4	4	2	1	1	1	1	1	1	1	1	1

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_HiEngSpdHiDsblEc

**Description:** Exhaust cam is disabled when engine speed exceeds this value

**Value Units:** Engine Speed (rpm)  
**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000	8,000

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_HiEngSpdLoEnblEc

**Description:** Exhaust cam is enabled when engine speed remains below this value

**Value Units:** Engine Speed (rpm)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800	7,800

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_LoPresHiEnbIEc

**Description:** Exhaust cam is enabled when oil pressure exceeds this value

**Value Units:** Engine Oil Pressure (kPa)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_LoPresLoDsblEc

**Description:** Exhaust cam is disabled when oil pressure falls below this value

**Value Units:** Engine Oil Pressure (kPa)

**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100



Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_LoRpmHiEnbIEc

**Description:** Exhaust cam is enabled when engine speed exceeds this value.

**Value Units:** Engine Speed (rpm)  
**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	400	400	400	400	450	450	450	450	450	450	450	450	450	1,200	1,400	1,650	7,600

Initial Supporting table - P0014\_P0024\_P05CE\_P05CF\_LoRpmLoDsblEc

**Description:** Exhaust cam is disabled when engine speed is below this value.

**Value Units:** Engine Speed (rpm)  
**X Unit:** Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300	300	300	300	350	350	350	350	350	350	350	350	350	1,100	1,300	1,550	7,500

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0014\_P05CE\_StablePositionTimeEc1

**Description:** Minimum time for Exhaust Cam 1 phase position to be stable to enable performance diagnostic.

**Value Units:** Minimum time (sec)

**X Unit:** Engine Oil Temperature (degC)

**Y Units:** Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
800	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
1,200	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
1,600	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
2,000	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
2,400	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
2,800	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
3,200	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
3,600	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
4,000	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
4,400	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
4,800	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
5,200	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
5,600	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
6,000	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
6,400	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
6,800	100.0	80.0	6.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

**Description:** P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

**Value Units:** Engine Run Time- Seconds

**X Unit:** Oil Temperature- C

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	3.0	3.0	2.5	1.8	1.0	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5

Initial Supporting table - P0016-0019 Mid-Park Phaser Delay

**Description:** P0016-0019 Mid-Park Phaser Park Delay. Total delay is twice the calibration value as both 'hi' side and 'lo' side park check sequences are delayed by the stated calibration values

**Value Units:** Time - seconds  
**X Unit:** Oil Temperature - degC

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	600.0	600.0	320.0	36.0	36.0	36.0	36.0	20.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

Initial Supporting table - P0071: OAT Performance Drive Equilibrium Engine Off

**Description:** OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine off (for hybrid applications)

**Value Units:** Counter Increment Value (Unitless)

**X Unit:** Vehicle Speed (KPH)

y/x	0.0	5.0	10.0	15.0	20.0	25.0	30.0	50.0	80.0
1.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0071: OAT Performance Drive Equilibrium Engine Running

**Description:** OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine running

**Value Units:** Counter Increment Value (Unitless)

**X Unit:** Vehicle Speed (KPH)

**Y Units:** Engine Air Flow (Grams/Second)

y/x	0.0	5.0	10.0	15.0	20.0	25.0	30.0	50.0	80.0
1.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0	9.0
5.0	-5.0	-2.0	-1.0	0.0	1.0	2.0	3.0	4.0	5.0
10.0	-4.0	-1.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0
20.0	-2.0	-1.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0
30.0	-1.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0
40.0	0.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0
50.0	0.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0
60.0	0.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0
70.0	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0	9.0

Initial Supporting table - P00C4 P2261: Compressor Surge Line

**Description:** Turbo compressor recirculation valve diagnosis surge area limit.

**Value Units:** [ratio] CRV diagnosis surge area limit.

**X Unit:** [g/sec[] KnBSTD\_dm\_AirFlowBP - Air FLOW

y/x	0.00	38.09	76.63	100.00	143.52	189.11
1	1.000	1.500	2.444	2.700	3.100	3.412



## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

**Description:** Turbocharger Intake Flow Rationality Diagnostic Failure Matrix - This table describes combinations of individual model failures that will set P0101, P0106, P010B, P0121, P0236 and P1101 on turbocharged applications.

**Value Units:** Boolean

**X Unit:** Unitless (See top line for heading information)

**Y Units:** Unitless

y/x	1	2	3	4	5	6	7	8	9
1	MAF Model	MAP1 Model	MAP2 Model	MAP3 Model	TIAP1 Model	TPS Model	TIAP Correlation	TIAP Correlation	DTC Set
2	Failed	Failed	Failed	Failed	Failed	Failed	Failed	Valid	
3	F	F	F	F	F	F	F	F	No DTC
4	F	F	F	F	F	F	F	T	No DTC
5	F	F	F	F	F	F	T	F	No DTC
6	F	F	F	F	F	F	T	T	No DTC
7	F	F	F	F	F	T	F	F	No DTC
8	F	F	F	F	F	T	F	T	No DTC
9	F	F	F	F	F	T	T	F	No DTC
10	F	F	F	F	F	T	T	T	No DTC
11	F	F	F	F	T	F	F	F	No DTC
12	F	F	F	F	T	F	F	T	No DTC
13	F	F	F	F	T	F	T	F	No DTC
14	F	F	F	F	T	F	T	T	No DTC
15	F	F	F	F	T	T	F	F	P1101
16	F	F	F	F	T	T	F	T	P0121
17	F	F	F	F	T	T	T	F	P1101
18	F	F	F	F	T	T	T	T	P0236
19	F	F	F	T	F	F	F	F	No DTC
20	F	F	F	T	F	F	F	T	No DTC
21	F	F	F	T	F	F	T	F	P1101
22	F	F	F	T	F	F	T	T	P1101
23	F	F	F	T	F	T	F	F	P1101
24	F	F	F	T	F	T	F	T	P1101
25	F	F	F	T	F	T	T	F	P1101
26	F	F	F	T	F	T	T	T	P1101
27	F	F	F	T	T	F	F	F	P1101
28	F	F	F	T	T	F	F	T	P1101
29	F	F	F	T	T	F	T	F	P1101
30	F	F	F	T	T	F	T	T	P1101
31	F	F	F	T	T	T	F	F	P1101

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

32	F	F	F	T	T	T	F	T	P1101
33	F	F	F	T	T	T	T	F	P1101
34	F	F	F	T	T	T	T	T	P1101
35	F	F	T	F	F	F	F	F	No DTC
36	F	F	T	F	F	F	F	T	No DTC
37	F	F	T	F	F	F	T	F	P1101
38	F	F	T	F	F	F	T	T	P1101
39	F	F	T	F	F	T	F	F	P1101
40	F	F	T	F	F	T	F	T	P1101
41	F	F	T	F	F	T	T	F	P1101
42	F	F	T	F	F	T	T	T	P1101
43	F	F	T	F	T	F	F	F	P1101
44	F	F	T	F	T	F	F	T	P1101
45	F	F	T	F	T	F	T	F	P1101
46	F	F	T	F	T	F	T	T	P1101
47	F	F	T	F	T	T	F	F	P1101
48	F	F	T	F	T	T	F	T	P1101
49	F	F	T	F	T	T	T	F	P1101
50	F	F	T	F	T	T	T	T	P1101
51	F	F	T	T	F	F	F	F	P1101
52	F	F	T	T	F	F	F	T	P1101
53	F	F	T	T	F	F	T	F	P1101
54	F	F	T	T	F	F	T	T	P1101
55	F	F	T	T	F	T	F	F	P1101
56	F	F	T	T	F	T	F	T	P1101
57	F	F	T	T	F	T	T	F	P1101
58	F	F	T	T	F	T	T	T	P1101
59	F	F	T	T	T	F	F	F	No DTC
60	F	F	T	T	T	F	F	T	No DTC
61	F	F	T	T	T	F	T	F	No DTC
62	F	F	T	T	T	F	T	T	No DTC
63	F	F	T	T	T	T	F	F	P1101
64	F	F	T	T	T	T	F	T	P1101
65	F	F	T	T	T	T	T	F	P1101
66	F	F	T	T	T	T	T	T	P1101
67	F	T	F	F	F	F	F	F	No DTC
68	F	T	F	F	F	F	F	T	No DTC
69	F	T	F	F	F	F	T	F	P1101

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

70	F	T	F	F	F	F	T	T	P0236
71	F	T	F	F	F	T	F	F	P1101
72	F	T	F	F	F	T	F	T	P0121
73	F	T	F	F	F	T	T	F	P1101
74	F	T	F	F	F	T	T	T	P0236
75	F	T	F	F	T	F	F	F	P1101
76	F	T	F	F	T	F	F	T	P1101
77	F	T	F	F	T	F	T	F	P1101
78	F	T	F	F	T	F	T	T	P0236
79	F	T	F	F	T	T	F	F	P1101
80	F	T	F	F	T	T	F	T	P0121
81	F	T	F	F	T	T	T	F	P1101
82	F	T	F	F	T	T	T	T	P0236
83	F	T	F	T	F	F	F	F	P1101
84	F	T	F	T	F	F	F	T	P1101
85	F	T	F	T	F	F	T	F	P1101
86	F	T	F	T	F	F	T	T	P1101
87	F	T	F	T	F	T	F	F	P1101
88	F	T	F	T	F	T	F	T	P1101
89	F	T	F	T	F	T	T	F	P1101
90	F	T	F	T	F	T	T	T	P1101
91	F	T	F	T	T	F	F	F	P1101
92	F	T	F	T	T	F	F	T	P1101
93	F	T	F	T	T	F	T	F	P1101
94	F	T	F	T	T	F	T	T	P1101
95	F	T	F	T	T	T	F	F	P1101
96	F	T	F	T	T	T	F	T	P1101
97	F	T	F	T	T	T	T	F	P1101
98	F	T	F	T	T	T	T	T	P1101
99	F	T	T	F	F	F	F	F	P1101
100	F	T	T	F	F	F	F	T	P1101
101	F	T	T	F	F	F	T	F	P1101
102	F	T	T	F	F	F	T	T	P1101
103	F	T	T	F	F	T	F	F	P1101
104	F	T	T	F	F	T	F	T	P1101
105	F	T	T	F	F	T	T	F	P1101
106	F	T	T	F	F	T	T	T	P1101
107	F	T	T	F	T	F	F	F	P1101

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

108	F	T	T	F	T	F	F	T	P1101
109	F	T	T	F	T	F	T	F	P1101
110	F	T	T	F	T	F	T	T	P1101
111	F	T	T	F	T	T	F	F	P1101
112	F	T	T	F	T	T	F	T	P1101
113	F	T	T	F	T	T	T	F	P1101
114	F	T	T	F	T	T	T	T	P1101
115	F	T	T	T	F	F	F	F	P0106
116	F	T	T	T	F	F	F	T	P0106
117	F	T	T	T	F	F	T	F	P0106
118	F	T	T	T	F	F	T	T	P0106
119	F	T	T	T	F	T	F	F	P1101
120	F	T	T	T	F	T	F	T	P1101
121	F	T	T	T	F	T	T	F	P1101
122	F	T	T	T	F	T	T	T	P1101
123	F	T	T	T	T	F	F	F	P1101
124	F	T	T	T	T	F	F	T	P1101
125	F	T	T	T	T	F	T	F	P1101
126	F	T	T	T	T	F	T	T	P1101
127	F	T	T	T	T	T	F	F	P1101
128	F	T	T	T	T	T	F	T	P1101
129	F	T	T	T	T	T	T	F	P1101
130	F	T	T	T	T	T	T	T	P1101
131	T	F	F	F	F	F	F	F	No DTC
132	T	F	F	F	F	F	F	T	No DTC
133	T	F	F	F	F	F	T	F	P1101
134	T	F	F	F	F	F	T	T	P0236
135	T	F	F	F	F	T	F	F	P1101
136	T	F	F	F	F	T	F	T	P0121
137	T	F	F	F	F	T	T	F	P1101
138	T	F	F	F	F	T	T	T	P0236
139	T	F	F	F	T	F	F	F	P1101
140	T	F	F	F	T	F	F	T	P1101
141	T	F	F	F	T	F	T	F	P1101
142	T	F	F	F	T	F	T	T	P0236
143	T	F	F	F	T	T	F	F	P1101
144	T	F	F	F	T	T	F	T	P0121
145	T	F	F	F	T	T	T	F	P1101

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

146	T	F	F	F	T	T	T	T	P0236
147	T	F	F	T	F	F	F	F	P1101
148	T	F	F	T	F	F	F	T	P1101
149	T	F	F	T	F	F	T	F	P1101
150	T	F	F	T	F	F	T	T	P1101
151	T	F	F	T	F	T	F	F	P1101
152	T	F	F	T	F	T	F	T	P1101
153	T	F	F	T	F	T	T	F	P1101
154	T	F	F	T	F	T	T	T	P1101
155	T	F	F	T	T	F	F	F	P1101
156	T	F	F	T	T	F	F	T	P1101
157	T	F	F	T	T	F	T	F	P1101
158	T	F	F	T	T	F	T	T	P1101
159	T	F	F	T	T	T	F	F	P1101
160	T	F	F	T	T	T	F	T	P1101
161	T	F	F	T	T	T	T	F	P1101
162	T	F	F	T	T	T	T	T	P1101
163	T	F	T	F	F	F	F	F	P1101
164	T	F	T	F	F	F	F	T	P1101
165	T	F	T	F	F	F	T	F	P1101
166	T	F	T	F	F	F	T	T	P1101
167	T	F	T	F	F	T	F	F	P1101
168	T	F	T	F	F	T	F	T	P1101
169	T	F	T	F	F	T	T	F	P1101
170	T	F	T	F	F	T	T	T	P1101
171	T	F	T	F	T	F	F	F	P1101
172	T	F	T	F	T	F	F	T	P1101
173	T	F	T	F	T	F	T	F	P1101
174	T	F	T	F	T	F	T	T	P1101
175	T	F	T	F	T	T	F	F	P1101
176	T	F	T	F	T	T	F	T	P1101
177	T	F	T	F	T	T	T	F	P1101
178	T	F	T	F	T	T	T	T	P1101
179	T	F	T	T	F	F	F	F	P1101
180	T	F	T	T	F	F	F	T	P1101
181	T	F	T	T	F	F	T	F	P1101
182	T	F	T	T	F	F	T	T	P1101
183	T	F	T	T	F	T	F	F	P1101

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

184	T	F	T	T	F	T	F	T	P1101
185	T	F	T	T	F	T	T	F	P1101
186	T	F	T	T	F	T	T	T	P1101
187	T	F	T	T	T	F	F	F	P0101 or P010B
188	T	F	T	T	T	F	F	T	P0101 or P010B
189	T	F	T	T	T	F	T	F	P0101 or P010B
190	T	F	T	T	T	F	T	T	P0101 or P010B
191	T	F	T	T	T	T	F	F	P1101
192	T	F	T	T	T	T	F	T	P1101
193	T	F	T	T	T	T	T	F	P1101
194	T	F	T	T	T	T	T	T	P1101
195	T	T	F	F	F	F	F	F	P1101
196	T	T	F	F	F	F	F	T	P1101
197	T	T	F	F	F	F	T	F	P1101
198	T	T	F	F	F	F	T	T	P0236
199	T	T	F	F	F	T	F	F	P1101
200	T	T	F	F	F	T	F	T	P0121
201	T	T	F	F	F	T	T	F	P1101
202	T	T	F	F	F	T	T	T	P0236
203	T	T	F	F	T	F	F	F	P1101
204	T	T	F	F	T	F	F	T	P1101
205	T	T	F	F	T	F	T	F	P1101
206	T	T	F	F	T	F	T	T	P0236
207	T	T	F	F	T	T	F	F	P1101
208	T	T	F	F	T	T	F	T	P0121
209	T	T	F	F	T	T	T	F	P1101
210	T	T	F	F	T	T	T	T	P0236
211	T	T	F	T	F	F	F	F	P1101
212	T	T	F	T	F	F	F	T	P1101
213	T	T	F	T	F	F	T	F	P1101
214	T	T	F	T	F	F	T	T	P1101
215	T	T	F	T	F	T	F	F	P1101
216	T	T	F	T	F	T	F	T	P1101
217	T	T	F	T	F	T	T	F	P1101
218	T	T	F	T	F	T	T	T	P1101
219	T	T	F	T	T	F	F	F	P1101
220	T	T	F	T	T	F	F	T	P1101
221	T	T	F	T	T	F	T	F	P1101

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P0101, P0106, P010B, P0121, P0236, P1101: Turbocharger Intake Flow Rationality Diagnostic Failure Matrix

222	T	T	F	T	T	F	T	T	P1101
223	T	T	F	T	T	T	F	F	P1101
224	T	T	F	T	T	T	F	T	P1101
225	T	T	F	T	T	T	T	F	P1101
226	T	T	F	T	T	T	T	T	P1101
227	T	T	T	F	F	F	F	F	P1101
228	T	T	T	F	F	F	F	T	P1101
229	T	T	T	F	F	F	T	F	P1101
230	T	T	T	F	F	F	T	T	P1101
231	T	T	T	F	F	T	F	F	P1101
232	T	T	T	F	F	T	F	T	P1101
233	T	T	T	F	F	T	T	F	P1101
234	T	T	T	F	F	T	T	T	P1101
235	T	T	T	F	T	F	F	F	P1101
236	T	T	T	F	T	F	F	T	P1101
237	T	T	T	F	T	F	T	F	P1101
238	T	T	T	F	T	F	T	T	P1101
239	T	T	T	F	T	T	F	F	P1101
240	T	T	T	F	T	T	F	T	P1101
241	T	T	T	F	T	T	T	F	P1101
242	T	T	T	F	T	T	T	T	P1101
243	T	T	T	T	F	F	F	F	P1101
244	T	T	T	T	F	F	F	T	P1101
245	T	T	T	T	F	F	T	F	P1101
246	T	T	T	T	F	F	T	T	P1101
247	T	T	T	T	F	T	F	F	P1101
248	T	T	T	T	F	T	F	T	P1101
249	T	T	T	T	F	T	T	F	P1101
250	T	T	T	T	F	T	T	T	P1101
251	T	T	T	T	T	F	F	F	P1101
252	T	T	T	T	T	F	F	T	P1101
253	T	T	T	T	T	F	T	F	P1101
254	T	T	T	T	T	F	T	T	P1101
255	T	T	T	T	T	T	F	F	P1101
256	T	T	T	T	T	T	F	T	P1101
257	T	T	T	T	T	T	T	F	P1101
258	T	T	T	T	T	T	T	T	P1101

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM																	
Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM																	
Value Units: Weight Factor (Unitless)																	
X Unit: Engine Speed (RPM)																	
y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,200
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000



## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP2 Residual Weight Factor based on RPM

**Value Units:** Weight Factor (Unitless)

**X Unit:** Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,200
1	1.000	1.000	1.000	1.000	0.857	0.896	0.800	0.999	1.000	0.950	0.950	0.950	0.950	0.950	0.950	0.950	0.950

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP3 Residual Weight Factor based on RPM

**Description:** P0101\_P0106\_P0121\_P012B\_P0236\_P1101 MAP3 Residual Weight Factor based on RPM

**Value Units:** Weight Factor (Unitless)

**X Unit:** Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,200
1	1.000	1.000	1.000	1.000	0.864	0.889	0.800	1.000	1.000	0.880	0.880	0.880	0.880	0.880	0.880	0.880	0.880

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM																	
Description: P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM																	
Value Units: Weight Factor (Unitless) X Unit: Engine Speed (RPM)																	
y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,200
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP Residual Weight Factor based on RPM

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP Residual Weight Factor based on RPM

**Value Units:** Weight Factor (Unitless)

**X Unit:** Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,200
1	1.000	0.700	0.600	1.000	1.000	0.990	0.900	0.947	0.928	0.800	0.800	0.800	0.800	0.800	0.800	0.800	0.800

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max Air Flow

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Max Air Flow

**Value Units:** Engine Air Flow (Grams/Second)

**X Unit:** Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	13.0	13.0	13.0	16.0	20.0	24.0	28.0	31.0	32.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Max MAP

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Max MAP

**Value Units:** Manifold Pressure (kPa)  
**X Unit:** Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	70.0	70.0	70.0	70.0	70.0	70.0	70.0	70.0	70.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-Baro Correlation Offset

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-Baro Correlation Offset

**Value Units:** Pressure Difference (kPa)  
**X Unit:** Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	0.0	1.5	3.5	6.0	9.0	12.0	16.0	20.0	25.0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min Air Flow

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Min Air Flow

**Value Units:** Engine Air Flow (Grams/Second)

**X Unit:** Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	17.0	43.0	92.0	120.0	164.0	189.0	195.0	189.0	192.0



Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Min MAP

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Min MAP

**Value Units:** Manifold Pressure (kPa)  
**X Unit:** Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	110.0	152.0	212.2	213.0	221.0	206.0	192.0	166.0	166.0

Initial Supporting table - P0101, P0106, P0121, P0236, P1101: TIAP-MAP Correlation Offset

**Description:** P0101\_P0106\_P0121\_P0236\_P1101 TIAP-MAP Correlation Offset

**Value Units:** Pressure Difference (kPa)  
**X Unit:** Engine Speed (RPM)

y/x	1,000	1,750	2,500	3,250	4,000	4,750	5,500	6,250	7,000
1	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0234 P0299: Ambient pressure correction as a function of engine speed and ambient pressure

**Description:** Additive offset on boost pressure control deviation fail limit.

**Value Units:** [kPa] Control Deviation - Ambient correction.

**X Unit:** [kPa] KnBSTD\_p\_CntrlDevDiagAmbCorrBP - Ambient Air Pressure

**Y Units:** [rpm] KnBSTD\_n\_CntrlDevDiagAmbCorrBP - Engine Speed

y/x	60.00	70.00	80.00	90.00	100.00	110.00
1,500	130.00	130.00	130.00	130.00	130.00	130.00
2,500	125.00	120.00	90.00	55.00	0.00	0.00
3,000	115.00	105.00	75.00	35.00	0.00	0.00
4,000	65.00	60.00	50.00	25.00	0.00	0.00
5,000	30.00	25.00	20.00	10.00	0.00	0.00
6,000	0.00	0.00	0.00	0.00	0.00	0.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0234 P0299: Boost deviation diagnostic enable delay as a function of engine speed

**Description:** Timer to stabilize enable conditions for over and underboost diagnosis.

**Value Units:** [sec] Pressure control deviation diagnosis enable delay.

**X Unit:** [rpm] KnBSTD\_n\_CntrlDevDiagEngSpdBP - Engine Speed

y/x	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	6,000
1	1.7500	1.5000	1.3750	1.1250	1.0000	0.8750	0.7500	0.6250	0.5000	0.5000

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0234: Overboost pressure deviation limit as a function of engine speed and desired boost pressure

**Description:** Negative boost pressure control deviation fail limit.

**Value Units:** [kPa] Negative boost pressure deviation limit.

**X Unit:** [kPa] KnBSTD\_p\_CntrlDevDiagDsrdBP - Boost pressure

**Y Units:** [rpm] KnBSTD\_n\_CntrlDevDiagEngSpdBP - Engine speed

y/x	5.00	50.00	100.00	120.00	140.00	160.00	180.00	200.00	250.00	300.00
1,000	-100.00	-100.00	-100.00	-100.00	-100.00	-100.00	-100.00	-100.00	-100.00	-100.00
1,500	-100.00	-80.00	-80.00	-80.00	-80.00	-80.00	-80.00	-80.00	-80.00	-80.00
2,000	-100.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00
2,500	-100.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00
3,000	-100.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00
3,500	-100.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00
4,000	-100.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00
4,500	-100.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00
5,000	-100.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00
6,000	-100.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00	-30.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0299: Underboost pressure deviation limit as a function of engine speed and desired boost pressure

**Description:** Positive boost pressure control deviation fail limit.

**Value Units:** [kPa] Positive boost pressure deviation limit.

**X Unit:** [kPa] KnBSTD\_p\_CntrlDevDiagDsrdBP - Boost pressure

**Y Units:** [rpm] KnBSTD\_n\_CntrlDevDiagEngSpdBP - Engine speed

y/x	5.00	50.00	100.00	120.00	140.00	160.00	180.00	200.00	250.00	300.00
1,000	100.00	100.00	100.00	100.00	100.00	100.00	100.00	100.00	100.00	100.00
1,500	100.00	80.00	80.00	80.00	80.00	80.00	80.00	80.00	80.00	130.00
2,000	100.00	80.00	80.00	75.00	40.00	40.00	40.00	50.00	80.00	120.00
2,500	100.00	80.00	80.00	75.00	40.00	40.00	40.00	40.00	60.00	90.00
3,000	100.00	80.00	80.00	75.00	40.00	40.00	40.00	40.00	40.00	80.00
3,500	100.00	50.00	50.00	50.00	40.00	40.00	40.00	40.00	40.00	80.00
4,000	100.00	30.00	30.00	30.00	30.00	30.00	30.00	30.00	40.00	80.00
4,500	100.00	30.00	30.00	30.00	30.00	30.00	30.00	30.00	40.00	80.00
5,000	100.00	30.00	30.00	30.00	30.00	30.00	30.00	30.00	40.00	80.00
6,000	100.00	30.00	30.00	30.00	30.00	30.00	30.00	30.00	40.00	80.00

## 20 OBDG03A ECM Supporting Tables

**Initial Supporting table - P050D\_P1400\_CatalystLightOffExtendedEngineRunTimeExit**

**Description:** Exit Catalyst Warm-up mode if Engine Run Time is greater than this value. This table is based on percent ethanol (x-axis) and catmon's NormRatio\_EWMA value (y-axis). The NormRatio\_EWMA value determines the state of the catalyst. Typically, NormRatio\_EWMA values below 0.35 (0 is bad and 1 is good) represent catalysts that have degraded. The emission performance of these degraded catalysts can be improved by extending catalyst light off of GetE85R\_Pct\_FFS\_CompAtEngFloat.

y/x	0	25	50	75	100
0.000	60	60	60	60	60
0.125	60	60	60	60	60
0.250	60	60	60	60	60
0.375	60	60	60	60	60
0.500	33	33	33	33	33
0.625	33	33	33	33	33
0.750	33	33	33	33	33
0.875	33	33	33	33	33
1.000	33	33	33	33	33

Initial Supporting table - P1400\_ColdStartDiagnosticDelayBasedOnEngineRunTime

**Description:** Quality weight-based on engine run time. This allows adjustment of the weighting factors at various engine run times in order to prevent the updating of the cumulative quality timer or to change the value of the average qualified residual energy calculation to prevent false Fails of the diagnostic under circumstances inappropriate to update the calculation of the average qualified residual value.

y/x	0	3	4	4	5	10	15	20	30
1	0	0	1	1	1	1	1	1	1



Initial Supporting table - P1400\_ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis

**Description:** This is the x-axis for the KtCSED\_K\_TimeWght calibration table. Refer to the description for KtCSED\_K\_TimeWght for details.

y/x	1	2	3	4	5	6	7	8	9
1	0	3	4	4	5	10	15	20	30

Initial Supporting table - P1400\_EngineSpeedResidual\_Table

**Description:** This 1x17 table of engine exhaust flow values is used to calculate both the desired and the actual engine exhaust flow based on desired and actual engine speed. The desired engine exhaust flow is gathered from the desired engine speed (VeSPDR\_n\_EngDsrd). The value used for the actual engine exhaust flow is based on the actual engine RPM value.

y/x	500	975	990	1,000	1,020	1,050	1,100	1,150	1,175	1,200	1,250	1,280	1,290	1,300	1,400	1,900	2,500
1	7	7	7	10	11	11	11	11	11	11	11	11	14	15	15	15	15

Initial Supporting table - P1400\_SparkResidual\_Table

**Description:** Predicted engine-out energy potential based on either the desired cold start spark advance value or the actual spark advance value. ExhEngyPerUnitMass calibration is used to calculate both desired exhaust energy and actual energy. The desired and actual exhaust energy per unit mass values are used in part to calculate the desired exhaust energy per unit time and actual exhaust energy per unit time. Both desired and actual go into the residual exhaust energy per unit time calculation.

y/x	-18	-8	-6	-4	0	4	6	10	20
1	1.25	1.25	1.25	1.19	0.88	0.69	0.63	0.63	0.63

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0068\_Delta MAF Threshold f(TPS)

**Description:** Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	9.38	12.13	16.89	19.20	29.84	49.55	255.00	255.00	255.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0068\_Delta MAP Threshold f(TPS)

**Description:** Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	37.45	44.08	46.55	45.54	46.96	41.86	255.00	255.00	255.00

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0068\_Maximum MAF f(RPM)

**Description:** Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
1.00	17.90	39.19	63.43	80.91	112.92	138.31	168.70	174.20	176.70

Initial Supporting table - P0068\_Maximum MAF f(Volts)

**Description:** Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.

y/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00
1.00	6.50	25.00	65.00	140.00	260.00	300.00	300.70	300.70	300.70

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est

**Description:** P0101\_P0106\_P010B\_P0121\_P012B\_P0236\_P1101 MAF1 Residual Weight Factor based on MAF Est

**Value Units:** Weight Factor (Unitless)

**X Unit:** Estimated Engine Air Flow (Grams/Second)

y/x	0	15	30	45	60	75	90	105	120	135	150	165	180	195	210	230	250
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000



## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM

**Description:** P0101\_P0106\_P010B\_P0121\_P012B\_P0236\_P1101 MAF1 Residual Weight Factor based on RPM

**Value Units:** Weight Factor (Unitless)

**X Unit:** Engine Speed (RPM)

y/x	0	400	800	1,200	1,600	2,000	2,400	2,800	3,200	3,600	4,000	4,400	4,800	5,200	5,600	6,000	6,200
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.750	0.750	0.750	0.750	0.750	0.750	0.750	0.750

Initial Supporting table - P0116\_Fail if power up ECT exceeds IAT by these values

**Description:** KtECTD\_T\_HSC\_FastFailTempDiff

**Value Units:** Fast Failure temp difference (°C)

**X Unit:** IAT Temperature at Power up (°C)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	80	80	80	60	60	40	40	30	30	30	30	30	30	30	30	30	30

Initial Supporting table - P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate							
Description: KtECTR_E_CTR_WrmUpEnrgyLimTest1							
Value Units: Cooling system energy failure threshold (kJ) X Unit: Minimum ECT for the key cycle (°C)							
y/x	-20	-5	10	30	45	60	75
1	8,985	7,680	6,375	4,635	3,330	2,025	2,025

Initial Supporting table - P0128\_Maximum Accumulated Energy for Start-up ECT conditions - Primary

**Description:** KtECTR\_E\_CTR\_WrmUpEnrgyLimTest0

**Value Units:** Cooling system energy failure threshold (kJ)  
**X Unit:** Minimum ECT for the key cycle (°C)

y/x	-20	-5	10	30	45	60	75
1	9,405	9,405	8,040	6,220	4,855	3,490	2,125

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

#### P0606\_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000

#### P0606\_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	500.000	500.000	1,000.000	8,191.875	8,191.875	8,191.875	

## Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)

**Description:** Fail threshold for PSW per operating loop.

## P0606\_PSW Sequence Fail f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	5	3	5	3	5	3	5

## P0606\_PSW Sequence Fail f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	5	5	5	3	5	5	

## Initial Supporting table - P0606\_PSW Sequence Sample f(Loop Time)

**Description:** Sample threshold for PSW per operating loop.

## P0606\_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	4	4	4	4	4	4	4

## P0606\_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	4	4	4	4	4	4	

Initial Supporting table - P1682\_PT Relay Pull-in Run/Crank Voltage f(IAT)

**Description:** The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

**Value Units:** Run/Crank Voltages required to pull in PT Relay (V)

**X Unit:** Induction Air Temperature (deg C)

y/x	23.000	85.000	95.000	105.000	125.000
1.000	7.000	8.699	9.000	9.199	10.000



Initial Supporting table - P16F3\_Delta MAP Threshold f(Desired Engine Torque)

**Description:** Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	37.45	37.45	37.45	37.45	37.45	37.45

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P16F3\_Speed Control External Load f(Oil Temp, RPM)

**Description:** Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
350.00	119.10	111.32	129.68	148.10	122.93	60.93
450.00	119.10	111.32	129.68	148.10	122.93	60.93
550.00	119.10	111.32	129.68	148.10	122.93	60.93
650.00	119.10	111.32	129.68	148.10	122.93	60.93
750.00	124.75	116.77	134.90	153.10	126.69	60.89
850.00	135.36	127.11	145.14	163.40	136.31	63.06
900.00	140.12	131.53	148.51	165.97	140.13	64.35
1,000.00	153.47	144.72	162.51	180.69	152.87	63.29
1,100.00	163.63	154.76	172.68	190.87	161.49	71.39
1,200.00	171.40	161.25	178.45	196.51	166.54	81.09
1,450.00	155.27	145.52	160.09	175.16	144.79	82.71
1,700.00	80.96	71.66	65.03	58.84	41.18	34.59
1,950.00	58.07	49.06	42.79	36.92	20.47	14.60
2,200.00	37.31	28.52	22.53	16.89	1.37	-3.94
3,200.00	-65.23	-65.23	-65.23	-65.23	-65.23	-65.23
4,200.00	-71.76	-71.76	-71.76	-71.76	-71.76	-71.76
6,400.00	-78.28	-78.28	-78.28	-78.28	-78.28	-78.28

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - 1st\_FireAftrMisfr\_Acel

**Description:** Used for P0300 - P0308, Multiplier for establishing the expected acceleration of the cylinder after the misfire

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	600	800	1,000	1,200	1,600	2,000	2,400	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
2	1.00	1.10	1.20	1.00	0.80	0.66	0.88	0.90	0.85	0.75	0.73	0.60	0.75	0.63	0.64	0.67	0.70
8	1.00	1.10	1.20	1.10	0.90	0.60	0.84	0.96	0.85	0.70	0.57	0.59	0.75	0.75	0.64	0.67	0.70
12	1.10	1.20	1.20	0.70	0.70	0.62	0.72	0.83	0.70	0.70	0.58	0.65	0.67	0.82	0.79	0.67	0.58
16	1.00	1.00	0.60	0.60	0.66	0.55	0.55	0.77	0.63	0.68	0.62	0.62	0.56	0.70	0.75	0.85	0.67
20	0.50	0.50	0.27	0.31	0.56	0.65	0.54	0.73	0.58	0.58	0.56	0.55	0.53	0.73	0.70	0.85	0.54
24	0.20	0.20	0.06	0.15	0.40	0.60	0.60	0.72	0.56	0.55	0.54	0.50	0.50	0.62	0.63	0.75	0.54
30	0.00	0.00	0.00	0.04	0.30	0.50	0.60	0.67	0.56	0.52	0.52	0.52	0.55	0.53	0.55	0.70	0.50
40	0.00	0.00	0.00	0.00	0.20	0.40	0.45	0.74	0.70	0.52	0.60	0.39	0.44	0.48	0.53	0.60	0.50
60	0.00	0.00	0.00	0.00	0.15	0.25	0.30	0.52	0.50	0.37	0.40	0.26	0.30	0.33	0.40	0.45	0.50

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - 1st\_FireAftrMisfr\_Jerk

**Description:** Used for P0300 - P0308, Multiplier for establishing the expected Jerk of the cylinder after the misfire

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	600	800	1,000	1,200	1,600	2,000	2,400	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
2	-0.44	-0.25	-0.39	-0.50	-0.70	-0.55	-0.50	-0.50	-0.60	-0.60	-0.63	-0.60	-0.63	-0.64	-0.75	-0.67	-0.58
8	-0.45	-0.25	-0.35	-0.45	-0.65	-0.70	-0.70	-0.65	-0.75	-0.83	-0.80	-0.70	-0.70	-0.75	-0.92	-0.83	-0.75
12	-0.45	-0.45	-0.54	-0.65	-0.82	-0.90	-0.95	-1.00	-1.27	-1.10	-0.95	-0.95	-0.94	-0.82	-0.76	-0.86	-0.85
16	-0.60	-0.50	-0.62	-0.70	-0.87	-0.95	-0.95	-1.11	-1.27	-1.20	-1.21	-1.19	-1.14	-0.95	-0.91	-0.78	-0.70
20	-0.60	-0.65	-0.75	-0.80	-0.90	-0.95	-0.95	-1.05	-1.29	-1.29	-1.25	-1.26	-1.20	-1.12	-0.95	-0.73	-0.64
24	-0.60	-0.60	-0.90	-0.90	-0.90	-0.95	-0.95	-1.05	-1.32	-1.29	-1.30	-1.25	-1.23	-1.13	-1.13	-0.69	-0.71
30	-0.70	-0.70	-0.90	-0.90	-0.90	-0.95	-0.90	-1.05	-1.34	-1.35	-1.29	-1.28	-1.23	-1.10	-1.13	-0.75	-0.73
40	-1.00	-0.70	-0.90	-0.90	-0.90	-0.95	-0.95	-1.07	-1.32	-1.40	-1.35	-1.30	-1.25	-1.12	-1.17	-0.88	-0.74
60	-1.00	-0.85	-0.90	-0.90	-0.90	-1.00	-1.04	-1.05	-1.30	-1.40	-1.34	-1.31	-1.28	-1.10	-1.00	-0.92	-0.79

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - 1stFireAfterMisJerkAFM

**Description:** Used for P0300 - P0308, Multiplier for establishing the expected jerk of the cylinder after the misfire if Active Fuel Management cylinder deact mode is active

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
2	-1	-1	-1	-1	-1	-1	-1	-1	-1
8	-1	-1	-1	-1	-1	-1	-1	-1	-1
12	-1	-1	-1	-1	-1	-1	-1	-1	-1
16	-1	-1	-1	-1	-1	-1	-1	-1	-1
20	-1	-1	-1	-1	-1	-1	-1	-1	-1
24	-1	-1	-1	-1	-1	-1	-1	-1	-1
30	-1	-1	-1	-1	-1	-1	-1	-1	-1
40	-1	-1	-1	-1	-1	-1	-1	-1	-1
60	-1	-1	-1	-1	-1	-1	-1	-1	-1

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - 1stFireAfrMisAcelAFM

**Description:** Used for P0300 - P0308, Multiplier for establishing the expected acceleration of the cylinder after the misfire if Active Fuel Management cylinder deact mode is active

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
2	0	0	0	0	0	0	0	0	0
8	0	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0
24	0	0	0	0	0	0	0	0	0
30	0	0	0	0	0	0	0	0	0
40	0	0	0	0	0	0	0	0	0
60	0	0	0	0	0	0	0	0	0

Initial Supporting table - Abnormal Cyl Mode

**Description:** Used for P0300-P0308. Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Cylinder Mode Equation)

**Value Units:** Number of consecutive number of decelerating cylinders (integer)

**X Unit:** thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	3	3	3	3	3	3	3	3	3

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - Abnormal Rev Mode

**Description:** Used for P0300-P0308. Abnormal Rev Mode Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Rev Mode Equation)

**Value Units:** Number of consecutive number of decelerating cylinders (integer)

**X Unit:** thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00



## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - Abnormal SCD Mode

**Description:** Used for P0300-P0308. Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (SCD Mode Equation)

**Value Units:** Number of consecutive number of decelerating cylinders (integer)

**X Unit:** thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	2	2	2	2	2	2	2	2	2

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - Bank\_SCD\_Decel

**Description:** Used for P0300 - P0308, Multplier to SCD decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60
8	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60
12	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60
16	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60
20	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60
24	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60
30	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60
40	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60
60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60	0.60

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - Bank\_SCD\_Jerk

**Description:** Used for P0300 - P0308, Multplier to Medres SCD jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** mulitplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - BankCylModeDecel

**Description:** Used for P0300 - P0308, Multplier to Lores Decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	600	800	1,000	1,200	1,600	2,000	2,400	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500
2	5.00	7.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
8	4.28	7.72	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
12	3.30	6.92	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
16	2.72	5.40	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
20	2.30	4.45	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
24	2.00	3.75	11.50	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
30	1.63	3.10	5.00	14.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
40	1.50	2.20	3.33	6.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
60	1.50	1.50	2.05	3.80	6.00	12.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - BankCylModeJerk

**Description:** Used for P0300 - P0308, Multplier to Lores Jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	600	800	1,000	1,200	1,600	2,000	2,400	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500
2	3.33	8.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
8	2.03	3.30	13.75	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
12	1.50	2.08	8.68	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
16	1.50	1.50	5.40	10.50	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
20	1.50	1.50	4.65	7.10	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
24	1.50	1.50	3.60	6.10	11.50	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
30	1.50	1.50	2.40	4.05	10.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
40	1.50	1.50	1.50	3.10	7.20	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00
60	1.50	1.50	1.50	1.50	2.60	7.00	13.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00	15.00

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - Catalyst\_Damage\_Misfire\_Percentage

**Description:** Catalyst Damaging Misfire Percentage" Table whenever secondary conditions are met.

**Value Units:** percent misfire over 200 revolutions (%)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000
0	22.4	22.4	22.4	22.4	20.0	11.1	9.1	7.1
10	22.4	22.4	22.4	22.4	16.7	11.1	9.1	7.1
20	22.4	22.4	20.8	16.7	15.0	7.1	4.6	4.6
30	22.4	17.7	16.7	12.3	8.6	4.6	4.6	4.6
40	22.4	14.8	14.8	8.4	4.6	4.6	4.6	4.6
50	22.4	14.3	8.4	4.6	4.6	4.6	4.6	4.6
60	22.4	14.3	7.1	4.6	4.6	4.6	4.6	4.6
70	22.4	14.3	7.1	4.6	4.6	4.6	4.6	4.6
80	22.4	14.3	7.1	4.6	4.6	4.6	4.6	4.6
90	22.4	14.3	7.1	4.6	4.6	4.6	4.6	4.6
100	22.4	14.3	7.1	4.6	4.6	4.6	4.6	4.6

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - ClyAfterAFM\_Decel

**Description:** Used for P0300 - P0308, Multiplier to Lores decel to account for different pattern of misfire after a deactivated cylinder. Similar to the second cylinder of consecutive cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - ClyBeforeAFM\_Jerk

**Description:** Used for P0300 - P0308, Multplier to Lores decel to account for different pattern of misfire before a deactivated cylider, but after an active cylinder that follows an deactive cylinder on engine that supports cylinder deactivation in non even fire patterns.. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00



## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - CombustModelIdleTbl

**Description:** Used for P0300 - P0308, Only used on Diesel engines. Combustion modes that will force use of Idle table. A value of CeCMBR\_i\_CombModesMax means not selected.

**Value Units:** Enumerated value of different combustion modes (enumeration)

**X Unit:** Current Combustion Mode (enumeration)

#### CombustModelIdleTbl - Part 1

y/x	0	1	2	3	4	5
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max

#### CombustModelIdleTbl - Part 2

y/x	6	7	8	9	10	11
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max

#### CombustModelIdleTbl - Part 3

y/x	12	13	14	15	16	
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - ConsecCylModDecel

**Description:** Used for P0300 - P0308, Multplier to Lores decel to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	600	800	1,000	1,200	1,600	2,000	2,400	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500
2	1.50	1.67	1.60	1.60	1.60	1.50	1.60	1.45	1.70	1.80	1.85	2.05	1.86	1.76	1.69	1.60	1.60
8	1.40	1.50	1.50	1.45	1.45	1.29	1.20	1.15	1.15	1.15	1.25	1.46	1.42	1.13	1.11	1.05	1.08
12	1.60	1.50	1.50	1.50	1.40	1.15	1.15	1.15	1.00	1.00	1.00	1.44	1.18	1.13	1.11	1.08	1.00
16	2.40	1.50	1.50	1.60	1.25	1.15	1.15	1.15	1.00	1.00	1.00	1.42	1.24	1.43	1.19	1.21	1.33
20	2.30	2.80	1.60	1.60	1.20	1.10	1.10	1.10	1.00	1.00	0.90	1.23	1.24	1.40	1.35	1.38	1.67
24	2.00	3.50	2.00	1.60	1.20	1.10	1.10	1.10	1.00	0.90	0.90	1.05	1.23	1.35	1.41	1.36	2.00
30	1.67	2.90	2.77	2.10	1.20	1.00	1.00	1.10	0.88	0.80	0.85	0.95	1.11	1.20	1.27	1.21	1.90
40	1.50	2.20	3.20	2.14	1.10	0.80	1.00	1.00	0.87	0.87	0.85	0.87	1.02	1.08	1.17	1.19	1.67
60	1.50	1.50	2.10	2.19	1.10	0.75	1.00	1.00	0.85	0.85	0.85	0.85	0.92	0.97	1.04	1.12	1.50

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - ConsecCylModeJerk

**Description:** Used for P0300 - P0308, Multplier to Lores Jerk to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	600	800	1,000	1,200	1,600	2,000	2,400	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500
2	1	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
8	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
24	0	0	0	0	0	0	0	0	0	0	0	-1	0	0	0	0	0
30	0	0	0	0	0	0	0	0	0	0	-1	-1	0	0	0	0	0
40	0	0	0	0	0	0	0	-1	0	0	0	0	0	0	0	0	0
60	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - ConsecSCD\_Decel

**Description:** Used for P0300 - P0308, Multplier to medres decel to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - ConsecSCD\_Jerk

**Description:** Used for P0300 - P0308, Multplier to medres Jerk to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
8	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
12	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
16	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
20	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
24	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
30	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
60	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - CylAfterAFM\_Jerk

**Description:** Used for P0300 - P0308, Multiplier to Lores Jerk to account for different pattern of misfire after a deactivated cylinder. Similar to the second cylinder of consecutive cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
2	1	1	1	1	1	1	1	1	1
8	1	1	1	1	1	1	1	1	1
12	1	1	1	1	1	1	1	1	1
16	1	1	1	1	1	1	1	1	1
20	1	1	1	1	1	1	1	1	1
24	1	1	1	1	1	1	1	1	1
30	1	1	1	1	1	1	1	1	1
40	1	1	1	1	1	1	1	1	1
60	1	1	1	1	1	1	1	1	1

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - CylBeforeAFM\_Decel

**Description:** Used for P0300 - P0308, Multiplier to Lores decel to account for different pattern of misfire before a deactivated cylinder, but after an active cylinder that follows an deactive cylinder on engine that supports cylinder deactivation in non even fire patterns.. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

# 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - CylModeDecel

**Description:** Used for P0300-P0308. Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

**Value Units:** Delta time per cylinder (usec)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

### CylModeDecel - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	6,000	5,000	3,000	1,800	1,200	750	550	400	300	225	135	100	85
6	6,500	5,000	3,000	1,800	1,200	775	550	400	310	250	145	100	85
8	7,000	5,000	3,000	1,800	1,200	825	565	400	335	275	160	110	85
10	8,000	5,335	3,000	1,800	1,200	905	625	450	370	310	175	125	90
12	9,000	5,870	3,130	1,950	1,280	988	683	538	410	345	195	145	95
14	10,000	6,620	3,510	2,150	1,415	1,125	825	673	480	400	225	165	105
16	11,000	7,370	4,085	2,535	1,635	1,320	985	805	590	455	260	185	115
18	12,000	8,120	4,550	2,915	1,850	1,538	1,145	940	700	510	290	205	125
20	13,000	8,880	5,040	3,300	2,130	1,758	1,338	1,075	805	585	335	225	140
22	14,000	9,630	5,530	3,685	2,405	1,975	1,515	1,210	910	660	380	245	155
24	15,000	10,380	6,010	4,065	2,680	2,193	1,693	1,345	1,020	735	430	265	170
26	16,000	11,130	6,500	4,450	2,958	2,413	1,870	1,480	1,130	810	480	290	185
30	18,000	12,640	7,480	5,215	3,513	2,850	2,228	1,750	1,350	960	575	340	215
40	20,000	16,400	9,910	7,125	4,895	3,940	3,118	2,420	1,890	1,335	815	455	290
60	20,000	20,000	14,790	10,950	7,665	6,123	4,898	3,765	2,970	2,090	1,295	690	435
78	20,000	20,000	19,060	14,300	10,085	8,033	6,455	4,945	3,910	2,750	1,720	895	565
97	20,000	20,000	20,000	18,160	12,855	10,215	8,235	6,290	4,990	3,500	2,200	1,130	710

### CylModeDecel - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
3	60	48	35	25	20	16	11	9	9	8	8	7	6
6	60	45	35	27	23	17	12	9	8	8	7	7	6
8	65	45	40	29	25	18	12	9	8	7	7	6	6
10	70	50	45	33	28	20	13	10	8	7	7	6	6
12	75	55	50	39	34	24	14	11	8	7	7	6	6
14	83	63	55	44	39	28	16	13	9	8	7	6	6
16	90	70	60	49	44	33	19	15	11	8	7	6	6
18	100	78	67	55	50	37	23	18	13	9	8	6	6
20	110	85	74	60	55	42	26	20	14	10	8	6	6
22	122	95	83	67	61	46	29	22	16	11	9	6	6
24	134	105	90	73	66	51	32	24	18	13	10	6	6



## 20 OBDG03A ECM Supporting Tables

**Initial Supporting table - CylModeDecel**

26	145	115	100	80	72	55	36	27	20	14	11	7	6
30	170	135	115	93	82	64	42	31	23	17	14	8	7
40	229	183	160	130	110	86	59	43	32	23	19	12	9
60	348	280	248	203	164	130	90	65	50	36	29	20	13
78	452	365	324	267	211	170	120	85	65	47	38	27	16
97	570	460	412	340	266	215	150	108	83	60	48	35	20

# 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - CylModeJerk

**Description:** Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

**Value Units:** Change in Delta time per cylinder from last cylinder (usec)

**Y Units:** percent load of max indicated torque (%)

### CylModeJerk - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	8,000	5,220	3,125	2,000	1,400	900	700	500	400	250	175	125	100
6	10,480	7,150	3,850	2,400	1,840	1,165	831	550	475	250	190	130	100
8	13,000	9,490	4,660	3,420	2,175	1,435	1,087	805	535	305	220	145	100
10	17,000	11,870	5,530	4,315	2,675	1,785	1,504	1,060	600	375	300	200	140
12	20,000	14,250	7,615	5,260	3,350	2,320	1,921	1,310	795	440	385	260	175
14	20,000	16,630	9,790	6,200	4,250	2,860	2,338	1,570	1,035	570	465	315	215
16	20,000	19,010	11,920	7,560	4,980	3,390	2,750	1,970	1,275	705	550	370	250
18	20,000	20,000	13,530	8,590	5,755	3,930	3,160	2,400	1,510	840	630	425	285
20	20,000	20,000	15,145	9,630	6,450	4,470	3,560	2,710	1,750	970	715	480	320
22	20,000	20,000	16,760	10,660	7,140	5,000	3,970	3,020	1,990	1,110	800	540	350
24	20,000	20,000	18,370	11,700	7,830	5,540	4,375	3,330	2,230	1,245	880	595	390
26	20,000	20,000	20,000	12,730	8,520	6,080	4,780	3,640	2,470	1,385	965	650	425
30	20,000	20,000	20,000	14,800	9,900	7,150	5,590	4,260	2,945	1,665	1,130	765	500
40	20,000	20,000	20,000	19,975	13,360	9,840	7,625	5,810	4,140	2,355	1,540	1,045	675
60	20,000	20,000	20,000	20,000	20,000	15,200	11,680	8,910	6,530	3,740	2,370	1,605	1,030
78	20,000	20,000	20,000	20,000	20,000	19,900	15,240	11,620	8,620	4,955	3,090	2,100	1,345
97	20,000	20,000	20,000	20,000	20,000	20,000	19,300	14,720	11,020	6,340	3,920	2,660	1,700

### CylModeJerk - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
3	75	60	45	35	30	25	16	10	8	8	7	7	6
6	77	60	45	40	30	20	14	10	8	8	7	7	6
8	85	60	50	45	34	22	16	12	10	8	8	6	6
10	97	75	60	55	43	26	18	14	12	10	9	6	6
12	122	94	70	64	53	29	20	17	13	11	10	7	7
14	148	112	79	74	61	32	22	19	15	13	11	8	8
16	174	130	89	84	71	38	24	20	17	14	13	9	9
18	200	148	104	96	80	45	25	21	18	16	14	10	10
20	225	166	119	108	90	52	29	23	20	17	15	11	11
22	251	184	135	120	100	59	33	25	21	18	16	13	12
24	277	202	150	132	110	66	39	27	23	20	18	14	13

## 20 OBDG03A ECM Supporting Tables

**Initial Supporting table - CylModeJerk**

26	303	220	165	143	120	73	45	31	25	21	19	15	14
30	354	256	196	172	139	87	60	38	29	24	22	17	15
40	483	347	273	231	188	122	83	56	42	31	28	23	20
60	740	530	425	350	285	190	130	88	63	46	40	34	30
78	965	685	560	450	370	255	170	115	81	58	50	44	40
97	1,225	865	715	570	470	325	218	150	102	73	62	55	50

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - DeacCylInversionDecel

**Description:** Used for P0300 - P0308, Negative Torque can cause crank readings to invert (active cylinders appear weak & deactivated cylinders appear "strong" If deactivated cylinders don't decelerate at least this amount then the crank signal is inverting. Function of speed and load.

**Value Units:** Delta time per cylinder (usec)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
2	0	0	0	0	0	0	0	0	0
8	0	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0
24	0	0	0	0	0	0	0	0	0
30	0	0	0	0	0	0	0	0	0
40	0	0	0	0	0	0	0	0	0
60	0	0	0	0	0	0	0	0	0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - DeacCylInversionJerk

**Description:** Used for P0300 - P0308, Negative Torque can cause crank readings to invert (active cylinders appear weak & deactivated cylinders appear "strong" If deactivated cylinders don't jerk at least this amount then the crank signal is inverting. Function of speed and load.

**Value Units:** Change in Delta time per cylinder from last cylinder (usec)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
2	0	0	0	0	0	0	0	0	0
8	0	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0
24	0	0	0	0	0	0	0	0	0
30	0	0	0	0	0	0	0	0	0
40	0	0	0	0	0	0	0	0	0
60	0	0	0	0	0	0	0	0	0

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - EngineOverSpeedLimit

**Description:** Engine OverSpeed Limit versus gear**Value Units:** RPM**X Unit:** Enumeration of transmission gear state (enumeration)**EngineOverSpeedLimit - Part 1**

y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6	CeTGRR_e_TransGr9
1	6,900	6,900	6,900	6,900	6,900	6,900	6,900

**EngineOverSpeedLimit - Part 2**

y/x	CeTGRR_e_TransGr10	CeTGRR_e_TransGrN eut	CeTGRR_e_TransGrR vrs	CeTGRR_e_TransGrP ark	CeTGRR_e_TransGr7	CeTGRR_e_TransGr8	
1	6,900	4,000	4,000	4,000	6,900	6,900	

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - InfrequentRegen

**Description:** Used for P0300-P0308. Only used on Diesel engines. Initiates a misfire delay when the current combustion mode matches a selection in the table. A value of CeCMBR\_i\_CombModesMax means not selected.

**Value Units:** Enumerated value of different combustion modes (enumeration)

**X Unit:** Current Combustion Mode (enumeration)

#### InfrequentRegen - Part 1

y/x	0	1	2	3	4	5
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max

#### InfrequentRegen - Part 2

y/x	6	7	8	9	10	11
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max

#### InfrequentRegen - Part 3

y/x	12	13	14	15	16	
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - Number of Normals

**Description:** Used for P0300-P0308. Number of Normals for the Driveline Ring Filter

After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

**Value Units:** Number of Engine cycles after isolated misfire (Engine cycles)

**X Unit:** thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	3	3	3	3	3	3	3	3	3



Initial Supporting table - P00C6 - High Pressure Pump Control Mode timeout

**Description:** High Pressure Pump Control Mode timeout

**Value Units:** Time (Seconds)  
**X Unit:** Coolant Temperature (Deg C)

y/x	-40	-32	-24	-16	-8	0	8	16	20	24	32	40	48	64	80	96	112
1	12.8	12.8	11.5	10.0	8.0	5.8	4.9	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	3.0	3.0

## 20 OBDG03A ECM Supporting Tables

Supporting table - P00C6 - maximum acceptable counts of fuel rail pressure below KtFHPD\_p\_HPS\_PressFallLoThrsh after High Pressure Start

**Description:** The maximum acceptable counts of fuel rail pressure below KtFHPD\_p\_HPS\_PressFallLoThrsh after High Pressure Start (HPS) is executed but before engine is in run mode.

**Value Units:** maximum acceptable counts of fuel rail pressure below KtFHPD\_p\_HPS\_PressFallLoThrsh after High Pressure Start (Count)

**X Unit:** Ethanol Precent (%)

**Y Units:** Coolant Temperature (Deg C)

y/x	-40	-32	-24	-16	-8	0	8	16	20	24	32	40	48	64	80	96	112
0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
13	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
25	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
38	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
50	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
63	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
75	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
88	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
100	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P00C6 - Minimum acceptable value of fuel rail pressure after High Pressure Start

**Description:** The minimum acceptable value of fuel rail pressure after High Pressure Start (HPS) is executed. This ensures the pressure does not fall off drastically after High Pressure Start (HPS) is executed, but before engine is in run mode.

**Value Units:** Minimum acceptable value of fuel rail pressure after High Pressure Start (Mpa)

**X Unit:** Ethanol Precent (%)

**Y Units:** Coolant Temperature (Deg C)

y/x	-40	-32	-24	-16	-8	0	8	16	20	24	32	40	48	64	80	96	112
0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
13	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
25	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
38	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
50	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
63	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
75	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
88	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5
100	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5	0.5

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P00C6 - Minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery

**Description:** This calibration is the minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery

**Value Units:** Minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery

**X Unit:** Ethanol Precent (%)

**Y Units:** Coolant Temperature (Deg C)

y/x	-40	-32	-24	-16	-8	0	8	16	20	24	32	40	48	64	80	96	112
0	5.0	13.3	12.0	10.0	8.0	6.0	4.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
13	5.0	13.3	12.0	10.0	8.0	6.0	4.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
25	5.0	13.3	12.0	10.0	8.0	6.0	4.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
38	5.0	13.3	12.0	10.0	8.0	6.0	4.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
50	5.0	13.3	12.0	10.0	8.0	6.0	4.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
63	5.0	13.3	12.0	10.0	8.0	6.0	4.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
75	5.0	13.3	12.0	10.0	8.0	6.0	4.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
88	5.0	13.3	12.0	10.0	8.0	6.0	4.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
100	5.0	13.3	12.0	10.0	8.0	6.0	4.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0420\_BestFailingOSCTableB1

**Description:** This table is a 9x17 table of baseline Best Failing (e.g. threshold converter) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the BestFailing OSC value is found within this table for the measured temp and airflow and is used along with the OSC\_TimeRaw (and the WorstPassing value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the identified BPU converter that is used for MIL illumination across the specific temp and airflow range for a given program.

y/x	2.00	2.40	2.80	3.20	3.60	4.00	4.40	4.80	5.20	5.60	6.00	6.60	7.20	7.80	8.40	9.00	11.00
550.00	1.12	1.06	1.00	0.93	0.86	0.80	0.69	0.60	0.55	0.52	0.50	0.48	0.47	0.44	0.43	0.42	0.40
600.00	1.14	1.08	1.01	0.94	0.88	0.82	0.70	0.61	0.56	0.53	0.51	0.49	0.47	0.45	0.43	0.43	0.40
650.00	1.17	1.09	1.02	0.96	0.89	0.83	0.71	0.63	0.57	0.54	0.52	0.50	0.48	0.45	0.44	0.43	0.41
700.00	1.18	1.11	1.04	0.97	0.91	0.84	0.73	0.64	0.58	0.55	0.53	0.51	0.49	0.46	0.44	0.43	0.41
750.00	1.21	1.13	1.05	0.99	0.92	0.86	0.74	0.65	0.59	0.56	0.54	0.52	0.50	0.46	0.45	0.44	0.41
800.00	1.22	1.14	1.07	1.00	0.93	0.87	0.75	0.66	0.61	0.57	0.54	0.53	0.50	0.47	0.45	0.44	0.41
850.00	1.25	1.16	1.08	1.01	0.95	0.88	0.77	0.67	0.62	0.58	0.55	0.54	0.51	0.47	0.46	0.44	0.42
900.00	1.26	1.18	1.10	1.03	0.96	0.90	0.78	0.69	0.63	0.59	0.56	0.54	0.52	0.48	0.46	0.45	0.42
950.00	1.29	1.19	1.11	1.04	0.98	0.91	0.79	0.70	0.64	0.60	0.57	0.55	0.53	0.48	0.46	0.45	0.42

## 20 OBDG03A ECM Supporting Tables

**Initial Supporting table - P0420\_WorstPassingOSCTableB1**

**Description:** This table is a 9x17 table of WorstPassing (e.g. 120k) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the WorstPassing OSC value is found within this table for the measured temp and airflow and is used along with the OSC\_TimeRaw (and the BestFailing OSC value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the WPA part across the temp and airflow range.

y/x	2.00	2.40	2.80	3.20	3.60	4.00	4.40	4.80	5.20	5.60	6.00	6.60	7.20	7.80	8.40	9.00	11.00
550.00	1.98	1.89	1.80	1.61	1.30	1.18	1.08	0.98	0.90	0.85	0.80	0.72	0.66	0.61	0.58	0.56	0.52
600.00	2.01	1.92	1.83	1.63	1.32	1.20	1.09	0.99	0.91	0.85	0.80	0.73	0.67	0.62	0.59	0.57	0.52
650.00	2.04	1.95	1.86	1.66	1.35	1.22	1.11	1.00	0.92	0.86	0.81	0.73	0.67	0.62	0.59	0.57	0.53
700.00	2.07	1.98	1.88	1.68	1.37	1.25	1.12	1.01	0.93	0.87	0.81	0.74	0.68	0.63	0.59	0.57	0.53
750.00	2.10	2.01	1.91	1.71	1.40	1.26	1.14	1.03	0.94	0.87	0.82	0.74	0.68	0.63	0.60	0.57	0.53
800.00	2.13	2.04	1.94	1.74	1.42	1.29	1.15	1.04	0.94	0.88	0.82	0.75	0.69	0.64	0.60	0.58	0.54
850.00	2.16	2.07	1.97	1.76	1.44	1.31	1.17	1.05	0.95	0.88	0.83	0.75	0.70	0.64	0.61	0.58	0.54
900.00	2.19	2.09	2.00	1.79	1.47	1.33	1.18	1.06	0.96	0.89	0.83	0.75	0.70	0.65	0.61	0.58	0.54
950.00	2.22	2.13	2.02	1.81	1.49	1.35	1.20	1.08	0.97	0.89	0.84	0.76	0.71	0.65	0.62	0.59	0.54

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P2635 Max Fuel Flow

**Description:** P2635 Maximum Fuel Flow Disable Criteria

Maximum allowed fuel flow values above which the diagnostic is disabled

**Value Units:** grams / second**X Unit:** kilopascals [commanded fuel pressure]**Y Units:** volts [device supply]

y/x	200	250	300	350	400	450	500	550	600
5	512	512	512	512	512	512	512	512	512
6	512	512	512	512	512	512	512	512	512
8	512	512	512	512	512	512	512	512	512
9	512	512	512	512	512	512	512	512	512
11	512	512	512	512	512	512	512	512	512
12	512	512	512	512	512	512	512	512	512
14	512	512	512	512	512	512	512	512	512
15	512	512	512	512	512	512	512	512	512
17	512	512	512	512	512	512	512	512	512
18	512	512	512	512	512	512	512	512	512
20	512	512	512	512	512	512	512	512	512
21	512	512	512	512	512	512	512	512	512
23	512	512	512	512	512	512	512	512	512
24	512	512	512	512	512	512	512	512	512
26	512	512	512	512	512	512	512	512	512
27	512	512	512	512	512	512	512	512	512
29	512	512	512	512	512	512	512	512	512

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P2635 Threshold High

**Description:** P2635 Filtered Fuel Pressure Error High Threshold [under-performing pump]  
Instantaneously calculated filtered fuel pressure error

**Value Units:** kilopascals

**X Unit:** kilopascals [commanded fuel pressure]

**Y Units:** grams / sec [fuel flow]

y/x	200	250	300	350	400	450	500	550	600
0	30	38	45	53	60	68	75	83	90
2	30	38	45	53	60	68	75	83	90
3	30	38	45	53	60	68	75	83	90
5	30	38	45	53	60	68	75	83	90
6	30	38	45	53	60	68	75	83	90
8	30	38	45	53	60	68	75	83	90
9	30	38	45	53	60	68	75	83	90
11	30	38	45	53	60	68	75	83	90
12	30	38	45	53	60	68	75	83	90
14	30	38	45	53	60	68	75	83	90
15	30	38	45	53	60	68	75	83	90
17	30	38	45	53	60	68	75	83	90
18	30	38	45	53	60	68	75	83	90
20	30	38	45	53	60	68	75	83	90
21	30	38	45	53	60	68	75	83	90
23	30	38	45	53	60	68	75	83	90
24	30	38	45	53	60	68	75	83	90
26	30	38	45	53	60	68	75	83	90
27	30	38	45	53	60	68	75	83	90
29	30	38	45	53	60	68	75	83	90
30	30	38	45	53	60	68	75	83	90
32	30	38	45	53	60	68	75	83	90
33	30	38	45	53	60	68	75	83	90
35	30	38	45	53	60	68	75	83	90
36	30	38	45	53	60	68	75	83	90
38	30	38	45	53	60	68	75	83	90
39	30	38	45	53	60	68	75	83	90
41	30	38	45	53	60	68	75	83	90
42	30	38	45	53	60	68	75	83	90
44	30	38	45	53	60	68	75	83	90
45	30	38	45	53	60	68	75	83	90



20 OBDG03A ECM Supporting Tables

Initial Supporting table - P2635 Threshold High									
47	30	38	45	53	60	68	75	83	90
48	30	38	45	53	60	68	75	83	90

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P2635 Threshold Low

**Description:** P2635 Filtered Pressure Error Low Threshold [over-performing pump]  
Instantaneously calculated filtered fuel pressure error

**Value Units:** kilopascals

**X Unit:** kilopascals [commanded fuel pressure]

**Y Units:** grams / second [fuel flow]

y/x	200	250	300	350	400	450	500	550	600
0	-260	-210	-160	-110	-60	-68	-75	-83	-90
2	-145	-125	-103	-81	-60	-68	-75	-83	-90
3	-30	-38	-45	-53	-60	-68	-75	-83	-90
5	-30	-38	-45	-53	-60	-68	-75	-83	-90
6	-30	-38	-45	-53	-60	-68	-75	-83	-90
8	-30	-38	-45	-53	-60	-68	-75	-83	-90
9	-30	-38	-45	-53	-60	-68	-75	-83	-90
11	-30	-38	-45	-53	-60	-68	-75	-83	-90
12	-30	-38	-45	-53	-60	-68	-75	-83	-90
14	-30	-38	-45	-53	-60	-68	-75	-83	-90
15	-30	-38	-45	-53	-60	-68	-75	-83	-90
17	-30	-38	-45	-53	-60	-68	-75	-83	-90
18	-30	-38	-45	-53	-60	-68	-75	-83	-90
20	-30	-38	-45	-53	-60	-68	-75	-83	-90
21	-30	-38	-45	-53	-60	-68	-75	-83	-90
23	-30	-38	-45	-53	-60	-68	-75	-83	-90
24	-30	-38	-45	-53	-60	-68	-75	-83	-90
26	-30	-38	-45	-53	-60	-68	-75	-83	-90
27	-30	-38	-45	-53	-60	-68	-75	-83	-90
29	-30	-38	-45	-53	-60	-68	-75	-83	-90
30	-30	-38	-45	-53	-60	-68	-75	-83	-90
32	-30	-38	-45	-53	-60	-68	-75	-83	-90
33	-30	-38	-45	-53	-60	-68	-75	-83	-90
35	-30	-38	-45	-53	-60	-68	-75	-83	-90
36	-30	-38	-45	-53	-60	-68	-75	-83	-90
38	-30	-38	-45	-53	-60	-68	-75	-83	-90
39	-30	-38	-45	-53	-60	-68	-75	-83	-90
41	-30	-38	-45	-53	-60	-68	-75	-83	-90
42	-30	-38	-45	-53	-60	-68	-75	-83	-90
44	-30	-38	-45	-53	-60	-68	-75	-83	-90
45	-30	-38	-45	-53	-60	-68	-75	-83	-90

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P2635 Threshold Low									
47	-30	-38	-45	-53	-60	-68	-75	-83	-90
48	-30	-38	-45	-53	-60	-68	-75	-83	-90

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - Pair\_SCD\_Decel

**Description:** Used for P0300 - P0308, Multplier to SCD\_Decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - Pair\_SCD\_Jerk

**Description:** Used for P0300 - P0308, Multplier to P0300\_SCD\_Jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - PairCylModeDecel

**Description:** Used for P0300 - P0308, Multplier to Cyl Mode Deceleration to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multitplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	600	800	1,000	1,200	1,600	2,000	2,400	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	0.80	0.85	0.85	0.85	0.85	0.80	0.80	0.86	0.82	0.70	0.70	0.70	0.78	0.86	0.90	0.90	0.92
12	0.80	0.80	0.90	0.85	0.90	0.90	0.88	0.87	0.76	0.76	0.60	0.70	0.74	0.86	0.90	0.90	0.92
16	1.00	1.00	1.10	0.90	0.80	0.80	1.10	1.10	0.90	0.80	0.65	0.70	0.70	0.86	0.88	0.88	0.92
20	1.50	1.30	1.30	0.85	0.72	0.75	1.10	1.10	0.90	0.85	0.68	0.70	0.70	0.83	0.90	0.90	0.90
24	1.50	1.50	1.50	0.80	0.65	0.70	1.10	1.10	0.90	0.85	0.68	0.68	0.67	0.77	0.85	0.90	0.98
30	1.50	1.50	1.50	0.80	0.65	0.65	1.10	1.10	0.90	0.85	0.63	0.68	0.65	0.70	0.73	0.78	0.94
40	1.50	1.50	1.50	0.80	0.65	0.65	1.10	1.00	0.90	0.83	0.64	0.64	0.62	0.63	0.65	0.68	0.79
60	1.50	1.50	1.50	0.80	0.65	0.65	1.10	1.00	0.90	0.78	0.65	0.61	0.62	0.55	0.58	0.58	0.58

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - PairCylModeJerk

**Description:** Used for P0300 - P0308, Multplier to P0300\_CylModeJerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	600	800	1,000	1,200	1,600	2,000	2,400	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500
2	1.50	1.40	1.20	1.20	1.10	1.10	1.10	1.05	1.00	1.00	1.00	1.00	1.20	1.15	1.00	1.00	1.00
8	0.90	0.90	0.80	0.88	0.94	1.00	1.05	0.99	0.90	1.00	1.00	1.00	1.05	1.15	1.06	1.00	1.00
12	1.00	0.82	0.82	0.70	0.90	1.00	1.00	1.00	1.00	1.00	1.28	1.17	1.00	1.06	1.05	0.98	0.95
16	1.10	0.85	0.85	0.75	0.80	1.00	1.00	1.10	1.05	1.05	1.34	1.34	1.18	1.10	1.03	1.00	0.82
20	1.50	0.85	0.85	0.82	0.70	1.00	1.10	1.14	1.07	1.10	1.23	1.44	1.27	1.21	1.06	1.00	0.82
24	1.50	0.93	0.90	0.75	0.70	1.00	1.10	1.15	1.05	1.12	1.18	1.29	1.26	1.27	1.05	1.00	0.81
30	1.50	1.00	0.90	0.81	0.70	1.00	1.16	1.20	1.03	1.14	1.13	1.00	1.12	1.18	1.04	1.00	0.88
40	1.50	1.30	1.00	0.84	0.70	1.00	1.15	1.18	1.05	1.14	1.07	1.00	1.00	1.00	1.00	1.00	0.93
60	1.50	1.50	1.00	0.87	0.70	1.00	1.15	1.14	1.08	1.14	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - Random\_SCD\_Decel

**Description:** Used for P0300 - P0308, Multplier to SCD\_Decel to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00



## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - Random\_SCD\_Jerk

**Description:** Used for P0300 - P0308, Multplier to Random\_SCD\_Jerk to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	550	700	800	900	1,000	1,200	1,400	1,600
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - RandomAFM\_Decl

**Description:** Used for P0300 - P0308, Multplier to Cylinder\_Decel while in Cylinder Deactivation mode to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - RandomAFM\_Jerk

**Description:** Used for P0300 - P0308, Multplier to Cylinder\_Jerk while in CyLnder Deactivation mode to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - RandomCylModDecel

**Description:** Used for P0300 - P0308. Multiplier to CylMode\_Decel. account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** Multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	600	800	1,000	1,200	1,600	2,000	2,400	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500
2	1.30	1.10	1.10	1.20	1.20	1.15	1.15	1.10	1.35	1.35	1.10	1.18	1.00	1.00	1.00	1.00	1.00
8	1.90	1.60	1.60	1.60	1.60	1.60	1.55	1.60	1.70	1.70	1.70	1.65	1.65	1.36	1.20	1.27	1.05
12	2.50	2.50	2.50	2.50	2.00	2.00	2.00	2.00	2.00	2.00	1.70	1.70	1.70	1.96	1.89	1.72	1.50
16	2.35	3.20	3.20	2.75	2.00	2.00	2.00	2.00	2.00	2.00	1.70	1.70	1.70	1.92	2.00	2.00	2.00
20	2.35	3.20	3.20	2.75	2.00	2.00	2.00	2.00	2.00	2.00	1.70	1.70	1.67	1.80	2.00	2.13	2.00
24	2.00	3.20	3.20	2.75	2.00	2.00	2.00	2.00	2.00	2.00	1.70	1.70	1.67	1.74	2.00	2.00	2.00
30	1.60	3.10	3.20	2.75	1.90	1.80	2.10	2.10	2.10	2.10	1.70	1.70	1.61	1.65	1.80	1.80	1.80
40	1.50	2.20	3.20	2.75	1.90	1.80	2.10	2.10	2.10	2.10	1.70	1.64	1.59	1.59	1.72	1.72	1.73
60	1.50	1.50	2.00	2.00	1.90	1.65	2.10	2.10	2.10	2.10	1.70	1.59	1.56	1.52	1.52	1.52	1.52

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - RandomCylModJerk

**Description:** Used for P0300 - P0308, Multiplier to CylMode\_Jerk to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	600	800	1,000	1,200	1,600	2,000	2,400	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - RandomRevModDecl

**Description:** Used for P0300 - P0308, Multplier to RevMode\_Decel to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	3,000	3,500	4,000	4,500	5,000	5,500	6,000	7,000	8,000
2	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - RepetSnapDecayAdjst

**Description:** Used for P0300 - P0308, If misfire is present in consecutive engine cycles, this multiplier is applied to the misfire jerk threshold and compared to a crankshaft snap value after the misfire has taken place.. Table lookup as a function of engine rpm.

**Value Units:** multiplier

**X Unit:** RPM

y/x	1,000	1,400	1,800	2,200	2,600	3,000	4,000	5,000	6,000
1	4.50	4.50	4.75	6.50	6.50	6.20	5.50	5.50	5.50

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - RevMode\_Decel

**Description:** Used for P0300-P0308. Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

**Value Units:** Delta time between revolutions (usec)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
40	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
78	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
97	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767



## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - Ring Filter

**Description:** Used for P0300-P0308. Driveline Ring Filter

After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

**Value Units:** Number of Engine cycles after isolated misfire (Engine cycles)

**X Unit:** thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	4	4	4	4	4	4	4	4	4

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - SCD\_Decel

**Description:** Used for P0300-P0308 Crankshaft decel threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

**Value Units:** Delta time per cylinder (usec)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
40	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
78	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
97	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - SCD\_Jerk

**Description:** Used for P0300-P0308. Crankshaft jerk threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

**Value Units:** Change in Delta time per cylinder from last cylinder (usec)

**X Unit:** RPM

**Y Units:** percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
40	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
78	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
97	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - SnapDecayAfterMisfire

**Description:** Used for P0300 - P0308, multiplier times the ddt\_jerk value used used to detect misfire at that speed and load to see if size of disturbance has died down as expected of real misfire. Table lookup as a function of engine rpm and trans gear ratio.

**Value Units:** multiplier

**X Unit:** RPM

**Y Units:** gear ratio

y/x	1,000	1,400	1,800	2,200	2,600	3,000	4,000	5,000	6,000
1	2.00	2.50	3.00	4.00	4.00	3.60	3.00	3.00	3.00
1	2.00	2.50	3.00	4.00	4.00	3.60	3.00	3.00	3.00
1	2.00	2.50	2.80	2.20	2.50	3.60	2.70	3.00	3.00
1	2.00	2.50	2.70	2.00	1.50	1.75	2.30	3.00	3.00
2	2.00	2.50	2.60	1.90	1.50	1.50	2.00	2.50	3.00
2	2.00	2.50	2.60	1.90	1.50	1.50	2.00	2.50	3.00
3	1.80	2.30	2.00	1.60	1.50	1.50	2.00	2.50	2.00
3	1.80	2.30	2.00	1.60	1.50	1.50	2.00	2.50	2.00
5	1.80	2.20	2.50	1.80	3.00	3.00	2.80	2.60	2.25

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - TOSSRoughRoadThres

**Description:** Used for P0300-P0308. Only used if Rough Road source = TOSS: dispersion value on Transmission Output Speed Sensor above which rough road is indicated present

**Value Units:** change in rpm per sec (rpm)

**X Unit:** Engine Speed (RPM)

**Y Units:** Transmission Speed (RPM)

y/x	600	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000
100	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
300	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
500	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
700	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
900	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,100	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,300	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - WaitToStart

**Description:** Used for P0300-P0308. Number of engine cycles to delay if diesel engine is cranked before wait to start lamp is extinguished. This lookup table determines the delay length by taking into account the coolant temperature.

**Value Units:** Number of Engine Cycles (integer)

**X Unit:** Engine Coolant (deg C)

y/x	-20	-10	0	10	20	30	40	50	60
1	0	0	0	0	0	0	0	0	0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - WSSRoughRoadThres

**Description:** Used for P0300-P0308. Only used if Wheel speed from ABS is used. If difference between wheel speed readings is larger than this limit, rough road is present

**Value Units:** acceleration

**X Unit:** Vehicle Speed (KPH)

y/x	0	12	24	36	48	60	72	85	97	109	121	133	145	157	169	181	193
1	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000	1.00000

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - ZeroTorqueAFM

**Description:** Used for P0300-P0308. Zero torque engine load while in Active Fuel Management. %of Max Brake Torque along the Neutral rev line, as a function of RPM and Baro

**Value Units:** Percent of Maximum Brake torque (%)

**X Unit:** RPM

**Y Units:** Barometric Pressure (kPa)

#### ZeroTorqueAFM - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
65	-0.40	-0.70	-0.90	-1.05	-1.18	-1.30	-1.40	-1.50	-1.60	-1.75	-1.85	-1.90	-1.95
75	-0.40	-0.70	-0.90	-1.05	-1.18	-1.30	-1.40	-1.50	-1.60	-1.75	-1.85	-1.90	-1.95
85	-0.40	-0.70	-0.90	-1.05	-1.18	-1.30	-1.40	-1.50	-1.60	-1.75	-1.85	-1.90	-1.95
95	-0.40	-0.70	-0.90	-1.05	-1.18	-1.30	-1.40	-1.50	-1.60	-1.75	-1.85	-1.90	-1.95
105	-0.40	-0.70	-0.90	-1.05	-1.18	-1.30	-1.40	-1.50	-1.60	-1.75	-1.85	-1.90	-1.95

#### ZeroTorqueAFM - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
65	-1.98	-2.00	-2.00	-2.00	-2.00	-0.75	0.50	1.75	3.00	4.25	5.50	6.75	8.00
75	-1.98	-2.00	-2.00	-2.00	-2.00	-0.75	0.50	1.75	3.00	4.25	5.50	6.75	8.00
85	-1.98	-2.00	-2.00	-2.00	-2.00	-0.75	0.50	1.75	3.00	4.25	5.50	6.75	8.00
95	-1.98	-2.00	-2.00	-2.00	-2.00	-0.75	0.50	1.75	3.00	4.25	5.50	6.75	8.00
105	-1.98	-2.00	-2.00	-2.00	-2.00	-0.75	0.50	1.75	3.00	4.25	5.50	6.75	8.00



## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - ZeroTorqueEngLoad

**Description:** Used for P0300-P0308. %of Max Brake Torque that represents Zero Brake torque along the Neutral rev line, as a function of RPM and Baro

**Value Units:** Percent of Maximum Brake torque (%)

**X Unit:** RPM

**Y Units:** Barometric Pressure (kPa)

#### ZeroTorqueEngLoad - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
65	-0.40	-0.70	-0.90	-1.05	-1.18	-1.30	-1.40	-1.50	-1.60	-1.75	-1.85	-1.90	-1.95
75	-0.40	-0.70	-0.90	-1.05	-1.18	-1.30	-1.40	-1.50	-1.60	-1.75	-1.85	-1.90	-1.95
85	-0.40	-0.70	-0.90	-1.05	-1.18	-1.30	-1.40	-1.50	-1.60	-1.75	-1.85	-1.90	-1.95
95	-0.40	-0.70	-0.90	-1.05	-1.18	-1.30	-1.40	-1.50	-1.60	-1.75	-1.85	-1.90	-1.95
105	-0.40	-0.70	-0.90	-1.05	-1.18	-1.30	-1.40	-1.50	-1.60	-1.75	-1.85	-1.90	-1.95

#### ZeroTorqueEngLoad - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
65	-1.98	-2.00	-2.00	-2.00	-2.00	-0.75	0.50	1.75	3.00	4.25	5.50	6.75	8.00
75	-1.98	-2.00	-2.00	-2.00	-2.00	-0.75	0.50	1.75	3.00	4.25	5.50	6.75	8.00
85	-1.98	-2.00	-2.00	-2.00	-2.00	-0.75	0.50	1.75	3.00	4.25	5.50	6.75	8.00
95	-1.98	-2.00	-2.00	-2.00	-2.00	-0.75	0.50	1.75	3.00	4.25	5.50	6.75	8.00
105	-1.98	-2.00	-2.00	-2.00	-2.00	-0.75	0.50	1.75	3.00	4.25	5.50	6.75	8.00

Initial Supporting table - P0191 - High fail limit of fuel control due to high pressure sensor skewed High

**Description:** High fail limit of fuel control due to high pressure sensor skewed High error as Function of desired pressure

**Value Units:** Ratio  
**X Unit:** Desired Pressure (Mpa)

y/x	1.50	3.00	7.00	15.00	20.00	25.00	27.50	32.00	36.00
1.00	1.20	1.20	1.20	1.20	1.20	1.20	1.20	1.09	1.05

Initial Supporting table - P0191 - Low fail limit of fuel control due to pressure sensor skewed low

**Description:** Low fail limit of fuel control due to pressure sensor skewed low error as Function of desired pressure

**Value Units:** Ratio  
**X Unit:** Desired Pressure (Mpa)

y/x	1.50	3.00	7.00	15.00	20.00	25.00	27.50	32.00	36.00
1.00	0.76	0.81	0.81	0.81	0.81	0.82	0.86	0.92	0.95

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0494\_LIN\_Threshold

**Description:** Tabulated LIN Fan1 Speed Low Limits

**Value Units:** rpm

**X Unit:** Commanded LIN Fan1 Speed rpm

y/x	0	750	2,750	2,988	2,989	2,990	2,991	2,992	2,993	2,994	2,995	2,996	2,997	2,998	3,998	3,999	4,000
1	0	440	2,090	2,090	2,090	2,090	2,090	2,090	2,090	2,090	2,090	2,090	2,090	2,090	2,090	2,090	2,090

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0495\_LIN\_Threshold

**Description:** Tabulated LIN Fan1 Speed High Limits

**Value Units:** rpm

**X Unit:** Commanded LIN Fan1 Speed rpm

**Y Units:** Sensed LIN Fan1 Speed Upper Limit rpm

y/x	0	750	2,750	2,988	2,989	2,990	2,991	2,992	2,993	2,994	2,995	2,996	2,997	2,998	3,998	3,999	4,000
1	2,900	2,900	2,900	2,900	2,900	2,900	2,900	2,900	2,900	2,900	2,900	2,900	2,900	2,900	2,900	2,900	2,900

Initial Supporting table - P0556\_BBVS\_VacLowFlow

**Description:** The brake booster vacuum pressure below which the sensor's output will be considered abnormally low when it is non-increasing when the brake apply is in released condition.

**Value Units:** KPAA  
**X Unit:** Scaled ambient air pressure (KPAA)

y/x	60.0	70.0	80.0	90.0	100.0
1	50	60	70	80	90

Initial Supporting table - P06B7\_OpenTestCktMax2

**Description:** Max threshold table for the 20 KHz for the test circuit diagnostic for sensor 2. The lookup into this table will be filtered to define the max threshold for the filtered intensity. To fail, the filtered intensity needs to fall between this cal and the min cal filters.

y/x	750	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.209	0.209	0.215	0.215	0.232	0.232	0.232	0.271	0.305	0.367	0.588	0.576	0.592	0.592	0.592	0.592	0.592

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P06B7\_OpenTestCktMin2

**Description:** Min threshold table for the 20 KHz for the test circuit diagnostic for sensor 2. The lookup into this table will be filtered to define the max threshold for the filtered intensity. To fail, the filtered intensity needs to fall between this cal and the max cal filters.

y/x	750	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.102	0.102	0.104	0.104	0.115	0.115	0.115	0.139	0.154	0.191	0.320	0.311	0.322	0.322	0.322	0.322	0.322



Initial Supporting table - P228C P2C1F - High Pressure Pump Control (HPC) fail threshold of pressure too low									
<b>Description:</b> The High Pressure Pump Control (HPC) fail threshold of pressure too low test as a function of desired fuel pressure.									
<b>Value Units:</b> Pressure Error - Desired pressure - Actual Pressure (Mpa)									
<b>X Unit:</b> Desired Pressure (Mpa)									
y/x	2	3	7	15	20	25	28	32	36
1	0	2	3	3	5	5	5	5	5

Initial Supporting table - P228D P2C20 - High Pressure Pump Control (HPC) fail threshold for pressure too high									
<b>Description:</b> The High Pressure Pump Control (HPC) fail threshold for pressure too high test as a function of desired fuel pressure.									
<b>Value Units:</b> Pressure Error - Desired pressure - Actual Pressure (Mpa)									
<b>X Unit:</b> Desired Pressure (Mpa)									
y/x	1.50	3.00	7.00	15.00	20.00	25.00	27.50	32.00	36.00
1	-3.00	-3.00	-3.00	-3.00	-4.00	-4.00	-4.00	-4.00	-4.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P2635 Max Fuel Flow

**Description:** P2635 Maximum Fuel Flow Disable Criteria

Maximum allowed fuel flow values above which the diagnostic is disabled

**Value Units:** grams / second

**X Unit:** kilopascals [commanded fuel pressure]

**Y Units:** volts [device supply]

y/x	200	250	300	350	400	450	500	550	600
5	512	512	512	512	512	512	512	512	512
6	512	512	512	512	512	512	512	512	512
8	512	512	512	512	512	512	512	512	512
9	512	512	512	512	512	512	512	512	512
11	512	512	512	512	512	512	512	512	512
12	512	512	512	512	512	512	512	512	512
14	512	512	512	512	512	512	512	512	512
15	512	512	512	512	512	512	512	512	512
17	512	512	512	512	512	512	512	512	512
18	512	512	512	512	512	512	512	512	512
20	512	512	512	512	512	512	512	512	512
21	512	512	512	512	512	512	512	512	512
23	512	512	512	512	512	512	512	512	512
24	512	512	512	512	512	512	512	512	512
26	512	512	512	512	512	512	512	512	512
27	512	512	512	512	512	512	512	512	512
29	512	512	512	512	512	512	512	512	512

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P2635 Threshold High

**Description:** P2635 Filtered Fuel Pressure Error High Threshold [under-performing pump]  
Instantaneously calculated filtered fuel pressure error

**Value Units:** kilopascals

**X Unit:** kilopascals [commanded fuel pressure]

**Y Units:** grams / sec [fuel flow]

y/x	200	250	300	350	400	450	500	550	600
0	30	38	45	53	60	68	75	83	90
2	30	38	45	53	60	68	75	83	90
3	30	38	45	53	60	68	75	83	90
5	30	38	45	53	60	68	75	83	90
6	30	38	45	53	60	68	75	83	90
8	30	38	45	53	60	68	75	83	90
9	30	38	45	53	60	68	75	83	90
11	30	38	45	53	60	68	75	83	90
12	30	38	45	53	60	68	75	83	90
14	30	38	45	53	60	68	75	83	90
15	30	38	45	53	60	68	75	83	90
17	30	38	45	53	60	68	75	83	90
18	30	38	45	53	60	68	75	83	90
20	30	38	45	53	60	68	75	83	90
21	30	38	45	53	60	68	75	83	90
23	30	38	45	53	60	68	75	83	90
24	30	38	45	53	60	68	75	83	90
26	30	38	45	53	60	68	75	83	90
27	30	38	45	53	60	68	75	83	90
29	30	38	45	53	60	68	75	83	90
30	30	38	45	53	60	68	75	83	90
32	30	38	45	53	60	68	75	83	90
33	30	38	45	53	60	68	75	83	90
35	30	38	45	53	60	68	75	83	90
36	30	38	45	53	60	68	75	83	90
38	30	38	45	53	60	68	75	83	90
39	30	38	45	53	60	68	75	83	90
41	30	38	45	53	60	68	75	83	90
42	30	38	45	53	60	68	75	83	90
44	30	38	45	53	60	68	75	83	90
45	30	38	45	53	60	68	75	83	90

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P2635 Threshold High									
47	30	38	45	53	60	68	75	83	90
48	30	38	45	53	60	68	75	83	90

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P2635 Threshold Low

**Description:** P2635 Filtered Pressure Error Low Threshold [over-performing pump]  
Instantaneously calculated filtered fuel pressure error

**Value Units:** kilopascals

**X Unit:** kilopascals [commanded fuel pressure]

**Y Units:** grams / second [fuel flow]

y/x	200	250	300	350	400	450	500	550	600
0	-260	-210	-160	-110	-60	-68	-75	-83	-90
2	-145	-125	-103	-81	-60	-68	-75	-83	-90
3	-30	-38	-45	-53	-60	-68	-75	-83	-90
5	-30	-38	-45	-53	-60	-68	-75	-83	-90
6	-30	-38	-45	-53	-60	-68	-75	-83	-90
8	-30	-38	-45	-53	-60	-68	-75	-83	-90
9	-30	-38	-45	-53	-60	-68	-75	-83	-90
11	-30	-38	-45	-53	-60	-68	-75	-83	-90
12	-30	-38	-45	-53	-60	-68	-75	-83	-90
14	-30	-38	-45	-53	-60	-68	-75	-83	-90
15	-30	-38	-45	-53	-60	-68	-75	-83	-90
17	-30	-38	-45	-53	-60	-68	-75	-83	-90
18	-30	-38	-45	-53	-60	-68	-75	-83	-90
20	-30	-38	-45	-53	-60	-68	-75	-83	-90
21	-30	-38	-45	-53	-60	-68	-75	-83	-90
23	-30	-38	-45	-53	-60	-68	-75	-83	-90
24	-30	-38	-45	-53	-60	-68	-75	-83	-90
26	-30	-38	-45	-53	-60	-68	-75	-83	-90
27	-30	-38	-45	-53	-60	-68	-75	-83	-90
29	-30	-38	-45	-53	-60	-68	-75	-83	-90
30	-30	-38	-45	-53	-60	-68	-75	-83	-90
32	-30	-38	-45	-53	-60	-68	-75	-83	-90
33	-30	-38	-45	-53	-60	-68	-75	-83	-90
35	-30	-38	-45	-53	-60	-68	-75	-83	-90
36	-30	-38	-45	-53	-60	-68	-75	-83	-90
38	-30	-38	-45	-53	-60	-68	-75	-83	-90
39	-30	-38	-45	-53	-60	-68	-75	-83	-90
41	-30	-38	-45	-53	-60	-68	-75	-83	-90
42	-30	-38	-45	-53	-60	-68	-75	-83	-90
44	-30	-38	-45	-53	-60	-68	-75	-83	-90
45	-30	-38	-45	-53	-60	-68	-75	-83	-90

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P2635 Threshold Low									
47	-30	-38	-45	-53	-60	-68	-75	-83	-90
48	-30	-38	-45	-53	-60	-68	-75	-83	-90

P2B00 P2B01 P2B02 P2B03 P2B04 P2B05 P2B06 P2B07 P2B96 P2B08 P2B09 P2B0A P2B0B P2B0C P2B0D P2B0E P2B0F - kaFULO\_n]RP

Description: Max Engine Speed to allow Multipulse function of injector energy profile				
Value Units: Max Engine Speed to allow Multipulse				
X Unit: Injector Energy Profile				
Y Units: Multipulse Mode (0 = Double Pulse, 1 = Triple Pulse)				
y/x	0	1	2	3
0	3,600	3,600	3,600	3,600
1	3,000	3,000	3,000	3,000



## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - Closed Loop Enable Clarification - KaFCLP\_U\_SlphrIntglOfst\_Thrsh

**Description:** Integral Offset voltage thresholds (bank and cell specific cals) used with KeFCLP\_Pct\_CatAccuSlphrPostDsbl to check for sulphur poisoning.

**Value Units:** millivolts

**X Unit:** Post Catalyst Number

y/x	CiOXYR_O2_PostCat1	CiOXYR_O2_PostCat2
CiFCLP_Decel	2,048	2,048
CiFCLP_Idle	2,048	2,048
CiFCLP_Cruise	2,048	2,048
CiFCLP_LightAccel	2,048	2,048
CiFCLP_HeavyAccel	2,048	2,048

Initial Supporting table - Closed Loop Enable Clarification - KcFCLP\_Cnt\_O2RdyCyclesThrsh

**Description:** Number of times a post oxygen sensor value must be in range before declaring it ready

**Value Units:** Time (events \* 12.5 milliseconds)

y/x	1
1	80

Initial Supporting table - Closed Loop Enable Clarification - KcFULC\_O2\_SensorReadyEvents

**Description:** Number of times a pre oxygen sensor value must be in range before declaring it ready

**Value Units:** Time (events \* 12.5 milliseconds)

y/x	1
1	2

Initial Supporting table - Closed Loop Enable Clarification - KeEOSD\_U\_RichThrsh

**Description:** The oxygen sensor voltage above which a sensor will be considered failing during a Rich Test.

**Value Units:** Volts

y/x	1
1	1,050

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP\_dm\_IntegrationAirflowMax

**Description:** Maximum allowed estimated airflow for post O2 integral terms to be updated.

**Value Units:** Grams per Second

y/x	1
1	512

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP\_Pct\_CatAccuSlphrPostDsbl

**Description:** Sulphur percent threshold above which post integral learning is disabled if the threshold criteria KaFCLP\_U\_SlphrIntglOfst\_Thrsh is also met.

**Value Units:** Percent

y/x	1
1	255

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP\_T\_IntegrationCatalystMax

**Description:** Maximum allowed estimated catalytic converter temperature for post O2 integral terms to be updated.

**Value Units:** Celcius

y/x	1
1	1,000

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP\_T\_IntegrationCatalystMin

**Description:** Minimum allowed estimated catalytic converter temperature to begin using post O2 integration correction terms. Converter temperature must remain above this threshold to ramp-in the post O2 integration adjustments. Once the ramp-in has started, a converter temperature below this threshold will freeze the ramp-in multiplier. Post O2 integration will not be allowed below this converter temperature

**Value Units:** Celcius

y/x	1
1	425



Initial Supporting table - Closed Loop Enable Clarification - KeFULC\_T\_WRAF\_SensorReadyThrsh

**Description:** Pumping cell temperature threshold above which the wideband oxygen sensor will be considered ready for use

**Value Units:** Degrees Celcius

y/x	1
1	700

Initial Supporting table - Closed Loop Enable Clarification - KeWRSC\_T\_HtrCntrlCL

**Description:** WRAF heater temperature enabling threshold for transition from Open Loop to Closed Loop

**Value Units:** Degrees Celcius

y/x	1
1	628

Initial Supporting table - Closed Loop Enable Clarification - KeWRSI\_T\_PumpCurrentEnable

**Description:** WRAF heater temperature threshold for enabling the sensor pump current

**Value Units:** Degrees Celcius

y/x	1
1	628

Initial Supporting table - Closed Loop Enable Clarification - KfFCLL\_T\_AdaptiveLoCoolant

**Description:** LTM learning is inhibited if the engine coolant temperature is below this calibration.

**Value Units:** Degrees Celcius

y/x	1
1	40

Initial Supporting table - Closed Loop Enable Clarification - KfFCLP\_U\_O2ReadyThrshLo

**Description:** Voltage limit checked against when determining if a post converter oxygen sensor is in range

**Value Units:** millivolts

y/x	1
1	1,100

Initial Supporting table - Closed Loop Enable Clarification - KfFULC\_U\_O2\_SensorReadyThrshLo

**Description:** Voltage limit checked against when determining if a pre converter oxygen sensor is in range

**Value Units:** millivolts

y/x	1
1	1,250

Initial Supporting table - Closed Loop Enable Clarification - KtFCLL\_p\_AdaptiveLowMAP\_Limit

**Description:** Long term fuel learning is disabled below this MAP limit as a function of barometric pressure.

**Value Units:** KPa  
**X Unit:** KPa

y/x	65	70	75	80	85	90	95	100	105
1	16.0	16.0	16.0	16.0	16.0	17.0	18.0	18.0	18.0

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP\_t\_PostIntglDisableTime

**Description:** Disable integral offset after engine start for this amount of time as a function of start up coolant temperature.

**Value Units:** Time in seconds

**X Unit:** Degrees Celcius

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	100.0	100.0	100.0	100.0	100.0	100.0	100.0	100.0	100.0	80.0	60.0	50.0	50.0	50.0	50.0	50.0	50.0



Initial Supporting table - Closed Loop Enable Clarification - KtFCLP\_t\_PostIntglRamplnTime

**Description:** Time required to ramp integral offset to desired value as a function of start up coolant temperature.

**Value Units:** Time in seconds

**X Unit:** Degrees Celcius

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	50.0	50.0	50.0	50.0	30.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - Closed Loop Enable Clarification - KtFSTA\_t\_ClosedLoopAutostart

**Description:** Engine run time following an autostart, as a function of begin run coolant, which must be exceeded to enable CLOSED LOOP.

**Value Units:** Time in seconds

**X Unit:** Degrees Celcius

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300.0	300.0	230.0	90.0	80.0	32.0	32.0	16.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA\_t\_ClosedLoopTime

**Description:** Engine run time, as a function of startup coolant temperature, which must be exceeded to enable CLOSED LOOP.

**Value Units:** Time in seconds

**X Unit:** Degrees Celcius

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	300.0	300.0	230.0	90.0	80.0	32.0	32.0	32.0	32.0	32.0	0.0	0.0	0.0	30.0	45.0	45.0	45.0

Initial Supporting table - P0442 Volatility Time as a Function of Estimate of Ambient Temperature

**Description:** EONV volatility time as a function of estimated ambient temperature

**Value Units:** Volatility time (seconds)

**X Unit:** Estimated Ambient Temperature (Deg C)

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	30	30	45	60	80	120	220	300	400	400	400	400	400	400	400	400	400

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0442 Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature

**Description:** Maximum engine off time before vehicle off time as a function of estimated ambient temperature (EAT)

**Value Units:** Maximum Engine Off Time Before Vehicle Off Time (seconds)

**X Unit:** Estimated Ambient Temperature (Deg C)

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	44	44	44	44	68	82	105	153	320	480	480	480	480	480	480	480	480

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0442 EONV Pressure Threshold (Pascals)

**Description:** EONV pressure threshold as a function of fuel level and estimated ambient temperature (EAT)

**Value Units:** EONV Pressure Threshold (Pascals)

**X Unit:** Fuel Level (percent) from 0 to 100 with step size 6.25

**Y Units:** Estimated Ambient Temperature (deg C) from -10 to 80 with step size 5.625

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
2	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
3	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
4	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
5	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
6	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
7	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
8	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
9	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
10	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
11	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
12	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
13	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
14	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
15	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
16	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7
17	-474.6	-474.6	-447.8	-421.1	-394.3	-367.6	-340.8	-314.3	-287.5	-260.8	-234.0	-207.2	-180.5	-155.7	-155.7	-155.7	-155.7

Initial Supporting table - P0496 Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level																	
Description: Purge valve leak test engine vacuum test time as a function of fuel level																	
Value Units: Purge Valve Leak Test Engine Vacuum Test Time (seconds)																	
X Unit: Fuel Level (percent)																	
y/x	0	6	12	19	25	31	37	44	50	56	62	69	75	81	87	94	100
1	55	54	53	52	52	51	50	49	48	47	47	46	45	44	43	42	42

Initial Supporting table - P057B KtBRKI\_K\_CmpltTestPointWeight

Description:									
y/x	0.000	0.002	0.012	0.030	0.047	0.057	0.094	0.141	1.000
1	0	0	0	0	1	1	1	1	1



Initial Supporting table - P057B KtBRKI\_K\_FastTestPointWeight

Description:									
y/x	0.000	0.002	0.012	0.030	0.047	0.057	0.094	0.200	1.000
1	0	0	0	0	1	1	1	1	1

Initial Supporting table - DFCO\_CoolEnbIHi\_Temp

Description:			
y/x	-40	0	25
1	45.0	45.0	45.0

Initial Supporting table - DFCO\_DelayAfterStart\_Time

Description:					
y/x	-30	-10	20	60	90
1	10.0	7.5	5.0	5.0	5.0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - DFCO\_DsblLo\_Vehicle\_Speed

Description:		
y/x	CeTCOR_e_NonEcoMode	CeTCOR_e_EcoMode
CeTGRR_e_TransGr1	29	29
CeTGRR_e_TransGr2	21	21
CeTGRR_e_TransGr3	21	21
CeTGRR_e_TransGr4	18	18
CeTGRR_e_TransGr5	0	0
CeTGRR_e_TransGr6	0	0
CeTGRR_e_TransGr9	0	0
CeTGRR_e_TransGr10	0	0
CeTGRR_e_TransGrNeut	0	0
CeTGRR_e_TransGrRvrs	0	0
CeTGRR_e_TransGrPark	0	0
CeTGRR_e_TransGr7	0	0
CeTGRR_e_TransGr8	0	0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - DFCO\_EnblHi\_Vehicle\_Speed

Description:		
y/x	CeTCOR_e_NonEcoMode	CeTCOR_e_EcoMode
CeTGRR_e_TransGr1	32.0	32.0
CeTGRR_e_TransGr2	24.0	24.0
CeTGRR_e_TransGr3	30.0	30.0
CeTGRR_e_TransGr4	30.0	30.0
CeTGRR_e_TransGr5	0.0	0.0
CeTGRR_e_TransGr6	0.0	0.0
CeTGRR_e_TransGr9	0.0	0.0
CeTGRR_e_TransGr10	0.0	0.0
CeTGRR_e_TransGrNeut	0.0	0.0
CeTGRR_e_TransGrRvrs	512.0	512.0
CeTGRR_e_TransGrPark	0.0	0.0
CeTGRR_e_TransGr7	0.0	0.0
CeTGRR_e_TransGr8	0.0	0.0

Initial Supporting table - DFCO\_EngSpdEnblOfst

Description:									
y/x	-1,750	-1,500	-1,250	-1,000	-750	-500	-300	-100	0
1	500	400	250	150	100	50	0	0	0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - CalculatedPerfMaxEc1

**Description:** Maximum desired camshaft position for Exhaust CAM - Bank1

**Value Units:** Maximum desired camshaft position (degCam)

**X Unit:** Engine Oil Temperature (degC)

[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]

[-40 -28 -16 -4 8 20 32 44 56 68 80 92 104 116 128 140 152]

**Y Units:** Engine Speed (rpm)

[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]

[400 800 1200 1600 2000 2400 2800 3200 3600 4000 4400 4800 5200 5600 6000 6400 6800]

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
2	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
3	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
4	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
5	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
6	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
7	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
8	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
9	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
10	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
11	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
12	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
13	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
14	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
15	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
16	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
17	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - CalculatedPerfMaxlc1

**Description:** Maximum desired camshaft position for Intake CAM - Bank1

**Value Units:** Maximum desired camshaft position (degCam)

**X Unit:** Engine Oil Temperature (degC)

[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]

[-40 -28 -16 -4 8 20 32 44 56 68 80 92 104 116 128 140 152]

**Y Units:** Engine Speed (rpm)

[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]

[400 800 1200 1600 2000 2400 2800 3200 3600 4000 4400 4800 5200 5600 6000 6400 6800]

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
2	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
3	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
4	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
5	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
6	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
7	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
8	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
9	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
10	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
11	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
12	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
13	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
14	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
15	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
16	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0
17	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0



## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0234: Overboost pressure limit below basic pressure as a function of engine speed and ambient pressure

**Description:** Overboost under basic pressure (open loop pressure control) diagnose failure limit.

**Value Units:** [kPa] Overboost under basic pressure fail limit.

**X Unit:** [kPa] KnBSTD\_p\_CntrlDevDiagAmbCorrBP - Ambient Air Pressure

**Y Units:** [rpm] KnBSTD\_n\_CntrlDevDiagAmbCorrBP - Engine Speed

y/x	60.00	70.00	80.00	90.00	100.00	110.00
1,500.00	90.000	90.000	73.000	65.000	59.000	59.000
2,500.00	62.000	50.000	27.000	26.000	26.000	26.000
3,000.00	42.000	25.000	10.000	10.000	10.000	10.000
4,000.00	30.000	10.000	10.000	10.000	10.000	10.000
5,000.00	30.000	10.000	10.000	10.000	10.000	10.000
6,000.00	30.000	10.000	10.000	10.000	10.000	10.000

Initial Supporting table - P0299: Underboost high rate limit as a function of engine speed

**Description:** Allowed positive rate limit on desired boost pressure. In allowed kPa per 100 ms.

**Value Units:** [kPa] Allowed positive rate limit  
**X Unit:** [rpm] KnBSTD\_n\_CntrlDevDiagEngSpdBP - Engine Speed

y/x	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	6,000
1	2.000	2.500	2.700	2.900	3.000	3.000	3.100	3.200	3.500	4.000

Initial Supporting table - P0299: Underboost low rate limit as a function of engine speed

**Description:** Allowed negative rate limit on desired boost pressure. In allowed kPa per 100 ms.

**Value Units:** [kPa] Allowed negative rate limit.  
**X Unit:** [rpm] KnBSTD\_n\_CntrlDevDiagEngSpdBP - Engine Speed

y/x	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	6,000
1	-200.00	-200.00	-200.00	-200.00	-200.00	-200.00	-200.00	-200.00	-200.00	-200.00

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P0521\_P06DD\_P06DE\_OP\_HiStatePressure

**Description:** Two Stage Oil Pump Oil Pressure in High State**Value Units:** Nominal high state oil pressure (kPa)**X Unit:** Engine oil temperature (deg C)

y/x	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0
1,000.0	492.1	459.1	428.6	390.5	350.4	302.9	252.1	215.1	168.9
1,500.0	534.7	510.1	488.6	463.3	435.8	402.9	367.0	332.6	270.4
2,000.0	556.8	538.8	521.3	499.9	477.1	450.9	416.0	387.1	347.6
2,500.0	570.0	554.6	540.3	523.1	500.6	476.6	444.9	414.8	374.9
3,000.0	570.5	557.6	543.2	528.2	509.5	487.6	452.2	422.8	388.7
3,500.0	562.8	552.0	537.9	522.3	508.8	490.6	461.4	435.9	404.2
4,000.0	549.8	535.8	526.1	517.8	510.4	497.2	470.1	442.3	407.7
4,500.0	547.8	535.4	526.4	517.9	510.3	498.4	475.6	449.1	417.2
5,000.0	542.5	532.5	526.1	523.0	510.9	500.4	472.6	454.7	420.0

## 20 OBDG03A ECM Supporting Tables

**Initial Supporting table - P0521\_P06DD\_P06DE\_OP\_LoStatePressure**

**Description:** Two Stage Oil Pump Oil Pressure in Low State

**Value Units:** Nominal low state oil pressure (kPa)

**X Unit:** Engine oil temperature (deg C)

y/x	40	50	60	70	80	90	100	110	120
1,000	325	309	295	280	265	250	228	207	169
1,500	347	336	326	314	300	284	266	253	232
2,000	359	350	341	330	318	307	290	276	256
2,500	363	353	345	339	329	319	304	290	269
3,000	363	356	349	341	333	323	309	295	280
3,500	361	355	348	339	331	323	312	301	287
4,000	357	347	339	335	325	325	314	303	282
4,500	351	344	338	333	326	324	315	305	295
5,000	347	340	334	329	325	321	312	303	294

Initial Supporting table - P06DD\_P06DE\_MaxEnableTorque\_OP

**Description:** Two Stage Oil Pump Rationality Test Torque Max Enable Threshold

**Value Units:** Maximum engine torque (Nm)

**X Unit:** Engine speed (RPM)

y/x	1,000.0	1,250.0	1,500.0	1,750.0	2,000.0	2,250.0	2,500.0	2,750.0	3,000.0
1.0	0.0	0.0	140.0	140.0	140.0	140.0	140.0	0.0	0.0

Initial Supporting table - P06DD\_P06DE\_MinEnableTorque\_OP

**Description:** Two Stage Oil Pump Rationality Test Torque Min Enable Threshold

**Value Units:** Min engine torque (Nm)

**X Unit:** Engine speed (RPM)

y/x	1,000.0	1,250.0	1,500.0	1,750.0	2,000.0	2,250.0	2,500.0	2,750.0	3,000.0
1.0	0.0	0.0	20.0	20.0	20.0	20.0	20.0	0.0	0.0

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P06DD\_P06DE\_MinOilPressThresh

**Description:** Intrusive diagnostic minimum pressure limit that is a function of Engine Speed and Oil Temperature

**Value Units:** Minimum engine oil pressure threshold (kPa)

**X Unit:** Engine oil temperature (deg C)

y/x	40	50	60	70	80	90	100	110	120
1,000	160	160	160	160	160	160	160	160	160
1,500	160	160	160	160	160	160	160	160	160
2,000	187	187	187	187	187	187	187	187	187
2,500	200	200	200	200	200	200	200	200	200
3,000	200	200	200	200	200	200	200	200	200
3,500	200	200	200	200	200	200	200	200	200
4,000	200	200	200	200	200	200	200	200	200
4,500	200	200	200	200	200	200	200	200	200
5,000	1,133	1,133	1,133	1,133	1,133	1,133	1,133	1,133	1,133



## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P06DD\_P06DE\_OP\_StateChangeMin

**Description:** Minimum allowed pressure change on a Two Stage Oil Pump state change

**Value Units:** Min pressure change (kPa)

**X Unit:** Engine oil temperature (deg C)

y/x	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0
1,000.0	66.7	60.1	53.4	40.9	0.0	0.0	0.0	0.0	0.0
1,500.0	75.1	69.8	65.3	59.9	54.3	47.6	40.6	31.8	15.4
2,000.0	79.1	75.4	72.1	68.1	63.6	57.8	50.3	44.5	36.8
2,500.0	83.0	80.5	77.9	73.9	68.8	63.3	56.4	50.0	42.5
3,000.0	83.0	80.4	77.7	74.8	70.5	65.6	57.3	51.1	43.6
3,500.0	80.9	78.9	76.1	73.3	71.1	66.9	59.8	54.1	46.7
4,000.0	77.3	75.4	74.7	73.0	74.0	68.8	62.6	55.7	33.5
4,500.0	78.7	76.7	75.1	74.0	73.6	69.9	64.4	57.8	49.1
5,000.0	78.3	77.0	76.8	77.8	74.4	71.7	64.3	60.6	50.4

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - Minimum Non-Purge Samples for Purge Vapor Fuel

**Description:** Number of Fuel Trim Monitor sample counts required to allow the Purge Vapor Fuel value to inhibit the Intrusive Rich test

**Value Units:** Sample Counts per loop rate of 100ms (divide by 10 to get seconds)

**X Unit:** Long Term Fuel Trim Cell I.D. (no units) (Only PurgeOff cells are used)

#### Minimum Non-Purge Samples for Purge Vapor Fuel - Part 1

y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	65,535	65,535	65,535	65,535

#### Minimum Non-Purge Samples for Purge Vapor Fuel - Part 2

y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	65,535	65,535	65,535	65,535

#### Minimum Non-Purge Samples for Purge Vapor Fuel - Part 3

y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	65,535	65,535	65,535	65,535

#### Minimum Non-Purge Samples for Purge Vapor Fuel - Part 4

y/x	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	65,535	65,535	65,535	65,535

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage

**Description:** Identifies which Long Term Fuel Trim Cell I.D.s are used for diagnosis. Only cells identified as "CeFADD\_e\_NonSelectedCell" are not used for diagnosis.

#### P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage - Part 1

y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell

#### P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage - Part 2

y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_NonSelectedCell

#### P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage - Part 3

y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell

#### P0171\_P0172\_P0174\_P0175 Long-Term Fuel Trim Cell Usage - Part 4

y/x	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_NonSelectedCell

## 20 OBDG03A ECM Supporting Tables

Initial Supporting table - P219A Normalizer Bank1 Table

**Description:** Bank 1 Normalizer table used in the calculation of the Ratio for the current sample period.

**Value Units:** Unitless Scalar

**X Unit:** Engine Speed (RPM)

**Y Units:** Air Per Cylinder (APC) (mg/cylinder)

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
120	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
160	9,999.00	9,999.00	9,999.00	7.75	7.75	8.75	11.50	11.50	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
200	9,999.00	9,999.00	9,999.00	7.75	7.75	8.75	11.50	11.50	12.75	16.00	9.25	9.25	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
240	9,999.00	9,999.00	9,999.00	30.25	30.25	21.25	19.25	16.00	12.75	16.00	9.25	9.25	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
280	9,999.00	9,999.00	9,999.00	49.00	49.00	51.00	45.75	32.75	24.25	22.00	24.00	24.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
320	9,999.00	9,999.00	9,999.00	74.25	74.25	69.50	56.25	28.50	43.50	35.00	31.00	24.75	18.50	9,999.00	9,999.00	9,999.00	9,999.00
360	9,999.00	9,999.00	9,999.00	97.50	97.50	86.75	76.00	46.00	54.50	46.00	35.50	18.50	18.50	9,999.00	9,999.00	9,999.00	9,999.00
400	9,999.00	9,999.00	9,999.00	124.00	124.00	132.25	113.50	76.25	69.75	62.00	50.50	32.50	32.50	9,999.00	9,999.00	9,999.00	9,999.00
440	9,999.00	9,999.00	9,999.00	158.50	158.50	148.75	136.75	90.50	87.50	75.00	58.50	40.75	40.75	9,999.00	9,999.00	9,999.00	9,999.00
480	9,999.00	9,999.00	9,999.00	174.50	174.50	173.00	154.00	119.50	108.50	89.00	60.75	39.00	39.00	9,999.00	9,999.00	9,999.00	9,999.00
520	9,999.00	9,999.00	9,999.00	176.25	176.25	171.75	154.50	133.00	112.00	97.50	68.25	59.25	59.25	9,999.00	9,999.00	9,999.00	9,999.00
560	9,999.00	9,999.00	9,999.00	152.00	152.00	189.50	176.00	133.50	129.50	110.75	85.25	61.00	61.00	9,999.00	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	182.25	182.25	211.50	169.50	150.50	150.75	133.25	100.25	73.25	73.25	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	182.25	192.00	202.00	176.00	155.75	167.00	149.00	117.00	78.50	78.50	9,999.00	9,999.00	9,999.00	9,999.00
800	9,999.00	9,999.00	9,999.00	9,999.00	202.00	202.00	176.00	155.75	167.00	149.00	117.00	78.50	78.50	9,999.00	9,999.00	9,999.00	9,999.00

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P219A Quality Factor Bank1 Table

**Description:** Bank 1 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

**Value Units:** Unitless Scalar

**X Unit:** Engine Speed (RPM)

**Y Units:** Air Per Cylinder (APC) (mg/cylinder)

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
80	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
120	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
160	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
200	0.00	0.00	0.00	0.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
240	0.00	0.00	0.00	0.00	1.00	1.00	1.00	0.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
280	0.00	0.00	0.00	0.00	1.00	1.00	1.00	0.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
320	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
360	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
400	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
440	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
480	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
520	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
560	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
640	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
720	0.00	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

# 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P219A Variance Threshold Bank1 Table

**Description:** Bank 1 lookup table of Variance metric used to calculate the Ratio for the current sample period

**Value Units:** Unitless ratio

**X Unit:** Engine Speed (RPM)

**Y Units:** Air Per Cylinder (APC) (mg/cylinder)

y/x	250	500	750	1,000	1,250	1,500	1,750	2,000	2,250	2,500	2,750	3,000	3,500	4,000	4,500	5,000	6,000
40	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
80	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
120	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
160	9,999.00	9,999.00	9,999.00	10.75	10.75	12.00	10.25	10.25	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
200	9,999.00	9,999.00	9,999.00	10.75	10.75	12.00	10.25	10.25	10.00	10.00	7.50	7.50	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
240	9,999.00	9,999.00	9,999.00	18.50	18.50	15.25	11.75	11.00	10.00	10.00	7.50	7.50	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
280	9,999.00	9,999.00	9,999.00	25.50	25.50	20.00	15.00	22.75	13.00	13.25	7.75	7.75	9,999.00	9,999.00	9,999.00	9,999.00	9,999.00
320	9,999.00	9,999.00	9,999.00	33.75	33.75	29.00	20.00	40.50	15.25	13.25	12.75	22.25	31.75	9,999.00	9,999.00	9,999.00	9,999.00
360	9,999.00	9,999.00	9,999.00	47.25	47.25	51.50	35.50	45.75	19.75	18.75	18.25	31.75	31.75	9,999.00	9,999.00	9,999.00	9,999.00
400	9,999.00	9,999.00	9,999.00	65.75	65.75	43.50	32.50	44.50	24.00	26.25	19.25	28.25	28.25	9,999.00	9,999.00	9,999.00	9,999.00
440	9,999.00	9,999.00	9,999.00	52.25	52.25	50.50	37.75	54.00	29.50	26.50	22.75	29.25	29.25	9,999.00	9,999.00	9,999.00	9,999.00
480	9,999.00	9,999.00	9,999.00	55.50	55.50	49.25	43.25	50.50	33.50	24.75	26.25	35.50	35.50	9,999.00	9,999.00	9,999.00	9,999.00
520	9,999.00	9,999.00	9,999.00	70.50	70.50	65.00	63.25	52.00	45.00	31.50	34.50	32.25	32.25	9,999.00	9,999.00	9,999.00	9,999.00
560	9,999.00	9,999.00	9,999.00	103.50	103.50	62.50	51.00	63.75	41.75	31.50	32.25	33.25	33.25	9,999.00	9,999.00	9,999.00	9,999.00
640	9,999.00	9,999.00	9,999.00	115.00	115.00	67.25	64.00	62.50	43.75	39.00	30.75	32.25	32.25	9,999.00	9,999.00	9,999.00	9,999.00
720	9,999.00	9,999.00	9,999.00	115.00	98.25	81.50	62.00	65.25	41.75	33.75	32.00	37.25	37.25	9,999.00	9,999.00	9,999.00	9,999.00
800	9,999.00	9,999.00	9,999.00	9,999.00	81.50	81.50	62.00	65.25	41.75	33.75	32.00	37.25	37.25	9,999.00	9,999.00	9,999.00	9,999.00

Initial Supporting table - P0068\_Delta MAF Threshold f(TPS)

**Description:** Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

**Value Units:** Delta MAF Values (dm)  
**X Unit:** Desired Throttle Position (Pct)

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	9.38	12.13	16.89	19.20	29.84	49.55	255.00	255.00	255.00

Initial Supporting table - P0068\_Delta MAP Threshold f(TPS)

**Description:** Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

**Value Units:** Delta MAP Values (kPa)  
**X Unit:** Desired Throttle Position (Pct)

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	37.45	44.08	46.55	45.54	46.96	41.86	255.00	255.00	255.00



Initial Supporting table - P0068\_Maximum MAF f(RPM)

**Description:** Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

**Value Units:** Delta MAF Values (dm)  
**X Unit:** Engine Speed (RPM)

y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
1.00	17.90	39.19	63.43	80.91	112.92	138.31	168.70	174.20	176.70

Initial Supporting table - P0068\_Maximum MAF f(Volts)

**Description:** Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.

**Value Units:** Delta MAF Values (dm)  
**X Unit:** System Voltage (V)

y/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00
1.00	6.50	25.00	65.00	140.00	260.00	300.00	300.70	300.70	300.70

Initial Supporting table - P0326\_P0331\_AbnormalNoise\_Thresh\_AFM

**Description:** Fail threshold for the Knock Performance Abnormal Noise Diagnostic when engine IS in AFM mode

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.881	0.721	0.590	0.483	0.396	0.324	0.266	0.217	0.178	0.146	0.119	0.098	0.080	0.065	0.054	0.044	0.036

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

**Value Units:** Max Time for Last Seed Timeout (ms)

**X Unit:** Operating Loop Sequence (enum)

#### P0606\_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000

#### P0606\_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	500.000	500.000	1,000.000	8,191.875	8,191.875	8,191.875	

# 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)

**Description:** Fail threshold for PSW per operating loop.

**Value Units:** Fail threshold for PSW (count)

**X Unit:** Operating Loop (enum)

### P0606\_PSW Sequence Fail f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	5	3	5	3	5	3	5

### P0606\_PSW Sequence Fail f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	5	5	5	3	5	5	

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P0606\_PSW Sequence Sample f(Loop Time)

**Description:** Sample threshold for PSW per operating loop.**Value Units:** Sample threshold for PSW (count)**X Unit:** Operating Loop (enum)

## P0606\_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	4	4	4	4	4	4	4

## P0606\_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	4	4	4	4	4	4	

Initial Supporting table - P1682\_PT Relay Pull-in Run/Crank Voltage f(IAT)

**Description:** The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

**Value Units:** Run/Crank Voltages required to pull in PT Relay (V)

**X Unit:** Induction Air Temperature (deg C)

y/x	23.0	85.0	95.0	105.0	125.0
1	7.000	8.699	9.000	9.199	10.000

Initial Supporting table - P16F3\_Delta MAP Threshold f(Desired Engine Torque)

**Description:** Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

**Value Units:** Torque Security Threshold for Engine Sync and Time Based Delta Pressure (kPa)

**X Unit:** Desired Engine Torque (Nm)

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	37.45	37.45	37.45	37.45	37.45	37.45



## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P16F3\_Speed Control External Load f(Oil Temp, RPM)

**Description:** Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

**Value Units:** External Load Table for SPDR (Nm)

**X Unit:** Engine Oil Temperature (deg C)

**Y Units:** Engine Speed (RPM)

y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
350.00	119.10	111.32	129.68	148.10	122.93	60.93
450.00	119.10	111.32	129.68	148.10	122.93	60.93
550.00	119.10	111.32	129.68	148.10	122.93	60.93
650.00	119.10	111.32	129.68	148.10	122.93	60.93
750.00	124.75	116.77	134.90	153.10	126.69	60.89
850.00	135.36	127.11	145.14	163.40	136.31	63.06
900.00	140.12	131.53	148.51	165.97	140.13	64.35
1,000.00	153.47	144.72	162.51	180.69	152.87	63.29
1,100.00	163.63	154.76	172.68	190.87	161.49	71.39
1,200.00	171.40	161.25	178.45	196.51	166.54	81.09
1,450.00	155.27	145.52	160.09	175.16	144.79	82.71
1,700.00	80.96	71.66	65.03	58.84	41.18	34.59
1,950.00	58.07	49.06	42.79	36.92	20.47	14.60
2,200.00	37.31	28.52	22.53	16.89	1.37	-3.94
3,200.00	-65.23	-65.23	-65.23	-65.23	-65.23	-65.23
4,200.00	-71.76	-71.76	-71.76	-71.76	-71.76	-71.76
6,400.00	-78.28	-78.28	-78.28	-78.28	-78.28	-78.28

Initial Supporting table - P0068\_Delta MAF Threshold f(TPS)

**Description:** Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

**Value Units:** Delta MAF Values (dm)  
**X Unit:** Desired Throttle Position (Pct)

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	9.38	12.13	16.89	19.20	29.84	49.55	255.00	255.00	255.00

Initial Supporting table - P0068\_Delta MAP Threshold f(TPS)

**Description:** Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

**Value Units:** Delta MAP Values (kPa)  
**X Unit:** Desired Throttle Position (Pct)

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	37.45	44.08	46.55	45.54	46.96	41.86	255.00	255.00	255.00

Initial Supporting table - P0068\_Maximum MAF f(RPM)

**Description:** Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

**Value Units:** Delta MAF Values (dm)  
**X Unit:** Engine Speed (RPM)

y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
1.00	17.90	39.19	63.43	80.91	112.92	138.31	168.70	174.20	176.70

Initial Supporting table - P0068\_Maximum MAF f(Volts)

**Description:** Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.

**Value Units:** Delta MAF Values (dm)  
**X Unit:** System Voltage (V)

y/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00
1.00	6.50	25.00	65.00	140.00	260.00	300.00	300.70	300.70	300.70

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

**Value Units:** Max Time for Last Seed Timeout (ms)

**X Unit:** Operating Loop Sequence (enum)

#### P0606\_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000

#### P0606\_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	500.000	500.000	1,000.000	8,191.875	8,191.875	8,191.875	

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)

**Description:** Fail threshold for PSW per operating loop.

**Value Units:** Fail threshold for PSW (count)

**X Unit:** Operating Loop (enum)

## P0606\_PSW Sequence Fail f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	5	3	5	3	5	3	5

## P0606\_PSW Sequence Fail f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	5	5	5	3	5	5	

## 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - P0606\_PSW Sequence Sample f(Loop Time)

**Description:** Sample threshold for PSW per operating loop.

**Value Units:** Sample threshold for PSW (count)

**X Unit:** Operating Loop (enum)

## P0606\_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	4	4	4	4	4	4	4

## P0606\_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	4	4	4	4	4	4	



Initial Supporting table - P1682\_PT Relay Pull-in Run/Crank Voltage f(IAT)

**Description:** The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

**Value Units:** Run/Crank Voltages required to pull in PT Relay (V)

**X Unit:** Induction Air Temperature (deg C)

y/x	23.0	85.0	95.0	105.0	125.0
1	7.000	8.699	9.000	9.199	10.000

Initial Supporting table - P16F3\_Delta MAP Threshold f(Desired Engine Torque)

**Description:** Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

**Value Units:** Torque Security Threshold for Engine Sync and Time Based Delta Pressure (kPa)

**X Unit:** Desired Engine Torque (Nm)

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	37.45	37.45	37.45	37.45	37.45	37.45

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P16F3\_Speed Control External Load f(Oil Temp, RPM)

**Description:** Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

**Value Units:** External Load Table for SPDR (Nm)

**X Unit:** Engine Oil Temperature (deg C)

**Y Units:** Engine Speed (RPM)

y/x	-40.00	-20.00	-10.00	0.00	50.00	90.00
350.00	119.10	111.32	129.68	148.10	122.93	60.93
450.00	119.10	111.32	129.68	148.10	122.93	60.93
550.00	119.10	111.32	129.68	148.10	122.93	60.93
650.00	119.10	111.32	129.68	148.10	122.93	60.93
750.00	124.75	116.77	134.90	153.10	126.69	60.89
850.00	135.36	127.11	145.14	163.40	136.31	63.06
900.00	140.12	131.53	148.51	165.97	140.13	64.35
1,000.00	153.47	144.72	162.51	180.69	152.87	63.29
1,100.00	163.63	154.76	172.68	190.87	161.49	71.39
1,200.00	171.40	161.25	178.45	196.51	166.54	81.09
1,450.00	155.27	145.52	160.09	175.16	144.79	82.71
1,700.00	80.96	71.66	65.03	58.84	41.18	34.59
1,950.00	58.07	49.06	42.79	36.92	20.47	14.60
2,200.00	37.31	28.52	22.53	16.89	1.37	-3.94
3,200.00	-65.23	-65.23	-65.23	-65.23	-65.23	-65.23
4,200.00	-71.76	-71.76	-71.76	-71.76	-71.76	-71.76
6,400.00	-78.28	-78.28	-78.28	-78.28	-78.28	-78.28

# 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - RufCyl\_Decel

**Description:** Used for P0300-P0308. Crankshaft decel threshold during Idle or GPF regen. Thresholds are a function of rpm and % engine Load.

**Value Units:** Delta time per cylinder (usec)

**X Unit:** rpm

**Y Units:** percent load of max indicated torque (%)

### RufCyl\_Decel - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	6,000	5,000	3,000	1,800	1,200	750	550	400	300	225	135	100	85
6	6,500	5,000	3,000	1,800	1,200	775	550	400	300	250	145	100	85
8	7,000	5,000	3,000	1,800	1,200	825	565	400	335	275	160	110	85
10	8,000	5,335	3,000	1,800	1,200	905	625	450	365	300	175	125	90
12	9,000	5,870	3,130	1,950	1,280	988	683	500	400	325	195	145	95
14	10,000	6,620	3,510	2,150	1,415	1,125	825	600	480	350	225	165	105
16	11,000	7,370	4,085	2,535	1,635	1,320	985	750	590	375	260	185	115
18	12,000	8,120	4,550	2,915	1,850	1,538	1,145	900	700	450	290	205	125
20	13,000	8,880	5,040	3,300	2,130	1,758	1,338	1,050	805	525	335	225	140
22	14,000	9,630	5,530	3,685	2,405	1,975	1,515	1,200	910	600	380	245	155
24	15,000	10,380	6,010	4,065	2,680	2,193	1,693	1,345	1,020	675	430	265	170
26	16,000	11,130	6,500	4,450	2,958	2,413	1,870	1,480	1,130	775	480	290	185
28	17,000	11,885	6,990	4,833	3,235	2,632	2,049	1,615	1,240	885	528	315	200
30	18,000	12,640	7,480	5,215	3,513	2,850	2,228	1,750	1,350	960	575	340	215
32	18,400	13,392	7,966	5,597	3,789	3,068	2,406	1,884	1,458	1,035	623	363	230
34	18,800	14,144	8,452	5,979	4,066	3,286	2,584	2,018	1,566	1,110	671	386	245
36	19,200	14,896	8,938	6,361	4,342	3,504	2,762	2,152	1,674	1,185	719	409	260

### RufCyl\_Decel - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
3	60	48	35	25	20	16	11	9	9	8	8	7	6
6	60	45	35	27	23	17	12	9	8	8	7	7	6
8	65	45	40	29	25	18	12	9	8	7	7	6	6
10	70	50	45	33	28	20	13	10	8	7	7	6	6
12	75	55	50	39	34	24	14	11	8	7	7	6	6
14	83	63	55	44	39	28	16	13	9	8	7	6	6
16	90	70	60	49	44	33	19	15	11	8	7	6	6
18	100	78	67	55	50	37	23	18	13	9	8	6	6
20	110	85	74	60	55	42	26	20	14	10	8	6	6
22	122	95	83	67	61	46	29	22	16	11	9	6	6
24	134	105	90	73	66	51	32	24	18	13	10	6	6

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - RufCyl\_Decel

26	145	115	100	80	72	55	36	27	20	14	11	7	6
28	158	125	108	87	77	60	39	29	22	16	13	8	7
30	170	135	115	93	82	64	42	31	23	17	14	8	7
32	182	145	124	101	88	68	46	34	25	18	15	9	8
34	194	154	133	108	93	73	49	36	27	19	16	10	8
36	205	164	142	115	99	77	52	38	29	21	17	11	8

# 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - RufCyl\_Jerk

**Description:** Crankshaft jerk threshold during Idle or GPF regen. Thresholds are a function of rpm and % engine Load.

**Value Units:** Delta time per cylinder (usec)

**X Unit:** rpm

**Y Units:** percent load of max indicated torque (%)

### RufCyl\_Jerk - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	8,000	5,220	3,125	2,000	1,400	900	700	500	400	250	175	125	100
6	10,480	7,150	3,850	2,400	1,840	1,165	831	550	475	250	190	130	100
8	13,000	9,490	4,660	3,420	2,175	1,435	1,087	800	535	305	220	145	100
10	17,000	11,870	5,530	4,315	2,675	1,785	1,400	1,000	600	375	300	200	140
12	20,000	14,250	7,615	5,260	3,350	2,320	1,800	1,200	795	400	350	260	175
14	20,000	16,630	9,790	6,200	4,250	2,860	2,200	1,400	900	400	375	315	215
16	20,000	19,010	11,920	7,560	4,980	3,390	2,550	1,600	1,000	400	400	370	250
18	20,000	20,000	13,530	8,590	5,755	3,930	2,900	1,800	1,200	500	500	425	285
20	20,000	20,000	15,145	9,630	6,450	4,470	3,250	2,000	1,500	650	600	480	320
22	20,000	20,000	16,760	10,660	7,140	5,000	3,750	2,500	1,800	900	750	540	350
24	20,000	20,000	18,370	11,700	7,830	5,540	4,250	3,000	2,230	1,200	880	595	390
26	20,000	20,000	20,000	12,730	8,520	6,080	4,780	3,600	2,470	1,385	965	650	425
28	20,000	20,000	20,000	13,765	9,210	6,615	5,185	3,950	2,708	1,525	1,048	708	463
30	20,000	20,000	20,000	14,800	9,900	7,150	5,590	4,260	2,945	1,665	1,130	765	500
32	20,000	20,000	20,000	15,835	10,592	7,688	5,997	4,570	3,184	1,803	1,212	821	535
34	20,000	20,000	20,000	16,870	11,284	8,226	6,404	4,880	3,423	1,941	1,294	877	570
36	20,000	20,000	20,000	17,905	11,976	8,764	6,811	5,190	3,662	2,079	1,376	933	605

### RufCyl\_Jerk - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
3	75	60	45	35	30	25	16	10	8	8	7	7	6
6	77	60	45	40	30	20	14	10	8	8	7	7	6
8	85	60	50	45	34	22	16	12	10	8	8	6	6
10	97	75	60	55	43	26	18	14	12	10	9	6	6
12	122	94	70	64	53	29	20	17	13	11	10	7	7
14	148	112	79	74	61	32	22	19	15	13	11	8	8
16	174	130	89	84	71	38	24	20	17	14	13	9	9
18	200	148	104	96	80	45	25	21	18	16	14	10	10
20	225	166	119	108	90	52	29	23	20	17	15	11	11
22	251	184	135	120	100	59	33	25	21	18	16	13	12
24	277	202	150	132	110	66	39	27	23	20	18	14	13

## 20 OBDG03A ECM Supporting Tables

Initial Supporting table - RufCyl\_Jerk

26	303	220	165	143	120	73	45	31	25	21	19	15	14
28	329	238	181	158	130	80	53	34	27	23	21	16	15
30	354	256	196	172	139	87	60	38	29	24	22	17	15
32	380	274	211	184	149	94	65	41	31	26	23	18	16
34	406	292	227	196	159	101	69	45	34	27	24	19	17
36	432	311	242	208	169	108	74	49	37	28	25	20	18

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - RufSCD\_Decel

**Description:** Used for P0300-P0308. Crankshaft decel threshold while in SCD mode during Idle or GPF regen. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load. Note: Misfire's Load term is %, but not PID\$04. PID \$04 is not robust to temperature and altitude shifts. (especially decel and jerk thresholds since they track actual air trapped in cylinder)

**Value Units:** Delta time per cylinder (usec)

**X Unit:** rpm

**Y Units:** percent load of max indicated torque (%)

#### RufSCD\_Decel - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

#### RufSCD\_Decel - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767



## 20 OBDG03A ECM Supporting Tables

Initial Supporting table - RufSCD\_Decel

22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

# 20 OBDG03A ECM Supporting Tables

## Initial Supporting table - RufSCD\_Jerk

**Description:** Used for P0300-P0308. Crankshaft jerk threshold while in SCD mode during Idle or GPF regen. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

**Value Units:** Delta time per cylinder (usec)

**X Unit:** rpm

**Y Units:** percent load of max indicated torque (%)

### RufSCD\_Jerk - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

### RufSCD\_Jerk - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

## 20 OBDG03A ECM Supporting Tables

Initial Supporting table - RufSCD\_Jerk

24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

Initial Supporting table - P0324\_PerCyl\_ExcessiveKnock\_Threshold

**Description:** Fail threshold for the Knock Performance per-cylinder Excessive Knock Diagnostic

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	1.69	1.69	1.69	1.69	1.69	1.69	1.69	1.69	1.69	1.69	1.69	1.69	1.69	1.69	1.69	1.69	1.69

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P0325_P0330_OpenCktThrshMax (20 kHz)																	
Description: Knock Open Circuit Diagnostic Maximum Threshold when using the 20 kHz method (see "OpenMethod" description)																	
y/x	750	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	8.0703	8.5195	8.5078	8.4121	8.4160	8.3320	8.4141	8.4141	8.7715	8.2207	8.0234	7.6289	7.2500	7.2500	7.2500	7.2500	7.2500

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0325\_P0330\_OpenCktThrshMax (Normal Noise)

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

y/x	2,700	2,900	3,000	3,250	3,500	3,750	4,000	4,250	4,500	4,750	5,000	5,500	6,000	6,500	7,000	7,500	8,500
1	0.4980	0.4980	0.4980	0.4980	0.4980	0.4570	0.4160	0.4082	0.4004	0.3477	0.2949	0.2441	0.2520	0.2109	0.2109	0.2109	0.2109

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0325\_P0330\_OpenCktThrshMin (20 kHz)

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the 20 kHz method (see "OpenMethod" description)

y/x	750	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	2.8887	3.0430	3.0410	2.9941	2.9902	2.9648	2.9961	2.9980	3.1523	2.9336	2.8887	2.7480	2.6309	2.6309	2.6309	2.6309	2.6309

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0325\_P0330\_OpenCktThrshMin (Normal Noise)

**Description:** Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

y/x	2,700	2,900	3,000	3,250	3,500	3,750	4,000	4,250	4,500	4,750	5,000	5,500	6,000	6,500	7,000	7,500	8,500
1	0.1621	0.1621	0.1621	0.1621	0.1621	0.1543	0.1465	0.1406	0.1328	0.1172	0.0996	0.0840	0.0879	0.0781	0.0781	0.0781	0.0781



## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P0325\_P0330\_OpenMethod\_2

**Description:** Defines which Knock Open Circuit Diagnostic method to use.

#### P0325\_P0330\_OpenMethod\_2 - Part 1

y/x	0	1	2	3	4
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz

#### P0325\_P0330\_OpenMethod\_2 - Part 2

y/x	5	6	7	8	9
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_None	CeKNKD_e_Open_None

#### P0325\_P0330\_OpenMethod\_2 - Part 3

y/x	10	11	12	13	14
1	CeKNKD_e_Open_NormalNoise	CeKNKD_e_Open_NormalNoise	CeKNKD_e_Open_NormalNoise	CeKNKD_e_Open_NormalNoise	CeKNKD_e_Open_NormalNoise

#### P0325\_P0330\_OpenMethod\_2 - Part 4

y/x	15	16			
1	CeKNKD_e_Open_NormalNoise	CeKNKD_e_Open_NormalNoise			

Initial Supporting table - P0326\_P0331\_AbnormalNoise\_CylsEnabled

**Description:** Specifies which cylinders will be used for the Abnormal Noise portion of the performance diagnostics (1 = cylinder used, 0 = cylinder not used)

y/x	0	1	2	3	4	5	6	7
1	1	1	1	1	0	0	0	0

Initial Supporting table - P0326\_P0331\_AbnormalNoise\_Threshold

**Description:** Fail threshold for the Knock Performance Abnormal Noise Diagnostic when engine is NOT in AFM mode

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.881	0.721	0.590	0.483	0.396	0.324	0.266	0.217	0.178	0.146	0.119	0.098	0.080	0.065	0.054	0.044	0.036

20 OBDG03A ECM Supporting Tables

Initial Supporting table - P06B6\_P06B7\_OpenTestCktThrshMax

**Description:** Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

y/x	750	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.209	0.209	0.215	0.215	0.232	0.232	0.232	0.271	0.305	0.367	0.588	0.576	0.592	0.592	0.592	0.592	0.592

## 20 OBDG03A ECM Supporting Tables

### Initial Supporting table - P06B6\_P06B7\_OpenTestCktThrshMin

**Description:** Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

y/x	750	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.102	0.102	0.104	0.104	0.115	0.115	0.115	0.139	0.154	0.191	0.320	0.311	0.322	0.322	0.322	0.322	0.322

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Sensor Not Plausible	P111E	This DTC detects either a biased high or low ECT (Engine Coolant temperature) sensor. This is done by comparing the ECT sensor output to two other temperature sensor outputs after a soak condition.	<b>Sensor usage definitions:</b>  <b>Sensor1 =</b> CeECTR_e_ECT_Snsr  (Sensor1 is the temp sensor most impacted by the block heater (if equipped))  <b>Sensor2 =</b> CeECTR_e_RCT_Snsr  <b>Sensor3 =</b> CeECTR_e_OAT_Snsr  ===== <p>A failure will be reported if any of the following occur:  1) Sensor1 power up absolute temp difference to Sensor2 and Sensor3 is  (Sensor1 fast fail) .</p> <p>2) Sensor1 power up temp is greater than Sensor2 and Sensor3 in this range:  (and a block heater has not been detected)</p> <p>3) Sensor1 power up temp is lower than Sensor2 and Sensor3 by this amount:</p> <p>4) Sensor1 power up temp is ≥ Sensor2 and</p>	≥ 25.0 °C          ≥ 15.0 and < 25.0 °C          ≤ 15.0 Deg °C	No Active DTC's          Engine Off Soak Time Propulsion Off Soak Time Non-volatile memory initialization  Test complete this trip Test aborted this trip Test disabled this trip Ambient  LowFuelCondition Diag  ===== Block Heater detection is <b>enabled</b> when either of the following occurs:  1) Sensor1 power up temp is greater than Sensor2 and Sensor3 in this range:  2) Cranking time  =====	VehicleSpeedSensor_FA IAT_SensorCircuitFA THMR_RCT_Sensor_Ckt_FA ECT_Sensor_Ckt_FA EngineModeNotRunTimerError EngineModeNotRunTimer_FA OAT_PtEstFiltFA OAT_PtEstRawFA PSAR_PropSysInactiveCr_s_FA DRER_DiagSystemDsbl  > 28,800 seconds > 28,800 seconds  = Not occurred  = False = False = False ≥ -9 °C  = False  =====  ≥ 15.0 °C and < 25.0 °C  < 14.0 Seconds  =====	1 failure to set DTC  1 sec/ sample  Once per valid cold start	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Ignition Switch Run/ Start Position Circuit High	B2B0E	This DTC monitors for a CGM Ignition Switch Run/Start Position Circuit High error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the CGM Ignition Switch Run/Start Position Circuit High DTC has set in the CGM.		General Enable Criteria:  Message \$3CF  Central Gateway Module	  is being received  is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Ignition Switch Run/ Start Position Circuit High	B2B0E	This DTC monitors for a CGM Ignition Switch Run/Start Position Circuit High error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the CGM Ignition Switch Run/Start Position Circuit High DTC has set in the CGM.		General Enable Criteria:  Message \$3CF  Central Gateway Module	  is being received  is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips



## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Ignition Switch Run/ Start Position Circuit High	B2B0E	This DTC monitors for a CGM Ignition Switch Run/Start Position Circuit High error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the CGM Ignition Switch Run/Start Position Circuit High DTC has set in the CGM.		General Enable Criteria:  Message \$3CF  Central Gateway Module	  is being received  is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Ignition Switch Run/ Start Position Circuit High	B2B0E	This DTC monitors for a CGM Ignition Switch Run/Start Position Circuit High error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the CGM Ignition Switch Run/Start Position Circuit High DTC has set in the CGM.		General Enable Criteria:  Message \$3CF  Central Gateway Module	  is being received  is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Ignition Switch Run/ Start Position Circuit High	B2B0E	This DTC monitors for a CGM Ignition Switch Run/Start Position Circuit High error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the CGM Ignition Switch Run/Start Position Circuit High DTC has set in the CGM.		General Enable Criteria:  Message \$3CF  Central Gateway Module	  is being received  is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Sensor3 by 15.0 °C and the time spent cranking the engine without starting is ≥ 14.0 seconds with the LowFuelConditionDiag	= False	<p>Block Heater is <b>detected</b> and diagnostic is aborted when 1) or 2) occurs.</p> <p>1a) IAT monitoring is enabled after the following Vehicle drive constraints</p> <p>1b) Drive time</p> <p>1c) Vehicle speed</p> <p>1d) Additional Vehicle drive time is provided to 1b when Vehicle speed is below 1c as follows:</p> <p>1e) IAT drops from power up IAT</p> <p>2a) ECT monitoring is enabled after engine start in the following engine run time window</p> <p>2b) Sensor1 temp derivative during the test is:</p> <p>2c) Consecutive samples of 2b) being true are:</p> <p>=====</p> <p>Diagnostic is <b>aborted</b> when 3) or 4) occurs:</p> <p>3) Engine run time with vehicle speed below 1b</p> <p>4) Engine off time (i.e. auto stop) during Block heater detection</p>	<p>&gt; 400 Seconds with</p> <p>&gt; 12.4 MPH and</p> <p>0.00 times the seconds with vehicle speed below 1b</p> <p>≥ 8.0 °C</p> <p>10.0 &lt;= seconds &lt;= 15.0</p> <p>&lt; -0.50 °C/sec</p> <p>≥ 10 samples</p> <p>=====</p> <p>≥ 1,370 Seconds</p> <p>≥ 300.0 Seconds</p>		

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switches Primary Signal Message Counter Incorrect	P187F	Detects error on ARC & PV reported by ECM about signal \$1E4 from TRS on PT Sensor Bus from SIB (Shifter Buttons)	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1  OR  The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1      Primary Value ≠ Protection Value	Battery voltage  AND  A diagnostic code clear event or diagnostic re- enable event is not in progress for:	within proper operating range for 3,000 msec     for a time > 3,000 msec	8 failures out of 10 samples  Signal received in 25 ms message	DTC Type B  Two Trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switches Secondary Signal Message Counter Incorrect	P188A	Detects error on ARC & PV reported by ECM about signal \$2C2 from TRS on PT Exp Bus	The current alive rolling count value does not equal the previous alive rolling count value incremented by 1  OR  The primary signal value does not equal the protection value	Current ARC ≠ Previous ARC +1       Primary Value ≠ Protection Value	Battery voltage   A diagnostic code clear event or diagnostic re- enable event is not in progress for:	within proper operating range for 3 seconds     for a time > 3,000 msec	8 failures out of 10 samples  Signal received in 50 ms message.	DTC Type B  Two Trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switch "A" Circuit Correlation	P18CD	Compares Switch "A" with other relevant TRS Switches Switch "A" = Drive Input 1	Valid switch status "pressed" or "released", but disagree		Not Fault Active	P17E3, P17E4, P17E5	0 failures out of 0 samples  12.5 ms loop	DTC Type B  Two trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switch "B" Circuit Correlation	P18CF	Compares Switch "B" with other relevant TRS Switches Switch "B" = Drive Input 2	Valid switch status "pressed" or "released", but disagree		Not Fault Active	P17E6, P17E7, P17E8	0 failures out of 0 samples  12.5 ms loop	DTC Type B  Two trips



## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switch "C" Circuit Correlation	P18D1	Compares Switch "C" with other relevant TRS Switches Switch "C" = Drive Input 3	Valid switch status "pressed" or "released", but disagree		Not Fault Active	P17E9, P17EA, P17EB	0 failures out of 0 samples  12.5 ms loop	DTC Type B  Two trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switch "D" Circuit Correlation	P18D3	Compares Switch "D" with other relevant TRS Switches Switch "D" = Neutral Input 1	Valid switch status "pressed" or "released", but disagree		Not Fault Active	P17EC, P17ED, P17EE	0 failures out of 0 samples  12.5 ms loop	DTC Type B  Two trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switch "E" Circuit Correlation	P18D5	Compares Switch "E" with other relevant TRS Switches Switch "E" = Neutral Input 2	Valid switch status "pressed" or "released", but disagree		Not Fault Active	P17EF, P17F0, P17F8	0 failures out of 0 samples  12.5 ms loop	DTC Type B  Two trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switch "F" Circuit Correlation	P18D7	Compares Switch "F" with other relevant TRS Switches Switch "F" = Neutral Input 3	Valid switch status "pressed" or "released", but disagree		Not Fault Active	P17F9, P17FD, P17FE	0 failures out of 0 samples  12.5 ms loop	DTC Type B  Two trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switch "G" Circuit Correlation	P18D9	Compares Switch "G" with other relevant TRS Switches Switch "G" = Reverse Input 1	Valid switch status "pressed" or "released", but disagree		Not Fault Active	P1803, P1805, P1806	0 failures out of 0 samples  12.5 ms loop	DTC Type B  Two trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switch "H" Circuit Correlation	P18DB	Compares Switch "H" with other relevant TRS Switches Switch "H" = Reverse Input 2	Valid switch status "pressed" or "released", but disagree		Not Fault Active	P1807, P180C, P180D	0 failures out of 0 samples  12.5 ms loop	DTC Type B  Two trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switch "J" Circuit Correlation	P18DD	Compares Switch "J" with other relevant TRS Switches Switch "J" = Reverse Input 3	Valid switch status "pressed" or "released", but disagree		Not Fault Active	P180E, P180F, P1812	0 failures out of 0 samples  12.5 ms loop	DTC Type B  Two trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switch "L" Stuck On	P18E1	Detects TRC Switch "L" is stuck on. Switch "L" = Manual/ Low Input	Valid switch status "pressed" for a longer than expected time.		Not Fault Active	P186B, P186C, P186D	0 failures out of 0 samples  12.5 ms loop	DTC Type B  Two trips



## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switches A- B-C Stuck On	P18E9	Detects when TRS Switches A, B and C are stuck on A, B, C are Drive Button switches	Valid switches "PRESSED" for extended time		Not Fault Active	P17E3, P17E4, P17E5, P17E6, P17E7, P17E8, P17E9, P17EA, P17EB	0 failures out of 0 samples  12.5 ms rate	DTC Type B  Two trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switches D- E-F Stuck On	P18EA	Detects when TRS Switches D, E and F are stuck on D, E, F are Neutral Button switches	Valid switches "PRESSED" for extended time		Not Fault Active	P17EC, P17ED, P17EE, P17EF, P17F0, P17F8, P17F9, P17FD, P17FE	0 failures out of 0 samples  12.5 ms rate	DTC Type B  Two trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Selector Switches G- H-J Stuck On	P18EB	Detects when TRS Switches G, H and J are stuck on G, H, J are Reverse Button switches	Valid switches "PRESSED" for extended time		Not Fault Active	P1803, P1805, P1806, P1807, P180C, P180D, P186B, P186C, P186D	0 failures out of 0 samples  12.5 ms rate	DTC Type B  Two trips

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Injection Pulse Performance	P2B95	Monitors injector pulses when the cold start emission reduction strategy is active by accumulating and determining the percentage of engine cycles that missed a pulse relative to the total number of pulses when multi pulse is active.	<p>Injector voltage feedback is not able to detect an opening magnitude on any pulse for any cylinder</p> <p>Or</p> <p>Measured Voltage feedback converted to Injector Opening Magnitude on any pulse for any cylinder</p>	<p>=&lt;</p> <p><b>P2B96 - Opening Magnitude Missing Pulse Fail Limit</b></p> <p>(See supporting table)</p>	<p>Small Pulse General Diagnostic Enable (See Definition in Supporting Material below)</p> <p>Fuel Pulse Voltage Feedback Data Ready (See Definition in Supporting Material below)</p> <p>OBD Manufacturer Enable Counter</p> <p>To enable the diagnostic, the Cold Start Emission Reduction Strategy Must Be Active per the following:</p> <p>Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure</p> <p>In addition, Multi Pulse Strategy Is Enabled and Active Per the following:</p> <p>Engine Speed</p> <p>Accel Position</p> <p>Engine Run Time</p>	<p>= True</p> <p>= True</p> <p>= 0</p> <p>&lt; 350.00 degC &gt; -12.00 degC &lt;= 66.00 degC &gt;= 72.00 KPa</p> <p>&gt;= 450.00 RPM &lt;= 2,200.00 RPM</p> <p>&lt;= 110.00 Pct</p> <p>&lt; 30 seconds</p>	<p>Runs once per trip when the cold start emission reduction strategy is active and Dual Pulse is enabled and active.</p> <p>Frequency: 100ms</p> <p>Test completes after Dual Pulse is no longer active OR The first 500 engine cycles have been reached</p>	Type X, No MIL

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:</p> <p>Catalyst Temperature AND Engine Run Time</p> <p>OR</p> <p>Engine Run Time</p> <p>OR</p> <p>Barometric Pressure</p> <p>Multi Pulse Strategy will exit per the following:</p> <p>Engine Speed OR Accel Position</p> <p>Engine Run Time</p>	<p>&gt;= 900.00 degC</p> <p>&gt;= 30.00 seconds</p> <p>&gt;</p> <p><b>P050D_P1400_CatalystLightOffExtendedEngineRunTimeExit</b></p> <p>This Extended Engine run time exit table is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.</p> <p>&lt; 72.00 KPa</p> <p>&gt; 2,400.00 RPM</p> <p>&gt; 110.00 Pct</p> <p>&gt;= 30 seconds</p>		

## 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Mult Pulse Strategy will also exit if the any of the "Additional Dual Pulse Enabling Criteria" is not satisfied:</p> <p>"Additional Multi Pulse Enabling Criteria":</p> <p>Green Engine Enrichment</p> <p>Misfire Converter Protection strategy</p> <p>Engine Metal Overtemp strategy</p> <p>Fuel control state</p> <p>Output State Control</p> <p>DOD Or DFCO</p> <p>Power Enrichment</p> <p>Dynamic Power Enrichment</p> <p>Piston Protection</p> <p>Hot Coolant Enrichment</p> <p>Injector Flow Test</p> <p>General Enable</p> <p>DTC's Not Set:</p>	<p>Not Enabled</p> <p>Not being requested</p> <p>Not being requested</p> <p>Open Loop</p> <p>Not being requested for fuel</p> <p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>Not Active</p> <p>AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFA CrankSensor_FA</p>		

# 20 OBDG03A ECM Summary Tables (California)

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA AnyCamPhaser_TFTKO ClutchPstnSnsr_FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA FuelInjectorCircuit_TFTK O FHPR_b_FRP_SnsrCkt_F A FHPR_b_FRP_SnsrCkt_T FTKO FHPR_b_PumpCkt_FA FHPR_b_PumpCkt_TFTK O TransmissionEngagedStat e_FA EngineTorqueEstInaccura te FuelPumpRlyCktFA		

## ECM Summary Tables (California) 27 of 27

842 of 1,779



## DIAGNOSTIC SUMMARY TABLES -- ECM

**Description:** Exit Catalyst Warm-up mode if Engine Run Time is greater than this value. This table is based on percent ethanol (x-axis) and catmon's NormRatio\_EWMA value (y-axis). The NormRatio\_EWMA value determines the state of the catalyst. Typically, NormRatio\_EWMA values below 0.35 (0 is bad and 1 is good) represent catalysts that have degraded. The emission performance of these degraded catalysts can be improved by extending catalyst light off of GetE85R\_Pct\_FFS\_CompAtEngFloat.

y/x	0	25	50	75	100
0.000	30	30	30	30	30
0.125	30	30	30	30	30
0.250	30	30	30	30	30
0.375	30	30	30	30	30
0.500	30	30	30	30	30
0.625	30	30	30	30	30
0.750	30	30	30	30	30
0.875	30	30	30	30	30
1.000	30	30	30	30	30

DIAGNOSTIC SUMMARY TABLES -- ECM

**Description:** Opening Magnitude threshold to detect missing injection pulse

**Value Units:** Opening Magnitude Voltage

**X Unit:** Measured Fuel Rail Pressure

y/x	0	1	2	3	4	5	6	7	8	9	10	12	14	16	18	19	20
1	10	10	10	10	10	10	10	10	10	10	10	10	10	10	10	10	10

DIAGNOSTIC SUMMARY TABLES -- ECM

**Description:** Opening Magnitude threshold to detect missing injection pulse

**Value Units:** Opening Magnitude Voltage

**X Unit:** Measured Fuel Rail Pressure

y/x	0.40	1.00	2.00	3.00	4.00	5.00	6.00	7.00	8.00	9.00	10.00	12.00	14.00	16.00	18.00	19.00	20.00
1.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00	10.00

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lateral Acceleration Sensor Circuit Low	C124F	Controller specific analog circuit diagnoses the raw lateral acceleration signal for a short to ground or open fault by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral acceleration signal = 0.0 g.	raw lateral acceleration signal when sensor type is directly proportional OR raw lateral acceleration signal when sensor type is inversely proportional  update raw lateral acceleration signal stability time, fail and sample time, 50 millisecond update rate	$\leq -3.8500 \text{ g}$  $\geq -3.8500 \text{ g}$  ( $\leq 0.5 \Omega$ impedance between signal and controller ground)	battery voltage run crank voltage diagnostic monitor enable  sensor type is either directly proportional or inversely proportional  U0073 fault active U0073 test fail this key on	$\geq 11.00 \text{ volts}$ $\geq 11.00 \text{ volts}$ = 1 Boolean  = CeLATR_e_VoltageDirec tProp  = FALSE = FALSE	raw lateral acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lateral Acceleration Sensor Circuit High	C1250	Controller specific analog circuit diagnoses the raw lateral acceleration signal for a short to power or open fault by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral acceleration signal = 0.0 g.	raw lateral acceleration signal when sensor type is directly proportional OR raw lateral acceleration signal when sensor type is inversely proportional  update raw lateral acceleration signal stability time, fail and sample time, 50 millisecond update rate	$\geq 3.8500 \text{ g}$  $\leq 3.8500 \text{ g}$  ( $\leq 0.5 \Omega$ impedance between signal and controller power)	battery voltage run crank voltage diagnostic monitor enable  sensor type is either directly proportional or inversely proportional  U0073 fault active U0073 test fail this key on	$\geq 11.00 \text{ volts}$ $\geq 11.00 \text{ volts}$ = 1 Boolean  = CeLATR_e_VoltageDirec tProp  = FALSE = FALSE	raw lateral acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lateral Acceleration Sensor Performance	C1251	Controller specific analog circuit diagnoses the raw lateral acceleration signal for a signal value that is stuck in a valid range by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral acceleration signal = 0.0 g.	ABS(raw lateral acceleration signal) AND ABS(raw lateral acceleration signal)  update raw lateral acceleration signal fail, 50 millisecond update rate	$\geq 0.5000 \text{ g}$  $\leq 3.8500 \text{ g}$	battery voltage run crank voltage diagnostic monitor enable  update raw lateral acceleration signal stability time: TOSS vehicle speed automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable diagnotic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear attained gear slip  ABS(raw lateral acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	$\geq 11.00 \text{ volts}$ $\geq 11.00 \text{ volts}$ = 1 Boolean   $\geq 15.0 \text{ KPH}$ = TRUE  = TRUE = TRUE = FALSE  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1st thru 10th $\leq 100.0 \text{ RPM}$  $< 0.5000 \text{ g}$  = FALSE = FALSE VehicleSpeedSensor_FA	raw lateral acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Longitudinal Acceleration Sensor Circuit Low	C1252	Controller specific analog circuit diagnoses the raw longitudinal acceleration signal for a short to ground or open fault by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral longitudinal acceleration signal = 0.0 g.	raw longitudinal acceleration signal when sensor type is directly proportional OR raw longitudinal acceleration signal when sensor type is inversely proportional  update raw longitudinal acceleration signal stability time, fail and sample time, 50 millisecond update rate	$\leq -3.8500$ g  $\geq -3.8500$ g  ( $\leq 0.5 \Omega$ impedance between signal and controller ground)	battery voltage run crank voltage diagnostic monitor enable  sensor type is either directly proportional or inversely proportional  U0073 fault active U0073 test fail this key on	$\geq 11.00$ volts $\geq 11.00$ volts = 1 Boolean  = CeLATR_e_VoltageDirec tProp  = FALSE = FALSE	raw longitudinal acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Longitudinal Acceleration Sensor Circuit High	C1253	Controller specific analog circuit diagnoses the raw longitudinal acceleration signal for a short to power or open fault by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral longitudinal acceleration signal = 0.0 g.	raw longitudinal acceleration signal when sensor type is directly proportional OR raw longitudinal acceleration signal when sensor type is inversely proportional  update raw longitudinal acceleration signal stability time, fail and sample time, 50 millisecond update rate	$\geq 3.8500 \text{ g}$  $\leq 3.8500 \text{ g}$  ( $\leq 0.5 \Omega$ impedance between signal and controller power)	battery voltage run crank voltage diagnostic monitor enable  sensor type is either directly proportional or inversely proportional  U0073 fault active U0073 test fail this key on	$\geq 11.00 \text{ volts}$ $\geq 11.00 \text{ volts}$ = 1 Boolean  = CeLATR_e_VoltageDirec tProp  = FALSE = FALSE	raw longitudinal acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Longitudinal Acceleration Sensor Performance	C1254	<p>Controller specific analog circuit diagnoses the raw longitudinal acceleration signal rationalized against the TOSS vehicle speed acceleration. The diagnostic monitor can be designed to detect an invalid longitudinal acceleration signal based on the TOSS vehicle speed windows and TOSS vehicle speed acceleration, 4 windows can be enabled. The delta between the TOSS vehicle speed acceleration and longitudinal acceleration signal is taken within each window to verify the delta is small, no failure indicated, or the delta is large indicating the longitudinal acceleration signal is in error.</p> <p>Emission neutral default state sets lateral longitudinal acceleration signal = 0.0 g.</p>	<p>ABS(TOSS vehicle speed acceleration - raw longitudinal acceleration signal)</p> <p>update raw longitudinal acceleration signal region 1 fail time, 50 millisecond update rate</p>	≥ 0.5300 g	<p>battery voltage run crank voltage diagnostic monitor enable region 1 specific enable</p> <p>update raw lateral longitudinal acceleration signal stability time: TOSS vehicle speed TOSS vehicle speed acceleration automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable diagnsotic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear attained gear slip ABS(raw longitudinal acceleration signal) AND ABS(raw longitudinal acceleration signal)</p> <p>update region 1 sample time: brake pedal position engine torque TOSS vehicle speed acceleration TOSS vehicle speed TOSS vehicle speed</p>	<p>≥ 11.00 volts ≥ 11.00 volts = 1 Boolean = 0 Boolean</p> <p>≥ 15.0 KPH ≤ 0.5300 g</p> <p>= TRUE</p> <p>= TRUE = TRUE = FALSE</p> <p>= FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE</p> <p>= 1st thru 10th ≤ 100.0 RPM ≥ 0.5300 g</p> <p>≤ 3.8500 g</p> <p>≤ 0.70 % ≥ 80.0 Nm ≥ 0.1500 g ≥ 15.0 KPH ≤ 200.0 KPH</p>	<p>raw lateral longitudinal acceleration signal stability time ≥ 10.0 seconds, fail time ≥ 75.0 seconds out of sample time ≥ 120.0 seconds, 50 millisecond update rate</p> <p>region 1 fail time ≥ 75.0 seconds out of region 1 sample time ≥ 120.0 seconds, 50 millisecond update rate</p>	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					ABS(raw longitudinal acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	< 0.5300 g  = FALSE = FALSE VehicleSpeedSensor_FA VehicleSpeedSensorError		
			ABS(TOSS vehicle speed acceleration - raw longitudinal acceleration signal)  update raw longitudinal acceleration signal region 2 fail time, 50 millisecond update rate	≥ 0.0000 g	battery voltage run crank voltage diagnostic monitor enable region 2 specific enable  update raw lateral longitudinal acceleration signal stability time: TOSS vehicle speed TOSS vehicle speed acceleration automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable diagnsotic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear attained gear slip ABS(raw longitudinal acceleration signal) AND ABS(raw longitudinal	≥ 11.00 volts ≥ 11.00 volts = 1 Boolean = 0 Boolean  ≥ 15.0 KPH ≤ 0.5300 g  = TRUE  = TRUE = TRUE = FALSE  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1st thru 10th ≤ 100.0 RPM ≥ 0.5300 g  ≤ 3.8500 g	raw lateral longitudinal acceleration signal stability time ≥ 10.0 seconds, fail time ≥ 75.0 seconds out of sample time ≥ 120.0 seconds, 50 millisecond update rate	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					acceleration signal)  update region 2 sample time: brake pedal position engine torque TOSS vehicle speed acceleration TOSS vehicle speed TOSS vehicle speed  ABS(raw longitudinal acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	≤ 0.70 % ≥ 80.0 Nm ≥ 0.1500 g  ≥ 0.0 KPH ≤ 0.0 KPH  < 0.5300 g  = FALSE = FALSE VehicleSpeedSensor_FA VehicleSpeedSensorError	region 2 fail time ≥ 75.0 seconds out of region 2 sample time ≥ 120.0 seconds, 50 millisecond update rate	
			ABS(TOSS vehicle speed acceleration - raw longitudinal acceleration signal)  update raw longitudinal acceleration signal region 3 fail time, 50 millisecond update rate	≥ 0.0000 g	battery voltage run crank voltage diagnostic monitor enable region 3 specific enable  update raw lateral longitudinal acceleration signal stability time: TOSS vehicle speed TOSS vehicle speed acceleration automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable diagnosis fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on	≥ 11.00 volts ≥ 11.00 volts = 1 Boolean = 0 Boolean  ≥ 15.0 KPH ≤ 0.5300 g  = TRUE  = TRUE = TRUE = FALSE  = FALSE = FALSE = FALSE = FALSE	raw lateral longitudinal acceleration signal stability time ≥ 10.0 seconds, fail time ≥ 75.0 seconds out of sample time ≥ 120.0 seconds, 50 millisecond update rate	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear attained gear slip ABS(raw longitudinal acceleration signal) AND ABS(raw longitudinal acceleration signal)  update region 3 sample time: brake pedal position engine torque ABS(TOSS vehicle speed acceleration) TOSS vehicle speed  ABS(raw longitudinal acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	= FALSE = FALSE = FALSE = FALSE = 1st thru 10th ≤ 100.0 RPM ≥ 0.5300 g  ≤ 3.8500 g  ≤ 0.70 % ≥ 80.0 Nm ≤ 0.1000 g ≥ 0.0 KPH  < 0.5300 g  = FALSE = FALSE VehicleSpeedSensor_FA VehicleSpeedSensorError	region 3 fail time ≥ 75.0 seconds out of region 3 sample time ≥ 120.0 seconds, 50 millisecond update rate	
			ABS(TOSS vehicle speed acceleration - raw longitudinal acceleration signal)  update raw longitudinal acceleration signal region 4 fail time, 50 millisecond update rate	≥ 0.0000 g	battery voltage run crank voltage diagnostic monitor enable region 3 specific enable  update raw lateral longitudinal acceleration signal stability time: TOSS vehicle speed TOSS vehicle speed acceleration automatic transmission is clutch to clutch OR dual	≥ 11.00 volts ≥ 11.00 volts = 1 Boolean = 0 Boolean  ≥ 15.0 KPH ≤ 0.5300 g  = TRUE	raw lateral longitudinal acceleration signal stability time ≥ 10.0 seconds, fail time ≥ 75.0 seconds out of sample time ≥ 120.0 seconds, 50 millisecond update rate	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					clutch high side drive 1 enable high side drive 2 enable diagnsotic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear attained gear slip ABS(raw longitudinal acceleration signal) AND ABS(raw longitudinal acceleration signal)  update region 4 sample time: brake pedal position engine torque TOSS vehicle speed acceleration TOSS vehicle speed TOSS vehicle speed  ABS(raw longitudinal acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	= TRUE = TRUE = FALSE  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1st thru 10th ≤ 100.0 RPM ≥ 0.5300 g  ≤ 3.8500 g   ≤ 0.70 % ≤ 80.0 Nm ≤ 0.1500 g  ≥ 0.0 KPH ≤ 0.0 KPH  < 0.5300 g   = FALSE = FALSE VehicleSpeedSensor_FA VehicleSpeedSensorError	region 4 fail time ≥ 75.0 seconds out of region 4 sample time ≥ 120.0 seconds, 50 millisecond update rate	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage Performance	P0561	Detects a low performing 12V battery system. This diagnostic reports the DTC when the absolute value of the difference between the battery voltage and the run/ crank voltage exceeds a calibrated value.	Run Crank voltage low and high	ABS(Battery voltage - Run Crank voltage) > 3.00	Battery voltage B+ line present = TRUE  Battery voltage low and high diag enable = TRUE  Run Crank voltage	1.00  1.00  Voltage ≥ 5.00 volts	40 failures out of 50 samples  100 ms / sample	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5.00 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
			The Primary Processor's calculated checksum does not match the stored checksum value for a selected subset of the calibrations.	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
			The Secondary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	
				In all cases, the failure count is cleared when controller shuts down				

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the DEC ECU has not been flash programmed with production software and calibration.	controller not flash programmed calibration	= 0 Boolean	controller normal power up initialization, ignition run crank transtions from low to high  service Mode \$04 active during one second loop	= FALSE	at controller power up intitalization one time (one event/ occurance) OR in one second time loop	Type A, 1 Trips



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM Long Term Memory Reset	P0603	This DTC detects an invalid NVM which includes a Static NVM, Perserved NVM, ECC ROM in NVM Flash Region, and Perserved NVM during shut down.	Static NVM region error detected during initialization				Diagnostic runs at controller power up.	Type A, 1 Trips
			Perserved NVM region error detected during initialization				Diagnostic runs at controller power up.	
			ECC ROM fault detected in NVM Flash region				Diagnostic runs at controller power up.	
			ECC ROM Error Count >	3				
			Perserved NVM region error detected during shut down.				Diagnostic runs at controller power down.	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604	Indicates that the ECM has detected a RAM fault. This includes Primary Processor System RAM Fault, Primary Processor Cache RAM Fault, Primary Processor TPU RAM Fault, Primary Processor Update Dual Store RAM Fault, Primary Processor Write Protected RAM Fault, and Secondary Processor RAM Fault. This diagnostic runs continuously.	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips
			Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	3 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.40000 s			When dual store updates occur.	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	65,534 counts			Diagnostic runs continuously (background loop)	
			Indicates that the secondary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault. These include diagnostics done on the SPI Communication as well as a host of diagnostics for both the primary and secondary processors.	Loss or invalid message of SPI communication from the Secondary Processor at initialization detected by the Primary Processor or loss or invalid message of SPI communication from the Secondary Processor after a valid message was received by the Primary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received	Run/Crank voltage  Run/Crank voltage	>= 8.00 Volts or >= 11.00 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent or 10 counts continuous; 100 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	Type A, 1 Trips
			Loss or invalid message of SPI communication from the Primary Processor at initialization detected by the Secondary Processor or loss or invalid message of SPI communication from the Primary Processor after a valid message was received by the Secondary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received			In the secondary processor, 64 / 161 counts intermittent or 0.1875 s continuous; 0.4875 s continuous @ initialization. 12.5 ms /count in the ECM secondary processor	
			Checks for stack over or underflow in secondary processor by looking for corruption of known pattern at stack boundaries. Checks number of stack over/under flow since last powerup reset >=	5		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			MAIN processor is verified by responding to a seed sent from the secondary with a key response to secondary. Checks number of incorrect keys	2 incorrect seeds within 8 messages, 0.2000 seconds		ignition in Run or Crank	150 ms for one seed continually failing	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			received > or Secondary processor has not received a new within time limit					
			Time new seed not received exceeded			always running	0.450 seconds	
			MAIN processor receives seed in wrong order			always running	3 / 17 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the Secondary processor's ALU check			Test is Enabled: 1 (If 0, this test is disabled)	25 ms	
			2 fails in a row in the Secondary processor's configuration register masks versus known good data			Test is Enabled: 1 (If 0, this test is disabled)	12.5 to 25 ms	
			Secondary processor detects an error in the toggling of a hardware discrete line controlled by the MAIN processor: number of discrete changes > = or < = over time window(50ms)	7 17		Test is Enabled: 0 (If 0, this test is disabled)  time from initialization >= 0.5000 seconds	50 ms	
			Software background task first pass time to complete exceeds			Run/Crank voltage > 6.41	35.000 seconds	
			2 fails in a row in the MAIN processor's ALU check			Test is Enabled: 0 CPU 1 enable 1 CPU 2 enable 0 CPU 3 enable 0 CPU 4 enable	25 ms	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						(If 0, this test is disabled)		
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			Test is Enabled: 1 (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	5		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		Test is Enabled: 1 (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM variable, depends on length of time to write flash to RAM	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			MAIN processor DMA transfer from Flash to RAM has 1 failure			Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	
			Safety critical software is not executed in proper order.	>= 1 incorrect sequence.		Test is Enabled: <b>P0606 enable</b> see supporting table	Fail Table, f(Loop Time). See supporting tables: <b>P0606_PSW Sequence Fail f (Loop Time)</b> /  Sample Table, f (Loop Time)See supporting tables: <b>P0606_PSW Sequence Sample f(Loop Time)</b>  counts  50 ms/count in the ECM main processor	
			MAIN processor determines a seed has not changed within a specified time period within the 50ms task.	Previous seed value equals current seed value.		Test is Enabled: 1 (If 0, this test is disabled)	Table, f(Loop Time). See supporting tables: <b>P0606_Last Seed Timeout f (Loop Time)</b>	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Internal Control Module EEPROM Error	P062F	This DTC detects a NVM long term performance. There are two types of diagnostics that run during controller power up. One for HWIO reports that writing to NVM (at shutdown) will not succeed, and the other HWIO reports the assembly calibration integrity check has failed.	HWIO reports that writing to NVM (at shutdown) will not succeed				Diagnostic runs at controller power up.	Type A, 1 Trips
			HWIO reports the assembly calibration integrity check has failed				Diagnostic runs at controller power up.	



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Actuator Supply Voltage Circuit Low	P0658	Controller specific output driver circuit diagnoses the high sided driver circuit for a short to ground failure, or where controller H/W cannot differentiate, diagnoses the high sided driver circuit for a short to ground failure or open circuit failure, when the output is powered on, by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	$\leq 0.5 \Omega$ impedance between signal and controller ground	<p>diagnostic monitor enable high side drive ON service mode \$04 not active service fast learn not active P0658 fault active P0658 test fail this key on</p>	<p>= 1 Boolean = TRUE</p> <p>= FALSE = FALSE</p>	<p>fail count <math>\geq 6</math> counts out of sample count <math>\geq 2,400</math> counts</p> <p>6.25 millisecond update rate</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range (TR) Switch Circuit Low Voltage	P0707	Diagnoses the internal range sensor circuit A and wiring for a ground short circuit fault using controller specific PWM duty cycle measurement thresholds.	<p>when PWM sensor type and PWM voltage direct conditional internal range sensor A PWM duty cycle</p> <p>when PWM sensor type and PWM voltage inverse conditional internal range sensor A PWM duty cycle</p> <p>Increment fail and sample time, update rate 25 milliseconds</p> <p>Controller specific PWM duty cycle thresholds are set to meet the following controller specification for a short to ground.</p>	<p><math>\leq 8.789\%</math> duty cycle</p> <p><math>\geq 8.789\%</math> duty cycle</p> <p><math>\leq 0.5\ \Omega</math> impedance between signal and controller ground</p>	<p>diagnostic monitor enable battery voltage</p> <p>when sensor type is PWM duty cycle direct or inverse conditional for fail threshold is used conditional type check calibration</p>	<p>= 1 Boolean <math>\geq 9.00</math> volts</p> <p>= CeTRGD_e_VoltDirctProp</p>	<p>fail time <math>\geq 0.500</math> seconds out of sample time <math>\geq 1.500</math> seconds</p> <p>battery voltage time <math>\geq 1.000</math> seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range (TR) Switch Circuit High Voltage	P0708	Diagnoses the internal range sensor circuit A and wiring for a short to voltage circuit fault using controller specific PWM duty cycle measurement thresholds.	<p>when PWM sensor type and PWM voltage direct conditional internal range sensor A PWM duty cycle</p> <p>when PWM sensor type and PWM voltage inverse conditional internal range sensor A PWM duty cycle</p> <p>Increment fail and sample time, update rate 25 milliseconds</p> <p>Controller specific PWM duty cycle thresholds are set to meet the following controller specification for a short to power.</p>	<p><math>\geq 91.190</math> % duty cycle</p> <p><math>\leq 91.190</math> % duty cycle</p> <p><math>\leq 0.5 \Omega</math> impedance between signal and controller power</p>	<p>diagnostic monitor enable battery voltage</p> <p>when sensor type is PWM duty cycle direct or inverse conditional for fail threshold is used conditional type check calibration</p>	<p>= 1 Boolean <math>\geq 9.00</math> volts</p> <p>= CeTRGD_e_VoltDirctProp</p>	<p>fail time <math>\geq 1.800</math> seconds out of sample time <math>\geq 2.250</math> seconds</p> <p>battery voltage time <math>\geq 1.000</math> seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Fluid Temperature (TFT) Sensor Performance	P0711	The diagnostic monitor will verify the time to transmission fluid temperature warm up based on the raw transmission fluid temperature sensor, any intermittent signal that causes multiple unrealistic delta changes (intermittent faults) based on the raw transmission fluid temperature sensor, and, raw transmission fluid temperature sensor signal stuck in valid range.	raw transmission fluid temperature and the transmission fluid temperature warm up time has elapsed	$\leq 15.0\text{ }^{\circ}\text{C}$	<p>diagnostic monitor enable P0712 NOT fault active P0713 NOT fault active battery voltage</p> <p>run crank voltage</p> <p>warm up test enable TFT rationality diagnostic monitor enabled</p> <p>driver accelerator pedal position engine torque engine speed vehicle speed engine coolant temperature engine coolant temperature raw transmission fluid temperature raw transmission fluid temperature</p> <p>P2818 fault active P2818 test fail this key on</p> <p>DTCs not fault active</p>	<p>= 1 Boolean</p> <p><math>\geq 9.00\text{ volts}</math></p> <p><math>\geq 9.00\text{ volts}</math></p> <p>= 1 Boolean = VeTFSR_b_TFT_RatlEnbl</p> <p><math>\geq 5.0\%</math></p> <p><math>\geq 50.0\text{ Nm}</math> <math>\geq 500.0\text{ RPM}</math> <math>\geq 10.0\text{ KPH}</math> <math>\geq -40.0\text{ }^{\circ}\text{C}</math></p> <p><math>\leq 150.0\text{ }^{\circ}\text{C}</math></p> <p><math>\geq -40.0\text{ }^{\circ}\text{C}</math></p> <p><math>\leq 150.0\text{ }^{\circ}\text{C}</math></p> <p>= FALSE = FALSE</p>	<p>transmission fluid temperature warm up time <math>\geq</math> <b>transmission fluid temperature warm up time</b> seconds</p> <p>battery voltage time <math>\geq 0.100</math> seconds</p> <p>run crank voltage time <math>\geq 0.100</math> seconds</p>	Type B, 2 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngineTorqueEstInaccuracy AcceleratorPedalFailure CrankSensor_FA ECT_Sensor_FA VehicleSpeedSensor_FA		
			current transmission fluid temperature string length = previous transmission fluid temperature transmission temperature string length + (raw transmission fluid temperature - previous raw transmission fluid temperature, update rate 100 milliseconds, increment sample count	$\geq 80.0\text{ }^{\circ}\text{C}$			sample count $\geq$ 10 counts evaluate fail temperature threshold, 100 millisecond update rate, if transmission fluid temperature string length above fail threshold increment fail time  fail time $\geq$ 8.0 seconds out of sample time $\geq$ 12.0 seconds	
					diagnsotic monitor enable P0712 NOT fault active P0713 NOT fault active battery voltage  run crank voltage  intermittent test enable propulsion system active	= 1 Boolean  $\geq 9.00\text{ volts}$  $\geq 9.00\text{ volts}$  = 1 Boolean = TRUE	battery voltage time $\geq$ 0.100 seconds  run crank voltage time $\geq$ 0.100 seconds	
			raw transmission fluid temperature - previous	$\leq 0.0000\text{ }^{\circ}\text{C}$			fail time $\geq$ 300.0 seconds	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			raw transmission fluid temperature, update rate 100 milliseconds, update fail time		diagnsotic monitor enable P0712 NOT fault active P0713 NOT fault active battery voltage  run crank voltage  stuck in range test enable propulsion system active raw transmission fluid temperature raw transmission fluid temperature	= 1 Boolean  ≥ 9.00 volts  ≥ 9.00 volts  = 1 Boolean = TRUE ≥ -40.0 °C ≤ 150.0 °C	battery voltage time ≥ 0.100 seconds  run crank voltage time ≥ 0.100 seconds	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Fluid Temperature Sensor Circuit Low Voltage	P0712	Controller specific analog circuit diagnoses the transmission fluid temperature sensor and wiring for a short to ground fault by comparing a voltage measurement to controller specific voltage thresholds, converted to a resistance value.	circuit resistance update fail time 1 seconds update rate	$\leq 13.500 \ \Omega$	diagnostic monitor enable  battery voltage  run crank voltage run crank voltage in range time	= 1 Boolean  $\geq 9.00 \text{ volts}$  $\geq 9.00 \text{ volts}$	fail time $\geq 5.00$ seconds out of sample time $\geq$ 6.00 seconds 1 seconds update rate  battery voltage in range time $\geq$ 0.100 seconds  run crank voltage in range time $\geq$ 0.100 seconds	Type B, 2 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Fluid Temperature Sensor Circuit Low Voltage	P0713	Controller specific analog circuit diagnoses the transmission fluid temperature sensor and wiring for an open circuit or short to voltage failure by comparing a voltage measurement to controller specific voltage thresholds, converted to a resistance value.	circuit resistance update fail time 1 seconds update rate	$\geq 49,411,396.0 \ \Omega$	diagnostic monitor enable  battery voltage  run crank voltage run crank voltage in range time	= 1 Boolean  $\geq 9.00$ volts  $\geq 9.00$ volts	fail time $\geq 5.00$ seconds out of fail time $\geq 6.00$ seconds 1 seconds update rate  battery voltage in range time $\geq$ 0.100 seconds  run crank voltage in range time $\geq$ 0.100 seconds	Type B, 2 Trips



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

[illegible]

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

[illegible]

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

[illegible]

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>AND (P0717 fault active OR P0717 test fail this key on) *****</p> <p>TISS/TOSS fault (single power supply to TISS and TOSS) = TRUE occurs when: (P0722 fail time high gear exceeds fail threshold OR P0722 fail time low gear exceeds fail threshold) AND TISS/TOSS has single power supply calibration TISS/TOSS single power supply test enabled Raw Input Speed</p> <p>DTCs not fault active</p>	<p>≥ 162.0 RPM *****</p> <p>= FALSE</p> <p>= FALSE</p> <p>*****</p> <p>≥ 5.00 s</p> <p>≥ 3.50 s</p> <p>= 0 Boolean</p> <p>= 1 Boolean</p> <p>&lt; 475.00 rpm</p> <p>EngineTorqueEstInaccu te</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Output Speed Sensor Performance	P0721	The diagnostic monitor determines if the direction TOSS value is coherent based on the on period time of the directional sensor and TOSS raw. When the on period time indicates a transitional state, the direction must also be transitional as measured by very slow TOSS raw RPM. When the on period time indicates a non-transitional state, forward or reverse, the direction must also be transition, not forward and not reverse.	TOSS raw direction when TOSS transitional period = FALSE AND (TOSS raw direction when TOSS transitional period = FALSE OR TOSS raw when TOSS transitional period = TRUE)  update fail and sample time 6.25 ms update rate	≠ FORWARD  ≠ REVERSE  ≥ 225.0 RPM	service mode \$04 active diagnostic monitor enable TOSS count sample period (P0721 fault active OR P0721 test fail this key on) senor type is directional senor type calibration  ***** TOSS transitional period detected = FALSE when: (on period OR on period when direction unknown  OR on period AND on period when direction is reverse  OR on period AND on period when direction is forward)  TOSS transitional period detected = TRUE when: on period AND	= FALSE = 1 Boolean ≠ 0 counts  = FALSE  = FALSE  = CeTOSR_e_Directional  *****  ≥ 0.4434 seconds ≤ 0.2773 seconds  < 0.2363 seconds > 0.1240 seconds  < 0.0811 seconds > 0.0088 seconds  < 0.4434 seconds	fail time ≥ 3.500 seconds out of sample time ≥ 5.000 seconds	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					on period when direction unknown	> 0.2773 seconds		

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Output Speed Sensor Circuit Low Voltage	P0722	Detects no activity in raw transmission output speed signal RPM due to open circuit electrical failure mode or sensor internal faults, or, controller internal failure modes. The raw transmission output speed signal RPM is rationalized against vehicle conditions in which the the powertrain is producing torque, but raw transmission output speed signal RPM remains low. After a sudden drop in raw transmission output speed signal RPM, a race condition can occur between P0722 and "Output Speed Sensor Circuit Intermittent" depending on the true nature of the failure.	raw transmission output speed, update fail time 6.25 millisecond update rate  use high gear fail time threshold when: (attained gear  attained gear  attained gear)  ELSE use low gear fail time threshold	≤ 30.0 RPM    ≥ CeCGSR_e_CR_First ≤ CeCGSR_e_CR_Tenth > CeCGSR_e_CR_Fourth	service mode \$04 active diagnostic monitor enable  *****  when neutral range or shift occurs: (Intrusive Shift Active OR (garage shift AND Locked to Freewheel AND Freewheel to Locked) OR PRNDL OR PRNDL OR range inhibit state) AND (engine torque accelerator pedal position)  when not neutral range occurs: attained gear attained gear (attained gear  engine torque accelerator pedal (TCC slip	= FALSE = 1 Boolean  *****  = TRUE ≠ COMPLETE = FALSE = FALSE = PARK = NEUTRAL ≠ no inhibit active ≥ 8,192.0 Nm ≥ 100.0 %  ≥ CeCGSR_e_CR_First ≤ CeCGSR_e_CR_Tenth > CeCGSR_e_CR_Fourth ≥ 50.0 Nm ≥ 5.0 % > 100.00 rpm	fail time ≥ 5.00 seconds high gear OR fail time ≥ 3.50 seconds low gear	Type A, 1 Trips

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OR TCC mode))  when not neutral range occurs: (attained gear  engine torque accelerator pedal (TCC slip OR TCC mode))  OR Independent of neutral range: Attained Gear Commanded Gear Internal Speed Sensor Held in First FALSE TIS minus Input speed calculated from TNS TNS *****  (TISS AND TISS) OR (Engine Speed AND Engine Speed) *****  P0716 test fail this key on P0717 test fail this key on P07BF test fail this key on P07C0 test fail this key on  PTO check: PTO enable calibration is FALSE	≠ Off Mode  ≤ CeCGSR_e_CR_Fourth ≥ 80.0 Nm ≥ 8.0 % > 100.00 rpm  ≠ Off Mode  = First = First <b>P0722 Internal Speed</b> = <b>Sensor Held</b>  ≤ <b>P0722 TIS TNS Diff</b> ≥ 172.00 RPM *****  ≤ 8,191.9 RPM ≥ 475.0 RPM  ≤ 8,191.9 RPM ≥ 5,800.0 RPM *****  = FALSE = FALSE = FALSE = FALSE  = 1 Boolean		



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

[illegible]

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

[illegible]

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(PTO disable calibration is TRUE AND PTO active)  run crank voltage  service fast learn active run crank voltage P077C test fail this key on P077D test fail this key on ***** when PRNDL is moved to NEUTRAL allow transmission engaged state time before enabling fail evaluation, or, if raw raw transmission output speed is active in NEUTRAL enable fail evaluation: PRNDL OR PRNDL OR PRNDL OR raw transmission output speed OR last valid raw transmission output speed ***** determine if raw transmission input speed is stable:	= 1 Boolean  = FALSE  ≥ 5.00 volts  = FALSE ≥ 9.00 volts = FALSE = FALSE ***** = CeTRGR_e_PRNDL_Neu tral = CeTRGR_e_PRNDL_Tra nsitional1 N-D transitional = CeTRGR_e_PRNDL_Tra nsitional4 R-N transitional ≥ 250.0 RPM  ≥ 250.0 RPM *****	run crank voltage time ≥ 25 milliseconds	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

[illegible]

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					***** PRNDL AND PRNDL AND ***** ((PRNDL OR PRNDL OR PRNDL) AND (Output Speed raw transmission output speed - raw transmission output speed previous, 25 millisecond update)) OR ***** (PRNDL AND PRNDL AND PRNDL) DTCs not fault active	***** ≠ ParkCeTRGR_e_PRNDL _Park ≠ CeTRGR_e_PRNDL_Tra nsitional2 ***** = CeTRGR_e_PRNDL_Neu tral = CeTRGR_e_PRNDL_Tra nsitional1 = CeTRGR_e_PRNDL_Tra nsitional4 ≥ 50.00 RPM < 20.00 AND > -140.00 ***** ≠ CeTRGR_e_PRNDL_Neu tral ≠ CeTRGR_e_PRNDL_Tra nsitional1 ≠ CeTRGR_e_PRNDL_Tra nsitional4 AcceleratorPedalFailure EngineTorqueEstInaccura te	Delta met time > 2.00	

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Torque Converter Clutch (TCC) System Performance - GF9 specific	P0741	The GF9 diagnostic monitor detects the transmission torque converter control valve failed hydraulically on. The torque converter hydraulic control circuit is multiplexed with the transmission clutch select valve hydraulic control circuit, allowing for the torque converter control valve stuck on test to execute when the clutch select valve solenoid is commanded ON. When the clutch select valve solenoid is commanded ON as the vehicle speed decreases toward zero KPH, and, if the torque converter control valve is stuck on, the torque converter slip speed rate of change will have a large slope while decreasing toward zero RPM, and the torque converter slip speed will remain low near zero RPM.	while control valve test time timing down: rate of change of torque convert slip speed = (ABS (current loop value torque convert slip speed - previous loop value torque convert slip speed) / 25 milliseconds) when clutch select valve solenoid multiplexed to TCC hydraulic AND torque convert slip speed = ABS(engine speed - transmission input shaft speed) THEN increment fail time 25 millisecond update rate	$\geq$ <b>P0741 (GF9 specific) torque convert derivative slip speed fail threshold</b> see supporting tables  $\leq$ <b>P0741 (GF9 specific) TCC slip speed crash RPM</b>	diagnostic monitor enable (TCC stuck off enable OR TCC stuck on enable) hydraulic pressure available: engine speed          service fast learn active battery voltage   run crank voltage   P281B falut active P281D falut active P281E falut active  PRNDL PRNDL PRNDL transmission fluid temperature	= 1 Boolean = 1 Boolean OR = 1 Boolean  $\geq 500.0$ RPM          = FALSE $\geq 9.00$ volts  $\geq 9.00$ volts   = FALSE = FALSE = FALSE  $\neq$ PARK $\neq$ NEUTRAL $\neq$ REVERSE $\geq -6.66$ °C	failt ime $\geq 0.250$ seconds, increment fail count fail count $\geq 4$ counts 25 millisecond update rate          engine speed time $\geq$ <b>engine speed time for transmission hydraulic pressure available</b> see supporting table   battery voltage time $\geq 0.100$ seconds run crank voltage time $\geq 0.100$ seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					transmission fluid temperature accelerator pedal position accelerator pedal position vehicle speed vehicle speed TCC command mode break latch state (clutch select valve solenoid control) P0722 fault pending P0723 fault pending P0716 fault pending P0717 fault pending P07BF fault pending P07C0 fault pending (PTO active OR PTO disable calibration) transmission fluid temperature transmission fluid temperature engine torque engine torque P0741 test fail this key on vehicle speed engine speed engine speed accelerator pedal position 4WD low state (driver shift mode active OR driver shift mode calibration) (misfire requests TCC off OR misfire TCC off calibration) (clutch control solenoid stuck on OR solenoid stuck OFF intrusive shift active)	$\leq 130.00\text{ }^{\circ}\text{C}$ $\geq 0.00\text{ } \%$ $\leq 1.00\text{ } \%$ $\geq 3.0\text{ KPH}$ $\leq 9.5\text{ KPH}$ $= \text{OFF}$ $\neq \text{disabled (clutch select valve transitioning)}$ $= \text{FALSE}$ $= \text{FALSE}$ $= \text{FALSE}$ $= \text{FALSE}$ $= \text{FALSE}$ $= \text{FALSE}$ $= \text{FALSE}$ $= 1\text{ Boolean}$ $\geq -6.66\text{ }^{\circ}\text{C}$ $\leq 130.00\text{ }^{\circ}\text{C}$ $\leq 130.00\text{ }^{\circ}\text{C}$ $\geq 55.0\text{ Nm}$ $\leq 800.0\text{ Nm}$ $= \text{FALSE}$ $\leq 45.0\text{ KPH}$ $\geq 400.0\text{ RPM}$ $\leq 5,500.0\text{ RPM}$ $\leq 95.0\text{ } \%$ $= \text{FALSE}$ $= \text{FALSE}$ $= 0\text{ Boolean}$ $= 0\text{ Boolean}$ $= \text{FALSE}$		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P0746 fault pending P0747 fault pending P0776 fault pending P0777 fault pending P0796 fault pending P0797 fault pending P2714 fault pending P2715 fault pending P2723 fault pending P2724 fault pending P2732 fault pending P2733 fault pending P2820 fault pending P2821 fault pending vehicle speed accelerator pedal position hysteresis  when: break latch state (clutch select valve solenoid) previous break latch state (clutch select valve solenoid) set stuck on test time and begin time down, stuck on test time must time down from calibration value to zero (0.0) seconds  break latch state AND  previous break latch state THEN initialize control valve test time, control valve test time must time down from calibration value to zero (0.0) seconds	= FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE ≤ 8.0 KPH ≥ 4.0 % > 1.0 %  = disabled (clutch select valve not transitioning) = complete (clutch select valve transition complete) = <b>P0741 stuck on test time</b> see supporting tables  = clutch select valve solenoid multiplexed to TCC hydraulic = disabled (clutch select valve not transitioning) = 2.50 seconds		



20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					DTCs not fault active	AcceleratorPedalFailure EngineTorqueEstInaccu rate P0716, P0717, P07BF, P07C0 P0722, P0723, P077C, P077D		

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid A Stuck Off (GF9)	P0746	Each pressure control solenoid stuck off diagnostic monitor detects a clutch pressure control solenoid failed hydraulically off, while the solenoid is electrically functional. In the failure mode the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM. The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line	C1 clutch slip speed, update fail time 6.25 millisecond update	≥ 200.0 RPM	<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active</p> <p>service solenoid cleaning</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean</p>	<p>fail time ≥ 3.00 seconds, update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch pressure control solenoid is failed hydraulically off, the clutch does not maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable. The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed in the opposite sense, clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional, which must take priority over any clutch pressure control solenoid stuck off diagnostic monitor. All clutch pressure control			<p>procedure active</p> <p>hydraulic pressure available</p> <p>*****</p> <p>enable C1 clutch slip speed fail compare when:</p> <p>((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below)</p> <p>unintended deceleration fault pending OR unintended deceleration fault pending enable cal is FALSE (startle mitigation)</p> <p>clutch steady state adaptive active</p> <p>(transmission output shaft speed OR (accelerator pedal position OR engine speed)</p> <p>C1 clutch slip speed valid</p> <p>C1 clutch pressured map</p>	<p>= FALSE Boolean</p> <p>= TRUE</p> <p>*****</p> <p>= FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 (0 to enable, 1 to disable)</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 %</p> <p>≥ 1,500.0 RPM</p> <p>= TRUE (all speed sensors are functional for lever node clutch slip speed calculation)</p> <p>= mapped to line</p>	≥ 0.900 seconds	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck off test is disabled. This diagnostic monitor is relative to GF9 C1 CB123456 clutch pressure control solenoid.			<p>(enable forward gear cal AND driver direction request AND Attained Gear)</p> <p>OR</p> <p>(enable reverse gear cal AND driver direction request AND Attained Gear)</p> <p>P2821 (clutch select valve stuck on) test active</p> <p>range shift state</p> <p>*****</p> <p>DTCs not fault pending</p> <p>*****</p> <p>DTCs not fault active</p>	<p>pressure, C1 clutch pressure has reached fully applied state</p> <p>= 1 (1 to enable, 0 to disable)</p> <p>= FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (1 to enable, 0 to disable)</p> <p>= REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= range shift complete</p> <p>*****</p> <p>P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6</p> <p>P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>DTCs not test fail this key on</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797 P2715 P2724 P2733 P2821</p>	<p>P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p>		

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid A Stuck On	P0747	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	shift type is power down shift: C1 clutch slip speed OR shift type is garage shift: C1 clutch slip speed ELSE shift is another type: C1 clutch slip speed  update fail time 6.25 milliscond update	< 50.0 RPM  < 100.00 RPM  < 50.0 RPM			Base fail time:  shift type is power down shift: fail time ≥ 0.80 seconds  shift type is garage shift: fail time ≥ 0.25  shift type is another type: fail time ≥ 0.150 seconds  Add fail time offset according to shift type:  open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b>  open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b>  garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b>  closed throttle downshift:	Type A, 1 Trips

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C1 CB123456, GR10 C1 CB123456R, or 8 Speed C1 CB1278R clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C1 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C1 off going clutch command pressure )	= TRUE Boolean  = TRUE Boolean  = FALSE Boolean  = FALSE Boolean  = TRUE  *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350.0 kPa	exhaust delay by shift type:	



20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck on torque enable cal)	$\geq 8,191.8 \text{ Nm}$ $= 0$ (0 is enable, 1 is enable)	closed throttle upshift: <b>C1 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C1 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C1 exhaust delay garage shift</b>  closed throttle downshift: <b>C1 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C1 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C1 exhaust delay open throttle power down shift</b>	

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>OR</p> <p>( primary oncoming clutch active</p> <p>primary on coming control state</p> <p>primary on coming commanded pressure)</p> <p>C1 clutch slip speed valid, all speed sensors are functional for lever node clutch slip speed calculation</p>	<p>= TRUE</p> <p>≠ clutch fill phase</p> <p>≥ pressure clip threshold according to shift type:</p> <p>closed throttle upshift: <b>Clutch Clip Press CU Shifts</b></p> <p>open throttle upshift: <b>Clutch Clip Press PU Shifts</b></p> <p>garage shifts: <b>Clutch Clip Press GS Shifts</b></p> <p>closed throttle downshift: <b>Clutch Clip Press CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>open throttle downshift: <b>Clutch Clip Press PD Shifts</b></p> <p>= TRUE</p>	absolute value of ( -0.60 ) seconds	

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>conditions needed to trigger test:</p> <p>(current shift type AND shift type enable cal for current shift type)</p> <p>OR</p> <p>(Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear)</p> <p>OR</p> <p>(stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))</p> <p>clutch stuck off intrusive shift active</p> <p>startle mitigation active (see note on startle mitigation below)</p> <p>(new clutch controller has been initalized OR</p>	<p>*****</p> <p>≠ Garage shift</p> <p><b>Clutch Stuck On Shift = Type Enable</b> (0 table value will disable, 1 will enable)</p> <p>= FALSE</p> <p>= 0 (0 will enable, 1 will enable)</p> <p>= NEUTRAL OR commanded gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= TRUE</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					transitioning to a different clutch controller)  current clutch solenoid test state  ***** DTCs not fault pending    DTCs not fault active    DTCs not test fail this key on	= TRUE  transitions to TestState or TUT_HOLD (see note below about state transitions)  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA  P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions:            Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing.            AND            That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold.            Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the automatic transmission shift, until:</p>	P172A P172B *****		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute.</p> <p>OR</p> <p>The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended vehicle deceleration occurred. Once a safe</p>			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid B Stuck Off (GF9)	P0776	Each pressure control solenoid stuck off diagnostic monitor detects a clutch pressure control solenoid failed hydraulically off, while the solenoid is electrically functional. In the failure mode the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM. The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line	C2 clutch slip speed, update fail time 6.25 millisecond update	≥ 200.0 RPM	<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active</p> <p>service solenoid cleaning</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean</p>	<p>fail time ≥ 3.00 seconds, update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch pressure control solenoid is failed hydraulically off, the clutch does not maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable. The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed in the opposite sense, clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional, which must take priority over any clutch pressure control solenoid stuck off diagnostic monitor. All clutch pressure control			<p>procedure active</p> <p>hydraulic pressure available</p> <p>*****</p> <p>enable C2 clutch slip speed fail compare when:</p> <p>((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below)</p> <p>unintended deceleration fault pending OR unintended deceleration fault pending enable cal is FALSE (startle mitigation)</p> <p>clutch steady state adaptive active</p> <p>(transmission output shaft speed OR (accelerator pedal position OR engine speed)</p> <p>C2 clutch slip speed valid</p> <p>C2 clutch pressured map</p>	<p>= FALSE Boolean</p> <p>= TRUE</p> <p>*****</p> <p>= FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 (0 to enable, 1 to disable)</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 %</p> <p>≥ 1,500.0 RPM</p> <p>= TRUE (all speed sensors are functional for lever node clutch slip speed calculation)</p> <p>= mapped to line</p>	≥ 0.900 seconds	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck off test is disabled. This diagnostic monitor is relative to GF9 C2 CB29 clutch pressure control solenoid.			<p>(enable forward gear cal AND driver direction request AND Attained Gear)</p> <p>OR</p> <p>(enable reverse gear cal AND driver direction request AND Attained Gear)</p> <p>P2821 (clutch select valve stuck on) test active</p> <p>range shift state</p> <p>*****</p> <p>DTCs not fault pending</p> <p>*****</p> <p>DTCs not fault active</p>	<p>pressure, C2 clutch pressure has reached fully applied state</p> <p>= 1 (1 to enable, 0 to disable)</p> <p>= FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (1 to enable, 0 to disable)</p> <p>= REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= range shift complete</p> <p>*****</p> <p>P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6</p> <p>P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>DTCs not test fail this key on</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797 P2715 P2724 P2733 P2821</p>	<p>P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid B Stuck On	P0777	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	shift type is power down shift: C2 clutch slip speed OR shift type is garage shift: C2 clutch slip speed ELSE shift is another type: C2 clutch slip speed  update fail time 6.25 milliscond update	< 50.00 RPM  < 100.00 RPM  < 50.00 RPM			Base fail time:  shift type is power down shift: fail time ≥ 0.80 seconds  shift type is garage shift: fail time ≥ 0.25  shift type is another type: fail time ≥ 0.15 seconds  Add fail time offset according to shift type:  open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b>  open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b>  garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b>  closed throttle downshift:	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C2 CB29, GR10 C2 CB128910R, or 8 Speed C2 CB12345R clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C2 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C2 off going clutch command pressure )	= TRUE Boolean  = TRUE Boolean  = FALSE Boolean  = FALSE Boolean  = TRUE  *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350 kPa	exhaust delay by shift type:	

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck	$\geq 8,192 \text{ Nm}$ $= 0$ (0 is enable, 1 is	closed throttle upshift: <b>C2 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C2 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C2 exhaust delay garage shift</b>  closed throttle downshift: <b>C2 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C2 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C2 exhaust delay open throttle power down shift</b>	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					on torque enable cal)  OR  ( primary oncoming clutch active  primary on coming control state  primary on coming commanded pressure)	enable)   = TRUE  ≠ clutch fill phase  ≥ pressure clip threshold according to shift type:  closed throttle upshift: <b>Clutch Clip Press CU Shifts</b>  open throttle upshift: <b>Clutch Clip Press PU Shifts</b>  garage shifts: <b>Clutch Clip Press GS Shifts</b>  closed throttle downshift: <b>Clutch Clip Press CD Shifts</b>  negative torque upshift: <b>Clutch Clip Press NU Shifts</b>  open throttle downshift: <b>Clutch Clip Press PD Shifts</b>	absolute value of ( -0.60 ) seconds	
					C2 clutch slip speed valid, all speed sensors are functional for lever node clutch slip speed	= TRUE		



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					calculation  ***** conditions needed to trigger test:  (current shift type AND shift type enable cal for current shift type)  OR  (Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear) OR (stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))  clutch stuck off intrusive shift active  startle mitigation active (see note on startle mitigation below)  (new clutch controller has	≠ Garage shift  <b>Clutch Stuck On Shift            = Type Enable</b> (0 table value will disable, 1 will enable)  = FALSE  = 0 (0 will enable, 1 will enable)  = NEUTRAL OR commanded gear  = 0 (0 to disable, 1 to enable) = FORWARD  = a FORWARD gear  = 0 (0 to disable, 1 to enable) = REVERSE  = REVERSE  = FALSE  = FALSE		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>been initalized OR transitioning to a different clutch controller)</p> <p>current clutch solenoid test state</p> <p>*****</p> <p>DTCs not fault pending</p> <p>DTCs not fault active</p> <p>DTCs not test fail this key on</p>	<p>= TRUE</p> <p>= TRUE</p> <p>transitions to TestState or TUT_HOLD (see note below about state transitions)</p> <p>*****</p> <p>P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6</p> <p>P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions: Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing. AND That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold. Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the</p>	<p>P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B *****</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>automatic transmission shift, until: An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute. OR The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended</p>			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					vehicle deceleration occurred. Once a safe vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Output Speed Sensor Circuit Low	P077C	Controller specific analog circuit diagnoses the transmission output speed sensor and wiring for a short to ground fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission output speed sensor raw voltage, update fail time, 12.5 millisecond update rate	$\leq 0.2500$ volts ( $\leq 0.5 \Omega$ impedance between signal and controller ground)	service mode \$04 active diagnostic monitor enable P077D fault active  service fast learn run crank voltage battery voltage  P077C fault active P077C test fail this key on	= FALSE = 1 Boolean = FALSE  = FALSE $\geq 10.00$ volts $\geq 10.00$ volts  = FALSE = FALSE	fail time $\geq 0.050$ seconds, update fail count, fail count $\geq 16$ counts 6.25 millisecond update rate  service fast learn, run crank and battery voltage time $\geq 5.00$ seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Output Speed Sensor Circuit High	P077D	Controller specific analog circuit diagnoses the transmission output speed sensor and wiring for a short to voltage fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission output speed sensor raw voltage, update fail time, 12.5 millisecond update rate	$\geq 4.7500$ volts ( $\leq 0.5 \Omega$ impedance between signal and controller power)	service mode \$04 active diagnostic monitor enable P077C fault active  service fast learn run crank voltage battery voltage  P077D fault active P077D test fail this key on	= FALSE = 1 Boolean = FALSE  = FALSE $\geq 10.00$ volts $\geq 10.00$ volts  = FALSE = FALSE	fail time $\geq 0.050$ seconds, update fail count, fail count $\geq 16$ counts 6.25 millisecond update rate  service fast learn, run crank and battery voltage time $\geq 5.000$ seconds	Type A, 1 Trips

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid C Stuck Off (GF9)	P0796	Each pressure control solenoid stuck off diagnostic monitor detects a clutch pressure control solenoid failed hydraulically off, while the solenoid is electrically functional. In the failure mode the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM. The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line	C3 clutch slip speed, update fail time 6.25 millisecond update	≥ 200.0 RPM	<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active</p> <p>service solenoid cleaning</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean</p>	<p>fail time ≥ 3.00 seconds, update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch pressure control solenoid is failed hydraulically off, the clutch does not maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable. The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed in the opposite sense, clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional, which must take priority over any clutch pressure control solenoid stuck off diagnostic monitor. All clutch pressure control			<p>procedure active</p> <p>hydraulic pressure available</p> <p>*****</p> <p>enable C3 clutch slip speed fail compare when:</p> <p>((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below)</p> <p>unintended deceleration fault pending OR unintended deceleration fault pending enable cal is FALSE (startle mitigation)</p> <p>clutch steady state adaptive active</p> <p>(transmission output shaft speed OR (accelerator pedal position OR engine speed)</p> <p>C3 clutch slip speed valid</p>	<p>= FALSE Boolean</p> <p>= TRUE</p> <p>*****</p> <p>= FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 (0 to enable, 1 to disable)</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 %</p> <p>≥ 1,500.0 RPM</p> <p>= TRUE (all speed sensors are functional for lever node clutch slip speed calculation)</p>	≥ 0.900 seconds	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck off test is disabled. This diagnostic monitor is relative to C3 GF9 CB38 clutch pressure control solenoid.			C3 clutch pressured map  (enable forward gear cal AND driver direction request AND Attained Gear) OR (enable reverse gear cal AND driver direction request AND Attained Gear)  P2821 (clutch select valve stuck on) test active  range shift state  ***** DTCs not fault pending         DTCs not fault active	= mapped to line pressure, C3 clutch pressure has reached fully applied state  = 1 (1 to enable, 0 to disable) = FORWARD  = a FORWARD gear  = 0 (1 to enable, 0 to disable) = REVERSE  = REVERSE  = FALSE  = range shift complete  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>DTCs not test fail this key on</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797 P2715 P2724 P2733 P2821</p>	<p>P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p>		

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid C Stuck On	P0797	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	shift type is power down shift: C3 clutch slip speed OR shift type is garage shift: C3 clutch slip speed ELSE shift is another type: C3 clutch slip speed  update fail time 6.25 milliscond update	< 50.00 RPM  < 100.00 RPM  < 50.00 RPM			Base fail time:  shift type is power down shift: fail time ≥ 0.80 seconds  shift type is garage shift: fail time ≥ 0.25  shift type is another type: fail time ≥ 0.15 seconds  Add fail time offset according to shift type:  open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b>  open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b>  garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b>  closed throttle downshift:	Type A, 1 Trips

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C3 CB38, GR10 C3 C23457910, or 8 Speed C3 C13567 clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C3 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C3 off going clutch command pressure )	= TRUE Boolean          = TRUE Boolean          = FALSE Boolean          = FALSE Boolean          = TRUE          *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350 kPa	exhaust delay by shift type:	

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck on torque enable cal)	$\geq 8,192 \text{ Nm}$ $= 0$ (0 is enable, 1 is enable)	closed throttle upshift: <b>C3 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C3 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C3 exhaust delay garage shift</b>  closed throttle downshift: <b>C3 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C3 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C3 exhaust delay open throttle power down shift</b>	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

[illegible]



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>conditions needed to trigger test:</p> <p>(current shift type AND shift type enable cal for current shift type)</p> <p>OR</p> <p>(Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear)</p> <p>OR</p> <p>(stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))</p> <p>clutch stuck off intrusive shift active</p> <p>startle mitigation active (see note on startle mitigation below)</p> <p>(new clutch controller has been initalized OR</p>	<p>*****</p> <p>≠ Garage shift</p> <p><b>Clutch Stuck On Shift = Type Enable</b> (0 table value will disable, 1 will enable)</p> <p>= FALSE</p> <p>= 0 (0 will enable, 1 will enable)</p> <p>= NEUTRAL OR commanded gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= TRUE</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					transitioning to a different clutch controller)  current clutch solenoid test state  ***** DTCs not fault pending    DTCs not fault active    DTCs not test fail this key on	= TRUE  transitions to TestState or TUT_HOLD (see note below about state transitions)  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA  P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions:            Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing.            AND            That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold.            Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the automatic transmission shift, until:</p>	P172A P172B *****		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute.</p> <p>OR</p> <p>The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended vehicle deceleration occurred. Once a safe</p>			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Input/Turbine Speed Sensor A Circuit Low	P07BF	Controller specific analog circuit diagnoses the transmission input/ turbine speed sensor and wiring for a short to ground fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission input/turbine speed sensor raw voltage, update fail time, 12.5 millisecond update rate	$\leq 0.2500$ volts ( $\leq 0.5 \Omega$ impedance between signal and controller ground)	service mode \$04 active diagnostic monitor enable P07C0 fault active  service fast learn run crank voltage battery voltage  P07BF fault active P07BF test fail this key on	= FALSE = 1 Boolean = FALSE  = FALSE $\geq 10.00$ volts $\geq 10.00$ volts  = FALSE = FALSE	fail time $\geq 0.050$ seconds, update fail count, fail count $\geq 16$ counts 6.25 millisecond update rate  service fast learn, run crank and battery voltage time $\geq 5.000$ seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Input/Turbine Speed Sensor A Circuit High	P07C0	Controller specific analog circuit diagnoses the transmission input/ turbine speed sensor and wiring for a short to voltage fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission input/turbine speed sesnor raw voltage, update fail time, 12.5 millisecond update rate	$\geq 4.7500$ volts ( $\leq 0.5 \Omega$ impedance between signal and controller power)	service mode \$04 active diagnostic monitor enable P07BF fault active  service fast learn run crank voltage battery voltage  P07C0 fault active P07C0 test fail this key on	= FALSE = 1 Boolean = FALSE  = FALSE $\geq 10.00$ volts $\geq 10.00$ volts  = FALSE = FALSE	fail time $\geq 0.050$ seconds, update fail count, fail count $\geq 16$ counts 6.25 millisecond update rate  service fast learn, run crank and battery voltage time $\geq 5.000$ seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Upshift Switch Circuit	P0815	Diagnoses the state of the upshift switch circuit, stuck in the state "tap up" (upshift) active.  Emissions neutral default, disables tap-up tap-down or manual-up manual-down.	switch state update fail time 1 100 millisecond update rate	= tap up (upshift) state active	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active P0826 fault active P0826 test fail this key on P0826 fault pending (P0815 fault active OR P0815 fault active test fail this key on) PRNDL range change time PRNDL in range: D1 OR D2 OR D3 OR D4 OR D5 OR D6 OR D7 OR D8 OR D9 OR D10 OR NEUTRAL OR PARK OR REVERSE  DTCs not fault pending	= FALSE = 1 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE ≥ 1.00 seconds  = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean  Transmission Shift Lever Position Validity	fail time 1 ≥ 1.00 seconds	Emissio ns Neutral Diagnost ics – Type C
			switch state update fail time 2 100 millisecond update rate	= tap up (upshift) state active	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active	= FALSE = 1 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE	fail time 2 ≥ 120.00 seconds	



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P0826 fault active P0826 test fail this key on P0826 fault pending (P0815 fault active OR P0815 fault active test fail this key on) PRNDL range change time PRNDL in range: D1 OR D2 OR D3 OR D4 OR D5 OR D6 OR D7 OR D8 OR D9 OR D10 OR NEUTRAL OR PARK OR REVERSE  DTCs not fault pending	= FALSE = FALSE = FALSE = FALSE = FALSE  ≥ 1.00 seconds  = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean  Transmission Shift Lever Position Validity		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Downshift Switch Circuit	P0816	<p>Diagnoses the state of the downshift switch circuit, stuck in the state "tap down" (downshift) active.</p> <p>Emissions neutral default, disables tap-up tap-down or manual-up manual-down.</p>	switch state update fail time 1 100 millisecond update rate	= tap down (downshift) state active	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active P0826 fault active P0826 test fail this key on P0826 fault pending (P0816 fault active OR P0816 fault active test fail this key on) PRNDL range change time PRNDL in range: D1 OR D2 OR D3 OR D4 OR D5 OR D6 OR D7 OR D8 OR D9 OR D10 OR NEUTRAL OR PARK OR REVERSE  DTCs not fault pending	= FALSE = 1 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE  ≥ 1.00 seconds  = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean  Transmission Shift Lever Position Validity	fail time 1 ≥ 1.00 seconds	Emissio ns Neutral Diagnost ics – Type C
			switch state update fail time 2 100 millisecond update rate	= tap down (downshift) state active	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active	= FALSE = 1 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE	fail time 2 ≥ 120.00 seconds	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P0826 fault active P0826 test fail this key on P0826 fault pending (P0816 fault active OR P0816 fault active test fail this key on) PRNDL range change time PRNDL in range: D1 OR D2 OR D3 OR D4 OR D5 OR D6 OR D7 OR D8 OR D9 OR D10 OR NEUTRAL OR PARK OR REVERSE  DTCs not fault pending	= FALSE = FALSE = FALSE = FALSE = FALSE  ≥ 1.00 seconds  = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean  Transmission Shift Lever Position Validity		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Up and Down Shift Switch Circuit	P0826	Diagnoses the state of the upshift/downshift switch circuit at an illegal voltage, voltage out of range.  Emissions neutral default, disables tap-up tap-down or manual-up manual-down.	switch state update fail time 100 millisecond update rate	= illegal (voltage out of range)	service mode \$04 active diagnostic monitor enable  run crank voltage  run crank voltage P1761 fault active (P0826 fault active OR P0826 fault active test fail this key on)	= FALSE = 1 Boolean  ≥ 5.00 volts  ≥ 9.00 volts = FALSE = FALSE = FALSE	fail time ≥ 60.00 seconds  run crank voltage time ≥ 25 milliseconds	Emissions Neutral Diagnostics – Type C

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid A Control Circuit Open	P0960	Controller specific circuit diagnoses 9 speed CB123456, 10 speed CB123456R, or 8 speed CB1278R clutch or CVT secondary pulley, solenoid for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates an open circuit</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit</p> <p>Increment fail time</p>	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00 \text{ volts}</math> and <math>\leq 32.00 \text{ volts}</math></p> <p><math>\geq 5.00 \text{ volts}</math></p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid A Control Circuit Low	P0962	Controller specific circuit diagnoses 9 speed CB123456, 10 speed CB123456R, or 8 speed CB1278R clutch or CVT secondary pulley, solenoid for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a ground short</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller ground	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid A Control Circuit High	P0963	Controller specific circuit diagnoses 9 speed, 10 speed CB123456R, 8 speed CB1278R clutch or CVT secondary pulley, solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid B Control Circuit Open	P0964	Controller specific circuit diagnoses 9 speed CB29, 10 speed CB128910R, 8 speed CB12345R clutch or CVT primary pulley, solenoid for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates an open circuit  Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit  Increment fail time	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1) OR (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2) OR (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00 \text{ volts}$ and $\leq 32.00 \text{ volts}$  $\geq 5.00 \text{ volts}$  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00 \text{ seconds}$  $\geq 25 \text{ milliseconds}$  $\geq 12.5 \text{ milliseconds}$	Type A, 1 Trips



# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid B Control Circuit Low	P0966	Controller specific circuit diagnoses 9 speed CB29, 10 speed CB128910R, 8 speed CB12345R clutch or CVT primary pulley, solenoid for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid B Control Circuit High	P0967	Controller specific circuit diagnoses 9 speed CB29, 10 speed CB128910R, 8 speed CB12345R clutch or CVT primary pulley, solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid C Control Circuit Open	P0968	Controller specific circuit diagnoses 9 speed CB38, 10 speed C23457910, or 8 speed C13567, clutch or CVT line pressure, solenoid for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates an open circuit  Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit  Increment fail time	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1) OR (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2) OR (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00 \text{ volts and } \leq 32.00 \text{ volts}$  $\geq 5.00 \text{ volts}$  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.000 \text{ seconds}$  25 milliseconds  12.5 milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid C Control Circuit Low	P0970	Controller specific circuit diagnoses 9 speed CB38, 10 speed C23457910, or 8 speed C13567 clutch, or CVT line pressure, solenoid for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid C Control Circuit High	P0971	Controller specific circuit diagnoses 9 speed CB38, 10 speed C23457910, or 8 speed C13567, clutch or CVT line pressure, solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 2	P16E9	This DTC will be stored if the internal serial peripheral interface bus #2 has failed.	Serial Peripheral Bus #2 has failed	>= 8.00		Diagnostic System Enabled  AND  (Battery Voltage In Range  OR  Run/Crank Voltage In Range)  (GetDRER_b_DiagSyste mDsbl() == CbFALSE)  &&  ((GetLVTR_b_Ru nCrankIgnInRange() == CbTRUE)      (GetLVTR_b_BatteryI nRange() == CbTRUE) )	Diagnostic runs periodically at either 5 milliseconds or 6.25 milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 1	P16F0	This DTC will be stored if the internal serial peripheral interface bus #1 has failed.	Serial Peripheral Bus #1 has failed	>= 8.00		Diagnostic System Enabled  AND  (Battery Voltage In Range)  OR  Run/Crank Voltage In Range)  (GetDRER_b_DiagSystemDsbl() == CbFALSE)  &&  ((GetLVTR_b_RunCrankIgnInRange() == CbTRUE)      (GetLVTR_b_BatteryInRange() == CbTRUE) )	Diagnostic runs periodically at either 5 milliseconds or 6.25 milliseconds	Type A, 1 Trips

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Redundant Memory Performance	P16F3	<p>The diagnostic monitor is a rationalization of command values: command clutch pressures and command gear. The monitor is broken up into two fault detection routines, command pressure (tie up) fault detection and command gear/shift fault detection.</p> <p>The command pressure (tie up) fault detection is designed to verify the number of clutches applied in a given gear state is limited, in order to prevent a transmission internal mechanical tie-up condition. A condition which could lead to a vehicle deceleration above the design safety metric. If commanded clutch pressures are above a threshold which would allow multiple clutches to carry torque, the clutch is considered applied, otherwise the clutch is considered released. If there are more clutches applied, via the commanded clutch pressures, in a given gear state than is rational, one or more of</p>	<p>command pressure (tie up) fault detection</p> <p>minimum # of clutches ON by attained gear and by commanded gear, take lower of the 2 values, where attained gear is the current operating gear and command gear is the targetted value to transition toward</p> <p>see <b>9 speed transmission clutch definition and gear state to clutch map</b> and <b>10 speed transmission clutch definition and gear state to clutch map</b> attached supporting tables for clutch 1 through clutch 7 definition and gear state to clutch map</p>	$\leq$ <b>NumClchTieUp</b> See Attached Supporting Tables	<p>Redundant Memory Command Pressure Enable Calibration Not</p> <p>Redundant Memory Command Pressure Enable Calibration</p> <p>No traction event in progress:  <math>\text{ABS}((\text{driven wheel speed} - \text{non-drive wheel speed}) / \text{driven wheel speed})</math></p> <p>25 millisecond derivative TOSS RPM, (TOSS delta 25 millisecond loop to 25 millisecond loop) / 25 millisecond for time</p> <p>Clutch 1 hydraulic volume fill factor</p> <p>Clutch 2 hydraulic volume fill factor</p> <p>Clutch 3 hydraulic volume fill factor</p> <p>Clutch 4 hydraulic volume fill factor</p> <p>Clutch 5 hydraulic volume fill factor</p> <p>Clutch 6 hydraulic volume fill factor</p> <p>Clutch 7 hydraulic volume fill factor</p> <p>when clutch is off going (releasing) clutch the commanded clutch pressure equation = ((pressure control solenoid command</p>	<p>= 0 Boolean</p> <p>= 1 Boolean</p> <p><math>\geq 0.00 \%</math></p> <p><math>&lt; 0.750 *</math>  <b>P2D2 Cltch Slip Sum</b>            see attached supporting Table</p> <p><math>\geq 0.0500</math> seconds</p> <p><math>\geq 1.000</math> unitless</p> <p><math>\geq 1.000</math> unitless</p> <p><math>\geq 1.000</math> unitless</p> <p><math>\geq 1.000</math> unitless</p> <p><math>\geq 1.000</math> unitless</p> <p><math>\geq 1.000</math> unitless</p> <p><math>\geq 1.000</math> unitless</p>	<p>single event</p> <p>6.25 millisecond update rate</p>	Type A, 1 Trips



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>the clutch pressure command values are in error. Given rate of change of transmission output shaft speed, command gear state clutches and clutch hydraulic fill volumes, those clutches in transition from the hydraulic released state to the hydraulic applied state and from the hydraulic applied state to the hydraulic released state, the rationality detects any number of command clutch pressures above a threshold, that are simultaneously active to cause a vehicle deceleration above the design safety metric.</p> <p>The command gear/ shift fault detection is designed to verify the commanded gear will not induce a downshift resulting in a gear state that is erroneous given vehicle operating conditions. The detection rationalizes the command gear against a minimum gear, highest gear ratio, for given vehicle speed and driver accelerator position.</p>			<p>pressure - pressure offset) * regulator valve gain) - regulator valve return spring pressure adaptive</p> <p>when clutch 1 is off going clutch: clutch 1 command pressure</p> <p>clutch 1 state is OFF when: clutch 1 command pressure, else clutch is ON and count clutch 1 toward minimum # of clutches ON</p> <p>when clutch 2 is off going clutch: clutch 2 command pressure</p> <p>clutch 2 state is OFF when: clutch 2 command pressure, else clutch is ON and count clutch 2 toward minimum # of clutches ON</p> <p>when clutch 3 is off going clutch: clutch 3 command pressure</p>	<p>= ((clutch 1 pressure control solenoid command pressure - 0.00 ) * 1.00 ) - regulator valve return spring pressure adaptive, kPa</p> <p><b>P2D2 Decel Pressure - ≤ C1</b> see attached supporting tables</p> <p>= ((clutch 2 pressure control solenoid command pressure - 0.00 ) * 1.00 ) - regulator valve return spring pressure adaptive, kPa</p> <p><b>P2D2 Decel Pressure - ≤ C2</b> see attached supporting tables</p> <p>= ((clutch 3 pressure</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>clutch 3 state is OFF when: clutch 3 command pressure, else clutch is ON and count clutch 3 toward minimum # of clutches ON</p> <p>when clutch 4 is off going clutch: clutch 4 command pressure</p> <p>clutch 4 state is OFF when: clutch 4 command pressure, else clutch is ON and count clutch 4 toward minimum # of clutches ON</p> <p>when clutch 5 is off going clutch: clutch 5 command pressure</p> <p>clutch 5 state is OFF when: clutch 5 command pressure.</p>	<p>control solenoid command pressure - 177.00 ) * 1.51 ) - regulator valve return spring pressure adaptive, kPa</p> <p><b>P2D2 Decel Pressure - ≤ C3</b> see attached supporting tables</p> <p>= ((clutch 4 pressure control solenoid command pressure - 160.00 ) * 2.25 ) - regulator valve return spring pressure adaptive, kPa</p> <p><b>P2D2 Decel Pressure - ≤ C4</b> see attached supporting tables</p> <p>= ((clutch 5 pressure control solenoid command pressure - 0.00 ) * 1.00 ) - regulator valve return spring pressure adaptive, kPa</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>else clutch is ON and count clutch 5 toward minimum # of clutches ON</p> <p>when clutch 6 is off going clutch: clutch 6 command pressure</p> <p>clutch 6 state is OFF when: clutch 6 command pressure, else clutch is ON and count clutch 6 toward minimum # of clutches ON</p> <p>when clutch 7 is off going clutch: clutch 7 command pressure</p> <p>clutch 7 state is OFF when: clutch 7 command pressure, else clutch is ON and count clutch 7 toward minimum # of clutches ON</p> <p>service fast learn not active</p>	<p><b>P2D2 Decel Pressure - ≤ C5</b> see attached supporting tables</p> <p>= ((clutch 6 pressure control solenoid command pressure - 0.00) * 1.00) - regulator valve return spring pressure adaptive, kPa</p> <p><b>P2D2 Decel Pressure - ≤ C6</b> see attached supporting tables</p> <p>= ((clutch 7 pressure control solenoid command pressure - 0.00) * 1.00) - regulator valve return spring pressure adaptive, kPa</p> <p><b>P2D2 Decel Pressure - ≤ C7</b> see attached supporting tables</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					no speed sensor DTCs fault active: P0716, P0717, P0721, P0722, P0723, P077C, P077D, P07BF, P07C0, P172A, P172B, P176B, P176C, P176D, P1783, P178F, P17C4, P17C5, P17C6, P17CC, P17CD, P17CE, P17D3, P17D6  no high side driver DTCs fault active: P0658, P2670			
			command gear/shift fault detection  1st gear commanded and vehicle seed OR 2nd gear commanded and vehicle seed OR 3rd gear commanded and vehicle seed OR 4th gear commanded and vehicle seed OR 5th gear commanded and vehicle seed OR 6th gear commanded and vehicle seed OR 7th gear commanded and vehicle seed OR 8th gear commanded and	> 66.07 KPH  > 93.71 KPH  > 102.86 KPH  > 126.66 KPH  > 161.11 KPH  > 214.25 KPH  > 309.81 KPH	Reduandant Memory Command Gear Enable Calibraiton Not  Reduandant Memory Command Gear Enable Calibraiton  service fast learn not active  no speed sensor DTCs fault active: P0716, P0717, P0721, P0722, P0723, P077C, P077D, P07BF, P07C0, P172A, P172B, P176B, P176C, P176D, P1783, P178F, P17C4, P17C5, P17C6, P17CC, P17CD, P17CE, P17D3, P17D6  no high side driver DTCs fault active:	= 0 Boolean  = 1 Boolean	command gear fail event count ≥ 3 counts  6.25 millisecond update rate	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			vehicle seed OR 9th gear commanded and vehicle seed OR 10th gear commanded and vehicle seed THEN increment command gear fail event count and abort commanded gear and delay for time before next fail evaluation	> 414.73 KPH  > 502.12 KPH  > 502.12 KPH  > 5.00 seconds	P0658, P2670			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Speed Signal Analog to Digital Converter Performance	P16FB	The diagnostic monitor validates the controller calculated transmission output speed sensor data parameters, calculated in multiple paths/subroutines and at different rates. There are multiple transmission output speed sensor data parameters, calculated at rates of 6.25 milliseconds, 12.5 milliseconds and 25 milliseconds. While the same subroutine, a generic "calculate TOSS" is called from different time loops, each call stores that current value of the calculated TOSS to a different memory location. For example, a 12.5 millisecond loop calling "calculate TOSS" stores the calculated TOSS value to a "12.5 millisecond TOSS calculated" data parameter in memory, while a 25 millisecond loop calling "calculate TOSS" stores the calculated TOSS value to a "25 millisecond TOSS calculated" data parameter in memory. The raw transmission output speed sensor	ABS(raw transmission output speed, 6.25 millisecond data parameter - raw transmission output speed, 25 millisecond data parameter) update fail and sample time 25 millisecond update rate	≥ 60.0 RPM	service mode \$04 active diagnsotic monitor enable  raw transmission output speed, 25 millisecond data parameter  raw transmission output speed, 6.25 millisecond data parameter  service fast learn run crank voltage battery voltage	= FALSE = 1 Boolean  ≥ 356.0 RPM  ≥ 356.0 RPM  = FALSE ≥ 10.00 volts ≥ 10.00 volts	fail time ≥ 8.000 seconds within sample time < 10.000 seconds 25 millisecond update rate              service fast learn, run crank and battery voltage time ≥ 5.000 seconds	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		signal is diagnosed independently electrically and for performance of this DTC. The transmission output speed sensor data parameters that are calculated at different rates must always be within a negligible difference of each other.						

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Surge Solenoid Circuit Low	P171B	Controller specific transmission surge accumulator control circuit diagnoses the transmission surge accumulator and wiring for a ground short circuit fault by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage battery voltage battery enable time run/crank voltage run crank voltage time $\geq$ diagnostic monitor enable	$\geq 9.00$ volts $\leq 32.00$ volts $\geq 1.00$ seconds $\geq 5.00$ volts 25 milliseconds = 1 Boolean	fail time $\geq 0.300$ seconds out of sample time $\geq 0.500$ seconds	Type B, 2 Trips



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Surge Solenoid Circuit High	P171C	Controller specific transmission surge accumulator control circuit diagnoses the transmission surge accumulator and wiring for a short to voltage circuit fault by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>battery voltage</p> <p>battery voltage enable time</p> <p>run/crank voltage</p> <p>run crank voltage time</p> <p>diagnostic monitor enable</p>	<p><math>\geq 9.00</math> volts</p> <p><math>\leq 32.00</math> volts</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 5.00</math> volts</p> <p>time <math>\geq 25</math> milliseconds</p> <p>= 1 Boolean</p>	fail time $\geq 0.300$ seconds out of $\geq 0.500$ seconds sample time	Type B, 2 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Surge Accumulator System Performance	P171D	Detects when the surge accumulator system, used to provide transmission hydraulic pressure, is not capable of supplying adequate hydraulic pressure during an engine auto-start. The transmission holding clutch pressures are commanded to meet the engine crank shaft torque output, to prevent clutch slip to those holding clutches, during the engine auto-start. The diagnostic monitors transmission input shaft speed during the auto-start event as the primary malfunction criteria. Measured input shaft speed that is excessive is an indication the holding clutches are slipping due to inadequate hydraulic pressure, as a result of a failed surge accumulator system.	Transmission turbine speed is greater than predicted turbine speed during autostart event, update initial fail count	<b>P171D predicted ≥ turbine speed error</b> Refer to "Transmission Supporting Tables" for details	PRNDL state defaulted  Transmission shift lever position  Propulsion system active  Ignition voltage Ignition voltage  Transmission fluid temp Transmission fluid temp  Hybrid state AutoStop duration min  During autostop Engine speed was  ***** If above conditions are met then the following must occur:  Turbine speed  Engine speed  Hydraulic pressure delay time    If above conditions are met then increment time-out timer. Time-out timer  Note: The initial fail	= False  = Forward range A  = True  > 9.00 volts < 32.00 volts  > 0.00 °C < 110.00 °C  = Engine off ≥ 1.200 seconds  < 5.0 RPM    ≥ 80.0 RPM  ≥ 450.0 RPM  <b>P171D hydraulic ≥ pressure delay</b> Refer to "Transmission Supporting Tables" for details    ≤ 0.38 seconds	≥ 8 counts (initial fail count) Frequency =12.5ms  Once the above counts are achieved then increment the final fail counter once. The final fail counter can only increment once per autostart event  ≥ 3 counts (final fail counter)  If above counter is greater than threshold then report DTC failed.  Frequency = 12.5ms	Type B, 2 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>counter must achieve it's fail threshold in less than the time-out time.</p> <p>*****</p> <p>If vehicle is launched then:</p> <p>Transmission gear ratio</p> <p>Trans 1st gear ratio</p> <p>Trans 1st gear ratio</p> <p>Trans gear ratio not 1st gear</p> <p>Trans gear ratio not 1st gear</p> <p>Valid transmission gear ratio achieved time</p> <p>OR</p> <p>If vehicle is not launched but autostart occurs then:</p> <p>Turbine speed</p> <p>Turbine speed less then above threshold for</p> <p>Note: During an autostart event the lack of hydraulic pressure will result in momentary clutch slip in</p>	<p>= 4.689 1st gear ratio</p> <p>= 3.306 2nd gear ratio</p> <p>= 3.012 3rd gear ratio</p> <p>= 2.446 4th gear ratio</p> <p>= 1.923 5th gear ratio</p> <p>= 1.446 6th gear ratio</p> <p>≤ 1.120 % of 1st gear ratio</p> <p>≥ 0.880 % of 1st gear ratio</p> <p>≤ 1.070 % of gear ratio</p> <p>≥ 0.930 % of gear ratio</p> <p>≥ 0.500 seconds</p> <p>≤ 5.00 RPM</p> <p>≥ 0.500 seconds</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>the C1234 clutch. After the clutch slip event, the main transmission pump and clutch will gain capacity, clutch slip will go to zero. If the vehicle is launching (moving) then a valid transmission ratio can be achieved. Or if the brake is continually applied and an autostart occurs naturally, then no ratio can be measured. In this case turbine speed will return to near zero rpm.</p> <p>*****</p> <p>DTCs not fault active</p>	<p>CrankSensor_FA Transmission Output Shaft Angular Velocity Validity Transmission Turbine Angular Velocity Validity Transmission Oil Temperature Validity P171A P171B P171C U0101 P182E P1915</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control System - Shift Limiting Active	P175E	The latent fault diagnostic monitors detects when the vehicle has been driven excessively with an emission MIL request. The DTCs requesting the emission MIL are all due to a safety critical system or component fault present in which a DTC is set fault active, test fail this key on or fault pending (fault pending is fail time ≠ 0). The safety critical systems or safety critical components include: transmission input, output and intermediate speed sensors, transmission range sensors, clutch pressure control solenoids including unintended deceleration detected due to clutch pressure control solenoids, driver accelerator pedal position, engine crankshaft position and engine torque. The DTCs for these safety critical systems or safety critical components include both electrical fault DTCs and performance fault DTCs. The latent fault diagnostic monitor	P0747 OR P0777 OR P0797 OR P2715 OR P2724 OR P2731 OR P2733 fault active due to unintended deceleration detection, increment unintended deceleration latent fault fail count		transmission default gear active (emission MIL active) calibration CeTRDR_e_DSG_DfltGr Opt5_Action any non-zero (0) option	> CeTRDR_e_DSG_DfltGr OptNone, zero (0) element in default gear array	unintended deceleration latent fault fail count ≥ 100 counts  25 millisecond update rate	Type A, 1 Trips
			P0747 OR P0777 OR P0797 OR P2715 OR P2724 OR P2731 OR P2733 clutch pressure control solenoid fault active due to clutch stuck on during shift, increment clutch pressure control solenoid latent fault fail count		transmission default gear active (emission MIL active) calibration CeTRDR_e_DSG_DfltGr Opt5_Action any non-zero (0) option	> CeTRDR_e_DSG_DfltGr OptNone, zero (0) element in default gear array	clutch pressure control solenoid latent fault fail count ≥ 100 counts  25 millisecond update rate	
			P2802 OR P2803 fault active, increment transmission range sensor latent fault fail count		transmission default gear active (emission MIL active) calibration CeTRDR_e_DSG_DfltGr Opt5_Action any non-zero (0) option	> CeTRDR_e_DSG_DfltGr OptNone, zero (0) element in default gear array	transmission range sensor latent fault fail count ≥ 200 counts  25 millisecond update rate	
			P0721 OR P0722 OR P0723 OR P077C OR P077D OR P172A fault active, increment transmission output speed sensor latent fault fail count		transmission default gear active (emission MIL active) calibration CeTRDR_e_DSG_DfltGr Opt5_Action any non-zero (0) option	> CeTRDR_e_DSG_DfltGr OptNone, zero (0) element in default gear array	transmission output speed sensor latent fault fail count ≥ 100 counts  25 millisecond update rate	
			P0716 OR P0717 OR P0721 OR P07BF OR P07C0 fault active OR		transmission default gear active (emission MIL active) calibration	>	transmission input output speed sensor latent fault fail	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		counts the run/crank ignition cycles before the latent fault DTC is set fault active.	P077D OR P077D OR P1783 OR P17CE fault active OR P0722 OR P0723 OR P172A test fail this key on OR P0716 OR P0717 OR P0721 OR P0722 OR P0723 OR P077C OR P077D OR P07BF OR P07C0 Or P172A OR P172B OR P1783 OR P17CE fault pending (fail time ≠ 0) increment transmission input output speed sensor latent fault fail count		CeTRDR_e_DSG_DfltGr OptNone any non-zero (0) option	CeTRDR_e_DSG_DfltGr OptNone, zero (0) element in default gear array	count ≥ 100 counts  25 millisecond update rate	
			AcceleratorPedalFailure OR EngineTorqueEstInaccurate OR P2534 fault active OR CrankSensor_FA OR P0707 OR P0708 fault active OR test fail this key on OR P2805 fault active OR P0716 OR P0717 OR P07BF OR P07C0 fault active OR P0722 OR P0723 test fail this key on OR P077C OR P077D fault active OR P176C OR P176D OR	= TRUE  = TRUE       = TRUE	transmission default gear active (emission MIL active) calibration CeTRDR_e_DSG_DfltGr Opt5_Action any non-zero (0) option   ignition run crank voltage for time	> CeTRDR_e_DSG_DfltGr OptNone, zero (0) element in default gear array   > 5.00 volts ≥ 12.5 milliseconds	system latent fault fail count ≥ 100 counts  6.25 millisecond update rate	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			P17CC OR P17CD OR P176B OR P17D6 fault active OR test fail this key on OR P0747 OR P0777 OR P0797 OR P2715 OR P2724 OR P2733 OR P0746 OR P0776 OR P0796 OR P2714 OR P2723 OR P2732 OR P178F OR P17C4 OR P17C6 OR P172A OR P172B test fail this key on OR P0960 OR P0962 OR P0963 OR P0964 OR P0966 OR P0967 OR P0968 OR P0970 OR P0971 OR P2718 OR P2720 OR P2721 OR P2727 OR P2729 OR P2730 OR P2736 OR P2738 OR P2739 OR P17C5 OR P17D3OR P0721 fault active OR P0716 OR P0717 OR P0721 OR P0722 OR P0723 OR P077C OR P077D OR P07BF OR P07C0 fault pending (fail time ≠ 0) OR P176B OR P176C OR P176D OR P17CC OR P17CD OR P17D6 OR P1783 OR P178F OR P17C4 OR P17C5 OR P17C6 OR P17CE OR P17D3 OR P172A or P172B fault pending (fail					

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			time ≠ 0) OR P1783 fault active OR P1783 fault pending (fail time ≠ 0)  update system fault time when system fault time increment system latent fault fail count	≥ 10.0 seconds				



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Acceleration Sensor Signal Message Counter Incorrect	P175F	<p>The diagnostic monitor detects an alive rolling count error or checksum error in the CAN frame containing the lateral acceleration signal value and longitudinal acceleration sensor signal value.</p> <p>Emission neutral default state sets lateral and longitudinal acceleration signal = 0.0 g.</p>	<p>rolling count value received from EBCM and expected TCM calculated value not equal OR checksum lateral and longitudinal acceleration CAN frame message value error</p> <p>50 millisecond update rate</p>	<p>= TRUE</p> <p>= TRUE</p>	<p>enable alive rolling count error detection: diagnostic monitor enable lateral and longitudinal acceleration CAN frame message received battery voltage run crank voltage</p> <p>enable checksum error detection: diagnostic monitor enable lateral and longitudinal acceleration CAN frame message received normal CAN battery voltage run crank voltage communication enabled</p> <p>DTCs not fault active</p>	<p>= 1 Boolean = TRUE</p> <p>≥ 11.0 volts ≥ 11.0 volts</p> <p>= 1 Boolean = TRUE</p> <p>≥ 11.0 volts ≥ 11.0 volts = TRUE</p> <p>U0073</p>	<p>alive rolling count errors ≥ 54 out of 9 sample counts 50 millisecond update rate</p> <p>checksum error time ≥ 54.00 seconds</p>	Emission Neutral Diagnostic – Type C

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Up and Down Shift Switch Signal Circuit	P1761	<p>The alive rolling count normally cycles 0, 1, 2, and 3 as a serial data periodic frame is processed normally. The diagnostic monitor counts the number of times an alive rolling count error occurs over a period of time. The TCM receives a serial data frame at a periodic rate, during which, the receive data is processed the comparing the current value of the alive rolling count in the frame date to the incremented value of the diagnostic alive rolling count. When the two values of the alive rolling count do not agree, an alive rolling count error has occurred. The error indicator is saved in an array buffer, and when the number of error indicators in the buffer exceed the fail threshold the fail time is allowed to time up.</p> <p>Emissions neutral default, disables tap-up tap-down or manual-up manual-down.</p>	<p>alive rolling count error counter update fail time 100 millisecond update rate</p>	≥ 3 counts	<p>service mode \$04 active diagnostic monitor enable</p> <p>run crank voltage run crank voltage time</p> <p>up and down shift serial data frame receive occurred</p> <p>when up and down shift serial data frame receive occurred: increment the diagnosis alive rolling count data value, if the diagnosis alive rolling count data value, set alive rolling count error to TRUE,</p> <p>when alive rolling count error AND previous alive rolling count error in 10 element array buffer, increment alive rolling count error counter</p>	<p>= FALSE = 1 Boolean</p> <p>≥ 9.00 volts ≥ 0.100 seconds</p> <p>= TRUE</p> <p>≠ frame alive rolling count data value</p> <p>= TRUE = FALSE</p>	fail time ≥ 10.00 seconds	Emissions Neutral Diagnostics – Type C

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Upshift Switch Circuit 2	P1765	Diagnoses the state of the upshift switch circuit, stuck in the state "tap up" (upshift) active.  Emissions neutral default, disables tap-up tap-down or manual-up manual-down.	switch state update fail time 1 100 millisecond update rate	= tap up (upshift) state active	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active P1767 fault active P1767 test fail this key on P1767 fault pending (P1765 fault active OR P1765 fault active test fail this key on) PRNDL range change time PRNDL in range: D1 OR D2 OR D3 OR D4 OR D5 OR D6 OR D7 OR D8 OR D9 OR D10 OR NEUTRAL OR PARK OR REVERSE  DTCs not fault pending	= FALSE = 0 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE ≥ 1.00 seconds  = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean  Transmission Shift Lever Position Validity	fail time 1 ≥ 1.00 seconds	Emissio ns Neutral Diagnost ics – Type C
			switch state update fail time 2 100 millisecond update rate	= tap up (upshift) state active	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active	= FALSE = 0 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE	fail time 2 ≥ 120.00 seconds	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P1767 fault active P1767 test fail this key on P1767 fault pending (P1765 fault active OR P1765 fault active test fail this key on) PRNDL range change time PRNDL in range: D1 OR D2 OR D3 OR D4 OR D5 OR D6 OR D7 OR D8 OR D9 OR D10 OR NEUTRAL OR PARK OR REVERSE  DTCs not fault pending	= FALSE = FALSE = FALSE = FALSE = FALSE  ≥ 1.00 seconds  = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean  Transmission Shift Lever Position Validity		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Downshift Switch Circuit 2	P1766	Diagnoses the state of the downshift switch circuit, stuck in the state "tap down" (downshift) active.  Emissions neutral default, disables tap-up tap-down or manual-up manual-down.	switch state update fail time 1 100 millisecond update rate	= tap down (downshift) state active	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active P1767 fault active P1767 test fail this key on P1767 fault pending (P1766 fault active OR P1766 fault active test fail this key on) PRNDL range change time PRNDL in range: D1 OR D2 OR D3 OR D4 OR D5 OR D6 OR D7 OR D8 OR D9 OR D10 OR NEUTRAL OR PARK OR REVERSE  DTCs not fault pending	= FALSE = 0 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE  ≥ 1.00 seconds  = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean  Transmission Shift Lever Position Validity	fail time 1 ≥ 1.00 seconds	Emissio ns Neutral Diagnost ics – Type C
			switch state update fail time 2 100 millisecond update rate	= tap down (downshift) state active	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active	= FALSE = 0 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE	fail time 2 ≥ 120.00 seconds	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P1767 fault active P1767 test fail this key on P1767 fault pending (P1766 fault active OR P1766 fault active test fail this key on) PRNDL range change time PRNDL in range: D1 OR D2 OR D3 OR D4 OR D5 OR D6 OR D7 OR D8 OR D9 OR D10 OR NEUTRAL OR PARK OR REVERSE  DTCs not fault pending	= FALSE = FALSE = FALSE = FALSE = FALSE  ≥ 1.00 seconds  = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean  Transmission Shift Lever Position Validity		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Up and Down Shift Switch Circuit 2	P1767	Diagnoses the state of the upshift/downshift switch circuit at an illegal voltage, voltage out of range.  Emissions neutral default, disables tap-up tap-down or manual-up manual-down.	switch state update fail time 100 millisecond update rate	= illegal (voltage out of range)	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active P1767 fault active	= FALSE = 0 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE = FALSE	fail time ≥ 60.00 seconds	Emissions Neutral Diagnostics – Type C

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Planetary Gearset Ring Gear Speed Sensor Circuit Range/ Performance	P176B	The diagnostic monitor rationalizes the transmission intermediate shaft speed sensor by using the transmission output shaft output speed sensor and the known ratio between the transmission intermediate shaft speed and the transmission output shaft output speed based on the commanded gear and the transmission lever node design. The estimated transmission intermediate shaft speed is equal to the gear ratio times the transmission output shaft output speed. The absolute value of the delta between the measured transmission intermediate shaft speed and the estimated transmission intermediate shaft speed is used to determine if the measured transmission intermediate shaft speed is rational.	delta1 = ABS (transmission input speed - (transmission output speed * gear ratio commanded))  update fail time 25 millisecond update rate	> 10.0 RPM	diagnostic monitor enable          speed sensor configuration calibration is single OR dual  ratio calibration is function of command gear and intermediate speed sensor when not REVERSE  ratio calibration is function of command gear and intermediate speed sensor when REVERSE  ***** delay time updates when: estimated transmission intermediate speed (transmission input speed / ratio calibration)	= 1 Boolean          = CeTNSR_e_NSPD_Singl eSpdSnsr  <b>P176B ratio calibration</b> = <b>when not REVERSE</b> see supporting tables  <b>P176B ratio calibration</b> = <b>when REVERSE</b> see supporting tables ***** ≥ <b>P176B minimum estimated transmission intermediate speed to enable fail evaluation</b> see supporting tables	fail time ≥ <b>P176B intermediate speed sensor fail time threshold</b> see supporting tables  fail time threshold met increments fail count, fail count ≥ <b>P176B intermediate speed sensor fail count threshold</b> see supporting tables  ***** delay time ≥	Type A, 1 Trips



20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>with</p> <p>transmission input speed</p> <p>input speed sensor ready based on commaned gear and transmission intermediate speed sensor (state output must be FALSE to enable fail evaluation) with with attained gear</p> <p>*****</p> <p>transmission input speed transmission output speed neutral idle mode range shift state P0716 fault active P0717 fault active P07BF fault active P07C0 fault active P0722 fault active P0723 fault active P077C fault active P077D fault active P176C fault active P176D fault active battery voltage</p>	<p>P176B minimum transmission input speed to enable fail ≥ evaluation see supporting tables</p> <p>P176B holding clutch = states see supporting tables</p> <p>= REVERSE OR = 1st thru 10th</p> <p>*****</p> <p>≥ 172.0 RPM ≥ 89.0 RPM = nuetral idle mode ON = range shift complete = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE ≥ 9.00 volts</p> <p>= FALSE ≥ 9.00 volts</p>	P176B delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation see supporting tables	

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					service fast learn active run crank voltage  transmission hydraulic pressure available: engine speed	≥ 500.0 RPM	battery voltage time ≥ 0.100 seconds  run crank voltage time ≥ 0.100 seconds  engine speed time ≥ <b>engine speed time for transmission hydraulic pressure available</b> see supporting tables	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Planetary Gearset Ring Gear Speed Sensor Circuit Low	P176C	Controller specific analog circuit diagnoses the transmission intermediate speed sensor and wiring for a short to ground fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission intermediate speed sensor raw voltage, update fail time, 12.5 millisecond update rate	$\leq$ volts ( $\leq 0.5 \Omega$ impedance between signal and controller ground)	service mode \$04 active diagnostic monitor enable  P176D fault active service fast learn  run crank voltage battery voltage  P176C fault active P176C test fail this key on	= FALSE = <b>P176C Enable Boolean</b>  = FALSE = FALSE  $\geq 10.00$ volts $\geq 10.00$ volts  = FALSE = FALSE	fail time $\geq$ <b>P176C Fail Timer</b> seconds, update fail count, fail count $\geq$ <b>P176C Fail Count Threshold</b> counts 6.25 millisecond update rate  run crank and battery voltage time $\geq 5.000$ seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Planetary Gearset Ring Gear Speed Sensor Circuit High	P176D	Controller specific analog circuit diagnoses the transmission intermediate speed sensor and wiring for a short to voltage fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission intermediate speed sensor raw voltage, update fail time, 12.5 millisecond update rate	<b>P176D Voltage Fail</b> ≥Threshold volts (≤ 0.5 Ω impedance between signal and controller power)	service mode \$04 active diagnostic monitor enable  P176C fault active service fast learn   run crank voltage battery voltage  P176D fault active P176D test fail this key on	= FALSE = <b>P176D Boolean Enable</b>  = FALSE = FALSE   ≥ 10.00 volts ≥ 10.00 volts  = FALSE = FALSE	fail time ≥ <b>P176D Fail Time Threshold</b> seconds, update fail count, fail count ≥ <b>P176D Fail Count Threshold</b> counts 6.25 millisecond update rate  run crank and battery voltage time ≥ 5.000 seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intermediate Speed Sensor 1 Direction Error	P17D3	The diagnostic monitor determines if the direction transmission intermediate speed sensor value is coherent based on the on period time of the directional sensor and raw speed sensor value. When the on period time indicates a transitional state, the direction must also be transitional as measured by very slow raw signal RPM. When the on period time indicates a non-transitional state, forward or reverse, the direction must also be transition, not forward and not reverse.	intermediate speed sesnor raw direction when transitional period = FALSE AND intermediate speed sesnor raw direction when transitional period = FALSE OR intermediate speed sesnor raw when transitional period = TRUE  update fail and sample time 6.26 millisecond update rate	≠ FORWARD  ≠ REVERSE  <b>P17C5 P17D3 intermediate speed ≥ sensor RPM</b>	service mode \$04 active diagnostic monitor enable intermediate speed sesnor count sample period P17D3 fault active OR P17D3 test fail this key on senor type cailbration (senor type is directional)  transitional period detected = FALSE when: on period OR on period when direction unknown OR on period on period when direction is reverse OR on period on period when direction is forward  transitional period detected = TRUE when: on period on period when direction unknown	= FALSE = 1 Boolean ≠ 0 counts  = FALSE = FALSE = CeTNSR_e_NSPD_Singl eSpdSnsr  ≥ 0.4434 seconds ≤ 0.2773 seconds  < 0.2363 seconds > 0.1240 seconds  < 0.0811 seconds > 0.0088 seconds  < 0.4434 seconds > 0.2773 seconds	fail time ≥ 3.500 seconds out of sample time ≥ 5.000 seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Up and Down Shift Switch Performance	P1876	<p>This diagnostic monitor rationalizes the PRNDL, transmission shift lever position, against the state for the tap-up-tap-down (TUTD) enable switch or the manual-up-manual-down (MUMD) enable switch. The switch circuit is considered failing when the PRNDL is in park, reverse or neutral, and the switch circuit is indicating the switch in in the enable, or TUTD/ MUMD function request state. The switch can only be in the enable state when the PRNDL is in the appropriate drive range, for example D9, D8 or D7, but not in park, reverse or neutral.</p> <p>Emissions neutral default, disables tap-up tap-down or manual-up manual-down.</p>	<p>(PRNDL OR PRNDL OR PRNDL)</p> <p>AND</p> <p>(shift lever range calibration is tap-up-tap-down (TUTD) OR shift lever range calibration is manual-up-manual-down (MUMD))</p> <p>AND</p> <p>TUTD/MUMD enable request (switch state)</p> <p>update fail time</p> <p>100 millisecond update rate</p>	<p>= NEUTRAL</p> <p>= REVERSE</p> <p>= PARK</p> <p>=</p> <p>CeTUDR_e_MUMD_ModeOnly</p> <p>= TRUE</p>	<p>service mode \$04 active diagnostic monitor enable (P1876 test fail this key on OR P1876 fault active)</p> <p>PRNDL OR PRNDL OR PRNDL</p> <p>DTCs not test fail this key on</p> <p>DTCs not fault active</p>	<p>= FALSE</p> <p>= 0 Boolean</p> <p>= FALSE</p> <p>= FALSE</p> <p>= NEUTRAL</p> <p>= REVERSE</p> <p>= PARK</p> <p>P0815, P0816, P0826</p> <p>Transmission Shift Lever Position Validity U0100, P0815, P0816, P0826, P1761, P0707, P0708</p>	<p>fail time ≥ 3.00 seconds, update fail count</p> <p>fail count ≥ 5 counts</p> <p>100 millisecond update rate</p>	Emissions Neutral Diagnostics – Type C

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Switch Run/ Start Position Circuit Low	P2534	Detects a low ignition switch run/start position circuit. This diagnostic reports the DTC when this circuit is low. Monitoring occurs when the TCM run/crank is active.	Ignition switch Run/Start position circuit low	TCM Run / Crank = FALSE	Ignition switch Run/Start position circuit low diag enable  and Run / Crank active ECM	= 1.00   = TRUE	280 failures out of 280 samples  25 ms / sample	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Switch Run/ Start Position Circuit High	P2535	Detects a high ignition switch run/start position circuit. This diagnostic reports the DTC when this circuit is high. Monitoring occurs when the TCM run/crank is NOT active.	Ignition switch Run/Start position circuit high	TCM Run / Crank = TRUE	Ignition switch Run/Start position circuit low diag enable  and Run / Crank active ECM	= 1.00   = FALSE	280 failures out of 280 samples  25 ms / sample	Type A, 1 Trips



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Actuator Supply Voltage B Circuit Low	P2670	Controller specific output driver circuit diagnoses the high sided driver circuit for a short to ground failure, or where controller H/W cannot differentiate, diagnoses the high sided driver circuit for a short to ground failure or open circuit failure, when the output is powered on, by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	$\leq \leq 0.5 \Omega$ impedance between signal and controller ground	diagnostic monitor enable high side drive 2 ON P2670 fault active P2670 test fail this key on	= 1 Boolean = TRUE = FALSE = FALSE	<p>fail count <math>\geq 6</math> counts out of sample count <math>\geq 2,400</math> counts</p> <p>6.25 millisecond update rate</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid D Stuck Off (GF9)	P2714	Each pressure control solenoid stuck off diagnostic monitor detects a clutch pressure control solenoid failed hydraulically off, while the solenoid is electrically functional. In the failure mode the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM. The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line	C4 clutch slip speed, update fail time 6.25 millisecond update	≥ 200.0 RPM	<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active</p> <p>service solenoid cleaning</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean</p>	<p>fail time ≥ 3.00 seconds, update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch pressure control solenoid is failed hydraulically off, the clutch does not maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable. The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed in the opposite sense, clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional, which must take priority over any clutch pressure control solenoid stuck off diagnostic monitor. All clutch pressure control			<p>procedure active</p> <p>hydraulic pressure available</p> <p>*****</p> <p>enable C4 clutch slip speed fail compare when:</p> <p>((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below)</p> <p>unintended deceleration fault pending OR unintended deceleration fault pending enable cal is FALSE (startle mitigation)</p> <p>clutch steady state adaptive active</p> <p>(transmission output shaft speed OR (accelerator pedal position OR engine speed)</p> <p>C4 clutch slip speed valid</p>	<p>= FALSE Boolean</p> <p>= TRUE</p> <p>*****</p> <p>= FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 (0 to enable, 1 to disable)</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 %</p> <p>≥ 1,500.0 RPM</p> <p>= TRUE (all speed sensors are functional for lever node clutch slip speed calculation)</p>	≥ 0.900 seconds	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck off test is disabled. This diagnostic monitor is relative to C4 GF9 clutch pressure control solenoid.			C4 clutch pressured map  (enable forward gear cal AND driver direction request AND Attained Gear) OR (enable reverse gear cal AND driver direction request AND Attained Gear)  P2821 (clutch select valve stuck on) test active  range shift state  ***** DTCs not fault pending          DTCs not fault active	= mapped to line pressure, C4 clutch pressure has reached fully applied state  = 1 (1 to enable, 0 to disable) = FORWARD  = a FORWARD gear  = 0 (1 to enable, 0 to disable) = REVERSE  = REVERSE  = FALSE  = range shift complete  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>DTCs not test fail this key on</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797 P2715 P2724 P2733 P2821</p>	<p>P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid D Stuck On	P2715	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	<p>shift type is power down shift: C4 clutch slip speed</p> <p>OR</p> <p>shift type is garage shift: C4 clutch slip speed</p> <p>ELSE</p> <p>shift is another type: C4 clutch slip speed</p> <p>update fail time 6.25 millisecond update</p>	<p>&lt; 50.00 RPM</p> <p>&lt; 100.00 RPM</p> <p>&lt; 50.00 RPM</p>			<p>Base fail time:</p> <p>shift type is power down shift: fail time ≥ 0.80 seconds</p> <p>shift type is garage shift: fail time ≥ 0.25</p> <p>shift type is another type: fail time ≥ 0.15 seconds</p> <p>Add fail time offset according to shift type:</p> <p>open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b></p> <p>open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b></p> <p>garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b></p> <p>closed throttle downshift:</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C4 C4, GR10 C4 C23467810R, or 8 Speed C4 C23468 clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C4 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C4 off going clutch command pressure )	= TRUE Boolean  = TRUE Boolean  = FALSE Boolean  = FALSE Boolean  = TRUE  *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350 kPa	exhaust delay by shift type:	



20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck	$\geq 8,192 \text{ Nm}$ $= 0$ (0 is enable, 1 is	closed throttle upshift: <b>C4 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C4 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C4 exhaust delay garage shift</b>  closed throttle downshift: <b>C4 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C4 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C4 exhaust delay open throttle power down shift</b>	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

[illegible]

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>conditions needed to trigger test:</p> <p>(current shift type AND shift type enable cal for current shift type) OR</p> <p>(Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear) OR (stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))</p> <p>clutch stuck off intrusive shift active</p> <p>startle mitigation active (see note on startle mitigation below)</p> <p>(new clutch controller has been initalized</p>	<p>*****</p> <p>≠ Garage shift</p> <p><b>Clutch Stuck On Shift</b> = <b>Type Enable</b> (0 table value will disable, 1 will enable)</p> <p>= FALSE</p> <p>= 0 (0 will enable, 1 will enable)</p> <p>= NEUTRAL OR commanded gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= TRUE</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OR transitioning to a different clutch controller)  current clutch solenoid test state  ***** DTCs not fault pending  DTCs not fault active  DTCs not test fail this key on	= TRUE  transitions to TestState or TUT_HOLD (see note below about state transitions)  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA  P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions:            Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing.            AND            That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold.            Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the automatic transmission</p>	<p>P17C6 P17C4 P17C7 P172A P172B *****</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>shift, until: An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute. OR The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended vehicle deceleration</p>			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					occurred. Once a safe vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid D Control Circuit Open	P2718	Controller specific circuit diagnoses 9 speed C4, 10 speed C23467810R, 8 speed C23468 clutch, or CVT input clutch, solenoid for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates an open circuit  Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit  Increment fail time	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage  OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00 \text{ volts and } \leq 32.00 \text{ volts}$  $\geq 5.00 \text{ volts}$  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00 \text{ seconds}$  $\geq 25 \text{ milliseconds}$  $\geq 12.5 \text{ milliseconds}$	Type A, 1 Trips



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid D Control Circuit Low	P2720	Controller specific circuit diagnoses 9 speed C4, 10 speed C23467810R, 8 speed C23468 clutch, or CVT input clutch, solenoid for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid D Control Circuit High	P2721	Controller specific circuit diagnoses 9 speed C4, 10 speed C23467810R, 8 speed C23468 clutch, or CVT input clutch, solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid E Stuck Off (GF9)	P2723	Each pressure control solenoid stuck off diagnostic monitor detects a clutch pressure control solenoid failed hydraulically off, while the solenoid is electrically functional. In the failure mode the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM. The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line	C5 clutch slip speed, update fail time 6.25 millisecond update	≥ 200.0 RPM	<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active</p> <p>service solenoid cleaning</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean</p>	<p>fail time ≥ 3.00 seconds, update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch pressure control solenoid is failed hydraulically off, the clutch does not maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable. The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed in the opposite sense, clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional, which must take priority over any clutch pressure control solenoid stuck off diagnostic monitor. All clutch pressure control			<p>procedure active</p> <p>hydraulic pressure available</p> <p>*****</p> <p>enable C5 clutch slip speed fail compare when:</p> <p>((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below)</p> <p>unintended deceleration fault pending OR unintended deceleration fault pending enable cal is FALSE (startle mitigation)</p> <p>clutch steady state adaptive active</p> <p>(transmission output shaft speed OR (accelerator pedal position OR engine speed)</p> <p>C5 clutch slip speed valid</p>	<p>= FALSE Boolean</p> <p>= TRUE</p> <p>*****</p> <p>= FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 (0 to enable, 1 to disable)</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 %</p> <p>≥ 1,500.0 RPM</p> <p>= TRUE (all speed sensors are functional for lever node clutch slip speed calculation)</p>	≥ 0.900 seconds	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck off test is disabled. This diagnostic monitor is relative to C5 GF9 C57R clutch pressure control solenoid.			C5 clutch pressured map  (enable forward gear cal AND driver direction request AND Attained Gear) OR (enable reverse gear cal AND driver direction request AND Attained Gear)  P2821 (clutch select valve stuck on) test active  range shift state  ***** DTCs not fault pending         DTCs not fault active	= mapped to line pressure, C5 clutch pressure has reached fully applied state  = 1 (1 to enable, 0 to disable) = FORWARD  = a FORWARD gear  = 0 (1 to enable, 0 to disable) = REVERSE  = REVERSE  = FALSE  = range shift complete  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>DTCs not test fail this key on</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797 P2715 P2724 P2733 P2821</p>	<p>P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p>		

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid E Stuck On	P2724	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	shift type is power down shift: C5 clutch slip speed OR shift type is garage shift: C5 clutch slip speed ELSE shift is another type: C5 clutch slip speed  update fail time 6.25 milliscond update	< 50.00 RPM  < 100.00 RPM  < 50.00 RPM			Base fail time:  shift type is power down shift: fail time ≥ 0.40 seconds  shift type is garage shift: fail time ≥ 0.25  shift type is another type: fail time ≥ 0.15 seconds  Add fail time offset according to shift type:  open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b>  open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b>  garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b>  closed throttle downshift:	Type A, 1 Trips

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C5 C57R, GR10 C5 C1356789, or 8 Speed C5 C45678R clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C5 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C5 off going clutch command pressure )	= TRUE Boolean  = TRUE Boolean  = FALSE Boolean  = FALSE Boolean  = TRUE  *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350 kPa	exhaust delay by shift type:	

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck	$\geq 8,192 \text{ Nm}$ $= 0$ (0 is enable, 1 is	closed throttle upshift: <b>C5 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C5 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C5 exhaust delay garage shift</b>  closed throttle downshift: <b>C5 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C5 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C5 exhaust delay open throttle power down shift</b>	

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					on torque enable cal)  OR  ( primary oncoming clutch active  primary on coming control state  primary on coming commanded pressure)	enable)  = TRUE  ≠ clutch fill phase  ≥ pressure clip threshold according to shift type:  closed throttle upshift: <b>Clutch Clip Press CU Shifts</b>  open throttle upshift: <b>Clutch Clip Press PU Shifts</b>  garage shifts: <b>Clutch Clip Press GS Shifts</b>  closed throttle downshift: <b>Clutch Clip Press CD Shifts</b>  negative torque upshift: <b>Clutch Clip Press NU Shifts</b>  open throttle downshift: <b>Clutch Clip Press PD Shifts</b>  = TRUE	absolute value of ( -0.60 ) seconds	
					C5 clutch slip speed valid, all speed sensors are functional for lever node clutch slip speed	= TRUE		

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					calculation ***** conditions needed to trigger test: (current shift type AND shift type enable cal for current shift type) OR (Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear) OR (stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear)) clutch stuck off intrusive shift active startle mitigation active (see note on startle mitigation below) (new clutch controller has	≠ Garage shift <b>Clutch Stuck On Shift            = Type Enable</b> (0 table value will disable, 1 will enable) = FALSE = 0 (0 will enable, 1 will enable) = NEUTRAL OR commanded gear = 0 (0 to disable, 1 to enable) = FORWARD = a FORWARD gear = 0 (0 to disable, 1 to enable) = REVERSE = REVERSE = FALSE = FALSE		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>been initalized OR transitioning to a different clutch controller)</p> <p>current clutch solenoid test state</p> <p>*****</p> <p>DTCs not fault pending</p> <p>DTCs not fault active</p> <p>DTCs not test fail this key on</p>	<p>= TRUE</p> <p>= TRUE</p> <p>transitions to TestState or TUT_HOLD (see note below about state transitions)</p> <p>*****</p> <p>P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6</p> <p>P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions: Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing. AND That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold. Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the</p>	<p>P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B *****</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>automatic transmission shift, until: An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute. OR The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended</p>			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					vehicle deceleration occurred. Once a safe vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid E Control Circuit Open	P2727	Controller specific circuit diagnoses 9 speed C57R, 10 speed C1356789, or 8 speed C45678R clutch solenoid for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates an open circuit  Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit  Increment fail time	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage  OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00 \text{ volts and } \leq 32.00 \text{ volts}$  $\geq 5.00 \text{ volts}$  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid E Control Circuit Low	P2729	Controller specific circuit diagnoses 9 speed C57R, 10 speed C1356789, or 8 speed C45678R clutch solenoid for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid E Control Circuit High	P2730	Controller specific circuit diagnoses 9 speed C57R, 10 speed C1356789, or 8 speed C45678R clutch solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F (GF9)	P2731	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	common logic between P2731 and P2733  shift type is power down shift: C6 clutch slip speed OR shift type is garage shift: C6 clutch slip speed ELSE shift is another type: C6 clutch slip speed  P2731 specific attained gear  update fail time 6.25 milliscond update	< 50.00 RPM  < 100.00 RPM  < 50.00 RPM  = 1st lock OR = 1st free wheel			Base fail time:  shift type is power down shift: fail time ≥ 0.80 seconds  shift type is garage shift: fail time ≥ 0.25  shift type is another type: fail time ≥ 0.15 seconds  Add fail time offset according to shift type:  open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b>  open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b>  garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b>  closed throttle downshift:	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C6 Selectable One Way Clutch (SOWC) / CBR1 clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C6 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C6 off going clutch command pressure )	= TRUE Boolean  = TRUE Boolean  = FALSE Boolean  = FALSE Boolean  = TRUE  *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350 kPa	exhaust delay by shift type:	

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck on torque enable cal)	$\geq 8,192 \text{ Nm}$ $= 0$ (0 is enable, 1 is enable)	closed throttle upshift: <b>C6 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C6 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C6 exhaust delay garage shift</b>  closed throttle downshift: <b>C6 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C6 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C6 exhaust delay open throttle power down shift</b>	

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>OR</p> <p>( primary oncoming clutch active</p> <p>primary on coming control state</p> <p>primary on coming commanded pressure)</p> <p>C5 clutch slip speed valid, all speed sensors are functional for lever node clutch slip speed calculation</p>	<p>= TRUE</p> <p>≠ clutch fill phase</p> <p>≥ pressure clip threshold according to shift type:</p> <p>closed throttle upshift: <b>Clutch Clip Press CU Shifts</b></p> <p>open throttle upshift: <b>Clutch Clip Press PU Shifts</b></p> <p>garage shifts: <b>Clutch Clip Press GS Shifts</b></p> <p>closed throttle downshift: <b>Clutch Clip Press CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>open throttle downshift: <b>Clutch Clip Press PD Shifts</b></p> <p>= TRUE</p>	absolute value of ( -0.60 ) seconds	



# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>conditions needed to trigger test:</p> <p>(current shift type AND shift type enable cal for current shift type) OR</p> <p>(Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear) OR (stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))</p> <p>clutch stuck off intrusive shift active</p> <p>startle mitigation active (see note on startle mitigation below)</p> <p>(new clutch controller has been initalized</p>	<p>*****</p> <p>≠ Garage shift</p> <p><b>Clutch Stuck On Shift</b> = <b>Type Enable</b> (0 table value will disable, 1 will enable)</p> <p>= FALSE</p> <p>= 0 (0 will enable, 1 will enable)</p> <p>= NEUTRAL OR commanded gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= TRUE</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OR transitioning to a different clutch controller)  current clutch solenoid test state  ***** DTCs not fault pending          DTCs not fault active          DTCs not test fail this key on	= TRUE  transitions to TestState or TUT_HOLD (see note below about state transitions)  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA  P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions:            Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing.            AND            That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold.            Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the automatic transmission</p>	<p>P17C6 P17C4 P17C7 P172A P172B *****</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>shift, until:  An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute.  OR  The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended vehicle deceleration</p>			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					occurred. Once a safe vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F Stuck Off (GF9)	P2732	Each pressure control solenoid stuck off diagnostic monitor detects a clutch pressure control solenoid failed hydraulically off, while the solenoid is electrically functional. In the failure mode the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM. The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line	C6 clutch slip speed, update fail time 6.25 millisecond update	≥ 200.0 RPM	<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active</p> <p>service solenoid cleaning</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean</p>	<p>fail time ≥ 3.00 seconds, update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch pressure control solenoid is failed hydraulically off, the clutch does not maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable. The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed in the opposite sense, clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional, which must take priority over any clutch pressure control solenoid stuck off diagnostic monitor. All clutch pressure control			<p>procedure active</p> <p>hydraulic pressure available</p> <p>*****</p> <p>enable C6 clutch slip speed fail compare when:</p> <p>((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below)</p> <p>unintended deceleration fault pending OR unintended deceleration fault pending enable cal is FALSE (startle mitigation)</p> <p>clutch steady state adaptive active</p> <p>(transmission output shaft speed OR (accelerator pedal position OR engine speed)</p> <p>C6 clutch slip speed valid</p>	<p>= FALSE Boolean</p> <p>= TRUE</p> <p>*****</p> <p>= FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 (0 to enable, 1 to disable)</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 %</p> <p>≥ 1,500.0 RPM</p> <p>= TRUE (all speed sensors are functional for lever node clutch slip speed calculation)</p>	≥ 0.900 seconds	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck off test is disabled. This diagnostic monitor is relative to GF9 C6 C6789/Selectable One Way Clutch (SOWC) CBR1 clutch pressure control solenoid.			C6 clutch pressured map  (enable forward gear cal AND driver direction request AND Attained Gear) OR (enable reverse gear cal AND driver direction request AND Attained Gear)  P2821 (clutch select valve stuck on) test active  range shift state  ***** DTCs not fault pending         DTCs not fault active	= mapped to line pressure, C6 clutch pressure has reached fully applied state  = 1 (1 to enable, 0 to disable) = FORWARD = a FORWARD gear = 0 (1 to enable, 0 to disable) = REVERSE = REVERSE = FALSE = range shift complete  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727		



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>DTCs not test fail this key on</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797 P2715 P2724 P2733 P2821</p>	<p>P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F Stuck On (GF9 and GR10)	P2733	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	common logic between P2731 and P2733  shift type is power down shift: C6 clutch slip speed OR shift type is garage shift: C6 clutch slip speed ELSE shift is another type: C6 clutch slip speed  P2733 specific attained gear  update fail time  6.25 millisecond update	< 50.00 RPM  < 100.00 RPM  < 50.00 RPM  ≠ 1st lock AND ≠ 1st free wheel			Base fail time:  shift type is power down shift: fail time ≥ 0.80 seconds  shift type is garage shift: fail time ≥ 0.25  shift type is another type: fail time ≥ 0.15 seconds  Add fail time offset according to shift type:  open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b>  open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b>  garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b>  closed throttle downshift:	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C6 C6789 or GR10 C6 C45678910R clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C6 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C6 off going clutch command pressure )	= TRUE Boolean          = TRUE Boolean          = FALSE Boolean          = FALSE Boolean          = TRUE          *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350 kPa	exhaust delay by shift type:	

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck on torque enable cal)	$\geq 8,192 \text{ Nm}$ $= 0$ (0 is enable, 1 is enable)	closed throttle upshift: <b>C6 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C6 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C6 exhaust delay garage shift</b>  closed throttle downshift: <b>C6 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C6 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C6 exhaust delay open throttle power down shift</b>	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

[illegible]

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>conditions needed to trigger test:</p> <p>(current shift type AND shift type enable cal for current shift type)  OR</p> <p>(Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear) OR (stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))</p> <p>clutch stuck off intrusive shift active</p> <p>startle mitigation active (see note on startle mitigation below)</p> <p>(new clutch controller has been initalized</p>	<p>*****</p> <p>≠ Garage shift</p> <p><b>Clutch Stuck On Shift</b> = <b>Type Enable</b> (0 table value will disable, 1 will enable)</p> <p>= FALSE</p> <p>= 0 (0 will enable, 1 will enable)</p> <p>= NEUTRAL OR commanded gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= TRUE</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

[illegible]



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions:            Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing.            AND            That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold.            Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the automatic transmission</p>	<p>P17C6 P17C4 P17C7 P172A P172B *****</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>shift, until:  An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute.  OR  The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended vehicle deceleration</p>			

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					occurred. Once a safe vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F Control Circuit Open	P2736	Controller specific circuit diagnoses 9 speed (C6789/SOWC CBR1) clutch, 10 speed C45678910R clutch, 8 speed Line Pressure Control Circuit, or CVT binary pump, solenoid for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates an open circuit  Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit  Increment fail time	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1) OR (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2) OR (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00 \text{ volts and } \leq 32.00 \text{ volts}$  $\geq 5.00 \text{ volts}$  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00 \text{ seconds}$  $\geq 25 \text{ milliseconds}$  $\geq 12.5 \text{ milliseconds}$	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F Control Circuit Low	P2738	Controller specific circuit diagnoses 9 speed (C6789/SOWC CBR1, 10 speed C45678910R clutch, 8 speed line pressure control, or CVT binary pump, solenoid for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F Control Circuit High	P2739	Controller specific circuit diagnoses 9 speed (C6789/SOWC CBR1), 10 speed C45678910R clutch, 8 speed line pressure control, or CVT binary pump, solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.000$ seconds  25 milliseconds  12.5 milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid A Calibration Incorrect	P27A7	The diagnostic monitor verifies that the pressure control solenoid A (GF9 line or GR10 C1 C123456R clutch or CVT secondary pulley) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid A electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid B Calibration Incorrect	P27A8	The diagnostic monitor verifies that the pressure control solenoid B (GF9 TCC or GR10 C2 C128910R clutch or CVT primary pulley) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid B electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power event during the controller initialization before normal time loop execution	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid C Calibration Incorrect	P27A9	The diagnostic monitor verifies that the pressure control solenoid C (GF9 C1 CB123456 clutch or GR10 C3 C23457910 clutch or CVT line) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid C electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid D Calibration Incorrect	P27AA	The diagnostic monitor verifies that the pressure control solenoid D (GF9 C2 CB29 clutch or GR10 C5 C1356789 clutch pressure or CVT C1 clutch) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid D electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid E Calibration Incorrect	P27AB	The diagnostic monitor verifies that the pressure control solenoid E (GF9 C3 CB38 clutch or GR10 C4 C23467810R clutch or CVT TCC) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid E electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F Calibration Incorrect	P27AC	The diagnostic monitor verifies that the pressure control solenoid F (GF9 C4 C4 clutch or GR10 C6 C45678910R clutch or CVT binary pump) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid F electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid G Calibration Incorrect	P27AD	The diagnostic monitor verifies that the pressure control solenoid G (GF9 C5 C57R clutch or GR10 line or CVT mode valve A ETRS only) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid G electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid H Calibration Incorrect	P27AE	The diagnostic monitor verifies that the pressure control solenoid H (GF9 C6 C6789 clutch or GR10 TCC or CVT mode valve B ETRS only) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid H electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Sensor A/B Correlation	P2805	Internal range sensor A is wired independently to the TCM while internal range sensor B is wired independently to the ECM. The monitor diagnoses the internal range sensor A PWM duty cycle by comparing the raw sensor A value against the raw sensor B adjusted value, to verify signals are consistent, or determine the TCM internal range sensor A does not correlate to the ECM internal range sensor B. The ECM transmits internal range sensor B raw PWM to the TCM over the serial data bus.	ABS((TCM internal range sensor A + ECM internal range sensor B raw adjusted for high or low time) - 100 %))  Increment fail and sample time, update rate 25 milliseconds	> 5.200 % duty cycle	diagnostic monitor enable  P0707 fault active P0708 fault active U0100 fault active ECM internal range sensor B available from ECM ECM internal range sensor B fault active  battery voltage  ABS(TCM internal range sensor A current loop value - TCM internal range sensor A previous loop value), update TCM internal range sensor A stability time, update rate 25 milliseconds  ABS(ECM internal range sensor B current loop value - ECM internal range sensor B previous loop value), update ECM internal range sensor B stability time, update rate 25 milliseconds  TCM internal range sensor A stability time met OR ECM internal range sensor B stability time met  ECM internal range sensor B raw adjusted for	= 1 Boolean  = FALSE = FALSE = FALSE = TRUE  = FALSE  ≥ 9.00 volts  < 1.001 % duty cycle  < 1.001 % duty cycle  = ABS(ECM internal range sensor B raw -	PWM fail time ≥ 2.000 seconds out of sample time ≥ 2.500 seconds      battery voltage time ≥ 1.000 seconds  TCM internal range sensor A stability time ≥ 1.000 seconds  ECM internal range sensor B stability time ≥ 1.000 seconds	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					high or low time	0.000 %)		



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid G Control Circuit Open	P2812	Controller specific circuit diagnoses 9 speed Line Pressure Control Circuit, 10 speed Line Pressure Control Circuit, or 8 speed TCC Control Circuit for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates an open circuit</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit</p> <p>Increment fail time</p>	<p>≥ 200 K Ω impedance between signal and controller ground</p>	<p>battery voltage</p> <p>(run crank voltage</p> <p>OR</p> <p>accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p>≥ 9.00 volts and ≤ 32.00 volts</p> <p>≥ 5.00 volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON</p>	<p>fail time ≥ 0.30 seconds out of sample time ≥ 0.50 seconds</p> <p>≥ 1.00 seconds</p> <p>≥ 25 milliseconds</p> <p>≥ 12.5 milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid G Control Circuit Low	P2814	Controller specific circuit diagnoses 9 speed Line Pressure Circuit, 10 speed Line Pressure Circuit, or 8 speed TCC Control Circuit for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid G Control Circuit High	P2815	Controller specific circuit diagnoses 9 speed Line Pressure Circuit, 10 speed Line Pressure Circuit, or 8 speed TCC Control Circuit for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid H Performance /Stuck Off	P2817	The diagnostic monitor detects the transmission torque converter control valve solenoid failed hydraulically off. The monitor executes when the transmission torque converter is commanded to a "lock" mode during which the torque converter will be controlled to near zero (0.0) RPM slip speed, or, an "on" mode during which the torque converter will be controlled to target slip speed using slip speed error. The transmission torque converter control valve solenoid is considered failed hydraulically off when the "lock" mode slip speed is excessive, or, when the 'on" mode slip speed error is excessive.	if use TCC slip speed error OR TCC control mode  TCC slip speed error = TCC slip speed - TCC comand slip speed  else if TCC control mode torque convert slip = engine speed - transmission input shaft speed  then update fail time 25 millisecond update rate	= 0 Boolean  = ON mode (controlled slip mode) ≥ <b>P2817 TCC stuck off fail TCC slip speed</b> see supporting table  = LOCK ≥ 130.0 RPM	diagnostic monitor enable   TCC command capacity  TCC command pressure  (TCC control mode previous TCC control mode previous TCC control mode previous) AND (TCC control mode current OR TCC control mode current)  (TCC stuck off enable OR TCC stuck on enable) hydraulic pressure available: engine speed	= 1 Boolean   ≥ 0.00 %  ≥ 800.0 kPa  ≠ TCC control mode current ≠ ON mode (controlled slip mode) ≠ LOCK  = ON mode (controlled slip mode) = LOCK  = 1 Boolean  = 1 Boolean  ≥ 500.0 RPM	fail time ≥ 2.500 seconds increment fail count fail count ≥ 3 counts 25 millisecond update rate  TCC command capacity time ≥ 0.00 seconds  TCC command pressure time ≥ 2.00 seconds          engine speed time ≥ <b>engine speed time for transmission hydraulic pressure available</b>	Type B, 2 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					service fast learn active battery voltage  run crank voltage  P281B falut active P281D falut active P281E falut active P0722 fault pending P0723 fault pending P0716 fault pending P0717 fault pending P07BF fault pending P07C0 fault pending (PTO active OR PTO disable calibration) accelerator pedal position accelerator pedal position range shift state transmission fluid temperature transmission fluid temperature engine torque engine torque P2817 test fail this key on (TCC control mode OR TCC control mode) break latch state (clutch select valve solenoid) attained gear  attained gear slip  DTCs not fault active	= FALSE ≥ 9.00 volts  ≥ 9.00 volts  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1 Boolean ≥ 8.0 % ≤ 100.0 % = range shift complete ≥ -6.66 °C  ≤ 130.0 °C  ≥ 50.0 Nm ≤ 8,191.8 Nm = FALSE = ON mode (controlled slip mode) = LOCK = disabled (clutch select valve not transitioning) ≥ CeCGSR_e_CR_Third  ≤ 25 RPM  AcceleratorPedalFailure EngineTorqueEstInaccu te	see supporting table  battery voltage time ≥ 0.100 seconds run crank voltage time ≥ 0.100 seconds	

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P0716, P0717, P07BF, P07C0 P0722, P0723, P077C, P077D		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid H Stuck On - GF9 specific	P2818	The diagnostic monitor detects the transmission torque converter control valve solenoid failed hydraulically on. The torque converter hydraulic control circuit is multiplexed with the transmission clutch select valve hydraulic control circuit, allowing for the torque converter control valve solenoid stuck on test to execute when the clutch select valve solenoid is commanded ON. When the clutch select valve solenoid is commanded ON as the vehicle speed decreases toward zero KPH, and, if the torque converter control valve solenoid is stuck on, the torque converter slip speed rate of change will have a large slope while decreasing toward zero RPM, and the torque converter slip speed will remain low near zero RPM.	while control valve test time timing down: rate of change of torque convert slip speed = (ABS (current loop value torque convert slip speed - previous loop value torque convert slip speed) / 25 milliseconds) when clutch select valve solenoid multiplexed to TCC hydraulic AND torque convert slip speed = ABS(engine speed - transmission input shaft speed) AND torque convert slip speed = engine speed - transmission input shaft speed torque convert slip speed torque convert slip speed THEN increment fail time 25 millisecond update rate	$\geq$ <b>P2818 torque convert derivative slip speed fail threshold</b> see supporting table  $\leq$ <b>P0741 (GF9 specific) TCC slip speed crash RPM</b>  $\geq -50.0 \text{ RPM}$ $\leq 30.0 \text{ RPM}$	diagnostic monitor enable (TCC stuck off enable OR TCC stuck on enable) hydraulic pressure available: engine speed  service fast learn active battery voltage  run crank voltage  P281B falut active P281D falut active P281E falut active  PRNDL PRNDL transmission fluid temperature transmission fluid	= 1 Boolean = 1 Boolean OR = 1 Boolean  $\geq 500.0 \text{ RPM}$  = FALSE $\geq 9.00 \text{ volts}$  $\geq 9.00 \text{ volts}$  = FALSE = FALSE = FALSE  $\neq \text{NEUTRAL}$ $\neq \text{REVERSE}$ $\geq -6.66 \text{ }^{\circ}\text{C}$ $\leq 130.00 \text{ }^{\circ}\text{C}$	fail time $\geq 1.500$ seconds increment fail count fail count $\geq 4$ counts 25 millisecond update rate  engine speed time $\geq$ <b>engine speed time for transmission hydraulic pressure available</b> see supportinf table  battery voltage time $\geq 0.100$ seconds run crank voltage time $\geq 0.100$ seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					temperature accelerator pedal position accelerator pedal position vehicle speed vehicle speed TCC command mode break latch state (clutch select valve solenoid) P0722 fault pending P0723 fault pending P0716 fault pending P0717 fault pending P07BF fault pending P07C0 fault pending (PTO active OR PTO disable calibration) transmission fluid temperature transmission fluid temperature engine torque engine torque P2818 test fail this key on vehicle speed engine speed engine speed accelerator pedal position 4WD low state (driver shift mode active OR driver shift mode calibration) (misfire requests TCC off OR misfire TCC off calibration) (clutch control solenoid stuck on OR stuck OFF intrusive shift active) P0746 fault pending P0747 fault pending P0776 fault pending	≥ 0.00 % ≤ 1.00 % ≥ 3.0 KPH ≤ 9.5 KPH = OFF ≠ disabled (clutch select valve transitioning) = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1 Boolean ≥ -6.66 °C ≤ 130.00 °C ≥ 55.0 Nm ≤ 800.0 Nm = FALSE ≤ 45.0 KPH ≥ 400.0 RPM ≤ 5,500.0 RPM ≤ 95.0 % = FALSE = FALSE = 0 Boolean = FALSE = 0 Boolean = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE		



# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P0777 fault pending P0796 fault pending P0797 fault pending P2714 fault pending P2715 fault pending P2723 fault pending P2724 fault pending P2732 fault pending P2733 fault pending P2820 fault pending P2821 fault pending vehicle speed accelerator pedal position hysteresis  when: break latch state (clutch select valve solenoid) previous break latch state (clutch select valve solenoid) set stuck on test time and begin time down, stuck on test time must time down from calibration value to zero (0.0) seconds  break latch state (clutch select valve solenoid) AND  previous break latch state (clutch select valve solenoid) THEN initialize control valve test time, control valve test time must time down from calibration value to zero (0.0) seconds	= FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE ≤ 8.0 KPH ≥ 4.0 % > 1.0 %  = disabled (clutch select valve not transitioning) = complete (clutch select valve transition complete) = <b>P2818 stuck on test time</b> see supporting tables  = clutch select valve solenoid multiplexed to TCC hydraulic  = disabled (clutch select valve not transitioning) = <b>P2818 (GF9 specific)</b> <b>control valve test time</b> see supporting tables		

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					DTCs not fault active	AcceleratorPedalFailure EngineTorqueEstInaccura te P0716, P0717, P07BF, P07C0 P0722, P0723, P077C, P077D		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid H Control Circuit Open	P281B	Controller specific circuit diagnoses 9 speed TCC Control Circuit, 10 speed TCC Control Circuit, or 8 speed T93 Default Valve Control Circuit for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates an open circuit</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit</p> <p>Increment fail time</p>	≥ 200 K Ω impedance between signal and controller ground	<p>battery voltage</p> <p>(run crank voltage</p> <p>OR</p> <p>accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p>≥ 9.00 volts and ≤ 32.00 volts</p> <p>≥ 5.00 volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON</p>	<p>fail time ≥ 0.30 seconds out of sample time ≥ 0.50 seconds</p> <p>≥ 1.00 seconds</p> <p>≥ 25 milliseconds</p> <p>≥ 12.5 milliseconds</p>	Type B, 2 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid H Control Circuit Low	P281D	Controller specific circuit diagnoses 9 speed TCC Pressure Control Circuit, 10 speed TCC Control Circuit, or 8 speed Default Valve Control Circuit for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds. For 8 speed T87a controllers, an open circuit on the Default Valve Control Circuit will also set P281D.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid H Control Circuit High	P281E	Controller specific circuit diagnoses 9 speed TCC Pressure Control Circuit, 10 speed TCC Control Circuit, or 8 speed Default Valve Control Circuit for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type B, 2 Trips

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid J Stuck Off (GF9)	P2820	<p>Each pressure control solenoid stuck off diagnostic monitor detects a control solenoid failed hydraulically off, while the solenoid is electrically functional. This diagnostic monitor detects the clutch select valve solenoid failed hydraulically off. The clutch select valve is used to route hydraulic fluid to, either, the selectable one way clutch hydraulic circuit used to attain transmission 1st gear lock state, or, to the C6 - C6789 clutch hydraulic circuit necessary for transmission higher gear states.</p> <p>When the clutch select valve is failed hydraulically off, and transmission is in 1st gear lock state, it is possible to measure low C6 - C6789 clutch slip speed or 6th gear transmission ratio, since hydraulic fluid is routed to the clutch C6 - C6789. This can be determined based on transmission lever node design, the</p>	<p>(gear ratio AND gear ratio) OR C6 clutch slip speed</p> <p>update fail time 6.25 milliscond update</p>	<p>≤ 1.700 ≥ 1.200 ≤ 20.0 RPM</p>	<p>***** system-level enables:  use battery voltage calibration is FALSE  OR  (use battery voltage calibration is TRUE  AND battery voltage)  use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)  TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active</p>	<p>*****  = 1 Boolean   = 1 Boolean   ≥ 9.00 volts  = 0 Boolean = 0 Boolean ≥ 9.00 volts  = TRUE Boolean  = TRUE Boolean = FALSE Boolean</p>	<p>fail time ≥ 0.250 seconds, update fail count, fail count ≥ 3 counts 6.25 milliscond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>transmission input shaft speed, the transmission output shaft speed, and one transmission intermediate shaft speed, while not commanding 6th-9th gear.</p> <p>This diagnostic monitor is relative to the GF9 clutch select valve pressure control solenoid.</p>			<p>service solenoid cleaning procedure active</p> <p>hydraulic pressure available *****</p> <p>diagnostic monitor enabled</p> <p>transmission output shaft speed</p> <p>transmission fluid temperature</p> <p>transmission fluid temperature</p> <p>(command gear AND attained gear) OR (attained gear AND SOWC state)</p> <p>C6 clutch slip speed valid *****</p> <p>DTCs not fault pending</p> <p>DTCs not fault active</p>	<p>= FALSE Boolean</p> <p>= TRUE *****</p> <p>= 1 (1 to enable, 0 to disable)</p> <p>≥ 35 RPM</p> <p>≥ -256.00 °C</p> <p>≤ 130.0 °C</p> <p>= 1st lock</p> <p>= 1st lock</p> <p>= 2nd lock</p> <p>= APPLY COMPLETE</p> <p>= TRUE *****</p> <p>P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6</p> <p>P2534 P0707 P0708 P0716 P0717 P07C0</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					DTCs not test fail this key on	P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA  P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B		



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid J Stuck On (GF9)	P2821	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch select pressure control solenoid must be hydraulically off and the clutch select valve in the off state, to allow hydraulic fluid supply to the C3 (CB38) or C4 (C4) or C5 (C57R) clutches, such that when activated, commanded gear 3rd or 4th or 5th can be attained. With the clutch select valve pressure control solenoid failed hydraulically on, commanded gear 3rd or 4th or 5th cannot be attained. In the failure mode, the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM, when commanding 3rd or 4th or 5th gear, but due to the clutch select pressure control solenoid failed hydraulically on and not	Cx clutch slip speed fail compare C3 (CB38) OR C4 (C4) OR C5 (C57R) update Cx clutch slip speed fail time 6.25 milliscond update  once intrusive gear is commanded and clutch select stuck on test active remains and Cx clutch fail count limit occurs, increment clutch select valve solenoid stuck on fail count and time up clutch select stuck on test gear time 6.25 milliscond update	≥ 200.0 RPM ≥ 200.0 RPM ≥ 200.0 RPM       = TRUE			Cx clutch slip speed fail time ≥  (C3 (CB38) 3.00 seconds OR C4 (C4) 3.00 seconds OR C5 (C57R) 3.00 seconds)  update Cx fail count,  Cx fail count ≥ (C3 (CB38) 3 counts OR C4 (C4) 3 counts OR C5 (C57R) 3 counts)  Cx clutch fail count limit occurs 6.25 milliscond update  clutch select valve solenoid stuck on fail count ≥ 2 counts OR clutch select stuck on test gear time ≥ 9.00 seconds	Type A, 1 Trips

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>individual clutch control faults. It is thus necessary, when individual clutch slip occurs in 3rd or 4th or 5th gear and counted toward the clutch pressure control solenoid stuck on failure, for an intrusive gear commanded from 3rd or 4th or 5th to verify the clutch slip in the remaining gear states. The individual clutch slip that occurs in those intrusive gears, 3rd or 4th or 5th, is also counted toward the clutch pressure control solenoid stuck on failure. As individual clutch slip is accumulated in each commanded gear 3rd or 4th or 5th, that failure time is the verification of the clutch pressure control solenoid failed hydraulically on.</p> <p>The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch</p>			<p>***** system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active service solenoid cleaning procedure active</p> <p>hydraulic pressure available</p> <p>***** diagnostic monitor enable</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 0 Boolean</p> <p>= 0 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean = FALSE Boolean</p> <p>= TRUE</p> <p>***** = 1 Boolean</p>	<p>6.25 milliscond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch select pressure control solenoid is failed hydraulically on, C3 (CB38) or C4 (C4) or C5 (C57R) clutches cannot maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable.</p> <p>The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is</p>			<p>P2821 test fail this key on</p> <p>test trigger set to TRUE: enable forward gear AND direction request OR enable reverse gear AND direction request current loop test trigger clutch control solenoid test state range shift state</p> <p>clutch solenoid test state set to NEUTRAL TEST when: test trigger initialize range shift complete time, when range shift state, range shift complete time must time down to zero when range shift complete</p> <p>Cx indicates any one of the 3 clutches: C3 (CB38) OR C4 (C4) OR C5 (C57R)</p> <p>enable Cx clutch slip speed fail compare when: diagnostic clutch test Cx ((startle mitigation active OR (startle mitigation active</p>	<p>= FALSE</p> <p>= 1 Boolean = forward gear</p> <p>= 0 Boolean = reverse gear = FALSE ≠ NEUTRAL TEST</p> <p>= range shift completed</p> <p>= TRUE</p> <p>≠ range shift completed</p> <p>= HOLDING CLUTCH = FALSE</p> <p>= TRUE</p>	<p>initialize range shift complete time = 0.900 seconds, range shift complete time must time down to zero when range shift complete</p>	

# 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional, which, must take priority over this clutch select pressure control solenoid stuck off diagnostic monitor. All clutch pressure control solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the a clutch pressure control solenoid stuck off test is disabled.</p> <p>This diagnostic monitor is relative to the GF9 clutch select valve pressure control solenoid.</p>			<p>AND startle mitigation gear)) (see startle mitigation active NOTE below) unintended deceleration fault pending OR unintended deceleration fault pending enable FASLE (startle mitigation) clutch steady state adaptive active transmission output shaft speed Cx clutch slip speed valid, all speed sesnors are functional for lever node cluth slip speed calculation</p> <p>accelerator pedal position engine speed</p> <p>diagnostic clutch test Cx set to HOLDING CLUTCH when: clutch solenoid test state ((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below) Cx clutch pressured map</p> <p>***** clutch select stuck on test active set to TRUE when:</p>	<p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 Boolean</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 % ≥ 1,500.0 RPM</p> <p>= NEUTRAL TEST = FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= mapped to line pressure, Cx clutch pressure has transtioned from off-applying-applied</p> <p>*****</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>command gear clutch control solenoid test state any Cx clutch fail count limit occurs break latch state, clutch select valve hydraulic latch fluid is applied, hydraulic latch fluid force balance acts with clutch select valve return spring, to force the clutch select valve to the off position in normal operation, allowing hydraulic fluid to C3 (CB38) C4 (C4) and C5 (C57R) clutches</p> <p>clutch select stuck on test active driver direction (PRNDL) change request, select intrusive gear to verify clutch select valve solenoid when HOLDING CLUTCH: C3 (CB38) C4 (C4) C5 (C57R) enable clutch select stuck on test gear time</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797</p>	<p>≠ REVERSE = NEUTRAL TEST</p> <p>= complete</p> <p>= TRUE</p> <p>= FALSE</p> <p>= CeCGSR_e_Fifth = CeCGSR_e_Fifth = CeCGSR_e_Third</p>		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

[illegible]

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Stall Prevention Active Signal Message Counter Incorrect	P30BD	The diagnostic monitor detects an alive rolling count error in the CAN frame containing the engine stall protection signal value. The alive rolling count sequences 0, 1, 2, 3 repeatedly. As each serial data frame is broadcast by the transmitting controller, the transmitting controller increments the alive rolling count in this sequence manner. The receiving controller compares the most recent received alive rolling count value to the previous value plus one. If the values are not equal, an alive rolling count error has occurred. If continuous alive rolling count errors occur the DTC is set.	rolling count value received from ECM and expected TCM calculated value not equal  50 millisecond update rate	= TRUE	10 millisecond update rate of enable conditions  service mode \$04 active battery voltage battery voltage time  engine stall protection ECM frame recieved	= FALSE ≥ 11.00 volts ≥ 300.000 seconds  = TRUE	alive rolling count errors ≥ 8 out of 10 sample counts  50 millisecond update rate	Type B, 2 Trips

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communicati on Bus A Off	U0073	This DTC monitors for a BUS A off condition	Bus off failures exceeds  before the sample time of is reached	3 counts (equivalent to 0.04 seconds)  0.81 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Run/Crank Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds  CAN hardware is bus OFF for	Not Active on Current Key Cycle  Enabled  Not Active  Not Active  > 6.41 Volts  = run  = 1 ( 1 indicates enabled)  = Active  > 11.00 Volts        > 0.1625 seconds	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips



## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With ECM	U0100	This DTC monitors for a loss of communication with the engine control module	<p>Message is not received from controller for</p> <p>Message \$0BE</p> <p>Message \$0C9</p> <p>Message \$18E</p> <p>Message \$1A1</p> <p>Message \$1A3</p> <p>Message \$1AA</p> <p>Message \$1BA</p> <p>Message \$287</p> <p>Message \$3D1</p> <p>Message \$3E9</p> <p>Message \$4C1</p> <p>Message \$4C7</p> <p>Message \$4D1</p> <p>Message \$4F1</p> <p>Message \$589</p>	<p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p>	<p>General Enable Criteria:</p> <p>U0073</p> <p>Normal CAN transmission on Bus A</p> <p>Device Control</p> <p>High Voltage Virtual Network Management</p> <p>Ignition Voltage Criteria:</p> <p>Run/Crank Ignition voltage</p> <p>Power Mode</p> <p>Off Cycle Enable Criteria:</p> <p>KeCAND_b_OffKeyCycle DiagEnbl</p> <p>Ignition Accessory Line and Battery Voltage</p> <p>General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for &gt; 5.0000 seconds</p> <p>Power Mode is in accessory or run or crank and High Voltage Virtual</p>	<p>Not Active on Current Key Cycle</p> <p>Enabled</p> <p>Not Active</p> <p>Not Active</p> <p>&gt; 6.41 Volts</p> <p>= run</p> <p>= 1 (1 indicates enabled)</p> <p>= Active</p> <p>&gt; 11.00 Volts</p>	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Network Management is not active for  U0100  ECM	> 0.4000 seconds  Not Active on Current Key Cycle  is present on the bus		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Anti- Lock Brake System (ABS) Control Module	U0121	This DTC monitors for a loss of communication with the Anti-Lock Brake System (ABS) Control Module (Non-OBD Module ID 243).	<p>Message is not received from controller for</p> <p>Message \$0C1</p> <p>Message \$0C5</p> <p>Message \$1E9</p> <p>Message \$2F9</p>	<p>≥ 12.0 seconds</p> <p>≥ 12.0 seconds</p> <p>≥ 12.0 seconds</p> <p>≥ 12.0 seconds</p>	<p>General Enable Criteria:</p> <p>U0073</p> <p>Normal CAN transmission on Bus A</p> <p>Device Control</p> <p>High Voltage Virtual Network Management</p> <p>Ignition Voltage Criteria:</p> <p>Run/Crank Ignition voltage</p> <p>Power Mode</p> <p>Off Cycle Enable Criteria:</p> <p>KeCAND_b_OffKeyCycle DiagEnbl</p> <p>Ignition Accessory Line and Battery Voltage</p> <p>General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for &gt; 5.0000 seconds</p> <p>Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for</p>	<p>Not Active on Current Key Cycle</p> <p>Enabled</p> <p>Not Active</p> <p>Not Active</p> <p>&gt; 6.41 Volts</p> <p>= run</p> <p>= 1 (1 indicates enabled)</p> <p>= Active</p> <p>&gt; 11.00 Volts</p> <p>&gt; 0.4000 seconds</p>	Diagnostic runs in 12.5 ms loop	Emissio ns Neutral Diagnost ic – Type C

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U0121  Anti-Lock Brake System Control Module	Not Active on Current Key Cycle  is present on the bus		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Body Control Module	U0140	This DTC monitors for a loss of communication with the Body Control Module.	<p>Message is not received from controller for</p> <p>Message \$0F1</p> <p>Message \$12A</p> <p>Message \$1F1</p> <p>Message \$1F3</p> <p>Message \$4E1</p> <p>Message \$4E9</p>	<p>≥ 0.5 seconds</p> <p>≥ 12.0 seconds</p> <p>≥ 12.0 seconds</p> <p>≥ 12.0 seconds</p> <p>≥ 12.0 seconds</p> <p>≥ 12.0 seconds</p>	<p>General Enable Criteria:</p> <p>U0073</p> <p>Normal CAN transmission on Bus A</p> <p>Device Control</p> <p>High Voltage Virtual Network Management</p> <p>Ignition Voltage Criteria:</p> <p>Run/Crank Ignition voltage</p> <p>Power Mode</p> <p>Off Cycle Enable Criteria:</p> <p>KeCAND_b_OffKeyCycle DiagEnbl</p> <p>Ignition Accessory Line and Battery Voltage</p> <p>General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for &gt; 5.0000 seconds</p> <p>Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for</p>	<p>Not Active on Current Key Cycle</p> <p>Enabled</p> <p>Not Active</p> <p>Not Active</p> <p>&gt; 6.41 Volts</p> <p>= run</p> <p>= 1 (1 indicates enabled)</p> <p>= Active</p> <p>&gt; 11.00 Volts</p> <p>&gt; 0.4000 seconds</p>	Diagnostic runs in 12.5 ms loop	Emissio ns Neutral Diagnost ic – Type C

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U0140  Body Control Module	Not Active on Current Key Cycle  is present on the bus		

## 20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Gateway A	U0146	This DTC monitors for a loss of communication with Gateway A	Message is not received from controller for  Message \$3CF	  ≥ 10.00 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Run/Crank Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds  Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for	Not Active on Current Key Cycle  Enabled  Not Active  Not Active    Run/Crank Ignition voltage = 6.41 Volts  = run   = 1 (1 indicates enabled)  = Active  > 11.00 Volts          = 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03A TCM T87A 9 Speed FWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U0146  Gateway A	Not Active on Current Key Cycle  is present on the bus		



## Initial Supporting table - P0606 enable

**Description:** P0606 program sequence watch diagnostic monitor enable**Value Units:** Boolean**X Unit:** CPU number**Y Units:** loop time

y/x	CeTSKR_e_CPU	CeTSKR_e_CPU2	CeTSKR_e_CPU3	CeTSKR_e_CPU4
CePISR_e_5msSeq	0	0	0	0
CePISR_e_6p25msSeq	1	0	0	0
CePISR_e_10msSeq	0	0	0	0
CePISR_e_12p5msSeq	1	0	0	0
CePISR_e_20msSeq	0	0	0	0
CePISR_e_25msSeq	1	0	0	0
CePISR_e_40msSeq	0	0	0	0
CePISR_e_50msSeq	0	0	0	0
CePISR_e_80msSeq	0	0	0	0
CePISR_e_100msSeq	0	0	0	0
CePISR_e_EventA_Seq	0	0	0	0
CePISR_e_EventB_Seq	0	0	0	0
CePISR_e_EventC_Seq	1	0	0	0

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

**Value Units:** Max Time for Last Seed Timeout (ms)

**X Unit:** Operating Loop Sequence (enum)

#### P0606\_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000

#### P0606\_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	200.000	200.000	200.000	8,191.875	8,191.875	8,191.875	

## Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)

**Description:** Fail threshold for PSW per operating loop.**Value Units:** Fail threshold for PSW (count)**X Unit:** Operating Loop (enum)**P0606\_PSW Sequence Fail f(Loop Time) - Part 1**

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	3	3	3	3	3	3	3

**P0606\_PSW Sequence Fail f(Loop Time) - Part 2**

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	3	3	3	3	3	3	

## Initial Supporting table - P0606\_PSW Sequence Sample f(Loop Time)

**Description:** Sample threshold for PSW per operating loop.**Value Units:** Sample threshold for PSW (count)**X Unit:** Operating Loop (enum)

## P0606\_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	4	4	4	4	4	4	4

## P0606\_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	4	4	4	4	4	4	

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - 10 speed transmission clutch definition and gear state to clutch map

**Description:** indicates clutch definition and gear state verses applied and released clutches for 10 speed transmission

**Value Units:** applied or released

**X Unit:** clutch

**Y Units:** gear index Y axis, actual gear column 1

y/x	1	2	3	4	5	6	7	8
1		C1 = C123456R	C2 = C1289-10R	C3 = C234579-10	C4 = C234678-10R	C5 = C1356789	C6 = C456789-10R	C7 = OWC12
2	1st gear braking	applied	applied	released	released	applied	released	applied
3	1st gear free wheel	applied	applied	released	released	applied	released	released
4	2nd gear braking	applied	applied	applied	applied	released	released	applied
5	2nd gear free wheel	applied	applied	applied	applied	released	released	released
6	3rd gear	applied	released	applied	applied	applied	released	released
7	4th gear	applied	released	applied	applied	released	applied	released
8	5th gear	applied	released	applied	released	applied	applied	released
9	6th gear	applied	released	released	released	applied	applied	released
10	7th gear	released	released	applied	applied	applied	applied	released
11	8th gear	released	applied	released	applied	applied	applied	released
12	9th gear	released	applied	applied	released	applied	applied	released
13	10th gear	released	applied	applied	applied	released	applied	released
14	reverse gear	applied	applied	released	applied	released	released	released

## Initial Supporting table - 9 speed transmission clutch definition and gear state to clutch map

**Description:** indicates clutch definition and gear state verses applied and released clutches for 9 speed transmission

**Value Units:** applied or released

**X Unit:** clutch

**Y Units:** gear index Y axis, actual gear column 1

y/x	1	2	3	4	5	6	7	8
1		C1 = CB123456	C2 = C6789	C3 = CB1R	C4 = CB29	C5 = CB38	C6 = C4	C7 = C57R
2	1st gear braking	applied	released	applied	released	released	released	released
3	1st gear free wheel	applied	released	released	released	released	released	released
4	2nd gear	applied	released	released	applied	released	released	released
5	3rd gear	applied	released	released	released	applied	released	released
6	4th gear	applied	released	released	released	released	applied	released
7	5th gear	applied	released	released	released	released	released	applied
8	6th gear	applied	applied	released	released	released	released	released
9	7th gear	released	applied	released	released	released	released	applied
10	8th gear	released	applied	released	released	applied	released	released
11	9th gear	released	applied	released	applied	released	released	released
12	reverse gear	released	released	applied	released	released	released	applied

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - engine speed time for transmission hydraulic pressure available

**Description:** time needed for engine speed to trigger "transmission hydraulic pressure available"

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-30.00	-20.00	0.00	40.00
1	0.300	0.300	0.275	0.200	0.200

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - NumClchTieUp

**Description:** NumClchTieUp

**Value Units:** minimum # of clutches

**X Unit:** command gear or attained gear

**Y Units:** not applicable, no units, single row table f(gear)

### NumClchTieUp - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5
1	2	3	2	2	2	2	2

### NumClchTieUp - Part 2

y/x	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3
1	2	2	1	1	1	1	1

### NumClchTieUp - Part 3

y/x	CeCGSR_e_NeutralC2C4	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6	CeCGSR_e_NeutralC4C5
1	1	1	1	1	1	1	1

### NumClchTieUp - Part 4

y/x	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4
1	1	1	3	2	2	2	2

### NumClchTieUp - Part 5

y/x	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	2	2	2	1	1	1	1

### NumClchTieUp - Part 6

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5
1	1	1	1	1	1	1	1

### NumClchTieUp - Part 7

y/x	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth
1	1	1	2	1	1	1	1

### NumClchTieUp - Part 8

y/x	CeCGSR_e_Fifth	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth	
-----	----------------	----------------	------------------	-----------------	----------------	----------------	--



Initial Supporting table - NumClchTieUp							
1	1	1	1	1	1	1	

## Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

**Value Units:** Max Time for Last Seed Timeout (ms)

**X Unit:** Operating Loop Sequence (enum)

## P0606\_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000

## P0606\_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	200.000	200.000	200.000	8,191.875	8,191.875	8,191.875	

## Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)

**Description:** Fail threshold for PSW per operating loop.**Value Units:** Fail threshold for PSW (count)**X Unit:** Operating Loop (enum)**P0606\_PSW Sequence Fail f(Loop Time) - Part 1**

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	3	3	3	3	3	3	3

**P0606\_PSW Sequence Fail f(Loop Time) - Part 2**

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	3	3	3	3	3	3	

## Initial Supporting table - P0606\_PSW Sequence Sample f(Loop Time)

**Description:** Sample threshold for PSW per operating loop.**Value Units:** Sample threshold for PSW (count)**X Unit:** Operating Loop (enum)**P0606\_PSW Sequence Sample f(Loop Time) - Part 1**

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	4	4	4	4	4	4	4

**P0606\_PSW Sequence Sample f(Loop Time) - Part 2**

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	4	4	4	4	4	4	

Initial Supporting table - P171D hydraulic pressure delay

**Description:** Time to delay the initial x of y counter due to hydraulic transients. Thresholds are a function of transmission fluid temperature. Horizontal axis is transmission fluid temperature (DegC) and table output is delay time (seconds).

**Value Units:** delay time seconds  
**X Unit:** transmission fluid temperature DegC

y/x	-40	0	20	30	40	50	60
1	0.090	0.090	0.080	0.050	0.050	0.050	0.050

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - P171D predicted turbine speed error

**Description:** Predicted turbine speed vs actual turbine speed error. Thresholds are a function of engine speed and transmission fluid temperature. Diagnostic is considered failing above these values. Table vertical axis is engine speed (RPM), horizontal axis is transmission fluid temperature (DegC) and table output is predicted turbine speed error (RPM).

**Value Units:** turbine speed RPM error

**X Unit:** transmission fluid temperature DegC

**Y Units:** engine speed RPM

y/x	-40	0	10	20	40
0	300	300	300	300	300
500	300	300	300	300	300
1,100	300	300	300	300	300
1,500	300	300	300	300	300
2,500	300	300	300	300	300

**Initial Supporting table - P176B delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation****Description:** delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation**Value Units:** seconds**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	1.000	1.000

## Initial Supporting table - P176B holding clutch states

**Description:** inditaces when the clutch states allow transmission intermediate speed sensor evaluation, when rotating components can trigger speed sesnor, holding clutches will not allow evaluation while clutches not holding will allow evaluation

**Value Units:** TRUE or FALSE

**X Unit:** intermediate speed sensor select

**Y Units:** commanded gear

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
CeCGSR_e_CR_NullForSched	1	1
CeCGSR_e_CR_Neutral	1	1
CeCGSR_e_CR_Park	1	1
CeCGSR_e_CR_Reverse	0	1
CeCGSR_e_CR_First	0	1
CeCGSR_e_CR_Second	0	1
CeCGSR_e_CR_Third	1	1
CeCGSR_e_CR_Fourth	0	1
CeCGSR_e_CR_Fifth	0	1
CeCGSR_e_CR_Sixth	0	1
CeCGSR_e_CR-Seventh	0	1
CeCGSR_e_CR_Eighth	1	1
CeCGSR_e_CR_Ninth	0	1
CeCGSR_e_CR_Tenth	1	1



## Initial Supporting table - P176B intermediate speed sensor fail count threshold

**Description:** P176B intermediate speed sensor fail count threshold**Value Units:** fail counts**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	4	4

## Initial Supporting table - P176B intermediate speed sensor fail time threshold

**Description:** P176B intermediate speed sensor fail time threshold**Value Units:** seconds**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	2.000	2.000

**Initial Supporting table - P176B minimum estimated transmission intermediate speed to enable fail evaluation**

**Description:** minimum estimated transmission intermediate speed to enable fail evaluation, where estimate is based on transmission input speed / ratio calibration, where ratio calibration is either P176B ratio calibration when REVERSE or P176B ratio calibration when not REVERSE

**Value Units:** estimated transmission intermediate speed RPM

**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	172.0	172.0

**Initial Supporting table - P176B minimum transmission input speed to enable fail evaluation****Description:** minimum transmission input speed to enable fail evaluation**Value Units:** transmission input speed RPM**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	172.0	172.0

## Initial Supporting table - P176B ratio calibration when not REVERSE

**Description:** used to estimate transmission input speed based on transmission intermediate speed when range is not REVERSE**Value Units:** ratio**X Unit:** commanded gear**Y Units:** intermediate speed sensor select

y/x	CeTGRR_e_Gear1	CeTGRR_e_Gear2	CeTGRR_e_Gear3	CeTGRR_e_Gear4	CeTGRR_e_Gear5	CeTGRR_e_Gear6	CeTGRR_e_Gear7	CeTGRR_e_Gear8	CeTGRR_e_Gear9	CeTGRR_e_Gear10
CeTSRR_e_C2 C_ClchSpdSnsr1	1.5848	6.3694	1.0000	2.4450	1.0000	0.5227	1.0000	1.0000	1.1905	1.0000
CeTSRR_e_C2 C_ClchSpdSnsr2	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000

## Initial Supporting table - P176B ratio calibration when REVERSE

**Description:** used to estimate transmission input speed based on transmission intermediate speed when range is REVERSE**Value Units:** ratio**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	1.0000	1.0000

Initial Supporting table - P17C5 P17D3 intermediate speed sensor RPM

**Description:** P17C5 P17D3 intermediate speed sensor RPM at signal period transtion to enable fail time update

**Value Units:** intermediate speed sensor RPM

**X Unit:** intermediate speed sensor 1 or 2

y/x	0	1
1	25	25

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Cltch Slip Sum

### Description:

**Value Units:** rate of change of output rpm (dn) per 25 milliseconds

**X Unit:** % brake pedal position

**Y Units:** not applicable, no units, single row table f(brake pedal position)

y/x	0	15	20	30	35	50	75	88	100
1	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192



# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C1

**Description:** clutch 1 command pressure threshold below which clutch 1 is considered released, such that, clutch 1 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C1 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	131.3	131.3	9,999.0	344.3	409.6

### P2D2 Decel Pressure - C1 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	9,999.0	131.3	344.3	131.3	9,999.0

### P2D2 Decel Pressure - C1 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	9,999.0	9,999.0	9,999.0	50.0	50.0

### P2D2 Decel Pressure - C1 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50.0	344.3	50.0	50.0	409.6

### P2D2 Decel Pressure - C1 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	644.8	644.8	50.0	131.3	9,999.0

### P2D2 Decel Pressure - C1 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	344.3	409.6	9,999.0	131.3	344.3

### P2D2 Decel Pressure - C1 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	131.3	9,999.0	50.0	50.0	50.0

### P2D2 Decel Pressure - C1 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	344.3	50.0	50.0	409.6	644.8

### P2D2 Decel Pressure - C1 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C1

1	644.8	50.0	131.3	9,999.0	9,999.0
P2D2 Decel Pressure - C1 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	9,999.0	9,999.0	9,999.0	9,999.0	9,999.0
P2D2 Decel Pressure - C1 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	9,999.0	644.8	409.6	344.3	50.0
P2D2 Decel Pressure - C1 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C2

**Description:** clutch 2 command pressure threshold below which clutch 2 is considered released, such that, clutch 2 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C2 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	359	359	359	9,999	2,125

### P2D2 Decel Pressure - C2 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	801	489	359	512	9,999

### P2D2 Decel Pressure - C2 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	2,125	801	489	50	50

### P2D2 Decel Pressure - C2 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	9,999	50	50	2,125

### P2D2 Decel Pressure - C2 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	765	765	50	359	359

### P2D2 Decel Pressure - C2 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	9,999	2,125	801	489	359

### P2D2 Decel Pressure - C2 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	512	9,999	50	50	50

### P2D2 Decel Pressure - C2 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	9,999	50	50	2,125	765

### P2D2 Decel Pressure - C2 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C2

1	765	50	512	570	570
P2D2 Decel Pressure - C2 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	9,999	9,999	2,125	801	489
P2D2 Decel Pressure - C2 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	359	765	2,125	9,999	50
P2D2 Decel Pressure - C2 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C3

**Description:** clutch 3 command pressure threshold below which clutch 3 is considered released, such that, clutch 3 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C3 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	245	245	247	1,293	9,999

### P2D2 Decel Pressure - C3 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	706	245	247	245	1,294

### P2D2 Decel Pressure - C3 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	9,999	706	360	50	50

### P2D2 Decel Pressure - C3 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	1,293	50	50	9,999

### P2D2 Decel Pressure - C3 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	674	674	50	245	247

### P2D2 Decel Pressure - C3 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	1,293	9,999	706	245	247

### P2D2 Decel Pressure - C3 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	245	1,294	50	50	50

### P2D2 Decel Pressure - C3 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	1,293	50	50	9,999	674

### P2D2 Decel Pressure - C3 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C3

1	674	50	245	273	273
P2D2 Decel Pressure - C3 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	1,294	1,294	9,999	706	360
P2D2 Decel Pressure - C3 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	247	674	9,999	1,293	50
P2D2 Decel Pressure - C3 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C4

**Description:** clutch 4 command pressure threshold below which clutch 4 is considered released, such that, clutch 4 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C4 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	433	433	482	1,041	1,585

### P2D2 Decel Pressure - C4 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	9,999	433	915	433	1,145

### P2D2 Decel Pressure - C4 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	1,713	9,999	1,772	50	50

### P2D2 Decel Pressure - C4 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	1,041	50	50	1,585

### P2D2 Decel Pressure - C4 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	9,999	9,999	50	433	482

### P2D2 Decel Pressure - C4 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	1,041	1,585	9,999	433	915

### P2D2 Decel Pressure - C4 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	433	1,145	50	50	50

### P2D2 Decel Pressure - C4 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	1,041	50	50	1,585	9,999

### P2D2 Decel Pressure - C4 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C4

1	9,999	50	433	482	482
P2D2 Decel Pressure - C4 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	1,145	1,145	1,713	9,999	1,772
P2D2 Decel Pressure - C4 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	915	2,030	1,585	1,041	50
P2D2 Decel Pressure - C4 - Part 12					
y/x					
1					



# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C5

**Description:** clutch 5 command pressure threshold below which clutch 5 is considered released, such that, clutch 5 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C5 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	140	140	140	255	318

### P2D2 Decel Pressure - C5 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	646	9,999	685	140	255

### P2D2 Decel Pressure - C5 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	318	646	9,999	50	50

### P2D2 Decel Pressure - C5 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	780	50	50	1,188

### P2D2 Decel Pressure - C5 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	9,999	50	50	140	140

### P2D2 Decel Pressure - C5 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	255	318	646	9,999	685

### P2D2 Decel Pressure - C5 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	140	255	50	50	50

### P2D2 Decel Pressure - C5 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	780	50	50	1,188	9,999

### P2D2 Decel Pressure - C5 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C5

1	50	50	9,999	140	140
P2D2 Decel Pressure - C5 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	255	255	318	646	9,999
P2D2 Decel Pressure - C5 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	685	9,999	1,188	780	50
P2D2 Decel Pressure - C5 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C6

**Description:** clutch 6 command pressure threshold below which clutch 6 is considered released, such that, clutch 6 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C6 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	178	178	178	283	330

### P2D2 Decel Pressure - C6 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	504	253	9,999	178	283

### P2D2 Decel Pressure - C6 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	330	504	1,036	50	50

### P2D2 Decel Pressure - C6 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	9,999	50	50	9,999

### P2D2 Decel Pressure - C6 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	50	9,999	50	178	178

### P2D2 Decel Pressure - C6 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	283	330	504	253	9,999

### P2D2 Decel Pressure - C6 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	178	283	50	50	50

### P2D2 Decel Pressure - C6 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	9,999	50	50	9,999	50

### P2D2 Decel Pressure - C6 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C6

1	9,999	50	253	178	178
P2D2 Decel Pressure - C6 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	283	283	330	504	1,036
P2D2 Decel Pressure - C6 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	9,999	9,999	9,999	9,999	50
P2D2 Decel Pressure - C6 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C7

**Description:** clutch 7 command pressure threshold below which clutch 7 is considered released, such that, clutch 7 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C7 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	50	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	50	50	50	9,999	50

### P2D2 Decel Pressure - C7 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	50	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	50	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	50	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	9,999	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	50	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C7

1	50	50	9,999	9,999	50
P2D2 Decel Pressure - C7 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	50	50	50	50	50
P2D2 Decel Pressure - C7 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	50	50	50	50	50
P2D2 Decel Pressure - C7 - Part 12					
y/x					
1					

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - transmission fluid temperature warm up time

## Description:

**Value Units:** transmission fluid temperature normal warm up time, seconds**X Unit:** transmission fluid temperature at controller power up, °C

y/x	-40.00	-30.00	-20.00	0.00	20.00
1	1,800.0	1,500.0	1,200.0	600.0	60.0

## Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

## P0606\_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000

## P0606\_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	200.000	200.000	200.000	8,191.875	8,191.875	8,191.875	



## Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)

**Description:** Fail threshold for PSW per operating loop.

## P0606\_PSW Sequence Fail f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	3	3	3	3	3	3	3

## P0606\_PSW Sequence Fail f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	3	3	3	3	3	3	

## Initial Supporting table - P0606\_PSW Sequence Sample f(Loop Time)

**Description:** Sample threshold for PSW per operating loop.

## P0606\_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	4	4	4	4	4	4	4

## P0606\_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	4	4	4	4	4	4	

## Initial Supporting table - 10 speed transmission clutch definition and gear state to clutch map

**Description:** indicates clutch definition and gear state verses applied and released clutches for 10 speed transmission

**Value Units:** applied or released

**X Unit:** clutch

**Y Units:** gear index Y axis, actual gear column 1

y/x	1	2	3	4	5	6	7	8
1		C1 = C123456R	C2 = C1289-10R	C3 = C234579-10	C4 = C234678-10R	C5 = C1356789	C6 = C456789-10R	C7 = OWC12
2	1st gear braking	applied	applied	released	released	applied	released	applied
3	1st gear free wheel	applied	applied	released	released	applied	released	released
4	2nd gear braking	applied	applied	applied	applied	released	released	applied
5	2nd gear free wheel	applied	applied	applied	applied	released	released	released
6	3rd gear	applied	released	applied	applied	applied	released	released
7	4th gear	applied	released	applied	applied	released	applied	released
8	5th gear	applied	released	applied	released	applied	applied	released
9	6th gear	applied	released	released	released	applied	applied	released
10	7th gear	released	released	applied	applied	applied	applied	released
11	8th gear	released	applied	released	applied	applied	applied	released
12	9th gear	released	applied	applied	released	applied	applied	released
13	10th gear	released	applied	applied	applied	released	applied	released
14	reverse gear	applied	applied	released	applied	released	released	released

## Initial Supporting table - 9 speed transmission clutch definition and gear state to clutch map

**Description:** indicates clutch definition and gear state verses applied and released clutches for 9 speed transmission

**Value Units:** applied or released

**X Unit:** clutch

**Y Units:** gear index Y axis, actual gear column 1

y/x	1	2	3	4	5	6	7	8
1		C1 = CB123456	C2 = C6789	C3 = CB1R	C4 = CB29	C5 = CB38	C6 = C4	C7 = C57R
2	1st gear braking	applied	released	applied	released	released	released	released
3	1st gear free wheel	applied	released	released	released	released	released	released
4	2nd gear	applied	released	released	applied	released	released	released
5	3rd gear	applied	released	released	released	applied	released	released
6	4th gear	applied	released	released	released	released	applied	released
7	5th gear	applied	released	released	released	released	released	applied
8	6th gear	applied	applied	released	released	released	released	released
9	7th gear	released	applied	released	released	released	released	applied
10	8th gear	released	applied	released	released	applied	released	released
11	9th gear	released	applied	released	applied	released	released	released
12	reverse gear	released	released	applied	released	released	released	applied

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - engine speed time for transmission hydraulic pressure available

**Description:** ime needed for engine speed to trigger "transmission hydraulic pressure available"

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-30.00	-20.00	0.00	40.00
1	0.300	0.300	0.275	0.200	0.200

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - engine speed time for transmission hydraulic pressure available

**Description:** time needed for engine speed to trigger "transmission hydraulic pressure available"

**Value Units:** seconds

**X Unit:** °C

y/x	-40.00	-30.00	-20.00	0.00	40.00
1	0.300	0.300	0.275	0.200	0.200

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - NumClchTieUp

**Description:** NumClchTieUp

**Value Units:** minimum # of clutches

**X Unit:** command gear or attained gear

**Y Units:** not applicable, no units, single row table f(gear)

## NumClchTieUp - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5
1	2	3	2	2	2	2	2

## NumClchTieUp - Part 2

y/x	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3
1	2	2	1	1	1	1	1

## NumClchTieUp - Part 3

y/x	CeCGSR_e_NeutralC2C4	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6	CeCGSR_e_NeutralC4C5
1	1	1	1	1	1	1	1

## NumClchTieUp - Part 4

y/x	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4
1	1	1	3	2	2	2	2

## NumClchTieUp - Part 5

y/x	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	2	2	2	1	1	1	1

## NumClchTieUp - Part 6

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5
1	1	1	1	1	1	1	1

## NumClchTieUp - Part 7

y/x	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth
1	1	1	2	1	1	1	1

## NumClchTieUp - Part 8

y/x	CeCGSR_e_Fifth	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth	
-----	----------------	----------------	------------------	-----------------	----------------	----------------	--

Initial Supporting table - NumClchTieUp							
1	1	1	1	1	1	1	



## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - P0741 (GF9 specific) TCC slip speed crash RPM

**Description:** RPM limit used to establish slip crashed when TCC oil became available

**Value Units:** RPM

**X Unit:** % accelerator position

y/x	0.00	15.00	25.00	50.00	75.00
1	100	100	160	233	300

## Initial Supporting table - P0741 (GF9 specific) torque convert derivative slip speed fail threshold

**Description:** he fail threshold, rate of change of torque converter slip speed, at which the torque convert clutch is considered stuck on.

**Value Units:** RPM/second

**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
0	-600	-600	-600
15	-600	-600	-600
25	-900	-900	-900
50	-1,200	-1,200	-1,200
75	-1,500	-1,500	-1,500

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P0741 stuck on test time

**Description:** Value to initialize the TCC Stuck On test time to after transition of clutch select valve allowing TCC hydraulic circuit connectivity. Window is a time down window from the calibration value to zero (0.0) seconds.

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
1	1.500	1.250	1.000

**Initial Supporting table - P176B delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation****Description:** delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation**Value Units:** seconds**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	1.000	1.000

## Initial Supporting table - P176B holding clutch states

**Description:** inditaces when the clutch states allow transmission intermediate speed sensor evaluation, when rotating components can trigger speed sesnor, holding clutches will not allow evaluation while clutches not holding will allow evaluation

**Value Units:** TRUE or FALSE

**X Unit:** intermediate speed sensor select

**Y Units:** commanded gear

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
CeCGSR_e_CR_NullForSched	1	1
CeCGSR_e_CR_Neutral	1	1
CeCGSR_e_CR_Park	1	1
CeCGSR_e_CR_Reverse	0	1
CeCGSR_e_CR_First	0	1
CeCGSR_e_CR_Second	0	1
CeCGSR_e_CR_Third	1	1
CeCGSR_e_CR_Fourth	0	1
CeCGSR_e_CR_Fifth	0	1
CeCGSR_e_CR_Sixth	0	1
CeCGSR_e_CR-Seventh	0	1
CeCGSR_e_CR_Eighth	1	1
CeCGSR_e_CR_Ninth	0	1
CeCGSR_e_CR_Tenth	1	1

## Initial Supporting table - P176B intermediate speed sensor fail count threshold

**Description:** P176B intermediate speed sensor fail count threshold**Value Units:** fail counts**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	4	4

## Initial Supporting table - P176B intermediate speed sensor fail time threshold

**Description:** P176B intermediate speed sensor fail time threshold**Value Units:** seconds**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	2.000	2.000

**Initial Supporting table - P176B minimum estimated transmission intermediate speed to enable fail evaluation**

**Description:** minimum estimated transmission intermediate speed to enable fail evaluation, where estimate is based on transmission input speed / ratio calibration, where ratio calibration is either P176B ratio calibration when REVERSE or P176B ratio calibration when not REVERSE

**Value Units:** estimated transmission intermediate speed RPM

**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	172.0	172.0



**Initial Supporting table - P176B minimum transmission input speed to enable fail evaluation****Description:** minimum transmission input speed to enable fail evaluation**Value Units:** transmission input speed RPM**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	172.0	172.0

## Initial Supporting table - P176B ratio calibration when not REVERSE

**Description:** used to estimate transmission input speed based on transmission intermediate speed when range is not REVERSE**Value Units:** ratio**X Unit:** commanded gear**Y Units:** intermediate speed sensor select

y/x	CeTGRR_e_Gear1	CeTGRR_e_Gear2	CeTGRR_e_Gear3	CeTGRR_e_Gear4	CeTGRR_e_Gear5	CeTGRR_e_Gear6	CeTGRR_e_Gear7	CeTGRR_e_Gear8	CeTGRR_e_Gear9	CeTGRR_e_Gear10
CeTSRR_e_C2 C_ClchSpdSnsr1	1.5848	6.3694	1.0000	2.4450	1.0000	0.5227	1.0000	1.0000	1.1905	1.0000
CeTSRR_e_C2 C_ClchSpdSnsr2	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000

## Initial Supporting table - P176B ratio calibration when REVERSE

**Description:** used to estimate transmission input speed based on transmission intermediate speed when range is REVERSE**Value Units:** ratio**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	1.0000	1.0000

Initial Supporting table - P17C5 P17D3 intermediate speed sensor RPM

**Description:** P17C5 P17D3 intermediate speed sensor RPM at signal period transtion to enable fail time update

**Value Units:** intermediate speed sensor RPM

**X Unit:** intermediate speed sensor 1 or 2

y/x	0	1
1	25	25

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2817 TCC stuck off fail TCC slip speed

**Description:** TCC stuck off slip speed fail threshold when TCC is in ON mode (controlled slip mode)

**Value Units:** RPM

**X Unit:** engine torque Nm

y/x	0.00	64.00	128.00	192.00	256.00	320.00	384.00	448.00	512.00
1	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - P2818 (GF9 specific) control valve test time

**Description:** Value to initialize the torque converter clutch control valve test time to after clutch select valve solenoid is turned on, window of time in which the torque converter clutch slip speed and derivative slip speed must be evaluated for failure. Window is a time down window from the calibration value to zero (0.0) seconds.

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
1	0.600	0.300	0.100

## Initial Supporting table - P2818 stuck on test time

**Description:** Value to initialize the TCC Stuck On test time to after transition of clutch select valve allowing TCC hydraulic circuit connectivity. Window is a time down window from the calibration value to zero (0.0) seconds.

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
1	1.500	1.250	1.000

## Initial Supporting table - P2818 torque convert derivative slip speed fail threshold

**Description:** The fail threshold, rate of change of torque converter slip speed, at which the torque convert clutch is considered stuck on.

**Value Units:** RPM/second

**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
0	-600.0	-600.0	-600.0
15	-600.0	-600.0	-600.0
25	-900.0	-900.0	-900.0
50	-1,200.0	-1,200.0	-1,200.0
75	-1,500.0	-1,500.0	-1,500.0



## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Cltch Slip Sum

## Description:

**Value Units:** rate of change of output rpm (dn) per 25 milliseconds**X Unit:** % brake pedal position**Y Units:** not applicable, no units, single row table f(brake pedal position)

y/x	0	15	20	30	35	50	75	88	100
1	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C1

**Description:** clutch 1 command pressure threshold below which clutch 1 is considered released, such that, clutch 1 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C1 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	131.3	131.3	9,999.0	344.3	409.6

### P2D2 Decel Pressure - C1 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	9,999.0	131.3	344.3	131.3	9,999.0

### P2D2 Decel Pressure - C1 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	9,999.0	9,999.0	9,999.0	50.0	50.0

### P2D2 Decel Pressure - C1 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50.0	344.3	50.0	50.0	409.6

### P2D2 Decel Pressure - C1 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	644.8	644.8	50.0	131.3	9,999.0

### P2D2 Decel Pressure - C1 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	344.3	409.6	9,999.0	131.3	344.3

### P2D2 Decel Pressure - C1 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	131.3	9,999.0	50.0	50.0	50.0

### P2D2 Decel Pressure - C1 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	344.3	50.0	50.0	409.6	644.8

### P2D2 Decel Pressure - C1 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C1

1	644.8	50.0	131.3	9,999.0	9,999.0
P2D2 Decel Pressure - C1 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	9,999.0	9,999.0	9,999.0	9,999.0	9,999.0
P2D2 Decel Pressure - C1 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	9,999.0	644.8	409.6	344.3	50.0
P2D2 Decel Pressure - C1 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C2

**Description:** clutch 2 command pressure threshold below which clutch 2 is considered released, such that, clutch 2 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C2 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	359	359	359	9,999	2,125

### P2D2 Decel Pressure - C2 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	801	489	359	512	9,999

### P2D2 Decel Pressure - C2 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	2,125	801	489	50	50

### P2D2 Decel Pressure - C2 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	9,999	50	50	2,125

### P2D2 Decel Pressure - C2 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	765	765	50	359	359

### P2D2 Decel Pressure - C2 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	9,999	2,125	801	489	359

### P2D2 Decel Pressure - C2 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	512	9,999	50	50	50

### P2D2 Decel Pressure - C2 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	9,999	50	50	2,125	765

### P2D2 Decel Pressure - C2 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C2					
1	765	50	512	570	570
P2D2 Decel Pressure - C2 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	9,999	9,999	2,125	801	489
P2D2 Decel Pressure - C2 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	359	765	2,125	9,999	50
P2D2 Decel Pressure - C2 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C3

**Description:** clutch 3 command pressure threshold below which clutch 3 is considered released, such that, clutch 3 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C3 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	245	245	247	1,293	9,999

### P2D2 Decel Pressure - C3 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	706	245	247	245	1,294

### P2D2 Decel Pressure - C3 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	9,999	706	360	50	50

### P2D2 Decel Pressure - C3 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	1,293	50	50	9,999

### P2D2 Decel Pressure - C3 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	674	674	50	245	247

### P2D2 Decel Pressure - C3 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	1,293	9,999	706	245	247

### P2D2 Decel Pressure - C3 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	245	1,294	50	50	50

### P2D2 Decel Pressure - C3 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	1,293	50	50	9,999	674

### P2D2 Decel Pressure - C3 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C3

1	674	50	245	273	273
P2D2 Decel Pressure - C3 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	1,294	1,294	9,999	706	360
P2D2 Decel Pressure - C3 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	247	674	9,999	1,293	50
P2D2 Decel Pressure - C3 - Part 12					
y/x					
1					

## Initial Supporting table - P2D2 Decel Pressure - C4

**Description:** clutch 4 command pressure threshold below which clutch 4 is considered released, such that, clutch 4 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

## P2D2 Decel Pressure - C4 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	433	433	482	1,041	1,585

## P2D2 Decel Pressure - C4 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	9,999	433	915	433	1,145

## P2D2 Decel Pressure - C4 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	1,713	9,999	1,772	50	50

## P2D2 Decel Pressure - C4 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	1,041	50	50	1,585

## P2D2 Decel Pressure - C4 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	9,999	9,999	50	433	482

## P2D2 Decel Pressure - C4 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	1,041	1,585	9,999	433	915

## P2D2 Decel Pressure - C4 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	433	1,145	50	50	50

## P2D2 Decel Pressure - C4 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	1,041	50	50	1,585	9,999

## P2D2 Decel Pressure - C4 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------



20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C4

1	9,999	50	433	482	482
P2D2 Decel Pressure - C4 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	1,145	1,145	1,713	9,999	1,772
P2D2 Decel Pressure - C4 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	915	2,030	1,585	1,041	50
P2D2 Decel Pressure - C4 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C5

**Description:** clutch 5 command pressure threshold below which clutch 5 is considered released, such that, clutch 5 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C5 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	140	140	140	255	318

### P2D2 Decel Pressure - C5 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	646	9,999	685	140	255

### P2D2 Decel Pressure - C5 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	318	646	9,999	50	50

### P2D2 Decel Pressure - C5 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	780	50	50	1,188

### P2D2 Decel Pressure - C5 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	9,999	50	50	140	140

### P2D2 Decel Pressure - C5 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	255	318	646	9,999	685

### P2D2 Decel Pressure - C5 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	140	255	50	50	50

### P2D2 Decel Pressure - C5 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	780	50	50	1,188	9,999

### P2D2 Decel Pressure - C5 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C5

1	50	50	9,999	140	140
P2D2 Decel Pressure - C5 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	255	255	318	646	9,999
P2D2 Decel Pressure - C5 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	685	9,999	1,188	780	50
P2D2 Decel Pressure - C5 - Part 12					
y/x					
1					

## Initial Supporting table - P2D2 Decel Pressure - C6

**Description:** clutch 6 command pressure threshold below which clutch 6 is considered released, such that, clutch 6 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

## P2D2 Decel Pressure - C6 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	178	178	178	283	330

## P2D2 Decel Pressure - C6 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	504	253	9,999	178	283

## P2D2 Decel Pressure - C6 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	330	504	1,036	50	50

## P2D2 Decel Pressure - C6 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	9,999	50	50	9,999

## P2D2 Decel Pressure - C6 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	50	9,999	50	178	178

## P2D2 Decel Pressure - C6 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	283	330	504	253	9,999

## P2D2 Decel Pressure - C6 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	178	283	50	50	50

## P2D2 Decel Pressure - C6 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	9,999	50	50	9,999	50

## P2D2 Decel Pressure - C6 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C6

1	9,999	50	253	178	178
P2D2 Decel Pressure - C6 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	283	283	330	504	1,036
P2D2 Decel Pressure - C6 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	9,999	9,999	9,999	9,999	50
P2D2 Decel Pressure - C6 - Part 12					
y/x					
1					

## Initial Supporting table - P2D2 Decel Pressure - C7

**Description:** clutch 7 command pressure threshold below which clutch 7 is considered released, such that, clutch 7 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

## P2D2 Decel Pressure - C7 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	50	50	50	50	50

## P2D2 Decel Pressure - C7 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	50	50	50	9,999	50

## P2D2 Decel Pressure - C7 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	50	50	50	50	50

## P2D2 Decel Pressure - C7 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	50	50	50	50

## P2D2 Decel Pressure - C7 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	50	50	50	50	50

## P2D2 Decel Pressure - C7 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	50	50	50	50	50

## P2D2 Decel Pressure - C7 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	9,999	50	50	50	50

## P2D2 Decel Pressure - C7 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	50	50	50	50	50

## P2D2 Decel Pressure - C7 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C7

1	50	50	9,999	9,999	50
P2D2 Decel Pressure - C7 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	50	50	50	50	50
P2D2 Decel Pressure - C7 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	50	50	50	50	50
P2D2 Decel Pressure - C7 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - transmission fluid temperature warm up time

**Description:**

**Value Units:** transmission fluid temperature normal warm up time, seconds

**X Unit:** transmission fluid temperature at controller power up, °C

y/x	-40.00	-30.00	-20.00	0.00	20.00
1	1,800.0	1,500.0	1,200.0	600.0	60.0



## Initial Supporting table - 10 speed transmission clutch definition and gear state to clutch map

**Description:** indicates clutch definition and gear state verses applied and released clutches for 10 speed transmission

**Value Units:** applied or released

**X Unit:** clutch

**Y Units:** gear index Y axis, actual gear column 1

y/x	1	2	3	4	5	6	7	8
1		C1 = C123456R	C2 = C1289-10R	C3 = C234579-10	C4 = C234678-10R	C5 = C1356789	C6 = C456789-10R	C7 = OWC12
2	1st gear braking	applied	applied	released	released	applied	released	applied
3	1st gear free wheel	applied	applied	released	released	applied	released	released
4	2nd gear braking	applied	applied	applied	applied	released	released	applied
5	2nd gear free wheel	applied	applied	applied	applied	released	released	released
6	3rd gear	applied	released	applied	applied	applied	released	released
7	4th gear	applied	released	applied	applied	released	applied	released
8	5th gear	applied	released	applied	released	applied	applied	released
9	6th gear	applied	released	released	released	applied	applied	released
10	7th gear	released	released	applied	applied	applied	applied	released
11	8th gear	released	applied	released	applied	applied	applied	released
12	9th gear	released	applied	applied	released	applied	applied	released
13	10th gear	released	applied	applied	applied	released	applied	released
14	reverse gear	applied	applied	released	applied	released	released	released

## Initial Supporting table - 9 speed transmission clutch definition and gear state to clutch map

**Description:** indicates clutch definition and gear state verses applied and released clutches for 9 speed transmission

**Value Units:** applied or released

**X Unit:** clutch

**Y Units:** gear index Y axis, actual gear column 1

y/x	1	2	3	4	5	6	7	8
1		C1 = CB123456	C2 = C6789	C3 = CB1R	C4 = CB29	C5 = CB38	C6 = C4	C7 = C57R
2	1st gear braking	applied	released	applied	released	released	released	released
3	1st gear free wheel	applied	released	released	released	released	released	released
4	2nd gear	applied	released	released	applied	released	released	released
5	3rd gear	applied	released	released	released	applied	released	released
6	4th gear	applied	released	released	released	released	applied	released
7	5th gear	applied	released	released	released	released	released	applied
8	6th gear	applied	applied	released	released	released	released	released
9	7th gear	released	applied	released	released	released	released	applied
10	8th gear	released	applied	released	released	applied	released	released
11	9th gear	released	applied	released	applied	released	released	released
12	reverse gear	released	released	applied	released	released	released	applied

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C1 exhaust delay closed throttle down shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in closed throttle down shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C1 exhaust delay closed throttle lift foot up shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in closed throttle lift foot up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C1 exhaust delay garage shift					
<b>Description:</b> P0747 C1 clutch hydraulic circuit exhaust time in garage shift					
<b>Value Units:</b> seconds <b>X Unit:</b> transmission fluid temperature °C					
y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - C1 exhaust delay negative torque up shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in negative torque up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.500	0.500	0.500	0.500	0.500

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C1 exhaust delay open throttle power down shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in open throttle power down shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C1 exhaust delay open throttle power on up shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in open throttle power on up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	2.000	1.100	0.813	0.500	0.269



## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C2 exhaust delay closed throttle down shift

**Description:** P0777 C2 clutch hydraulic circuit exhaust time in closed throttle down shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.350	0.200

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C2 exhaust delay closed throttle lift foot up shift

**Description:** P0777 C2 clutch hydraulic circuit exhaust time in closed throttle lift foot up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C2 exhaust delay garage shift

**Description:** P0777 C2 clutch hydraulic circuit exhaust time in garage shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C2 exhaust delay negative torque up shift

**Description:** P0777 C2 clutch hydraulic circuit exhaust time in negative torque up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.500	0.500	0.500	0.500	0.500

## Initial Supporting table - C2 exhaust delay open throttle power down shift

**Description:** P0777 C2 clutch hydraulic circuit exhaust time in open throttle power down shift**Value Units:** seconds**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.212	0.212

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C2 exhaust delay open throttle power on up shift

**Description:** P0777 C2 clutch hydraulic circuit exhaust time in open throttle power on up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	3.100	0.900	0.800	0.700	0.262

## Initial Supporting table - C3 exhaust delay closed throttle down shift

**Description:** P0797 C3 clutch hydraulic circuit exhaust time in closed throttle down shift**Value Units:** seconds**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.300	1.000	0.950	0.469	0.200

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C3 exhaust delay closed throttle lift foot up shift

**Description:** P0797 C3 clutch hydraulic circuit exhaust time in closed throttle lift foot up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850



Initial Supporting table - C3 exhaust delay garage shift

**Description:** P0797 C3 clutch hydraulic circuit exhaust time in garage shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C3 exhaust delay negative torque up shift

**Description:** P0797 C3 clutch hydraulic circuit exhaust time in negative torque up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.500	0.500	0.500	0.500	0.500

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C3 exhaust delay open throttle power down shift

**Description:** P0797 C3 clutch hydraulic circuit exhaust time in open throttle power down shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.387	0.144

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C3 exhaust delay open throttle power on up shift

**Description:** P0797 C3 clutch hydraulic circuit exhaust time in open throttle power on up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.900	0.800	0.750	0.650	0.256

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C4 exhaust delay closed throttle down shift

**Description:** P2715 C4 clutch hydraulic circuit exhaust time in closed throttle down shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.400	0.750	0.700	0.663	0.225

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C4 exhaust delay closed throttle lift foot up shift

**Description:** P2715 C4 clutch hydraulic circuit exhaust time in closed throttle lift foot up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C4 exhaust delay garage shift

**Description:** P2715 C4 clutch hydraulic circuit exhaust time in garage shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C4 exhaust delay negative torque up shift

**Description:** P2715 C4 clutch hydraulic circuit exhaust time in negative torque up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.500	0.500	0.500	0.500	0.500



## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C4 exhaust delay open throttle power down shift

**Description:** P2715 C4 clutch hydraulic circuit exhaust time in open throttle power down shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.119	0.119

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C4 exhaust delay open throttle power on up shift

**Description:** P2715 C4 clutch hydraulic circuit exhaust time in open throttle power on up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.900	0.650	0.600	0.550	0.300

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C5 exhaust delay closed throttle down shift

**Description:** P2724 C5 clutch hydraulic circuit exhaust time in closed throttle down shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.700	1.369	1.100	0.650	0.337

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C5 exhaust delay closed throttle lift foot up shift

**Description:** P2724 C5 clutch hydraulic circuit exhaust time in closed throttle lift foot up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C5 exhaust delay garage shift

**Description:** P2724 C5 clutch hydraulic circuit exhaust time in garage shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40	-20	0	30	110
1	2	1	1	1	1

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C5 exhaust delay negative torque up shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in negative torque up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.500	0.500	0.500	0.500	0.500

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C5 exhaust delay open throttle power down shift

**Description:** P2724 C5 clutch hydraulic circuit exhaust time in open throttle power down shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.900	0.613	0.450	0.300	0.163

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C5 exhaust delay open throttle power on up shift

**Description:** P2724 C5 clutch hydraulic circuit exhaust time in open throttle power on up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	2.900	1.350	1.100	0.850	0.406



## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C6 exhaust delay closed throttle down shift

**Description:** P2733 C6 clutch hydraulic circuit exhaust time in closed throttle down shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.400	1.100	0.719	0.400	0.350

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C6 exhaust delay closed throttle lift foot up shift

**Description:** P2733 C6 clutch hydraulic circuit exhaust time in closed throttle lift foot up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C6 exhaust delay garage shift

**Description:** P2733 C6 clutch hydraulic circuit exhaust time in garage shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C6 exhaust delay negative torque up shift

**Description:** P2733 C6 clutch hydraulic circuit exhaust time in negative torque up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.500	0.500	0.500	0.500	0.500

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C6 exhaust delay open throttle power down shift

**Description:** P2733 C6 clutch hydraulic circuit exhaust time in open throttle power down shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.850	0.350	0.300	0.238	0.131

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - C6 exhaust delay open throttle power on up shift

**Description:** P2733 C6 clutch hydraulic circuit exhaust time in open throttle power on up shift

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.600	0.600

Initial Supporting table - Clutch Clip Press CD Shifts						
<b>Description:</b> Oncoming clutch clip pressure for closed throttle down shifts						
<b>Value Units:</b> kPa <b>X Unit:</b> Oncoming Clutch						
y/x	CeTSER_e_C1_Clutch	CeTSER_e_C2_Clutch	CeTSER_e_C3_Clutch	CeTSER_e_C4_Clutch	CeTSER_e_C5_Clutch	CeTSER_e_C6_Clutch
1	690	800	500	850	703	655

Initial Supporting table - Clutch Clip Press CU Shifts						
<b>Description:</b> Oncoming clutch clip pressure for closed throttle lift foot up shifts						
<b>Value Units:</b> kPa <b>X Unit:</b> Oncoming Clutch						
y/x	CeTSER_e_C1_Clutch	CeTSER_e_C2_Clutch	CeTSER_e_C3_Clutch	CeTSER_e_C4_Clutch	CeTSER_e_C5_Clutch	CeTSER_e_C6_Clutch
1	690	800	500	850	703	655



Initial Supporting table - Clutch Clip Press GS Shifts						
<b>Description:</b> Oncoming clutch clip pressure for garage shifts						
<b>Value Units:</b> kPa <b>X Unit:</b> Oncoming Clutch						
y/x	CeTSER_e_C1_Clutch	CeTSER_e_C2_Clutch	CeTSER_e_C3_Clutch	CeTSER_e_C4_Clutch	CeTSER_e_C5_Clutch	CeTSER_e_C6_Clutch
1	750	750	750	750	750	750

Initial Supporting table - Clutch Clip Press NU Shifts						
<b>Description:</b> Oncoming clutch clip pressure for negative torque up shifts						
<b>Value Units:</b> kPa <b>X Unit:</b> Oncoming Clutch						
y/x	CeTSER_e_C1_Clutch	CeTSER_e_C2_Clutch	CeTSER_e_C3_Clutch	CeTSER_e_C4_Clutch	CeTSER_e_C5_Clutch	CeTSER_e_C6_Clutch
1	690	800	500	850	703	655

Initial Supporting table - Clutch Clip Press PD Shifts						
<b>Description:</b> Oncoming clutch clip pressure for open throttle power down shifts						
<b>Value Units:</b> kPa <b>X Unit:</b> Oncoming Clutch						
y/x	CeTSER_e_C1_Clutch	CeTSER_e_C2_Clutch	CeTSER_e_C3_Clutch	CeTSER_e_C4_Clutch	CeTSER_e_C5_Clutch	CeTSER_e_C6_Clutch
1	400	800	500	850	703	655

Initial Supporting table - Clutch Clip Press PU Shifts						
<b>Description:</b> Oncoming clutch clip pressure for open throttle powered up shifts						
<b>Value Units:</b> kPa <b>X Unit:</b> Oncoming Clutch						
y/x	CeTSER_e_C1_Clutch	CeTSER_e_C2_Clutch	CeTSER_e_C3_Clutch	CeTSER_e_C4_Clutch	CeTSER_e_C5_Clutch	CeTSER_e_C6_Clutch
1	2,100	900	500	850	703	655

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - Clutch Stuck On Fail Offset Time CD Shifts

**Description:** Used for closed throttle down shifts to add additional fail time based on oil temperature

**Value Units:** time (seconds)

**X Unit:** transmission fluid temperature °C

y/x	-40	-20	0	30	110
1	0	0	0	0	0

## Initial Supporting table - Clutch Stuck On Fail Offset Time GS Shifts

**Description:** Used for garage shifts to add additional fail time based on oil temperature**Value Units:** time (seconds)**X Unit:** transmission fluid temperature °C

y/x	-40	-20	0	30	110
1	0	0	0	0	0

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - Clutch Stuck On Fail Offset Time PD Shifts

**Description:** Used for open throttle power down shifts to add additional fail time based on oil temperature

**Value Units:** time (seconds)

**X Unit:** transmission fluid temperature °C

y/x	-40	-20	0	30	110
1	1	0	0	0	0

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - Clutch Stuck On Fail Offset Time PU Shifts

**Description:** Used for powered up shifts to add additional fail time based on oil temperature

**Value Units:** time (seconds)

**X Unit:** transmission fluid temperature °C

y/x	-40	-20	0	30	110
1	0	0	0	0	0



## Initial Supporting table - Clutch Stuck On Fail Offset Time STGR Shifts

**Description:** Used for clutch staging shifts to add additional fail time based on oil temperature

**Value Units:** time (seconds)

**X Unit:** transmission fluid temperature °C

y/x	-40	-20	0	30	110
1	0	0	0	0	0

## Initial Supporting table - Clutch Stuck On Shift Type Enable

**Description:** Calibration to enable the clutch stuck on test for each shift type**X Unit:** Shift Type**Y Units:** Boolean

y/x	CeTSER_e_STGR	CeTSER_e_GSCR	CeTSER_e_NUCR	CeTSER_e_PUCR	CeTSER_e_CDCR	CeTSER_e_PDCR	CeTSER_e_CLAR
1	0	0	1	1	1	1	0

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - engine speed time for transmission hydraulic pressure available

**Description:** ime needed for engine speed to trigger "transmission hydraulic pressure available"

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-40.00	-30.00	-20.00	0.00	40.00
1	0.300	0.300	0.275	0.200	0.200

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - engine speed time for transmission hydraulic pressure available

**Description:** time needed for engine speed to trigger "transmission hydraulic pressure available"

**Value Units:** seconds

**X Unit:** °C

y/x	-40.00	-30.00	-20.00	0.00	40.00
1	0.300	0.300	0.275	0.200	0.200

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - NumClchTieUp

**Description:** NumClchTieUp

**Value Units:** minimum # of clutches

**X Unit:** command gear or attained gear

**Y Units:** not applicable, no units, single row table f(gear)

### NumClchTieUp - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5
1	2	3	2	2	2	2	2

### NumClchTieUp - Part 2

y/x	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3
1	2	2	1	1	1	1	1

### NumClchTieUp - Part 3

y/x	CeCGSR_e_NeutralC2C4	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6	CeCGSR_e_NeutralC4C5
1	1	1	1	1	1	1	1

### NumClchTieUp - Part 4

y/x	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wN C	CeCGSR_e_Park_wN C1	CeCGSR_e_Park_wN C2	CeCGSR_e_Park_wN C3	CeCGSR_e_Park_wN C4
1	1	1	3	2	2	2	2

### NumClchTieUp - Part 5

y/x	CeCGSR_e_Park_wN C5	CeCGSR_e_Park_wN C6	CeCGSR_e_Park_wN C7	CeCGSR_e_Park_wN C1C2	CeCGSR_e_Park_wN C2C3	CeCGSR_e_Park_wN C2C4	CeCGSR_e_Park_wN C2C5
1	2	2	2	1	1	1	1

### NumClchTieUp - Part 6

y/x	CeCGSR_e_Park_wN C2C6	CeCGSR_e_Park_wN C3C4	CeCGSR_e_Park_wN C3C5	CeCGSR_e_Park_wN C3C6	CeCGSR_e_Park_wN C4C5	CeCGSR_e_Park_wN C4C6	CeCGSR_e_Park_wN C2C3C4C5
1	1	1	1	1	1	1	1

### NumClchTieUp - Part 7

y/x	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth
1	1	1	2	1	1	1	1

### NumClchTieUp - Part 8

y/x	CeCGSR_e_Fifth	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth	
-----	----------------	----------------	------------------	-----------------	----------------	----------------	--

Initial Supporting table - NumClchTieUp							
1	1	1	1	1	1	1	

## Initial Supporting table - P0722 Internal Speed Sensor Held

## Description:

Value Units: Boolean

X Unit: Gear

Y Units: Internal Speed Sensor location

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
CeCGSR_e_CR_NullForSched	1	1
CeCGSR_e_CR_Neutral	1	1
CeCGSR_e_CR_Park	1	1
CeCGSR_e_CR_Reverse	0	1
CeCGSR_e_CR_First	0	1
CeCGSR_e_CR_Second	0	1
CeCGSR_e_CR_Third	1	1
CeCGSR_e_CR_Fourth	0	1
CeCGSR_e_CR_Fifth	0	1
CeCGSR_e_CR_Sixth	0	1
CeCGSR_e_CR_Seventh	0	1
CeCGSR_e_CR_Eighth	1	1
CeCGSR_e_CR_Ninth	0	1
CeCGSR_e_CR_Tenth	1	1

## Initial Supporting table - P0722 OSS Direction Change Delay

Description:

Value Units: seconds

X Unit: DegC

y/x	-40	0	40
1	5	3	1



# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P0722 TIS TNS Diff

### Description:

**Value Units:** RPM  
**X Unit:** Speed Sensor Location  
**Y Units:** Gear

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
CeTGRR_e_Gear1	251	0
CeTGRR_e_Gear2	382	0
CeTGRR_e_Gear3	10,000	0
CeTGRR_e_Gear4	248	0
CeTGRR_e_Gear5	50	0
CeTGRR_e_Gear6	133	0
CeTGRR_e_Gear7	50	0
CeTGRR_e_Gear8	10,000	0
CeTGRR_e_Gear9	121	0
CeTGRR_e_Gear10	10,000	0

## Initial Supporting table - P0723 transmission engaged state time threshold

**Description:** time necessary after transmission engaged state indicates transmsision engaged to allow P0723 enable**Value Units:** seconds**X Unit:** transmission fluid temperature °C

y/x	-40.000	0.000	40.000
1	5.000	3.000	1.000

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - P0741 (GF9 specific) TCC slip speed crash RPM

**Description:** RPM limit used to establish slip crashed when TCC oil became available

**Value Units:** RPM

**X Unit:** % accelerator position

y/x	0.00	15.00	25.00	50.00	75.00
1	100	100	160	233	300

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - P0741 (GF9 specific) torque convert derivative slip speed fail threshold

**Description:** he fail threshold, rate of change of torque converter slip speed, at which the torque convert clutch is considered stuck on.

**Value Units:** RPM/second

**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
0	-600	-600	-600
15	-600	-600	-600
25	-900	-900	-900
50	-1,200	-1,200	-1,200
75	-1,500	-1,500	-1,500

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P0741 stuck on test time

**Description:** Value to initialize the TCC Stuck On test time to after transition of clutch select valve allowing TCC hydraulic circuit connectivity. Window is a time down window from the calibration value to zero (0.0) seconds.

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
1	1.500	1.250	1.000

Initial Supporting table - P171D hydraulic pressure delay

**Description:** Time to delay the initial x of y counter due to hydraulic transients. Thresholds are a function of transmission fluid temperature. Horizontal axis is transmission fluid temperature (DegC) and table output is delay time (seconds).

**Value Units:** delay time seconds  
**X Unit:** transmission fluid temperature DegC

y/x	-40	0	20	30	40	50	60
1	0.090	0.090	0.080	0.050	0.050	0.050	0.050

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - P171D predicted turbine speed error

**Description:** Predicted turbine speed vs actual turbine speed error. Thresholds are a function of engine speed and transmission fluid temperature. Diagnostic is considered failing above these values. Table vertical axis is engine speed (RPM), horizontal axis is transmission fluid temperature (DegC) and table output is predicted turbine speed error (RPM).

**Value Units:** turbine speed RPM error

**X Unit:** transmission fluid temperature DegC

**Y Units:** engine speed RPM

y/x	-40	0	10	20	40
0	300	300	300	300	300
500	300	300	300	300	300
1,100	300	300	300	300	300
1,500	300	300	300	300	300
2,500	300	300	300	300	300

**Initial Supporting table - P176B delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation****Description:** delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation**Value Units:** seconds**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	1.000	1.000



## Initial Supporting table - P176B holding clutch states

**Description:** inditaces when the clutch states allow transmission intermediate speed sensor evaluation, when rotating components can trigger speed sesnor, holding clutches will not allow evaluation while clutches not holding will allow evaluation

**Value Units:** TRUE or FALSE

**X Unit:** intermediate speed sensor select

**Y Units:** commanded gear

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
CeCGSR_e_CR_NullForSched	1	1
CeCGSR_e_CR_Neutral	1	1
CeCGSR_e_CR_Park	1	1
CeCGSR_e_CR_Reverse	0	1
CeCGSR_e_CR_First	0	1
CeCGSR_e_CR_Second	0	1
CeCGSR_e_CR_Third	1	1
CeCGSR_e_CR_Fourth	0	1
CeCGSR_e_CR_Fifth	0	1
CeCGSR_e_CR_Sixth	0	1
CeCGSR_e_CR-Seventh	0	1
CeCGSR_e_CR_Eighth	1	1
CeCGSR_e_CR_Ninth	0	1
CeCGSR_e_CR_Tenth	1	1

## Initial Supporting table - P176B intermediate speed sensor fail count threshold

**Description:** P176B intermediate speed sensor fail count threshold**Value Units:** fail counts**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	4	4

## Initial Supporting table - P176B intermediate speed sensor fail time threshold

**Description:** P176B intermediate speed sensor fail time threshold**Value Units:** seconds**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	2.000	2.000

**Initial Supporting table - P176B minimum estimated transmission intermediate speed to enable fail evaluation**

**Description:** minimum estimated transmission intermediate speed to enable fail evaluation, where estimate is based on transmission input speed / ratio calibration, where ratio calibration is either P176B ratio calibration when REVERSE or P176B ratio calibration when not REVERSE

**Value Units:** estimated transmission intermediate speed RPM

**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	172.0	172.0

**Initial Supporting table - P176B minimum transmission input speed to enable fail evaluation****Description:** minimum transmission input speed to enable fail evaluation**Value Units:** transmission input speed RPM**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	172.0	172.0

## Initial Supporting table - P176B ratio calibration when not REVERSE

**Description:** used to estimate transmission input speed based on transmission intermediate speed when range is not REVERSE**Value Units:** ratio**X Unit:** commanded gear**Y Units:** intermediate speed sensor select

y/x	CeTGRR_e_Gear1	CeTGRR_e_Gear2	CeTGRR_e_Gear3	CeTGRR_e_Gear4	CeTGRR_e_Gear5	CeTGRR_e_Gear6	CeTGRR_e_Gear7	CeTGRR_e_Gear8	CeTGRR_e_Gear9	CeTGRR_e_Gear10
CeTSRR_e_C2 C_ClchSpdSnsr1	1.5848	6.3694	1.0000	2.4450	1.0000	0.5227	1.0000	1.0000	1.1905	1.0000
CeTSRR_e_C2 C_ClchSpdSnsr2	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000

## Initial Supporting table - P176B ratio calibration when REVERSE

**Description:** used to estimate transmission input speed based on transmission intermediate speed when range is REVERSE

**Value Units:** ratio

**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	1.0000	1.0000

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P176C Enable Boolean

Description:		
Value Units: Boolean		
y/x	0	1
1	1	0



Initial Supporting table - P176C Fail Count Threshold

Description:

Value Units: Count

y/x	0	1
1	40	65,535

Initial Supporting table - P176C Fail Timer		
Description:		
Value Units: seconds X Unit: intermediate speed sensor index		
y/x	0	1
1	0	410

Initial Supporting table - P176D Boolean Enable

Description:

Value Units: Boolean  
X Unit: Speed Sensor Index

y/x	0	1
1	1	0

Initial Supporting table - P176D Fail Count Threshold

Description:		
Value Units: Count X Unit: Speed Sensor Index		
y/x	0	1
1	40	65,535

Initial Supporting table - P176D Fail Time Threshold

Description:

Value Units: seconds  
X Unit: Speed Sensor Index

y/x	0	1
1	0	410

Initial Supporting table - P176D Voltage Fail Threshold

Description:

Value Units: Volts  
X Unit: Speed Sensor Index

y/x	0	1
1	5	12

## Initial Supporting table - P17C5 P17D3 intermediate speed sensor RPM

**Description:** P17C5 P17D3 intermediate speed sensor RPM at signal period transtion to enable fail time update

**Value Units:** intermediate speed sensor RPM

**X Unit:** intermediate speed sensor 1 or 2

y/x	0	1
1	25	25

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

### Initial Supporting table - P2817 TCC stuck off fail TCC slip speed

**Description:** TCC stuck off slip speed fail threshold when TCC is in ON mode (controlled slip mode)

**Value Units:** RPM

**X Unit:** engine torque Nm

y/x	0.00	64.00	128.00	192.00	256.00	320.00	384.00	448.00	512.00
1	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0



## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2818 (GF9 specific) control valve test time

**Description:** Value to initialize the torque converter clutch control valve test time to after clutch select valve solenoid is turned on, window of time in which the torque converter clutch slip speed and derivative slip speed must be evaluated for failure. Window is a time down window from the calibration value to zero (0.0) seconds.

**Value Units:** seconds

**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
1	0.600	0.300	0.100

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2818 stuck on test time			
<b>Description:</b> Value to initialize the TCC Stuck On test time to after transition of clutch select valve allowing TCC hydraulic circuit connectivity. Window is a time down window from the calibration value to zero (0.0) seconds.			
<b>Value Units:</b> seconds <b>X Unit:</b> transmission fluid temperature °C			
y/x	-7.00	10.00	40.00
1	1.500	1.250	1.000

## Initial Supporting table - P2818 torque convert derivative slip speed fail threshold

**Description:** The fail threshold, rate of change of torque converter slip speed, at which the torque convert clutch is considered stuck on.

**Value Units:** RPM/second

**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
0	-600.0	-600.0	-600.0
15	-600.0	-600.0	-600.0
25	-900.0	-900.0	-900.0
50	-1,200.0	-1,200.0	-1,200.0
75	-1,500.0	-1,500.0	-1,500.0

## 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Cltch Slip Sum

## Description:

**Value Units:** rate of change of output rpm (dn) per 25 milliseconds**X Unit:** % brake pedal position**Y Units:** not applicable, no units, single row table f(brake pedal position)

y/x	0	15	20	30	35	50	75	88	100
1	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C1

**Description:** clutch 1 command pressure threshold below which clutch 1 is considered released, such that, clutch 1 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C1 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	131.3	131.3	9,999.0	344.3	409.6

### P2D2 Decel Pressure - C1 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	9,999.0	131.3	344.3	131.3	9,999.0

### P2D2 Decel Pressure - C1 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	9,999.0	9,999.0	9,999.0	50.0	50.0

### P2D2 Decel Pressure - C1 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50.0	344.3	50.0	50.0	409.6

### P2D2 Decel Pressure - C1 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	644.8	644.8	50.0	131.3	9,999.0

### P2D2 Decel Pressure - C1 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	344.3	409.6	9,999.0	131.3	344.3

### P2D2 Decel Pressure - C1 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	131.3	9,999.0	50.0	50.0	50.0

### P2D2 Decel Pressure - C1 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	344.3	50.0	50.0	409.6	644.8

### P2D2 Decel Pressure - C1 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C1

1	644.8	50.0	131.3	9,999.0	9,999.0
P2D2 Decel Pressure - C1 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	9,999.0	9,999.0	9,999.0	9,999.0	9,999.0
P2D2 Decel Pressure - C1 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	9,999.0	644.8	409.6	344.3	50.0
P2D2 Decel Pressure - C1 - Part 12					
y/x					
1					

## Initial Supporting table - P2D2 Decel Pressure - C2

**Description:** clutch 2 command pressure threshold below which clutch 2 is considered released, such that, clutch 2 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

## P2D2 Decel Pressure - C2 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	359	359	359	9,999	2,125

## P2D2 Decel Pressure - C2 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	801	489	359	512	9,999

## P2D2 Decel Pressure - C2 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	2,125	801	489	50	50

## P2D2 Decel Pressure - C2 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	9,999	50	50	2,125

## P2D2 Decel Pressure - C2 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	765	765	50	359	359

## P2D2 Decel Pressure - C2 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	9,999	2,125	801	489	359

## P2D2 Decel Pressure - C2 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	512	9,999	50	50	50

## P2D2 Decel Pressure - C2 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	9,999	50	50	2,125	765

## P2D2 Decel Pressure - C2 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C2

1	765	50	512	570	570
P2D2 Decel Pressure - C2 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	9,999	9,999	2,125	801	489
P2D2 Decel Pressure - C2 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	359	765	2,125	9,999	50
P2D2 Decel Pressure - C2 - Part 12					
y/x					
1					



# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C3

**Description:** clutch 3 command pressure threshold below which clutch 3 is considered released, such that, clutch 3 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C3 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	245	245	247	1,293	9,999

### P2D2 Decel Pressure - C3 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	706	245	247	245	1,294

### P2D2 Decel Pressure - C3 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	9,999	706	360	50	50

### P2D2 Decel Pressure - C3 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	1,293	50	50	9,999

### P2D2 Decel Pressure - C3 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	674	674	50	245	247

### P2D2 Decel Pressure - C3 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	1,293	9,999	706	245	247

### P2D2 Decel Pressure - C3 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	245	1,294	50	50	50

### P2D2 Decel Pressure - C3 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	1,293	50	50	9,999	674

### P2D2 Decel Pressure - C3 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C3

1	674	50	245	273	273
P2D2 Decel Pressure - C3 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	1,294	1,294	9,999	706	360
P2D2 Decel Pressure - C3 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	247	674	9,999	1,293	50
P2D2 Decel Pressure - C3 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C4

**Description:** clutch 4 command pressure threshold below which clutch 4 is considered released, such that, clutch 4 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa  
**X Unit:** command gear  
**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C4 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	433	433	482	1,041	1,585

### P2D2 Decel Pressure - C4 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	9,999	433	915	433	1,145

### P2D2 Decel Pressure - C4 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	1,713	9,999	1,772	50	50

### P2D2 Decel Pressure - C4 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	1,041	50	50	1,585

### P2D2 Decel Pressure - C4 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	9,999	9,999	50	433	482

### P2D2 Decel Pressure - C4 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	1,041	1,585	9,999	433	915

### P2D2 Decel Pressure - C4 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	433	1,145	50	50	50

### P2D2 Decel Pressure - C4 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	1,041	50	50	1,585	9,999

### P2D2 Decel Pressure - C4 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C4

1	9,999	50	433	482	482
P2D2 Decel Pressure - C4 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	1,145	1,145	1,713	9,999	1,772
P2D2 Decel Pressure - C4 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	915	2,030	1,585	1,041	50
P2D2 Decel Pressure - C4 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C5

**Description:** clutch 5 command pressure threshold below which clutch 5 is considered released, such that, clutch 5 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C5 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	140	140	140	255	318

### P2D2 Decel Pressure - C5 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	646	9,999	685	140	255

### P2D2 Decel Pressure - C5 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	318	646	9,999	50	50

### P2D2 Decel Pressure - C5 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	780	50	50	1,188

### P2D2 Decel Pressure - C5 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	9,999	50	50	140	140

### P2D2 Decel Pressure - C5 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	255	318	646	9,999	685

### P2D2 Decel Pressure - C5 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	140	255	50	50	50

### P2D2 Decel Pressure - C5 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	780	50	50	1,188	9,999

### P2D2 Decel Pressure - C5 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C5

1	50	50	9,999	140	140
P2D2 Decel Pressure - C5 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	255	255	318	646	9,999
P2D2 Decel Pressure - C5 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	685	9,999	1,188	780	50
P2D2 Decel Pressure - C5 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C6

**Description:** clutch 6 command pressure threshold below which clutch 6 is considered released, such that, clutch 6 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C6 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	178	178	178	283	330

### P2D2 Decel Pressure - C6 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	504	253	9,999	178	283

### P2D2 Decel Pressure - C6 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	330	504	1,036	50	50

### P2D2 Decel Pressure - C6 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	9,999	50	50	9,999

### P2D2 Decel Pressure - C6 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	50	9,999	50	178	178

### P2D2 Decel Pressure - C6 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	283	330	504	253	9,999

### P2D2 Decel Pressure - C6 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	178	283	50	50	50

### P2D2 Decel Pressure - C6 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	9,999	50	50	9,999	50

### P2D2 Decel Pressure - C6 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C6

1	9,999	50	253	178	178
P2D2 Decel Pressure - C6 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	283	283	330	504	1,036
P2D2 Decel Pressure - C6 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	9,999	9,999	9,999	9,999	50
P2D2 Decel Pressure - C6 - Part 12					
y/x					
1					



# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C7

**Description:** clutch 7 command pressure threshold below which clutch 7 is considered released, such that, clutch 7 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

### P2D2 Decel Pressure - C7 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	50	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	50	50	50	9,999	50

### P2D2 Decel Pressure - C7 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	50	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	50	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	50	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	9,999	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	50	50	50	50	50

### P2D2 Decel Pressure - C7 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW

20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C7

1	50	50	9,999	9,999	50
P2D2 Decel Pressure - C7 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	50	50	50	50	50
P2D2 Decel Pressure - C7 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	50	50	50	50	50
P2D2 Decel Pressure - C7 - Part 12					
y/x					
1					

# 20 OBDG03A TCM T87A 9 Speed FWD Supporting Tables

## Initial Supporting table - transmission fluid temperature warm up time

**Description:**

**Value Units:** transmission fluid temperature normal warm up time, seconds

**X Unit:** transmission fluid temperature at controller power up, °C

y/x	-40.00	-30.00	-20.00	0.00	20.00
1	1,800.0	1,500.0	1,200.0	600.0	60.0

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Backup Transmission Range Command Message Counter Incorrect	C1201	UPDATE The diagnostic monitor detects an alive rolling count error or protection value (checksum) error in the LIN bus frame containing the Electronic Transmission Range Selector (ETRS) signal data. The alive rolling count sequences 0, 1, 2, 3 repeatedly. As each serial data frame is broadcast by the transmitting controller, the transmitting controller increments the alive rolling count in this sequence manner. The receiving controller compares the most recent received alive rolling count value to the previous value plus one. If the values are not equal, an alive rolling count error has occurred. The protection value is based on the checksum of the ETRS data parameters in the transmit message frame, and is incorporated in the transmit message frame. If the TCM receives the ECM/CHCM ETRS data	rolling count value received from ECM/CHCM and expected TCM calculated value not equal	= TRUE	Loop rate calibration either 10 milliseconds or 12.5 milliseconds  service mode \$04 active battery voltage battery voltage time  ETRS ECM/CHCM frame recieved	= CeCFMD_e_DEC_Time Base_12p5  = FALSE ≥ 11.00 volts ≥ 300.000 seconds  = TRUE	alive rolling count errors ≥ 8 out of 10 sample counts	Type B, 2 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		message frame, the TCM calculates the protection value, again based on the ETRS data parameters, in the receive message frame. If the TCM calculated protection value does not equal the protection value incorporated in the ECM/CHCM ETRS data message frame, a or protection value error has occurred. If continuous alive rolling count errors or protection value errors occur, the DTC is set.						

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lateral Acceleration Sensor Circuit Low	C124F	Controller specific analog circuit diagnoses the raw lateral acceleration signal for a short to ground or open fault by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral acceleration signal = 0.0 g.	raw lateral acceleration signal when sensor type is directly proportional OR raw lateral acceleration signal when sensor type is inversely proportional  update raw lateral acceleration signal stability time, fail and sample time, 50 millisecond update rate	$\leq -3.8500 \text{ g}$  $\geq -3.8500 \text{ g}$  ( $\leq 0.5 \Omega$ impedance between signal and controller ground)	battery voltage run crank voltage diagnostic monitor enable  sensor type is either directly proportional or inversely proportional  U0073 fault active U0073 test fail this key on	$\geq 11.00 \text{ volts}$ $\geq 11.00 \text{ volts}$ = 1 Boolean  = CeLATR_e_VoltageDirec tProp  = FALSE = FALSE	raw lateral acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lateral Acceleration Sensor Circuit High	C1250	Controller specific analog circuit diagnoses the raw lateral acceleration signal for a short to power or open fault by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral acceleration signal = 0.0 g.	raw lateral acceleration signal when sensor type is directly proportional OR raw lateral acceleration signal when sensor type is inversely proportional  update raw lateral acceleration signal stability time, fail and sample time, 50 millisecond update rate	$\geq 3.8500 \text{ g}$  $\leq 3.8500 \text{ g}$  ( $\leq 0.5 \Omega$ impedance between signal and controller power)	battery voltage run crank voltage diagnostic monitor enable  sensor type is either directly proportional or inversely proportional  U0073 fault active U0073 test fail this key on	$\geq 11.00 \text{ volts}$ $\geq 11.00 \text{ volts}$ = 1 Boolean  = CeLATR_e_VoltageDirec tProp  = FALSE = FALSE	raw lateral acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lateral Acceleration Sensor Performance	C1251	Controller specific analog circuit diagnoses the raw lateral acceleration signal for a signal value that is stuck in a valid range by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral acceleration signal = 0.0 g.	ABS(raw lateral acceleration signal) AND ABS(raw lateral acceleration signal)  update raw lateral acceleration signal fail, 50 millisecond update rate	$\geq 0.5300 \text{ g}$  $\leq 3.8500 \text{ g}$	battery voltage run crank voltage diagnostic monitor enable  update raw lateral acceleration signal stability time: TOSS vehicle speed automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable diagnsotic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear attained gear slip  ABS(raw lateral acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	$\geq 11.00 \text{ volts}$ $\geq 11.00 \text{ volts}$ = 1 Boolean    $\geq 15.0 \text{ KPH}$ = TRUE  = TRUE = TRUE = FALSE  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1st thru 10th $\leq 100.0 \text{ RPM}$  $< 0.5300 \text{ g}$  = FALSE = FALSE VehicleSpeedSensor_FA	raw lateral acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Longitudinal Acceleration Sensor Circuit Low	C1252	Controller specific analog circuit diagnoses the raw longitudinal acceleration signal for a short to ground or open fault by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral longitudinal acceleration signal = 0.0 g.	raw longitudinal acceleration signal when sensor type is directly proportional OR raw longitudinal acceleration signal when sensor type is inversely proportional  update raw longitudinal acceleration signal stability time, fail and sample time, 50 millisecond update rate	$\leq -3.8500$ g  $\geq -3.8500$ g  ( $\leq 0.5 \Omega$ impedance between signal and controller ground)	battery voltage run crank voltage diagnostic monitor enable  sensor type is either directly proportional or inversely proportional  U0073 fault active U0073 test fail this key on	$\geq 11.00$ volts $\geq 11.00$ volts = 1 Boolean  = CeLATR_e_VoltageDirec tProp  = FALSE = FALSE	raw longitudinal acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Longitudinal Acceleration Sensor Circuit High	C1253	Controller specific analog circuit diagnoses the raw longitudinal acceleration signal for a short to power or open fault by comparing raw signal value to fail thresholds.  Emission neutral default state sets lateral longitudinal acceleration signal = 0.0 g.	raw longitudinal acceleration signal when sensor type is directly proportional OR raw longitudinal acceleration signal when sensor type is inversely proportional  update raw longitudinal acceleration signal stability time, fail and sample time, 50 millisecond update rate	$\geq 3.8500 \text{ g}$  $\leq 3.8500 \text{ g}$  ( $\leq 0.5 \Omega$ impedance between signal and controller power)	battery voltage run crank voltage diagnostic monitor enable  sensor type is either directly proportional or inversely proportional  U0073 fault active U0073 test fail this key on	$\geq 11.00 \text{ volts}$ $\geq 11.00 \text{ volts}$ = 1 Boolean  = CeLATR_e_VoltageDirec tProp  = FALSE = FALSE	raw longitudinal acceleration signal stability time $\geq 30.0$ seconds, fail time $\geq 75.0$ seconds out of sample time $\geq 120.0$ seconds, 50 millisecond update rate	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Longitudinal Acceleration Sensor Performance	C1254	<p>Controller specific analog circuit diagnoses the raw longitudinal acceleration signal rationalized against the TOSS vehicle speed acceleration. The diagnostic monitor can be designed to detect an invalid longitudinal acceleration signal based on the TOSS vehicle speed windows and TOSS vehicle speed acceleration, 4 windows can be enabled. The delta between the TOSS vehicle speed acceleration and longitudinal acceleration signal is taken within each window to verify the delta is small, no failure indicated, or the delta is large indicating the longitudinal acceleration signal is in error.</p> <p>Emission neutral default state sets lateral longitudinal acceleration signal = 0.0 g.</p>	<p>ABS(TOSS vehicle speed acceleration - raw longitudinal acceleration signal)</p> <p>update raw longitudinal acceleration signal region 1 fail time, 50 millisecond update rate</p>	≥ 0.5300 g	<p>battery voltage run crank voltage diagnostic monitor enable region 1 specific enable</p> <p>update raw lateral longitudinal acceleration signal stability time: TOSS vehicle speed TOSS vehicle speed acceleration automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable diagnotic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear attained gear slip ABS(raw longitudinal acceleration signal) AND ABS(raw longitudinal acceleration signal)</p> <p>update region 1 sample time: brake pedal position engine torque TOSS vehicle speed acceleration TOSS vehicle speed TOSS vehicle speed</p>	<p>≥ 11.00 volts ≥ 11.00 volts = 1 Boolean = 0 Boolean</p> <p>≥ 15.0 KPH ≤ 0.5300 g</p> <p>= TRUE</p> <p>= TRUE = TRUE = FALSE</p> <p>= FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1st thru 10th ≤ 100.0 RPM ≥ 0.5300 g</p> <p>≤ 3.8500 g</p> <p>≤ 0.70 % ≥ 80.0 Nm ≥ 0.1500 g ≥ 15.0 KPH ≤ 200.0 KPH</p>	<p>raw lateral longitudinal acceleration signal stability time ≥ 10.0 seconds, fail time ≥ 75.0 seconds out of sample time ≥ 120.0 seconds, 50 millisecond update rate</p> <p>region 1 fail time ≥ 75.0 seconds out of region 1 sample time ≥ 120.0 seconds, 50 millisecond update rate</p>	Emission Neutral Diagnostic – Type C

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					ABS(raw longitudinal acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	< 0.5300 g  = FALSE = FALSE VehicleSpeedSensor_FA VehicleSpeedSensorError		
			ABS(TOSS vehicle speed acceleration - raw longitudinal acceleration signal)  update raw longitudinal acceleration signal region 2 fail time, 50 millisecond update rate	≥ 0.0000 g	battery voltage run crank voltage diagnostic monitor enable region 2 specific enable  update raw lateral longitudinal acceleration signal stability time: TOSS vehicle speed TOSS vehicle speed acceleration automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable diagnsotic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear attained gear slip ABS(raw longitudinal acceleration signal) AND ABS(raw longitudinal	≥ 11.00 volts ≥ 11.00 volts = 1 Boolean = 0 Boolean  ≥ 15.0 KPH ≤ 0.5300 g  = TRUE  = TRUE = TRUE = FALSE  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1st thru 10th ≤ 100.0 RPM ≥ 0.5300 g  ≤ 3.8500 g	raw lateral longitudinal acceleration signal stability time ≥ 10.0 seconds, fail time ≥ 75.0 seconds out of sample time ≥ 120.0 seconds, 50 millisecond update rate	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					acceleration signal)  update region 2 sample time: brake pedal position engine torque TOSS vehicle speed acceleration TOSS vehicle speed TOSS vehicle speed  ABS(raw longitudinal acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	≤ 0.70 % ≥ 80.0 Nm ≥ 0.1500 g  ≥ 0.0 KPH ≤ 0.0 KPH  < 0.5300 g  = FALSE = FALSE VehicleSpeedSensor_FA VehicleSpeedSensorError	region 2 fail time ≥ 75.0 seconds out of region 2 sample time ≥ 120.0 seconds, 50 millisecond update rate	
			ABS(TOSS vehicle speed acceleration - raw longitudinal acceleration signal)  update raw longitudinal acceleration signal region 3 fail time, 50 millisecond update rate	≥ 0.0000 g	battery voltage run crank voltage diagnostic monitor enable region 3 specific enable  update raw lateral longitudinal acceleration signal stability time: TOSS vehicle speed TOSS vehicle speed acceleration automatic transmission is clutch to clutch OR dual clutch high side drive 1 enable high side drive 2 enable diagnostic fault sequence gear active P0716 fault active P0716 test fail this key on P0717 fault active P0717 test fail this key on	≥ 11.00 volts ≥ 11.00 volts = 1 Boolean = 0 Boolean  ≥ 15.0 KPH ≤ 0.5300 g  = TRUE  = TRUE = TRUE = FALSE  = FALSE = FALSE = FALSE = FALSE	raw lateral longitudinal acceleration signal stability time ≥ 10.0 seconds, fail time ≥ 75.0 seconds out of sample time ≥ 120.0 seconds, 50 millisecond update rate	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P07BF fault active P07BF test fail this key on P07C0 fault active P07C0test fail this key on attained gear attained gear slip ABS(raw longitudinal acceleration signal) AND ABS(raw longitudinal acceleration signal)  update region 3 sample time: brake pedal position engine torque ABS(TOSS vehicle speed acceleration) TOSS vehicle speed  ABS(raw longitudinal acceleration signal) update sample time  U0073 fault active U0073 test fail this key on DTCs not fault active	= FALSE = FALSE = FALSE = FALSE = 1st thru 10th ≤ 100.0 RPM ≥ 0.5300 g  ≤ 3.8500 g  ≤ 0.70 % ≥ 80.0 Nm ≤ 0.1000 g ≥ 0.0 KPH  < 0.5300 g  = FALSE = FALSE VehicleSpeedSensor_FA VehicleSpeedSensorError	region 3 fail time ≥ 75.0 seconds out of region 3 sample time ≥ 120.0 seconds, 50 millisecond update rate	
			ABS(TOSS vehicle speed acceleration - raw longitudinal acceleration signal)  update raw longitudinal acceleration signal region 4 fail time, 50 millisecond update rate	≥ 0.0000 g	battery voltage run crank voltage diagnostic monitor enable region 3 specific enable  update raw lateral longitudinal acceleration signal stability time: TOSS vehicle speed TOSS vehicle speed acceleration automatic transmission is clutch to clutch OR dual	≥ 11.00 volts ≥ 11.00 volts = 1 Boolean = 0 Boolean  ≥ 15.0 KPH ≤ 0.5300 g  = TRUE	raw lateral longitudinal acceleration signal stability time ≥ 10.0 seconds, fail time ≥ 75.0 seconds out of sample time ≥ 120.0 seconds, 50 millisecond update rate	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

[illegible]

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
System Voltage Performance	P0561	Detects a low performing 12V battery system. This diagnostic reports the DTC when the absolute value of the difference between the battery voltage and the run/ crank voltage exceeds a calibrated value.	Run Crank voltage low and high	ABS(Battery voltage - Run Crank voltage) > 3.00	Battery voltage B+ line present = TRUE  Battery voltage low and high diag enable = TRUE  Run Crank voltage	1.00  1.00  Voltage ≥ 5.00 volts	40 failures out of 50 samples  100 ms / sample	Type A, 1 Trips



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5.00 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
			The Primary Processor's calculated checksum does not match the stored checksum value for a selected subset of the calibrations.	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
			The Secondary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	
				In all cases, the failure count is cleared when controller shuts down				

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the DEC ECU has not been flash programmed with production software and calibration.	controller not flash programmed calibration	= 0 Boolean	controller normal power up initialization, ignition run crank transtions from low to high  service Mode \$04 active during one second loop	= FALSE	at controller power up intitalization one time (one event/ occurance) OR in one second time loop	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM Long Term Memory Reset	P0603	This DTC detects an invalid NVM which includes a Static NVM, Perserved NVM, ECC ROM in NVM Flash Region, and Perserved NVM during shut down.	Static NVM region error detected during initialization				Diagnostic runs at controller power up.	Type A, 1 Trips
			Perserved NVM region error detected during initialization				Diagnostic runs at controller power up.	
			ECC ROM fault detected in NVM Flash region				Diagnostic runs at controller power up.	
			ECC ROM Error Count >	3				
			Perserved NVM region error detected during shut down.				Diagnostic runs at controller power down.	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604	Indicates that the ECM has detected a RAM fault. This includes Primary Processor System RAM Fault, Primary Processor Cache RAM Fault, Primary Processor TPU RAM Fault, Primary Processor Update Dual Store RAM Fault, Primary Processor Write Protected RAM Fault, and Secondary Processor RAM Fault. This diagnostic runs continuously.	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips
			Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	3 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.40000 s			When dual store updates occur.	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	65,534 counts			Diagnostic runs continuously (background loop)	
			Indicates that the secondary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault. These include diagnostics done on the SPI Communication as well as a host of diagnostics for both the primary and secondary processors.	Loss or invalid message of SPI communication from the Secondary Processor at initialization detected by the Primary Processor or loss or invalid message of SPI communication from the Secondary Processor after a valid message was received by the Primary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received	Run/Crank voltage  Run/Crank voltage	>= 8.00 Volts or >= 11.00 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent or 10 counts continuous; 100 counts continuous @ initialization. 12.5 ms /count in the ECM main processor	Type A, 1 Trips
			Loss or invalid message of SPI communication from the Primary Processor at initialization detected by the Secondary Processor or loss or invalid message of SPI communication from the Primary Processor after a valid message was received by the Secondary Processor	Loss or invalid message at initialization detected or loss or invalid message after a valid message was received			In the secondary processor, 64 / 161 counts intermittent or 0.1875 s continuous; 0.4875 s continuous @ initialization. 12.5 ms /count in the ECM secondary processor	
			Checks for stack over or underflow in secondary processor by looking for corruption of known pattern at stack boundaries. Checks number of stack over/under flow since last powerup reset >=	5		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			MAIN processor is verified by responding to a seed sent from the secondary with a key response to secondary. Checks number of incorrect keys	2 incorrect seeds within 8 messages, 0.2000 seconds		ignition in Run or Crank	150 ms for one seed continually failing	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			received > or Secondary processor has not received a new within time limit					
			Time new seed not received exceeded			always running	0.450 seconds	
			MAIN processor receives seed in wrong order			always running	3 / 17 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the Secondary processor's ALU check			Test is Enabled: 1 (If 0, this test is disabled)	25 ms	
			2 fails in a row in the Secondary processor's configuration register masks versus known good data			Test is Enabled: 1 (If 0, this test is disabled)	12.5 to 25 ms	
			Secondary processor detects an error in the toggling of a hardware discrete line controlled by the MAIN processor: number of discrete changes > = or < = over time window(50ms)	7 17		Test is Enabled: 0 . (If 0, this test is disabled)  time from initialization >= 0.5000 seconds	50 ms	
			Software background task first pass time to complete exceeds			Run/Crank voltage > 6.41	35.000 seconds	
			2 fails in a row in the MAIN processor's ALU check			Test is Enabled: 0 CPU 1 enable 1 CPU 2 enable 0 CPU 3 enable 0 CPU 4 enable	25 ms	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						(If 0, this test is disabled)		
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			Test is Enabled: 1 (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	5		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		Test is Enabled: 1 (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to write flash to RAMvariable, depends on length of time to write flash to RAM	



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			MAIN processor DMA transfer from Flash to RAM has 1 failure			Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	
			Safety critical software is not executed in proper order.	>= 1 incorrect sequence.		Test is Enabled: <b>P0606 enable</b> see supporting table	Fail Table, f(Loop Time). See supporting tables: <b>P0606_PSW Sequence Fail f (Loop Time)</b> /  Sample Table, f (Loop Time)See supporting tables: <b>P0606_PSW Sequence Sample f(Loop Time)</b>  counts  50 ms/count in the ECM main processor	
			MAIN processor determines a seed has not changed within a specified time period within the 50ms task.	Previous seed value equals current seed value.		Test is Enabled: 1 (If 0, this test is disabled)	Table, f(Loop Time). See supporting tables: <b>P0606_Last Seed Timeout f (Loop Time)</b>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Internal Control Module EEPROM Error	P062F	This DTC detects a NVM long term performance. There are two types of diagnostics that run during controller power up. One for HWIO reports that writing to NVM (at shutdown) will not succeed, and the other HWIO reports the assembly calibration integrity check has failed.	HWIO reports that writing to NVM (at shutdown) will not succeed				Diagnostic runs at controller power up.	Type A, 1 Trips
			HWIO reports the assembly calibration integrity check has failed				Diagnostic runs at controller power up.	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Actuator Supply Voltage Circuit Low	P0658	Controller specific output driver circuit diagnoses the high sided driver circuit for a short to ground failure, or where controller H/W cannot differentiate, diagnoses the high sided driver circuit for a short to ground failure or open circuit failure, when the output is powered on, by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	$\leq 0.5 \Omega$ impedance between signal and controller ground	<p>diagnostic monitor enable high side drive ON service mode \$04 not active service fast learn not active P0658 fault active P0658 test fail this key on</p>	<p>= 1 Boolean = TRUE</p> <p>= FALSE = FALSE</p>	<p>fail count <math>\geq 6</math> counts out of sample count <math>\geq 2,400</math> counts</p> <p>6.25 millisecond update rate</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Torque Managment System - Forced Engine Shutdown	P06AF	The diagnostic is monitoring that the TCM is processing code correctly. The TCM has a main and a secondary processor. As long as the main TCM processor responds to the secondary TCM processor correctly then the correct pattern is sent via CAN message to the Monitoring Controller. When the TCM does not have correct interaction between its two microprocessors then an incorrect pattern is sent to the monitoring controller and the the monitoring controller sets the DTC.	Received pattern from the TCM OR Received malfunction pattern	≠ expected pattern (F, 5, B, D, A, 6, 3, 0)  ≥ 2.00 counts	Run/Crank Voltage OR Ignition Run/Crank Voltage  Run Crank Active Time	≥ 8.00 V  ≥ 11.00 V  ≥ 0.50 seconds	0.075 seconds out of a 0.15 second window	Type A, 1 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Fluid Temperature (TFT) Sensor Performance	P0711	The diagnostic monitor will verify the time to transmission fluid temperature warm up based on the raw transmission fluid temperature sensor, any intermittent signal that causes multiple unrealistic delta changes (intermittent faults) based on the raw transmission fluid temperature sensor, and, raw transmission fluid temperature sensor signal stuck in valid range.	raw transmission fluid temperature and the transmission fluid temperature warm up time has elapsed	$\leq 15.0\text{ }^{\circ}\text{C}$	<div>diagnsotic monitor enable P0712 NOT fault active P0713 NOT fault active battery voltage</div> <div>run crank voltage</div> <div>warm up test enable TFT rationality diagnostic monitor enabled</div> <div>driver accelerator pdeal position engine torque engine speed vehicle speed engine coolant temperature engine coolant temperature raw transmission fluid temperature raw transmission fluid temperature</div> <div>P2818 fault active P2818 test fail this key on</div> <div>DTCs not fault active</div>	<div>= 1 Boolean</div> <div><math>\geq 9.00\text{ volts}</math></div> <div><math>\geq 9.00\text{ volts}</math></div> <div>= 1 Boolean = VeTFSR_b_TFT_RatlEnbl</div> <div><math>\geq 5.0\text{ }\%</math></div> <div><math>\geq 50.0\text{ Nm}</math> <math>\geq 500.0\text{ RPM}</math> <math>\geq 10.0\text{ KPH}</math> <math>\geq -40.0\text{ }^{\circ}\text{C}</math></div> <div><math>\leq 150.0\text{ }^{\circ}\text{C}</math></div> <div><math>\geq -40.0\text{ }^{\circ}\text{C}</math></div> <div><math>\leq 150.0\text{ }^{\circ}\text{C}</math></div> <div>= FALSE = FALSE</div>	<div>transmission fluid temperature warm up time <math>\geq</math> <b>transmission fluid temperature warm up time</b> seconds</div> <div>battery voltage time <math>\geq 0.100</math> seconds</div> <div>run crank voltage time <math>\geq 0.100</math> seconds</div>	Type B, 2 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngineTorqueEstInaccu rate AcceleratorPedalFailure CrankSensor_FA ECT_Sensor_FA VehicleSpeedSensor_FA		
			current transmission fluid temperature string length = previous transmission fluid temperature transmission temperature string length + (raw transmission fluid temperature - previous raw transmission fluid temperature, update rate 100 milliseconds, increment sample count	≥ 80.0 °C			sample count ≥ 10 counts evaluate fail temperature threshold, 100 millisecond update rate, if transmission fluid temperature string length above fail threshold increment fail time  fail time ≥ 8.0 seconds out of sample time ≥ 12.0 seconds	
					diagnsotic monitor enable P0712 NOT fault active P0713 NOT fault active battery voltage	= 1 Boolean  ≥ 9.00 volts	battery voltage time ≥ 0.100 seconds	
					run crank voltage	≥ 9.00 volts	run crank voltage time ≥ 0.100 seconds	
					intermittent test enable propulsion system active	= 1 Boolean = TRUE		
			raw transmission fluid temperature - previous	≤ 0.0000 °C			fail time ≥ 300.0 seconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			raw transmission fluid temperature, update rate 100 milliseconds, update fail time		diagnsotic monitor enable P0712 NOT fault active P0713 NOT fault active battery voltage  run crank voltage  stuck in range test enable propulsion system active raw transmission fluid temperature raw transmission fluid temperature	= 1 Boolean  ≥ 9.00 volts  ≥ 9.00 volts  = 1 Boolean = TRUE ≥ -40.0 °C ≤ 150.0 °C	battery voltage time ≥ 0.100 seconds  run crank voltage time ≥ 0.100 seconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Fluid Temperature Sensor Circuit Low Voltage	P0712	Controller specific analog circuit diagnoses the transmission fluid temperature sensor and wiring for a short to ground fault by comparing a voltage measurement to controller specific voltage thresholds, converted to a resistance value.	circuit resistance update fail time 1 seconds update rate	$\leq 13.500 \ \Omega$	<div>diagnostic monitor enable</div> <div>battery voltage</div> <div>run crank voltage run crank voltage in range time</div>	<div>= 1 Boolean</div> <div><math>\geq 9.00</math> volts</div> <div><math>\geq 9.00</math> volts</div>	<div>fail time <math>\geq 5.00</math> seconds out of sample time <math>\geq 6.00</math> seconds 1 seconds update rate</div> <div>battery voltage in range time <math>\geq 0.100</math> seconds</div> <div>run crank voltage in range time <math>\geq 0.100</math> seconds</div>	Type B, 2 Trips



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Fluid Temperature Sensor Circuit Low Voltage	P0713	Controller specific analog circuit diagnoses the transmission fluid temperature sensor and wiring for an open circuit or short to voltage failure by comparing a voltage measurement to controller specific voltage thresholds, converted to a resistance value.	circuit resistance update fail time 1 seconds update rate	$\geq 49,411,396.0 \ \Omega$	<div>diagnostic monitor enable</div> <div>battery voltage</div> <div>run crank voltage run crank voltage in range time</div>	<div>= 1 Boolean</div> <div><math>\geq 9.00</math> volts</div> <div><math>\geq 9.00</math> volts</div>	<div>fail time <math>\geq 5.00</math> seconds out of fail time <math>\geq 6.00</math> seconds 1 seconds update rate</div> <div>battery voltage in range time <math>\geq</math> 0.100 seconds</div> <div>run crank voltage in range time <math>\geq</math> 0.100 seconds</div>	Type B, 2 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Input Speed Sensor Performance	P0716	Detects unrealistic drop in raw transmission input speed signal RPM. Drop events are counted up to fail threshold. A drop event is defined by a sudden delta change in RPM from one value to a lower value. The raw transmission input speed must achieve a value high enough to record an unrealistic drop sample to sample. Once the drop threshold is met, fail time is accumulated indicating the raw transmission input speed has not recovered above a threshold, allowing the fail event count to increment. Multiple fail event counts must occur, but if the signal remains low, no further deltas occur, the "Input Speed Sensor Circuit Low Voltage" DTC will set before P0716, as P0716 is designed to set based on an intermittent raw transmission input speed signal RPM.	<p>delta raw transmission input speed</p> <p>delta raw transmission input speed = raw transmission input speed - last valid raw transmission input speed, 25 millisecond update rate</p>	≥ 2,000.0 RPM	<p>service mode \$04 active diagnostic monitor enable</p> <p>P0717 test fail this key on P07BF test fail this key on P07C0 test fail this key on High Side Driver 1 and 2 Run Crank Voltage Service Fast Learn Run Crank Active</p> <p>last valid raw transmission input speed OR valid raw transmission input speed (before drop event) *****</p> <p>Stability Criteria last valid raw transmission input speed updates very 25 milliseconds when stability time complete as long as (delta delta raw transmission input speed AND raw transmission input</p>	<p>= FALSE = 1 Boolean (0 is disable, 1 is enable) = FALSE = FALSE = FALSE = TRUE ≥ 9.0 Volts = FALSE = TRUE</p> <p>≥ 160.0 RPM</p> <p>≥ 160.0 RPM</p> <p>*****</p> <p>≤ 320.0 RPM</p> <p>&gt; 160.0 RPM</p>	<p>fail time ≥ 1.500 seconds updated fail event count, fail event count ≥ 5 counts, 25 millisecond update rate</p> <p>raw transmission input speed time ≥ 2.000 seconds</p> <p>stability time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					speed)  raw transmission output speed accelerator pedal position engine torque engine torque  hydraulic system pressure available  DTCs not fault active	≥ 254.0 RPM  ≥ 5.0 % ≤ 8,191.9 Nm ≥ 30.0 Nm  = TRUE  AcceleratorPedalFailure EngineTorqueEstInaccu te		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

[illegible]

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>AND (P0717 fault active OR P0717 test fail this key on) *****</p> <p>TISS/TOSS fault (single power supply to TISS and TOSS) = TRUE occurs when: (P0722 fail time high gear exceeds fail threshold OR P0722 fail time low gear exceeds fail threshold) AND TISS/TOSS has single power supply calibration TISS/TOSS single power supply test enabled Raw Input Speed</p> <p>DTCs not fault active</p>	<p>≥ 263.0 RPM *****</p> <p>= FALSE</p> <p>= FALSE</p> <p>*****</p> <p>≥ 5.00 s</p> <p>≥ 3.50 s</p> <p>= 0 Boolean</p> <p>= 1 Boolean &lt; 475.00 rpm</p> <p>EngineTorqueEstInaccu te</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Output Speed Sensor Performance	P0721	The diagnostic monitor determines if the direction TOSS value is coherent based on the on period time of the directional sensor and TOSS raw. When the on period time indicates a transitional state, the direction must also be transitional as measured by very slow TOSS raw RPM. When the on period time indicates a non-transitional state, forward or reverse, the direction must also be transition, not forward and not reverse.	TOSS raw direction when TOSS transitional period = FALSE AND (TOSS raw direction when TOSS transitional period = FALSE OR TOSS raw when TOSS transitional period = TRUE)  update fail and sample time 6.25 ms update rate	≠ FORWARD  ≠ REVERSE  ≥ 225.0 RPM	service mode \$04 active diagnostic monitor enable TOSS count sample period (P0721 fault active OR P0721 test fail this key on) senor type is directional senor type calibration  ***** TOSS transitional period detected = FALSE when: (on period OR on period when direction unknown  OR on period AND on period when direction is reverse  OR on period AND on period when direction is forward)  TOSS transitional period detected = TRUE when: on period AND	= FALSE = 1 Boolean ≠ 0 counts  = FALSE  = FALSE  = CeTOSR_e_Directional  ***** ≥ 0.4434 seconds ≤ 0.2773 seconds  < 0.2363 seconds > 0.1240 seconds  < 0.0811 seconds > 0.0088 seconds  < 0.4434 seconds	fail time ≥ 3.500 seconds out of sample time ≥ 5.000 seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					on period when direction unknown	> 0.2773 seconds		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Output Speed Sensor Circuit Low Voltage	P0722	Detects no activity in raw transmission output speed signal RPM due to open circuit electrical failure mode or sensor internal faults, or, controller internal failure modes. The raw transmission output speed signal RPM is rationalized against vehicle conditions in which the powertrain is producing torque, but raw transmission output speed signal RPM remains low. After a sudden drop in raw transmission output speed signal RPM, a race condition can occur between P0722 and "Output Speed Sensor Circuit Intermittent" depending on the true nature of the failure.	raw transmission output speed, update fail time 6.25 millisecond update rate  use high gear fail time threshold when: (attained gear  attained gear  attained gear)  ELSE use low gear fail time threshold	≤ 30.0 RPM   ≥ CeCGSR_e_CR_First ≤ CeCGSR_e_CR_Tenth > CeCGSR_e_CR_Fourth	service mode \$04 active diagnostic monitor enable  ***** when neutral range or shift occurs: (Intrusive Shift Active OR (garage shift AND Locked to Freewheel AND Freewheel to Locked) OR PRNDL OR PRNDL OR range inhibit state) AND (engine torque accelerator pedal position)  when not neutral range occurs: attained gear attained gear (attained gear  engine torque accelerator pedal (TCC slip	= FALSE = 1 Boolean  ***** = TRUE ≠ COMPLETE = FALSE = FALSE = PARK = NEUTRAL ≠ no inhibit active ≥ 8,192.0 Nm ≥ 100.0 %  ≥ CeCGSR_e_CR_First ≤ CeCGSR_e_CR_Tenth > CeCGSR_e_CR_Fourth ≥ 50.0 Nm ≥ 5.0 % > 100.00 rpm	fail time ≥ 5.00 seconds high gear OR fail time ≥ 3.50 seconds low gear	Type A, 1 Trips



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OR TCC mode))  when not neutral range occurs: (attained gear  engine torque accelerator pedal (TCC slip OR TCC mode))  OR Independent of neutral range: Attained Gear Commanded Gear Internal Speed Sensor Held in First FALSE TIS minus Input speed calculated from TNS TNS *****  (TISS AND TISS) OR (Engine Speed AND Engine Speed) *****  P0716 test fail this key on P0717 test fail this key on P07BF test fail this key on P07C0 test fail this key on  PTO check: PTO enable calibration is FALSE	≠ Off Mode  ≤ CeCGSR_e_CR_Fourth ≥ 80.0 Nm ≥ 8.0 % > 100.00 rpm ≠ Off Mode  = First = First <b>P0722 Internal Speed</b> = <b>Sensor Held</b>  ≤ <b>P0722 TIS TNS Diff</b> ≥ 172.00 RPM ***** ≤ 8,191.9 RPM ≥ 475.0 RPM ≤ 8,191.9 RPM ≥ 5,800.0 RPM ***** = FALSE = FALSE = FALSE = FALSE  = 1 Boolean		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

[illegible]

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Output Speed Sensor Circuit Intermittent	P0723	Detects unrealistic drop in raw transmission output speed signal RPM. Drop events are counted up to fail threshold. A drop event is defined by a sudden delta change in RPM from one value to a lower value. The raw transmission output speed must achieve a value high enough to record an unrealistic drop sample to sample. Once the drop threshold is met, fail time is accumulated indicating the raw transmission output speed has not recovered above a threshold, allowing the fail event count to increment. Multiple fail event counts must occur, but if the signal remains low, no further deltas occur, the "Output Speed Sensor Circuit Low Voltage" DTC will set before P0723, as P0723 is designed to set based on an intermittent raw transmission output speed signal RPM.	4WD low fail threshold: delta raw transmission output speed OR NOT 4WD low fail threshold, update fail time, delta raw transmission output speed = raw transmission output speed previous loop - raw transmission output speed, 25 millisecond update rate	≥ 700.0 RPM  ≥ 700.0 RPM	service mode \$04 active diagnostic monitor enable          transmission engaged state          4WD low state    PTO check: PTO disable calibration is FALSE OR	= FALSE = 1 Boolean          ≠ not engaged          = 4WD low state previous loop, 25 millisecond update rate   ≠ 1 Boolean	fail time ≥ 1.500 seconds updated fail event count, fail event count ≥ 5 counts, 25 millisecond update rate          transmission engaged state time ≥ <b>P0723 transmission engaged state time threshold</b>   4WD low change time ≥ 3.0 seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(PTO disable calibration is TRUE AND PTO active)  run crank voltage  service fast learn active run crank voltage P077C test fail this key on P077D test fail this key on ***** when PRNDL is moved to NEUTRAL allow transmission engaged state time before enabling fail evaluation, or, if raw raw transmission output speed is active in NEUTRAL enable fail evaluation: PRNDL OR  PRNDL OR  PRNDL OR  raw transmission output speed OR last valid raw transmission output speed ***** determine if raw transmission input speed is stable:	= 1 Boolean  = FALSE  ≥ 5.00 volts  = FALSE ≥ 9.00 volts = FALSE = FALSE *****  = CeTRGR_e_PRNDL_Neu tral = CeTRGR_e_PRNDL_Tra nsitional1 N-D transitional = CeTRGR_e_PRNDL_Tra nsitional4 R-N transitional ≥ 250.0 RPM  ≥ 250.0 RPM ***** *****	run crank voltage time ≥ 25 milliseconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(raw transmission input speed - raw transmission input speed previous, 25 millisecond update AND raw transmission input speed) OR (TISS/TOSS has single power supply calibration AND raw transmission input speed)	≤ 4,095.9 RPM  ≥ 160.0 RPM  = 0 Boolean  = 0.0 RPM	raw transmission input speed stability time ≥ 2.00 seconds	
					***** select delta RPM fail threshold: (4WD low state AND 4WD low valid) select P0723 4WD TOSS delta fail threshold otherwise use P0723 TOSS delta fail threshold *****	*****  = TRUE = TRUE  *****	no time required	
					last valid raw transmission output speed OR valid raw transmission output speed (before drop event)	> 89.0 RPM  > 89.0 RPM	raw transmission output speed time ≥ 2.00 seconds	
					last valid raw transmission output speed updates every 25 milliseconds when stability time complete as long as (delta delta raw transmission output speed AND raw transmission output speed)	≤ 140.0 RPM  ≥ 89.0 RPM	stability time ≥ 0.100 seconds	
					hydraulic pressure avail	= TRUE		

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					***** PRNDL AND PRNDL AND ***** ((PRNDL OR PRNDL OR PRNDL) AND (Output Speed raw transmission output speed - raw transmission output speed previous, 25 millisecond update)) OR ***** (PRNDL AND PRNDL AND PRNDL) DTCs not fault active	***** ≠ ParkCeTRGR_e_PRNDL _Park ≠ CeTRGR_e_PRNDL_Tra nsitional2 ***** = CeTRGR_e_PRNDL_Neu tral = CeTRGR_e_PRNDL_Tra nsitional1 = CeTRGR_e_PRNDL_Tra nsitional4 ≥ 50.00 RPM < 20.00 AND > -140.00 ***** ≠ CeTRGR_e_PRNDL_Neu tral ≠ CeTRGR_e_PRNDL_Tra nsitional1 ≠ CeTRGR_e_PRNDL_Tra nsitional4 AcceleratorPedalFailure EngineTorqueEstInaccura te	Delta met time > 2.00	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid A Stuck Off (GF9)	P0746	Each pressure control solenoid stuck off diagnostic monitor detects a clutch pressure control solenoid failed hydraulically off, while the solenoid is electrically functional. In the failure mode the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM. The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line	C1 clutch slip speed, update fail time 6.25 millisecond update	≥ 200.0 RPM	<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active</p> <p>service solenoid cleaning</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean</p>	<p>fail time ≥ 3.00 seconds, update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch pressure control solenoid is failed hydraulically off, the clutch does not maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable. The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed in the opposite sense, clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional, which must take priority over any clutch pressure control solenoid stuck off diagnostic monitor. All clutch pressure control			<p>procedure active</p> <p>hydraulic pressure available</p> <p>*****</p> <p>enable C1 clutch slip speed fail compare when:</p> <p>((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below)</p> <p>unintended deceleration fault pending OR unintended deceleration fault pending enable cal is FALSE (startle mitigation)</p> <p>clutch steady state adaptive active</p> <p>(transmission output shaft speed OR (accelerator pedal position OR engine speed)</p> <p>C1 clutch slip speed valid</p> <p>C1 clutch pressured map</p>	<p>= FALSE Boolean</p> <p>= TRUE</p> <p>*****</p> <p>= FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 (0 to enable, 1 to disable)</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 %</p> <p>≥ 1,500.0 RPM</p> <p>= TRUE (all speed sensors are functional for lever node clutch slip speed calculation)</p> <p>= mapped to line</p>	≥ 1.000 seconds	



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck off test is disabled. This diagnostic monitor is relative to GF9 C1 CB123456 clutch pressure control solenoid.			<p>(enable forward gear cal AND driver direction request AND Attained Gear) OR (enable reverse gear cal AND driver direction request AND Attained Gear)</p> <p>P2821 (clutch select valve stuck on) test active</p> <p>range shift state</p> <p>*****</p> <p>DTCs not fault pending</p> <p>DTCs not fault active</p>	<p>pressure, C1 clutch pressure has reached fully applied state</p> <p>= 1 (1 to enable, 0 to disable) = FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (1 to enable, 0 to disable) = REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= range shift complete</p> <p>*****</p> <p>P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6</p> <p>P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>DTCs not test fail this key on</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797 P2715 P2724 P2733 P2821</p>	<p>P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid A Stuck On	P0747	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	shift type is power down shift: C1 clutch slip speed OR shift type is garage shift: C1 clutch slip speed ELSE shift is another type: C1 clutch slip speed  update fail time 6.25 milliscond update	< 50.0 RPM  < 100.00 RPM  < 50.0 RPM			Base fail time:  shift type is power down shift: fail time ≥ 0.80 seconds  shift type is garage shift: fail time ≥ 0.25  shift type is another type: fail time ≥ 0.150 seconds  Add fail time offset according to shift type:  open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b>  open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b>  garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b>  closed throttle downshift:	Type A, 1 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C1 CB123456, GR10 C1 CB123456R, or 8 Speed C1 CB1278R clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C1 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C1 off going clutch command pressure )	= TRUE Boolean  = TRUE Boolean  = FALSE Boolean  = FALSE Boolean  = TRUE  *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350.0 kPa	exhaust delay by shift type:	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck on torque enable cal)	$\geq 8,191.8 \text{ Nm}$ $= 0$ (0 is enable, 1 is enable)	closed throttle upshift: <b>C1 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C1 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C1 exhaust delay garage shift</b>  closed throttle downshift: <b>C1 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C1 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C1 exhaust delay open throttle power down shift</b>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>OR</p> <p>( primary oncoming clutch active</p> <p>primary on coming control state</p> <p>primary on coming commanded pressure)</p> <p>C1 clutch slip speed valid, all speed sensors are functional for lever node clutch slip speed calculation</p>	<p>= TRUE</p> <p>≠ clutch fill phase</p> <p>≥ pressure clip threshold according to shift type:</p> <p>closed throttle upshift: <b>Clutch Clip Press CU Shifts</b></p> <p>open throttle upshift: <b>Clutch Clip Press PU Shifts</b></p> <p>garage shifts: <b>Clutch Clip Press GS Shifts</b></p> <p>closed throttle downshift: <b>Clutch Clip Press CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>open throttle downshift: <b>Clutch Clip Press PD Shifts</b></p> <p>= TRUE</p>	absolute value of ( -0.60 ) seconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>conditions needed to trigger test:</p> <p>(current shift type AND shift type enable cal for current shift type)</p> <p>OR</p> <p>(Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear)</p> <p>OR</p> <p>(stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))</p> <p>clutch stuck off intrusive shift active</p> <p>startle mitigation active (see note on startle mitigation below)</p> <p>(new clutch controller has been initalized OR</p>	<p>*****</p> <p>≠ Garage shift</p> <p><b>Clutch Stuck On Shift = Type Enable</b> (0 table value will disable, 1 will enable)</p> <p>= FALSE</p> <p>= 0 (0 will enable, 1 will enable)</p> <p>= NEUTRAL OR commanded gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= TRUE</p>		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					transitioning to a different clutch controller)  current clutch solenoid test state  ***** DTCs not fault pending    DTCs not fault active    DTCs not test fail this key on	= TRUE  transitions to TestState or TUT_HOLD (see note below about state transitions)  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA  P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions:            Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing.            AND            That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold.            Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the automatic transmission shift, until:</p>	P172A P172B *****		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute.</p> <p>OR</p> <p>The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended vehicle deceleration occurred. Once a safe</p>			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid B Stuck Off (GF9)	P0776	Each pressure control solenoid stuck off diagnostic monitor detects a clutch pressure control solenoid failed hydraulically off, while the solenoid is electrically functional. In the failure mode the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM. The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line	C2 clutch slip speed, update fail time 6.25 millisecond update	≥ 200.0 RPM	<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active</p> <p>service solenoid cleaning</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean</p>	<p>fail time ≥ 3.00 seconds, update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch pressure control solenoid is failed hydraulically off, the clutch does not maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable. The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed in the opposite sense, clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional, which must take priority over any clutch pressure control solenoid stuck off diagnostic monitor. All clutch pressure control			<p>procedure active</p> <p>hydraulic pressure available</p> <p>*****</p> <p>enable C2 clutch slip speed fail compare when:</p> <p>((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below)</p> <p>unintended deceleration fault pending OR unintended deceleration fault pending enable cal is FALSE (startle mitigation)</p> <p>clutch steady state adaptive active</p> <p>(transmission output shaft speed OR (accelerator pedal position OR engine speed)</p> <p>C2 clutch slip speed valid</p> <p>C2 clutch pressured map</p>	<p>= FALSE Boolean</p> <p>= TRUE</p> <p>*****</p> <p>= FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 (0 to enable, 1 to disable)</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 %</p> <p>≥ 1,500.0 RPM</p> <p>= TRUE (all speed sensors are functional for lever node clutch slip speed calculation)</p> <p>= mapped to line</p>	≥ 1.000 seconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck off test is disabled. This diagnostic monitor is relative to GF9 C2 CB29 clutch pressure control solenoid.			<p>(enable forward gear cal AND driver direction request AND Attained Gear) OR (enable reverse gear cal AND driver direction request AND Attained Gear)</p> <p>P2821 (clutch select valve stuck on) test active</p> <p>range shift state</p> <p>*****</p> <p>DTCs not fault pending</p> <p>DTCs not fault active</p>	<p>pressure, C2 clutch pressure has reached fully applied state</p> <p>= 1 (1 to enable, 0 to disable) = FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (1 to enable, 0 to disable) = REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= range shift complete</p> <p>*****</p> <p>P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6</p> <p>P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>DTCs not test fail this key on</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797 P2715 P2724 P2733 P2821</p>	<p>P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p>		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid B Stuck On	P0777	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	shift type is power down shift: C2 clutch slip speed OR shift type is garage shift: C2 clutch slip speed ELSE shift is another type: C2 clutch slip speed  update fail time 6.25 millisecond update	< 50.00 RPM  < 100.00 RPM  < 50.00 RPM			Base fail time:  shift type is power down shift: fail time ≥ 0.80 seconds  shift type is garage shift: fail time ≥ 0.25  shift type is another type: fail time ≥ 0.15 seconds  Add fail time offset according to shift type:  open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b>  open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b>  garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b>  closed throttle downshift:	Type A, 1 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C2 CB29, GR10 C2 CB128910R, or 8 Speed C2 CB12345R clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C2 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C2 off going clutch command pressure )	= TRUE Boolean  = TRUE Boolean  = FALSE Boolean  = FALSE Boolean  = TRUE  *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350 kPa	exhaust delay by shift type:	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck	$\geq 8,192 \text{ Nm}$ = 0 (0 is enable, 1 is	closed throttle upshift: <b>C2 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C2 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C2 exhaust delay garage shift</b>  closed throttle downshift: <b>C2 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C2 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C2 exhaust delay open throttle power down shift</b>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

[illegible]

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					calculation  ***** conditions needed to trigger test:  (current shift type AND shift type enable cal for current shift type)  OR  (Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear) OR (stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))  clutch stuck off intrusive shift active  startle mitigation active (see note on startle mitigation below)  (new clutch controller has	*****   ≠ Garage shift  <b>Clutch Stuck On Shift</b> <b>= Type Enable</b> (0 table value will disable, 1 will enable)  = FALSE  = 0 (0 will enable, 1 will enable)  = NEUTRAL OR commanded gear  = 0 (0 to disable, 1 to enable) = FORWARD  = a FORWARD gear  = 0 (0 to disable, 1 to enable) = REVERSE  = REVERSE  = FALSE  = FALSE		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>been initalized OR transitioning to a different clutch controller)</p> <p>current clutch solenoid test state</p> <p>*****</p> <p>DTCs not fault pending</p> <p>DTCs not fault active</p> <p>DTCs not test fail this key on</p>	<p>= TRUE</p> <p>= TRUE</p> <p>transitions to TestState or TUT_HOLD (see note below about state transitions)</p> <p>*****</p> <p>P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6</p> <p>P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p> <p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions: Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing. AND That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold. Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the</p>	<p>P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p> <p>*****</p>		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>automatic transmission shift, until: An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute.</p> <p>OR</p> <p>The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended</p>			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					vehicle deceleration occurred. Once a safe vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Output Speed Sensor Circuit Low	P077C	Controller specific analog circuit diagnoses the transmission output speed sensor and wiring for a short to ground fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission output speed sensor raw voltage, update fail time, 12.5 millisecond update rate	$\leq 0.2500$ volts ( $\leq 0.5 \Omega$ impedance between signal and controller ground)	<p>service mode \$04 active diagnostic monitor enable P077D fault active</p> <p>service fast learn run crank voltage battery voltage</p> <p>P077C fault active P077C test fail this key on</p>	<p>= FALSE = 1 Boolean = FALSE</p> <p>= FALSE <math>\geq 10.00</math> volts <math>\geq 10.00</math> volts</p> <p>= FALSE = FALSE</p>	<p>fail time <math>\geq 0.050</math> seconds, update fail count, fail count <math>\geq 16</math> counts 6.25 millisecond update rate</p> <p>service fast learn, run crank and battery voltage time <math>\geq 5.00</math> seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Output Speed Sensor Circuit High	P077D	Controller specific analog circuit diagnoses the transmission output speed sensor and wiring for a short to voltage fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission output speed sensor raw voltage, update fail time, 12.5 millisecond update rate	$\geq 4.7500$ volts ( $\leq 0.5 \Omega$ impedance between signal and controller power)	service mode \$04 active diagnostic monitor enable P077C fault active  service fast learn run crank voltage battery voltage  P077D fault active P077D test fail this key on	= FALSE = 1 Boolean = FALSE  = FALSE $\geq 10.00$ volts $\geq 10.00$ volts  = FALSE = FALSE	fail time $\geq 0.050$ seconds, update fail count, fail count $\geq 16$ counts 6.25 millisecond update rate  service fast learn, run crank and battery voltage time $\geq 5.000$ seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid C Stuck Off (GF9)	P0796	Each pressure control solenoid stuck off diagnostic monitor detects a clutch pressure control solenoid failed hydraulically off, while the solenoid is electrically functional. In the failure mode the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM. The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line	C3 clutch slip speed, update fail time 6.25 millisecond update	≥ 200.0 RPM	<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active</p> <p>service solenoid cleaning</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean</p>	<p>fail time ≥ 3.00 seconds, update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch pressure control solenoid is failed hydraulically off, the clutch does not maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable. The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed in the opposite sense, clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional, which must take priority over any clutch pressure control solenoid stuck off diagnostic monitor. All clutch pressure control			<p>procedure active</p> <p>hydraulic pressure available</p> <p>*****</p> <p>enable C3 clutch slip speed fail compare when:</p> <p>((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below)</p> <p>unintended deceleration fault pending OR unintended deceleration fault pending enable cal is FALSE (startle mitigation)</p> <p>clutch steady state adaptive active</p> <p>(transmission output shaft speed OR (accelerator pedal position OR engine speed)</p> <p>C3 clutch slip speed valid</p>	<p>= FALSE Boolean</p> <p>= TRUE</p> <p>*****</p> <p>= FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 (0 to enable, 1 to disable)</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 %</p> <p>≥ 1,500.0 RPM</p> <p>= TRUE (all speed sensors are functional for lever node clutch slip speed calculation)</p>	≥ 1.000 seconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck off test is disabled. This diagnostic monitor is relative to C3 GF9 CB38 clutch pressure control solenoid.			C3 clutch pressured map  (enable forward gear cal AND driver direction request AND Attained Gear) OR (enable reverse gear cal AND driver direction request AND Attained Gear)  P2821 (clutch select valve stuck on) test active  range shift state  ***** DTCs not fault pending         DTCs not fault active	= mapped to line pressure, C3 clutch pressure has reached fully applied state  = 1 (1 to enable, 0 to disable) = FORWARD = a FORWARD gear = 0 (1 to enable, 0 to disable) = REVERSE = REVERSE  = FALSE  = range shift complete  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>DTCs not test fail this key on</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797 P2715 P2724 P2733 P2821</p>	<p>P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p>		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid C Stuck On	P0797	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	shift type is power down shift: C3 clutch slip speed OR shift type is garage shift: C3 clutch slip speed ELSE shift is another type: C3 clutch slip speed  update fail time 6.25 milliscond update	< 50.00 RPM  < 100.00 RPM  < 50.00 RPM			Base fail time:  shift type is power down shift: fail time ≥ 0.80 seconds  shift type is garage shift: fail time ≥ 0.25  shift type is another type: fail time ≥ 0.15 seconds  Add fail time offset according to shift type:  open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b>  open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b>  garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b>  closed throttle downshift:	Type A, 1 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C3 CB38, GR10 C3 C23457910, or 8 Speed C3 C13567 clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C3 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C3 off going clutch command pressure )	= TRUE Boolean  = TRUE Boolean  = FALSE Boolean  = FALSE Boolean  = TRUE  *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350 kPa	exhaust delay by shift type:	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck on torque enable cal)	$\geq 8,192 \text{ Nm}$  $= 0$ (0 is enable, 1 is enable)	closed throttle upshift: <b>C3 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C3 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C3 exhaust delay garage shift</b>  closed throttle downshift: <b>C3 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C3 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C3 exhaust delay open throttle power down shift</b>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OR  ( primary oncoming clutch active  primary on coming control state  primary on coming commanded pressure)	= TRUE  ≠ clutch fill phase  ≥ pressure clip threshold according to shift type:  closed throttle upshift: <b>Clutch Clip Press CU Shifts</b>  open throttle upshift: <b>Clutch Clip Press PU Shifts</b>  garage shifts: <b>Clutch Clip Press GS Shifts</b>  closed throttle downshift: <b>Clutch Clip Press CD Shifts</b>  negative torque upshift: <b>Clutch Clip Press NU Shifts</b>  open throttle downshift: <b>Clutch Clip Press PD Shifts</b>	absolute value of ( -0.60 ) seconds	
					C3 clutch slip speed valid, all speed sensors are functional for lever node cluth slip speed calculation	= TRUE		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>conditions needed to trigger test:</p> <p>(current shift type AND shift type enable cal for current shift type)</p> <p>OR</p> <p>(Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear)</p> <p>OR</p> <p>(stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))</p> <p>clutch stuck off intrusive shift active</p> <p>startle mitigation active (see note on startle mitigation below)</p> <p>(new clutch controller has been initalized OR</p>	<p>*****</p> <p>≠ Garage shift</p> <p><b>Clutch Stuck On Shift = Type Enable</b> (0 table value will disable, 1 will enable)</p> <p>= FALSE</p> <p>= 0 (0 will enable, 1 will enable)</p> <p>= NEUTRAL OR commanded gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= TRUE</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					transitioning to a different clutch controller)  current clutch solenoid test state  ***** DTCs not fault pending    DTCs not fault active    DTCs not test fail this key on	= TRUE  transitions to TestState or TUT_HOLD (see note below about state transitions)  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA  P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions:            Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing.            AND            That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold.            Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the automatic transmission shift, until:</p>	P172A P172B *****		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute.</p> <p>OR</p> <p>The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended vehicle deceleration occurred. Once a safe</p>			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Input/Turbine Speed Sensor A Circuit Low	P07BF	Controller specific analog circuit diagnoses the transmission input/turbine speed sensor and wiring for a short to ground fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission input/turbine speed sensor raw voltage, update fail time, 12.5 millisecond update rate	$\leq 0.2500$ volts ( $\leq 0.5 \Omega$ impedance between signal and controller ground)	service mode \$04 active diagnostic monitor enable P07C0 fault active  service fast learn run crank voltage battery voltage  P07BF fault active P07BF test fail this key on	= FALSE = 1 Boolean = FALSE  = FALSE $\geq 10.00$ volts $\geq 10.00$ volts  = FALSE = FALSE	fail time $\geq 0.050$ seconds, update fail count, fail count $\geq 16$ counts 6.25 millisecond update rate  service fast learn, run crank and battery voltage time $\geq 5.000$ seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Input/Turbine Speed Sensor A Circuit High	P07C0	Controller specific analog circuit diagnoses the transmission input/turbine speed sensor and wiring for a short to voltage fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission input/turbine speed sensor raw voltage, update fail time, 12.5 millisecond update rate	$\geq 4.7500$ volts ( $\leq 0.5 \Omega$ impedance between signal and controller power)	service mode \$04 active diagnostic monitor enable P07BF fault active  service fast learn run crank voltage battery voltage  P07C0 fault active P07C0 test fail this key on	= FALSE = 1 Boolean = FALSE  = FALSE $\geq 10.00$ volts $\geq 10.00$ volts  = FALSE = FALSE	fail time $\geq 0.050$ seconds, update fail count, fail count $\geq 16$ counts 6.25 millisecond update rate  service fast learn, run crank and battery voltage time $\geq 5.000$ seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Upshift Switch Circuit	P0815	Diagnoses the state of the upshift switch circuit, stuck in the state "tap up" (upshift) active.  Emissions neutral default, disables tap-up tap-down or manual-up manual-down.	switch state update fail time 1 100 millisecond update rate	= tap up (upshift) state active	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active P0826 fault active P0826 test fail this key on P0826 fault pending (P0815 fault active OR P0815 fault active test fail this key on) PRNDL range change time PRNDL in range: D1 OR D2 OR D3 OR D4 OR D5 OR D6 OR D7 OR D8 OR D9 OR D10 OR NEUTRAL OR PARK OR REVERSE  DTCs not fault pending	= FALSE = 1 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE  ≥ 1.00 seconds  = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean  Transmission Shift Lever Position Validity	fail time 1 ≥ 1.00 seconds	Emissio ns Neutral Diagnost ics – Type C
			switch state update fail time 2 100 millisecond update rate	= tap up (upshift) state active	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active	= FALSE = 1 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE	fail time 2 ≥ 120.00 seconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P0826 fault active P0826 test fail this key on P0826 fault pending (P0815 fault active OR P0815 fault active test fail this key on) PRNDL range change time PRNDL in range: D1 OR D2 OR D3 OR D4 OR D5 OR D6 OR D7 OR D8 OR D9 OR D10 OR NEUTRAL OR PARK OR REVERSE  DTCs not fault pending	= FALSE = FALSE = FALSE = FALSE = FALSE  ≥ 1.00 seconds  = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean  Transmission Shift Lever Position Validity		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Downshift Switch Circuit	P0816	Diagnoses the state of the downshift switch circuit, stuck in the state "tap down" (downshift) active.  Emissions neutral default, disables tap-up tap-down or manual-up manual-down.	switch state update fail time 1 100 millisecond update rate	= tap down (downshift) state active	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active P0826 fault active P0826 test fail this key on P0826 fault pending (P0816 fault active OR P0816 fault active test fail this key on) PRNDL range change time PRNDL in range: D1 OR D2 OR D3 OR D4 OR D5 OR D6 OR D7 OR D8 OR D9 OR D10 OR NEUTRAL OR PARK OR REVERSE  DTCs not fault pending	= FALSE = 1 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE  ≥ 1.00 seconds  = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean  Transmission Shift Lever Position Validity	fail time 1 ≥ 1.00 seconds	Emissions Neutral Diagnostics – Type C
			switch state update fail time 2 100 millisecond update rate	= tap down (downshift) state active	service mode \$04 active diagnostic monitor enable  run crank voltage run crank voltage time  run crank voltage P1761 fault active	= FALSE = 1 Boolean  ≥ 5.00 volts ≥ 25 milliseconds  ≥ 9.00 volts = FALSE	fail time 2 ≥ 120.00 seconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P0826 fault active P0826 test fail this key on P0826 fault pending (P0816 fault active OR P0816 fault active test fail this key on) PRNDL range change time PRNDL in range: D1 OR D2 OR D3 OR D4 OR D5 OR D6 OR D7 OR D8 OR D9 OR D10 OR NEUTRAL OR PARK OR REVERSE  DTCs not fault pending	= FALSE = FALSE = FALSE = FALSE = FALSE  ≥ 1.00 seconds  = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean  Transmission Shift Lever Position Validity		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Up and Down Shift Switch Circuit	P0826	Diagnoses the state of the upshift/downshift switch circuit at an illegal voltage, voltage out of range.  Emissions neutral default, disables tap-up tap-down or manual-up manual-down.	switch state update fail time 100 millisecond update rate	= illegal (voltage out of range)	service mode \$04 active diagnostic monitor enable  run crank voltage  run crank voltage P1761 fault active (P0826 fault active OR P0826 fault active test fail this key on)	= FALSE = 1 Boolean  ≥ 5.00 volts  ≥ 9.00 volts = FALSE = FALSE = FALSE	fail time ≥ 60.00 seconds  run crank voltage time ≥ 25 milliseconds	Emissions Neutral Diagnostics – Type C

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid A Control Circuit Open	P0960	Controller specific circuit diagnoses 9 speed CB123456, 10 speed CB123456R, or 8 speed CB1278R clutch or CVT secondary pulley, solenoid for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates an open circuit</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit</p> <p>Increment fail time</p>	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00 \text{ volts}</math> and <math>\leq 32.00 \text{ volts}</math></p> <p><math>\geq 5.00 \text{ volts}</math></p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid A Control Circuit Low	P0962	Controller specific circuit diagnoses 9 speed CB123456, 10 speed CB123456R, or 8 speed CB1278R clutch or CVT secondary pulley, solenoid for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a ground short</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller ground	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid A Control Circuit High	P0963	Controller specific circuit diagnoses 9 speed, 10 speed CB123456R, 8 speed CB1278R clutch or CVT secondary pulley, solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a short to voltage  Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts = TRUE = 1 (1 is enable, 0 is disable) = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid B Control Circuit Open	P0964	Controller specific circuit diagnoses 9 speed CB29, 10 speed CB128910R, 8 speed CB12345R clutch or CVT primary pulley, solenoid for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates an open circuit  Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit  Increment fail time	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage  OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00 \text{ volts and } \leq 32.00 \text{ volts}$  $\geq 5.00 \text{ volts}$  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00 \text{ seconds}$  $\geq 25 \text{ milliseconds}$  $\geq 12.5 \text{ milliseconds}$	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid B Control Circuit Low	P0966	Controller specific circuit diagnoses 9 speed CB29, 10 speed CB128910R, 8 speed CB12345R clutch or CVT primary pulley, solenoid for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON    = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON    = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid B Control Circuit High	P0967	Controller specific circuit diagnoses 9 speed CB29, 10 speed CB128910R, 8 speed CB12345R clutch or CVT primary pulley, solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid C Control Circuit Open	P0968	Controller specific circuit diagnoses 9 speed CB38, 10 speed C23457910, or 8 speed C13567, clutch or CVT line pressure, solenoid for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates an open circuit  Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit  Increment fail time	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage  OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00 \text{ volts and } \leq 32.00 \text{ volts}$  $\geq 5.00 \text{ volts}$  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.000 \text{ seconds}$  25 milliseconds  12.5 milliseconds	Type A, 1 Trips



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid C Control Circuit Low	P0970	Controller specific circuit diagnoses 9 speed CB38, 10 speed C23457910, or 8 speed C13567 clutch, or CVT line pressure, solenoid for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid C Control Circuit High	P0971	Controller specific circuit diagnoses 9 speed CB38, 10 speed C23457910, or 8 speed C13567, clutch or CVT line pressure, solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a short to voltage  Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON    = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON    = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 2	P16E9	This DTC will be stored if the internal serial peripheral interface bus #2 has failed.	Serial Peripheral Bus #2 has failed	>= 8.00		Diagnostic System Enabled  AND  (Battery Voltage In Range)  OR  Run/Crank Voltage In Range)  (GetDRER_b_DiagSystemDsbl() == CbFALSE)  &&  ((GetLVTR_b_RunCrankIgnInRange() == CbTRUE)      (GetLVTR_b_BatteryInRange() == CbTRUE) )	Diagnostic runs periodically at either 5 milliseconds or 6.25 milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 1	P16F0	This DTC will be stored if the internal serial peripheral interface bus #1 has failed.	Serial Peripheral Bus #1 has failed	>= 8.00		Diagnostic System Enabled  AND  (Battery Voltage In Range)  OR  (Run/Crank Voltage In Range)  (GetDRER_b_DiagSystemDsbl() == CbFALSE)  &&  ((GetLVTR_b_RunCrankIgnInRange() == CbTRUE)      (GetLVTR_b_BatteryInRange() == CbTRUE) )	Diagnostic runs periodically at either 5 milliseconds or 6.25 milliseconds	Type A, 1 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Redundant Memory Performance	P16F3	<p>The diagnostic monitor is a rationalization of command values: command clutch pressures and command gear. The monitor is broken up into two fault detection routines, command pressure (tie up) fault detection and command gear/shift fault detection.</p> <p>The command pressure (tie up) fault detection is designed to verify the number of clutches applied in a given gear state is limited, in order to prevent a transmission internal mechanical tie-up condition. A condition which could lead to a vehicle deceleration above the design safety metric. If commanded clutch pressures are above a threshold which would allow multiple clutches to carry torque, the clutch is considered applied, otherwise the clutch is considered released. If there are more clutches applied, via the commanded clutch pressures, in a given gear state than is rational, one or more of</p>	<p>command pressure (tie up) fault detection</p> <p>minimum # of clutches ON by attained gear and by comanded gear, take lower of the 2 values, where attained gear is the current operating gear and command gear is the targetted value to transtion toward</p> <p>see <b>9 speed transmission clutch definition and gear state to clutch map</b> and <b>10 speed transmission clutch definition and gear state to clutch map</b> attached supporting tables for clutch 1 through clutch 7 definition and gear state to clutch map</p>	<p>≤ <b>NumClchTieUp</b> See Attached Supporting Tables</p>	<p>Reduandant Memory Command Pressure Enable Calibraiton Not</p> <p>Reduandant Memory Command Pressure Enable Calibraiton</p> <p>No traction event in progress: ABS((driven wheel speed - non-drive wheel speed) / driven wheel speed)</p> <p>25 millisecond derivative TOSS RPM, (TOSS delta 25 millisecond loop to 25 milisecond loop) / 25 millisecond for time</p> <p>Clutch 1 hydraulic volume fill factor Clutch 2 hydraulic volume fill factor Clutch 3 hydraulic volume fill factor Clutch 4 hydraulic volume fill factor Clutch 5 hydraulic volume fill factor Clutch 6 hydraulic volume fill factor Clutch 7 hydraulic volume fill factor</p> <p>when clutch is off going (releasing) clutch the commanded clutch pressure equation = ((pressure control solenoid command</p>	<p>= 0 Boolean</p> <p>= 1 Boolean</p> <p>≥ 0.00 %</p> <p>&lt; 0.750 * <b>P2D2 Cltch Slip Sum</b> see attached supporting Table</p> <p>≥ 0.0500 seconds</p> <p>≥ 1.000 unitless ≥ 1.000 unitless ≥ 1.000 unitless ≥ 1.000 unitless ≥ 1.000 unitless ≥ 1.000 unitless ≥ 1.000 unitless</p>	<p>single event</p> <p>6.25 millisecond update rate</p>	<p>Type A, 1 Trips</p>

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>the clutch pressure command values are in error. Given rate of change of transmission output shaft speed, command gear state clutches and clutch hydraulic fill volumes, those clutches in transition from the hydraulic released state to the hydraulic applied state and from the hydraulic applied state to the hydraulic released state, the rationality detects any number of command clutch pressures above a threshold, that are simultaneously active to cause a vehicle deceleration above the design safety metric.</p> <p>The command gear/ shift fault detection is designed to verify the commanded gear will not induce a downshift resulting in a gear state that is erroneous given vehicle operating conditions. The detection rationalizes the command gear against a minimum gear, highest gear ratio, for given vehicle speed and driver accelerator position.</p>			<p>pressure - pressure offset) * regulator valve gain) - regulator valve return spring pressure adaptive</p> <p>when clutch 1 is off going clutch: clutch 1 command pressure</p> <p>clutch 1 state is OFF when: clutch 1 command pressure, else clutch is ON and count clutch 1 toward minimum # of clutches ON</p> <p>when clutch 2 is off going clutch: clutch 2 command pressure</p> <p>clutch 2 state is OFF when: clutch 2 command pressure, else clutch is ON and count clutch 2 toward minimum # of clutches ON</p> <p>when clutch 3 is off going clutch: clutch 3 command pressure</p>	<p>= ((clutch 1 pressure control solenoid command pressure - 0.00 ) * 1.00 ) - regulator valve return spring pressure adaptive, kPa</p> <p><b>P2D2 Decel Pressure - ≤ C1</b> see attached supporting tables</p> <p>= ((clutch 2 pressure control solenoid command pressure - 0.00 ) * 1.00 ) - regulator valve return spring pressure adaptive, kPa</p> <p><b>P2D2 Decel Pressure - ≤ C2</b> see attached supporting tables</p> <p>= ((clutch 3 pressure</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>clutch 3 state is OFF when: clutch 3 command pressure, else clutch is ON and count clutch 3 toward minimum # of clutches ON</p> <p>when clutch 4 is off going clutch: clutch 4 command pressure</p> <p>clutch 4 state is OFF when: clutch 4 command pressure, else clutch is ON and count clutch 4 toward minimum # of clutches ON</p> <p>when clutch 5 is off going clutch: clutch 5 command pressure</p> <p>clutch 5 state is OFF when: clutch 5 command pressure,</p>	<p>control solenoid command pressure - 177.00 ) * 1.51 ) - regulator valve return spring pressure adaptive, kPa</p> <p><b>P2D2 Decel Pressure - ≤ C3</b> see attached supporting tables</p> <p>= ((clutch 4 pressure control solenoid command pressure - 160.00 ) * 2.25 ) - regulator valve return spring pressure adaptive, kPa</p> <p><b>P2D2 Decel Pressure - ≤ C4</b> see attached supporting tables</p> <p>= ((clutch 5 pressure control solenoid command pressure - 0.00 ) * 1.00 ) - regulator valve return spring pressure adaptive, kPa</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>else clutch is ON and count clutch 5 toward minimum # of clutches ON</p> <p>when clutch 6 is off going clutch: clutch 6 command pressure</p> <p>clutch 6 state is OFF when: clutch 6 command pressure, else clutch is ON and count clutch 6 toward minimum # of clutches ON</p> <p>when clutch 7 is off going clutch: clutch 7 command pressure</p> <p>clutch 7 state is OFF when: clutch 7 command pressure, else clutch is ON and count clutch 7 toward minimum # of clutches ON</p> <p>service fast learn not active</p>	<p><b>P2D2 Decel Pressure - <math>\leq C5</math></b> see attached supporting tables</p> <p>= ((clutch 6 pressure control solenoid command pressure - 0.00) * 1.00) - regulator valve return spring pressure adaptive, kPa</p> <p><b>P2D2 Decel Pressure - <math>\leq C6</math></b> see attached supporting tables</p> <p>= ((clutch 7 pressure control solenoid command pressure - 0.00) * 1.00) - regulator valve return spring pressure adaptive, kPa</p> <p><b>P2D2 Decel Pressure - <math>\leq C7</math></b> see attached supporting tables</p>		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					no speed sensor DTCs fault active: P0716, P0717, P0721, P0722, P0723, P077C, P077D, P07BF, P07C0, P172A, P172B, P176B, P176C, P176D, P1783, P178F, P17C4, P17C5, P17C6, P17CC, P17CD, P17CE, P17D3, P17D6  no high side driver DTCs fault active: P0658, P2670			
			command gear/shift fault detection  1st gear commanded and vehicle seed OR 2nd gear commanded and vehicle seed OR 3rd gear commanded and vehicle seed OR 4th gear commanded and vehicle seed OR 5th gear commanded and vehicle seed OR 6th gear commanded and vehicle seed OR 7th gear commanded and vehicle seed OR 8th gear commanded and	> 66.07 KPH  > 93.71 KPH  > 102.86 KPH  > 126.66 KPH  > 161.11 KPH  > 214.25 KPH  > 309.81 KPH	Reduandant Memory Command Gear Enable Calibraiton Not  Reduandant Memory Command Gear Enable Calibraiton  service fast learn not active  no speed sensor DTCs fault active: P0716, P0717, P0721, P0722, P0723, P077C, P077D, P07BF, P07C0, P172A, P172B, P176B, P176C, P176D, P1783, P178F, P17C4, P17C5, P17C6, P17CC, P17CD, P17CE, P17D3, P17D6  no high side driver DTCs fault active:	= 0 Boolean  = 1 Boolean	command gear fail event count ≥ 3 counts  6.25 millisecond update rate	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			vehicle seed OR 9th gear commanded and vehicle seed OR 10th gear commanded and vehicle seed THEN increment command gear fail event count and abort commanded gear and delay for time before next fail evaluation	> 414.73 KPH  > 502.12 KPH  > 502.12 KPH  > 5.00 seconds	P0658, P2670			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Speed Signal Analog to Digital Converter Performance	P16FB	The diagnostic monitor validates the controller calculated transmission output speed sensor data parameters, calculated in multiple paths/subroutines and at different rates. There are multiple transmission output speed sensor data parameters, calculated at rates of 6.25 milliseconds, 12.5 milliseconds and 25 milliseconds. While the same subroutine, a generic "calculate TOSS" is called from different time loops, each call stores that current value of the calculated TOSS to a different memory location. For example, a 12.5 millisecond loop calling "calculate TOSS" stores the calculated TOSS value to a "12.5 millisecond TOSS calculated" data parameter in memory, while a 25 millisecond loop calling "calculate TOSS" stores the calculated TOSS value to a "25 millisecond TOSS calculated" data parameter in memory. The raw transmission output speed sensor	ABS(raw transmission output speed, 6.25 millisecond data parameter - raw transmission output speed, 25 millisecond data parameter) update fail and sample time 25 millisecond update rate	≥ 60.0 RPM	service mode \$04 active diagnsotic monitor enable  raw transmission output speed, 25 millisecond data parameter  raw transmission output speed, 6.25 millisecond data parameter  service fast learn run crank voltage battery voltage	= FALSE = 1 Boolean  ≥ 356.0 RPM  ≥ 356.0 RPM  = FALSE ≥ 10.00 volts ≥ 10.00 volts	fail time ≥ 8.000 seconds within sample time < 10.000 seconds 25 millisecond update rate          service fast learn, run crank and battery voltage time ≥ 5.000 seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		signal is diagnosed independently electrically and for performance of this DTC. The transmission output speed sensor data parameters that are calculated at different rates must always be within a negligible difference of each other.						

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Surge Solenoid Circuit Low	P171B	Controller specific transmission surge accumulator control circuit diagnoses the transmission surge accumulator and wiring for a ground short circuit fault by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a ground short</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller ground	<p>battery voltage</p> <p>battery voltage</p> <p>battery enable time</p> <p>run/crank voltage</p> <p>run crank voltage time <math>\geq</math> diagnostic monitor enable</p>	<p><math>\geq 9.00</math> volts</p> <p><math>\leq 32.00</math> volts</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 5.00</math> volts</p> <p>25 milliseconds</p> <p>= 1 Boolean</p>	fail time $\geq 0.300$ seconds out of sample time $\geq 0.500$ seconds	Type B, 2 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Surge Solenoid Circuit High	P171C	Controller specific transmission surge accumulator control circuit diagnoses the transmission surge accumulator and wiring for a short to voltage circuit fault by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>battery voltage</p> <p>battery voltage enable time</p> <p>run/crank voltage</p> <p>run crank voltage time</p> <p>diagnostic monitor enable</p>	<p><math>\geq 9.00</math> volts</p> <p><math>\leq 32.00</math> volts</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 5.00</math> volts</p> <p>time <math>\geq 25</math> milliseconds</p> <p>= 1 Boolean</p>	fail time $\geq 0.300$ seconds out of $\geq 0.500$ seconds sample time	Type B, 2 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Surge Accumulator System Performance	P171D	Detects when the surge accumulator system, used to provide transmission hydraulic pressure, is not capable of supplying adequate hydraulic pressure during an engine auto-start. The transmission holding clutch pressures are commanded to meet the engine crank shaft torque output, to prevent clutch slip to those holding clutches, during the engine auto-start. The diagnostic monitors transmission input shaft speed during the auto-start event as the primary malfunction criteria. Measured input shaft speed that is excessive is an indication the holding clutches are slipping due to inadequate hydraulic pressure, as a result of a failed surge accumulator system.	Transmission turbine speed is greater than predicted turbine speed during autostart event, update initial fail count	<b>P171D predicted</b> ≥ <b>turbine speed error</b> Refer to "Transmission Supporting Tables" for details	PRNDL state defaulted  Transmission shift lever position  Propulsion system active  Ignition voltage Ignition voltage  Transmission fluid temp Transmission fluid temp  Hybrid state AutoStop duration min  During autostop Engine speed was  ***** If above conditions are met then the following must occur:  Turbine speed  Engine speed  Hydraulic pressure delay time   If above conditions are met then increment time-out timer. Time-out timer  Note: The initial fail	= False  = Forward range A  = True  > 9.00 volts < 31.99 volts  > 0.00 °C < 110.00 °C  = Engine off ≥ 1.200 seconds  < 5.0 RPM   ≥ 80.0 RPM  ≥ 450.0 RPM  <b>P171D hydraulic</b> ≥ <b>pressure delay</b> Refer to "Transmission Supporting Tables" for details   ≤ 0.38 seconds	≥ 8 counts (initial fail count) Frequency =12.5ms  Once the above counts are achieved then increment the final fail counter once. The final fail counter can only increment once per autostart event  ≥ 3 counts (final fail counter)  If above counter is greater than threshold then report DTC failed.  Frequency = 12.5ms	Type B, 2 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>counter must achieve it's fail threshold in less than the time-out time.</p> <p>*****</p> <p>If vehicle is launched then:</p> <p>Transmission gear ratio</p> <p>Trans 1st gear ratio</p> <p>Trans 1st gear ratio</p> <p>Trans gear ratio not 1st gear</p> <p>Trans gear ratio not 1st gear</p> <p>Valid transmission gear ratio achieved time</p> <p>OR</p> <p>If vehicle is not launched but autostart occurs then:</p> <p>Turbine speed</p> <p>Turbine speed less then above threshold for</p> <p>Note: During an autostart event the lack of hydraulic pressure will result in momentary clutch slip in</p>	<p>= 4.689 1st gear ratio</p> <p>= 3.306 2nd gear ratio</p> <p>= 3.012 3rd gear ratio</p> <p>= 2.446 4th gear ratio</p> <p>= 1.923 5th gear ratio</p> <p>= 1.446 6th gear ratio</p> <p>≤ 1.120 % of 1st gear ratio</p> <p>≥ 0.880 % of 1st gear ratio</p> <p>≤ 1.070 % of gear ratio</p> <p>≥ 0.930 % of gear ratio</p> <p>≥ 0.500 seconds</p> <p>≤ 5.00 RPM</p> <p>≥ 0.500 seconds</p>		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>the C1234 clutch. After the clutch slip event, the main transmission pump and clutch will gain capacity, clutch slip will go to zero. If the vehicle is launching (moving) then a valid transmission ratio can be achieved. Or if the brake is continually applied and an autostart occurs naturally, then no ratio can be measured. In this case turbine speed will return to near zero rpm.</p> <p>*****</p> <p>DTCs not fault active</p>	<p>CrankSensor_FA Transmission Output Shaft Angular Velocity Validity Transmission Turbine Angular Velocity Validity Transmission Oil Temperature Validity P171A P171B P171C U0101 P182E P1915</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control System - Shift Limiting Active	P175E	The latent fault diagnostic monitors detects when the vehicle has been driven excessively with an emission MIL request. The DTCs requesting the emission MIL are all due to a safety critical system or component fault present in which a DTC is set fault active, test fail this key on or fault pending (fault pending is fail time ≠ 0). The safety critical systems or safety critical components include: transmission input, output and intermediate speed sensors, transmission range sensors, clutch pressure control solenoids including unintended deceleration detected due to clutch pressure control solenoids, driver accelerator pedal position, engine crankshaft position and engine torque. The DTCs for these safety critical systems or safety critical components include both electrical fault DTCs and performance fault DTCs. The latent fault diagnostic monitor	P0747 OR P0777 OR P0797 OR P2715 OR P2724 OR P2731 OR P2733 fault active due to unintended deceleration detection, increment unintended deceleration latent fault fail count		transmission default gear active (emission MIL active) calibration CeTRDR_e_DSG_DfltGr Opt5_Action any non-zero (0) option	> CeTRDR_e_DSG_DfltGr OptNone, zero (0) element in default gear array	unintended deceleration latent fault fail count ≥ 100 counts  25 millisecond update rate	Type A, 1 Trips
			P0747 OR P0777 OR P0797 OR P2715 OR P2724 OR P2731 OR P2733 clutch pressure control solenoid fault active due to clutch stuck on during shift, increment clutch pressure control solenoid latent fault fail count		transmission default gear active (emission MIL active) calibration CeTRDR_e_DSG_DfltGr Opt5_Action any non-zero (0) option	> CeTRDR_e_DSG_DfltGr OptNone, zero (0) element in default gear array	clutch pressure control solenoid latent fault fail count ≥ 100 counts  25 millisecond update rate	
			P2802 OR P2803 fault active, increment transmission range sensor latent fault fail count		transmission default gear active (emission MIL active) calibration CeTRDR_e_DSG_DfltGr OptNone any non-zero (0) option	> CeTRDR_e_DSG_DfltGr OptNone, zero (0) element in default gear array	transmission range sensor latent fault fail count ≥ 200 counts  25 millisecond update rate	
			P0721 OR P0722 OR P0723 OR P077C OR P077D or P172A fault active, increment transmission output speed sensor latent fault fail count		transmission default gear active (emission MIL active) calibration CeTRDR_e_DSG_DfltGr Opt5_Action any non-zero (0) option	> CeTRDR_e_DSG_DfltGr OptNone, zero (0) element in default gear array	transmission output speed sensor latent fault fail count ≥ 100 counts  25 millisecond update rate	
			P0716 OR P0717 OR P0721 OR P07BF OR P07C0 fault active OR		transmission default gear active (emission MIL active) calibration	>	transmission input output speed sensor latent fault fail	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfuction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		counts the run/crank ignition cycles before the latent fault DTC is set fault active.	P077D OR P077D OR P1783 OR P17CE fault active OR P0722 OR P0723 OR P172A test fail this key on OR P0716 OR P0717 OR P0721 OR P0722 OR P0723 OR P077C OR P077D OR P07BF OR P07C0 Or P172A OR P172B OR P1783 OR P17CE fault pending (fail time ≠ 0) increment transmission input output speed sensor latent fault fail count		CeTRDR_e_DSG_DfltGr Opt5_Action any non-zero (0) option	CeTRDR_e_DSG_DfltGr OptNone, zero (0) element in default gear array	count ≥ 100 counts  25 millisecond update rate	
			AcceleratorPedalFailure OR EngineTorqueEstInaccuracy OR P2534 fault active OR CrankSensor_FA OR P0707 OR P0708 fault active OR test fail this key on OR P2805 fault active OR P0716 OR P0717 OR P07BF OR P07C0 fault active OR P0722 OR P0723 test fail this key on OR P077C OR P077D fault active OR P176C OR P176D OR	= TRUE  = TRUE          = TRUE	transmission default gear active (emission MIL active) calibration CeTRDR_e_DSG_DfltGr Opt5_Action any non-zero (0) option   ignition run crank voltage for time	> CeTRDR_e_DSG_DfltGr OptNone, zero (0) element in default gear array   > 5.00 volts ≥ 12.5 milliseconds	system latent fault fail count ≥ 100 counts  6.25 millisecond update rate	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			P17CC OR P17CD OR P176B OR P17D6 fault active OR test fail this key on OR P0747 OR P0777 OR P0797 OR P2715 OR P2724 OR P2733 OR P0746 OR P0776 OR P0796 OR P2714 OR P2723 OR P2732 OR P178F OR P17C4 OR P17C6 OR P172A OR P172B test fail this key on OR P0960 OR P0962 OR P0963 OR P0964 OR P0966 OR P0967 OR P0968 OR P0970 OR P0971 OR P2718 OR P2720 OR P2721 OR P2727 OR P2729 OR P2730 OR P2736 OR P2738 OR P2739 OR P17C5 OR P17D3OR P0721 fault active OR P0716 OR P0717 OR P0721 OR P0722 OR P0723 OR P077C OR P077D OR P07BF OR P07C0 fault pending (fail time ≠ 0) OR P176B OR P176C OR P176D OR P17CC OR P17CD OR P17D6 OR P1783 OR P178F OR P17C4 OR P17C5 OR P17C6 OR P17CE OR P17D3 OR P172A or P172B fault pending (fail					

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			time ≠ 0) OR P1783 fault active OR P1783 fault pending (fail time ≠ 0)  update system fault time when system fault time increment system latent fault fail count	≥ 10.0 seconds				

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Acceleration Sensor Signal Message Counter Incorrect	P175F	<p>The diagnostic monitor detects an alive rolling count error or checksum error in the CAN frame containing the lateral acceleration signal value and longitudinal acceleration sensor signal value.</p> <p>Emission neutral default state sets lateral and longitudinal acceleration signal = 0.0 g.</p>	<p>rolling count value received from EBCM and expected TCM calculated value not equal OR checksum lateral and longitudinal acceleration CAN frame message value error</p> <p>50 millisecond update rate</p>	<p>= TRUE</p> <p>= TRUE</p>	<p>enable alive rolling count error detection: diagnostic monitor enable lateral and longitudinal acceleration CAN frame message received battery voltage run crank voltage</p> <p>enable checksum error detection: diagnostic monitor enable lateral and longitudinal acceleration CAN frame message received normal CAN battery voltage run crank voltage communication enabled</p> <p>DTCs not fault active</p>	<p>= 1 Boolean = TRUE</p> <p>≥ 11.0 volts ≥ 11.0 volts</p> <p>= 1 Boolean = TRUE</p> <p>≥ 11.0 volts ≥ 11.0 volts = TRUE</p> <p>U0073</p>	<p>alive rolling count errors ≥ 54 out of 9 sample counts 50 millisecond update rate</p> <p>checksum error time ≥ 54.00 seconds</p>	Emission Neutral Diagnostic – Type C

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Up and Down Shift Switch Signal Circuit	P1761	<p>The alive rolling count normally cycles 0, 1, 2, and 3 as a serial data periodic frame is processed normally. The diagnostic monitor counts the number of times an alive rolling count error occurs over a period of time. The TCM receives a serial data frame at a periodic rate, during which, the receive data is processed the comparing the current value of the alive rolling count in the frame data to the incremented value of the diagnostic alive rolling count. When the two values of the alive rolling count do not agree, an alive rolling count error has occurred. The error indicator is saved in an array buffer, and when the number of error indicators in the buffer exceed the fail threshold the fail time is allowed to time up.</p> <p>Emissions neutral default, disables tap-up tap-down or manual-up manual-down.</p>	<p>alive rolling count error counter update fail time 100 millisecond update rate</p>	≥ 3 counts	<p>service mode \$04 active diagnostic monitor enable</p> <p>run crank voltage run crank voltage time</p> <p>up and down shift serial data frame receive occurred</p> <p>when up and down shift serial data frame receive occurred: increment the diagnsotic alive rolling count data value, if the diagnsotic alive rolling count data value, set alive rolling count error to TRUE,</p> <p>when alive rolling count error AND previous alive rolling count error in 10 element array buffer, increment alive rolling count error counter</p>	<p>= FALSE = 1 Boolean</p> <p>≥ 9.00 volts ≥ 0.100 seconds</p> <p>= TRUE</p> <p>≠ frame alive rolling count data value</p> <p>= TRUE = FALSE</p>	fail time ≥ 10.00 seconds	Emissions Neutral Diagnostics – Type C

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Planetary Gearset Ring Gear Speed Sensor Circuit Range/ Performance	P176B	The diagnostic monitor rationalizes the transmission intermediate shaft speed sensor by using the transmission output shaft output speed sensor and the known ratio between the transmission intermediate shaft speed and the transmission output shaft output speed based on the commanded gear and the transmission lever node design. The estimated transmission intermediate shaft speed is equal to the gear ratio times the transmission output shaft output speed. The absolute value of the delta between the measured transmission intermediate shaft speed and the estimated transmission intermediate shaft speed is used to determine if the measured transmission intermediate shaft speed is rational.	delta1 = ABS (transmission input speed - (transmission output speed * gear ratio commanded))  update fail time 25 millisecond update rate	> 10.0 RPM	diagnostic monitor enable          speed sensor configuration calibration is single OR dual  ratio calibration is function of command gear and intermediate speed sensor when not REVERSE  ratio calibration is function of command gear and intermediate speed sensor when REVERSE  ***** delay time updates when: estimated transmission intermediate speed (transmission input speed / ratio calibration)	= 1 Boolean          = CeTNSR_e_NSPD_SingleSpdSnsr  <b>P176B ratio calibration = when not REVERSE</b> see supporting tables  <b>P176B ratio calibration = when REVERSE</b> see supporting tables  ***** ≥ <b>P176B minimum estimated transmission intermediate speed to enable fail evaluation</b> see supporting tables	fail time ≥ <b>P176B intermediate speed sensor fail time threshold</b> see supporting tables  fail time threshold met increments fail count, fail count ≥ <b>P176B intermediate speed sensor fail count threshold</b> see supporting tables  ***** delay time ≥	Type A, 1 Trips



# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>with</p> <p>transmission input speed</p> <p>input speed sensor ready based on commaned gear and transmission intermediate speed sensor (state output must be FALSE to enable fail evaluation) with with attained gear</p> <p>*****</p> <p>transmission input speed transmission output speed neutral idle mode range shift state P0716 fault active P0717 fault active P07BF fault active P07C0 fault active P0722 fault active P0723 fault active P077C fault active P077D fault active P176C fault active P176D fault active battery voltage</p>	<p>P176B minimum transmission input speed to enable fail ≥ evaluation see supporting tables</p> <p>P176B holding clutch = states see supporting tables</p> <p>= REVERSE OR = 1st thru 10th</p> <p>*****</p> <p>≥ 172.0 RPM ≥ 89.0 RPM = nuetral idle mode ON = range shift complete = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE ≥ 9.00 volts</p> <p>= FALSE ≥ 9.00 volts</p>	<p>P176B delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation see supporting tables</p>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					service fast learn active run crank voltage  transmission hydraulic pressure available: engine speed	≥ 500.0 RPM	battery voltage time ≥ 0.100 seconds  run crank voltage time ≥ 0.100 seconds  engine speed time ≥ <b>engine speed            time for            transmission            hydraulic            pressure            available</b> see supporting tables	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Planetary Gearset Ring Gear Speed Sensor Circuit Low	P176C	Controller specific analog circuit diagnoses the transmission intermediate speed sensor and wiring for a short to ground fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission intermediate speed sensor raw voltage, update fail time, 12.5 millisecond update rate	$\leq$ volts ( $\leq 0.5 \Omega$ impedance between signal and controller ground)	<p>service mode \$04 active diagnostic monitor enable</p> <p>P176D fault active service fast learn</p> <p>run crank voltage battery voltage</p> <p>P176C fault active P176C test fail this key on</p>	<p>= FALSE = <b>P176C Enable Boolean</b></p> <p>= FALSE = FALSE</p> <p><math>\geq 10.00</math> volts <math>\geq 10.00</math> volts</p> <p>= FALSE = FALSE</p>	<p>fail time <math>\geq</math> <b>P176C Fail Timer</b> seconds, update fail count, fail count <math>\geq</math> <b>P176C Fail Count Threshold</b> counts 6.25 millisecond update rate</p> <p>run crank and battery voltage time <math>\geq 5.000</math> seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Planetary Gearset Ring Gear Speed Sensor Circuit High	P176D	Controller specific analog circuit diagnoses the transmission intermediate speed sensor and wiring for a short to voltage fault by comparing a voltage measurement to controller specific voltage thresholds.	transmission intermediate speed sensor raw voltage, update fail time, 12.5 millisecond update rate	<b>P176D Voltage Fail</b> ≥Threshold volts (≤ 0.5 Ω impedance between signal and controller power)	service mode \$04 active diagnostic monitor enable  P176C fault active service fast learn   run crank voltage battery voltage  P176D fault active P176D test fail this key on	= FALSE = <b>P176D Boolean Enable</b>  = FALSE = FALSE   ≥ 10.00 volts ≥ 10.00 volts  = FALSE = FALSE	fail time ≥ <b>P176D Fail Time Threshold</b> seconds, update fail count, fail count ≥ <b>P176D Fail Count Threshold</b> counts 6.25 millisecond update rate  run crank and battery voltage time ≥ 5.000 seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ETRS GMLAN Command Signal Message Incorrect	P1775	The diagnostic monitor detects an alive rolling count error or protection value (checksum) error in the CAN bus frame containing the Electronic Transmission Range Selector (ETRS) signal data. The alive rolling count sequences 0, 1, 2, 3 repeatedly. As each serial data frame is broadcast by the transmitting controller, the transmitting controller increments the alive rolling count in this sequence manner. The receiving controller compares the most recent received alive rolling count value to the previous value plus one. If the values are not equal, an alive rolling count error has occurred. The protection value is based on the checksum of the ETRS data parameters in the transmit message frame, and is incorporated in the transmit message frame. If the TCM receives the ECM/CHCM ETRS data message frame, the	rolling count value received from ECM/CHCM and expected TCM calculated value not equal	= TRUE	<p>Loop rate calibration either 10 milliseconds or 12.5 milliseconds</p> <p>service mode \$04 active battery voltage battery voltage time</p> <p>ETRS ECM/CHCM frame recieved</p>	<p>CeCFMD_e_DEC_Time Base_12p5</p> <p>= FALSE ≥ 11.00 volts ≥ 300.000 seconds</p> <p>= TRUE</p>	alive rolling count errors ≥ 8 out of 10 sample counts	Type B, 2 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		TCM calculates the protection value, again based on the ETRS data parameters, in the receive message frame. If the TCM calculated protection value does not equal the protection value incorporated in the ECM/CHCM ETRS data message frame, a or protection value error has occurred. If continuous alive rolling count errors or protection value errors occur, the DTC is set.						

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intermediate Speed Sensor 1 Direction Error	P17D3	The diagnostic monitor determines if the direction transmission intermediate speed sensor value is coherent based on the on period time of the directional sensor and raw speed sensor value. When the on period time indicates a transitional state, the direction must also be transitional as measured by very slow raw signal RPM. When the on period time indicates a non-transitional state, forward or reverse, the direction must also be transition, not forward and not reverse.	intermediate speed sesnor raw direction when transitional period = FALSE AND intermediate speed sesnor raw direction when transitional period = FALSE OR intermediate speed sesnor raw when transitional period = TRUE  update fail and sample time 6.26 millisecond update rate	≠ FORWARD  ≠ REVERSE  <b>P17C5 P17D3 intermediate speed ≥ sensor RPM</b>	service mode \$04 active diagnostic monitor enable intermediate speed sesnor count sample period P17D3 fault active OR P17D3 test fail this key on senor type cailbration (senor type is directional)  transitional period detected = FALSE when: on period OR on period when direction unknown OR on period on period when direction is reverse OR on period on period when direction is forward  transitional period detected = TRUE when: on period on period when direction unknown	= FALSE = 1 Boolean ≠ 0 counts  = FALSE = FALSE = CeTNSR_e_NSPD_Singl eSpdSnsr  ≥ 0.4434 seconds ≤ 0.2773 seconds  < 0.2363 seconds > 0.1240 seconds  < 0.0811 seconds > 0.0088 seconds  < 0.4434 seconds > 0.2773 seconds	fail time ≥ 3.500 seconds out of sample time ≥ 5.000 seconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Park Valve Position Sensor/ Switch A Circuit/Open	P17F5	The diagnostic monitor detects an illegal voltage on the park valve position sensor circuit.	raw sensor voltage raw sensor voltage	> 1.263 volts < 1.504 volts	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is hall sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETR S = CePSCR_e_HallSns	0.100 seconds in 0.163 second sample  6.25 millisecond update rate	Type A, 1 Trips



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Valve Position Sensor/ Switch A Circuit Low	P17F6	The diagnostic monitor detects a ground short or open circuit fault in the park valve position sensor circuit.	raw sensor voltage	< 0.414 volts	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is hall sensor	1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	0.100 seconds in 0.163 second sample  6.25 millisecond update rate	Type A, 1 Trips
			sensor voltage direct proportion	= CePSCD_e_VoltDirct Prop	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is PWM sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	1.000 seconds in 1.500 second sample  6.25 millisecond update rate	
			raw sensor % duty cycle	≤ 9.998 % duty cycle				
			sensor voltage indirect proportion	= CePSCD_e_VoltDirct Prop				
			raw sensor % duty cycle	≥ 9.998 % duty cycle				

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Valve Position Sensor/ Switch A Circuit High	P17F7	The diagnostic monitor detects a short to voltage circuit fault in the park valve position sensor circuit.	raw sensor voltage	> 2.538 volts	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is hall sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	0.100 seconds in 0.163 second sample  6.25 millisecond update rate	Type A, 1 Trips
			sensor voltage direct proportion	= CePSCD_e_VoltDirct Prop	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is PWMsensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	1.000 seconds in 1.500 second sample	
			raw sensor % duty cycle	≥ 91.998 % duty cycle				
			sensor voltage indirect proportion	= CePSCD_e_VoltDirct Prop			6.25 millisecond update rate	
			raw sensor % duty cycle	≤ 91.998 % duty cycle				

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Park Valve Position Sensor/ Switch B Circuit/Open	P17FA	The diagnostic monitor detects an illegal voltage on the park valve position sensor circuit.	raw sensor voltage raw sensor voltage	> 1.263 volts < 1.504 volts	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is hall sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETR S = CePSCR_e_HallSns	0.100 seconds in 0.163 second sample  6.25 millisecond update rate	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Valve Position Sensor/ Switch B Circuit Low	P17FB	The diagnostic monitor detects a ground short or open circuit fault in the park valve position sensor circuit.	raw sensor voltage	< 0.414 volts	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is hall sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	0.100 seconds in 0.163 second sample  6.25 millisecond update rate	Type A, 1 Trips
			sensor voltage direct proportion	= CePSCD_e_VoltDirct Prop	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is PWM sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	1.000 seconds in 1.500 second sample  6.25 millisecond update rate	
			raw sensor % duty cycle	≤ 9.998 % duty cycle				
			sensor voltage indirect proportion	= CePSCD_e_VoltDirct Prop				
			raw sensor % duty cycle	≥ 9.998 % duty cycle				

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Valve Position Sensor/ Switch B Circuit High	P17FC	The diagnostic monitor detects a short to voltage circuit fault in the park valve position sensor circuit.	raw sensor voltage	> 2.538 volts	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is hall sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	0.100 seconds in 0.163 second sample  6.25 millisecond update rate	Type A, 1 Trips
			sensor voltage direct proportion	= CePSCD_e_VoltDirct Prop	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is PWMsensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	1.000 seconds in 1.500 second sample	
			raw sensor % duty cycle	≥ 91.998 % duty cycle				
			sensor voltage indirect proportion	= CePSCD_e_VoltDirct Prop			6.25 millisecond update rate	
			raw sensor % duty cycle	≤ 91.998 % duty cycle				

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Valve Stuck On	P187D	This diagnostic monitor rationalizes the driver ETRS command direction of "out of PARK" against the actual park valve position, as the park valve position is measured by the park valve position sensor A or B.	<p>when: (Park Valve Position Sensor A OR Park Valve Position Sensor B) AND (out of park state calculated OR out of park state calculated) update delay time</p> <p>when: delay time AND</p> <p>fail time</p> <p>increment fail count</p>	<p>= PARK</p> <p>= PARK</p> <p>= UNKNOWN</p> <p>= PARK</p> <p>≥ <b>Park Valve Stk On Dly Lim</b></p> <p>&gt;= <b>Park Valve Stk On Fail Lim</b></p>	<p>park servo enable ETRS system type is internal ETRS</p> <p>battery voltage for battery voltage time diagnostic monitor enable</p> <p>park state transtion is TRUE when: (out of park state calculated OR out of park state calculated) AND P187D, P187E Test Fail This Key On AND ((ETRS command direction AND out of park state) OR (ETRS command direction AND out of park state)) otherwise park state transition is FALSE</p> <p>park state transition AND (P17F5, P17F6, P17F7 Fault Active OR P17FA, P17FB, P17FC Fault Active) AND P187D, P187E Fault Active</p> <p>park servo stuck on avaiable is TRUE when: ETRS command direction AND</p>	<p>= 1 Boolean = CeTRGR_e_InternalETRS</p> <p>≥ 9.00 volts ≥ 1.000 seconds = 1 Boolean</p> <p>= PARK</p> <p>= OUT OF PARK</p> <p>= FALSE</p> <p>= PARK</p> <p>≠ PARK</p> <p>≠ PARK</p> <p>≠ PARK</p> <p>= TRUE = FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>≠ PARK</p>	<p>fail count ≥ 2 counts</p> <p>update rate 6.25 milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					line pressure command AND ((ETRS command direction AND P18AB Test Fail This Key On AND mode valve A pressure) OR (ETRS command direction AND P18A8 Test Fail This Key On AND (mode valve A pressure OR mode valve B pressure)) OR (ETRS command direction AND P18AD Test Fail This Key On AND mode valve B pressure) OR (ETRS command direction AND ((P18AB Test Fail This Key On AND mode valve A pressure) OR (P18AD Test Fail This Key On AND mode valve B pressure))) OR (ETRS command direction AND P18AB Test Fail This Key On AND mode valve B pressure)) otherwise park servo stuck on available is FALSE  hydraulic pressure	>= 120.00  = DRIVE = FALSE  >= 195.00  = NEUTRAL LOW = FALSE  >= 195.00  >= 295.00  = NEUTRAL HIGH = FALSE  >= 295.00  = NEUTRAL SHIFT = FALSE  >= 195.00 = FALSE  >= 295.00  = REVERSE = FALSE  >= 295.00		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					available = TRUE when: engine speed for engine speed time otherwise hydraulic pressure available = FALSE  hydraulic pressure available park servo stuck on available  (mode valve A state attained OR P18AA Test Fail This Key On OR P27EC Test Fail This Key On OR P27EC Fault Pending) AND (mode valve B state attained OR P18AC Test Fail This Key On OR P27F0 Test Fail This Key On OR P27F0 Fault Pending)	≥ 500.0 RPM <b>Hydraulic Press Avail</b> ≥ Tm Thrsh  = TRUE = TRUE  = TRUE = TRUE = TRUE = TRUE = TRUE = TRUE = TRUE = TRUE		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Valve Stuck Off	P187E	This diagnostic monitor rationalizes the driver ETRS command direction of "PARK" against the actual park valve position, as the park valve position is measured by the mode valve position sensor A and B.	when: ETRS command direction out of park state update delay time  when: delay time  increment fail time	= PARK ≠ PARK  ≥ <b>Park Valve Eng Off Dly Lim</b>	park servo enable ETRS system type is internal ETRS  battery voltage for battery voltage time engine mode run  hydraulic pressure available is TRUE when: engine speed for engine speed time otherwise hydraulic pressure available is FALSE  hydraulic pressure available surge accumulator on/off request engine off diagnostic enabled  P187D, P187E Test Fail This Key On	= 1 Boolean = CeTRGR_e_InternalETRS  ≥ 9.00 volts ≥ 1.000 seconds = FALSE  ≥ 500.0 RPM ≥ <b>Hydraulic Press Avail Tm Thrsh</b>  = FALSE = FALSE = 1 Boolean = FALSE	fail time ≥ <b>Park Valve Eng Off Dly Lim</b> seconds  update rate 6.25 milliseconds	Type A, 1 Trips
			when: (Park Valve Position Sensor A OR Park Valve Position Sensor B) AND (out of park state calculated OR out of park state calculated) update delay time  when: delay time AND	= OUT OF PARK = OUT OF PARK = UNKNOWN = OUT OF PARK  ≥ <b>Park Valve Stk Off Dly Lim</b>	park servo enable ETRS system type is internal ETRS  battery voltage for battery voltage time diagnostic monitor enable  park state transition is TRUE when: (out of park state calculated OR out of park state calculated) AND	= 1 Boolean = CeTRGR_e_InternalETRS  ≥ 9.00 volts ≥ 1.000 seconds = 1 Boolean  = PARK = OUT OF PARK	fail count ≥ 2 counts  update rate 6.25 milliseconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			fail time  increment fail count	>= <b>Park Valve Stk Off Fail Lim</b>	<p>P187D, P187E Test Fail This Key On AND ((ETRS command direction AND out of park state) OR (ETRS command direction AND out of park state)) otherwise park state transition is FALSE</p> <p>park servo stuck off availabe is TRUE when: park state transtion ((P17F5, P17F6, P17F7 Fault Active OR P17FA, P17FB, P17FC Fault Active) AND (P187E, P187D Test Fail This Key On)) ((ETRS command direction AND (P182A Fault Active) OR (P182A Fault Active AND calculated line pressure)) AND ((P18AA Test Fail This Key On AND P18AC Test Fail This Key On) OR ETRS mode enable valve state)) otherwise park servo stuck off availabe is FALSE</p> <p>((mode valve A state attained OR P18AA Test Fail This Key On OR</p>	<p>= FALSE</p> <p>= PARK</p> <p>≠ PARK</p> <p>= OUT OF PARK</p> <p>= PARK</p> <p>= TRUE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= PARK</p> <p>= FALSE</p> <p>= TRUE</p> <p>≥ 1,000.0 kPa</p> <p>= FALSE</p> <p>= FALSE</p> <p>= ETRS zero limit (hydraulic cicruit exhausted)</p> <p>= TRUE</p> <p>= TRUE</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P27EC Test Fail This Key On OR P27EC Fault Pending) AND mode valve A pressure) AND ((mode valve B state attained OR P18AC Test Fail This Key On OR P27F0 Test Fail This Key On OR P27F0 Fault Pending) AND mode valve B pressure) OR ETRS mode enable valve state)	= TRUE  = TRUE < 195.00 = TRUE = TRUE = TRUE = TRUE < 295.00 = ETRS zero limit (hydraulic cicruit exhausted)		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Command Message Performance	P189C	The diagnostic monitor detects a failure of the LIN serial communication failure between the TCM and the ECM/CHCM for Electronic Transmission Range Select (ETRS) vehicles.	LIN range command is undetected by TCM based on Rx LIN service function  Range Command Secondary Updated	= FALSE set to FALSE as part of normal background time updates, set to TRUE as part of normal LIN service function when Rx messages are processed	diagnostic monitor calibration enable service mode \$04 active run/crank voltage run/crank voltage time	= 1 Boolean  = FALSE ≥ 5.00 volts ≥ 3,000.000 seconds	initial fail time ≥ 5.000 seconds  final fail time ≥ 375.000 seconds	Type B, 2 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Inhibit Actuator Control Circuit Low	P18A2	Controller specific circuit diagnoses internal ETRS park solenoid for an ground short or open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates an open circuit  Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit  Increment fail time	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground  OR  $\leq 0.5 \text{ } \Omega$ impedance between signal and controller ground	((battery voltage AND battery voltage AND for battery voltage time run crank voltage for run crank voltage time) OR accessory voltage active))  diagnostic monitor enable calibration	$\geq 9.00 \text{ volts}$ $\leq 32.00 \text{ volts}$ $\geq 1.000 \text{ seconds}$ $\geq 5.00 \text{ volts}$ $\geq 25 \text{ milliseconds}$  = TRUE for 12.5 milliseconds  = 1 Boolean	fail time $\geq 0.100$ seconds out of sample time $\geq 0.166$ seconds	Type B, 2 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Inhibit Actuator Control Circuit High	P18A4	Controller specific circuit diagnoses internal ETRS park solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>((battery voltage AND battery voltage AND for battery voltage time run crank voltage for run crank voltage time) OR accessory voltage active))</p> <p>diagnostic monitor enable calibration</p>	<p><math>\geq 9.00</math> volts  <math>\leq 32.00</math> volts  <math>\geq 1.000</math> seconds  <math>\geq 5.00</math> volts  <math>\geq 25</math> milliseconds</p> <p>= TRUE for 12.5 milliseconds</p> <p>= 1 Boolean</p>	fail time $\geq 0.100$ seconds out of sample time $\geq 0.166$ seconds	Type B, 2 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Park Inhibit Solenoid Stuck Off	P18A8	This diagnostic monitor rationalizes the park inhibit solenoid based on the driver ETRS command direction and mode valve states.	when: P18A8 Test Fail This Key On mode valve A position mode valve B position park position sensor A park position sensor B update fail time	= FALSE  = mode valve low = mode valve low = PARK = PARK	park servo enable ETRS system type is internal ETRS  battery voltage for battery voltage time ignition inputs power mode  hydraulic pressure available = TRUE when: engine speed for engine speed time otherwise hydraulic pressure available = FALSE  engine mode run AND engine off diagnostic enable AND [auto stop active OR (auto stop active AND hydraulic pressure available)]  (ETRS command direction AND diag park state	= 1 Boolean = CeTRGR_e_InternalETRS  ≥ 9.00 volts ≥ 1.000 seconds ≠ power mode off  ≥ 500.0 RPM ≥ <b>Hydraulic Press Avail Tm Thrsh</b>  = FALSE = 1 Boolean  = TRUE = FALSE = FALSE  ≠ PARK = OUT OF PARK	fail time ≥ <b>PISA Stk Off Eng Off Dly Lim</b>  update rate 6.25 milliseconds	Type B, 2 Trips
			when: ETRS command direction P18A8 Test Fail This Key On diagnostic park state mode valve A position mode valve B position	= NEUTRAL LOW = FALSE  = OUT OF PARK = mode valve low = mode valve low	park servo enable ETRS system type is internal ETRS  battery voltage for battery voltage time	= 1 Boolean = CeTRGR_e_InternalETRS  ≥ 9.00 volts ≥ 1.000 seconds	fail counter >= 3.00  update rate 6.25 milliseconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			park position sensor A park position sensor B  increment fail count	= PARK = PARK	ignition inputs power mode  Engine mode run AND P18E7 Fault Active AND P18E7 Fault Pending AND P18E8 Fault Active AND P18E8 Fault Pending AND P18A2 Fault Active AND P18A3 Fault Active AND P18A4 Fault Active	≠ power mode off  = TRUE = FALSE = FALSE  = FALSE = FALSE  = FALSE = FALSE = FALSE		



# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Control Valve A Stuck On	P18AA	This diagnostic monitor detects a Mode Valve A Position Sensor State in the "on" or "high" state, which is in error, when commanded hydraulic pressure in the circuit used to move the mode valve is not sufficient to overcome the mode valve return spring force, leaving the mode valve mechanically in the "off" or "low" state.	Mode Valve A Position Sensor State  mode valve A pressure  (((ETRS commanded direction AND ETRS diagnostic range AND line pressure command) OR (ETRS commanded direction AND ETRS diagnostic range AND line pressure command)))  ((Mode valve A transition AND mode valve A state attained AND Mode valve A transition delay)  IF mode valve A transition FP (mode valve A fail timer	≠ Mode Valve Low  < 25.00  ≠ Drive or NeutShf  = Drive or NeutShf  ≠ 0  = NeutShf  = Drive  = 0  = FALSE  = FALSE  >= ModeVlvA_TrnstnDly [ETRS diagnostic range][ETRS commanded direction] (see supporting tables for specific delay associated with each shift)  = FALSE  >= <b>Mode Vlv A GS TurbDly Lim</b>	park diagnostic monitor enable ETRS system configuration is internal ETRS battery voltage battery voltage time ignition inputs power mode  (engine run mode OR hydraulic system pressure available)  Mode valve performance diagnostic enable  ETRS commanded direction  ((Driver command P2812 Fault Active P2815 Fault Active P0970 Fault Active P2720 Fault Active) OR (Driver command P2814 Fault Active (P0968 Fault Active P0971 Fault Active) OR (P2718 Fault Active P2721 Fault Active)))  P18AA Test Fail This Key On P27EB Fault Active P27ED Fault Active P27EE Fault Active P18AB Test Fail This Key On	= 1 Boolean  = CeTRGR_e_InternalETRS ≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = TRUE  = TRUE  = 1.00 Boolean  ≠ ETRS diagnostic range  = Park = FALSE = FALSE = FALSE = FALSE  ≠ Park = FALSE = FALSE = FALSE  = FALSE = FALSE  = FALSE = FALSE = FALSE = FALSE	When: ((Park is commanded AND fail count >= 2.00 ) OR (Park is not commanded AND fail count >= 2.00 ))  update rate 6.25 milliseconds	Type A, 1 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			set mode valve A transition FP)  ELSE (set mode valve A transition FP)))  OR  ((ETRS commanded direction ETRS diagnostic range mode valve A state attained mode valve A transition mode valve A final delay)  set mode valve A final FP)  IF mode valve A transition FP OR mode valve A final FP (Increment fail count AND reset delay and fail timers)	= TRUE  = TRUE  = NeutLo = Park = FALSE = TRUE >= ModeVlvA_FnlDly [ETRS diagnostic range][ETRS commanded direction] (see supporting tables for specific delay associated with each shift) = TRUE  = TRUE  = TRUE	P27EC Test Fail This Key On  Mode valve A state attained = TRUE when: Mode valve A sensor position Mode valve sensor position  (mode valve A transition OR <b>Mode Valve A Trnstrn State</b> )  Mode valve A transition = TRUE when: Mode valve A sensor position	= FALSE  = mode valve A command = <b>Mode Valve A Final State</b>  = TRUE = <b>Mode Valve A Final State</b>  = <b>Mode Valve A Trnstrn State</b>		
			Mode Valve A Position Sensor State  ETRS commanded direction AND mode valve A pressure	≠ Mode Valve Low  ≠ Drive or NeutShf <= 25.00	park diagnostic monitor enable ETRS system configuration is internal ERTS battery voltage	= 1 Boolean = CeTRGR_e_InternalETRS	Mode valve A steady state remedial delay >=	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>When: clutch slip OR (Mode valve A steady state delay</p> <p>park servo Mode valve A steady state fail time)</p> <p>increment mode valve A remedial timer</p>	<p>= slip detected</p> <p>&gt;=</p> <p><b>Mode Vlv StdySt Park Dly Lim</b></p> <p>= OUT OF PARK</p> <p>&gt;=</p> <p><b>Mode Valve A steady state turbine speed delay</b></p>	<p>battery voltage time ignition inputs power mode (engine run mode OR hydraulic system pressure available)</p> <p>Mode valve performance diagnostic enable</p> <p>ETRS commanded direction</p> <p>P18AA Test Fail This Key On</p> <p>P27EB Fault Active</p> <p>P27ED Fault Active</p> <p>P27EE Fault Active</p> <p>P18AB Test Fail This Key On</p> <p>P27EC Test Fail This Key On</p> <p>mode valve steady state clutch slip = slip detected when: IF (commanded or attained gear C1 clutch slip speed validity) ELSE IF (range shift state active clutch control (turbine speed OR turbine speed) gear slip timer) ELSE (commanded gear slip AND</p>	<p>≥ 9.00 volts</p> <p>≥ 1.00 seconds</p> <p>≠ power mode off</p> <p>= TRUE</p> <p>= TRUE</p> <p>= 1.00 Boolean</p> <p>= ETRS diagnostic range</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= 1 FW</p> <p>= FALSE</p> <p>= clutch control ≠ GSCR</p> <p>&gt; upper bound</p> <p>&lt; lower bound</p> <p>&gt;= 0.10</p>	<p><b>Mode Valve A StdySt Rmdl Lim</b></p> <p>update rate 6.25 milleseconds</p>	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					gear slip timer)  mode valve steady state clutch slip = no slip detected when: IF (C1 clutch slip speed validity (C1 slip (turbine pull down OR throttle position %)) ELSE IF (range shift state active clutch control (turbine speed OR turbine speed )) ELSE (commanded gear slip (turbine pull down OR (throttle position % OR engine torque))) AND gear slip timer	>= 150.00  >= 0.10      = TRUE  < 200.00 >= 400.00  > 5.00  = clutch control ≠ GSCR < upper bound  > lower bound  < 150.00 >= 400.00  > 5.00 > 35.00  >= 0.05		
			Mode Valve A Position Sensor State  IF (max line pressure) Mode valve A engine off transition delay  ELSE mode valve A engine off transition delay	≠ Mode Valve Low  = FALSE >= <b>Mode Valve A Eng Off Dly Lim</b>  >=	park diagnostic monitor enable ETRS system configuration is internal ERTS battery voltage batyer voltage time ignition inputs power mode engine run mode AND	= 1 Boolean  = CeTRGR_e_InternalETR S ≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = FALSE	IF (max line pressure = FALSE) Mode valve A fail timer >= <b>Mode Valve A Eng Off Dly Lim</b>  ELSE	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Mode Valve A Eng Off ML Lim	(hydraulic system pressure available OR auto stop active)  GF9 engine off diagnosis enable P18AA Test Fail This Key On P27EB Fault Active P27ED Fault Active P27EE Fault Active	= FALSE  = TRUE  = 1 Boolean  = FALSE  = FALSE = FALSE = FALSE	mode valve A fail timer >= <b>Mode Valve A Eng Off ML Lim</b>  update rate 6.25 milleseconds	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Control Valve A Stuck Off	P18AB	This diagnostic monitor detects a Mode Valve A Position Sensor State in the "off" or "low" state, which is in error, when hydraulic pressure in the circuit used to move the mode valve is sufficient to overcome the mode valve return spring force, leaving the mode valve mechanically in the "on" or "high" state. The diagnostic monitor also executes during transitions of the mode valve to verify Mode Valve A Position Sensor State changes correctly with mode valve state command.	Mode Valve A Position Sensor State  ETRS commanded direction  (mode valve A pressure OR drive latch present)  (clutch slip OR (mode valve A steady state delay AND (park servo line pressure line pressure use) OR (mode valve steady state fail)))  increment remedial timer	≠ Mode Valve High  = Drive OR NeutShf  > 195.00  = TRUE  = slip detected  >= <b>Mode Vlv StdySt Park Dly Lim</b>  = PARK >= 450.00 ≠ diag min line action  >= <b>Mode Valve A steady state turbine speed delay</b>	park diagnostic monitor enable ETRS system configuration is internal ERTS battery voltage battery voltage time ignition inputs power mode (engine run mode OR hydraulic system pressure available)  position sensor diagnostic monitor enable  ETRS commanded direction  P18AA Test Fail This Key On P27EB Fault Active P27ED Fault Active P27EE Fault Active P18AB Test Fail This Key On P27EC Test Fail This Key On  mode valve steady state clutch slip = slip detected when: IF (commanded or attained gear C1 clutch slip speed validity) ELSE IF (range shift state active clutch control (turbine speed	= 1 Boolean  = CeTRGR_e_InternalETRS  ≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = TRUE  = TRUE  = 1 Boolean  = ETRS diagnostic range  = FALSE  = FALSE = FALSE = FALSE = FALSE  = 1 FW  = FALSE  = clutch control	Mode valve A steady state remedial delay >= <b>Mode Valve A StdySt Rmdl Lim</b>  update rate 6.25 milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OR (turbine speed) (gear slip timer) ELSE (commanded gear slip AND gear slip timer)  mode valve steady state clutch slip = no slip detected when: IF (C1 clutch slip speed validity (C1 slip (turbine pull down OR throttle position %)) ELSE IF (range shift state active clutch control (turbine speed OR turbine speed )) ELSE (commanded gear slip (turbine pull down OR (throttle position % OR engine torque))) AND gear slip timer	≠ GSCR > upper bound  < lower bound >= 0.10  >= 150.00  >= 0.10  = TRUE  < 200.00 >= 400.00  > 5.00  = clutch control ≠ GSCR < upper bound  > lower bound  < 150.00 >= 400.00  > 5.00  > 35.00  >= 0.05		
			Mode Valve A Position Sensor State	≠ Mode Valve High	park diagnostic monitor enable	= 1 Boolean		
			mode valve A pressure	> 195.00	ETRS system configuration is internal ERTS	= CeTRGR_e_InternalETR S	mode valve A transition fail count OUT OF PARK ≥ 2 counts	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			(ETRS commanded direction ETRS diagnostic range  (Mode valve A transition AND mode valve A state attained AND Mode valve A transition delay)  IF mode valve A transition FP (mode valve A fail timer  set mode valve A transition FP)  ELSE set mode valve A transition FP)  OR  ((ETRS commanded direction AND ETRS diagnostic range)  (Mode valve A transition AND mode valve A state	= Drive or NeutShf  ≠ Park  = FALSE  = FALSE  >= ModeVlvA_TrnstnDly [ETRS diagnostic range][ETRS commanded direction] (see supporting tables for specific delay associated with each shift)  = FALSE  >= <b>Mode Vlv A GS TurbDly Lim</b> = TRUE  = TRUE  = Drive, NeutShf, or NeutLo  = Park  = FALSE  = FALSE	battery voltage batyer voltage time ignition inputs power mode (engine run mode OR hydraulic system pressure available)  position sensor diagnostic monitor enable  ETRS commanded direction  ((Driver command P2812 Fault Active P2815 Fault Active P0970 Fault Active P2720 Fault Active) OR (Driver command P2814 Fault Active (P0968 Fault Active P0971 Fault Active) OR (P2718 Fault Active P2721 Fault Active)))  P18AA Test Fail This Key On P27EB Fault Active P27ED Fault Active P27EE Fault Active P18AB Test Fail This Key On P27EC Test Fail This Key On  Mode valve A state attained = TRUE when:	≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = TRUE  = TRUE  = 1 Boolean  ≠ ETRS diagnostic range  = Park = FALSE = FALSE = FALSE = FALSE  ≠ Park = FALSE = FALSE = FALSE  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE  = FALSE	update rate 6.25 milleseconds	



# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>attained AND Mode valve A transition delay)</p> <p>IF mode valve A transition FP (park servo AND mode valve A fail timer set mode valve A transition FP)</p> <p>ELSE set mode valve A transition FP</p> <p>IF mode valve A transition FP (increment fail counter)</p>	<p>&gt;= ModeVlvA_TrnstnDly [ETRS diagnostic range][ETRS commanded direction] (see supporting tables for specific delay associated with each shift)</p> <p>= FALSE = PARK</p> <p>&gt;= <b>Mode Vlv A GS TurbDly Lim</b> = TRUE</p> <p>=TRUE</p> <p>= TRUE</p>	<p>Mode valve A sensor position Mode valve A sensor position (mode valve A transition OR <b>Mode Valve A Trnstn State</b> ) Mode valve A transition = TRUE when: Mode valve A sensor position</p>	<p>= mode valve A command = <b>Mode Valve A Final State</b> = TRUE = <b>Mode Valve A Final State</b> = <b>Mode Valve A Trnstn State</b></p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Control Valve B Stuck On	P18AC	This diagnostic monitor detects a Mode Valve B Position Sensor State in the "on" or "high" state, which is in error, when hydraulic pressure in the circuit used to move the mode valve is not sufficient to overcome the mode valve return spring force, leaving the mode valve mechanically in the "off" or "low" state.	Mode Valve B Position Sensor State  mode valve B pressure (ETRS commanded direction)  When: clutch slip OR Mode valve B steady state delay  park servo Mode valve B steady state fail time)  increment mode valve B remedial timer	≠ Mode Valve Low  < 25.00  = Drive, NeutLo, or Park  = slip detected  >= <b>Mode Vlv StdySt Park Dly Lim</b> = OUT OF PARK >= <b>Mode Valve B steady state turbine speed delay limit</b>	park diagnostic monitor enable ETRS system configuration is internal ETRS battery voltage battery voltage time ignition inputs power mode (engine run mode OR hydraulic system pressure available)  position sensor diagnostic monitor enable  ETRS commanded direction  P18AC Test Fail This Key On P18AD Test Fail This Key On P27EF Fault Active P27F1 Fault Active P27F2 Fault Active P27F0 Test Fail This Key On  mode valve steady state clutch slip = slip detected when: IF (commanded or attained gear C1 clutch slip speed validity) ELSE IF (range shift state active clutch control (turbine speed	= 1 Boolean  = CeTRGR_e_InternalETRS  ≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = TRUE  = TRUE  = 1.00 Boolean  = ETRS diagnostic range  = FALSE  = FALSE  = FALSE = FALSE = FALSE = FALSE  = 1 FW  = FALSE  = clutch control	mode valve B remedial time ≥ <b>Mode Valve B StdySt Rmdl Lim</b> update rate 6.25 milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OR (turbine speed) (gear slip timer) ELSE (commanded gear slip AND gear slip timer)  mode valve steady state clutch slip = no slip detected when: IF (C1 clutch slip speed validity (C1 slip (turbine pull down OR throttle position %)) ELSE IF (range shift state active clutch control (turbine speed OR turbine speed )) ELSE (commanded gear slip (turbine pull down OR (throttle position % OR engine torque))) AND gear slip timer	≠ GSCR > upper bound  < lower bound >= 0.10  >= 150.00  >= 0.10  = TRUE  < 200.00 >= 400.00  > 5.00  = clutch control ≠ GSCR < upper bound  > lower bound  < 150.00 >= 400.00  > 5.00  > 35.00  >= 0.05		
			Mode Valve B Position Sensor State	≠ Mode Valve Low	park diagnostic monitor enable	= 1 Boolean	When: ((Park is commanded AND fail count >=	
			mode valve B pressure	< 25.00	ETRS system configuration is internal	=		

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			(((ETRS commanded direction OR (ETRS commanded direction AND ETRS diagnostic range) OR (ETRS commanded direction AND ETRS diagnostic range AND mode enable valve stuck on test)  (mode valve B transition AND mode valve B state attained AND mode valve B transition delay timer)  IF mode valve B transition FP (mode valve B fail timer  set mode valve B transition FP)  ELSE set mode valve B transition FP)	= Drive  = NeutLo  ≠ Park or Drive  = Park  ≠ Drive or NeutLo  = FALSE  = FALSE  = FALSE  >= ModeVlvB_TrnstnDly [ETRS diagnostic range][ETRS commanded direction] (see supporting tables for specific delay associated with each shift)  IF mode valve B transition FP (mode valve B fail timer  set mode valve B transition FP)  ELSE set mode valve B transition FP)	ERTS  battery voltage battery voltage time ignition inputs power mode (engine run mode OR hydraulic system pressure available)  position sensor diagnostic monitor enable  ETRS commanded direction  ((Driver command P2812 Fault Active P2815 Fault Active P0970 Fault Active P2720 Fault Active) OR (Driver command P2814 Fault Active (P0968 Fault Active P0971 Fault Active) OR (P2718 Fault Active P2721 Fault Active)))  P18AC Test Fail This Key On P18AD Test Fail This Key On P27EF Fault Active P27F1 Fault Active P27F2 Fault Active P27F0 Test Fail This Key On  Mode valve B state	CeTRGR_e_InternalETRS  ≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = TRUE  = TRUE  = 1.00 Boolean  ≠ ETRS diagnostic range  = Park = FALSE = FALSE = FALSE = FALSE  ≠ Park = FALSE = FALSE = FALSE  = FALSE = FALSE  = FALSE = FALSE = FALSE = FALSE	2.00 ) OR (Park is not commanded AND fail count >= 2.00 ))transition fail ≥  update rate 6.25 milleseconds	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR  ((ETRS commanded direction AND ETRS diagnostic range) OR (ETRS commanded direction AND ETRS diagnostic range AND mode enable valve stuck on test)  Mode valve B transition AND mode valve B state attained AND mode valve B final delay)  set mode valve B final FP)  IF mode valve B transition FP OR mode valve A final FP (Increment fail count AND reset delay and fail timers)	= NeutLo  = Park  = Park or NeutLo  = Drive  = FALSE  = TRUE  = FALSE  >= ModeVlvB_FnlDly [ETRS diagnostic range][ETRS commanded direction] (see supporting tables for specific delay associated with each shift) = TRUE  = TRUE  = TRUE	attained = TRUE when: Mode valve B sensor position Mode valve B sensor position  (mode valve B transition OR <b>Mode Valve B Trnsth State</b>  Mode valve B transition = TRUE when: Mode valve B sensor position	= mode valve B command  = <b>Mode Valve B Final State</b> = TRUE  = <b>Mode Valve B Final State</b>  = <b>Mode Valve B Trnsth State</b>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Mode Valve B Position Sensor State  IF (max line pressure) Mode valve B engine off transition delay  ELSE mode valve B engine off transition	≠ Mode Valve Low  >= <b>Mode Valve B Eng Off Dly Lim</b>  >= <b>Mode Valve B Eng Off ML Lim</b>	park diagnostic monitor enable ETRS system configuration is internal ERTS  battery voltage batyer voltage time ignition inputs power mode engine run mode AND (hydraulic system pressure available OR auto stop active)  GF9 engine off diagnsotic enable P18AC Test Fail This Key On P27EF Fault Active P27F1 Fault Active P27F2 Fault Active	= 1 Boolean  = CeTRGR_e_InternalETRS S  ≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = FALSE  = FALSE  = TRUE  = 1 Boolean  = FALSE  = FALSE  = FALSE = FALSE = FALSE	IF (max line pressure = FALSE) Mode valve A fail timer >= <b>Mode Valve B Eng Off Dly Lim</b>  ELSE mode valve B fault timer >= <b>Mode Valve B Eng Off ML Lim</b>  update rate 6.25 milleseconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Control Valve B Stuck Off	P18AD	This diagnostic monitor detects a Mode Valve B Position Sensor State in the "off" or "low" state, which is in error, when hydraulic pressure in the circuit used to move the mode valve is sufficient to overcome the mode valve return spring force, leaving the mode valve mechanically in the "on" or "high" state. The diagnostic monitor also executes during transitions of the mode valve to verify Mode Valve B Position Sensor State changes correctly with mode valve state command.	Mode Valve B Position Sensor State AND mode valve B pressure AND (ETRS commanded direction AND clutch slip OR (mode valve B steady state delay AND (park servo line pressure line pressure use) OR mode valve B steady state fail))  OR  (ETRS commanded direction AND mode valve B steady state delay AND ((park servo line pressure line pressure use) OR mode valve B steady state fail)))  increment mode valve B steady state remedial timer	≠ Mode Valve High  ≥ 295.00  = Reverse  = slip detected  ≥ <b>Mode Vlv StdySt Park Dly Lim</b> = Park ≥ 450.00 ≠ diag min line action  ≥ <b>Mode Valve B steady state turbine speed delay limit</b>  = NeutHi or NeutShf  ≥ <b>Mode Vlv StdySt Park Dly Lim</b> = Park ≥ 450.00 ≠ diag min line action  ≥ <b>Mode Valve B steady state turbine speed delay limit</b>	park diagnostic monitor enable ETRS system configuration is internal ERTS  battery voltage battery voltage time ignition inputs power mode (engine run mode OR hydraulic system pressure available)  engine auto stop active  position sensor diagnostic monitor enable  ETRS commanded direction  P18AC Test Fail This Key On P18AD Test Fail This Key On P27EF Fault Active P27F1 Fault Active P27F2 Fault Active P27F0 Test Fail This Key On  mode valve steady state clutch slip = slip detected when: IF (commanded or attained gear C1 clutch slip speed validity) ELSE IF	= 1 Boolean  = CeTRGR_e_InternalETRS  ≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = TRUE  = TRUE  = FALSE  = 1 Boolean  = ETRS diagnostic range  = FALSE = FALSE = FALSE = FALSE = FALSE  = 1 FW  = FALSE	mode valve B steady state remedial time ≥ <b>Mode Valve B StdySt Rmdl Lim</b>  update rate 6.25 milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(range shift state active clutch control (turbine speed OR turbine speed) gear slip timer) ELSE (commanded gear slip AND gear slip timer)  mode valve steady state clutch slip = no slip detected when: IF (C1 clutch slip speed validity (C1 slip (turbine pull down OR throttle position %)) ELSE IF (range shift state active clutch control (turbine speed OR turbine speed )) ELSE (commanded gear slip (turbine pull down OR (throttle position % OR engine torque))) AND gear slip timer	= clutch control ≠ GSCR > upper bound  < lower bound ≥ 0.10  ≥ 150.00  ≥ 0.10  = TRUE  < 150.00 ≥ 400.00  > 5.00  = clutch control ≠ GSCR < upper bound  > lower bound  < 150.00 ≥ 400.00  > 5.00  > 35.00  ≥ 0.05		
			Mode Valve B Position Sensor State	≠ Mode Valve High	park diagnostic monitor enable	= 1 Boolean	mode valve B fail count PARK ≥ 2	



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Mode Valve B pressure  (((ETRS commanded direction AND ETRS diagnostic range)  (mode valve B transition AND mode valve B state attained AND mode valve B transition delay timer)  IF mode valve B transition FP (park servo AND mode valve B fail timer  set mode valve B transition FP)  ELSE set mode valve B transition FP)  OR  ((ETRS commanded direction	>= 295.00  = Reverse, NeutHi, NeutLo, or NeutShf  = Park  = FALSE  = FALSE  >= ModeVlvB_TrnstrnDly [ETRS diagnostic range][ETRS commanded direction] (see supporting tables for specific delay associated with each shift)  = FALSE  = PARK  >= <b>Mode Valve B garage shift turbine speed delay limit</b> = TRUE  = TRUE  = Reverse, NeutHi,	ETRS system configuration is internal ERTS  battery voltage batyer voltage time ignition inputs power mode (engine run mode OR hydraulic system pressure available)  engine auto stop active  position sensor diagnostic monitor enable  ETRS commanded direction  ((Driver command P2812 Fault Active P2815 Fault Active P0970 Fault Active P2720 Fault Active) OR (Driver command P2814 Fault Active (P0968 Fault Active P0971 Fault Active) OR (P2718 Fault Active P2721 Fault Active)))  P18AC Test Fail This Key On P18AD Test Fail This Key On P27EF Fault Active P27F1 Fault Active P27F2 Fault Active	= CeTRGR_e_InternalETR S  ≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = TRUE  = TRUE  = FALSE  = 1 Boolean  ≠ ETRS diagnoatic range  = Park = FALSE = FALSE = FALSE = FALSE  ≠ Park = FALSE = FALSE = FALSE = FALSE  = FALSE = FALSE  = FALSE = FALSE = FALSE	counts  mode valve B fail count OUT OF PARK ≥ 2 counts  update rate 6.25 milleseconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>AND ETRS diagnostic range)</p> <p>(mode valve B transition AND mode valve B state attained AND mode valve B transition delay timer)</p> <p>IF mode valve B transition FP (mode valve B fail timer</p> <p>set mode valve B transition FP)</p> <p>ELSE set mode valve B transition FP)))</p> <p>Increment mode valve B fail counter</p>	<p>NeutLo, or NeutShf</p> <p>≠ Park</p> <p>= FALSE</p> <p>= FALSE</p> <p>&gt;=</p> <p>ModeVlvB_TrnstnDly [ETRS diagnostic range][ETRS commanded direction] (see supporting tables for specific delay associated with each shift)</p> <p>= FALSE</p> <p>&gt;=</p> <p><b>Mode Valve B garage shift turbine speed delay limit</b></p> <p>= TRUE</p> <p>= TRUE</p>	<p>P27F0 Test Fail This Key On</p> <p>Mode valve B state attained = TRUE when: Mode valve B sensor position Mode valve B sensor position</p> <p>(mode valve B transition OR <b>Mode Valve B Trnstn State</b></p> <p>Mode valve B transition = TRUE when: Mode valve B sensor position</p>	<p>= FALSE</p> <p>= mode valve B command</p> <p>=</p> <p><b>Mode Valve B Final State</b></p> <p>= TRUE</p> <p>=</p> <p><b>Mode Valve B Final State</b></p> <p>=</p> <p><b>Mode Valve B Trnstn State</b></p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Control Enable Valve Stuck On	P18AE	This diagnostic monitor detects the Mode Valve A Solenoid stuck in the hydraulic on state.	Mode valve position sensor A  mode enable valve stuck on delay timer  increment fail counter	≠ Mode valve low  ≥ <b>Mode valve fail delay limit</b>	park diagnostic monitor enable ETRS system configuration is internal ERTS  battery voltage battery voltage time ignition inputs power mode (engine run mode OR hydraulic system pressure available)  engine auto stop active  mode valve performance diagnostic monitor enable  ETRS command direction ETRS range mode enable valve stuck on diagnostic enable transmission fluid temperature transmission fluid temperature  P18AE Test Fail This Key On P2812 Fault Active P2815 Fault Active P0962 Fault Active P2738 Fault Active P0797 Fault Active P2715 Fault Active P18AA Fault Active P18AB Fault Active P27EC Fault Active P27EB Fault Active	= 1 Boolean  = CeTRGR_e_InternalETRS  ≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = TRUE OR = TRUE  = FALSE  = 1 Boolean  = PARK = DRIVE = 1 Boolean  ≥ 0.00 °C ≤ 256.0 °C  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE	mode enable valve fail count ≥ 2 counts  update rate 6.25 milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P27ED Fault Active P27EE Fault Active mode valve A init hi mode valve A sensor FP mode valve B sensor FP	= FALSE = FALSE = FALSE = FALSE = FALSE		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Valve Position Sensor/ Switch "A" Performance	P18E7	This diagnostic monitor detects park valve position sensor A performance faults, the sensor is indicating not park when command is park, or sensor does not transition when park is not commanded.	<p>(ETRS commanded direction diagnostic park state (Park position sensor A Park position sensor B P187D Test Fail This Key On P187E Test Fail This Key On Park servo FP Park servo stuck off fail timer)</p> <p>OR</p> <p>(ETRS commanded direction diagnostic park state Park position sensor A Park position sensor B)</p> <p>OR</p> <p>(ETRS commanded direction diagnostic park state Park position sensor A Park position sensor B)</p> <p>OR</p> <p>(park position sensor A delay AND park position sensor fail timer)</p> <p>set park position sensor A FP increment park position sensor A fail counter</p>	<p>= PARK</p> <p>= PARK</p> <p>≠ PARK</p> <p>= PARK</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= 0</p> <p>≠ PARK</p> <p>= OUT OF PARK</p> <p>≠ OUT OF PARK</p> <p>= OUT OF PARK</p> <p>≠ PARK</p> <p>= PARK</p> <p>≠ OUT OF PARK</p> <p>= PARK</p> <p>&gt;=</p> <p><b>Park Position Sensor A Dly Lim</b></p> <p>&gt;= 0.25</p> <p>= TRUE</p>	<p>PARK diagnostic monitor enable ETRS system configuration is internal ERTS</p> <p>battery voltage battery voltage time ignition inputs power mode (engine run mode OR hydraulic system pressure available)</p> <p>engine auto stop active</p> <p>park valve position sensor performance diagnostic monitor enable</p> <p>P17E7 fault active P17F5 fault active P17F6 fault active P17FC fault active P17FA fault active P17FB fault active P18E7 Test Fail This Key On Park position sensor A FP Park position sensor B FP P18E7 test Fail This Key On P18E8 Test Fail This Key On</p>	<p>= 1 Boolean</p> <p>= CeTRGR_e_InternalETRS</p> <p>≥ 9.00 volts</p> <p>≥ 1.00 seconds</p> <p>≠ power mode off</p> <p>= TRUE</p> <p>= TRUE</p> <p>= FALSE</p> <p>= 1 Boolean</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p>	<p>park valve position sensor A fail count ≥ 2 counts</p> <p>update rate 6.25 milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			(ETRS commanded direction diagnostic park state Park position sensor A Park position sensor B)  (park position sensor A delay AND park position sensor fail timer)  set park position sensor A FP increment park position sensor A fail counter	≠ PARK  = OUT OF PARK ≠ OUT Of PARK = OUT OF PARK  >= <b>Park Position Sensor A Dly Lim</b> >= 0.25  = TRUE	PARK diagnostic monitor enable ETRS system configuration is internal ERTS  battery voltage battery voltage time ignition inputs power mode engine run mode (hydraulic system pressure available OR engine auto stop active)  Engine off diagnostics enable  P17E7 fault active P17F5 fault active P17F6 fault active P17FC fault active P17FA fault active P17FB fault active P18E7 Test Fail This Key On Park positin sensor A FP Park position sensor B FP P18E7 test Fail This Key On P18E8 Test Fail This Key On	= 1 Boolean  = CeTRGR_e_InternalETRS  ≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = FALSE = FALSE  = TRUE = 1.00 Boolean  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE	park valve position sensor A fail count ≥ 2 counts  update rate 6.25 milliseconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Park Valve Position Sensor/ Switch "B" Performance	P18E8	This diagnostic monitor detects park valve position sensor B performance faults, the sensor is indicating not park when command is park, or sensor does not transition when park is not commanded.	(ETRS commanded direction diagnostic park state (Park position sensor A Park position sensor B)  OR (ETRS commanded direction diagnostic park state Park position sensor A Park position sensor B)  OR (ETRS commanded direction diagnostic park state Park position sensor A Park position sensor B)  Park position sensor B delay timer AND park position sensor fail timer  Set park position sensor B FP AND increment park position sensor fail count	= PARK  = PARK = PARK ≠ PARK  ≠ PARK  = OUT OF PARK = OUT OF PARK ≠ OUT OF PARK  = PARK = OUT OF PARK = PARK ≠ PARK  >= <b>Park Position Sensor B Dly Lim</b> >= 0.25  = TRUE	PARK diagnostic monitor enable ETRS system configuration is internal ERTS  battery voltage batyer voltage time ignition inputs power mode (engine run mode OR hydraulic system pressure available)  engine auto stop active  park valve position sensor performance diagnostic monitor enable  park state transtion P17E7 fault active P17F5 fault active P17F6 fault active P17FC fault active P17FA fault active P17FB fault active Park position sensor A FP Park position sensor B FP P18E7 Test Fail This Key On P18E8 Test Fail this Key On	= 1 Boolean  = CeTRGR_e_InternalETRS  ≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = TRUE  = TRUE  = FALSE  = 1 Boolean  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE	park valve position sensor B fail count ≥ 2 counts  update rate 6.25 milliseconds	Type A, 1 Trips
			(ETRS commanded direction diagnostic park state Park position sensor A Park position sensor B)	≠ PARK  = OUT OF PARK = OUT OF PARK ≠ OUT OF PARK	PARK diagnostic monitor enable  ETRS system configuration is internal ERTS	= 1 Boolean  = CeTRGR_e_InternalETRS	park valve position sensor B fail count ≥ 2 counts  update rate 6.25	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Park position sensor B delay timer AND park position sensor fail timer  Set park position sensor B FP AND increment park position sensor fail count	>= <b>Park Postition Sensor B Dly Lim</b> >= 0.25  = TRUE	battery voltage batyer voltage time ignition inputs power mode engine run mode (hydraulic system pressure available OR engine auto stop active)  Engine off diagnostics enable  park state transtion P17E7 fault active P17F5 fault active P17F6 fault active P17FC fault active P17FA fault active P17FB fault active Park position sensor A FP Park position sensor B FP P18E7 Test Fail This Key On P18E8 Test Fail this Key On	≥ 9.00 volts ≥ 1.00 seconds ≠ power mode off  = FALSE  = FALSE  = TRUE  = 1.00 Boolean  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE	milleseconds	



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Switch Run/ Start Position Circuit Low	P2534	Detects a low ignition switch run/start position circuit. This diagnostic reports the DTC when this circuit is low. Monitoring occurs when the ECM run/crank is active.	Ignition switch Run/Start position circuit low	Run / Crank = FALSE	Ignition switch Run/Start position circuit low diag enable  and Run / Crank active ECM	= 1.00   = TRUE	280 failures out of 280 samples  25 ms / sample	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Switch Run/ Start Position Circuit High	P2535	Detects a high ignition switch run/start position circuit. This diagnostic reports the DTC when this circuit is high. Monitoring occurs when the ECM run/crank is NOT active.	Ignition switch Run/Start position circuit high	Run / Crank = TRUE	Ignition switch Run/Start position circuit low diag enable  and Run / Crank active ECM	= 1.00   = FALSE	280 failures out of 280 samples  25 ms / sample	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Switch Accessory Position Circuit Low	P2537	Detects a low ignition switch accessory position circuit. This diagnostic reports the DTC when this circuit is low. Monitoring occurs when the propulsion system has been active for a calibrated duration.	<p>The TCM detects that the state of the accessory line is low when it should be high.</p> <p>The diagnostic is evaluated when Propulsion System Active time is &gt; 32.0 seconds.</p> <p>Diagnostic fails when pass counts are</p>	< 1 counts.			<p>12.5 ms / sample</p> <p>Once per trip</p>	Type B, 2 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Actuator Supply Voltage B Circuit Low	P2670	Controller specific output driver circuit diagnoses the high sided driver circuit for a short to ground failure, or where controller H/W cannot differentiate, diagnoses the high sided driver circuit for a short to ground failure or open circuit failure, when the output is powered on, by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.</p>	$\leq \leq 0.5 \Omega$ impedance between signal and controller ground	diagnostic monitor enable high side drive 2 ON P2670 fault active P2670 test fail this key on	= 1 Boolean = TRUE = FALSE = FALSE	<p>fail count <math>\geq 6</math> counts out of sample count <math>\geq 2,400</math> counts</p> <p>6.25 millisecond update rate</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid D Stuck Off (GF9)	P2714	Each pressure control solenoid stuck off diagnostic monitor detects a clutch pressure control solenoid failed hydraulically off, while the solenoid is electrically functional. In the failure mode the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM. The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line	C4 clutch slip speed, update fail time 6.25 millisecond update	≥ 200.0 RPM	<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active</p> <p>service solenoid cleaning</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean</p>	<p>fail time ≥ 3.00 seconds, update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch pressure control solenoid is failed hydraulically off, the clutch does not maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable. The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed in the opposite sense, clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional, which must take priority over any clutch pressure control solenoid stuck off diagnostic monitor. All clutch pressure control			<p>procedure active</p> <p>hydraulic pressure available</p> <p>*****</p> <p>enable C4 clutch slip speed fail compare when:</p> <p>((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below)</p> <p>unintended deceleration fault pending OR unintended deceleration fault pending enable cal is FALSE (startle mitigation)</p> <p>clutch steady state adaptive active</p> <p>(transmission output shaft speed OR (accelerator pedal position OR engine speed)</p> <p>C4 clutch slip speed valid</p>	<p>= FALSE Boolean</p> <p>= TRUE</p> <p>*****</p> <p>= FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 (0 to enable, 1 to disable)</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 %</p> <p>≥ 1,500.0 RPM</p> <p>= TRUE (all speed sensors are functional for lever node clutch slip speed calculation)</p>	≥ 1.000 seconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck off test is disabled. This diagnostic monitor is relative to C4 GF9 clutch pressure control solenoid.			C4 clutch pressured map  (enable forward gear cal AND driver direction request AND Attained Gear) OR (enable reverse gear cal AND driver direction request AND Attained Gear)  P2821 (clutch select valve stuck on) test active  range shift state  ***** DTCs not fault pending         DTCs not fault active	= mapped to line pressure, C4 clutch pressure has reached fully applied state  = 1 (1 to enable, 0 to disable) = FORWARD = a FORWARD gear = 0 (1 to enable, 0 to disable) = REVERSE = REVERSE = FALSE = range shift complete ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>DTCs not test fail this key on</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797 P2715 P2724 P2733 P2821</p>	<p>P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p>		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid D Stuck On	P2715	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	shift type is power down shift: C4 clutch slip speed OR shift type is garage shift: C4 clutch slip speed ELSE shift is another type: C4 clutch slip speed  update fail time 6.25 milliscond update	< 50.00 RPM  < 100.00 RPM  < 50.00 RPM			Base fail time:  shift type is power down shift: fail time ≥ 0.80 seconds  shift type is garage shift: fail time ≥ 0.25  shift type is another type: fail time ≥ 0.15 seconds  Add fail time offset according to shift type:  open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b>  open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b>  garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b>  closed throttle downshift:	Type A, 1 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C4 C4, GR10 C4 C23467810R, or 8 Speed C4 C23468 clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C4 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C4 off going clutch command pressure )	= TRUE Boolean  = TRUE Boolean  = FALSE Boolean  = FALSE Boolean  = TRUE  *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350 kPa	exhaust delay by shift type:	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck	$\geq 8,192 \text{ Nm}$ $= 0$ (0 is enable, 1 is	closed throttle upshift: <b>C4 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C4 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C4 exhaust delay garage shift</b>  closed throttle downshift: <b>C4 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C4 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C4 exhaust delay open throttle power down shift</b>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

[illegible]

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>conditions needed to trigger test:</p> <p>(current shift type AND shift type enable cal for current shift type) OR</p> <p>(Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear) OR (stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))</p> <p>clutch stuck off intrusive shift active</p> <p>startle mitigation active (see note on startle mitigation below)</p> <p>(new clutch controller has been initalized</p>	<p>*****</p> <p>≠ Garage shift</p> <p><b>Clutch Stuck On Shift = Type Enable</b> (0 table value will disable, 1 will enable)</p> <p>= FALSE</p> <p>= 0 (0 will enable, 1 will enable)</p> <p>= NEUTRAL OR commanded gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= TRUE</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OR transitioning to a different clutch controller)  current clutch solenoid test state  ***** DTCs not fault pending  DTCs not fault active  DTCs not test fail this key on	= TRUE  transitions to TestState or TUT_HOLD (see note below about state transitions)  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA  P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions: Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing. AND That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold. Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the automatic transmission</p>	<p>P17C6 P17C4 P17C7 P172A P172B *****</p>		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>shift, until:  An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute.  OR  The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended vehicle deceleration</p>			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					occurred. Once a safe vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid D Control Circuit Open	P2718	Controller specific circuit diagnoses 9 speed C4, 10 speed C23467810R, 8 speed C23468 clutch, or CVT input clutch, solenoid for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates an open circuit  Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit  Increment fail time	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage  OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00 \text{ volts and } \leq 32.00 \text{ volts}$  $\geq 5.00 \text{ volts}$  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00 \text{ seconds}$  $\geq 25 \text{ milliseconds}$  $\geq 12.5 \text{ milliseconds}$	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid D Control Circuit Low	P2720	Controller specific circuit diagnoses 9 speed C4, 10 speed C23467810R, 8 speed C23468 clutch, or CVT input clutch, solenoid for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON    = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON    = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid D Control Circuit High	P2721	Controller specific circuit diagnoses 9 speed C4, 10 speed C23467810R, 8 speed C23468 clutch, or CVT input clutch, solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid E Stuck Off (GF9)	P2723	Each pressure control solenoid stuck off diagnostic monitor detects a clutch pressure control solenoid failed hydraulically off, while the solenoid is electrically functional. In the failure mode the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM. The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line	C5 clutch slip speed, update fail time 6.25 millisecond update	≥ 200.0 RPM	<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active</p> <p>service solenoid cleaning</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean</p>	<p>fail time ≥ 3.00 seconds, update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch pressure control solenoid is failed hydraulically off, the clutch does not maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable. The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed in the opposite sense, clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional, which must take priority over any clutch pressure control solenoid stuck off diagnostic monitor. All clutch pressure control			<p>procedure active</p> <p>hydraulic pressure available</p> <p>*****</p> <p>enable C5 clutch slip speed fail compare when:</p> <p>((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below)</p> <p>unintended deceleration fault pending OR unintended deceleration fault pending enable cal is FALSE (startle mitigation)</p> <p>clutch steady state adaptive active</p> <p>(transmission output shaft speed OR (accelerator pedal position OR engine speed)</p> <p>C5 clutch slip speed valid</p>	<p>= FALSE Boolean</p> <p>= TRUE</p> <p>*****</p> <p>= FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 (0 to enable, 1 to disable)</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 %</p> <p>≥ 1,500.0 RPM</p> <p>= TRUE (all speed sensors are functional for lever node clutch slip speed calculation)</p>	≥ 1.000 seconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck off test is disabled. This diagnostic monitor is relative to C5 GF9 C57R clutch pressure control solenoid.			C5 clutch pressured map  (enable forward gear cal AND driver direction request AND Attained Gear) OR (enable reverse gear cal AND driver direction request AND Attained Gear)  P2821 (clutch select valve stuck on) test active  range shift state  ***** DTCs not fault pending         DTCs not fault active	= mapped to line pressure, C5 clutch pressure has reached fully applied state  = 1 (1 to enable, 0 to disable) = FORWARD = a FORWARD gear = 0 (1 to enable, 0 to disable) = REVERSE = REVERSE = FALSE = range shift complete ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>DTCs not test fail this key on</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797 P2715 P2724 P2733 P2821</p>	<p>P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p>		

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid E Stuck On	P2724	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	shift type is power down shift: C5 clutch slip speed OR shift type is garage shift: C5 clutch slip speed ELSE shift is another type: C5 clutch slip speed  update fail time 6.25 milliscond update	< 50.00 RPM  < 100.00 RPM  < 50.00 RPM			Base fail time:  shift type is power down shift: fail time ≥ 0.40 seconds  shift type is garage shift: fail time ≥ 0.25  shift type is another type: fail time ≥ 0.15 seconds  Add fail time offset according to shift type:  open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b>  open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b>  garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b>  closed throttle downshift:	Type A, 1 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C5 C57R, GR10 C5 C1356789, or 8 Speed C5 C45678R clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C5 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C5 off going clutch command pressure )	= TRUE Boolean  = TRUE Boolean  = FALSE Boolean  = FALSE Boolean  = TRUE  *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350 kPa	exhaust delay by shift type:	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck	$\geq 8,192 \text{ Nm}$ $= 0$ (0 is enable, 1 is	closed throttle upshift: <b>C5 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C5 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C5 exhaust delay garage shift</b>  closed throttle downshift: <b>C5 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C5 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C5 exhaust delay open throttle power down shift</b>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					on torque enable cal)  OR  ( primary oncoming clutch active  primary on coming control state  primary on coming commanded pressure)	enable)   = TRUE  ≠ clutch fill phase  ≥ pressure clip threshold according to shift type:  closed throttle upshift: <b>Clutch Clip Press CU Shifts</b>  open throttle upshift: <b>Clutch Clip Press PU Shifts</b>  garage shifts: <b>Clutch Clip Press GS Shifts</b>  closed throttle downshift: <b>Clutch Clip Press CD Shifts</b>  negative torque upshift: <b>Clutch Clip Press NU Shifts</b>  open throttle downshift: <b>Clutch Clip Press PD Shifts</b>   C5 clutch slip speed valid, all speed sensors are functional for lever node clutch slip speed	absolute value of ( -0.60 ) seconds	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					calculation  ***** conditions needed to trigger test:  (current shift type AND shift type enable cal for current shift type)  OR  (Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear) OR (stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))  clutch stuck off intrusive shift active  startle mitigation active (see note on startle mitigation below)  (new clutch controller has	*****   ≠ Garage shift  <b>Clutch Stuck On Shift</b> <b>= Type Enable</b> (0 table value will disable, 1 will enable)  = FALSE  = 0 (0 will enable, 1 will enable)  = NEUTRAL OR commanded gear  = 0 (0 to disable, 1 to enable) = FORWARD  = a FORWARD gear  = 0 (0 to disable, 1 to enable) = REVERSE  = REVERSE  = FALSE  = FALSE		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>been initalized OR transitioning to a different clutch controller)</p> <p>current clutch solenoid test state</p> <p>*****</p> <p>DTCs not fault pending</p> <p>DTCs not fault active</p> <p>DTCs not test fail this key on</p>	<p>= TRUE</p> <p>= TRUE</p> <p>transitions to TestState or TUT_HOLD (see note below about state transitions)</p> <p>*****</p> <p>P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6</p> <p>P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732</p>		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions:  Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing.  AND  That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold.  Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the</p>	<p>P2821 P2820 P178F  P17C6 P17C4 P17C7  P172A P172B  *****</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>automatic transmission shift, until: An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute. OR The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended</p>			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					vehicle deceleration occurred. Once a safe vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid E Control Circuit Open	P2727	Controller specific circuit diagnoses 9 speed C57R, 10 speed C1356789, or 8 speed C45678R clutch solenoid for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates an open circuit  Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit  Increment fail time	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage  OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00 \text{ volts}$ and $\leq 32.00 \text{ volts}$  $\geq 5.00 \text{ volts}$  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid E Control Circuit Low	P2729	Controller specific circuit diagnoses 9 speed C57R, 10 speed C1356789, or 8 speed C45678R clutch solenoid for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON    = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON    = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid E Control Circuit High	P2730	Controller specific circuit diagnoses 9 speed C57R, 10 speed C1356789, or 8 speed C45678R clutch solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F (GF9)	P2731	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	<p>common logic between P2731 and P2733</p> <p>shift type is power down shift: C6 clutch slip speed OR shift type is garage shift: C6 clutch slip speed ELSE shift is another type: C6 clutch slip speed</p> <p>P2731 specific attained gear</p> <p>update fail time 6.25 millisecond update</p>	<p>&lt; 50.00 RPM</p> <p>&lt; 100.00 RPM</p> <p>&lt; 50.00 RPM</p> <p>= 1st lock OR = 1st free wheel</p>			<p>Base fail time:</p> <p>shift type is power down shift: fail time ≥ 0.80 seconds</p> <p>shift type is garage shift: fail time ≥ 0.25</p> <p>shift type is another type: fail time ≥ 0.15 seconds</p> <p>Add fail time offset according to shift type:</p> <p>open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b></p> <p>open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b></p> <p>garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b></p> <p>closed throttle downshift:</p>	Type A, 1 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C6 Selectable One Way Clutch (SOWC) / CBR1 clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C6 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C6 off going clutch command pressure )	= TRUE Boolean  = TRUE Boolean  = FALSE Boolean  = FALSE Boolean  = TRUE  *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350 kPa	exhaust delay by shift type:	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck on torque enable cal)	≥ 8,192 Nm  = 0 (0 is enable, 1 is enable)	closed throttle upshift: <b>C6 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C6 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C6 exhaust delay garage shift</b>  closed throttle downshift: <b>C6 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C6 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C6 exhaust delay open throttle power down shift</b>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

[illegible]

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>conditions needed to trigger test:</p> <p>(current shift type AND shift type enable cal for current shift type) OR</p> <p>(Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear) OR (stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))</p> <p>clutch stuck off intrusive shift active</p> <p>startle mitigation active (see note on startle mitigation below)</p> <p>(new clutch controller has been initialized</p>	<p>*****</p> <p>≠ Garage shift</p> <p><b>Clutch Stuck On Shift = Type Enable</b> (0 table value will disable, 1 will enable)</p> <p>= FALSE</p> <p>= 0 (0 will enable, 1 will enable)</p> <p>= NEUTRAL OR commanded gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= TRUE</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OR transitioning to a different clutch controller)  current clutch solenoid test state  ***** DTCs not fault pending  DTCs not fault active  DTCs not test fail this key on	= TRUE  transitions to TestState or TUT_HOLD (see note below about state transitions)  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA  P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions:            Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing.            AND            That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold.            Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the automatic transmission</p>	<p>P17C6 P17C4 P17C7 P172A P172B *****</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>shift, until:  An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute.  OR  The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended vehicle deceleration</p>			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					occurred. Once a safe vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F Stuck Off (GF9)	P2732	Each pressure control solenoid stuck off diagnostic monitor detects a clutch pressure control solenoid failed hydraulically off, while the solenoid is electrically functional. In the failure mode the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM. The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line	C6 clutch slip speed, update fail time 6.25 millisecond update	≥ 200.0 RPM	<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active</p> <p>service solenoid cleaning</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean</p>	<p>fail time ≥ 3.00 seconds, update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch pressure control solenoid is failed hydraulically off, the clutch does not maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable. The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed in the opposite sense, clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional, which must take priority over any clutch pressure control solenoid stuck off diagnostic monitor. All clutch pressure control			<p>procedure active</p> <p>hydraulic pressure available</p> <p>*****</p> <p>enable C6 clutch slip speed fail compare when:</p> <p>((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below)</p> <p>unintended deceleration fault pending OR unintended deceleration fault pending enable cal is FALSE (startle mitigation)</p> <p>clutch steady state adaptive active</p> <p>(transmission output shaft speed OR (accelerator pedal position OR engine speed)</p> <p>C6 clutch slip speed valid</p>	<p>= FALSE Boolean</p> <p>= TRUE</p> <p>*****</p> <p>= FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 (0 to enable, 1 to disable)</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 %</p> <p>≥ 1,500.0 RPM</p> <p>= TRUE (all speed sensors are functional for lever node clutch slip speed calculation)</p>	≥ 1.000 seconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck off test is disabled. This diagnostic monitor is relative to GF9 C6 C6789/Selectable One Way Clutch (SOWC) CBR1 clutch pressure control solenoid.			C6 clutch pressured map  (enable forward gear cal AND driver direction request AND Attained Gear) OR (enable reverse gear cal AND driver direction request AND Attained Gear)  P2821 (clutch select valve stuck on) test active  range shift state  ***** DTCs not fault pending          DTCs not fault active	= mapped to line pressure, C6 clutch pressure has reached fully applied state  = 1 (1 to enable, 0 to disable) = FORWARD = a FORWARD gear = 0 (1 to enable, 0 to disable) = REVERSE = REVERSE = FALSE = range shift complete ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>DTCs not test fail this key on</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797 P2715 P2724 P2733 P2821</p>	<p>P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA</p> <p>P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F Stuck On (GF9 and GR10)	P2733	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch pressure control solenoid is tested during an automatic transmission shift by monitoring the off going clutch slip speed. With the clutch pressure control solenoid failed on, still allowing hydraulic pressure to the clutch being commanded off, the intended off going clutch continues to maintain torque capacity during the transmission automatic shift. In the failure mode, the off going clutch slip speed will remain near zero RPM when the clutch pressure control solenoid is commanded to an off pressure in the normal operation to release the holding clutch. The clutch slip speed is calculated based on the transmission lever node design, requiring	common logic between P2731 and P2733  shift type is power down shift: C6 clutch slip speed OR shift type is garage shift: C6 clutch slip speed ELSE shift is another type: C6 clutch slip speed  P2733 specific attained gear  update fail time  6.25 millisecond update	< 50.00 RPM  < 100.00 RPM  < 50.00 RPM  ≠ 1st lock AND ≠ 1st free wheel			Base fail time:  shift type is power down shift: fail time ≥ 0.80 seconds  shift type is garage shift: fail time ≥ 0.25  shift type is another type: fail time ≥ 0.15 seconds  Add fail time offset according to shift type:  open throttle upshift: <b>Clutch Stuck On Fail Offset Time PU Shifts</b>  open throttle downshift: <b>Clutch Stuck On Fail Offset Time PD Shifts</b>  garage shift: <b>Clutch Stuck On Fail Offset Time GS Shifts</b>  closed throttle downshift:	Type A, 1 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. As part of the pressure control solenoid stuck on diagnostic monitor, the safety startle mitigation function executes when in steady state gear, no automatic transmission shift in progress. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional. All clutch pressure control solenoid stuck on diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the clutch pressure control solenoid stuck on test			<p>*****</p> <p>system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage)</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p>	<p><b>Clutch Stuck On Fail Offset Time CD Shifts</b></p> <p>negative torque upshift: <b>Clutch Clip Press NU Shifts</b></p> <p>clutch staging shift: <b>Clutch Stuck On Fail Offset Time STGR Shifts</b></p> <p>update fail count, fail count ≥ 3 counts 6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		is disabled. This diagnostic monitor is relative to the GF9 C6 C6789 or GR10 C6 C45678910R clutch pressure control solenoid.			TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active  service solenoid cleaning procedure active  hydraulic pressure available  *****  range shift state  diagnostic clutch test  transmission output shaft speed  ((C6 off going clutch pressure control ramp time out complete AND off going clutch pressure ramp control ramp time out enable)  OR  C6 off going clutch command pressure )	= TRUE Boolean          = TRUE Boolean          = FALSE Boolean          = FALSE Boolean          = TRUE          *****  ≠ range shift complete  = OFF GOING CLUTCH TEST  ≥ 89.0 RPM  = TRUE  = 1 ( 1 to enable, 0 to disable)  ≤ 350 kPa	exhaust delay by shift type:	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					(engine torque AND Primary oncoming stuck on torque enable cal)	≥ 8,192 Nm  = 0 (0 is enable, 1 is enable)	closed throttle upshift: <b>C6 exhaust delay closed throttle lift foot up shift</b>  open throttle upshift: <b>C6 exhaust delay open throttle power on up shift</b>  garage shifts: <b>C6 exhaust delay garage shift</b>  closed throttle downshift: <b>C6 exhaust delay closed throttle down shift</b>  negative torque upshift: <b>C6 exhaust delay negative torque up shift</b>  open throttle downshift: <b>C6 exhaust delay open throttle power down shift</b>	



# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OR  ( primary oncoming clutch active  primary on coming control state  primary on coming commanded pressure)	= TRUE  ≠ clutch fill phase  ≥ pressure clip threshold according to shift type:  closed throttle upshift: <b>Clutch Clip Press CU Shifts</b>  open throttle upshift: <b>Clutch Clip Press PU Shifts</b>  garage shifts: <b>Clutch Clip Press GS Shifts</b>  closed throttle downshift: <b>Clutch Clip Press CD Shifts</b>  negative torque upshift: <b>Clutch Clip Press NU Shifts</b>  open throttle downshift: <b>Clutch Clip Press PD Shifts</b>   = TRUE	absolute value of ( -0.60 ) seconds	
					C5 clutch slip speed valid, all speed sensors are functional for lever node clutch slip speed calculation			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>conditions needed to trigger test:</p> <p>(current shift type AND shift type enable cal for current shift type) OR</p> <p>(Intrusive shift active AND shift type enable cal for garage shift AND Attained Gear AND (stuck on enable cal for forward garge shifts AND driver requested direction AND commanded gear) OR (stuck on enable cal for reverse garage shifts AND driver requested direction AND commanded gear))</p> <p>clutch stuck off intrusive shift active</p> <p>startle mitigation active (see note on startle mitigation below)</p> <p>(new clutch controller has been initialized</p>	<p>*****</p> <p>≠ Garage shift</p> <p><b>Clutch Stuck On Shift = Type Enable</b> (0 table value will disable, 1 will enable)</p> <p>= FALSE</p> <p>= 0 (0 will enable, 1 will enable)</p> <p>= NEUTRAL OR commanded gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= FORWARD</p> <p>= a FORWARD gear</p> <p>= 0 (0 to disable, 1 to enable)</p> <p>= REVERSE</p> <p>= REVERSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= TRUE</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					OR transitioning to a different clutch controller)  current clutch solenoid test state  ***** DTCs not fault pending  DTCs not fault active  DTCs not test fail this key on	= TRUE  transitions to TestState or TUT_HOLD (see note below about state transitions)  ***** P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6  P2534 P0707 P0708 P0716 P0717 P07C0 P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA  P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>*****</p> <p>NOTE: Clutch control solenoid test state TIE UP TEST HOLD is necessary, as it is possible to have multiple off going clutches during one automatic transmission shift. Clutch control solenoid test state is set to TIE UP TEST HOLD during an automatic transmission shift due to two conditions:  Current value of clutch control solenoid test state is TIE UP TEST TEST STATE, when one off going clutch pressure control solenoid stuck on diagnostic monitor is currently executing.  AND  That off going clutch pressure control solenoid stuck on diagnostic monitor currently executing passes, the corresponding clutch slip speed <math>\geq</math> clutch slip speed fail threshold.  Once clutch control solenoid test state is set to TIE UP TEST HOLD, it remains TIE UP TEST HOLD during the automatic transmission</p>	<p>P17C6 P17C4 P17C7 P172A P172B *****</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>shift, until:  An additional off going clutch occurs, as indicated by solenoid stuck on test trigger = TRUE, subsequently clutch control solenoid test state is reset to TIE UP TEST TEST STATE, to allow the additional corresponding off going clutch pressure control solenoid stuck on diagnostic monitor to execute.  OR  The automatic transmission shift completes, range shift state = range shift complete.</p> <p>NOTE: Startle mitigation is used to detect unintended vehicle deceleration due to a clutch pressure control solenoid stuck on failure mode that occurs during steady state gear, not during an automatic transmission shift. The startle mitigation active then forces the transmission clutch pressure control system to a safe gear or neutral state, based on the active and inactive clutches, when the unintended vehicle deceleration</p>			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					occurred. Once a safe vehicle gear state is attained, the gear and clutch pressure control system allows transitions of the clutches on and off, to sequence automatic transmission shifts, single step shifts. As each single step automatic transmission shift occurs the normal pressure control solenoid stuck on diagnostic monitors execute to verify which clutch pressure control solenoid is in the stuck on failure mode, allowing one of the clutch pressure control solenoid stuck on DTCs to set P0747, P0777, P0797, P2715, P2724, P2733, P2821.			

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F Control Circuit Open	P2736	Controller specific circuit diagnoses 9 speed (C6789/SOWC CBR1) clutch, 10 speed C45678910R clutch, 8 speed Line Pressure Control Circuit, or CVT binary pump, solenoid for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates an open circuit</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit</p> <p>Increment fail time</p>	≥ 200 K Ω impedance between signal and controller ground	<p>battery voltage</p> <p>(run crank voltage</p> <p>OR</p> <p>accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p>≥ 9.00 volts and ≤ 32.00 volts</p> <p>≥ 5.00 volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON</p>	<p>fail time ≥ 0.30 seconds out of sample time ≥ 0.50 seconds</p> <p>≥ 1.00 seconds</p> <p>≥ 25 milliseconds</p> <p>≥ 12.5 milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F Control Circuit Low	P2738	Controller specific circuit diagnoses 9 speed (C6789/SOWC CBR1, 10 speed C45678910R clutch, 8 speed line pressure control, or CVT binary pump, solenoid for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a ground short</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller ground	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F Control Circuit High	P2739	Controller specific circuit diagnoses 9 speed (C6789/SOWC CBR1), 10 speed C45678910R clutch, 8 speed line pressure control, or CVT binary pump, solenoid for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a ground short</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller ground	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.000</math> seconds</p> <p>25 milliseconds</p> <p>12.5 milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid A Calibration Incorrect	P27A7	The diagnostic monitor verifies that the pressure control solenoid A (GF9 line or GR10 C1 C123456R clutch or CVT secondary pulley) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid A electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid B Calibration Incorrect	P27A8	The diagnostic monitor verifies that the pressure control solenoid B (GF9 TCC or GR10 C2 C128910R clutch or CVT primary pulley) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid B electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power event during the controller initialization before normal time loop execution	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid C Calibration Incorrect	P27A9	The diagnostic monitor verifies that the pressure control solenoid C (GF9 C1 CB123456 clutch or GR10 C3 C23457910 clutch or CVT line) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid C electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid D Calibration Incorrect	P27AA	The diagnostic monitor verifies that the pressure control solenoid D (GF9 C2 CB29 clutch or GR10 C5 C1356789 clutch pressure or CVT C1 clutch) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid D electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid E Calibration Incorrect	P27AB	The diagnostic monitor verifies that the pressure control solenoid E (GF9 C3 CB38 clutch or GR10 C4 C23467810R clutch or CVT TCC) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid E electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid F Calibration Incorrect	P27AC	The diagnostic monitor verifies that the pressure control solenoid F (GF9 C4 C4 clutch or GR10 C6 C45678910R clutch or CVT binary pump) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid F electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid G Calibration Incorrect	P27AD	The diagnostic monitor verifies that the pressure control solenoid G (GF9 C5 C57R clutch or GR10 line or CVT mode valve A ETRS only) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid G electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid H Calibration Incorrect	P27AE	The diagnostic monitor verifies that the pressure control solenoid H (GF9 C6 C6789 clutch or GR10 TCC or CVT mode valve B ETRS only) characterization data is programmed correctly into the TCM EEPROM to match the pressure control solenoid H electrical characteristics of the device currently installed in the transmission valve body assembly.	<p>pressure control solenoid characterization data programming complete</p> <p>Matching is defined as pressure control solenoid characterization data corresponding to the transmission valve body assembly componentry.</p> <p>pressure control solenoid characterization data programming complete is set to FALSE when any of the following is present:</p> <p>Solenoid data is not programmed or incomplete data fault - occurs when a new or service TCM is installed. OR Solenoid class programming fault – the characterization data indicates a different type of device than the TCM calibration data OR Checksum mismatch – the checksum that was calculated from the programmed pressure control solenoid characterization data region does not match the calculated valve at the time of programming. OR Axis data fault – pressure</p>	= FALSE	<p>Pressure control solenoid characterization data is programmed originally at vehicle plant assembly based on transmission valve body assembly part number associated to the unit installed in vehicle.</p> <p>When valve body is serviced, dealership performs reprogramming of TCM with pressure control solenoid characterization data based on the associated transmission valve body part number installed.</p>		execution of monitor occurs once per controller normal power up event during the controller initialization before normal controller time loop execution	Type A, 1 Trips



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			control solenoid characterization data has one or more points that are less than the previous match point, axis data must be greater than or equal to previous data values.					

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Control A Position Sensor/Switch Circuit/Open	P27EB	The diagnostic monitor detects an illegal voltage on the mode valve A position sensor circuit.	raw sensor voltage raw sensor voltage	> 1.263 volts < 1.504 volts	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is hall sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	0.100 seconds in 0.163 second sample  6.25 millisecond update rate	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Control A Position Sensor/Switch Circuit Range/Performance	P27EC	Sensor signal fails to transition when solenoid mode valve control commands to PARK, DRIVE or REVERSE occur.	<p>Mode valve A position sensor</p> <p>mode valve A steady state delay</p> <p>line pressure line pressure action</p> <p>(ETRS commanded direction park servo)</p> <p>OR</p> <p>(ETRS commanded direction park servo)</p> <p>OR</p> <p>((ETRS commanded direction park servo)</p> <p>mode valve A fail timer</p> <p>clutch slip)</p> <p>set sensor fault to TRUE</p>	<p>≠ <b>Mode Valve A Final State</b></p> <p>&gt;= <b>Mode Vlv StdySt Park Dly Lim</b></p> <p>&gt;= 450.00</p> <p>≠ diagnostic min line</p> <p>= PARK</p> <p>= PARK</p> <p>= NeutLo</p> <p>≠ OUT OF PARK</p> <p>= Drive or Reverse</p> <p>≠ PARK</p> <p>&gt;= <b>Mode Valve A StdySt Rmdl Lim</b></p> <p>= no slip detected</p>	<p>park servo enable</p> <p>ETRS system type is internal ETRS</p> <p>battery voltage for battery voltage time (engine mode run OR hydraulic pressure available)</p> <p>auto stop active</p> <p>diagnostic monitor enable</p> <p>ETRS commanded direction</p> <p>P27EE fault active</p> <p>P27EB fault active</p> <p>P27ED fault active</p> <p>P18AB test fail this key on</p> <p>P18AA test fail this key on</p> <p>P27EC test fail this key on</p> <p>mode valve steady state clutch slip = slip detected when:</p> <p>IF (commanded or attained gear C1 clutch slip speed validity)</p> <p>ELSE IF (range shift state active clutch control (turbine speed OR turbine speed) gear slip timer)</p> <p>ELSE (commanded gear slip AND gear slip timer)</p> <p>mode valve steady state</p>	<p>= 1 Boolean</p> <p>= CeTRGR_e_InternalETRS</p> <p>≥ 9.00 volts</p> <p>≥ 1.000 seconds</p> <p>= TRUE</p> <p>= TRUE</p> <p>= FALSE</p> <p>= 1 Boolean</p> <p>= ETRS diagnostic range</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= FALSE</p> <p>= 1 FW</p> <p>= FALSE</p> <p>= clutch control ≠ GSCR</p> <p>&gt; upper bound</p> <p>&lt; lower bound</p> <p>&gt;= 0.10</p> <p>&gt;= 150.00</p> <p>&gt;= 0.10</p>	<p>IF mode valve A sensor fault = TRUE, set DTC fault active</p> <p>update rate 6.25 milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					clutch slip = no slip detected when: IF (C1 clutch slip speed validity (C1 slip (turbine pull down OR throttle position %)) ELSE IF (range shift state active clutch control (turbine speed OR turbine speed )) ELSE (commanded gear slip (turbine pull down OR (throttle position % OR engine torque))) AND gear slip timer	= TRUE  < 200.00 >= 400.00  > 5.00  = clutch control ≠ GSCR < upper bound  > lower bound  < 150.00 >= 400.00  > 5.00  35.00  >= 0.05		
			Mode valve A sensor position  mode valve A state attained mode valve A transition  ((ETRS commanded direction ETRS range line pressure command mode valve A pressure park servo)	≠ <b>Mode Valve A Final State</b>  = FALSE  = FALSE  = DRIVE  = PARK > 99.00 > 195.00 = OUT OF PARK	park servo enable ETRS system type is internal ETRS battery voltage for battery voltage time (engine mode run OR hydraulic pressure available) auto stop active diagnostic monitor enable  ((Driver command P2812 Fault Active P2815 Fault Active	= 1 Boolean = CeTRGR_e_InternalETR S  ≥ 9.00 volts ≥ 1.000 seconds = TRUE = TRUE  = FALSE = 1 Boolean  = Park	IF mode valve A sensor fault = TRUE, set DTC fault active  update rate 6.25 milliseconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>OR</p> <p>(ETRS commanded direction ETRS range mode valve A pressure park servo))</p> <p>mode valve A transition delay</p> <p>set mode valve A sensor fault</p>	<p>= PARK</p> <p>= DRIVE</p> <p>&lt; 25.00</p> <p>= PARK</p> <p>&gt;=</p> <p>ModeVlvA_TrnstnDly [ETRS diagnostic range][ETRS commanded direction] (see supporting tables for specific delay associated with each shift)</p> <p>= TRUE</p>	<p>P0970 Fault Active P2720 Fault Active) OR (Driver command P2814 Fault Active (P0968 Fault Active P0971 Fault Active) OR (P2718 Fault Active P2721 Fault Active)))</p> <p>ETRS commanded direction</p> <p>Mode enable valve stuck on test</p> <p>P27EE fault active P27EB fault active P27ED fault active P18AB test fail this key on P18AA test fail this key on P27EC test fail this key on</p> <p>Mode valve A state attained = TRUE when: Mode valve A sensor position Mode valve sensor position</p> <p>(mode valve A transition OR <b>Mode Valve A Trnstn State</b> )</p> <p>Mode valve A transition = TRUE when:</p>	<p>= FALSE = FALSE = FALSE = FALSE</p> <p>≠ Park = FALSE = FALSE = FALSE</p> <p>= FALSE = FALSE</p> <p>≠ ETRS diagnostic range</p> <p>= FALSE</p> <p>= FALSE = FALSE = FALSE = FALSE = FALSE = FALSE</p> <p>= mode valve A command position = <b>Mode Valve A Final State</b></p> <p>= TRUE</p> <p>= <b>Mode Valve A Final State</b></p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Mode valve A sensor position	= Mode Valve A Trnstrn State		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Control A Position Sensor/Switch Circuit Low	P27ED	The diagnostic monitor detects a ground short or open circuit fault on the mode valve A position sensor circuit.	raw sensor voltage	< 0.414 volts	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is hall sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	0.100 seconds in 0.163 second sample  6.25 millisecond update rate	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Control A Position Sensor/Switch Circuit High	P27EE	The diagnostic monitor detects a short to voltage on the mode valve A position sensor circuit.	raw sensor voltage	> 2.538 volts	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is hall sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	0.100 seconds in 0.163 second sample  6.25 millisecond update rate	Type A, 1 Trips



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmissio n Range Control B Position Sensor/ Switch Circuit/Open	P27EF	The diagnostic monitor detects an illegal voltage on the mode valve B position sensor circuit.	raw sensor voltage raw sensor voltage	> 1.263 volts < 1.504 volts	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is hall sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	0.100 seconds in 0.163 second sample  6.25 millisecond update rate	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Control B Position Sensor/Switch Circuit Range/Performance	P27F0	Sensor signal fails to transition when solenoid mode valve control commands to PARK, REVERSE, NEUTRAL HI, NEUTRAL LO, NEUTRAL SHIFT or DRIVE occur.	Mode valve B position sensor  mode valve B steady state delay  line pressure line pressure action  (ETRS commanded direction park servo)  OR  (ETRS commanded direction park servo)  OR  ((ETRS commanded direction park servo) mode valve A fail timer  clutch slip)  set mode valve B sensor fault to TRUE	≠ <b>Mode Valve B Final State</b>  ≥ <b>Mode Vlv StdySt Park Dly Lim</b> ≥ 450.00 ≠ diagnostic min line  = PARK  = PARK  = NeutLo  ≠ OUT OF PARK  = Drive or Reverse  ≠ PARK ≥ <b>Mode Valve B steady state turbine speed delay limit</b> = no slip detected	park servo enable ETRS system type is internal ETRS  battery voltage for battery voltage time (engine mode run OR hydraulic pressure available) auto stop active diagnostic monitor enable  ETRS commanded direction  P27F2 fault active P27EF fault active P27F1 fault active P18AD test fail this key on P18AC test fail this key on P27F0 test fail this key on  mode valve steady state clutch slip = slip detected when: IF (commanded or attained gear C1 clutch slip speed validity) ELSE IF (range shift state active clutch control (turbine speed OR turbine speed) gear slip timer) ELSE (commanded gear slip AND gear slip timer)	= 1 Boolean = CeTRGR_e_InternalETRS  ≥ 9.00 volts ≥ 1.000 seconds = TRUE = TRUE  = FALSE = 1 Boolean  = ETRS diagnostic range  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE  = 1 FW  = FALSE  = clutch control ≠ GSCR > upper bound  < lower bound ≥ 0.10  ≥ 150.00 AND ≥ 0.10	IF Mode valve B sensor fault = TRUE, set DTC fault active  update rate 6.25 milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					mode valve steady state clutch slip = no slip detected when: IF (C1 clutch slip speed validity (C1 slip (turbine pull down OR throttle position %)) ELSE IF (range shift state active clutch control (turbine speed OR turbine speed )) ELSE (commanded gear slip (turbine pull down OR (throttle position % OR engine torque))) AND gear slip timer	= TRUE < 200.00 >= 400.00 > 5.00 = clutch control ≠ GSCR < upper bound > lower bound < 150.00 >= 400.00 > 5.00 > 35.00 >= 0.05		
			Mode valve B sensor position  mode valve B state attained mode valve B transition  (ETRS commanded direction ETRS range park servo	≠ <b>Mode Valve B Final  State</b>  = FALSE = FALSE = Park ≠ Park = PARK	park servo enable ETRS system type is internal ETRS battery voltage for battery voltage time (engine mode run OR hydraulic pressure available) auto stop active diagnostic monitor enable  ((Driver command	= 1 Boolean = CeTRGR_e_InternalETRS ≥ 9.00 volts ≥ 1.000 seconds = TRUE = TRUE = FALSE = 1 Boolean	IF mode valve B sensor fault = TRUE, set DTC fault active  update rate 6.25 milliseconds	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			min line pressure command mode valve B pressure)  OR  (ETRS commanded direction ETRS range Line pressure command mode valve B pressure command park servo)  Mode valve B transition delay timer          set mode valve B sensor fault	= FALSE  <= 25.00          = Reverse, NeutHi, Neutshf, or NeutLo = Park >= 99.00 >= 295.00  = OUT OF PARK  >= ModeVlvB_TrnstnDly [ETRS diagnostic range][ETRS commanded direction] (see supporting tables for specific delay associated with each shift)  = TRUE	P2812 Fault Active P2815 Fault Active P0970 Fault Active P2720 Fault Active)  OR  (Driver command P2814 Fault Active (P0968 Fault Active P0971 Fault Active) OR (P2718 Fault Active P2721 Fault Active)))  ETRS commanded direction  Mode enable valve stuck on test  P27EF fault active P27F1 fault active P27F2 fault active P18AC test fail this key on P18AD test fail this key on P27F0 test fail this key on  Mode valve B state attained = TRUE when: (Mode valve B sensor position  Mode valve B position AND (Mode valve B transition OR  <b>Mode Valve B Trnstn State</b> ))	= Park = FALSE = FALSE = FALSE = FALSE  ≠ Park = FALSE = FALSE = FALSE  = FALSE = FALSE  ≠ ETRS diagnostic range  = FALSE  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE  = <b>Mode Valve B Final State</b> = Mode valve command  = TRUE		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Mode valve B transition = TRUE when: Mode valve B transition	= <b>Mode Valve B Final State</b>  = <b>Mode Valve B Trnstrn State</b>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Control B Position Sensor/Switch Circuit Low	P27F1	The diagnostic monitor detects a ground short or open circuit fault on the mode valve B position sensor circuit.	raw sensor voltage	> 0.414 volts	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is hall sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	0.100 seconds in 0.163 second sample  6.25 millisecond update rate	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Range Control B Position Sensor/Switch Circuit High	P27F2	The diagnostic monitor detects a short to voltage on the mode valve B position sensor circuit.	raw sensor voltage	> 2.538 volts	diagnostic monitor enable battery voltage battery voltage time ETRS system configuration is internal ERTS park sensor configuration type is hall sensor	= 1 Boolean ≥ 9.00 volts ≥ 1.00 seconds = CeTRGR_e_InternalETRS = CePSCR_e_HallSns	0.100 seconds in 0.163 second sample  6.25 millisecond update rate	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid G Control Circuit Open	P2812	Controller specific circuit diagnoses 9 speed Line Pressure Control Circuit, 10 speed Line Pressure Control Circuit, or 8 speed TCC Control Circuit for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates an open circuit</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit</p> <p>Increment fail time</p>	<p>≥ 200 K Ω impedance between signal and controller ground</p>	<p>battery voltage</p> <p>(run crank voltage</p> <p>OR</p> <p>accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p>≥ 9.00 volts and ≤ 32.00 volts</p> <p>≥ 5.00 volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON</p>	<p>fail time ≥ 0.30 seconds out of sample time ≥ 0.50 seconds</p> <p>≥ 1.00 seconds</p> <p>≥ 25 milliseconds</p> <p>≥ 12.5 milliseconds</p>	Type A, 1 Trips



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid G Control Circuit Low	P2814	Controller specific circuit diagnoses 9 speed Line Pressure Circuit, 10 speed Line Pressure Circuit, or 8 speed TCC Control Circuit for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a ground short</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller ground	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid G Control Circuit High	P2815	Controller specific circuit diagnoses 9 speed Line Pressure Circuit, 10 speed Line Pressure Circuit, or 8 speed TCC Control Circuit for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range indicates a short to voltage  Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON    = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON    = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid H Performance /Stuck Off	P2817	The diagnostic monitor detects the transmission torque converter control valve solenoid failed hydraulically off. The monitor executes when the transmission torque converter is commanded to a "lock" mode during which the torque converter will be controlled to near zero (0.0) RPM slip speed, or, an "on" mode during which the torque converter will be controlled to target slip speed using slip speed error. The transmission torque converter control valve solenoid is considered failed hydraulically off when the "lock" mode slip speed is excessive, or, when the 'on" mode slip speed error is excessive.	if use TCC slip speed error OR TCC control mode  TCC slip speed error = TCC slip speed - TCC comand slip speed  else if TCC control mode torque convert slip = engine speed - transmission input shaft speed  then update fail time 25 millisecond update rate	= 0 Boolean  = ON mode (controlled slip mode) ≥ <b>P2817 TCC stuck off fail TCC slip speed</b> see supporting table  = LOCK ≥ 130.0 RPM	diagnostic monitor enable   TCC command capacity  TCC command pressure  (TCC control mode previous TCC control mode previous TCC control mode previous) AND (TCC control mode current OR TCC control mode current)  (TCC stuck off enable OR TCC stuck on enable) hydraulic pressure available: engine speed	= 1 Boolean   ≥ 0.00 %  ≥ 800.0 kPa  ≠ TCC control mode current ≠ ON mode (controlled slip mode) ≠ LOCK  = ON mode (controlled slip mode) = LOCK  = 1 Boolean  = 1 Boolean  ≥ 500.0 RPM	fail time ≥ 2.500 seconds increment fail count fail count ≥ 3 counts 25 millisecond update rate  TCC command capacity time ≥ 0.00 seconds  TCC command pressure time ≥ 2.00 seconds          engine speed time ≥ <b>engine speed time for transmission hydraulic pressure available</b>	Type B, 2 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					service fast learn active battery voltage  run crank voltage  P281B falut active P281D falut active P281E falut active P0722 fault pending P0723 fault pending P0716 fault pending P0717 fault pending P07BF fault pending P07C0 fault pending (PTO active OR PTO disable calibration) accelerator pedal position accelerator pedal position range shift state transmission fluid temperature transmission fluid temperature engine torque engine torque P2817 test fail this key on (TCC control mode OR TCC control mode) break latch state (clutch select valve solenoid) attained gear  attained gear slip  DTCs not fault active	= FALSE ≥ 9.00 volts  ≥ 9.00 volts  = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1 Boolean ≥ 8.0 % ≤ 100.0 % = range shift complete ≥ -6.66 °C  ≤ 130.0 °C  ≥ 50.0 Nm ≤ 8,191.8 Nm = FALSE = ON mode (controlled slip mode) = LOCK = disabled (clutch select valve not transitioning) ≥ CeCGSR_e_CR_Third  ≤ 25 RPM  AcceleratorPedalFailure EngineTorqueEstInaccu te	see supporting table  battery voltage time ≥ 0.100 seconds run crank voltage time ≥ 0.100 seconds	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P0716, P0717, P07BF, P07C0 P0722, P0723, P077C, P077D		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid H Stuck On - GF9 specific	P2818	The diagnostic monitor detects the transmission torque converter control valve solenoid failed hydraulically on. The torque converter hydraulic control circuit is multiplexed with the transmission clutch select valve hydraulic control circuit, allowing for the torque converter control valve solenoid stuck on test to execute when the clutch select valve solenoid is commanded ON. When the clutch select valve solenoid is commanded ON as the vehicle speed decreases toward zero KPH, and, if the torque converter control valve solenoid is stuck on, the torque converter slip speed rate of change will have a large slope while decreasing toward zero RPM, and the torque converter slip speed will remain low near zero RPM.	while control valve test time timing down: rate of change of torque convert slip speed = (ABS (current loop value torque convert slip speed - previous loop value torque convert slip speed) / 25 milliseconds) when clutch select valve solenoid multiplexed to TCC hydraulic AND torque convert slip speed = ABS(engine speed - transmission input shaft speed) AND torque convert slip speed = engine speed - transmission input shaft speed torque convert slip speed torque convert slip speed THEN increment fail time 25 millisecond update rate	$\geq$ <b>P2818 torque convert derivative slip speed fail threshold</b> see supporting table  $\leq$ <b>P0741 (GF9 specific) TCC slip speed crash RPM</b>  $\geq -50.0 \text{ RPM}$ $\leq 30.0 \text{ RPM}$	diagnostic monitor enable (TCC stuck off enable OR TCC stuck on enable) hydraulic pressure available: engine speed  service fast learn active battery voltage  run crank voltage  P281B falut active P281D falut active P281E falut active  PRNDL PRNDL transmission fluid temperature transmission fluid	$= 1 \text{ Boolean}$ $= 1 \text{ Boolean}$ $= 1 \text{ Boolean}$ $\geq 500.0 \text{ RPM}$  $= \text{FALSE}$ $\geq 9.00 \text{ volts}$  $\geq 9.00 \text{ volts}$  $= \text{FALSE}$ $= \text{FALSE}$ $= \text{FALSE}$  $\neq \text{NEUTRAL}$ $\neq \text{REVERSE}$ $\geq -6.66 \text{ }^{\circ}\text{C}$ $\leq 130.00 \text{ }^{\circ}\text{C}$	fail time $\geq 1.500$ seconds increment fail count fail count $\geq 4$ counts 25 millisecond update rate  engine speed time $\geq$ <b>engine speed time for transmission hydraulic pressure available</b> see supportinf table  battery voltage time $\geq 0.100$ seconds run crank voltage time $\geq 0.100$ seconds	Type A, 1 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					temperature accelerator pedal position accelerator pedal position vehicle speed vehicle speed TCC command mode break latch state (clutch select valve solenoid) P0722 fault pending P0723 fault pending P0716 fault pending P0717 fault pending P07BF fault pending P07C0 fault pending (PTO active OR PTO disable calibration) transmission fluid temperature transmission fluid temperature engine torque engine torque P2818 test fail this key on vehicle speed engine speed engine speed accelerator pedal position 4WD low state (driver shift mode active OR driver shift mode calibration) (misfire requests TCC off OR misfire TCC off calibration) (clutch control solenoid stuck on OR stuck OFF intrusive shift active) P0746 fault pending P0747 fault pending P0776 fault pending	≥ 0.00 % ≤ 1.00 % ≥ 3.0 KPH ≤ 9.5 KPH = OFF ≠ disabled (clutch select valve transitioning) = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = 1 Boolean ≥ -6.66 °C ≤ 130.00 °C ≥ 55.0 Nm ≤ 800.0 Nm = FALSE ≤ 45.0 KPH ≥ 400.0 RPM ≤ 5,500.0 RPM ≤ 95.0 % = FALSE = FALSE = 0 Boolean = FALSE = 0 Boolean = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					P0777 fault pending P0796 fault pending P0797 fault pending P2714 fault pending P2715 fault pending P2723 fault pending P2724 fault pending P2732 fault pending P2733 fault pending P2820 fault pending P2821 fault pending vehicle speed accelerator pedal position hysteresis  when: break latch state (clutch select valve solenoid) previous break latch state (clutch select valve solenoid) set stuck on test time and begin time down, stuck on test time must time down from calibration value to zero (0.0) seconds  break latch state (clutch select valve solenoid) AND  previous break latch state (clutch select valve solenoid) THEN initialize control valve test time, control valve test time must time down from calibration value to zero (0.0) seconds	= FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE = FALSE ≤ 8.0 KPH ≥ 4.0 % > 1.0 %  = disabled (clutch select valve not transitioning) = complete (clutch select valve transition complete) = <b>P2818 stuck on test time</b> see supporting tables  = clutch select valve solenoid multiplexed to TCC hydraulic  = disabled (clutch select valve not transitioning) = <b>P2818 (GF9 specific)</b> <b>control valve test time</b> see supporting tables		



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					DTCs not fault active	AcceleratorPedalFailure EngineTorqueEstInaccuracy P0716, P0717, P07BF, P07C0 P0722, P0723, P077C, P077D		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid H Control Circuit Open	P281B	Controller specific circuit diagnoses 9 speed TCC Control Circuit, 10 speed TCC Control Circuit, or 8 speed T93 Default Valve Control Circuit for an open circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates an open circuit</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for an open circuit</p> <p>Increment fail time</p>	<p>≥ 200 K Ω impedance between signal and controller ground</p>	<p>battery voltage</p> <p>(run crank voltage</p> <p>OR</p> <p>accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p>≥ 9.00 volts and ≤ 32.00 volts</p> <p>≥ 5.00 volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON</p>	<p>fail time ≥ 0.30 seconds out of sample time ≥ 0.50 seconds</p> <p>≥ 1.00 seconds</p> <p>≥ 25 milliseconds</p> <p>≥ 12.5 milliseconds</p>	Type B, 2 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid H Control Circuit Low	P281D	Controller specific circuit diagnoses 9 speed TCC Pressure Control Circuit, 10 speed TCC Control Circuit, or 8 speed Default Valve Control Circuit for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds. For 8 speed T87a controllers, an open circuit on the Default Valve Control Circuit will also set P281D.	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid H Control Circuit High	P281E	Controller specific circuit diagnoses 9 speed TCC Pressure Control Circuit, 10 speed TCC Control Circuit, or 8 speed Default Valve Control Circuit for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD2 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type B, 2 Trips

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control (PC) Solenoid J Stuck Off (GF9)	P2820	<p>Each pressure control solenoid stuck off diagnostic monitor detects a control solenoid failed hydraulically off, while the solenoid is electrically functional. This diagnostic monitor detects the clutch select valve solenoid failed hydraulically off. The clutch select valve is used to route hydraulic fluid to, either, the selectable one way clutch hydraulic circuit used to attain transmission 1st gear lock state, or, to the C6 - C6789 clutch hydraulic circuit necessary for transmission higher gear states.</p> <p>When the clutch select valve is failed hydraulically off, and transmission is in 1st gear lock state, it is possible to measure low C6 - C6789 clutch slip speed or 6th gear transmission ratio, since hydraulic fluid is routed to the clutch C6 - C6789. This can be determined based on transmission lever node design, the</p>	<p>(gear ratio AND gear ratio) OR C6 clutch slip speed</p> <p>update fail time 6.25 milliscond update</p>	<p>≤ 1.700 ≥ 1.200 ≤ 20.0 RPM</p>	<p>***** system-level enables:  use battery voltage calibration is FALSE  OR  (use battery voltage calibration is TRUE  AND  battery voltage)  use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage)  TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled  TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled  service fast learn active</p>	<p>*****  = 1 Boolean  = 1 Boolean  ≥ 9.00 volts  = 1 Boolean = 1 Boolean ≥ 9.00 volts  = TRUE Boolean  = TRUE Boolean = FALSE Boolean</p>	<p>fail time ≥ 0.250 seconds, update fail count, fail count ≥ 3 counts 6.25 milliscond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>transmission input shaft speed, the transmission output shaft speed, and one transmission intermediate shaft speed, while not commanding 6th-9th gear.</p> <p>This diagnostic monitor is relative to the GF9 clutch select valve pressure control solenoid.</p>			<p>service solenoid cleaning procedure active</p> <p>hydraulic pressure available *****</p> <p>diagnostic monitor enabled</p> <p>transmission output shaft speed</p> <p>transmission fluid temperature</p> <p>transmission fluid temperature</p> <p>(command gear AND attained gear) OR (attained gear AND SOWC state)</p> <p>C6 clutch slip speed valid *****</p> <p>DTCs not fault pending</p> <p>DTCs not fault active</p>	<p>= FALSE Boolean</p> <p>= TRUE *****</p> <p>= 1 (1 to enable, 0 to disable)</p> <p>≥ 35 RPM</p> <p>≥ -256.00 °C</p> <p>≤ 130.0 °C</p> <p>= 1st lock</p> <p>= 1st lock</p> <p>= 2nd lock</p> <p>= APPLY COMPLETE</p> <p>= TRUE *****</p> <p>P17CE P1783 P178F P17C6 P17C4 P17C7 P17D3 P17C5 P0721 P172A P172B P0716 P0717 P07C0 P07BF P0723 P0722 P077D P077C P176C P176D P176B P17D6</p> <p>P2534 P0707 P0708 P0716 P0717 P07C0</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					DTCs not test fail this key on	P07BF P077D P077C P126C P176D P17CC P17CD P0962 P0966 P0970 P2720 P2729 P2738 P0963 P0967 P0971 P2721 P2730 P2739 P0960 P0964 P0968 P2718 P2727 P2736 P17CE P1783 P17D3 P17C5 P0721 AcceleratorPedalFailure CrankSensor_FA  P0707 P0708 P0723 P0722 P176B P17D6 P0747 P0777 P0797 P2715 P2724 P2733 P0746 P0776 P0796 P2714 P2723 P2732 P2821 P2820 P178F P17C6 P17C4 P17C7 P172A P172B		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid J Stuck On (GF9)	P2821	Each pressure control solenoid stuck on diagnostic monitor detects a clutch pressure control solenoid failed hydraulically on, while the solenoid is electrically functional. The clutch select pressure control solenoid must be hydraulically off and the clutch select valve in the off state, to allow hydraulic fluid supply to the C3 (CB38) or C4 (C4) or C5 (C57R) clutches, such that when activated, commanded gear 3rd or 4th or 5th can be attained. With the clutch select valve pressure control solenoid failed hydraulically on, commanded gear 3rd or 4th or 5th cannot be attained. In the failure mode, the clutch slip speed, and gear box gear slip, will be excessive, not near or at zero RPM, when commanding 3rd or 4th or 5th gear, but due to the clutch select pressure control solenoid failed hydraulically on and not	Cx clutch slip speed fail compare C3 (CB38) OR C4 (C4) OR C5 (C57R) update Cx clutch slip speed fail time 6.25 milliscond update  once intrusive gear is commanded and clutch select stuck on test active remains and Cx clutch fail count limit occurs, increment clutch select valve solenoid stuck on fail count and time up clutch select stuck on test gear time 6.25 milliscond update	≥ 200.0 RPM ≥ 200.0 RPM ≥ 200.0 RPM       = TRUE			Cx clutch slip speed fail time ≥  (C3 (CB38) 3.00 seconds OR C4 (C4) 3.00 seconds OR C5 (C57R) 3.00 seconds)  update Cx fail count,  Cx fail count ≥ (C3 (CB38) 3 counts OR C4 (C4) 3 counts OR C5 (C57R) 3 counts)  Cx clutch fail count limit occurs 6.25 milliscond update  clutch select valve solenoid stuck on fail count ≥ 2 counts OR clutch select stuck on test gear time ≥ 9.00 seconds	Type A, 1 Trips



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>individual clutch control faults. It is thus necessary, when individual clutch slip occurs in 3rd or 4th or 5th gear and counted toward the clutch pressure control solenoid stuck on failure, for an intrusive gear commanded from 3rd or 4th or 5th to verify the clutch slip in the remaining gear states. The individual clutch slip that occurs in those intrusive gears, 3rd or 4th or 5th, is also counted toward the clutch pressure control solenoid stuck on failure. As individual clutch slip is accumulated in each commanded gear 3rd or 4th or 5th, that failure time is the verification of the clutch pressure control solenoid failed hydraulically on.</p> <p>The clutch slip speed is calculated based on the transmission lever node design, requiring transmission input shaft speed, transmission output shaft speed, and, one transmission intermediate shaft speed. The clutch</p>			<p>***** system-level enables:</p> <p>use battery voltage calibration is FALSE OR (use battery voltage calibration is TRUE AND battery voltage</p> <p>use run crank voltage calibration is FALSE OR (use run crank voltage calibration is TRUE AND run crank voltage</p> <p>TCM output driver high side driver 1, clutch pressure control solenoid driver circuit enabled</p> <p>TCM output driver high side driver 2, clutch pressure control solenoid driver circuit enabled</p> <p>service fast learn active service solenoid cleaning procedure active</p> <p>hydraulic pressure available</p> <p>***** diagnostic monitor enable</p>	<p>*****</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= 1 Boolean</p> <p>= 1 Boolean</p> <p>≥ 9.00 volts</p> <p>= TRUE Boolean</p> <p>= TRUE Boolean</p> <p>= FALSE Boolean = FALSE Boolean</p> <p>= TRUE</p> <p>***** = 1 Boolean</p>	<p>6.25 millisecond update</p> <p>battery voltage time ≥ 0.100 seconds</p> <p>run crank voltage time ≥ 0.100 seconds</p>	

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>pressure control solenoid is tested after an automatic transmission shift occurs and has been considered shift complete, or, steady state gear is deemed active, range shift complete. When the automatic transmission shift is complete, steady state gear is considered, the clutch pressure control solenoid is mapped to transmission line pressure control, which normally allows the clutch to maintain full torque holding capacity at the given engine crankshaft torque, to maintain true gear ratio. When the clutch select pressure control solenoid is failed hydraulically on, C3 (CB38) or C4 (C4) or C5 (C57R) clutches cannot maintain holding capacity at any engine crankshaft torque, and the clutch slip speed is uncontrollable.</p> <p>The clutch pressure control solenoid test is suspended if the higher level safety startle mitigation function is</p>			<p>P2821 test fail this key on</p> <p>test trigger set to TRUE: enable forward gear AND direction request OR enable reverse gear AND direction request current loop test trigger clutch control solenoid test state range shift state</p> <p>clutch solenoid test state set to NEUTRAL TEST when: test trigger initialize range shift complete time, when range shift state, range shift complete time must time down to zero when range shift complete</p> <p>Cx indicates any one of the 3 clutches: C3 (CB38) OR C4 (C4) OR C5 (C57R)</p> <p>enable Cx clutch slip speed fail compare when: diagnostic clutch test Cx ((startle mitigation active OR (startle mitigation active</p>	<p>= FALSE</p> <p>= 1 Boolean = forward gear</p> <p>= 0 Boolean = reverse gear = FALSE ≠ NEUTRAL TEST</p> <p>= range shift completed</p> <p>= TRUE</p> <p>≠ range shift completed</p> <p>= HOLDING CLUTCH = FALSE = TRUE</p>	<p>initialize range shift complete time = 1.000 seconds, range shift complete time must time down to zero when range shift complete</p>	

# 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>active. The safety startle mitigation function is triggered when a sudden vehicle deceleration occurs due to a clutch pressure control solenoid that has failed hydraulically on, while the solenoid is electrically functional, which, must take priority over this clutch select pressure control solenoid stuck off diagnostic monitor. All clutch pressure control solenoid stuck on/off diagnostic monitors are emission MIL DTCs. System voltage must be normal, all clutch pressure control solenoid driver circuits must be functional, no clutch pressure control solenoid electrical or performance faults can be present, and no speed sensor electrical or performance faults can be present, or the a clutch pressure control solenoid stuck off test is disabled.</p> <p>This diagnostic monitor is relative to the GF9 clutch select valve pressure control solenoid.</p>			<p>AND startle mitigation gear)) (see startle mitigation active NOTE below) unintended deceleration fault pending OR unintended deceleration fault pending enable FASLE (startle mitigation) clutch steady state adaptive active transmission output shaft speed Cx clutch slip speed valid, all speed sesnors are functional for lever node cluth slip speed calculation</p> <p>accelerator pedal position engine speed</p> <p>diagnostic clutch test Cx set to HOLDING CLUTCH when: clutch solenoid test state ((startle mitigation active OR (startle mitigation active AND startle mitigation gear)) (see startle mitigation active NOTE below) Cx clutch pressured map</p> <p>***** clutch select stuck on test active set to TRUE when:</p>	<p>≠ initial startle mitigation gear</p> <p>= FALSE</p> <p>= 0 Boolean</p> <p>= FALSE</p> <p>≥ 89.0 RPM</p> <p>≥ 2.00 % ≥ 1,500.0 RPM</p> <p>= NEUTRAL TEST = FALSE</p> <p>= TRUE</p> <p>≠ initial startle mitigation gear</p> <p>= mapped to line pressure, Cx clutch pressure has transtioned from off-applying-applied</p> <p>*****</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>command gear clutch control solenoid test state any Cx clutch fail count limit occurs break latch state, clutch select valve hydraulic latch fluid is applied, hydraulic latch fluid force balance acts with clutch select valve return spring, to force the clutch select valve to the off position in normal operation, allowing hydraulic fluid to C3 (CB38) C4 (C4) and C5 (C57R) clutches</p> <p>clutch select stuck on test active driver direction (PRNDL) change request, select intrusive gear to verify clutch select valve solenoid when HOLDING CLUTCH: C3 (CB38) C4 (C4) C5 (C57R) enable clutch select stuck on test gear time</p> <p>NOTE: startle mitigation active is used to detect unintended deceleration due to clutch pressure control solenoid stuck on failure modes, the clutch pressure control solenoid stuck on DTCs being P0747 P0777 P0797</p>	<p>≠ REVERSE = NEUTRAL TEST</p> <p>= complete</p> <p>= TRUE</p> <p>= FALSE</p> <p>= CeCGSR_e_Fourth = CeCGSR_e_Fifth = CeCGSR_e_Fourth</p>		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

[illegible]

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid J Control Circuit Low	P2826	Controller specific circuit diagnoses 9 speed Clutch Select Valve Control Circuit, 10 speed Default Disable Control Circuit, or 8 speed Boost Valve Control Circuit for a ground short circuit failure by comparing a voltage measurement to controller specific voltage thresholds. For T87a controllers, an open circuit on solenoid I/J will also set P2826	Voltage measurement outside of controller specific acceptable range indicates a ground short  Controller specific circuit voltage thresholds are set to meet the following controller specification for a ground short  Increment fail time	$\leq 0.5 \Omega$ impedance between signal and controller ground	battery voltage  (run crank voltage OR accessory voltage active)  diagnostic monitor enable calibration  (solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)  OR  (solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)  OR  (solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)	$\geq 9.00$ volts and $\leq 32.00$ volts  $\geq 5.00$ volts  = TRUE  = 1 (1 is enable, 0 is disable)  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON  = CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable) = ON	fail time $\geq 0.30$ seconds out of sample time $\geq 0.50$ seconds  $\geq 1.00$ seconds  $\geq 25$ milliseconds  $\geq 12.5$ milliseconds	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Pressure Control Solenoid J Control Circuit High	P2827	Controller specific circuit diagnoses 9 speed Clutch Valve Control Circuit, 10 speed Default Disable Control Circuit, or 8 speed Boost Valve Control Circuit for a short to voltage circuit failure by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range indicates a short to voltage</p> <p>Controller specific circuit voltage thresholds are set to meet the following controller specification for a short to voltage</p> <p>Increment fail time</p>	$\leq 0.5 \Omega$ impedance between signal and controller voltage source	<p>battery voltage</p> <p>(run crank voltage OR accessory voltage active)</p> <p>diagnostic monitor enable calibration</p> <p>(solenoid is mapped to high side driver 1 (CeTSCR_e_HSD1) AND high side driver 1)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 2 (CeTSCR_e_HSD2) AND high side driver 2)</p> <p>OR</p> <p>(solenoid is mapped to high side driver 3 (CeTSCR_e_HSD3) AND high side driver 3)</p>	<p><math>\geq 9.00</math> volts and <math>\leq 32.00</math> volts</p> <p><math>\geq 5.00</math> volts</p> <p>= TRUE</p> <p>= 1 (1 is enable, 0 is disable)</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p> <p>= CeTSCR_e_HSD1 (CeTSCR_e_NoHSD will disable)</p> <p>= ON</p>	<p>fail time <math>\geq 0.30</math> seconds out of sample time <math>\geq 0.50</math> seconds</p> <p><math>\geq 1.00</math> seconds</p> <p><math>\geq 25</math> milliseconds</p> <p><math>\geq 12.5</math> milliseconds</p>	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Stall Prevention Active Signal Message Counter Incorrect	P30BD	The diagnostic monitor detects an alive rolling count error in the CAN frame containing the engine stall protection signal value. The alive rolling count sequences 0, 1, 2, 3 repeatedly. As each serial data frame is broadcast by the transmitting controller, the transmitting controller increments the alive rolling count in this sequence manner. The receiving controller compares the most recent received alive rolling count value to the previous value plus one. If the values are not equal, an alive rolling count error has occurred. If continuous alive rolling count errors occur the DTC is set.	rolling count value received from ECM and expected TCM calculated value not equal	= TRUE	<p>Loop rate calibration either 10 milliseconds or 12.5 milliseconds</p> <p>service mode \$04 active battery voltage battery voltage time</p> <p>engine stall protection ECM frame recieved</p>	<p>= CeCFMD_e_DEC_Time Base_12p5</p> <p>= FALSE ≥ 11.00 volts ≥ 300.000 seconds</p> <p>= TRUE</p>	alive rolling count errors ≥ 8 out of 10 sample counts	Type B, 2 Trips



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Communicati on Bus A Off	U0073	This DTC monitors for a BUS A off condition	Bus off failures exceeds  before the sample time of is reached	3 counts (equivalent to 0.04 seconds)  0.81 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Run/Crank Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds  CAN hardware is bus OFF for	Not Active on Current Key Cycle  Enabled  Not Active  Not Active  > 6.41 Volts  = run  = 1 ( 1 indicates enabled)  = Active  > 11.00 Volts        > 0.1625 seconds	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With ECM	U0100	This DTC monitors for a loss of communication with the engine control module	<p>Message is not received from controller for</p> <p>Message \$0BE</p> <p>Message \$0C9</p> <p>Message \$18E</p> <p>Message \$1A1</p> <p>Message \$1A3</p> <p>Message \$1AA</p> <p>Message \$1BA</p> <p>Message \$287</p> <p>Message \$3D1</p> <p>Message \$3E9</p> <p>Message \$4C1</p> <p>Message \$4C7</p> <p>Message \$4D1</p> <p>Message \$4F1</p> <p>Message \$589</p>	<p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 0.50 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p> <p>≥ 12.00 seconds</p>	<p>General Enable Criteria:</p> <p>U0073</p> <p>Normal CAN transmission on Bus A</p> <p>Device Control</p> <p>High Voltage Virtual Network Management</p> <p>Ignition Voltage Criteria:</p> <p>Run/Crank Ignition voltage</p> <p>Power Mode</p> <p>Off Cycle Enable Criteria:</p> <p>KeCAND_b_OffKeyCycle DiagEnbl</p> <p>Ignition Accessory Line and Battery Voltage</p> <p>General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for &gt; 5.0000 seconds</p> <p>Power Mode is in accessory or run or crank and High Voltage Virtual</p>	<p>Not Active on Current Key Cycle</p> <p>Enabled</p> <p>Not Active</p> <p>Not Active</p> <p>&gt; 6.41 Volts</p> <p>= run</p> <p>= 1 (1 indicates enabled)</p> <p>= Active</p> <p>&gt; 11.00 Volts</p>	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Network Management is not active for  U0100  ECM	> 0.4000 seconds  Not Active on Current Key Cycle  is present on the bus		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communication With Anti-Lock Brake System (ABS) Control Module	U0121	This DTC monitors for a loss of communication with the Anti-Lock Brake System (ABS) Control Module (Non-OBD Module ID 243).	<p>Message is not received from controller for</p> <p>Message \$0C1</p> <p>Message \$0C5</p> <p>Message \$1E9</p> <p>Message \$2F9</p>	<p>≥ 12.0 seconds</p> <p>≥ 12.0 seconds</p> <p>≥ 12.0 seconds</p> <p>≥ 12.0 seconds</p>	<p>General Enable Criteria:</p> <p>U0073</p> <p>Normal CAN transmission on Bus A</p> <p>Device Control</p> <p>High Voltage Virtual Network Management</p> <p>Ignition Voltage Criteria:</p> <p>Run/Crank Ignition voltage</p> <p>Power Mode</p> <p>Off Cycle Enable Criteria:</p> <p>KeCAND_b_OffKeyCycle DiagEnbl</p> <p>Ignition Accessory Line and Battery Voltage</p> <p>General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for &gt; 5.0000 seconds</p> <p>Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for</p>	<p>Not Active on Current Key Cycle</p> <p>Enabled</p> <p>Not Active</p> <p>Not Active</p> <p>&gt; 6.41 Volts</p> <p>= run</p> <p>= 1 (1 indicates enabled)</p> <p>= Active</p> <p>&gt; 11.00 Volts</p> <p>&gt; 0.4000 seconds</p>	Diagnostic runs in 12.5 ms loop	Emissions Neutral Diagnostic – Type C

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U0121  Anti-Lock Brake System Control Module	Not Active on Current Key Cycle  is present on the bus		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Chassis Control Module A	U012A	This DTC monitors for a loss of communication with the Chassis Control Module A, ICCM.	Message is not received from controller for  Message \$1F7	  ≥ 0.5000 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Run/Crank Ignition voltage  Power Mode  Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds  Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for	Not Active on Current Key Cycle  Enabled  Not Active  Not Active  > 6.41 Volts  = run  = 1 (1 indicates enabled)  = Active  > 11.00 Volts          > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Emissio ns Neutral Diagnost ic – Type C

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U012A  CHCMA  transmit device is ECM (CeCFMR_e_ECM) OR CCM (CeCFMR_e_CCM)	Not Active on Current Key Cycle  is present on the bus  = CeCFMR_e_ECM		

## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Lost Communicati on With Body Control Module	U0140	This DTC monitors for a loss of communication with the Body Control Module.	Message is not received from controller for  Message \$0F1  Message \$12A  Message \$1F1  Message \$1F3  Message \$4E1  Message \$4E9	 ≥ 0.5 seconds  ≥ 12.0 seconds  ≥ 12.0 seconds  ≥ 12.0 seconds  ≥ 12.0 seconds  ≥ 12.0 seconds	General Enable Criteria:  U0073  Normal CAN transmission on Bus A  Device Control  High Voltage Virtual Network Management  Ignition Voltage Criteria:  Run/Crank Ignition voltage  Power Mode   Off Cycle Enable Criteria:  KeCAND_b_OffKeyCycle DiagEnbl  Ignition Accessory Line and Battery Voltage  General Enable Criteria and either Ignition Voltage Criteria or Off Cycle Enable Criteria met for > 5.0000 seconds  Power Mode is in accessory or run or crank and High Voltage Virtual Network Management is not active for	 Not Active on Current Key Cycle  Enabled  Not Active  Not Active   > 6.41 Volts  = run   = 1 (1 indicates enabled)  = Active > 11.00 Volts         > 0.4000 seconds	Diagnostic runs in 12.5 ms loop	Emissio ns Neutral Diagnost ic – Type C



## 20 OBDG03A TCM T87A 10 Speed RWD Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					U0140  Body Control Module	Not Active on Current Key Cycle  is present on the bus		

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P0606 enable

**Description:** P0606 program sequence watch diagnostic monitor enable

**Value Units:** Boolean

**X Unit:** CPU number

**Y Units:** loop time

y/x	CeTSKR_e_CPU	CeTSKR_e_CPU2	CeTSKR_e_CPU3	CeTSKR_e_CPU4
CePISR_e_5msSeq	0	0	0	0
CePISR_e_6p25msSeq	1	0	0	0
CePISR_e_10msSeq	0	0	0	0
CePISR_e_12p5msSeq	1	0	0	0
CePISR_e_20msSeq	0	0	0	0
CePISR_e_25msSeq	1	0	0	0
CePISR_e_40msSeq	0	0	0	0
CePISR_e_50msSeq	0	0	0	0
CePISR_e_80msSeq	0	0	0	0
CePISR_e_100msSeq	0	0	0	0
CePISR_e_EventA_Seq	0	0	0	0
CePISR_e_EventB_Seq	0	0	0	0
CePISR_e_EventC_Seq	1	0	0	0

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

**Value Units:** Max Time for Last Seed Timeout (ms)

**X Unit:** Operating Loop Sequence (enum)

#### P0606\_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000

#### P0606\_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	200.000	200.000	200.000	8,191.875	8,191.875	8,191.875	

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)

**Description:** Fail threshold for PSW per operating loop.

**Value Units:** Fail threshold for PSW (count)

**X Unit:** Operating Loop (enum)

#### P0606\_PSW Sequence Fail f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	3	3	3	3	3	3	3

#### P0606\_PSW Sequence Fail f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	3	3	3	3	3	3	

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P0606\_PSW Sequence Sample f(Loop Time)

**Description:** Sample threshold for PSW per operating loop.

**Value Units:** Sample threshold for PSW (count)

**X Unit:** Operating Loop (enum)

#### P0606\_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	4	4	4	4	4	4	4

#### P0606\_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	4	4	4	4	4	4	

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - 10 speed transmission clutch definition and gear state to clutch map

**Description:** indicates clutch definition and gear state verses applied and released clutches for 10 speed transmission

**Value Units:** applied or released

**X Unit:** clutch

**Y Units:** gear index Y axis, actual gear column 1

y/x	1	2	3	4	5	6	7	8
1		C1 = C123456R	C2 = C1289-10R	C3 = C234579-10	C4 = C234678-10R	C5 = C1356789	C6 = C456789-10R	C7 = OWC12
2	1st gear braking	applied	applied	released	released	applied	released	applied
3	1st gear free wheel	applied	applied	released	released	applied	released	released
4	2nd gear braking	applied	applied	applied	applied	released	released	applied
5	2nd gear free wheel	applied	applied	applied	applied	released	released	released
6	3rd gear	applied	released	applied	applied	applied	released	released
7	4th gear	applied	released	applied	applied	released	applied	released
8	5th gear	applied	released	applied	released	applied	applied	released
9	6th gear	applied	released	released	released	applied	applied	released
10	7th gear	released	released	applied	applied	applied	applied	released
11	8th gear	released	applied	released	applied	applied	applied	released
12	9th gear	released	applied	applied	released	applied	applied	released
13	10th gear	released	applied	applied	applied	released	applied	released
14	reverse gear	applied	applied	released	applied	released	released	released

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - 9 speed transmission clutch definition and gear state to clutch map

**Description:** indicates clutch definition and gear state verses applied and released clutches for 9 speed transmission

**Value Units:** applied or released

**X Unit:** clutch

**Y Units:** gear index Y axis, actual gear column 1

y/x	1	2	3	4	5	6	7	8
1		C1 = CB123456	C2 = C6789	C3 = CB1R	C4 = CB29	C5 = CB38	C6 = C4	C7 = C57R
2	1st gear braking	applied	released	applied	released	released	released	released
3	1st gear free wheel	applied	released	released	released	released	released	released
4	2nd gear	applied	released	released	applied	released	released	released
5	3rd gear	applied	released	released	released	applied	released	released
6	4th gear	applied	released	released	released	released	applied	released
7	5th gear	applied	released	released	released	released	released	applied
8	6th gear	applied	applied	released	released	released	released	released
9	7th gear	released	applied	released	released	released	released	applied
10	8th gear	released	applied	released	released	applied	released	released
11	9th gear	released	applied	released	applied	released	released	released
12	reverse gear	released	released	applied	released	released	released	applied

Initial Supporting table - engine speed time for transmission hydraulic pressure available

**Description:** time needed for engine speed to trigger "transmission hydraulic pressure available"

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-30.00	-20.00	0.00	40.00
1	0.300	0.300	0.275	0.200	0.200



# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - NumClchTieUp

**Description:** NumClchTieUp

**Value Units:** minimum # of clutches

**X Unit:** command gear or attained gear

**Y Units:** not applicable, no units, single row table f(gear)

### NumClchTieUp - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5
1	2	3	2	2	2	2	2

### NumClchTieUp - Part 2

y/x	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3
1	2	2	1	1	1	1	1

### NumClchTieUp - Part 3

y/x	CeCGSR_e_NeutralC2C4	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6	CeCGSR_e_NeutralC4C5
1	1	1	1	1	1	1	1

### NumClchTieUp - Part 4

y/x	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4
1	1	1	3	2	2	2	2

### NumClchTieUp - Part 5

y/x	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	2	2	2	1	1	1	1

### NumClchTieUp - Part 6

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5
1	1	1	1	1	1	1	1

### NumClchTieUp - Part 7

y/x	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth
1	1	1	2	1	1	1	1

### NumClchTieUp - Part 8

y/x	CeCGSR_e_Fifth	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth	
-----	----------------	----------------	------------------	-----------------	----------------	----------------	--

Initial Supporting table - NumClchTieUp							
1	1	1	1	1	1	1	

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

**Value Units:** Max Time for Last Seed Timeout (ms)

**X Unit:** Operating Loop Sequence (enum)

#### P0606\_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000

#### P0606\_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	200.000	200.000	200.000	8,191.875	8,191.875	8,191.875	

## Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)

**Description:** Fail threshold for PSW per operating loop.**Value Units:** Fail threshold for PSW (count)**X Unit:** Operating Loop (enum)**P0606\_PSW Sequence Fail f(Loop Time) - Part 1**

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	3	3	3	3	3	3	3

**P0606\_PSW Sequence Fail f(Loop Time) - Part 2**

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	3	3	3	3	3	3	

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P0606\_PSW Sequence Sample f(Loop Time)

**Description:** Sample threshold for PSW per operating loop.

**Value Units:** Sample threshold for PSW (count)

**X Unit:** Operating Loop (enum)

#### P0606\_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	4	4	4	4	4	4	4

#### P0606\_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	4	4	4	4	4	4	

Initial Supporting table - P171D hydraulic pressure delay

**Description:** Time to delay the initial x of y counter due to hydraulic transients. Thresholds are a function of transmission fluid temperature. Horizontal axis is transmission fluid temperature (DegC) and table output is delay time (seconds).

**Value Units:** delay time seconds  
**X Unit:** transmission fluid temperature DegC

y/x	-40	0	20	30	40	50	60
1	0.090	0.090	0.080	0.050	0.050	0.050	0.050

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P171D predicted turbine speed error

**Description:** Predicted turbine speed vs actual turbine speed error. Thresholds are a function of engine speed and transmission fluid temperature. Diagnostic is considered failing above these values. Table vertical axis is engine speed (RPM), horizontal axis is transmission fluid temperature (DegC) and table output is predicted turbine speed error (RPM).

**Value Units:** turbine speed RPM error  
**X Unit:** transmission fluid temperature DegC  
**Y Units:** engine speed RPM

y/x	-40	0	10	20	40
0	300	300	300	300	300
500	300	300	300	300	300
1,100	300	300	300	300	300
1,500	300	300	300	300	300
2,500	300	300	300	300	300

Initial Supporting table - P176B delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation		
<b>Description:</b> delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation		
<b>Value Units:</b> seconds <b>X Unit:</b> intermediate speed sensor select		
y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	1.000	1.000



## Initial Supporting table - P176B holding clutch states

**Description:** inditaces when the clutch states allow transmission intermediate speed sensor evaluation, when rotating components can trigger speed sesnor, holding clutches will not allow evaluation while clutches not holding will allow evaluation

**Value Units:** TRUE or FALSE

**X Unit:** intermediate speed sensor select

**Y Units:** commanded gear

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
CeCGSR_e_CR_NullForSched	1	1
CeCGSR_e_CR_Neutral	1	1
CeCGSR_e_CR_Park	1	1
CeCGSR_e_CR_Reverse	0	1
CeCGSR_e_CR_First	0	1
CeCGSR_e_CR_Second	0	1
CeCGSR_e_CR_Third	1	1
CeCGSR_e_CR_Fourth	0	1
CeCGSR_e_CR_Fifth	0	1
CeCGSR_e_CR_Sixth	0	1
CeCGSR_e_CR-Seventh	0	1
CeCGSR_e_CR_Eighth	1	1
CeCGSR_e_CR_Ninth	0	1
CeCGSR_e_CR_Tenth	1	1

Initial Supporting table - P176B intermediate speed sensor fail count threshold

**Description:** P176B intermediate speed sensor fail count threshold

**Value Units:** fail counts  
**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	4	4

Initial Supporting table - P176B intermediate speed sensor fail time threshold		
<b>Description:</b> P176B intermediate speed sensor fail time threshold		
<b>Value Units:</b> seconds <b>X Unit:</b> intermediate speed sensor select		
y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	2.000	2.000

Initial Supporting table - P176B minimum estimated transmission intermediate speed to enable fail evaluation		
<b>Description:</b> minimum estimated transmission intermediate speed to enable fail evaluation, where estimate is based on transmission input speed / ratio calibration, where ratio calibration is either P176B ratio calibration when REVERSE or P176B ratio calibration when not REVERSE		
<b>Value Units:</b> estimated transmission intermediate speed RPM <b>X Unit:</b> intermediate speed sensor select		
y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	172.0	172.0

Initial Supporting table - P176B minimum transmission input speed to enable fail evaluation

**Description:** minimum transmission input speed to enable fail evaluation

**Value Units:** transmission input speed RPM

**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	172.0	172.0

Initial Supporting table - P176B ratio calibration when not REVERSE

**Description:** used to estimate transmission input speed based on transmission intermediate speed when range is not REVERSE

**Value Units:** ratio  
**X Unit:** commanded gear  
**Y Units:** intermediate speed sensor select

y/x	CeTGRR_e_Gear1	CeTGRR_e_Gear2	CeTGRR_e_Gear3	CeTGRR_e_Gear4	CeTGRR_e_Gear5	CeTGRR_e_Gear6	CeTGRR_e_Gear7	CeTGRR_e_Gear8	CeTGRR_e_Gear9	CeTGRR_e_Gear10
CeTSRR_e_C2 C_ClchSpdSnsr1	1.5848	6.3694	1.0000	2.4450	1.0000	0.5227	1.0000	1.0000	1.1905	1.0000
CeTSRR_e_C2 C_ClchSpdSnsr2	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000

Initial Supporting table - P176B ratio calibration when REVERSE

**Description:** used to estimate transmission input speed based on transmission intermediate speed when range is REVERSE

**Value Units:** ratio  
**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	1.0000	1.0000

Initial Supporting table - P17C5 P17D3 intermediate speed sensor RPM

**Description:** P17C5 P17D3 intermediate speed sensor RPM at signal period transtion to enable fail time update

**Value Units:** intermediate speed sensor RPM

**X Unit:** intermediate speed sensor 1 or 2

y/x	0	1
1	25	25



Initial Supporting table - P2D2 Cltch Slip Sum									
Description:									
Value Units: rate of change of output rpm (dn) per 25 milliseconds									
X Unit: % brake pedal position									
Y Units: not applicable, no units, single row table f(brake pedal position)									
y/x	0	15	20	30	35	50	75	88	100
1	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C1

**Description:** clutch 1 command pressure threshold below which clutch 1 is considered released, such that, clutch 1 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C1 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	131.3	131.3	9,999.0	344.3	409.6

#### P2D2 Decel Pressure - C1 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	9,999.0	131.3	344.3	131.3	9,999.0

#### P2D2 Decel Pressure - C1 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	9,999.0	9,999.0	9,999.0	50.0	50.0

#### P2D2 Decel Pressure - C1 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50.0	344.3	50.0	50.0	409.6

#### P2D2 Decel Pressure - C1 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	644.8	644.8	50.0	131.3	9,999.0

#### P2D2 Decel Pressure - C1 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	344.3	409.6	9,999.0	131.3	344.3

#### P2D2 Decel Pressure - C1 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	131.3	9,999.0	50.0	50.0	50.0

#### P2D2 Decel Pressure - C1 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	344.3	50.0	50.0	409.6	644.8

#### P2D2 Decel Pressure - C1 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C1					
1	644.8	50.0	131.3	9,999.0	9,999.0
P2D2 Decel Pressure - C1 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	9,999.0	9,999.0	9,999.0	9,999.0	9,999.0
P2D2 Decel Pressure - C1 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	9,999.0	644.8	409.6	344.3	50.0
P2D2 Decel Pressure - C1 - Part 12					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C2

**Description:** clutch 2 command pressure threshold below which clutch 2 is considered released, such that, clutch 2 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C2 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	359	359	359	9,999	2,125

#### P2D2 Decel Pressure - C2 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	801	489	359	512	9,999

#### P2D2 Decel Pressure - C2 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	2,125	801	489	50	50

#### P2D2 Decel Pressure - C2 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	9,999	50	50	2,125

#### P2D2 Decel Pressure - C2 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	765	765	50	359	359

#### P2D2 Decel Pressure - C2 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	9,999	2,125	801	489	359

#### P2D2 Decel Pressure - C2 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	512	9,999	50	50	50

#### P2D2 Decel Pressure - C2 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	9,999	50	50	2,125	765

#### P2D2 Decel Pressure - C2 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C2

1	765	50	512	570	570
<b>P2D2 Decel Pressure - C2 - Part 10</b>					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	9,999	9,999	2,125	801	489
<b>P2D2 Decel Pressure - C2 - Part 11</b>					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	359	765	2,125	9,999	50
<b>P2D2 Decel Pressure - C2 - Part 12</b>					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C3

**Description:** clutch 3 command pressure threshold below which clutch 3 is considered released, such that, clutch 3 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C3 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	245	245	247	1,293	9,999

#### P2D2 Decel Pressure - C3 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	706	245	247	245	1,294

#### P2D2 Decel Pressure - C3 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	9,999	706	360	50	50

#### P2D2 Decel Pressure - C3 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	1,293	50	50	9,999

#### P2D2 Decel Pressure - C3 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	674	674	50	245	247

#### P2D2 Decel Pressure - C3 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	1,293	9,999	706	245	247

#### P2D2 Decel Pressure - C3 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	245	1,294	50	50	50

#### P2D2 Decel Pressure - C3 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	1,293	50	50	9,999	674

#### P2D2 Decel Pressure - C3 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C3

1	674	50	245	273	273
P2D2 Decel Pressure - C3 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	1,294	1,294	9,999	706	360
P2D2 Decel Pressure - C3 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	247	674	9,999	1,293	50
P2D2 Decel Pressure - C3 - Part 12					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C4

**Description:** clutch 4 command pressure threshold below which clutch 4 is considered released, such that, clutch 4 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C4 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	433	433	482	1,041	1,585

#### P2D2 Decel Pressure - C4 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	9,999	433	915	433	1,145

#### P2D2 Decel Pressure - C4 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	1,713	9,999	1,772	50	50

#### P2D2 Decel Pressure - C4 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	1,041	50	50	1,585

#### P2D2 Decel Pressure - C4 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	9,999	9,999	50	433	482

#### P2D2 Decel Pressure - C4 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	1,041	1,585	9,999	433	915

#### P2D2 Decel Pressure - C4 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	433	1,145	50	50	50

#### P2D2 Decel Pressure - C4 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	1,041	50	50	1,585	9,999

#### P2D2 Decel Pressure - C4 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------



# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C4

1	9,999	50	433	482	482
P2D2 Decel Pressure - C4 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	1,145	1,145	1,713	9,999	1,772
P2D2 Decel Pressure - C4 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	915	2,030	1,585	1,041	50
P2D2 Decel Pressure - C4 - Part 12					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C5

**Description:** clutch 5 command pressure threshold below which clutch 5 is considered released, such that, clutch 5 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C5 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	140	140	140	255	318

#### P2D2 Decel Pressure - C5 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	646	9,999	685	140	255

#### P2D2 Decel Pressure - C5 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	318	646	9,999	50	50

#### P2D2 Decel Pressure - C5 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	780	50	50	1,188

#### P2D2 Decel Pressure - C5 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	9,999	50	50	140	140

#### P2D2 Decel Pressure - C5 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	255	318	646	9,999	685

#### P2D2 Decel Pressure - C5 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	140	255	50	50	50

#### P2D2 Decel Pressure - C5 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	780	50	50	1,188	9,999

#### P2D2 Decel Pressure - C5 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C5

1	50	50	9,999	140	140
P2D2 Decel Pressure - C5 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	255	255	318	646	9,999
P2D2 Decel Pressure - C5 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	685	9,999	1,188	780	50
P2D2 Decel Pressure - C5 - Part 12					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C6

**Description:** clutch 6 command pressure threshold below which clutch 6 is considered released, such that, clutch 6 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C6 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	178	178	178	283	330

#### P2D2 Decel Pressure - C6 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	504	253	9,999	178	283

#### P2D2 Decel Pressure - C6 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	330	504	1,036	50	50

#### P2D2 Decel Pressure - C6 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	9,999	50	50	9,999

#### P2D2 Decel Pressure - C6 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	50	9,999	50	178	178

#### P2D2 Decel Pressure - C6 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	283	330	504	253	9,999

#### P2D2 Decel Pressure - C6 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	178	283	50	50	50

#### P2D2 Decel Pressure - C6 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	9,999	50	50	9,999	50

#### P2D2 Decel Pressure - C6 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C6

1	9,999	50	253	178	178
<b>P2D2 Decel Pressure - C6 - Part 10</b>					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	283	283	330	504	1,036
<b>P2D2 Decel Pressure - C6 - Part 11</b>					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	9,999	9,999	9,999	9,999	50
<b>P2D2 Decel Pressure - C6 - Part 12</b>					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C7

**Description:** clutch 7 command pressure threshold below which clutch 7 is considered released, such that, clutch 7 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C7 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	50	50	50	9,999	50

#### P2D2 Decel Pressure - C7 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	9,999	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C7

1	50	50	9,999	9,999	50
P2D2 Decel Pressure - C7 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	50	50	50	50	50
P2D2 Decel Pressure - C7 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	50	50	50	50	50
P2D2 Decel Pressure - C7 - Part 12					
y/x					
1					

Initial Supporting table - transmission fluid temperature warm up time

Description:

**Value Units:** transmission fluid temperature normal warm up time, seconds  
**X Unit:** transmission fluid temperature at controller power up, °C

y/x	-40.00	-30.00	-20.00	0.00	20.00
1	1,800.0	1,500.0	1,200.0	600.0	60.0



## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P0606\_Last Seed Timeout f(Loop Time)

**Description:** The max time for the Last Seed Timeout as a function of operating loop time sequence.

#### P0606\_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000

#### P0606\_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	200.000	200.000	200.000	8,191.875	8,191.875	8,191.875	

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P0606\_PSW Sequence Fail f(Loop Time)

**Description:** Fail threshold for PSW per operating loop.

#### P0606\_PSW Sequence Fail f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	3	3	3	3	3	3	3

#### P0606\_PSW Sequence Fail f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	3	3	3	3	3	3	

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P0606\_PSW Sequence Sample f(Loop Time)

**Description:** Sample threshold for PSW per operating loop.

#### P0606\_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq	CePISR_e_40msSeq
1	4	4	4	4	4	4	4

#### P0606\_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq	
1	4	4	4	4	4	4	

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - 10 speed transmission clutch definition and gear state to clutch map

**Description:** indicates clutch definition and gear state verses applied and released clutches for 10 speed transmission

**Value Units:** applied or released

**X Unit:** clutch

**Y Units:** gear index Y axis, actual gear column 1

y/x	1	2	3	4	5	6	7	8
1		C1 = C123456R	C2 = C1289-10R	C3 = C234579-10	C4 = C234678-10R	C5 = C1356789	C6 = C456789-10R	C7 = OWC12
2	1st gear braking	applied	applied	released	released	applied	released	applied
3	1st gear free wheel	applied	applied	released	released	applied	released	released
4	2nd gear braking	applied	applied	applied	applied	released	released	applied
5	2nd gear free wheel	applied	applied	applied	applied	released	released	released
6	3rd gear	applied	released	applied	applied	applied	released	released
7	4th gear	applied	released	applied	applied	released	applied	released
8	5th gear	applied	released	applied	released	applied	applied	released
9	6th gear	applied	released	released	released	applied	applied	released
10	7th gear	released	released	applied	applied	applied	applied	released
11	8th gear	released	applied	released	applied	applied	applied	released
12	9th gear	released	applied	applied	released	applied	applied	released
13	10th gear	released	applied	applied	applied	released	applied	released
14	reverse gear	applied	applied	released	applied	released	released	released

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - 9 speed transmission clutch definition and gear state to clutch map

**Description:** indicates clutch definition and gear state verses applied and released clutches for 9 speed transmission

**Value Units:** applied or released

**X Unit:** clutch

**Y Units:** gear index Y axis, actual gear column 1

y/x	1	2	3	4	5	6	7	8
1		C1 = CB123456	C2 = C6789	C3 = CB1R	C4 = CB29	C5 = CB38	C6 = C4	C7 = C57R
2	1st gear braking	applied	released	applied	released	released	released	released
3	1st gear free wheel	applied	released	released	released	released	released	released
4	2nd gear	applied	released	released	applied	released	released	released
5	3rd gear	applied	released	released	released	applied	released	released
6	4th gear	applied	released	released	released	released	applied	released
7	5th gear	applied	released	released	released	released	released	applied
8	6th gear	applied	applied	released	released	released	released	released
9	7th gear	released	applied	released	released	released	released	applied
10	8th gear	released	applied	released	released	applied	released	released
11	9th gear	released	applied	released	applied	released	released	released
12	reverse gear	released	released	applied	released	released	released	applied

Initial Supporting table - engine speed time for transmission hydraulic pressure available

**Description:** time needed for engine speed to trigger "transmission hydraulic pressure available"

**Value Units:** seconds  
**X Unit:** °C

y/x	-40.00	-30.00	-20.00	0.00	40.00
1	0.300	0.300	0.275	0.200	0.200

Initial Supporting table - engine speed time for transmission hydraulic pressure available

**Description:** ime needed for engine speed to trigger "transmission hydraulic pressure available"

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-30.00	-20.00	0.00	40.00
1	0.300	0.300	0.275	0.200	0.200

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - NumClchTieUp

**Description:** NumClchTieUp

**Value Units:** minimum # of clutches

**X Unit:** command gear or attained gear

**Y Units:** not applicable, no units, single row table f(gear)

### NumClchTieUp - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5
1	2	3	2	2	2	2	2

### NumClchTieUp - Part 2

y/x	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3
1	2	2	1	1	1	1	1

### NumClchTieUp - Part 3

y/x	CeCGSR_e_NeutralC2C4	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6	CeCGSR_e_NeutralC4C5
1	1	1	1	1	1	1	1

### NumClchTieUp - Part 4

y/x	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4
1	1	1	3	2	2	2	2

### NumClchTieUp - Part 5

y/x	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	2	2	2	1	1	1	1

### NumClchTieUp - Part 6

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5
1	1	1	1	1	1	1	1

### NumClchTieUp - Part 7

y/x	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth
1	1	1	2	1	1	1	1

### NumClchTieUp - Part 8

y/x	CeCGSR_e_Fifth	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth	
-----	----------------	----------------	------------------	-----------------	----------------	----------------	--



Initial Supporting table - NumClchTieUp							
1	1	1	1	1	1	1	

Initial Supporting table - P0741 (GF9 specific) TCC slip speed crash RPM

**Description:** RPM limit used to establish slip crashed when TCC oil became available

**Value Units:** RPM  
**X Unit:** % accelerator position

y/x	0.00	15.00	25.00	50.00	75.00
1	100	100	160	233	300

Initial Supporting table - P176B delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation		
<b>Description:</b> delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation		
<b>Value Units:</b> seconds <b>X Unit:</b> intermediate speed sensor select		
y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	1.000	1.000

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P176B holding clutch states

**Description:** inditaces when the clutch states allow transmission intermediate speed sensor evaluation, when rotating components can trigger speed sesnor, holding clutches will not allow evaluation while clutches not holding will allow evaluation

**Value Units:** TRUE or FALSE

**X Unit:** intermediate speed sensor select

**Y Units:** commanded gear

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
CeCGSR_e_CR_NullForSched	1	1
CeCGSR_e_CR_Neutral	1	1
CeCGSR_e_CR_Park	1	1
CeCGSR_e_CR_Reverse	0	1
CeCGSR_e_CR_First	0	1
CeCGSR_e_CR_Second	0	1
CeCGSR_e_CR_Third	1	1
CeCGSR_e_CR_Fourth	0	1
CeCGSR_e_CR_Fifth	0	1
CeCGSR_e_CR_Sixth	0	1
CeCGSR_e_CR-Seventh	0	1
CeCGSR_e_CR_Eighth	1	1
CeCGSR_e_CR_Ninth	0	1
CeCGSR_e_CR_Tenth	1	1

Initial Supporting table - P176B intermediate speed sensor fail count threshold

**Description:** P176B intermediate speed sensor fail count threshold

**Value Units:** fail counts  
**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	4	4

Initial Supporting table - P176B intermediate speed sensor fail time threshold		
<b>Description:</b> P176B intermediate speed sensor fail time threshold		
<b>Value Units:</b> seconds <b>X Unit:</b> intermediate speed sensor select		
y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	2.000	2.000

Initial Supporting table - P176B minimum estimated transmission intermediate speed to enable fail evaluation		
<b>Description:</b> minimum estimated transmission intermediate speed to enable fail evaluation, where estimate is based on transmission input speed / ratio calibration, where ratio calibration is either P176B ratio calibration when REVERSE or P176B ratio calibration when not REVERSE		
<b>Value Units:</b> estimated transmission intermediate speed RPM <b>X Unit:</b> intermediate speed sensor select		
y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	172.0	172.0

Initial Supporting table - P176B minimum transmission input speed to enable fail evaluation

**Description:** minimum transmission input speed to enable fail evaluation

**Value Units:** transmission input speed RPM

**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	172.0	172.0



## Initial Supporting table - P176B ratio calibration when not REVERSE

**Description:** used to estimate transmission input speed based on transmission intermediate speed when range is not REVERSE**Value Units:** ratio**X Unit:** commanded gear**Y Units:** intermediate speed sensor select

y/x	CeTGRR_e_Gear1	CeTGRR_e_Gear2	CeTGRR_e_Gear3	CeTGRR_e_Gear4	CeTGRR_e_Gear5	CeTGRR_e_Gear6	CeTGRR_e_Gear7	CeTGRR_e_Gear8	CeTGRR_e_Gear9	CeTGRR_e_Gear10
CeTSRR_e_C2 C_ClchSpdSnsr 1	1.5848	6.3694	1.0000	2.4450	1.0000	0.5227	1.0000	1.0000	1.1905	1.0000
CeTSRR_e_C2 C_ClchSpdSnsr 2	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000

Initial Supporting table - P176B ratio calibration when REVERSE

**Description:** used to estimate transmission input speed based on transmission intermediate speed when range is REVERSE

**Value Units:** ratio  
**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	1.0000	1.0000

Initial Supporting table - P17C5 P17D3 intermediate speed sensor RPM

**Description:** P17C5 P17D3 intermediate speed sensor RPM at signal period transtion to enable fail time update

**Value Units:** intermediate speed sensor RPM

**X Unit:** intermediate speed sensor 1 or 2

y/x	0	1
1	25	25

Initial Supporting table - P2817 TCC stuck off fail TCC slip speed

**Description:** TCC stuck off slip speed fail threshold when TCC is in ON mode (controlled slip mode)

**Value Units:** RPM  
**X Unit:** engine torque Nm

y/x	0.00	64.00	128.00	192.00	256.00	320.00	384.00	448.00	512.00
1	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0

Initial Supporting table - P2818 (GF9 specific) control valve test time			
<b>Description:</b> Value to initialize the torque converter clutch control valve test time to after clutch select valve solenoid is turned on, window of time in which the torque converter clutch slip speed and derivative slip speed must be evaluated for failure. Window is a time down window from the calibration value to zero (0.0) seconds.			
<b>Value Units:</b> seconds <b>X Unit:</b> transmission fluid temperature °C			
y/x	-7.00	10.00	40.00
1	0.600	0.300	0.100

Initial Supporting table - P2818 stuck on test time

**Description:** Value to initialize the TCC Stuck On test time to after transition of clutch select valve allowing TCC hydraulic circuit connectivity. Window is a time down window from the calibration value to zero (0.0) seconds.

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
1	1.500	1.250	1.000

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2818 torque convert derivative slip speed fail threshold

**Description:** The fail threshold, rate of change of torque converter slip speed, at which the torque convert clutch is considered stuck on.

**Value Units:** RPM/second

**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
0	-600.0	-600.0	-600.0
15	-600.0	-600.0	-600.0
25	-900.0	-900.0	-900.0
50	-1,200.0	-1,200.0	-1,200.0
75	-1,500.0	-1,500.0	-1,500.0

Initial Supporting table - P2D2 Cltch Slip Sum									
Description:									
Value Units: rate of change of output rpm (dn) per 25 milliseconds									
X Unit: % brake pedal position									
Y Units: not applicable, no units, single row table f(brake pedal position)									
y/x	0	15	20	30	35	50	75	88	100
1	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192



## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C1

**Description:** clutch 1 command pressure threshold below which clutch 1 is considered released, such that, clutch 1 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C1 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	131.3	131.3	9,999.0	344.3	409.6

#### P2D2 Decel Pressure - C1 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	9,999.0	131.3	344.3	131.3	9,999.0

#### P2D2 Decel Pressure - C1 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	9,999.0	9,999.0	9,999.0	50.0	50.0

#### P2D2 Decel Pressure - C1 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50.0	344.3	50.0	50.0	409.6

#### P2D2 Decel Pressure - C1 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	644.8	644.8	50.0	131.3	9,999.0

#### P2D2 Decel Pressure - C1 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	344.3	409.6	9,999.0	131.3	344.3

#### P2D2 Decel Pressure - C1 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	131.3	9,999.0	50.0	50.0	50.0

#### P2D2 Decel Pressure - C1 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	344.3	50.0	50.0	409.6	644.8

#### P2D2 Decel Pressure - C1 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C1

1	644.8	50.0	131.3	9,999.0	9,999.0
<b>P2D2 Decel Pressure - C1 - Part 10</b>					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	9,999.0	9,999.0	9,999.0	9,999.0	9,999.0
<b>P2D2 Decel Pressure - C1 - Part 11</b>					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	9,999.0	644.8	409.6	344.3	50.0
<b>P2D2 Decel Pressure - C1 - Part 12</b>					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C2

**Description:** clutch 2 command pressure threshold below which clutch 2 is considered released, such that, clutch 2 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C2 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	359	359	359	9,999	2,125

#### P2D2 Decel Pressure - C2 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	801	489	359	512	9,999

#### P2D2 Decel Pressure - C2 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	2,125	801	489	50	50

#### P2D2 Decel Pressure - C2 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	9,999	50	50	2,125

#### P2D2 Decel Pressure - C2 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	765	765	50	359	359

#### P2D2 Decel Pressure - C2 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	9,999	2,125	801	489	359

#### P2D2 Decel Pressure - C2 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	512	9,999	50	50	50

#### P2D2 Decel Pressure - C2 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	9,999	50	50	2,125	765

#### P2D2 Decel Pressure - C2 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C2

1	765	50	512	570	570
P2D2 Decel Pressure - C2 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	9,999	9,999	2,125	801	489
P2D2 Decel Pressure - C2 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	359	765	2,125	9,999	50
P2D2 Decel Pressure - C2 - Part 12					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C3

**Description:** clutch 3 command pressure threshold below which clutch 3 is considered released, such that, clutch 3 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C3 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	245	245	247	1,293	9,999

#### P2D2 Decel Pressure - C3 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	706	245	247	245	1,294

#### P2D2 Decel Pressure - C3 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	9,999	706	360	50	50

#### P2D2 Decel Pressure - C3 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	1,293	50	50	9,999

#### P2D2 Decel Pressure - C3 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	674	674	50	245	247

#### P2D2 Decel Pressure - C3 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	1,293	9,999	706	245	247

#### P2D2 Decel Pressure - C3 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	245	1,294	50	50	50

#### P2D2 Decel Pressure - C3 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	1,293	50	50	9,999	674

#### P2D2 Decel Pressure - C3 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C3

1	674	50	245	273	273
P2D2 Decel Pressure - C3 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	1,294	1,294	9,999	706	360
P2D2 Decel Pressure - C3 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	247	674	9,999	1,293	50
P2D2 Decel Pressure - C3 - Part 12					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C4

**Description:** clutch 4 command pressure threshold below which clutch 4 is considered released, such that, clutch 4 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C4 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	433	433	482	1,041	1,585

#### P2D2 Decel Pressure - C4 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	9,999	433	915	433	1,145

#### P2D2 Decel Pressure - C4 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	1,713	9,999	1,772	50	50

#### P2D2 Decel Pressure - C4 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	1,041	50	50	1,585

#### P2D2 Decel Pressure - C4 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	9,999	9,999	50	433	482

#### P2D2 Decel Pressure - C4 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	1,041	1,585	9,999	433	915

#### P2D2 Decel Pressure - C4 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	433	1,145	50	50	50

#### P2D2 Decel Pressure - C4 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	1,041	50	50	1,585	9,999

#### P2D2 Decel Pressure - C4 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C4

1	9,999	50	433	482	482
P2D2 Decel Pressure - C4 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	1,145	1,145	1,713	9,999	1,772
P2D2 Decel Pressure - C4 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	915	2,030	1,585	1,041	50
P2D2 Decel Pressure - C4 - Part 12					
y/x					
1					



## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C5

**Description:** clutch 5 command pressure threshold below which clutch 5 is considered released, such that, clutch 5 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C5 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	140	140	140	255	318

#### P2D2 Decel Pressure - C5 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	646	9,999	685	140	255

#### P2D2 Decel Pressure - C5 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	318	646	9,999	50	50

#### P2D2 Decel Pressure - C5 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	780	50	50	1,188

#### P2D2 Decel Pressure - C5 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	9,999	50	50	140	140

#### P2D2 Decel Pressure - C5 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	255	318	646	9,999	685

#### P2D2 Decel Pressure - C5 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	140	255	50	50	50

#### P2D2 Decel Pressure - C5 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	780	50	50	1,188	9,999

#### P2D2 Decel Pressure - C5 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C5

1	50	50	9,999	140	140
P2D2 Decel Pressure - C5 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	255	255	318	646	9,999
P2D2 Decel Pressure - C5 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	685	9,999	1,188	780	50
P2D2 Decel Pressure - C5 - Part 12					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C6

**Description:** clutch 6 command pressure threshold below which clutch 6 is considered released, such that, clutch 6 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C6 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	178	178	178	283	330

#### P2D2 Decel Pressure - C6 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	504	253	9,999	178	283

#### P2D2 Decel Pressure - C6 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	330	504	1,036	50	50

#### P2D2 Decel Pressure - C6 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	9,999	50	50	9,999

#### P2D2 Decel Pressure - C6 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	50	9,999	50	178	178

#### P2D2 Decel Pressure - C6 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	283	330	504	253	9,999

#### P2D2 Decel Pressure - C6 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	178	283	50	50	50

#### P2D2 Decel Pressure - C6 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	9,999	50	50	9,999	50

#### P2D2 Decel Pressure - C6 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C6

1	9,999	50	253	178	178
<b>P2D2 Decel Pressure - C6 - Part 10</b>					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	283	283	330	504	1,036
<b>P2D2 Decel Pressure - C6 - Part 11</b>					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	9,999	9,999	9,999	9,999	50
<b>P2D2 Decel Pressure - C6 - Part 12</b>					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C7

**Description:** clutch 7 command pressure threshold below which clutch 7 is considered released, such that, clutch 7 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C7 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	50	50	50	9,999	50

#### P2D2 Decel Pressure - C7 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	9,999	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C7

1	50	50	9,999	9,999	50
P2D2 Decel Pressure - C7 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	50	50	50	50	50
P2D2 Decel Pressure - C7 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	50	50	50	50	50
P2D2 Decel Pressure - C7 - Part 12					
y/x					
1					

Initial Supporting table - transmission fluid temperature warm up time

Description:

**Value Units:** transmission fluid temperature normal warm up time, seconds  
**X Unit:** transmission fluid temperature at controller power up, °C

y/x	-40.00	-30.00	-20.00	0.00	20.00
1	1,800.0	1,500.0	1,200.0	600.0	60.0

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - 10 speed transmission clutch definition and gear state to clutch map

**Description:** indicates clutch definition and gear state verses applied and released clutches for 10 speed transmission

**Value Units:** applied or released

**X Unit:** clutch

**Y Units:** gear index Y axis, actual gear column 1

y/x	1	2	3	4	5	6	7	8
1		C1 = C123456R	C2 = C1289-10R	C3 = C234579-10	C4 = C234678-10R	C5 = C1356789	C6 = C456789-10R	C7 = OWC12
2	1st gear braking	applied	applied	released	released	applied	released	applied
3	1st gear free wheel	applied	applied	released	released	applied	released	released
4	2nd gear braking	applied	applied	applied	applied	released	released	applied
5	2nd gear free wheel	applied	applied	applied	applied	released	released	released
6	3rd gear	applied	released	applied	applied	applied	released	released
7	4th gear	applied	released	applied	applied	released	applied	released
8	5th gear	applied	released	applied	released	applied	applied	released
9	6th gear	applied	released	released	released	applied	applied	released
10	7th gear	released	released	applied	applied	applied	applied	released
11	8th gear	released	applied	released	applied	applied	applied	released
12	9th gear	released	applied	applied	released	applied	applied	released
13	10th gear	released	applied	applied	applied	released	applied	released
14	reverse gear	applied	applied	released	applied	released	released	released



## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - 9 speed transmission clutch definition and gear state to clutch map

**Description:** indicates clutch definition and gear state verses applied and released clutches for 9 speed transmission

**Value Units:** applied or released

**X Unit:** clutch

**Y Units:** gear index Y axis, actual gear column 1

y/x	1	2	3	4	5	6	7	8
1		C1 = CB123456	C2 = C6789	C3 = CB1R	C4 = CB29	C5 = CB38	C6 = C4	C7 = C57R
2	1st gear braking	applied	released	applied	released	released	released	released
3	1st gear free wheel	applied	released	released	released	released	released	released
4	2nd gear	applied	released	released	applied	released	released	released
5	3rd gear	applied	released	released	released	applied	released	released
6	4th gear	applied	released	released	released	released	applied	released
7	5th gear	applied	released	released	released	released	released	applied
8	6th gear	applied	applied	released	released	released	released	released
9	7th gear	released	applied	released	released	released	released	applied
10	8th gear	released	applied	released	released	applied	released	released
11	9th gear	released	applied	released	applied	released	released	released
12	reverse gear	released	released	applied	released	released	released	applied

Initial Supporting table - C1 exhaust delay closed throttle down shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in closed throttle down shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C1 exhaust delay closed throttle lift foot up shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in closed throttle lift foot up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C1 exhaust delay garage shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in garage shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C1 exhaust delay negative torque up shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in negative torque up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.500	0.500	0.500	0.500	0.500

Initial Supporting table - C1 exhaust delay open throttle power down shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in open throttle power down shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C1 exhaust delay open throttle power on up shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in open throttle power on up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	2.000	1.100	0.813	0.500	0.269

Initial Supporting table - C2 exhaust delay closed throttle down shift

**Description:** P0777 C2 clutch hydraulic circuit exhaust time in closed throttle down shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.350	0.200



Initial Supporting table - C2 exhaust delay closed throttle lift foot up shift					
Description: P0777 C2 clutch hydraulic circuit exhaust time in closed throttle lift foot up shift					
Value Units: seconds					
X Unit: transmission fluid temperature °C					
y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C2 exhaust delay garage shift

**Description:** P0777 C2 clutch hydraulic circuit exhaust time in garage shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C2 exhaust delay negative torque up shift

**Description:** P0777 C2 clutch hydraulic circuit exhaust time in negative torque up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.500	0.500	0.500	0.500	0.500

Initial Supporting table - C2 exhaust delay open throttle power down shift

**Description:** P0777 C2 clutch hydraulic circuit exhaust time in open throttle power down shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.212	0.212

Initial Supporting table - C2 exhaust delay open throttle power on up shift

**Description:** P0777 C2 clutch hydraulic circuit exhaust time in open throttle power on up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	3.100	0.900	0.800	0.700	0.262

Initial Supporting table - C3 exhaust delay closed throttle down shift

**Description:** P0797 C3 clutch hydraulic circuit exhaust time in closed throttle down shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.300	1.000	0.950	0.469	0.200

Initial Supporting table - C3 exhaust delay closed throttle lift foot up shift

**Description:** P0797 C3 clutch hydraulic circuit exhaust time in closed throttle lift foot up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C3 exhaust delay garage shift

**Description:** P0797 C3 clutch hydraulic circuit exhaust time in garage shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850



Initial Supporting table - C3 exhaust delay negative torque up shift

**Description:** P0797 C3 clutch hydraulic circuit exhaust time in negative torque up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.500	0.500	0.500	0.500	0.500

Initial Supporting table - C3 exhaust delay open throttle power down shift

**Description:** P0797 C3 clutch hydraulic circuit exhaust time in open throttle power down shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.387	0.144

Initial Supporting table - C3 exhaust delay open throttle power on up shift

**Description:** P0797 C3 clutch hydraulic circuit exhaust time in open throttle power on up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.900	0.800	0.750	0.650	0.256

Initial Supporting table - C4 exhaust delay closed throttle down shift

**Description:** P2715 C4 clutch hydraulic circuit exhaust time in closed throttle down shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.400	0.750	0.700	0.663	0.225

Initial Supporting table - C4 exhaust delay closed throttle lift foot up shift

**Description:** P2715 C4 clutch hydraulic circuit exhaust time in closed throttle lift foot up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C4 exhaust delay garage shift

**Description:** P2715 C4 clutch hydraulic circuit exhaust time in garage shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C4 exhaust delay negative torque up shift

**Description:** P2715 C4 clutch hydraulic circuit exhaust time in negative torque up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.500	0.500	0.500	0.500	0.500

Initial Supporting table - C4 exhaust delay open throttle power down shift

**Description:** P2715 C4 clutch hydraulic circuit exhaust time in open throttle power down shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.119	0.119



Initial Supporting table - C4 exhaust delay open throttle power on up shift

**Description:** P2715 C4 clutch hydraulic circuit exhaust time in open throttle power on up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.900	0.650	0.600	0.550	0.300

Initial Supporting table - C5 exhaust delay closed throttle down shift

**Description:** P2724 C5 clutch hydraulic circuit exhaust time in closed throttle down shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.700	1.369	1.100	0.650	0.337

Initial Supporting table - C5 exhaust delay closed throttle lift foot up shift

**Description:** P2724 C5 clutch hydraulic circuit exhaust time in closed throttle lift foot up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C5 exhaust delay garage shift

**Description:** P2724 C5 clutch hydraulic circuit exhaust time in garage shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40	-20	0	30	110
1	2	1	1	1	1

Initial Supporting table - C5 exhaust delay negative torque up shift

**Description:** P0747 C1 clutch hydraulic circuit exhaust time in negative torque up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.500	0.500	0.500	0.500	0.500

Initial Supporting table - C5 exhaust delay open throttle power down shift

**Description:** P2724 C5 clutch hydraulic circuit exhaust time in open throttle power down shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.900	0.613	0.450	0.300	0.163

Initial Supporting table - C5 exhaust delay open throttle power on up shift

**Description:** P2724 C5 clutch hydraulic circuit exhaust time in open throttle power on up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	2.900	1.350	1.100	0.850	0.406

Initial Supporting table - C6 exhaust delay closed throttle down shift

**Description:** P2733 C6 clutch hydraulic circuit exhaust time in closed throttle down shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.400	1.100	0.719	0.400	0.350



Initial Supporting table - C6 exhaust delay closed throttle lift foot up shift

**Description:** P2733 C6 clutch hydraulic circuit exhaust time in closed throttle lift foot up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C6 exhaust delay garage shift

**Description:** P2733 C6 clutch hydraulic circuit exhaust time in garage shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.850	0.850

Initial Supporting table - C6 exhaust delay negative torque up shift

**Description:** P2733 C6 clutch hydraulic circuit exhaust time in negative torque up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.500	0.500	0.500	0.500	0.500

Initial Supporting table - C6 exhaust delay open throttle power down shift

**Description:** P2733 C6 clutch hydraulic circuit exhaust time in open throttle power down shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	0.850	0.350	0.300	0.238	0.131

Initial Supporting table - C6 exhaust delay open throttle power on up shift

**Description:** P2733 C6 clutch hydraulic circuit exhaust time in open throttle power on up shift

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-20.00	0.00	30.00	110.00
1	1.600	1.100	0.950	0.600	0.600

Initial Supporting table - Clutch Clip Press CD Shifts

**Description:** Oncoming clutch clip pressure for closed throttle down shifts

**Value Units:** kPa  
**X Unit:** Oncoming Clutch

y/x	CeTSER_e_C1_Clutch	CeTSER_e_C2_Clutch	CeTSER_e_C3_Clutch	CeTSER_e_C4_Clutch	CeTSER_e_C5_Clutch	CeTSER_e_C6_Clutch
1	690	800	500	850	703	655

Initial Supporting table - Clutch Clip Press CU Shifts

**Description:** Oncoming clutch clip pressure for closed throttle lift foot up shifts

**Value Units:** kPa  
**X Unit:** Oncoming Clutch

y/x	CeTSER_e_C1_Clutch	CeTSER_e_C2_Clutch	CeTSER_e_C3_Clutch	CeTSER_e_C4_Clutch	CeTSER_e_C5_Clutch	CeTSER_e_C6_Clutch
1	690	800	500	850	703	655

Initial Supporting table - Clutch Clip Press GS Shifts

**Description:** Oncoming clutch clip pressure for garage shifts

**Value Units:** kPa  
**X Unit:** Oncoming Clutch

y/x	CeTSER_e_C1_Clutch	CeTSER_e_C2_Clutch	CeTSER_e_C3_Clutch	CeTSER_e_C4_Clutch	CeTSER_e_C5_Clutch	CeTSER_e_C6_Clutch
1	750	750	750	750	750	750



Initial Supporting table - Clutch Clip Press NU Shifts

**Description:** Oncoming clutch clip pressure for negative torque up shifts

**Value Units:** kPa  
**X Unit:** Oncoming Clutch

y/x	CeTSER_e_C1_Clutch	CeTSER_e_C2_Clutch	CeTSER_e_C3_Clutch	CeTSER_e_C4_Clutch	CeTSER_e_C5_Clutch	CeTSER_e_C6_Clutch
1	690	800	500	850	703	655

Initial Supporting table - Clutch Clip Press PD Shifts

**Description:** Oncoming clutch clip pressure for open throttle power down shifts

**Value Units:** kPa  
**X Unit:** Oncoming Clutch

y/x	CeTSER_e_C1_Clutch	CeTSER_e_C2_Clutch	CeTSER_e_C3_Clutch	CeTSER_e_C4_Clutch	CeTSER_e_C5_Clutch	CeTSER_e_C6_Clutch
1	400	800	500	850	703	655

Initial Supporting table - Clutch Clip Press PU Shifts

**Description:** Oncoming clutch clip pressure for open throttle powered up shifts

**Value Units:** kPa  
**X Unit:** Oncoming Clutch

y/x	CeTSER_e_C1_Clutch	CeTSER_e_C2_Clutch	CeTSER_e_C3_Clutch	CeTSER_e_C4_Clutch	CeTSER_e_C5_Clutch	CeTSER_e_C6_Clutch
1	2,100	900	500	850	703	655

Initial Supporting table - Clutch Stuck On Fail Offset Time CD Shifts

**Description:** Used for closed throttle down shifts to add additional fail time based on oil temperature

**Value Units:** time (seconds)  
**X Unit:** transmission fluid temperature °C

y/x	-40	-20	0	30	110
1	0	0	0	0	0

Initial Supporting table - Clutch Stuck On Fail Offset Time GS Shifts

**Description:** Used for garage shifts to add additional fail time based on oil temperature

**Value Units:** time (seconds)  
**X Unit:** transmission fluid temperature °C

y/x	-40	-20	0	30	110
1	0	0	0	0	0

Initial Supporting table - Clutch Stuck On Fail Offset Time PD Shifts

**Description:** Used for open throttle power down shifts to add additional fail time based on oil temperature

**Value Units:** time (seconds)  
**X Unit:** transmission fluid temperature °C

y/x	-40	-20	0	30	110
1	1	0	0	0	0

Initial Supporting table - Clutch Stuck On Fail Offset Time PU Shifts

**Description:** Used for powered up shifts to add additional fail time based on oil temperature

**Value Units:** time (seconds)  
**X Unit:** transmission fluid temperature °C

y/x	-40	-20	0	30	110
1	0	0	0	0	0

Initial Supporting table - Clutch Stuck On Fail Offset Time STGR Shifts

**Description:** Used for clutch staging shifts to add additional fail time based on oil temperature

**Value Units:** time (seconds)  
**X Unit:** transmission fluid temperature °C

y/x	-40	-20	0	30	110
1	0	0	0	0	0



Initial Supporting table - Clutch Stuck On Shift Type Enable

**Description:** Calibration to enable the clutch stuck on test for each shift type

**X Unit:** Shift Type

**Y Units:** Boolean

y/x	CeTSER_e_STGR	CeTSER_e_GSCR	CeTSER_e_NUCR	CeTSER_e_PUCR	CeTSER_e_CDCR	CeTSER_e_PDCR	CeTSER_e_CLAR
1	0	0	1	1	1	1	0

Initial Supporting table - engine speed time for transmission hydraulic pressure available

**Description:** time needed for engine speed to trigger "transmission hydraulic pressure available"

**Value Units:** seconds  
**X Unit:** °C

y/x	-40.00	-30.00	-20.00	0.00	40.00
1	0.300	0.300	0.275	0.200	0.200

Initial Supporting table - engine speed time for transmission hydraulic pressure available

**Description:** ime needed for engine speed to trigger "transmission hydraulic pressure available"

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-40.00	-30.00	-20.00	0.00	40.00
1	0.300	0.300	0.275	0.200	0.200

Initial Supporting table - Hydraulic Press Avail Tm Thrsh

**Description:** hydraulic system pressure is available when engine speed is above engine speed threshold for this amount of time

**Value Units:** seconds  
**X Unit:** transmission fluid temperature, degrees Celsius  
**Y Units:** unitless

y/x	-40.00	-30.00	-20.00	0.00	40.00
1	0.300	0.300	0.275	0.200	0.200

Initial Supporting table - Mode Valve A Eng Off Dly Lim

**Description:** used for both engine off mode valve A stability delay time required to enable fail time update and fail time threshold

**Value Units:** seconds  
**X Unit:** transmission fluid temperature, degrees Celsius  
**Y Units:** unitless

y/x	-40	-20	0	20	130
1	3.000	2.400	2.000	1.000	0.500

Initial Supporting table - Mode Valve A Eng Off ML Lim

**Description:** Mode Valve A transition limit when the engine and one or more HSD's are off or when max line pressure is being commanded. Temp based.

**Value Units:** Seconds  
**X Unit:** Degrees C  
**Y Units:** unitless

y/x	-40	-20	0	20	130
1	15	10	5	2	2

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - Mode Valve A Final State

**Description:** ETRS mode valve A position

**Value Units:** mode valve position

**X Unit:** ETRS diagnostic range

**Y Units:** ETRS command direction

### Mode Valve A Final State - Part 1

y/x	1	2	3
1		CeSTGR_e_ETRS_Park	CeSTGR_e_ETRS_NeutLo
2	CeSTGR_e_ETRS_Park	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
3	CeSTGR_e_ETRS_NeutLo	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
4	CeSTGR_e_ETRS_NeutHi	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
5	CeSTGR_e_ETRS_Drive	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh
6	CeSTGR_e_ETRS_Rvrs	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
7	CeSTGR_e_ETRS_NeutShf	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh

### Mode Valve A Final State - Part 2

y/x	4	5	6
1	CeSTGR_e_ETRS_NeutHi	CeSTGR_e_ETRS_Drive	CeSTGR_e_ETRS_Rvrs
2	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
3	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
4	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
5	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh
6	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
7	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh

### Mode Valve A Final State - Part 3

y/x	7		
1	CeSTGR_e_ETRS_NeutShf		
2	CePSCR_e_ModeValveLow		
3	CePSCR_e_ModeValveLow		
4	CePSCR_e_ModeValveLow		
5	CePSCR_e_ModeValveHigh		
6	CePSCR_e_ModeValveLow		
7	CePSCR_e_ModeValveHigh		

Initial Supporting table - Mode Valve A StdySt Rmdl Lim

**Description:** Cal limit for Mode Valve B turbine delay. Temp based. Amount the VaPSDR\_t\_MV\_SS\_Dly timer reaches limit before a slip check will be made to determine if the failure is a sensor or a value

**Value Units:** Seconds  
**X Unit:** Degrees C  
**Y Units:** unitless

y/x	-40	-20	0	20	130
1	0	0	0	0	0



Initial Supporting table - Mode Valve A steady state turbine speed delay

**Description:** ETRS mode valve A steady state turbine speed delay

**Value Units:** seconds  
**X Unit:** transmission fluid temperature, degrees Celsius  
**Y Units:** unitless

y/x	-40.0	-20.0	0.0	20.0	130.0
1	2.300	1.800	1.000	0.500	0.300

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - Mode Valve A Trnstn State

**Description:** Mode Valve A transition state

**Value Units:** TePSCR\_e\_ModeValveStat

**X Unit:** CeSTGR\_i\_ETRS\_CmndDirctn

**Y Units:** CeSTGR\_i\_ETRS\_CmndDirctn

y/x	CeSTGR_e_ETRS_Park	CeSTGR_e_ETRS_NeutLo	CeSTGR_e_ETRS_NeutHi	CeSTGR_e_ETRS_Drive	CeSTGR_e_ETRS_Rvrs	CeSTGR_e_ETRS_NeutShf
CeSTGR_e_ETRS_Park	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
CeSTGR_e_ETRS_NeutLo	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
CeSTGR_e_ETRS_NeutHi	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
CeSTGR_e_ETRS_Drive	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveLow
CeSTGR_e_ETRS_Rvrs	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
CeSTGR_e_ETRS_NeutShf	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh

Initial Supporting table - Mode Valve B Eng Off Dly Lim

**Description:** used for both engine off mode valve B stability delay time required to enable fail time update and fail time threshold

**Value Units:** seconds  
**X Unit:** transmission fluid temperature, degrees Celsius

y/x	-40	-20	0	20	130
1	3.000	2.400	2.000	1.000	0.500

Initial Supporting table - Mode Valve B Eng Off ML Lim

**Description:** Mode Valve B transition limit when the engine and one or more HSD's are off or when max line pressure is being commanded. Temp based.

**Value Units:** Seconds  
**X Unit:** Degrees C  
**Y Units:** unitless

y/x	-40	-20	0	20	130
1	15	10	5	2	2

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - Mode Valve B Final State

**Description:** ETRS mode valve B position

**Value Units:** mode valve B position

**X Unit:** ETRS diagnostic range

### Mode Valve B Final State - Part 1

y/x	1	2	3
1		CeSTGR_e_ETRS_Park	CeSTGR_e_ETRS_NeutLo
2	CeSTGR_e_ETRS_Park	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
3	CeSTGR_e_ETRS_NeutLo	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
4	CeSTGR_e_ETRS_NeutHi	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh
5	CeSTGR_e_ETRS_Drive	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
6	CeSTGR_e_ETRS_Rvrs	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh
7	CeSTGR_e_ETRS_NeutShf	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh

### Mode Valve B Final State - Part 2

y/x	4	5	6
1	CeSTGR_e_ETRS_NeutHi	CeSTGR_e_ETRS_Drive	CeSTGR_e_ETRS_Rvrs
2	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
3	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
4	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh
5	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
6	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh
7	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh

### Mode Valve B Final State - Part 3

y/x	7		
1	CeSTGR_e_ETRS_NeutShf		
2	CePSCR_e_ModeValveLow		
3	CePSCR_e_ModeValveLow		
4	CePSCR_e_ModeValveHigh		
5	CePSCR_e_ModeValveLow		
6	CePSCR_e_ModeValveHigh		
7	CePSCR_e_ModeValveHigh		

Initial Supporting table - Mode Valve B garage shift turbine speed delay limit					
Description: ETRS mode valve A garage shift transtion turbine speed delay					
Value Units: seconds					
X Unit: transmission fluid temperature, degrees Celsius					
y/x	-40.0	-20.0	0.0	20.0	130.0
1	0.250	0.250	0.250	0.250	0.250

Initial Supporting table - Mode Valve B StdySt Rmdl Lim

**Description:** Cal limit for Mode Valve B turbine delay. Temp based. Amount the VaPSDR\_t\_MV\_SS\_Dly timer reaches limit before a slip check will be made to determine if the failure is a sensor or a value

**Value Units:** Seconds  
**X Unit:** Degrees C  
**Y Units:** unitless

y/x	-40	-20	0	20	130
1	0	0	0	0	0

Initial Supporting table - Mode Valve B steady state turbine speed delay limit					
Description: ETRS Mode Valve B steady state turbine speed delay limit					
Value Units: seconds					
X Unit: transmission fluid temperature, degrees Celsius					
Y Units: unitless					
y/x	-40.0	-20.0	0.0	20.0	130.0
1	2.300	1.800	1.000	0.500	0.300



## Initial Supporting table - Mode Valve B Trnstn State

**Description:** Mode Valve B transition state.**Value Units:** TePSCR\_e\_ModeValveStat**X Unit:** CeSTGR\_i\_ETRS\_CmndDirctn**Y Units:** CeSTGR\_i\_ETRS\_CmndDirctn

y/x	CeSTGR_e_ETRS_Park	CeSTGR_e_ETRS_NeutLo	CeSTGR_e_ETRS_NeutHi	CeSTGR_e_ETRS_Drive	CeSTGR_e_ETRS_Rvrs	CeSTGR_e_ETRS_NeutShf
CeSTGR_e_ETRS_Park	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
CeSTGR_e_ETRS_NeutLo	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
CeSTGR_e_ETRS_NeutHi	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh
CeSTGR_e_ETRS_Drive	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow	CePSCR_e_ModeValveLow
CeSTGR_e_ETRS_Rvrs	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh
CeSTGR_e_ETRS_NeutShf	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh	CePSCR_e_ModeValveHigh

Initial Supporting table - Mode valve fail delay limit

**Description:** mode valve fail delay limit

**Value Units:** seconds  
**X Unit:** transmission fluid temperature, degrees Celsius  
**Y Units:** unitless

y/x	-40.0	-20.0	0.0	20.0	130.0
1	6.000	2.000	1.500	1.000	1.000

Initial Supporting table - Mode Vlv A GS TurbDly Lim

**Description:** mode valve A garage shift transtion turbine speed delay

**Value Units:** seconds  
**X Unit:** transmission fluid temperature, degrees Celsius  
**Y Units:** unitless

y/x	-40.0	-20.0	0.0	20.0	130.0
1	0.250	0.250	0.250	0.250	0.250

Initial Supporting table - Mode Vlv StdySt Park Dly Lim

**Description:** fail delay time

**Value Units:** seconds  
**X Unit:** transmission fluid temperature, degrees Celsius  
**Y Units:** unitless

y/x	-40.00	-20.00	0.00	20.00	130.00
1	4.000	0.731	0.244	0.244	0.244

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - NumClchTieUp

**Description:** NumClchTieUp

**Value Units:** minimum # of clutches

**X Unit:** command gear or attained gear

**Y Units:** not applicable, no units, single row table f(gear)

### NumClchTieUp - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5
1	2	3	2	2	2	2	2

### NumClchTieUp - Part 2

y/x	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3
1	2	2	1	1	1	1	1

### NumClchTieUp - Part 3

y/x	CeCGSR_e_NeutralC2C4	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6	CeCGSR_e_NeutralC4C5
1	1	1	1	1	1	1	1

### NumClchTieUp - Part 4

y/x	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4
1	1	1	3	2	2	2	2

### NumClchTieUp - Part 5

y/x	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	2	2	2	1	1	1	1

### NumClchTieUp - Part 6

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5
1	1	1	1	1	1	1	1

### NumClchTieUp - Part 7

y/x	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth
1	1	1	2	1	1	1	1

### NumClchTieUp - Part 8

y/x	CeCGSR_e_Fifth	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth	
-----	----------------	----------------	------------------	-----------------	----------------	----------------	--

Initial Supporting table - NumClchTieUp							
1	1	1	1	1	1	1	

## Initial Supporting table - P0722 Internal Speed Sensor Held

## Description:

Value Units: Boolean

X Unit: Gear

Y Units: Internal Speed Sensor location

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
CeCGSR_e_CR_NullForSched	1	1
CeCGSR_e_CR_Neutral	1	1
CeCGSR_e_CR_Park	1	1
CeCGSR_e_CR_Reverse	0	1
CeCGSR_e_CR_First	0	1
CeCGSR_e_CR_Second	0	1
CeCGSR_e_CR_Third	1	1
CeCGSR_e_CR_Fourth	0	1
CeCGSR_e_CR_Fifth	0	1
CeCGSR_e_CR_Sixth	0	1
CeCGSR_e_CR_Seventh	0	1
CeCGSR_e_CR_Eighth	1	1
CeCGSR_e_CR_Ninth	0	1
CeCGSR_e_CR_Tenth	1	1

Initial Supporting table - P0722 OSS Direction Change Delay

Description:

Value Units: seconds  
X Unit: DegC

y/x	-40	0	40
1	5	3	1



## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P0722 TIS TNS Diff

#### Description:

**Value Units:** RPM

**X Unit:** Speed Sensor Location

**Y Units:** Gear

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
CeTGRR_e_Gear1	251	0
CeTGRR_e_Gear2	382	0
CeTGRR_e_Gear3	10,000	0
CeTGRR_e_Gear4	248	0
CeTGRR_e_Gear5	50	0
CeTGRR_e_Gear6	133	0
CeTGRR_e_Gear7	50	0
CeTGRR_e_Gear8	10,000	0
CeTGRR_e_Gear9	121	0
CeTGRR_e_Gear10	10,000	0

Initial Supporting table - P0723 transmission engaged state time threshold			
<b>Description:</b> time necessary after transmission engaged state indicates transmsision engaged to allow P0723 enable			
<b>Value Units:</b> seconds <b>X Unit:</b> transmission fluid temperature °C			
y/x	-40.000	0.000	40.000
1	5.000	3.000	1.000

Initial Supporting table - P0741 (GF9 specific) TCC slip speed crash RPM

**Description:** RPM limit used to establish slip crashed when TCC oil became available

**Value Units:** RPM  
**X Unit:** % accelerator position

y/x	0.00	15.00	25.00	50.00	75.00
1	100	100	160	233	300

Initial Supporting table - P171D hydraulic pressure delay

**Description:** Time to delay the initial x of y counter due to hydraulic transients. Thresholds are a function of transmission fluid temperature. Horizontal axis is transmission fluid temperature (DegC) and table output is delay time (seconds).

**Value Units:** delay time seconds  
**X Unit:** transmission fluid temperature DegC

y/x	-40	0	20	30	40	50	60
1	0.090	0.090	0.080	0.050	0.050	0.050	0.050

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P171D predicted turbine speed error

**Description:** Predicted turbine speed vs actual turbine speed error. Thresholds are a function of engine speed and transmission fluid temperature. Diagnostic is considered failing above these values. Table vertical axis is engine speed (RPM), horizontal axis is transmission fluid temperature (DegC) and table output is predicted turbine speed error (RPM).

**Value Units:** turbine speed RPM error  
**X Unit:** transmission fluid temperature DegC  
**Y Units:** engine speed RPM

y/x	-40	0	10	20	40
0	300	300	300	300	300
500	300	300	300	300	300
1,100	300	300	300	300	300
1,500	300	300	300	300	300
2,500	300	300	300	300	300

Initial Supporting table - P176B delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation		
<b>Description:</b> delay to allow transmission input, intermediate and output speeds to stablize for fail evaluation		
<b>Value Units:</b> seconds <b>X Unit:</b> intermediate speed sensor select		
y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	1.000	1.000

## Initial Supporting table - P176B holding clutch states

**Description:** inditaces when the clutch states allow transmission intermediate speed sensor evaluation, when rotating components can trigger speed sesnor, holding clutches will not allow evaluation while clutches not holding will allow evaluation

**Value Units:** TRUE or FALSE

**X Unit:** intermediate speed sensor select

**Y Units:** commanded gear

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
CeCGSR_e_CR_NullForSched	1	1
CeCGSR_e_CR_Neutral	1	1
CeCGSR_e_CR_Park	1	1
CeCGSR_e_CR_Reverse	0	1
CeCGSR_e_CR_First	0	1
CeCGSR_e_CR_Second	0	1
CeCGSR_e_CR_Third	1	1
CeCGSR_e_CR_Fourth	0	1
CeCGSR_e_CR_Fifth	0	1
CeCGSR_e_CR_Sixth	0	1
CeCGSR_e_CR_Seventh	0	1
CeCGSR_e_CR_Eighth	1	1
CeCGSR_e_CR_Ninth	0	1
CeCGSR_e_CR_Tenth	1	1

Initial Supporting table - P176B intermediate speed sensor fail count threshold

**Description:** P176B intermediate speed sensor fail count threshold

**Value Units:** fail counts  
**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	4	4



Initial Supporting table - P176B intermediate speed sensor fail time threshold		
<b>Description:</b> P176B intermediate speed sensor fail time threshold		
<b>Value Units:</b> seconds <b>X Unit:</b> intermediate speed sensor select		
y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	2.000	2.000

Initial Supporting table - P176B minimum estimated transmission intermediate speed to enable fail evaluation		
<b>Description:</b> minimum estimated transmission intermediate speed to enable fail evaluation, where estimate is based on transmission input speed / ratio calibration, where ratio calibration is either P176B ratio calibration when REVERSE or P176B ratio calibration when not REVERSE		
<b>Value Units:</b> estimated transmission intermediate speed RPM <b>X Unit:</b> intermediate speed sensor select		
y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	172.0	172.0

Initial Supporting table - P176B minimum transmission input speed to enable fail evaluation

**Description:** minimum transmission input speed to enable fail evaluation

**Value Units:** transmission input speed RPM

**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	172.0	172.0

Initial Supporting table - P176B ratio calibration when not REVERSE

**Description:** used to estimate transmission input speed based on transmission intermediate speed when range is not REVERSE

**Value Units:** ratio  
**X Unit:** commanded gear  
**Y Units:** intermediate speed sensor select

y/x	CeTGRR_e_Gear1	CeTGRR_e_Gear2	CeTGRR_e_Gear3	CeTGRR_e_Gear4	CeTGRR_e_Gear5	CeTGRR_e_Gear6	CeTGRR_e_Gear7	CeTGRR_e_Gear8	CeTGRR_e_Gear9	CeTGRR_e_Gear10
CeTSRR_e_C2 C_ClchSpdSnsr1	1.5848	6.3694	1.0000	2.4450	1.0000	0.5227	1.0000	1.0000	1.1905	1.0000
CeTSRR_e_C2 C_ClchSpdSnsr2	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000

Initial Supporting table - P176B ratio calibration when REVERSE

**Description:** used to estimate transmission input speed based on transmission intermediate speed when range is REVERSE

**Value Units:** ratio  
**X Unit:** intermediate speed sensor select

y/x	CeTSRR_e_C2C_ClchSpdSnsr1	CeTSRR_e_C2C_ClchSpdSnsr2
1	1.0000	1.0000

Initial Supporting table - P176C Enable Boolean		
Description:		
Value Units: Boolean		
y/x	0	1
1	1	0

Initial Supporting table - P176C Fail Count Threshold

Description:

Value Units: Count

y/x	0	1
1	40	65,535

Initial Supporting table - P176C Fail Timer

Description:

Value Units: seconds  
X Unit: intermediate speed sensor index

y/x	0	1
1	0	410



Initial Supporting table - P176D Boolean Enable

Description:

Value Units: Boolean  
X Unit: Speed Sensor Index

y/x	0	1
1	1	0

Initial Supporting table - P176D Fail Count Threshold

Description:

Value Units: Count  
X Unit: Speed Sensor Index

y/x	0	1
1	40	65,535

Initial Supporting table - P176D Fail Time Threshold

Description:

Value Units: seconds  
X Unit: Speed Sensor Index

y/x	0	1
1	0	410

Initial Supporting table - P176D Voltage Fail Threshold

Description:

Value Units: Volts  
X Unit: Speed Sensor Index

y/x	0	1
1	5	12

Initial Supporting table - P17C5 P17D3 intermediate speed sensor RPM

**Description:** P17C5 P17D3 intermediate speed sensor RPM at signal period transtion to enable fail time update

**Value Units:** intermediate speed sensor RPM

**X Unit:** intermediate speed sensor 1 or 2

y/x	0	1
1	25	25

Initial Supporting table - P2817 TCC stuck off fail TCC slip speed

**Description:** TCC stuck off slip speed fail threshold when TCC is in ON mode (controlled slip mode)

**Value Units:** RPM  
**X Unit:** engine torque Nm

y/x	0.00	64.00	128.00	192.00	256.00	320.00	384.00	448.00	512.00
1	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0	50.0

Initial Supporting table - P2818 (GF9 specific) control valve test time			
<b>Description:</b> Value to initialize the torque converter clutch control valve test time to after clutch select valve solenoid is turned on, window of time in which the torque converter clutch slip speed and derivative slip speed must be evaluated for failure. Window is a time down window from the calibration value to zero (0.0) seconds.			
<b>Value Units:</b> seconds <b>X Unit:</b> transmission fluid temperature °C			
y/x	-7.00	10.00	40.00
1	0.600	0.300	0.100

Initial Supporting table - P2818 stuck on test time

**Description:** Value to initialize the TCC Stuck On test time to after transition of clutch select valve allowing TCC hydraulic circuit connectivity. Window is a time down window from the calibration value to zero (0.0) seconds.

**Value Units:** seconds  
**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
1	1.500	1.250	1.000



## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2818 torque convert derivative slip speed fail threshold

**Description:** The fail threshold, rate of change of torque converter slip speed, at which the torque convert clutch is considered stuck on.

**Value Units:** RPM/second

**X Unit:** transmission fluid temperature °C

y/x	-7.00	10.00	40.00
0	-600.0	-600.0	-600.0
15	-600.0	-600.0	-600.0
25	-900.0	-900.0	-900.0
50	-1,200.0	-1,200.0	-1,200.0
75	-1,500.0	-1,500.0	-1,500.0

Initial Supporting table - P2D2 Cltch Slip Sum									
Description:									
Value Units: rate of change of output rpm (dn) per 25 milliseconds									
X Unit: % brake pedal position									
Y Units: not applicable, no units, single row table f(brake pedal position)									
y/x	0	15	20	30	35	50	75	88	100
1	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192	-8,192

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C1

**Description:** clutch 1 command pressure threshold below which clutch 1 is considered released, such that, clutch 1 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C1 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	131.3	131.3	9,999.0	344.3	409.6

#### P2D2 Decel Pressure - C1 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	9,999.0	131.3	344.3	131.3	9,999.0

#### P2D2 Decel Pressure - C1 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	9,999.0	9,999.0	9,999.0	50.0	50.0

#### P2D2 Decel Pressure - C1 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50.0	344.3	50.0	50.0	409.6

#### P2D2 Decel Pressure - C1 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	644.8	644.8	50.0	131.3	9,999.0

#### P2D2 Decel Pressure - C1 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	344.3	409.6	9,999.0	131.3	344.3

#### P2D2 Decel Pressure - C1 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	131.3	9,999.0	50.0	50.0	50.0

#### P2D2 Decel Pressure - C1 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	344.3	50.0	50.0	409.6	644.8

#### P2D2 Decel Pressure - C1 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C1

1	644.8	50.0	131.3	9,999.0	9,999.0
<b>P2D2 Decel Pressure - C1 - Part 10</b>					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	9,999.0	9,999.0	9,999.0	9,999.0	9,999.0
<b>P2D2 Decel Pressure - C1 - Part 11</b>					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	9,999.0	644.8	409.6	344.3	50.0
<b>P2D2 Decel Pressure - C1 - Part 12</b>					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C2

**Description:** clutch 2 command pressure threshold below which clutch 2 is considered released, such that, clutch 2 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C2 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	359	359	359	9,999	2,125

#### P2D2 Decel Pressure - C2 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	801	489	359	512	9,999

#### P2D2 Decel Pressure - C2 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	2,125	801	489	50	50

#### P2D2 Decel Pressure - C2 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	9,999	50	50	2,125

#### P2D2 Decel Pressure - C2 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	765	765	50	359	359

#### P2D2 Decel Pressure - C2 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	9,999	2,125	801	489	359

#### P2D2 Decel Pressure - C2 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	512	9,999	50	50	50

#### P2D2 Decel Pressure - C2 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	9,999	50	50	2,125	765

#### P2D2 Decel Pressure - C2 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C2

1	765	50	512	570	570
<b>P2D2 Decel Pressure - C2 - Part 10</b>					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	9,999	9,999	2,125	801	489
<b>P2D2 Decel Pressure - C2 - Part 11</b>					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	359	765	2,125	9,999	50
<b>P2D2 Decel Pressure - C2 - Part 12</b>					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C3

**Description:** clutch 3 command pressure threshold below which clutch 3 is considered released, such that, clutch 3 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C3 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	245	245	247	1,293	9,999

#### P2D2 Decel Pressure - C3 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	706	245	247	245	1,294

#### P2D2 Decel Pressure - C3 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	9,999	706	360	50	50

#### P2D2 Decel Pressure - C3 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	1,293	50	50	9,999

#### P2D2 Decel Pressure - C3 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	674	674	50	245	247

#### P2D2 Decel Pressure - C3 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	1,293	9,999	706	245	247

#### P2D2 Decel Pressure - C3 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	245	1,294	50	50	50

#### P2D2 Decel Pressure - C3 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	1,293	50	50	9,999	674

#### P2D2 Decel Pressure - C3 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C3					
1	674	50	245	273	273
P2D2 Decel Pressure - C3 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	1,294	1,294	9,999	706	360
P2D2 Decel Pressure - C3 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	247	674	9,999	1,293	50
P2D2 Decel Pressure - C3 - Part 12					
y/x					
1					



## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C4

**Description:** clutch 4 command pressure threshold below which clutch 4 is considered released, such that, clutch 4 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C4 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	433	433	482	1,041	1,585

#### P2D2 Decel Pressure - C4 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	9,999	433	915	433	1,145

#### P2D2 Decel Pressure - C4 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	1,713	9,999	1,772	50	50

#### P2D2 Decel Pressure - C4 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	1,041	50	50	1,585

#### P2D2 Decel Pressure - C4 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	9,999	9,999	50	433	482

#### P2D2 Decel Pressure - C4 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	1,041	1,585	9,999	433	915

#### P2D2 Decel Pressure - C4 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	433	1,145	50	50	50

#### P2D2 Decel Pressure - C4 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	1,041	50	50	1,585	9,999

#### P2D2 Decel Pressure - C4 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C4

1	9,999	50	433	482	482
<b>P2D2 Decel Pressure - C4 - Part 10</b>					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	1,145	1,145	1,713	9,999	1,772
<b>P2D2 Decel Pressure - C4 - Part 11</b>					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	915	2,030	1,585	1,041	50
<b>P2D2 Decel Pressure - C4 - Part 12</b>					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C5

**Description:** clutch 5 command pressure threshold below which clutch 5 is considered released, such that, clutch 5 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C5 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	140	140	140	255	318

#### P2D2 Decel Pressure - C5 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	646	9,999	685	140	255

#### P2D2 Decel Pressure - C5 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	318	646	9,999	50	50

#### P2D2 Decel Pressure - C5 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	780	50	50	1,188

#### P2D2 Decel Pressure - C5 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	9,999	50	50	140	140

#### P2D2 Decel Pressure - C5 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	255	318	646	9,999	685

#### P2D2 Decel Pressure - C5 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	140	255	50	50	50

#### P2D2 Decel Pressure - C5 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	780	50	50	1,188	9,999

#### P2D2 Decel Pressure - C5 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C5

1	50	50	9,999	140	140
<b>P2D2 Decel Pressure - C5 - Part 10</b>					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	255	255	318	646	9,999
<b>P2D2 Decel Pressure - C5 - Part 11</b>					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	685	9,999	1,188	780	50
<b>P2D2 Decel Pressure - C5 - Part 12</b>					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C6

**Description:** clutch 6 command pressure threshold below which clutch 6 is considered released, such that, clutch 6 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C6 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	178	178	178	283	330

#### P2D2 Decel Pressure - C6 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	504	253	9,999	178	283

#### P2D2 Decel Pressure - C6 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	330	504	1,036	50	50

#### P2D2 Decel Pressure - C6 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	9,999	50	50	9,999

#### P2D2 Decel Pressure - C6 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	50	9,999	50	178	178

#### P2D2 Decel Pressure - C6 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	283	330	504	253	9,999

#### P2D2 Decel Pressure - C6 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	178	283	50	50	50

#### P2D2 Decel Pressure - C6 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	9,999	50	50	9,999	50

#### P2D2 Decel Pressure - C6 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW
-----	----------------------	--------------------------	------------------	--------------------	------------------

# 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

## Initial Supporting table - P2D2 Decel Pressure - C6

1	9,999	50	253	178	178
<b>P2D2 Decel Pressure - C6 - Part 10</b>					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	283	283	330	504	1,036
<b>P2D2 Decel Pressure - C6 - Part 11</b>					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	9,999	9,999	9,999	9,999	50
<b>P2D2 Decel Pressure - C6 - Part 12</b>					
y/x					
1					

## 20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

### Initial Supporting table - P2D2 Decel Pressure - C7

**Description:** clutch 7 command pressure threshold below which clutch 7 is considered released, such that, clutch 7 cannot carry enough clutch torque that would induce a vehicle deceleration above the design safety metric

**Value Units:** kPa

**X Unit:** command gear

**Y Units:** not applicable, no units, single row table f(command gear)

#### P2D2 Decel Pressure - C7 - Part 1

y/x	CeCGSR_e_NullForSched	CeCGSR_e_NeutralNoClutch	CeCGSR_e_NeutralC1	CeCGSR_e_NeutralC2	CeCGSR_e_NeutralC3
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 2

y/x	CeCGSR_e_NeutralC4	CeCGSR_e_NeutralC5	CeCGSR_e_NeutralC6	CeCGSR_e_NeutralC7	CeCGSR_e_NeutralC1C2
1	50	50	50	9,999	50

#### P2D2 Decel Pressure - C7 - Part 3

y/x	CeCGSR_e_NeutralC1C3	CeCGSR_e_NeutralC1C4	CeCGSR_e_NeutralC1C5	CeCGSR_e_NeutralC2C3	CeCGSR_e_NeutralC2C4
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 4

y/x	CeCGSR_e_NeutralC2C5	CeCGSR_e_NeutralC2C6	CeCGSR_e_NeutralC3C4	CeCGSR_e_NeutralC3C5	CeCGSR_e_NeutralC3C6
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 5

y/x	CeCGSR_e_NeutralC4C5	CeCGSR_e_NeutralC4C6	CeCGSR_e_NeutralC2C3C4C5	CeCGSR_e_Park_wNC	CeCGSR_e_Park_wNC1
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 6

y/x	CeCGSR_e_Park_wNC2	CeCGSR_e_Park_wNC3	CeCGSR_e_Park_wNC4	CeCGSR_e_Park_wNC5	CeCGSR_e_Park_wNC6
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 7

y/x	CeCGSR_e_Park_wNC7	CeCGSR_e_Park_wNC1C2	CeCGSR_e_Park_wNC2C3	CeCGSR_e_Park_wNC2C4	CeCGSR_e_Park_wNC2C5
1	9,999	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 8

y/x	CeCGSR_e_Park_wNC2C6	CeCGSR_e_Park_wNC3C4	CeCGSR_e_Park_wNC3C5	CeCGSR_e_Park_wNC3C6	CeCGSR_e_Park_wNC4C5
1	50	50	50	50	50

#### P2D2 Decel Pressure - C7 - Part 9

y/x	CeCGSR_e_Park_wNC4C6	CeCGSR_e_Park_wNC2C3C4C5	CeCGSR_e_Reverse	CeCGSR_e_FirstLckd	CeCGSR_e_FirstFW

20 OBDG03A TCM T87A 10 Speed RWD Supporting Tables

Initial Supporting table - P2D2 Decel Pressure - C7					
1	50	50	9,999	9,999	50
P2D2 Decel Pressure - C7 - Part 10					
y/x	CeCGSR_e_SecondLckd	CeCGSR_e_SecondFW	CeCGSR_e_Third	CeCGSR_e_Fourth	CeCGSR_e_Fifth
1	50	50	50	50	50
P2D2 Decel Pressure - C7 - Part 11					
y/x	CeCGSR_e_Sixth	CeCGSR_e_Seventh	CeCGSR_e_Eighth	CeCGSR_e_Ninth	CeCGSR_e_Tenth
1	50	50	50	50	50
P2D2 Decel Pressure - C7 - Part 12					
y/x					
1					



Initial Supporting table - Park Position Sensor A Dly Lim

**Description:** Delay timer limit for Park Sensor A Performance. Temp based

**Value Units:** Seconds  
**X Unit:** Degrees C  
**Y Units:** unitless

y/x	-40	-20	0	20	130
1	1	1	1	0	0

Initial Supporting table - Park Postition Sensor B Dly Lim

**Description:** Delay timer limit for Park Sensor B Performance. Temp based

**Value Units:** Seconds  
**X Unit:** Degrees C  
**Y Units:** unitless

y/x	-40	-20	0	20	130
1	1	0	0	0	0

Initial Supporting table - Park Valve Eng Off Dly Lim

**Description:** P187E time engine must be not running to enable fail time update

**Value Units:** seconds  
**X Unit:** transmission fluid temperature, degrees Celsius  
**Y Units:** unitless

y/x	-40.00	-20.00	0.00	20.00	130.00
1	3.100	2.500	2.100	1.100	0.600

Initial Supporting table - Park Valve Stk Off Dly Lim

**Description:** P187E Transmission Park Valve Stuck Off fail enable delay time

**Value Units:** seconds  
**X Unit:** transmission fluid temperature, degrees Celsius  
**Y Units:** unitless

y/x	-40.00	-20.00	0.00	20.00	130.00
1	1.600	1.200	1.000	1.000	1.000

Initial Supporting table - Park Valve Stk Off Fail Lim

**Description:** Fail timer limit for Park Servo to move from OOP to P. Temp based

**Value Units:** Seconds  
**X Unit:** Degrees C  
**Y Units:** unitless

y/x	-40	-20	0	20	130
1	0	0	0	0	0

Initial Supporting table - Park Valve Stk On Dly Lim

**Description:** P187D Transmission Park Valve Stuck On fail enable delay time

**Value Units:** seconds  
**X Unit:** transmission fluid temperature, degrees Celsius  
**Y Units:** unitless

y/x	-40.00	-20.00	0.00	20.00	130.00
1.00	3.500	2.700	0.500	0.250	0.250

Initial Supporting table - Park Valve Stk On Fail Lim

**Description:** Fail timer limit for Park servo to Move from P to OOP. Temp based

**Value Units:** Seconds  
**X Unit:** Degrees C  
**Y Units:** unitless

y/x	-40	-20	0	20	130
1	0	0	0	0	0

Initial Supporting table - PISA Stk Off Eng Off Dly Lim

**Description:** P18A8 fail time, engine not running

**Value Units:** seconds  
**X Unit:** transmission fluid temperature, degrees Celsius  
**Y Units:** unitless

y/x	-40.00	-20.00	0.00	20.00	130.00
1	0.200	0.200	0.200	0.200	0.200



Initial Supporting table - transmission fluid temperature warm up time

Description:

**Value Units:** transmission fluid temperature normal warm up time, seconds  
**X Unit:** transmission fluid temperature at controller power up, °C

y/x	-40.00	-30.00	-20.00	0.00	20.00
1	1,800.0	1,500.0	1,200.0	600.0	60.0