

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Ignition Switch Run/ Start Position Circuit Low	B2B0D	This DTC monitors for a CGM Ignition Switch Run/Start Position Circuit Low error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the CGM Ignition Switch Run/Start Position Circuit Low DTC has set in the CGM.		General Enable Criteria: Message \$3CF Central Gateway Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Ignition Switch Run/ Start Position Circuit High	B2B0E	This DTC monitors for a CGM Ignition Switch Run/Start Position Circuit High error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the CGM Ignition Switch Run/Start Position Circuit High DTC has set in the CGM.		General Enable Criteria: Message \$3CF Central Gateway Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Control Module Memory Failure	B2B12	This DTC monitors for a CGM Control Module Memory Failure error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the CGM Control Module Memory Failure DTC has set in the CGM.		General Enable Criteria: Message \$3CF Central Gateway Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Control Module Internal Performance Failure	B2B13	This DTC monitors for a CGM Control Module Internal Performance Failure error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the CGM Control Module Internal Performance Failure DTC has set in the CGM.		General Enable Criteria: Message \$3CF Central Gateway Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Left Front Wheel Speed Sensor Circuit High	C1207	This DTC monitors for a Left Front Wheel Speed Sensor Circuit High fault as determined by the EBCM.	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Left Front Wheel Speed Sensor Circuit High DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Right Front Wheel Speed Sensor Circuit High	C1208	This DTC monitors for a Right Front Wheel Speed Sensor Circuit High fault as determined by the EBCM.	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Right Front Wheel Speed Sensor Circuit High DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Left Rear Wheel Speed Sensor Circuit High	C1209	This DTC monitors for a Left Rear Wheel Speed Sensor Circuit High fault as determined by the EBCM.	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Left Rear Wheel Speed Sensor Circuit High DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Right Rear Wheel Speed Sensor Circuit High	C1210	This DTC monitors for a Right Rear Wheel Speed Sensor Circuit High fault as determined by the EBCM.	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Right Rear Wheel Speed Sensor Circuit High DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Left Front Wheel Speed Sensor Circuit	C1221	This DTC monitors for an error with the received CAN data for the Left Front Wheel Speed Sensor Circuit	If the wheel distance received over GMLAN is determined to be not valid for out of total samples	 >= 50.00 counts >= 60.00 counts	ABS system is present Wheel speed communications enabled OBD compliance type Speed sensor present on vehicle Run/Crank Voltage Run/Crank Active	= True = True = Non-USA/CARB = False >= 11.00 Volts >= 3.00 seconds	Diagnostic runs in 100ms loop.	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Right Front Wheel Speed Sensor Circuit	C1222	This DTC monitors for an error with the received CAN data for the Right Front Wheel Speed Sensor Circuit	If the wheel distance received over GMLAN is determined to be not valid for out of total samples	>= 50.00 counts >= 60.00 counts	ABS system is present Wheel speed communications enabled OBD compliance type Speed sensor present on vehicle Run/Crank Voltage Run/Crank Active	= True = True = Non-USA/CARB = False >= 11.00 Volts >= 3.00 seconds	Diagnostic runs in 100ms loop.	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Left Rear Wheel Speed Sensor Circuit	C1223	This DTC monitors for an error with the received CAN data for the Left Rear Wheel Speed Sensor Circuit	If the wheel distance received over GMLAN is determined to be not valid for out of total samples	>= 50.00 counts >= 60.00 counts	ABS system is present Wheel speed communications enabled OBD compliance type Speed sensor present on vehicle Run/Crank Voltage Run/Crank Active	= True = True = Non-USA/CARB = False >= 11.00 Volts >= 3.00 seconds	Diagnostic runs in 100ms loop.	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Right Rear Wheel Speed Sensor Circuit	C1224	This DTC monitors for an error with the received CAN data for the Right Rear Wheel Speed Sensor Circuit	If the wheel distance received over GMLAN is determined to be not valid for out of total samples	>= 50.00 counts >= 60.00 counts	ABS system is present Wheel speed communications enabled OBD compliance type Speed sensor present on vehicle Run/Crank Voltage Run/Crank Active	= True = True = Non-USA/CARB = False >= 11.00 Volts >= 3.00 seconds	Diagnostic runs in 100ms loop.	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Left Front Wheel Speed Sensor Circuit Range/ Performance	C1225	This DTC monitors for a Range/Performance error with the Left Front Wheel Speed Sensor Circuit as determined by the EBCM	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Left Front Wheel Speed Sensor Circuit Range/Performance DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Right Front Wheel Speed Sensor Circuit Range/ Performance	C1226	This DTC monitors for a Range/Performance error with the Right Front Wheel Speed Sensor Circuit as determined by the EBCM	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Right Front Wheel Speed Sensor Circuit Range/Performance DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Left Rear Wheel Speed Sensor Circuit Range/ Performance	C1227	This DTC monitors for a Range/Performance error with the Left Rear Wheel Speed Sensor Circuit as determined by the EBCM	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Left Rear Wheel Speed Sensor Circuit Range/Performance DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Right Rear Wheel Speed Sensor Circuit Range/ Performance	C1228	This DTC monitors for a Range/Performance error with the Right Rear Wheel Speed Sensor Circuit as determined by the EBCM	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Right Rear Wheel Speed Sensor Circuit Range/Performance DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Tire Size Mismatch	C122E	This DTC monitors for a Tire Size Mismatch fault as determined by the EBCM.	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Tire Size Mismatch DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Left Front Wheel Speed Sensor Circuit Low	C1232	This DTC monitors for a Sensor Circuit Low error with the Left Front Wheel Speed Sensor Circuit as determined by the EBCM	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Left Front Wheel Speed Sensor Circuit Low DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Right Front Wheel Speed Sensor Circuit Low	C1233	This DTC monitors for a Sensor Circuit Low error with the Right Front Wheel Speed Sensor Circuit as determined by the EBCM	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Right Front Wheel Speed Sensor Circuit Low DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Left Rear Wheel Speed Sensor Circuit Low	C1234	This DTC monitors for a Sensor Circuit Low error with the Left Rear Wheel Speed Sensor Circuit as determined by the EBCM	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Left Rear Wheel Speed Sensor Circuit Low DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Right Rear Wheel Speed Sensor Circuit Low	C1235	This DTC monitors for a Sensor Circuit Low error with the Right Rear Wheel Speed Sensor Circuit as determined by the EBCM	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the Right Rear Wheel Speed Sensor Circuit Low DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
EBCM Random Access Memory (RAM)	C1255	This DTC monitors for an EBCM Random Access Memory (RAM) fault as determined by the EBCM.	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the EBCM Random Access Memory (RAM) DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
EBCM Read Only Memory (ROM)	C1256	This DTC monitors for an EBCM Read Only Memory (ROM) fault as determined by the EBCM.	The EBCM Diagnostic Status Message signal in GMLAN frame \$2F9 indicates that the EBCM Read Only Memory (ROM) DTC has set in the EBCM.		General Enable Criteria: Message \$2F9 Electronic Brake Control Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Open – Bank 1	P0010	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	<p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	$\geq 200 \text{ K } \Omega$ impedance between signal and controller ground.	<p>System supply voltage</p> <p>Output driver is commanded on</p> <p>Ignition switch is in crank or run position</p>	> 11.00 Volts	<p>20 failures out of 25 samples</p> <p>250 ms /sample, continuous</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft System Performance – Bank 1	P0011	Detects a VVT system error by comparing the desired and actual cam positions when VVT is activated.	Camshaft position error [absolute value of (desired position - actual position)] is compared to thresholds to determine if excessive.	(Intake cam Bank 1) Cam Position Error > (P0011_CamPosErrorLimlc1) deg	Intake Cam Phsr Enable System Voltage Engine Running Power Take Off (PTO) active Desired cam position Desired AND Measured cam position Desired cam position variation No Active DTCs	= TRUE > 11.00 Volts = TRUE = FALSE > 0 deg > (P0011_CamPosErrorLimlc1) deg AND < (CalculatedPerfMaxlc1) deg < 7.50 deg for (P0011_P05CC_StablePositionTimeIc1) seconds P0010 P2088 P2089	100.00 failures out of 500.00 samples 100 ms /sample	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP)- Camshaft Position (CMP) Correlation Bank 1 Sensor A	P0016	Detects cam to crank misalignment by monitoring if the cam sensor pulse for bank 1 occurs during the incorrect crank position, diagnostic passes when the cam sensor pulse is in the expected range	Out of range cam edge measurements in one engine cycle Out of range values are: cam edge measurement OR cam edge measurement from the expected nominal cam position	>= 2 cam edges < -11.0 Crank Degrees OR > 11.0 Crank Degrees	Crankshaft and camshaft position signals are synchronized Engine is Spinning Cam phaser control indicates the phaser is 'parked' No Active DTCs: Time since last execution of a test IntCamECC_OilPresLow	Test is Enabled CrankSensor_FA P0340, P0341 > 1.0 sec = FALSE	4 cam edge measurements and 1 test sample per engine cycle Test failure is 4 fails in 5 samples Diagnostic failure is 2 failed tests out of 3 If the first test fails, the next test is delayed to confirm the phaser 'parked' This delay time is defined by P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold For mid-park phasers, an additional delay P0016-0019 Mid-Park Phaser Delay is applied	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 1	P0030	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	$\geq 200 \text{ K } \Omega$ impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0031 may also set

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0031	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	$\leq 0.5 \Omega$ impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0030 may also set

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor1	P0032	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	$\leq 0.5 \Omega$ impedance between output and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 1 Sensor 2	P0036	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0037 may also set

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0037	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	$\leq 0.5 \Omega$ impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0036 may also set

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank1 Sensor2	P0038	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	$\leq 0.5 \Omega$ impedance between output and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 2 Sensor 1	P0050	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0051 may also set

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensor1	P0051	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	$\leq 0.5 \Omega$ impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0050 may also set

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensor1	P0052	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	$\leq 0.5 \Omega$ impedance between output and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 1	P0053	<p>Detects an oxygen sensor heater having an incorrect or out of range resistance value. This test calculates the heater's resistance (using voltage and current) at engine start after a longer soak condition and compares it to the expected values for the released sensor.</p> <p>This fault is set if the heater resistance is outside the expected range.</p>	Heater Resistance outside of the expected range of	3.1 < ohms < 8.4	<p>No Active DTC's</p> <p>Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time</p>	<p>ECT_Sensor_FA P262B IAT_SensorFA < 8.0 °C > 28,800 seconds ≥ -30.0 °C < 32.0 volts < 0.04 seconds</p>	Once per valid cold start	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0054	<p>Detects an oxygen sensor heater having an incorrect or out of range resistance value. This test calculates the heater's resistance (using voltage and current) at engine start after a soak condition and compares it to the expected values for the released sensor.</p> <p>This fault is set if the heater resistance is outside the expected range.</p>	Heater Resistance outside of the expected range of	3.1 < ohms < 8.4	<p>No Active DTC's</p> <p>Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time</p>	<p>ECT_Sensor_FA P262B IAT_SensorFA < 8.0 °C > 28,800 seconds ≥ -30.0 °C < 32.0 volts < 0.04 seconds</p>	Once per valid cold start	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank 2 Sensor 2	P0056	Controller specific output driver circuit diagnoses the heater output low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	$\geq 200 \text{ K } \Omega$ impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controlle rs P0057 may also set

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensor2	P0057	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between output and controller ground.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips Note: In certain controllers P0056 may also set

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Control Circuit Bank2 Sensor2	P0058	Controller specific output driver circuit diagnoses the heater output low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	$\leq 0.5 \Omega$ impedance between output and controller power.	Ignition Voltage Engine Speed	= Crank or Run > 11.0 volts > 400 RPM	20 failures out of 25 samples 250 ms / sample Continuous	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 2 Sensor 1	P0059	<p>Detects an oxygen sensor heater having an incorrect or out of range resistance value.. This test calculates the heater's resistance (using voltage and current) at engine start after a soak condition and compares it to the expected values for the released sensor.</p> <p>This fault is set if the heater resistance is outside the expected range.</p>	Heater Resistance outside of the expected range of	3.4 < ohms < 8.6	<p>No Active DTC's</p> <p>Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time</p>	<p>ECT_Sensor_FA P262B IAT_SensorFA < 8.0 °C > 28,800 seconds ≥ -30.0 °C < 32.0 volts < 0.09 seconds</p>	Once per valid cold start	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
HO2S Heater Resistance Bank 2 Sensor 2	P0060	<p>Detects an oxygen sensor heater having an incorrect or out of range resistance value. This test calculates the heater's resistance (using voltage and current) at engine start after a soak condition and compares it to the expected values for the released sensor.</p> <p>This fault is set if the heater resistance is outside the expected range.</p>	Heater Resistance outside of the expected range of	3.4 < ohms < 8.6	<p>No Active DTC's</p> <p>Coolant – IAT Engine Soak Time Coolant Temp Ignition Voltage Engine Run time</p>	<p>ECT_Sensor_FA P262B IAT_SensorFA < 8.0 °C > 28,800 seconds ≥ -30.0 °C < 32.0 volts < 0.09 seconds</p>	Once per valid cold start	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
MAP / MAF / Throttle Position Correlation	P0068	Detect when MAP and MAF do not match estimated engine airflow as established by the TPS	Difference between MAP and estimated MAP exceeds threshold (kPa), or P0651 (5 Volt Ref), or P0107 (MAP circuit low), or P0108 (MAP circuit high) have failed this key cycle, then MAP portion of diagnostic fails Absolute difference between MAF and estimated MAF exceed threshold (grams/sec), or P0102 (MAF circuit low), or P0103 (MAF circuit hi) have failed this key cycle, or maximum MAF versus RPM (Table) is greater than or equal to maximum MAF versus battery voltage, then MAF portion of diagnostic fails	Table, f(TPS). See supporting tables: P0068_Delta MAP Threshold f(TPS) Table, f(TPS). See supporting tables: P0068_Delta MAF Threshold f(TPS) Table, f(RPM). See supporting tables: P0068_Maximum MAF f(RPM) Table, f(Volts). See supporting tables: P0068_Maximum MAF f(Volts)	Engine Speed Run/Crank voltage	> 800 RPM > 6.41 Volts	Continuously fail MAP and MAF portions of diagnostic for 0.1875 s Continuous in MAIN processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit Performance (OAT wired to ECM)	P0071	<p>Detects an Outside Air Temperature (OAT) sensor that is stuck in range. There are two components to the test: an engine off component, and an engine running component.</p> <p>If the engine has been off for a long enough period of time, and the coolant temperature and Intake Air Temperature (IAT) values are similar, then the air temperature values in the engine compartment of the vehicle are considered to have equalized. In this case, the engine off component of the diagnostic can be enabled.</p> <p>If the IAT and the OAT values are similar, then the OAT Performance Diagnostic passes. If the IAT and OAT values are not similar, the diagnostic will continue to monitor the IAT and the OAT as the vehicle starts to move.</p> <p>For applications that have ability to move without engaging the internal combustion</p>	<p>Engine Off:</p> <p>If IAT >= OAT: IAT - OAT</p> <p>If IAT < OAT: OAT - IAT</p> <p>If either of the following conditions are met, this diagnostic will pass:</p> <p>If IAT >= OAT: IAT - OAT</p> <p>If IAT < OAT: OAT - IAT</p>	<p>> 20.0 deg C</p> <p>> 20.0 deg C</p> <p><= 20.0 deg C</p> <p><= 20.0 deg C</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is not running</p> <p>Vehicle Speed</p> <p>Coolant Temperature - IAT</p> <p>IAT - Coolant Temperature</p> <p>OAT-to-IAT engine off equilibrium counter</p> <p>The "OAT-to-IAT engine off equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is off. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared. The value that is added or subtracted to the counter every 100 msec is contained in table P0071: OAT Performance Drive Equilibrium Engine Off</p> <p>No Active DTCs:</p>	<p>>= 28,800.0 seconds</p> <p>>= 15.5 MPH</p> <p>< 15.0 deg C</p> <p>< 15.0 deg C</p> <p>>= 300.0 counts</p> <p>VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngineModeNotRunTimer Error</p>	Executed every 100 msec until a pass or fail decision is made	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>engine, the engine off test will continue. If the vehicle has been moving quickly enough for a long enough period of time, the IAT and OAT values should have reached an equilibrium. This period of time is defined by the "OAT-to-IAT engine off equilibrium counter". The "OAT-to-IAT engine off equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is off. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared.</p> <p>While the "OAT-to-IAT engine off equilibrium counter" is counting, IAT and OAT are monitored for similarity. If they are similar, the OAT Performance Diagnostic passes. If the counter reaches an equilibrium and the IAT and OAT values are not similar, the OAT Performance Diagnostic will fail.</p>	<p>Engine Running:</p> <p>If IAT >= OAT: IAT - OAT</p> <p>If IAT < OAT: OAT - IAT</p> <p>If either of the following conditions are met, this diagnostic will pass:</p> <p>If IAT >= OAT: IAT - OAT</p> <p>If IAT < OAT: OAT - IAT</p>	<p>> 20.0 deg C</p> <p>> 20.0 deg C</p> <p><= 20.0 deg C</p> <p><= 20.0 deg C</p>	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is running</p> <p>Vehicle Speed</p> <p>Engine air flow</p> <p>OAT-to-IAT engine running equilibrium counter</p> <p>The "OAT-to-IAT engine running equilibrium counter" is a counter that is incremented or decremented based on vehicle speed and engine air flow when the engine is running. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared. The value that is added or subtracted to the counter every 100 msec is contained in table P0071: OAT Performance Drive Equilibrium Engine Running</p> <p>No Active DTCs:</p>	<p>>= 28,800.0 seconds</p> <p>>= 15.5 MPH</p> <p>>= 10.0 grams/second</p> <p>>= 300.0 counts</p> <p>VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngineModeNotRunTimer Error</p>	<p>Executed every 100 msec until a pass or fail decision is made</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>If the engine off component of the diagnostic was enabled, but did not make a pass or fail decision, the engine running component will begin executing when the internal combustion engine starts to run.</p> <p>If the vehicle has been moving quickly enough for a long enough period of time, the IAT and OAT values should have reached an equilibrium. This period of time is defined by the "OAT-to-IAT engine running equilibrium counter". The "OAT-to-IAT engine running equilibrium counter" is a counter that is incremented or decremented based on vehicle speed when the engine is running. When this counter is high enough, the vehicle has reached an equilibrium where IAT and OAT can be compared.</p> <p>While the "OAT-to-IAT engine running equilibrium counter" is counting, IAT and OAT are monitored for</p>						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		similarity. If they are similar, the OAT Performance Diagnostic passes. If the counter reaches an equilibrium and the IAT and OAT values are not similar, the OAT Performance Diagnostic will fail.						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit Low	P0072	Detects a continuous short to ground in the Outside Air Temperature (OAT) signal circuit by monitoring the OAT sensor output resistance and failing the diagnostic when the OAT resistance is too low. The OAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A lower resistance is equivalent to a higher temperature.	Raw OAT Input	<= 46 Ohms (~150 deg C)	None		40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Circuit High	P0073	Detects a continuous open circuit in the Outside Air Temperature (OAT) signal circuit by monitoring the OAT sensor output resistance and failing the diagnostic when the OAT resistance is too high. The OAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. A higher resistance is equivalent to a lower temperature.	Raw OAT Input	>= 427,757 Ohms (~-60 deg C)	None		40 failures out of 50 samples 1 sample every 100 msec	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Outside Air Temperature (OAT) Sensor Intermittent In-Range	P0074	<p>Detects a noisy or erratic signal in the OAT circuit by monitoring the OAT sensor and failing the diagnostic when the OAT signal has a noisier output than is expected.</p> <p>When the value of the OAT signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of OAT readings. The result of this summation is called a "string length".</p> <p>Since the OAT signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic OAT signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where:</p> <p>"String Length" = sum of "Diff" calculated over</p> <p>And where:</p> <p>"Diff" = ABS(current OAT reading - OAT reading from 100 milliseconds previous)</p>	<p>> 100 deg C</p> <p>10 consecutive OAT readings</p>	None		<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump min/ max authority	P0089	This DTC determines when the high pressure pump control has reached to its max or min authority	High Pressure Fuel Pump Delivery Angle OR High Pressure Fuel Pump Delivery Angle	$\geq 124^\circ$ $\leq 0^\circ$	High Pressure Pump Performance Diagnostic Enable Battery Voltage Low Side Fuel Pressure Barometric Pressure Inlet Air Temp Fuel Temp Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In	True ≥ 11 Volts > 0.275 MPa Enabled when a code clear is not active or not exiting device control Engine is not cranking ≥ 70.0 KPA ≥ -12.0 degC $-12 \leq \text{Temp degC} \leq 132$	Windup High/ Low 10.00 seconds failures out of 12.50 Seconds samples	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active			

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Control Solenoid Enable Low Side Short to Ground	P0091	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 0.1 Amps between signal and controller ground	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Pump Cntrl Solenoid Enable Low Side Short to Power	P0092	Controller specific output driver circuit diagnoses diagnoses High Pressure pump Control Solenoid low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1.1 or 15 Amps selectable thershold based on High pressure Pump .	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0096	<p>Detects an Intake Air Temperature 2 (IAT2) sensor value that is stuck in range by comparing the IAT2 sensor value against the IAT and coolant temperature sensor values and failing the diagnostic if the IAT2 value is more different than the IAT and coolant temperature values than is expected. If the engine has been off for a long enough period of time, the air temperature values in the engine compartment of the vehicle are considered to have equalized, and the diagnostic can be enabled.</p> <p>The diagnostic will fail if the IAT and coolant temperature values are similar, and the IAT2 value is not similar to the IAT and coolant temperature values.</p> <p>This diagnostic is executed once per ignition cycle if the enable conditions are met.</p>	<p>ABS(Power Up IAT - Power Up IAT2)</p> <p>AND</p> <p>ABS(Power Up ECT – Power Up IAT2)</p> <p>>=</p> <p>ABS(Power Up ECT – Power Up IAT)</p>	> 25 deg C	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Powertrain Relay Voltage for a time</p> <p>If application has a LIN MAF: LIN Communications established with MAF</p> <p>No Active DTCs:</p>	<p>> 28,800 seconds</p> <p>>= 11.0 Volts</p> <p>>= 0.9 seconds</p> <p>PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA HumTempSnsrCktFA EngineModeNotRunTimer Error</p>	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 Low (applications with LIN MAF)	P0097	<p>Detects an erroneously low value being reported over the LIN serial connection from the Intake Air Temperature 2 (IAT2) sensor. The diagnostic monitors the IAT2 sensor output temperature and fails the diagnostic when the IAT2 temperature is too low.</p> <p>The IAT2 sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	IAT 2 Temperature	< -60 degrees C	<p>Powertrain Relay Voltage for a time</p> <p>LIN Communications established with MAF</p> <p>No Active DTCs:</p>	<p>>= 11.0 Volts >= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit 2 High (applications with LIN MAF)	P0098	<p>Detects an erroneously high value being reported over the LIN serial connection from the Intake Air Temperature 2 (IAT2) sensor. The diagnostic monitors the IAT2 sensor output temperature and fails the diagnostic when the IAT2 temperature is too high.</p> <p>The IAT2 sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	IAT 2 Temperature	> 150 degrees C	<p>Powertrain Relay Voltage for a time</p> <p>LIN Communications established with MAF</p> <p>No Active DTCs:</p>	<p>>= 11.0 Volts >= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor 2 Intermittent In-Range (applications with humidity)	P0099	<p>Detects a noisy or erratic signal in the Intake Air Temperature 2 (IAT2) circuit by monitoring the IAT2 sensor and failing the diagnostic when the IAT2 signal has a noisier output than is expected.</p> <p>When the value of the IAT2 signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of IAT2 readings. The result of this summation is called a "string length". Since the IAT2 signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic IAT2 signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current IAT 2 reading - IAT 2 reading from 100 milliseconds previous)</p>	<p>> 100.00 deg C</p> <p>10 consecutive IAT 2 readings</p>	<p>Powertrain Relay Voltage for a time</p> <p>If application has a LIN MAF: LIN Communications established with MAF</p> <p>No Active DTCs:</p>	<p>>= 11.0 Volts >= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Pressure Start Diagnostic	P00C6	The DTC Diagnoses the high side fuel pressure during engine cranking.	The ECM detects that the fuel pressure is not rising or has fallen beyond acceptable limits during engine cranking Pressure Rise Test: Sensed High Pressure Fuel Rail Pressure value Pressure Fall Test: Sensed High Pressure Fuel Rail Pressure value	< P00C6 - Minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery (see Supporting Table) <= P00C6 - Minimum acceptable value of fuel rail pressure after High Pressure Start (see Supporting Table)	High Pressure Rise Diagnostic During Start High Pressure Fall Diagnostic During Start Low side feed fuel pressure Engine Run Time Run/Crank Voltage Engine Coolant For each engine start, only 1 diagnostic is performed. The pressure rise test will run if High side fuel pressure is less than KtFHPC_p_HighPressStart, otherwise, the pressure fall diagnostic will run when the engine is cranking.	Enabled Disabled ≥ 0 KPA < = 0 sec > 8 Volts -100 ≤ °C ≤ 132 All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT, IAT2 and ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control	Pressure Rise Test: Crank Time ≥ P00C6 - High Pressure Pump Control Mode timeout (see Supporting Table) 6.25 ms per sample Pressure Fall Test: Injected cylinder events ≥ P00C6 - maximum acceptable counts of fuel rail pressure below KtFHPD_p_HPS_PressFallLoThresh after High Pressure Start (see Supporting Table) 8 samples per engine rotation	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Barometric Pressure Inlet Air Temp	commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active >= 70.0 KPA >= -12.0 DegC		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Pressure Measuremen t System - Multiple Sensor Correlation (naturally aspirated with TIAP/ Baro sensor)	P00C7	<p>Detects an inconsistency between pressure sensors in the induction system in which a particular sensor cannot be identified as the failed sensor.</p> <p>If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The Manifold Pressure (MAP) and Barometric Pressure (BARO) sensors values are checked to see if they are within the normal expected atmospheric pressure range. If they are, then MAP and BARO are compared to see if their values are similar.</p> <p>If the MAP and BARO values are not similar, there are no other pressure sensors to compare against to identify which sensor is not rational. The Multiple Pressure Sensor Correlation Diagnostic will fail in this case.</p>	ABS(Manifold Pressure - Baro Pressure)	> 10.0 kPa	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Engine is not rotating</p> <p>Manifold Pressure Manifold Pressure Baro Pressure Baro Pressure</p> <p>If application has a LIN MAF: LIN Communications established with MAF</p> <p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>> 5.0 seconds</p> <p>>= 50.0 kPa <= 115.0 kPa >= 50.0 kPa <= 115.0 kPa</p> <p>EngineModeNotRunTimer Error MAP_SensorFA AAP_SnsrFA AAP_LIN1_SnsrCktFA</p> <p>MAP_SensorCircuitFP AAP_SnsrCktFP AAP_LIN1_SnsrCktFP</p>	<p>4 failures out of 5 samples</p> <p>1 sample every 12.5 msec for applications without LIN MAF</p> <p>1 sample every 25 msec for applications with LIN MAF</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control High Side Circuit Short to ground	P00C9	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1.1 or 15 Amps selectable thershhold based on High pressure Pump.	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Press Regulator Solenoid Supply Voltage Control High Side Circuit Short to power	P00CA	Controller specific output driver circuit diagnoses High Pressure pump Control Solenoid high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 0.1 Amps between signal and controller power	Engine Speed Battery Voltage	>= 50 RPM >= 11 Volts Not in pump device control Enabled when a code clear is not active or not exiting device control	20 failures out of 40 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Low (applications with LIN MAF)	P00F4	<p>Detects an erroneously low value being reported over the LIN serial connection from the humidity sensor. The diagnostic monitors the humidity sensor relative humidity output and fails the diagnostic when the humidity percentage is too low.</p> <p>The humidity sensor converts the capacitance across the sensor to a relative humidity. The relative humidity percentage value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	Relative Humidity	<= -6.25 %	<p>Powertrain Relay Voltage for a time</p> <p>LIN Communications established with MAF</p> <p>No Active DTCs:</p>	<p>>= 11.0 Volts >= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit High (applications with LIN MAF)	P00F5	<p>Detects an erroneously high value being reported over the LIN serial connection from the humidity sensor. The diagnostic monitors the humidity sensor relative humidity output and fails the diagnostic when the humidity percentage is too high.</p> <p>The humidity sensor converts the capacitance across the sensor to a relative humidity. The relative humidity percentage value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	Relative Humidity	>= 106.25 %	<p>Powertrain Relay Voltage for a time</p> <p>LIN Communications established with MAF</p> <p>No Active DTCs:</p>	<p>>= 11.0 Volts >= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Humidity Sensor Circuit Intermittent	P00F6	<p>Detects a noisy or erratic signal in the humidity circuit by monitoring the humidity sensor and failing the diagnostic when the humidity signal has a noisier output than is expected.</p> <p>When the value of relative humidity in % is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of humidity readings. The result of this summation is called a "string length".</p> <p>Since the humidity signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic humidity signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current Humidity reading - Humidity reading from 100 milliseconds previous)</p>	<p>> 80 %</p> <p>10 consecutive Humidity readings</p>	<p>Powertrain Relay Voltage for a time</p> <p>If application has a LIN MAF: LIN Communications established with MAF</p> <p>No Active DTCs:</p>	<p>>= 11.0 Volts >= 0.9 seconds</p> <p>PowertrainRelayFault</p>	<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow System Performance (naturally aspirated)	P0101	<p>Detects a performance failure in the Mass Air Flow (MAF) sensor, such as when a MAF value is stuck in range.</p> <p>This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Manifold Pressure (MAP) sensor and Throttle Position sensor (TPS).</p> <p>These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAF sensor. In this case, the MAF Performance diagnostic will fail.</p>	<p>Filtered Throttle Model Error AND ABS(Measured Flow – Modeled Air Flow) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered</p>	<p><= 300 kPa*(g/s) > 25.0 grams/sec > 22.0 kPa</p>	<p>Engine Speed Engine Speed</p> <p>(Coolant Temp OR OBD Coolant Enable Criteria</p> <p>(Coolant Temp OR OBD Max Coolant Achieved</p> <p>Intake Air Temp Intake Air Temp</p> <p>Minimum total weight factor (all factors multiplied together)</p> <p>See Residual Weight Factor tables.</p>	<p>>= 400 RPM <= 5,400 RPM</p> <p>>= -9 Deg C</p> <p>= TRUE)</p> <p><= 130 Deg C</p> <p>= FALSE)</p> <p>>= -20 Deg C <= 129 Deg C</p> <p>>= 0.50</p> <p>Filtered Throttle Model Error multiplied by P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM</p> <p>Modeled Air Flow Error multiplied by P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM and P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est</p>	<p>Continuous</p> <p>Calculation are performed every 12.5 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Active DTCs: No Pending DTCs:	MAP Model 2 Error multiplied by P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM MAP_SensorCircuitFA EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit Low Frequency (Continental MAF)	P0102	<p>Detects a continuous short to ground in the MAF sensor circuit or a MAF sensor that is outputting a frequency that is too low. The diagnostic monitors the MAF sensor frequency output and fails the diagnostic when the MAF frequency is too low. A low MAF frequency is associated with a high engine air flow.</p> <p>The MAF sensor monitors the temperature of a circuit in the air flow of the engine. The temperature of this circuit is related to the mass air flow across the sensor. The mass air flow value is converted by the sensor to a frequency value in Hertz. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the frequency of the square wave signal and converts that frequency to a mass air flow value in grams/second through a transfer function.</p>	MAF Output	<= 850 Hertz (>= 300.7 gm/sec)	Engine Run Time Engine Speed Powertrain Relay Voltage Above criteria present for a period of time	> 0.0 seconds >= 300 RPM >= 9.1 Volts >= 0.5 seconds	400 failures out of 500 samples 1 sample every cylinder firing event	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor Circuit High Frequency (Continental MAF)	P0103	<p>Detects a MAF sensor that is outputting a frequency signal that is too high. The diagnostic monitors the MAF sensor frequency output and fails the diagnostic when the MAF frequency is too high. A high MAF frequency is associated with a low engine air flow.</p> <p>The MAF sensor monitors the temperature of a circuit in the air flow of the engine. The temperature of this circuit is related to the mass air flow across the sensor. The mass air flow value is converted by the sensor to a frequency value in Hertz. A digital square wave signal is transmitted by the sensor to the ECM. The ECM calculates the frequency of the square wave signal and converts that frequency to a mass air flow value in grams/second through a transfer function.</p>	MAF Output	>= 14,500 Hertz (<= 0.00 gm/sec)	Engine Run Time Engine Speed Powertrain Relay Voltage Above criteria present for a period of time	> 0.0 seconds >= 300 RPM >= 9.1 Volts >= 0.5 seconds	400 failures out of 500 samples 1 sample every cylinder firing event	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Performance (naturally aspirated)	P0106	<p>Detects a performance failure in the Manifold Pressure (MAP) sensor, such as when a MAP value is stuck in range.</p> <p>If the engine has been off for a sufficient amount of time, the pressure values in the induction system will have equalized. The MAP sensor value is checked to see if it is within the normal expected atmospheric pressure range. If it is not, then the MAP performance diagnostic will fail.</p> <p>The engine running portion of this diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from other sensors. The other sensors are the Mass Air Flow (MAF) sensor and Throttle Position sensor (TPS).</p> <p>These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model</p>	<p>Engine Running:</p> <p>Filtered Throttle Model Error AND ABS(Measured MAP – MAP Model 1) Filtered AND ABS(Measured MAP – MAP Model 2) Filtered</p>	<p><= 300 kPa*(g/s)</p> <p>> 22.0 kPa</p> <p>> 22.0 kPa</p>	<p>Engine Speed Engine Speed</p> <p>(Coolant Temp OR OBD Coolant Enable Criteria</p> <p>(Coolant Temp OR OBD Max Coolant Achieved</p> <p>Intake Air Temp Intake Air Temp</p> <p>Minimum total weight factor (all factors multiplied together)</p> <p>See Residual Weight Factor tables.</p> <p>No Active DTCs:</p>	<p>>= 400 RPM <= 5,400 RPM</p> <p>>= -9 Deg C</p> <p>= TRUE)</p> <p><= 130 Deg C</p> <p>= FALSE)</p> <p>>= -20 Deg C <= 129 Deg C</p> <p>>= 0.50</p> <p>Filtered Throttle Model Error multiplied by P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM</p> <p>MAP Model 1 Error multiplied by P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM</p> <p>MAP Model 2 Error multiplied by P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM</p> <p>MAP_SensorCircuitFA</p>	<p>Continuous</p> <p>Calculations are performed every 12.5 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the MAP sensor. In this case, the MAP Performance diagnostic will fail.				EGRValvePerformance_F A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA No Pending DTCs: EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		
			Engine Not Rotating: Manifold Pressure OR Manifold Pressure	< 50.0 kPa > 115.0 kPa	Time between current ignition cycle and the last time the engine was running Engine is not rotating If application has a LIN MAF: LIN Communications established with MAF No Active DTCs: No Pending DTCs:	> 5.0 seconds EngineModeNotRunTimer Error MAP_SensorCircuitFA AAP_SnsrCktFA AAP_LIN1_SnsrCktFA MAP_SensorCircuitFP AAP_SnsrCktFP AAP_LIN1_SnsrCktFP	4 failures out of 5 samples 1 sample every 12.5 msec for applications without LIN MAF 1 sample every 25 msec for applications with LIN MAF	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit Low	P0107	Detects a continuous short to ground in the Manifold Absolute Pressure (MAP) signal circuit by monitoring the MAP sensor output voltage and failing the diagnostic when the MAP voltage is too low. The MAP sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	MAP Voltage	< 3.0 % of 5 Volt Range (This is equal to 6.1 kPa)	None		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Manifold Absolute Pressure Sensor Circuit High	P0108	Detects a continuous short to power or open circuit in the Manifold Absolute Pressure (MAP) signal circuit by monitoring the MAP sensor output voltage and failing the diagnostic when the MAP voltage is too high. The MAP sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure.	MAP Voltage	> 90.0 % of 5 Volt Range (This is equal to 115.1 kPa)	None		320 failures out of 400 samples 1 sample every 12.5 msec	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Performance (applications with humidity sensor, but no manifold temperature sensor)	P0111	<p>Detects an Intake Air Temperature (IAT) sensor value that is stuck in range by comparing the IAT sensor value against the IAT2 and coolant temperature sensor values and failing the diagnostic if the IAT value is more different than the IAT2 and coolant temperature values than is expected. If the engine has been off for a long enough period of time, the air temperature values in the engine compartment of the vehicle are considered to have equalized, and the diagnostic can be enabled.</p> <p>The diagnostic will fail if the IAT2 and coolant temperature values are similar, and the IAT value is not similar to the IAT2 and coolant temperature values.</p> <p>This diagnostic is executed once per ignition cycle if the enable conditions are met.</p>	<p>ABS(Power Up IAT - Power Up IAT2)</p> <p>AND</p> <p>ABS(Power Up ECT – Power Up IAT) > ABS(Power Up ECT – Power Up IAT2)</p>	> 25 deg C	<p>Time between current ignition cycle and the last time the engine was running</p> <p>Powertrain Relay Voltage for a time</p> <p>If application has a LIN MAF: LIN Communications established with MAF</p> <p>No Active DTCs:</p>	<p>> 28,800 seconds</p> <p>>= 11.0 Volts >= 0.9 seconds</p> <p>PowertrainRelayFault ECT_Sensor_Ckt_FA IAT_SensorCircuitFA HumTempSnsrCktFA EngineModeNotRunTimer Error</p>	Executes once at the beginning of each ignition cycle if enable conditions are met	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit Low (applications with LIN MAF)	P0112	<p>Detects an erroneously low value being reported over the LIN serial connection from the Intake Air Temperature (IAT) sensor. The diagnostic monitors the IAT sensor output temperature and fails the diagnostic when the IAT temperature is too low.</p> <p>The IAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	IAT Temperature	< -60 degrees C	LIN Communications established with MAF		<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Circuit High (applications with LIN MAF)	P0113	<p>Detects an erroneously high value being reported over the LIN serial connection from the Intake Air Temperature (IAT) sensor. The diagnostic monitors the IAT sensor output temperature and fails the diagnostic when the IAT temperature is too high.</p> <p>The IAT sensor is a thermistor in which the resistance across the sensor can be equated to a temperature. The temperature value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	IAT Temperature	> 150 degrees C	LIN Communications established with MAF		<p>40 failures out of 50 samples</p> <p>1 sample every 100 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Air Temperature Sensor Intermittent In-Range	P0114	<p>Detects a noisy or erratic signal in the Intake Air Temperature (IAT) circuit by monitoring the IAT sensor and failing the diagnostic when the IAT signal has a noisier output than is expected.</p> <p>When the value of the IAT signal in °C is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of IAT readings. The result of this summation is called a "string length".</p> <p>Since the IAT signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic IAT signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current IAT reading - IAT reading from 100 milliseconds previous)</p>	<p>> 80.00 deg C</p> <p>10 consecutive IAT readings</p>	<p>If application has a LIN MAF: LIN Communications established with MAF</p>		<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	<p>Type B, 2 Trips</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					up IAT 2a) ECT drops from power up ECT 2b) Engine run time ===== Diagnostic is aborted when 3) or 4) occurs: 3) Engine run time with vehicle speed below 1b 4) Minimum IAT during test	$\geq 3.3^{\circ}\text{C}$ $\geq 1^{\circ}\text{C}$ Within ≤ 30 seconds ===== > 1800 seconds $\leq -9^{\circ}\text{C}$		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit Low	P0117	Circuit Continuity This DTC detects a short to ground in the ECT (Engine Coolant temperature) signal circuit or the ECT sensor. This is accomplished by monitoring the resistance of the circuit. If the resistance goes out of the expected range the DTC is set.	ECT Resistance (@ 150°C)	< 55 Ohms			5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temp Sensor Circuit High	P0118	Circuit Continuity This DTC detects a short to high or open in the ECT (Engine Coolant temperature) signal circuit or the ECT sensor. This is accomplished by monitoring the resistance of the circuit. If the resistance goes out of the expected range the DTC is set.	ECT Resistance (@ -60°C)	> 134,000 Ohms	Engine run time OR IAT min	> 10.0 seconds ≥ -9.0 °C	5 failures out of 6 samples 1 sec/ sample Continuous	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature (ECT) Sensor Circuit Intermittent	P0119	Circuit Erratic This DTC detects large step changes in the ECT (Engine Coolant temperature) signal circuit or the ECT sensor. Allowable high and low limits are calculated for the next sample based on the previous sample and sensor time constant. If the sensor responds faster than should be possible the DTC is set.	ECT temperature step change: 1) positive step change is greater than calculated high limit OR 2) negative step change is lower than calculated low limit. The calculated high and low limits for the next reading use the following calibrations: 1) Sensor time constant 2) Sensor low limit 3) Sensor high limit *****Generic Example***** If the last ECT reading was 90 Deg C, the Time constant was calibrated at 10 seconds, the low limit was calibrated to -80 Deg C and the high limit was calibrated to 200 Deg C the calculated limits are 101 Deg C and 73 Deg C. The next reading (after the 90 Deg C reading) must be between 73 Deg C and 101 Deg C to be valid. *****	7.4 seconds -60.0 Deg C 200.0 Deg C	No Active DTC's	ECT_Sensor_Ckt_FP	3 failures out of 4 samples 1 sec/ sample Continuous	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No Pending DTCs:	EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit Low	P0122	Detects a continuous or intermittent short low or open in TPS1 circuit by monitoring the TPS 1 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too low. This diagnostic only runs when battery voltage is high enough.	TPS1 % Vref <	0.3250 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P06A3	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS1 Circuit High	P0123	Detects a continuous or intermittent short high in TPS1 circuit by monitoring the TPS 1 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too high. This diagnostic only runs when battery voltage is high enough.	TPS1 % Vref >	4.750 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P06A3	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Coolant Temperature Below Stat Regulating Temperature	P0128	This DTC detects if the ECT (EngineCoolant temperature) does not achieve the required target temperature after an allowed energy accumulation by the engine. This can be caused by an ECT sensor biased low or a cooling system that is not warming up correctly because of a stuck open thermostat or other fault.	<p>Energy is accumulated after the first combustion event using Range #1 or #2 below:</p> <p>Thermostat type is divided into normal (non-heated) and electrically heated.</p> <p>For this application the "type" cal (KeTHMG_b_TMS_ElectHstEquipped) = 0 If the type cal is equal to one, the application has an electrically heated t-stat, if equal to zero the the application has a non heated t-stat. See appropriate section below.</p> <p>***** Type cal above = 1 (Electrically heated t-stat) == == == == Range #1 (Primary) ECT reaches Commanded temperature minus 11 °C when Ambient min is ≤ 52 °C and > 10 °C. Note: Warm up target for range #1 will be at least 75 °C == == == == Range #2 (Alternate) ECT reaches Commanded temperature minus 11 °C when Ambient min is ≤ 10 °C and > -9 °C. Note: Warm up target for range #2 will be at least</p>		<p>No Active DTC's</p> <p>Engine not run time (soaking time before current trip)</p> <p>Engine run time</p> <p>Fuel Condition</p> <p>Distance traveled</p> <p>***** If Engine RPM is continuously greater than for this time period</p> <p>***** The diagnostic test for this key cycle will abort</p> <p>***** If T-Stat Heater commanded duty cycle for this time period</p>	<p>ECT_Sensor_Ckt_FA ECT_Sensor_Perf_FA VehicleSpeedSensor_FA OAT_PtEstFiltFA IAT_SensorCircuitFA MAF_SensorFA THMR_AWP_AuxPumpFA THMR_AHV_FA THMR_SWP_Control_FA THMR_SWP_NoFlow_FA THMR_SWP_FlowStuckOn_FA EngineTorqueEstInaccurate</p> <p>≥ 1,800 seconds</p> <p>30 ≤ Eng Run Tme ≤ 1,470 seconds</p> <p>Ethanol ≤ 87 %</p> <p>≥ 0.75 miles</p> <p>***** 8,200 rpm 5.0 seconds</p> <p>***** > 20.0 % duty cycle > 5.0 seconds</p>	<p>1 failure to set DTC</p> <p>1 sec/ sample</p> <p>Once per ignition key cycle</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			55 °C ***** Type cal above = 0 (non - heated t-stat) == == == == Range #1 (Primary) ECT reaches 75 °C when Ambient min is ≤ 52 °C and > 10 °C. == == == == Range #2 (Alternate) ECT reaches 55 °C when Ambient min is ≤ 10 °C and > -9 °C. *****	system during the warm-up process. The five energy terms are: heat from combustion (with AFM correction), heat from after-run, heat loss to enviroment, heat loss to cabin and heat loss to DFCO.	The diagnostic test for this key cycle will abort ***** ECT at start run	***** -60 ≤ ECT ≤ 56 °C		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 1	P0131	<p>This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	< 25.0 mVolts	<p>No Active DTC's</p> <p>AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Commanded Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active</p>	<p>TPS_ThrottleAuthorityDef aulted MAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA</p> <p>= Not active = Not active = Not active = Not active 10.0 < Volts = Not active = Not active = Not active = Not active</p> <p>= False = False</p> <p>0.9922 < ratio < 1.0137 175 < mgram < 700 = Closed Loop = TRUE (Please see "Closed Loop Enable Clarification" in Supporting Tables).</p>	<p>285 failures out of 350 samples</p> <p>Frequency: Continuous in 100 milli - second loop</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition Ethanol Estimation in Progress Fuel State All of the above met for	Enabled (On) Ethanol ≤ 87 % = Not Active (Please see " Ethanol Estimation in Progress " in Supporting Tables). DFCO not active > 5.0 seconds		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 1	P0132	<p>This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	> 1,050 mvolts	<p>No Active DTC's</p> <p>System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum</p> <p>Low Fuel Condition Diag Only when FuelLevelDataFault</p> <p>*****</p> <p>Secondary delay after above conditions are complete (cold start condition)</p> <p>Secondary delay after above conditions are complete (not cold start condition)</p> <p>Commanded Equivalence Ratio</p> <p>*****</p> <p>All of the above met for</p>	<p>TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA EvapExcessPurgePsbl_FA A FuelInjectorCircuit_FA Ethanol Composition Sensor FA AIR System FA</p> <p>10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds</p> <p>= False = False</p> <p>*****</p> <p>> 235.0 seconds when engine soak time > 28,800 seconds</p> <p>> 235.0 seconds when engine soak time ≤ 28,800 seconds</p> <p>≤ 1.014 EQR</p> <p>*****</p> <p>> 2.0 seconds</p>	<p>100 failures out of 125 samples</p> <p>Frequency: Continuous in 100 milli - second loop</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 1	P0135	<p>This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor.</p> <p>The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.</p>	Heater Current outside of the expected range of	$0.3 < \text{Amps} < 3.1$	<p>No Active DTC's</p> <p>System Voltage Heater Warm-up delay O2S Heater device control</p> <p>B1S1 O2S Heater Duty Cycle</p> <p>All of the above met for</p>	<p>ECT_Sensor_FA</p> <p>> 10.0 Volts = Complete</p> <p>= Not active</p> <p>> zero</p> <p>> 120 seconds</p>	<p>8 failures out of 10 samples</p> <p>Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0137	<p>This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	< 25 mvolts	<p>No Active DTC's</p> <p>AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Commanded Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active</p>	<p>TPS_ThrottleAuthorityDefaulted MAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA</p> <p>= Not active = Not active = Not active = Not active 10.0 < Volts = Not active = Not active = Not active = Not active</p> <p>= False = False</p> <p>0.992 ≤ ratio ≤ 1.014 175 ≤ mgrams ≤ 700 = Closed Loop = TRUE (Please see "Closed Loop Enable Clarification" in Supporting Tables).</p>	<p>320 failures out of 400 samples</p> <p>Frequency: Continuous in 100 milli - second loop</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition Ethanol Estimation in Progress Fuel State All of the above met for	Enabled (On) Ethanol ≤ 87 % = Not Active (Please see “ Ethanol Estimation in Progress ” in Supporting Tables). DFCO not active > 5.0 seconds		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0138	<p>This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	> 1,050 mvolts	<p>No Active DTC's</p> <p>System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>*****</p> <p>Secondary delay after above conditions are complete (cold start condition)</p> <p>Secondary delay after above conditions are complete (not cold start condition)</p> <p>Commanded Equivalence Ratio</p> <p>*****</p> <p>All of the above met for</p>	<p>TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA EvapExcessPurgePsbl_FA A FuelInjectorCircuit_FA Ethanol Composition Sensor FA AIR System FA</p> <p>10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds</p> <p>= False = False</p> <p>*****</p> <p>> 235.0 seconds when engine soak time > 28,800 seconds</p> <p>> 235.0 seconds when engine soak time ≤ 28,800 seconds</p> <p>≤ 1.014 EQR</p> <p>*****</p> <p>> 2.0 seconds</p>	<p>100 failures out of 125 samples</p> <p>Frequency: Continuous in 100 milli - second loop</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 1 Sensor 2	P013A	<p>The P013A diagnostic is the third in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, & P013B. This DTC determines if the secondary O2 sensor has an slow response to an A/F change from Rich to Lean and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>Note: The Primary method is used when the secondary O2 sensor signal transitions from above the upper threshold to below the lower threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P013A diagnostic measures the secondary O2 sensor voltage response rate</p>	<p>Primary Method: The EWMA of the Post O2 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient.</p> <p>OR</p> <p>Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)</p>	<p>> 8.0 units ≤ 7.0 units</p> <p>> 75.0 grams (upper voltage threshold is 500 mvolts and lower voltage threshold is 200 mvolts)</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013B, P013E, P013F, P2270 or P2271</p> <p>> 10.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's") = Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	<p>Type A, 1 Trips EWMA</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>between an upper and lower voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized integral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTC P013A is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p>Secondary method:</p>			<p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>Crankshaft Torque</p> <p>DTC's Passed</p> <p>=====</p> <p>After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).</p>	<p>= False</p> <p>= False</p> <p>= Enabled, refer to Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests for additional info. < 125.0 Nm</p> <p>P2270 (and P2272 if applicable) P013E (and P014A if applicable)</p> <p>=====</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required lower voltage threshold before the accumulated mass air flow threshold is reached.						

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 1 Sensor 2	P013B	<p>The P013B diagnostic is the sixth in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, & P013B. This DTC determines if the secondary O2 sensor has a slow response to an A/F change from Lean to Rich and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>Note: The Primary method is used when the secondary O2 sensor signal transitions from below the lower threshold to above the upper threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P013B diagnostic measures the secondary O2 sensor voltage response rate</p>	<p>Primary Method: The EWMA of the Post O2 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient.</p> <p>OR</p> <p>Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)</p>	<p>> 8.0 units ≤ 7.0 units</p> <p>> 450 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 650 mvolts)</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013A, P013E, P013F, P2270 or P2271</p> <p>> 10.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	<p>Type A, 1 Trips EWMA</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>between an lower and upper voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized integral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTC P013B is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p>Secondary method:</p>			<p>Green Cat System Condition</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>DTC's Passed</p> <p>=====</p> <p>After above conditions are met: Fuel Enrich mode continued.</p> <p>=====</p>	<p>is above 22.0 grams/sec.</p> <p>= Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False</p> <p>= False</p> <p>= Enabled, refer to Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests for additional info.</p> <p>P2270 P013E P013A P2271 P013F</p> <p>=====</p> <p>=====</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required upper voltage threshold before the accumulated mass air flow threshold is reached.			During this test the following must stay TRUE or the test will abort: 0.950 ≤ Base Commanded EQR ≤ 1.100 ===== During this test: Engine Airflow must stay below: and the delta Engine Airflow over 12.5 msec must be:	===== 100 gps ≤ 100.0 gps		

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Rich to Lean Bank 2 Sensor 2	P013C	<p>The P013C diagnostic is the third in a sequence of six intrusive secondary O2 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, & P013D. This DTC determines if the secondary O2 sensor has an slow response to an A/F change from Rich to Lean and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>Note: The Primary method is used when the secondary O2 sensor signal transitions from above the upper threshold to below the lower threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P013C diagnostic measures the secondary O2 sensor voltage response rate</p>	<p>Primary Method: The EWMA of the Post O2 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient.</p> <p>OR</p> <p>Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)</p>	<p>> 8.0 units ≤ 7.0 units</p> <p>> 75.0 grams (upper voltage threshold is 500 mvolts and lower voltage threshold is 200 mvolts)</p>	<p>No Active DTC's</p> <p>B2S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013D, P014A, P014B, P2272 or P2273</p> <p>> 10.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	<p>Type A, 1 Trips EWMA</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>between an upper and lower voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized integral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTC P013C is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p>Secondary method:</p>			<p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>Crankshaft Torque</p> <p>DTC's Passed</p> <p>=====</p> <p>After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).</p>	<p>is above 22.0 grams/sec.</p> <p>= False</p> <p>= False</p> <p>= Enabled, refer to Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests for additional info. < 125.0 Nm</p> <p>P2272 P014A</p> <p>=====</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required lower voltage threshold before the accumulated mass air flow threshold is reached.						

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Slow Response Lean to Rich Bank 2 Sensor 2	P013D	<p>The P013D diagnostic is the sixth in a sequence of six intrusive secondary O2 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, & P013D. This DTC determines if the secondary O2 sensor has a slow response to an A/F change from Lean to Rich and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>Note: The Primary method is used when the secondary O2 sensor signal transitions from below the lower threshold to above the upper threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P013D diagnostic measures the secondary O2 sensor voltage response rate</p>	<p>Primary Method: The EWMA of the Post O2 sensor normalized integral value. The EWMA repass limit is The EWMA calculation uses a 0.28 coefficient.</p> <p>OR</p> <p>Secondary Method: The Accumulated mass air flow monitored during the Slow Response Test (between the upper and lower voltage thresholds)</p>	<p>> 8.0 units ≤ 7.0 units</p> <p>> 450 grams (lower voltage threshold is 350 mvolts and upper voltage threshold is 650 mvolts)</p>	<p>No Active DTC's</p> <p>B2S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR_System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013C, P014A, P014B, P2272 or P2273</p> <p>> 10.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_Res etFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	<p>Type A, 1 Trips EWMA</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>between an lower and upper voltage threshold. The response rate is then normalized to mass air flow rate and scaled resulting in a normalized integral value. The normalized integral is fed into a 1st order lag filter to update the final EWMA result. DTC P013D is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p>Secondary method:</p>			<p>Green Cat System Condition</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>DTC's Passed</p> <p>=====</p> <p>After above conditions are met: Fuel Enrich mode continued.</p> <p>=====</p>	<p>is above 22.0 grams/sec.</p> <p>= Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False</p> <p>= False</p> <p>= Enabled, refer to Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests for additional info.</p> <p>P2272 P014A P013C P2273 P014B</p> <p>=====</p> <p>=====</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		This fault is set if the secondary O2 sensor does not achieve the required upper voltage threshold before the accumulated mass air flow threshold is reached.			During this test the following must stay TRUE or the test will abort: $0.950 \leq \text{Base Commanded EQR} \leq 1.100$ ===== During this test: Engine Airflow must stay below: and the delta Engine Airflow over 12.5 msec must be:	===== 100 gps $\leq 100.0 \text{ gps}$		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 1 Sensor 2	P013E	<p>The P013E diagnostic is the second in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, & P013B. This DTC determines if the secondary O2 sensor has an initial delayed response to an A/F change from Rich to Lean and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary O2 sensor does not achieve the required voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post O2 sensor voltage</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Delayed Response Test under DFCE</p> <p>DFCE begins after: 1) Catalyst has been rich for a minimum of</p> <p>AND 2) Catalyst Rich Accumulation Air Flow is</p>	<p>> 500 mvolts</p> <p>> 84 grams</p> <p>> 1 secs</p> <p>≥ 3.0 grams</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013A, P013B, P013F, P2270 or P2271</p> <p>> 10.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	<p>Type B, 2 Trips</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Only when FuelLevelDataFault Post fuel cell Crankshaft Torque DTC's Passed Number of fueled cylinders ===== After above conditions are met: DFCO mode entered (wo driver initiated pedal input).	is above 22.0 grams/sec. = False = False = Enabled, refer to Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests for additional info. < 125.0 Nm P2270 ≤ 7 cylinders =====		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 1 Sensor 2	P013F	<p>The P013F diagnostic is the fifth in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, & P013B. This DTC determines if the secondary O2 sensor has an initial delayed response to an A/F change from Lean to Rich and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary O2 sensor does not achieve the required voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post O2 sensor voltage</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Delayed Response Test</p>	<p>< 350 mvolts</p> <p>> 1,185 grams</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013A, P013B, P013E, P2270 or P2271</p> <p>> 10.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed</p>	<p>Type B, 2 Trips</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Green Cat System Condition</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>DTC's Passed</p> <p>Number of fueled cylinders</p> <p>=====</p> <p>After above conditions are met: Fuel Enrich mode entered.</p>	<p>is above 22.0 grams/sec.</p> <p>= Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/sec. (Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False</p> <p>= False</p> <p>= Enabled, refer to Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests for additional info.</p> <p>P2270 P013E P013A P2271</p> <p>≥ 1 cylinders</p> <p>=====</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>=====</p> <p>During this test the following must stay TRUE or the test will abort: 0.950 ≤ Base Commanded EQR ≤ 1.100</p> <p>=====</p> <p>During this test: Engine Airflow must stay below:</p> <p>and the delta Engine Airflow over 12.5msec must be :</p>	<p>=====</p> <p>100 gps</p> <p>≤ 100.0 gps</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 1 Sensor 2) (For Dual Bank Exhaust Only	P0141	<p>This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor.</p> <p>The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.</p>	Heater Current outside of the expected range of	0.3 > amps > 2.9	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA > 10.0 Volts = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate.	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 2 Sensor 2	P014A	<p>The P014A diagnostic is the second in a sequence of six intrusive secondary O2 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, & P013D. This DTC determines if the secondary O2 sensor has an initial delayed response to an A/F change from Rich to Lean and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary O2 sensor does not achieve the required voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post O2 sensor voltage</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Delayed Response Test under DFCO</p> <p>DFCO begins after: 1) Catalyst has been rich for a minimum of AND 2) Catalyst Rich Accumulation Air Flow is</p>	<p>> 500 mvolts</p> <p>> 84 grams</p> <p>> 1 secs</p> <p>≥ 3.0 grams</p>	<p>No Active DTC's</p> <p>B2S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013C, P013D, P014B, P2272 or P2273</p> <p>> 10.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed</p>	<p>Type B, 2 Trips</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Only when FuelLevelDataFault Post fuel cell Crankshaft Torque DTC's Passed Number of fueled cylinders ===== After above conditions are met: DFCO mode entered (wo driver initiated pedal input).	is above 22.0 grams/sec. = False = False = Enabled, refer to Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests for additional info. < 125.0 Nm P2272 ≤ 7 cylinders =====		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Lean to Rich Bank 2 Sensor 2	P014B	<p>The P014B diagnostic is the fifth in a sequence of six intrusive secondary O2 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, & P013D. This DTC determines if the secondary O2 sensor has an initial delayed response to an A/F change from Lean to Rich and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary O2 sensor does not achieve the required voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post O2 sensor</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Delayed Response Test</p>	<p>< 350 mvolts</p> <p>> 1,185 grams.</p>	<p>No Active DTC's</p> <p>B2S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013C, P013D, P014A, P2272 or P2273</p> <p>> 10.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed</p>	<p>Type B, 2 Trips</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Green Cat System Condition</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Post fuel cell</p> <p>DTC's Passed</p> <p>Number of fueled cylinders</p> <p>=====</p> <p>After above conditions are met: Fuel Enrich mode entered.</p>	<p>is above 22.0 grams/sec.</p> <p>= Not Valid, Green Cat System condition is considered valid until accumulated airflow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is greater than 22.0 grams/sec.</p> <p>(Note: This feature is only enabled when the vehicle is new and cannot be enabled in service).</p> <p>= False</p> <p>= False</p> <p>= Enabled, refer to Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests for additional info.</p> <p>P2272 P014A P013C P2273</p> <p>≥ 1 cylinders</p> <p>=====</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>=====</p> <p>During this test the following must stay TRUE or the test will abort: 0.950 ≤ Base Commanded EQR ≤ 1.100</p> <p>=====</p> <p>During this test: Engine Airflow must stay below:</p> <p>and the delta Engine Airflow over 12.5msec must be :</p>	<p>=====</p> <p>100 gps</p> <p>≤ 100.0 gps</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 2 Sensor 1	P0151	<p>This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	< 25 mvolts	<p>No Active DTC's</p> <p>AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Commanded Equivalence Ratio Air Per Cylinder</p> <p>Fuel Control State Closed Loop Active</p>	<p>TPS_ThrottleAuthorityDef aulted MAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA</p> <p>= Not active = Not active = Not active = Not active 10.0 < Volts = Not active = Not active = Not active = Not active</p> <p>= False = False</p> <p>0.992 ≤ ratio ≤ 1.014 175 ≤ APC ≤ 700 mgrams</p> <p>= Closed Loop = TRUE (Please see "Closed Loop Enable</p>	<p>285 failures out of 350 samples</p> <p>Frequency: Continuous in 100 milli - second loop</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition Ethanol Estimation in Progress Fuel State All of the above met for	Clarification in Supporting Tables). Enabled (On) ≤ 87 % Ethanol = Not Active (Please see "Ethanol Estimation in Progress" in Supporting Tables). DFCO not active > 5.0 seconds		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 2 Sensor 1	P0152	<p>This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	> 1,050 mvolts	<p>No Active DTC's</p> <p>System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>*****</p> <p>Secondary delay after above conditions are complete (cold start condition)</p> <p>Secondary delay after above conditions are complete (not cold start condition)</p> <p>Commanded Equivalence Ratio</p> <p>*****</p> <p>All of the above met for</p>	<p>TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA EvapExcessPurgePsbl_FA A FuelInjectorCircuit_FA Ethanol Composition Sensor FA AIR System FA</p> <p>10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds</p> <p>= False</p> <p>= False</p> <p>*****</p> <p>> 280.0 seconds when engine soak time > 28,800 seconds</p> <p>> 280.0 seconds when engine soak time ≤ 28,800 seconds</p> <p>≤ 1.014 EQR</p> <p>*****</p> <p>> 2 seconds</p>	<p>100 failures out of 125 samples</p> <p>Frequency: Continuous in 100 milli - second loop</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 2 Sensor 1	P0155	<p>This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor.</p> <p>The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.</p>	Heater Current outside of the expected range of	0.3 > amps > 3.1	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA > 10.0 Volts = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit Low Voltage Bank 2 Sensor 2	P0157	<p>This DTC determines if the O2 sensor signal circuit is shorted low. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is below the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	< 25 mvolts	<p>No Active DTC's</p> <p>AIR intrusive test Fuel intrusive test Idle intrusive test EGR intrusive test System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Commanded Equivalence Ratio Air Per Cylinder Fuel Control State Closed Loop Active</p>	<p>TPS_ThrottleAuthorityDef aulted MAP_SensorFA AIR System FA Ethanol Composition Sensor FA EvapPurgeSolenoidCircuit _FA EvapFlowDuringNonPurg e_FA EvapVentSolenoidCircuit_ FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt _FA FuelInjectorCircuit_FA</p> <p>= Not active = Not active = Not active = Not active 10.0 < Volts = Not active = Not active = Not active = Not active</p> <p>= False</p> <p>= False</p> <p>0.992 ≤ ratio ≤ 1.014 175 ≤ mgrams ≤ 700 = Closed Loop = TRUE (Please see "Closed Loop Enable Clarification" in Supporting Tables).</p>	<p>320 failures out of 400 samples</p> <p>Frequency: Continuous in 100 milli - second loop</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All Fuel Injectors for active Cylinders Fuel Condition Ethanol Estimation in Progress Fuel State All of the above met for	Enabled (On) ≤ 87% Ethanol = Not Active (Please see “ Ethanol Estimation in Progress ” in Supporting Tables). DFCO not active > 5.0 seconds		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Circuit High Voltage Bank 2 Sensor 2	P0158	<p>This DTC determines if the O2 sensor signal circuit is shorted high or open. When enabled, the diagnostic monitors the O2S signal and compares it to the threshold.</p> <p>The diagnostic failure counter is incremented if the O2S signal is above the threshold value. This DTC is set based on the fail and sample counters.</p>	Oxygen Sensor Signal	> 1,050 mvolts	<p>No Active DTC's</p> <p>System Voltage AFM Status Heater Warm-up delay Engine Run Time Engine Run Accum</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>*****</p> <p>Secondary delay after above conditions are complete (cold start condition)</p> <p>Secondary delay after above conditions are complete (not cold start condition)</p> <p>Commanded Equivalence Ratio</p> <p>*****</p> <p>All of the above met for</p>	<p>TPS_ThrottleAuthorityDefaulted MAF_SensorFA MAP_SensorFA EvapExcessPurgePsbl_FA A FuelInjectorCircuit_FA Ethanol Composition Sensor FA AIR System FA</p> <p>10.0 < Volts = All Cylinders active = Complete > 5.0 seconds > 30.0 seconds</p> <p>= False = False</p> <p>*****</p> <p>> 280.0 seconds when engine soak time > 28,800 seconds</p> <p>> 280.0 seconds when engine soak time ≤ 28,800 seconds</p> <p>≤ 1.014 EQR</p> <p>*****</p> <p>> 2 seconds</p>	<p>100 failures out of 125 samples</p> <p>Frequency: Continuous in 100 milli - second loop</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>value. The normalized delay is fed into a 1st order lag filter to update the final EWMA result. DTC P015A is set when the EWMA value exceeds the EWMA threshold.</p> <p>Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p>Secondary method: This fault is set if the primary O2 sensor does not achieve the required lower voltage threshold before a delay time threshold is reached.</p>			<p>O2 Heater (pre sensor) on for Learned Htr resistance</p> <p>Engine Coolant (Or OBD Coolant Enable Criteria</p> <p>IAT Engine run Accum</p> <p>Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)</p> <p>Closed loop integral</p>	<p>considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p> <p>≥ 30 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>> 50 °C = TRUE)</p> <p>> -40 °C > 30 seconds</p> <p>800 ≤ RPM ≤ 2,500</p> <p>750 ≤ RPM ≤ 2,650</p> <p>4.0 ≤ gps ≤ 20.0</p> <p>40.4 ≤ MPH ≤ 82.0</p> <p>36.0 ≤ MPH ≤ 87.0</p> <p>0.75 ≤ C/L Int ≤ 1.12</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed Loop Active Evap Ethanol Estimation in Progress Baro Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ===== All of the above met for at least 1.5 seconds, and then the Force Cat Rich intrusive stage is requested. ===== Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders ===== After above conditions are met: DFCO Mode is entered (wo driver	= TRUE (Please see “ Closed Loop Enable Clarification ” in Supporting Tables). not in control of purge = Not Active (Please see “ Ethanol Estimation in Progress ” in Supporting Tables). > 70 kpa = enabled = not active = not active ≥ 60.0 sec 575 ≤ °C ≤ 1,024 = DFCO possible ===== ===== ≥ 750 mvolts = DFCO active ≤ 7 cylinders =====		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					initiated pedal input).			

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>order lag filter to update the final EWMA result. DTC P015B is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p><u>Secondary method:</u> This fault is set if the primary O2 sensor does not achieve the required higher voltage threshold before a delay time threshold is reached.</p>			<p>Green O2S Condition</p> <p>O2 Heater (pre sensor) on for Learned Htr resistance</p> <p>Engine Coolant (Or OBD Coolant Enable Criteria</p> <p>IAT Engine run Accum</p> <p>Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after</p>	<p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p> <p>≥ 30 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>> 50 °C = TRUE)</p> <p>> -40 °C > 30 seconds</p> <p>800 ≤ RPM ≤ 2,500</p> <p>750 ≤ RPM ≤ 2,650</p> <p>4.0 ≤ gps ≤ 20.0</p> <p>40.4 ≤ MPH ≤ 82.0</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					initially enabled) Closed loop integral Closed Loop Active Evap Ethanol Estimation in Progress Baro Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State Number of fueled cylinders ===== When above conditions are met: Fuel Enrich mode is entered. ===== During this test: Engine Airflow must stay between: and the delta Engine Airflow over 12.5msec	$36.0 \leq \text{MPH} \leq 87.0$ $0.75 \leq \text{C/L Int} \leq 1.12$ = TRUE (Please see "Closed Loop Enable Clarification" in Supporting Tables). not in control of purge = Not Active (Please see "Ethanol Estimation in Progress" in Supporting Tables). $> 70 \text{ kpa}$ = enabled = not active = not active $\geq 60.0 \text{ sec}$ $575 \leq \text{°C} \leq 1,024$ = DFCE inhibit $\geq 1 \text{ cylinders}$ ===== ===== $4 \leq \text{gps} \leq 20$		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					must be :	≤ 50.0 gps		

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Delayed Response Rich to Lean Bank 2 Sensor 1) (For use w/o WRAF	P015C	<p>DTC P015C detects that the primary oxygen sensor for Bank 2 has delayed response when the air fuel ratio transitions from rich to lean condition. This diagnostic runs simultaneously with the intrusive secondary O2 monitor rich to lean tests (P014A / P013C / P2273), which commands fuel cut off.</p> <p>Note: The Primary method is used when the primary O2 sensor signal transitions from above to below the O2 voltage threshold, otherwise the Secondary method is used.</p> <p><u>Primary method:</u> The P015C diagnostic measures the primary O2 sensor response time between a rich condition above a starting voltage threshold and a lower voltage threshold. The response time is then scaled and normalized to mass air flow rate, engine speed, Baro, and intake air temperature resulting in a normalized delay</p>	<p>Primary method: The EWMA of the Pre O2 sensor normalized R2L time delay value. The EWMA repass limit is The EWMA calculation uses a 0.20 coefficient. This method calculates the result when the Pre O2 sensor voltage is</p> <p>OR</p> <p>Secondary method: The Accumulated time monitored during the R2L Delayed Response Test.</p> <p>AND</p> <p>Pre O2 sensor voltage is above</p>	<p>> 0.75 EWMA (sec) ≤ 0.65 EWMA (sec)</p> <p>< 450 mvolts</p> <p>≥ 2.5 Seconds</p> <p>> 100 mvolts</p>	<p>No Active DTC's</p> <p>System Voltage EGR Device Control Idle Device Control Fuel Device Control AIR Device Control</p> <p>Low Fuel Condition Only when FuelLevelDataFault</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted MAP_SensorFA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault MAF_SensorFA EvapPurgeSolenoidCircuit_FA EvapFlowDuringNonPurge_FA EvapVentSolenoidCircuit_FA EvapSmallLeak_FA EvapEmissionSystem_FA FuelTankPressureSnsrCkt_FA FuelInjectorCircuit_FA AIR System FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EthanolCompositionSensor_FA EngineMisfireDetected_FA</p> <p>P0151, P0152, P013C, P013D, P014A, P014B, P2272, P2273</p> <p>> 10.0 Volts = Not active = Not active = Not active = Not active</p> <p>= False = False</p> <p>= Not Valid, Green O2S condition is</p>	<p>Frequency: Once per trip Note: if NaESPD_b_Fast InitResplsActive = TRUE for the given Fuel Bank OR NaESPD_b_RapidResplsActive = TRUE, multiple tests per trip are allowed</p>	<p>Type A, 1 Trips EWMA</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>value. The normalized delay is fed into a 1st order lag filter to update the final EWMA result. DTC P015C is set when the EWMA value exceeds the EWMA threshold.</p> <p>Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p><u>Secondary method:</u> This fault is set if the primary O2 sensor does not achieve the required lower voltage threshold before a delay time threshold is reached.</p>			<p>O2 Heater (pre sensor) on for Learned Htr resistance</p> <p>Engine Coolant (Or OBD Coolant Enable Criteria</p> <p>IAT Engine run Accum</p> <p>Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow</p> <p>Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)</p>	<p>considered valid until the accumulated air flow is greater than</p> <p>Multiple DTC Use_Green Sensor Delay Criteria - Limit</p> <p>for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p> <p>≥ 30 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>> 50 °C = TRUE)</p> <p>> -40 °C > 30 seconds</p> <p>800 ≤ RPM ≤ 2,500</p> <p>750 ≤ RPM ≤ 2,650</p> <p>4.0 ≤ gps ≤ 20.0</p> <p>40.4 ≤ MPH ≤ 82.0</p> <p>36.0 ≤ MPH ≤ 87.0</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed loop integral Closed Loop Active Evap Ethanol Estimation in Progress Baro Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State ===== All of the above met for at least 1.5 seconds, and then the Force Cat Rich intrusive stage is requested. ===== Pre O2S voltage B1S1 at end of Cat Rich stage Fuel State Number of fueled cylinders ===== After above conditions are	$0.75 \leq C/L \text{ Int} \leq 1.12$ = TRUE (Please see " Closed Loop Enable Clarification " in Supporting Tables). not in control of purge = Not Active (Please see " Ethanol Estimation in Progress " in Supporting Tables). $> 70 \text{ kpa}$ = enabled = not active = not active $\geq 60.0 \text{ sec}$ $575 \leq ^\circ\text{C} \leq 1,024$ = DFCE possible ===== ===== $\geq 750 \text{ mvolts}$ = DFCE active $\leq 7 \text{ cylinders}$ ===== =====		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					met: DFCO Mode is entered (wo driver initiated pedal input).			

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>order lag filter to update the final EWMA result. DTC P015D is set when the EWMA value exceeds the EWMA threshold. Note: This EWMA diagnostic employs two features, Fast Initial Response (FIR) and Rapid Step Response (RSR). The FIR feature is used following a code clear event or any event that results in erasure of the engine controller's non-volatile memory. The RSR feature is used when a step change in the test result is identified. Both these temporary features improve the EWMA result following a non-typical event by allowing multiple intrusive tests on a given trip until the total number of tests reach a calibration value.</p> <p><u>Secondary method:</u> This fault is set if the primary O2 sensor does not achieve the required higher voltage threshold before a delay time threshold is reached.</p>			<p>Green O2S Condition</p> <p>O2 Heater (pre sensor) on for Learned Htr resistance</p> <p>Engine Coolant (Or OBD Coolant Enable Criteria</p> <p>IAT Engine run Accum</p> <p>Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)</p> <p>Engine Airflow Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)</p>	<p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S1, B2S1 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow is above 22.0 grams/sec.</p> <p>≥ 30 seconds = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>> 50 °C = TRUE)</p> <p>> -40 °C > 30 seconds</p> <p>800 ≤ RPM ≤ 2,500</p> <p>750 ≤ RPM ≤ 2,650</p> <p>4.0 ≤ gps ≤ 20.0</p> <p>40.4 ≤ MPH ≤ 82.0</p> <p>36.0 ≤ MPH ≤ 87.0</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed loop integral Closed Loop Active Evap Ethanol Estimation in Progress Baro Post fuel cell EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Predicted Catalyst temp Fuel State Number of fueled cylinders ===== When above conditions are met: Fuel Enrich mode is entered. ===== During this test: Engine Airflow must stay between: and the delta Engine Airflow over 12.5msec must be :	$0.75 \leq C/L \text{ Int} \leq 1.12$ = TRUE (Please see " Closed Loop Enable Clarification " in Supporting Tables). not in control of purge = Not Active (Please see " Ethanol Estimation in Progress " in Supporting Tables). $> 70 \text{ kpa}$ = enabled = not active = not active $\geq 60.0 \text{ sec}$ $575 \leq ^\circ\text{C} \leq 1,024$ = DFCO inhibit $\geq 1 \text{ cylinders}$ ===== ===== $4 \leq \text{gps} \leq 20$ $\leq 50.0 \text{ gps}$		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2S Heater Performance Bank 2 Sensor 2	P0161	<p>This DTC determines if the O2 sensor heater is functioning properly by monitoring the current through the heater circuit. This test compares the measured heater current (monitored thru the low side driver) and compares it to the expected values (over the voltage range provided) for the released sensor.</p> <p>The diagnostic failure counter is incremented if the heater current is outside the expected range. This DTC is set based on the fail and sample counters.</p>	Heater Current outside of the expected range of	0.3 > amps > 2.9	No Active DTC's System Voltage Heater Warm-up delay O2S Heater device control B1S1 O2S Heater Duty Cycle All of the above met for	ECT_Sensor_FA > 10.0 Volts = Complete = Not active > zero > 120 seconds	8 failures out of 10 samples Frequency: 1 tests per trip 5 seconds delay between tests and 1 second execution rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Lean Bank 1	P0171	<p>Determines if the primary fuel control system for Bank 1 is in a lean condition, based on the filtered long-term and short-term fuel trim. A normally operating system operates centered around long-term fuel trim metric of 1.0. For lean conditions extra fuel trim is required therefor values > 1.0 indicate a Lean condition.</p> <p>A fault is determined, when the long term fuel metric exceeds the threshold value. In addition to the long-term fuel trim limit, the short-term fuel trim metric can be monitored and the fault sets once both threshold values are exceeded. The short-term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority.</p>	<p>The filtered long-term fuel trim metric</p> <p>AND</p> <p>The filtered short-term fuel trim metric (Note: any value below 0.95 effectively nullifies the short-term fuel trim criteria)</p>	<p>>= 1.345</p> <p>>= 0.100</p> <p>If a fault has been detected the long-term fuel trim metric must be < 1.150 and the short-term fuel trim metric must be < 1.150 to repass the diagnostic.</p>	<p>Engine speed BARO Coolant Temp</p> <p>Coolant Temp MAP Inlet Air Temp MAF Fuel Level</p> <p>Long Term Fuel Trim data accumulation:</p> <p>Sometimes, certain Long-Term Fuel Trim Cells are not utilized for control and/or diagnosis</p>	<p>400 <rpm< 7,000 > 70 kPa > -40 °C (or OBD Coolant Enable Criteria = TRUE) < 150 °C 10 <kPa< 255 -40 <°C< 150 1 <g/s< 1,000 > 10 % or if fuel sender is faulty the diagnostic will bypass the fuel level criteria.</p> <p>> 25.00 seconds of data must accumulate on each trip, with at least 15.00 seconds of data in the current fuel trim cell before a pass or fail decision can be made. Additional time can be required for cold ambient starts to accommodate larger minimum LTM's for startability reasons. See Startup Engine Coolant adjustment to Minimum accumulation time</p> <p>(Please see P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage in Supporting Tables for a list of cells utilized for diagnosis)</p>	<p>Frequency: 100 ms Continuous Loop</p>	<p>Type B, 2 Trips</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Closed Loop Long Term FT EGR Diag. Catalyst Diag. Post O2 Diag. Device Control EVAP Diag. No active DTC:	Enabled Enabled (Please see "Closed Loop Enable Clarification" and "Long Term FT Enable Criteria" in Supporting Tables.) Intrusive Test Not Active Intrusive Test Not Active Intrusive Test Not Active Not Active Large Leak Diagnostic (P0455) Not Active IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR_System FA EvapExcessPurgePsbl_F A Ethanol Composition Sensor FA FuelInjectorCircuit_FA EngineMisfireDetected_F A EGRValvePerformance_F A EGRValveCircuit_FA MAP_EngineVacuumStat us AmbPresDfstdStatus TC_BoostPresSnsrFA O2S_Bank_1_Sensor_1_ FA		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority.</p> <p>Once purge is enabled if the filtered Purge Long Term Fuel Trim metric > 0.710 , the test passes without intrusively checking the filtered Non-Purge Long Term Fuel Trim metric. However if the filtered Purge Long Term Fuel Trim metric is <= 0.710 , the Intrusive test is invoked. The purge is ramped off to determine if excess purge vapor is the cause of the rich condition. If during 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric <= 0.705 the fault will set.</p> <p>Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions, and the execution frequency of other diagnostics. This is why the intrusive test is operated over several</p>		<p>term fuel trim metric must be > 0.850 to repass the diagnostic. The intrusive test will be enabled at long-term fuel metric values < 0.71 until the diagnostic repasses after a failure.</p>		<p>If the accumulated purge volume is > 0.0 grams, the intrusive test will not be inhibited even if Purge Vapor Fuel is > 100.0 %.</p>	<p>time to purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge Long Term Fuel Trim metric > 0.710 for at least 200.00 seconds, indicating that the canister has been purged.</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		segments allowing Purge to reenable between segments. Likewise, for these reasons, if after the 5 intrusive segments the diagnostic continues to pass, there is a delay period of 300 seconds to allow sufficient time to purge excess vapors from the canister, before re-evaluating a Rich condition if it still exists.						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Long Term FT</p> <p>EGR Diag. Catalyst Diag. Post O2 Diag. Device Control EVAP Diag.</p> <p>No active DTC:</p>	<p>Enabled (Please see "Closed Loop Enable Clarification" and "Long Term FT Enable Criteria" in Supporting Tables.)</p> <p>Intrusive Test Not Active Intrusive Test Not Active Intrusive Test Not Active Not Active Large Leak Diagnostic (P0455) Not Active</p> <p>IAC_SystemRPM_FA MAP_SensorFA MAF_SensorFA MAF_SensorTFTKO AIR_System FA EvapExcessPurgePsbl_FA Ethanol Composition Sensor FA FuelInjectorCircuit_FA EngineMisfireDetected_FA EGRValvePerformance_FA EGRValveCircuit_FA MAP_EngineVacuumStatus AmbPresDfstdStatus TC_BoostPresSnsrFA O2S_Bank_2_Sensor_1_FA</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel System Too Rich Bank 2	P0175	<p>Determines if the fuel control system is in a rich condition, based on the filtered long-term fuel trim metric. A normally operating system operates centered around long-term fuel trim metric of 1.0. For rich conditions less fuel trim is required therefore values < 1.0 indicate a rich condition.</p> <p>There are two methods to determine a Rich fault. They are Passive and Intrusive.</p> <p>A Passive Test decision can be made up until the time that purge is first enabled. From that point forward, rich faults can only be detected by turning purge off intrusively. If during this period of time the filtered long-term fuel trim metric exceeds the threshold a fault will be set. In addition to the long-term fuel trim limit, the short-term fuel trim metric can be monitored and the fault sets once both threshold values are exceeded. The short-</p>	<p>Passive Test: The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)</p> <p>*****</p> <p>Intrusive Test: For 3 out of 5 intrusive segments,</p> <p>the filtered Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Non-Purge Long Term Fuel Trim metric</p> <p>AND</p> <p>The filtered Short Term Fuel Trim metric (Note: any value above 1.05 effectively nullifies the short-term fuel trim criteria)</p>	<p><= 0.705</p> <p><= 2.000</p> <p>*****</p> <p><= 0.710</p> <p><= 0.705</p> <p><= 2.000</p> <p>If a fault has been detected (by the passive or intrusive test) the long-term fuel trim metric must be ></p>	<p>Purge Vapor Fuel</p>	<p>Secondary Parameters and Enable Conditions are identical to those for P0174, with the exception that fuel level is not considered.</p> <p><= 100.00 % Intrusive Test is inhibited when Purge Vapor percentage is greater than this threshold. (Note: values greater than 50% indicate the Purge Vapor Fuel requirement is not being used)</p> <p>A minimum number of accumulated Fuel Trim Data samples are required to adequately learn a correct Purge Vapor Fuel value. See the table</p> <p>Minimum Non-Purge Samples for Purge (Vapor Fuel) for the Purge Off cells used to validate the Purge Vapor Fuel parameter.</p> <p>If the accumulated purge volume is > 0.0 grams,</p>	<p>Frequency: 100 ms Continuous Loop</p> <p>Segment Definition: Segments can last up to 60 seconds and are separated by the lesser of 20.00 seconds of purge-on time or enough time to purge 36 grams of vapor. A maximum of 5 completed segments or 20 attempts are allowed for each intrusive test. After an intrusive test report is completed, another intrusive test cannot occur for 300 seconds to allow sufficient time to</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>term fuel trim metric is only monitored on programs that have acceptable emissions when the long-term fuel metric reaches its full authority.</p> <p>Once purge is enabled if the filtered Purge Long Term Fuel Trim metric > 0.710 , the test passes without intrusively checking the filtered Non-Purge Long Term Fuel Trim metric. However if the filtered Purge Long Term Fuel Trim metric is <= 0.710 , the Intrusive test is invoked. The purge is ramped off to determine if excess purge vapor is the cause of the rich condition. If during 3 out of 5 intrusive segments, the filtered Purge Long Term Fuel Trim metric <= 0.705 the fault will set.</p> <p>Performing intrusive tests too frequently may also affect EVAP and EPAIII emissions, and the execution frequency of other diagnostics. This is why the intrusive test is operated over several</p>		<p>0.705 and the short-term fuel trim metric must be > 0.850 to repass the diagnostic. The intrusive test will be enabled at long-term fuel metric values < 0.71 until the diagnostic repasses after a failure.</p>		<p>the intrusive test will not be inhibited even if Purge Vapor Fuel is > 100.0 %.</p> <p>(Note: values greater than 50% indicate the Purge Vapor Fuel requirement is not being used)</p>	<p>purge excess vapors from the canister. During this period, fuel trim will pass if the filtered Purge Long Term Fuel Trim metric > 0.710 for at least 200.00 seconds, indicating that the canister has been purged.</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		segments allowing Purge to renable between segments. Likewise, for these reasons, if after the 5 intrusive segments the diagnostic continues to pass, there is a delay period of 300 seconds to allow sufficient time to purge excess vapors from the canister, before re-evaluating a Rich condition if it still exists.						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit Range/ Performance	P018B	<p>This DTC detects a fuel pressure sensor response stuck within the normal operating range using an intrusive test (as follows)</p> <p>a] Intrusive Test Trigger: 1] Fuel Pump Duty Cycle Clamped Time (min or max duty cycle) >= 5 sec</p> <p>Or 2] Fuel Pres Err Variance <= calibration value KeFDBR_cmp_FPSS_MinPres</p> <p>Variance ; Otherwise, Report status as Pass</p> <p>b] Intrusive test freq limit: 60 sec between intrusive tests that pass,</p> <p>c] Intrusive test Fuel Flow limit: Fuel Flow Actual < Max allowed Fuel Flow rate</p>	Sensed fuel pressure change [absolute value, during intrusive test]	<= 30 kPa	<p>a) Diagnostic enabled [FDBR_b_FPSS_DiagEnb Id]</p> <p>b) Timer Engine Running [FDBR_t_EngModeRunCoarse]</p> <p>c1) Fuel Flow Rate Valid</p> <p>c2) FDB_FuelPresSnsrCktFA</p> <p>c3) Reference Voltage Fault Status [DTC P0641]</p> <p>c4) FAB_FuelPmpCktFA</p> <p>c5) Fuel Control Enable Fault Active [DTC P12A6]</p> <p>c6) Fuel Pump Driver Module OverTemp Fault Active [DTC P1255]</p> <p>c7) Fuel Pump Speed Fault Active [DTC P129F]</p> <p>c8) CAN Sensor Bus message \$0C3 Comm Fault [CFMR_b_FTZM_Info1_UcodeCmFA DTC P165C]</p> <p>c9) CAN Sensor Bus Fuel Pmp Spd Command ARC and Checksum Comm Fault Code [CFMR_b_FTZM_Cmd1_UcodeCmFA DTC]</p>	<p>a) == TRUE</p> <p>b) >= 5.00 seconds</p> <p>c1) == TRUE</p> <p>c2) <> TRUE</p> <p>c3) <> TRUE</p> <p>c4) <> TRUE</p> <p>c5) <> TRUE</p> <p>c6) <> TRUE</p> <p>c7) <> TRUE</p> <p>c8) <> TRUE</p> <p>c9) <> TRUE</p>	<p>1 sample / 12.5 millisec</p> <p>Intrusive Test Duration: Fuel Flow - related (5 to 12 sec)</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					c10) Fuel Pump Duty Cycle Fault Active c11) Sensor Configuration [FDBR_e_FuelPresSnsrC onfig] c12) Sensor Bus Relay On d) Emissions Fuel Level Low [Message \$3FB] e) Fuel Control Enable f) Fuel Pump Control State g) Instantaneous Fuel Flow [FCBR_dm_InstFuelFlow] h) Diagnostic System Disabled [DRER_b_DiagSysDsb] j1) Fuel Pmp Speed Command Alive Rolling Count and Checksum Error [CAN Bus B \$0CE] [CFMR_b_FTZM_Cmd1_ ARC_ChkErr DTC] j2) CAN Sensor Bus message \$0C3_Available j3) Fuel Pres Sensor Ref Voltage Status Message Counter Incorrect Alive Rolling Count and	c10) <> TRUE c11) == CeFDBR_e_WiredTo_FT ZM c12) == TRUE d) <> TRUE e) == TRUE f) == Normal Control OR == Fuel Pres Sensor Stuck Control g) >= 0.05 gm/sec h) <> TRUE j1) <> TRUE j2) == TRUE j3) <> TRUE		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Checksum Error [CAN Bus B \$0C3] [CFMR_b_FTZM_Info1_A RC_ChkErr DTC]			

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit Low	P018C	This DTC detects if the fuel pressure sensor circuit is shorted low Values are analyzed as percent of sensor reference voltage $[[Abs [5.0V - SensorVoltsActual] / 5.0V] * 100\%]$	Fuel Pressure Sensor output % [re. full range as percent of 5.0V reference]	< 4.00 % or [0 kPa gauge]	a) Diagnostic enabled [FDBR_b_FPSnsrCktLoDiagEnbl] b) Run_Crank Active [PMDR_b_RunCrankActive] c) Diagnostic System Disabled [DRER_b_DiagSysDsbl] d) Pressure Sensor Configuration [FDBR_e_FuelPresSnsrConfig]	a) == TRUE b) == TRUE c) <> TRUE d1) IF calibration CeFDBR_e_WiredTo_FT ZM == WiredTo ECM d2) IF NOT, then see Case2	64.00 failures / 80.00 samples 1 sample/12.5 ms	Type B, 2 Trips
			Fuel Pressure Sensor output % [re. full range as percent of 5.0V reference]	< 4.00 % or [0 kPa gauge]	a) Diagnostic enabled [FDBR_b_FPSnsrCktLoDiagEnbl] b) Run_Crank Active [PMDR_b_RunCrankActive] c) Diagnostic System Disabled [DRER_b_DiagSysDsbl] d1) Pressure Sensor Configuration [FDBR_e_FuelPresSnsrConfig] d2) Sensor Bus Relay On d3) CAN Sensor Bus message \$0C3_Available d4) Fuel Pres Sensor Ref	a) == TRUE b) == TRUE c) <> TRUE d1) IF calibration CeFDBR_e_WiredTo_FT ZM == WiredTo FTZM d2) == TRUE d3) == TRUE d4) <> TRUE	64.00 failures / 80.00 samples 1 sample/12.5 ms	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B \$0C3] [CFMR_b_FTZM_Info1_A RC_ChkErr DTC]	d2) IF calibration CeFDBR_e_WiredTo_FT ZM <> WiredTo FTZM, then see Case1		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pressure Sensor "B" Circuit High	P018D	This DTC detects if the fuel pressure sensor circuit is shorted High Values are analyzed as percent of sensor reference voltage $[[Abs [5.0V - SensorVoltsActual] / 5.0V] * 100\%]$	Fuel Pressure Sensor output % [re. full range as percent of 5.0V reference]	> 96.00 % or [743 kPa ga]	a) Diagnostic enabled [FDBR_b_FPSnsrCktLoDiagEnbl] b) Run_Crank Active [PMDR_b_RunCrankActive] c) Diagnostic System Disabled [DRER_b_DiagSysDsbl] d) Pressure Sensor Configuration [FDBR_e_FuelPresSnsrConfig]	a) == TRUE b) == TRUE c) <> TRUE d1) IF calibration CeFDBR_e_WiredTo_FT ZM == WiredTo ECM d2) IF NOT, then see Case2	64.00 failures / 80.00 samples 1 sample/12.5 ms	Type B, 2 Trips
			Fuel Pressure Sensor output % [re. full range as percent of 5.0V reference]	> 96.00 % or [743 kPa ga]	a) Diagnostic enabled [FDBR_b_FPSnsrCktLoDiagEnbl] b) Run_Crank Active [PMDR_b_RunCrankActive] c) Diagnostic System Disabled [DRER_b_DiagSysDsbl] d1) Pressure Sensor Configuration [FDBR_e_FuelPresSnsrConfig] d2) Sensor Bus Relay On d3) CAN Sensor Bus message \$0C3_Available d4) Fuel Pres Sensor Ref	a) == TRUE b) == TRUE c) <> TRUE d1) IF calibration CeFDBR_e_WiredTo_FT ZM == WiredTo FTZM d2) == TRUE d3) == TRUE d4) <> TRUE	64.00 failures / 80.00 samples 1 sample/12.5 ms	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B \$0C3] [CFMR_b_FTZM_Info1_A RC_ChkErr DTC]	d2) IF calibration CeFDBR_e_WiredTo_FT ZM <> WiredTo FTZM, then see Case1		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT SIDI High Pressure Sensor Performance	P0191	The DTC determines if there is a skewed control fuel rail sensor (Sensor1) via a comparison to diagnostic sensor (sensor2) continuously when the engine is running and the commanded pressure is steady.	Primary sensor (P1) vs. Secondary sensor (P2) performance rationality ((Low Limit fail Filtered Fuel Control Error) OR (High Limit Fail: Filtered Fuel Control Error)) AND (Filtered Absolute delta between sensor1 and sensor2	<= P0191 - Low fail limit of fuel control due to pressure sensor skewed low (See supporting table) >= P0191 - High fail limit of fuel control due to high pressure sensor skewed High (see Supporting table) >= 1.00 mpa Note: fuel control error is calculated based on the squareroot of sensor1 divided by sensor2, this value is filter to ensure proper failure detection. Absolute delta between sensor1 and sensor2 value is filter to ensure proper failure detection.	Commanded Pressure rate of change (increasing or decreasing) for a period of time	< 0.70 mpa >= 1.25 seconds Enabled when a code clear is not active or not exiting device control	Filter Fuel Control Error term and Absolute delta between sensor1 and sensor2 exceed Low or High Fail limit for a duration >= 1.50 seconds This is diagnostic runs Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure Sensor 1 Out of Range	P0192	<p>This DTC diagnose SENT high pressure sensor 1 that is too low out of range.</p> <p>If the sensor digital value (representing the reference voltage) is below the lower digital threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported. A pass is reported for this DTC if the low sample counter reaches its threshold.</p>	High Pressure Rail Sensor 1 SENT digital read value	=< 94			<p>Time Based: 400 Failuer out of 500 Samples 6.25 ms per Sample Continuous</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Temperature (EOT) Sensor Performance	P0196	Determines if the engine oil temperature (EOT) sensor is stuck or biased in range. Three independent tests can be used. 1) Cold Start Test Compares EOT to ECT and IAT at powerup after a long soak (Fast and regular tests). 2) Warm Up Test Compares EOT to a target EOT after a large enough accumulated airflow has occurred. 3) Continuous Test Compares the measured EOT to modeled EOT on a continuous basis on a warm engine.	Fast Cold Start Test <u>To indicate an fast fail:</u> Absolute value of Powerup EOT - Powerup ECT AND Absolute value of Powerup IAT - Powerup ECT <u>To indicate a fast pass:</u> Absolute value of Powerup EOT - Powerup ECT AND Absolute value of Powerup EOT - Powerup IAT	EOT Temp Diff > P0196_FastFailTemp Diff (See P0196 details on Supporting Tables Tab) AND < 16 degrees C AND < 16 degrees C AND < 16 degrees C	EOT Diagnostic main Status AND Engine Running Cold Start Specific EOT Test Conditions: Use Cold Start Diagnostic Engine Off Time Engine Off Timer Validity No active DTC's	Enabled = True Disabled > 540 Seconds = True Fault bundles: IgnitionOffTimer_FA IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngOilTempSensorCircuit FA	Cold Start Fast Test - one failure out of one sample - test performed once per second	Type B, 2 Trips
			Cold Start Test <u>Pass Condition 1:</u> Absolute value of Powerup EOT - Powerup ECT AND Absolute value of Powerup EOT - minIAT OR <u>Pass Condition 2:</u> Absolute value of Powerup EOT - Powerup ECT	<= 16 Deg C <= 16 Deg C OR > 16 Deg C	All three tests (Cold/Warm/Continuous) EOT Diagnostic main enable AND Engine Running Cold Start Specific EOT Test Conditions: Use Cold Start Diagnostic Engine Off Time Engine Off Timer Validity	Enabled = True Disabled > 540 Seconds = True		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>AND (IAT minimum observed with Block Heater or (IAT minimum observed and Absolute value of power up IAT - min. observed IAT))</p> <p>AND Absolute value of Powerup EOT - Powerup IAT</p> <p>AND Absolute value of Powerup EOT - minIAT</p> <p><u>Fail Condition:</u> Absolute value of Powerup EOT - Powerup ECT</p> <p>AND (IAT minimum observed with Block Heater or (IAT minimum observed and Absolute value of power up IAT - min. observed IAT))</p> <p>AND (Absolute value of Powerup EOT - Powerup IAT or Absolute value of Powerup EOT - minIAT)</p> <p>AND Absolute value of Powerup ECT - Powerup IAT</p>	<p>AND > -7 Deg C > -10 Deg C <= 5 Deg C</p> <p>AND <= 16 Deg C</p> <p><= 16 Deg C</p> <p>> 16 Deg C</p> <p>AND > -7 Deg C > -10 Deg C <= 5 Deg C</p> <p>AND > 16 Deg C</p> <p>> 16 Deg C</p> <p>AND <= 16 Deg C</p>	<p>Time above Minimum Vehicle Speed</p> <p>Time less than Vehicle speed resets above timer</p> <p>No active DTC's</p>	<p>> 9 MPH for > 400 seconds</p> <p>< 15.0 for > 20.0 seconds</p> <p>Fault bundles: IgnitionOffTimer_FA IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngOilTempSensorCircuit FA</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AND Absolute value of Powerup ECT - minIAT	AND <= 16 Deg C				
			Warmup Test <u>Warm Up Fail Condition:</u> EOT <u>Warm Up Test Pass Condition:</u> EOT	< 70 Deg C => 70 Deg C	EOT Diagnostic main enable Engine Running Warm Up EOT Test Specific Conditions: Use Warm Up EOT Diagnostic Power up ECT Power up ECT Total accumulated engine airflow since engine start DISABLE CONDITIONS (for all three tests)No active DTC's	Enabled = True Disabled > 200 degrees C < 200 degrees C >= P0196_TotalAccumulate dFlow (See P0196 details on Supporting Tables Tab) Fault bundles: IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngOilTempSensorCircuit FA	Warm up Tests - one failure out of one sample - test performed once per second	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>Continuous Test</p> <p><u>Pass Condition:</u></p> <p>(Measured Oil Temperature - Modeled Oil Temperature)</p> <p>OR</p> <p>Absolute value of (Measured Oil Temperature - Modeled Oil Temperature)</p> <p><u>Fail Condition:</u></p> <p>(Measured Oil Temperature - Modeled Oil Temperature)</p> <p>AND</p> <p>Absolute value of (Measured Oil Temperature - Modeled Oil Temperature)</p>	<p>≥ 0 and ≤ 40.0</p> <p>OR</p> <p>≥ 0 and ≤ 40.0</p> <p>> 40.0</p> <p>AND</p> <p>> 40.0</p>	<p>EOT Diagnostic main enable</p> <p>Engine Running</p> <p>Continuous EOT Test Specific Conditions: Use Continuous Diagnostic</p> <p>Power up ECT and ECT</p> <p>All of three criteria above AND</p> <p>EOT Model Oil Temperature reach Equilibrium</p> <p>OR</p> <p>Use quick transition to equilibrium state and ECT</p> <p>DISABLE CONDITIONS (for all three tests)No active DTC's</p>	<p>Enabled</p> <p>= True</p> <p>Enabled</p> <p>≥ -7 and ≤ 105 Deg C</p> <p>≥ 45 and ≤ 105 Deg C</p> <p>≥ 93 Deg C</p> <p>Enabled and \geq ECT from 5 sec previous</p> <p>Fault bundles: IAT_SensorFA ECT_Sensor_Ckt_FA MAF_SensorFA EngOilTempSensorCircuitFA IAT_SensorCircuitFA EngOilModeledTempValid</p>	<p>Continuous Test 70 failures out of 100 samples performed once per second</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Temperature (EOT) Circuit Low	P0197	Controller specific output driver circuit diagnoses the Engine Oil Temperature (EOT) Sensor low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Engine Oil Temperature Sensor (EOT) Circuit Resistance	< 25 ohms	Diagnostic Status	Enabled	4 failures out of 5 samples Sampled every 1 second	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Temperature (EOT) Circuit High	P0198	Controller specific output driver circuit diagnoses the Engine Oil Temperature (EOT) Sensor low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Engine Oil Temperature Sensor (EOT) Circuit Resistance	> 450,000 ohms	Diagnostic Status Engine Run Time OR ECT	Enabled > 20.0 seconds >= -20 Deg C	4 failures out of 5 samples Sampled every 1 second	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Temperature Sensor (EOT) Circuit Intermittent	P0199	Determines if an intermittent fault exists on the engine oil temperature sensor circuit. This diagnostic compares each temperature sample to the previous sample and measures cumulative error over a sample period.	<p>Continuous Test</p> <p><u>Pass/Fail Condition:</u></p> <p>Temperature signal string length, cumulative sum of absolute value of (Oil Temperature - Previous Oil Temperature)</p>	String Length >= 20.00 °C	None	Enabled	4 failures out of 5 samples, sampled every 2 seconds	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Coolant Temperature Dropped Below Diagnostic Monitoring Temperature	P01F0	This DTC detects an unexplained cooling system cool down below the OBD monitoring threshold during normal operating conditions. This check is run throughout the key cycle.	<p>For this application the "type" cal (KeTHMG_b_TMS_ElectHstEquipped) = 0</p> <p>If the type cal is equal to one, the application has an electrically heated t-stat, if equal to zero the the application has an non heated t-stat. See appropriate section below.</p> <p>*****</p> <p>Type cal above = 0 (non - heated t-stat) == == == ==</p> <p>Engine coolant temperature</p> <p>≤ 74.0 Deg C</p> <p>*****</p> <p>Type cal above = 1 (Electrically heated t-stat) == == == ==</p> <p>Engine coolant temperature</p> <p>≤ 87.9 Deg C</p>	<p>≤ 74.0 Deg C</p> <p>≤ 87.9 Deg C</p>	<p>No Active DTC's</p> <p>Engine Runtime</p> <p>Distance traveled this key cycle</p> <p>Ambient air pressure</p> <p>Ambient air temperature</p> <p>*****</p> <p>Engine coolant temperature At least once during the key cycle</p> <p>Type 0 (non-heated t-stat)</p> <p>Type 1 (Electrically heated T-stat)</p> <p>*****</p> <p>Heat to coolant</p> <p>DFCO time</p>	<p>ECT_Sensor_Ckt_FA VehicleSpeedSensor_FA OAT_PtEstFiltFA THMR_AWP_AuxPumpFA THMR_AHV_FA THMR_SWP_Control_FA EngineTorqueEstInaccurate ECT_Sensor_Perf_FA THMR_SWP_NoFlow_FA THMR_SWP_FlowStuckOn_FA</p> <p>≥ 30.0 seconds</p> <p>≥ 2.0 km</p> <p>≥ 55.0 kPa</p> <p>≥ -9.0 Deg C</p> <p>≥ 75 Deg C</p> <p>≥ 93.9 to 93.9 Deg C</p> <p>≥ P01F0 - Heat To Coolant Min 2D</p> <p>≤ 175.0 seconds</p>	30 seconds out of a 60 seconds window	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Thermostat duty cycle RPM Active Fuel Management is not in	≤ 20.0 % ≤ 5,000 Half Cylinder Mode		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Open Circuit - (SIDI)	P0201	<p>Controller specific output driver circuit diagnoses Injector 1 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 1 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>>= 200 KOhms impedance between signal and controller ground</p> <p>>= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>>= 11 Volts >= 0 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Open Circuit - (SIDI)	P0202	<p>Controller specific output driver circuit diagnoses Injector 2 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 2 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>>= 200 KOhms impedance between signal and controller ground</p> <p>>= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>>= 11 Volts >= 0 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Open Circuit - (SIDI)	P0203	<p>Controller specific output driver circuit diagnoses Injector 3 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 3 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>>= 200 KOhms impedance between signal and controller ground</p> <p>>= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>>= 11 Volts >= 0 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Open Circuit - (SIDI)	P0204	<p>Controller specific output driver circuit diagnoses Injector 4 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 4 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>>= 200 KOhms impedance between signal and controller ground</p> <p>>= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>>= 11 Volts >= 0 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 Open Circuit - (SIDI)	P0205	<p>Controller specific output driver circuit diagnoses Injector 5 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 5 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>>= 200 KOhms impedance between signal and controller ground</p> <p>>= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>>= 11 Volts >= 0 Sec</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Open Circuit - (SIDI)	P0206	<p>Controller specific output driver circuit diagnoses Injector 6 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 6 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>>= 200 KOhms impedance between signal and controller ground</p> <p>>= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>>= 11 Volts >= 0 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 Open Circuit - (SIDI)	P0207	<p>Controller specific output driver circuit diagnoses Injector 7 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 7 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>>= 200 KOhms impedance between signal and controller ground</p> <p>>= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>>= 11 Volts >= 0 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 Open Circuit - (SIDI)	P0208	<p>Controller specific output driver circuit diagnoses Injector 7 low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.</p> <p>Or</p> <p>Controller specific output driver circuit diagnoses Injector 7 high sided driver for an open circuit failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.</p>	<p>Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p> <p>Or</p> <p>Voltage measurement outside of controller specific acceptable range during driver on state indicates open circuit failure.</p> <p>Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.</p>	<p>>= 200 KOhms impedance between signal and controller ground</p> <p>>= 200 KOhms impedance between signal and controller ground</p>	Battery Voltage Engine Run Time	<p>>= 11 Volts >= 0 Seconds</p> <p>P062B not FA or TFTK</p>	<p>10.00 failures out of 20.00 samples</p> <p>100 ms /sample Continuous</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit Low	P0222	Detects a continuous or intermittent short low or open in TPS2 circuit by monitoring the TPS 2 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too low. This diagnostic only runs when battery voltage is high enough.	TPS2 % Vref <	0.250 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P06A3	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS2 Circuit High	P0223	Detects a continuous or intermittent short high in TPS2 circuit by monitoring the TPS 2 sensor percent Vref and failing the diagnostic when the TPS percent Vref is too high. This diagnostic only runs when battery voltage is high enough.	TPS2 % Vref >	4.590 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P06A3	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to ground (SIDI)	P0261	Controller specific output driver circuit diagnoses Injector 1 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 Low side circuit shorted to power (SIDI)	P0262	Controller specific output driver circuit diagnoses Injector 1 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to ground (SIDI)	P0264	Controller specific output driver circuit diagnoses Injector 2 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 Low side circuit shorted to power (SIDI)	P0265	Controller specific output driver circuit diagnoses Injector 2 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to ground (SIDI)	P0267	Controller specific output driver circuit diagnoses Injector 3 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 Low side circuit shorted to power (SIDI)	P0268	Controller specific output driver circuit diagnoses Injector 3 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to ground (SIDI)	P0270	Controller specific output driver circuit diagnoses Injector 4 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 Low side circuit shorted to power (SIDI)	P0271	Controller specific output driver circuit diagnoses Injector 4 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 Low side circuit shorted to ground (SIDI)	P0273	Controller specific output driver circuit diagnoses Injector 5 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 Low side circuit shorted to power (SIDI)	P0274	Controller specific output driver circuit diagnoses Injector 5 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Low side circuit shorted to ground (SIDI)	P0276	Controller specific output driver circuit diagnoses Injector 6 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 Low side circuit shorted to power (SIDI)	P0277	Controller specific output driver circuit diagnoses Injector 6 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 Low side circuit shorted to ground (SIDI)	P0279	Controller specific output driver circuit diagnoses Injector 7 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 Low side circuit shorted to power (SIDI)	P0280	Controller specific output driver circuit diagnoses Injector 7 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 Low side circuit shorted to ground (SIDI)	P0282	Controller specific output driver circuit diagnoses Injector 8 low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	<= 1 volt between signal and controller ground	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 Low side circuit shorted to power (SIDI)	P0283	Controller specific output driver circuit diagnoses Injector 8 low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 to 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.				
Random Misfire Detected	P0300	These DTC's will determine if a random or a cylinder specific misfire is occurring by monitoring various terms derived from crankshaft velocity. The rate of misfire over an interval is compared to both emissions and catalyst damaging thresholds. The pattern of crankshaft acceleration after the misfire is checked to differentiate between real misfire and other sources of crank shaft noise.	Crankshaft Deceleration Value(s) vs. Engine Speed and Engine load The equation used to calculate deceleration value is tailored to specific vehicle operating conditions. The selection of the equation used is based on the 1st single cylinder continuous misfire threshold tables encountered that are not max of range. If all tables are max of range at a given speed/load, that speed load region is an Undetectable region see Algorithm Description Document for additional details.		Engine Run Time	> 2 crankshaft revolution	Emission Exceedence = any (5) failed 200 rev blocks out of (16) 200 rev block tests	Type B, 2 Trips (Mil Flashes with Catalyst damage level of Misfire)				
Cylinder 1 Misfire Detected	P0301				Or If ECT at startup Then	Engine Coolant Temp			"ECT" If OBD Max Coolant Achieved = FALSE -9 °C < ECT Or if OBD Max Coolant Achieved = TRUE -9 °C < ECT < 130 °C	Failure reported for (1) Exceedence in 1st (16) 200 rev block tests, or (4) Exceedences thereafter.		
Cylinder 2 Misfire Detected	P0302					Or If ECT at startup Then			< -9 °C If OBD Max Coolant Achieved = FALSE 21 °C < ECT If OBD Max Coolant Achieved = TRUE 21 °C < ECT < 130 °C			
Cylinder 3 Misfire Detected	P0303				Emissions Neutral Default Action: If consumed Emissions Neutral Default DTCs from other subsystems are set: Ignore Rough Road, Traction, Stability, and Antilock brake signals. If default action not activated, Misfire Monitor could complete less frequently or inaccurately. Default Action Latched for duration of Trip	- see details of thresholds on Supporting Tables Tab			System Voltage + Throttle delta - Throttle delta	9.00 < volts < 32.00 < 95.00 % per 25 ms < 95.00 % per 25 ms	OR when Early Termination Reporting = Enabled and engine rev > 1,000 revs and < 3,200 revs at end of trip	
Cylinder 4 Misfire Detected	P0304											SINGLE CYLINDER CONTINUOUS MISFIRE((Medres_Decel Medres_Jerk
Cylinder 5 Misfire Detected	P0305				Default Action: If Misfire P030x sets on some hybrid applications, the isolation damper	OR (Medres_Decel Medres_Jerk			OR (Lores_Decel Lores_Jerk	> SCD_Decel AND > SCD_Jerk	OR (Lores_Decel Lores_Jerk	> RufCyl_Decel AND > RufCyl_Jerk
Cylinder 6 Misfire Detected	P0306											
Cylinder 7 Misfire Detected	P0307				Default Action: If Misfire P030x sets on some hybrid applications, the isolation damper	OR RevBalanceTime				> RevMode_Decel		
Cylinder 8 Misfire Detected	P0308											

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>between engine and transmission can go into extreme resonance. Default action is to move rpm out of the resonance zone. If default action not activated, significant hardware damage could occur rendering vehicle inoperable.</p>	<p>***** **This Feature not used on Gasoline engines**</p> <p>Combustion Modes that force selection of Idle Tables *****</p> <p>Other patterns of misfire use adjustments to the single cylinder continuous misfire threshold tables:</p> <p>RANDOM MISFIRE Use random misfire thresholds If no misfire for</p> <p>(Medres_Decel AND Medres_Jerk)</p> <p>OR (Medres_Decel AND Medres_Jerk)</p> <p>OR (Lores_Decel AND Lores_Jerk)</p>	<p>***** **This Feature not used on Gasoline engines**</p> <p>CombustModelIdleTbl in Supporting Tables *****</p> <p>> 3 Engine Cycles</p> <p>> RufSCD_Decel * Random_SCD_Decel</p> <p>>RufSCD_Jerk * Random_SCD_Jerk</p> <p>> SCD_Decel * Random_SCD_Decel</p> <p>> SCD_Jerk * Random_SCD_Jerk</p> <p>> RufCyl_Decel * RandomCylModDecel</p> <p>> RufCyl_Jerk * RandomCylModJerk</p>			<p>any Catalyst Exceedence = (1) 200 rev block as data supports for catalyst damage.</p> <p>Catalyst Failure reported with (1 or 3) Exceedences in FTP, or (1) Exceedence outside FTP.</p> <p>Continuous</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR (Lores_Decel AND Lores_Jerk) OR RevBalanceTime PAIRED CYLINDER MISFIRE If a cylinder & it's pair are above PAIR thresholds (Medres_Decel AND Medres_Jerk) OR (Medres_Decel AND Medres_Jerk) OR (Lores_Decel AND Lores_Jerk) OR (Lores_Decel AND Lores_Jerk)	> CylModeDecel * RandomCylModDecel > CylModeJerk * RandomCylModJerk > RevMode_Decel * RandomRevModDecel > RufSCD_Decel * Pair_SCD_Decel > RufSCD_Jerk * Pair_SCD_Jerk > SCD_Decel * Pair_SCD_Decel > SCD_Jerk * Pair_SCD_Jerk > RufCyl_Decel * PairCylModeDecel > RufCyl_Jerk * PairCylModeJerk > CylModeDecel * PairCylModeDecel > CylModeJerk * PairCylModeJerk				

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR (Revmode Active AND (within one engine cycle: 2nd largest Lores_Decel) AND Above TRUE for)) BANK MISFIRE Cylinders above Bank Thresholds (Medres_Decel AND Medres_Jerk) OR (Medres_Decel AND Medres_Jerk) OR (Lores_Decel AND Lores_Jerk) OR (Lores_Decel AND Lores_Jerk)	> CylModeDecel * PairCylModeDecel > 50 engine cycles out of 100 engine cycles >= 2 cylinders > RufSCD_Decel * Bank_SCD_Decel > RufSCD_Jerk * Bank_SCD_Jerk > SCD_Decel * Bank_SCD_Decel > SCD_Jerk * Bank_SCD_Jerk > RufCyl_Decel * BankCylModeDecel > RufCyl_Jerk * BankCylModeJerk > CylModeDecel * BankCylModeDecel > CylModeJerk * BankCylModeJerk				

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>CONSECUTIVE CYLINDER MISFIRE 1st cylinder uses single cyl continuous misfire thresholds; 2nd Cylinder uses: (Medres_Decel AND Medres_Jerk)</p> <p>OR (Medres_Decel AND Medres_Jerk)</p> <p>OR (Lores_Decel AND Lores_Jerk)</p> <p>OR (Lores_Decel AND Lores_Jerk)</p>	<p>> RufSCD_Decel * ConsecSCD_Decel</p> <p>> RufSCD_Jerk * ConsecSCD_Jerk</p> <p>> SCD_Decel * ConsecSCD_Decel</p> <p>> SCD_Jerk * ConsecSCD_Jerk</p> <p>> RufCyl_Decel * ConsecCylModDecel</p> <p>> RufCyl_Jerk * ConsecCylModeJerk</p> <p>> CylModeDecel * ConsecCylModDecel</p> <p>> CylModeJerk * ConsecCylModeJerk</p>				

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			CYLINDER DEACTIVATION MODE (Active Fuel Management)					
			AFM: SINGLE CYLINDER CONTINUOUS MISFIRE (CylAfterDeacCyl_Decel AND CylAfterDeacCyl_Jerk)	> CylModeDecel * ClyAfterAFM_Decel > CylModeJerk * CylAfterAFM_Jerk				
			OR (CylBeforeDeacCylDecel AND CylBeforeDeacCyl_Jerk)	> CylModeDecel * CylBeforeAFM_Decel > CylModeJerk * ClyBeforeAFM_Jerk				
			AFM: RANDOM MISFIRE Use random misfire thresholds If no misfire for (CylAfterDeacCyl_Decel AND CylAfterDeacCyl_Jerk)	> 3 Engine Cycles > CylModeDecel * ClyAfterAFM_Decel * RandomAFM_Decl > CylModeJerk * CylAfterAFM_Jerk * RandomAFM_Jerk				
			(CylBeforeDeacCylDecel	> CylModeDecel * CylBeforeAFM_Decel * RandomAFM_Decl				

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>AND CylBeforeDeacCyl_Jerk)</p> <p>OR IF option Crank based IMEP estimate is Enabled and CrankBased_IMEP is</p> <p>Misfire Percent Emission Failure Threshold</p>	<p>> CylModeJerk * ClyBeforeAFM_Jerk * RandomAFM_Jerk</p> <p>Not Enabled</p> <p>< Misfire_IMEP_Thresh _vs_BinID (Note: Thresholds uses following tables to pick threshold vs BinID. See supporting tables for more information on how BinID works to select appropriate calibration threshold) Misfire_IMEP_BinID_ vs_RPM_Load Misfire_IMEP_BinID_ RPM_Axis Misfire_IMEP_BinID_ Load_Axis</p> <p>- see details on Supporting Tables Tab</p> <p>≥ 1.80 % P0300</p>				

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Misfire Percent Catalyst Damage	> Catalyst_Damage_Mi sfire_Percentage in Supporting Tables whenever secondary conditions are met.	(at low speed/loads, one cylinder may not cause cat damage)	> 1,500 rpm AND > 20 % load AND < 180 counts on one cylinder		
			When engine speed and load are less than the FTP calcs (3) catalyst damage exceedences are allowed.	≤ 1,500 FTP rpm AND ≤ 15 FTP % load	Engine Speed Engine Load Misfire counts	350 < rpm < ((Engine Over Speed Limit) - 400) OR 8,191) Engine speed limit is a function of inputs like Gear and temperature see EngineOverSpeedLimit in supporting tables	4 cycle delay	
					No active DTCs:	TPS_FA EnginePowerLimited MAF_SensorTFTKO MAP_SensorTFTKO IAT_SensorTFTKO ECT_Sensor_Ckt_TFTKO 5VoltReferenceB_FA CrankSensor_TFTKO CrankSensor_FA CamLctnlntFA	4 cycle delay	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						CamLctnExhFA CamSensorAnyLctnTFTKO AnyCamPhaser_FA AnyCamPhaser_TFTKO AmbPresDfItDStatus		
					P0315 & engine speed	> 1,000 rpm	4 cycle delay	
					Fuel Level Low	LowFuelConditionDiagnostic	500 cycle delay	
					Cam and Crank Sensors	in sync with each other	4 cycle delay	
					Misfire requests TCC unlock	Not honored because Transmission in hot mode or POPD intrusive diagnostic running	4 cycle delay	
					Fuel System Status	≠ Fuel Cut	4 cycle delay	
					Active FuelManagement	Transition in progress	0 cycle delay	
					Undetectable engine speed and engine load region	Undetectable region from Malfunction Criteria	4 cycle delay	
					Abusive Engine Over Speed	> 8,192 rpm	0 cycle delay	
					Below zero torque (except CARB approved 3000 rpm to redline triangle.)	< ZeroTorqueEngLoad or < ZeroTorqueAFM if AFM is active in Supporting Tables	4 cycle delay	
					Below zero torque: TPS Vehicle Speed	≤ 0.8% (≤ 0.8% in AFM) > 30 mph (> 30 mph AFM)	4 cycle delay	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					NEGATIVE TORQ AFM If deactivated cylinders appear to make power, torque is negative: DeactivatedCyl_Decel AND DeactivatedCyl_Jerk AND # of Deact Cyls Inverted	<DeacCylInversionDecel <DeacCylInversionJerk > 4 cylinders	0 cycle delay 2 Cylinder delay	
					If EGR Valve present and EGR Intrusive test	Not Present is Active	0 cycle delay	
					Manual Trans	Clutch shift	4 cycle delay	
					Accel Pedal Position AND Automatic transmission shift	> 95.00 %	7 cycle delay	
					After Fuel resumes on Automatic shift containing Fuel Cut		2 Cylinder delay	
					Delay if PTO engaged	Enabled	4 cycle delay	
					Delay if error in indices of buffered data is detected and delay is enabled	Delay Enabled	3 cycle delay	
					Delay if IMEP calculation	initializing on startup or running resets (expires before rpm enablement)	4 cycle delay	
					***** **This Feature not used on Gasoline engines**	*****	*****	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Combustion Mode Driver cranks before Wait to Start lamp extinguishes Brake Torque ***** DRIVELINE RING FILTER After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early. Filter Driveline ring: Stop filter early: ABNORMAL ENGINE SPEED OSCILLATION: (checks each "misfire" candidate in 100 engine Cycle test to see if it looks like some disturbance like rough road (abnormal).) Used Off Idle, and while not shifting, TPS Engine Speed Veh Speed Auto Transmission	= InfrequentRegen value in Supporting Tables IF TRUE > 199.99 % Max Torque ***** > " Ring Filter " # of engine cycles after misfire in Supporting Tables > " Number of Normals " # of engine cycles after misfire in Supporting Tables tab > 3 % > 950 rpm > 3 mph not shifting	0 cycle delay WaitToStart cycle delay 0 cycle delay *****	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>individual candidate deemed abnormal if number of consecutive decelerating cylinders after "misfire": (Number of decels can vary with misfire detection equation) Consecutive decels while in SCD Mode Cyl Mode Rev Mode</p> <p>At the end of 100 engine cycle test, the ratio of abnormal/candidate is checked to confirm if real misfire is present within the 100 engine cycles.</p> <p>abnormal candidates/ total candidates</p> <p>MISFIRE CRANKSHAFT PATTERN RECOGNITION checks each "misfire" candidate in 100 engine Cycle test to see if overall crankshaft pattern looks like real misfire (recognized), or some disturbance like rough road (unrecognized). At the end of 100 engine cycle test, the ratio of</p>	<p>> Abnormal SCD Mode > Abnormal Cyl Mode > Abnormal Rev Mode in Supporting Tables</p> <p>> 0.50 ratio</p>	<p>discard 100 engine cycle test</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>unrecog/recognized is checked to confirm if real misfire is present within the 100 engine cycles. Typically used for checking a single misfire per engine cycle but can support some other patterns on some packages</p> <p>Pattern Recog Enabled:</p> <p>Pattern Recog Enabled during Cylinder Deac</p> <p>Pattern Recog Enabled consecutive cyl patrn</p> <p>Engine Speed Veh Speed</p> <p>The 1st check for "recognized" is the 1st fired cylinder after the misfire candidate should both accelerate and jerk an amount based acceleration and jerk of Single Cylinder Misfire thresholds in effect at that speed and load.</p> <p>(CylAfter_Accel AND CylAfter_Jerk)</p>	<p>Enabled</p> <p>Not Enabled</p> <p>Enabled</p> <p>1,000 < rpm < 3,000 > 5.0 mph</p> <p>> Misfire_decel * 1st_FireAftrMisfr_Acel</p> <p>> Misfire_Jerk * 1st_FireAftrMisfr_Jerk</p> <p>Or if AFM mode is active: > Misfire_decel * 1stFireAftrMisAcelAFM > Misfire_Jerk *</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Additionally, the crankshaft is checked again a small calibratable number of cylinders later to see if the disturbance is still large like rough road, or has calmed down like real misfire. The size of disturbance is compared to a multiplier times the ddt_jerk value used to detect misfire at that speed and load. If there is repetitive misfire on consecutive engine cycles, the expected snap is adjusted due to the higher expected disturbance.</p> <p>Num of Cylinders after misfire to start check of crankshaft snap</p> <p>"misfire" recognized if: Crankshaft snap after: isolated "misfire"</p> <p>repetative "misfire"</p> <p>At the end of 100 engine cycle test, the ratio of unrecog/recognized is checked to confirm if real misfire is present.</p>	<p>1stFireAfterMisJerkAFM</p> <p>3 Cylinders</p> <p>< Misfire_Jerk * SnapDecayAfterMisfire</p> <p>< Misfire_Jerk * SnapDecayAfterMisfire * RepetSnapDecayAdjst in Supporting Tables</p>	<p>discard 100</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Ratio of Unrecog/Recog	> 0.60	engine cycle test	
					***** NON-CRANKSHAFT BASED ROUGH ROAD: Rough Road Source *****	***** Disabled CeRRDR_e_None *****	*****	
					IF Rough Road Source = WheelSpeedInECM (Wheel speed noise OR ABS = OR Traction = OR Vehicle Stability) =	> WSSRoughRoadThres active active active	discard 100 engine cycle test	
					AND No Emission Neutral Default Action DTCs	ABS Failed Vehicle Dynamics Control System Status Driven Wheel Rotation Status Non Driven Wheel Rotation Status		
					***** IF Rough Road Source = "FromABS" (RoughRoad = OR ABS = OR Traction = OR Vehicle Stability) =	***** detected active active active	***** discard 100 engine cycle test	
					AND No Emission Neutral Default Action DTCs	ABS Failed Vehicle Dynamics Control System Status		
					***** IF Rough Road Source	***** > TOSSRoughRoadThres	***** discard 100	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					= "TOSS" TOSS dispersion AND No Active DTCs ***** Default Action Isolator Resonance Default Action Option ***** If Isolator Resonance Option Enabled AND Misfire P030x TFTKO	in supporting tables Transmission Output Shaft Angular Velocity Validity TransmissionEngagedStat e_FA (Auto Trans only) ClutchPstnSnsr FA (Manual Trans only) ***** Not Enabled ***** Set engine speed limits: 0 < Eng RPM < 9,000	engine cycle test 4 cycle delay ***** *****	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position System Variation Not Learned	P0315	This DTC determines if the crankshaft sensor learn values that are stored in memory are valid. The angle between each tooth of the reluctor wheel is learned, and the sum of all angles together should sum to 360° (one revolution of the reluctor wheel). Default values, or corrupted values will not sum to 360°.	The Crankshaft target wheel should be 360 degrees around in circumference. Loss or controller non-volatile memory or an error in memory will cause the values of individual teeth learn to be defaulted or incorrect. Set the DTC if the Difference between the sum of the reluctor wheel's teeth and 360 degrees is greater than:	> 0.001 degrees	OBD Manufacturer Enable Counter	MEC = 0	0.50 seconds Frequency Continuous100 msec	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Performance Per Cylinder	P0324	This diagnostic checks for knock sensor performance out of the normal expected range on a per cylinder basis due to Excessive Knock (either real or false knock).	Common Enable Criteria Excessive Knock Diag: Filtered Knock Intensity (where 'Knock Intensity' = 0 with no knock; and > 0 & proportional to knock magnitude with knock)	> P0324_PerCyl_ExcessiveKnock_Threshold (no units)	Diagnostic Enabled? Engine Run Time Engine Speed Engine Air Flow (Engine Coolant Temperature OR OBD Coolant Enable Criteria Inlet Air Temperature Cumulative Number of Engine Revs Above Min Eng Speed (per key cycle)	Yes ≥ 2.0 seconds ≥ 400 RPM AND ≤ 8,500 RPM ≥ 200 mg/cylinder AND ≤ 2,000 mg/cylinder ≥ -40 deg's C = TRUE) ≥ -40 deg's C ≥ 42 Revs	First Order Lag Filters with Weight Coefficient = 0.0234 Updated each engine event	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 1	P0325	<p>This diagnostic checks for an open in the knock sensor circuit.</p> <p>There are two possible methods used:</p> <ol style="list-style-type: none"> 20 kHz Normal Noise <p>See Supporting Tables for method definition: P0325_P0330_OpenMethod</p> <p>Typical implementations:</p> <ol style="list-style-type: none"> Use 20 kHz method at all RPM (used when acceptable separation achieved at all RPM) or Use 20 kHz method at low/medium RPM and Normal Noise at high RPM 	<p>Open Circuit Method chosen (2 possible methods: 20 kHz or Normal Noise):</p> <p>Thresholds for OpenMethod = 20 kHz</p> <p>Filtered FFT Output</p> <p>Thresholds for OpenMethod = NormalNoise:</p> <p>Filtered FFT Output</p>	<p>Supporting Table: P0325_P0330_OpenMethod_2</p> <p>(see Supporting Tables)</p> <p>> P0325_P0330_OpenCktThrshMin (20 kHz) AND < P0325_P0330_OpenCktThrshMax (20 kHz)</p> <p>> P0325_P0330_OpenCktThrshMin (Normal Noise) AND < P0325_P0330_OpenCktThrshMax (Normal Noise)</p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)</p> <p>Engine Air Flow</p> <p>(Engine Coolant Temperature</p> <p>OR OBD Coolant Enable Criteria</p> <p>Inlet Air Temperature</p>	<p>Yes</p> <p>≥ 2.0 seconds</p> <p>≥ 400 RPM and ≤ 8,500 RPM</p> <p>≥ 100 revs</p> <p>≥ 50 mg/cylinder and ≤ 2,000 mg/cylinder</p> <p>≥ -40 deg's C</p> <p>= TRUE)</p> <p>≥ -40 deg's C</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p>Weight Coefficient = 0.0100</p> <p>Updated each engine event</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 1	P0327	This diagnostic checks for an out of range low knock sensor signal	Sensor Input or Return Signal Line	< 8.0 Percent (of 5 V reference)	Diagnostic Enabled? Engine Speed	Yes > 400 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 1	P0328	This diagnostic checks for an out of range high knock sensor signal	Sensor Input or Return Signal Line	> 39.0 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 400 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Bank 2	P0330	<p>This diagnostic checks for an open in the knock sensor circuit</p> <p>There are two possible methods used:</p> <ol style="list-style-type: none"> 20 kHz Normal Noise <p>See Supporting Tables for method definition: P0325_P0330_OpenMethod</p> <p>Typical implementations:</p> <ol style="list-style-type: none"> Use 20 kHz method at all RPM (used when acceptable separation achieved at all RPM) or Use 20 kHz method at low/medium RPM and Normal Noise at high RPM 	<p>Open Circuit Method chosen (2 possible methods: 20 kHz or Normal Noise):</p> <p>Thresholds for OpenMethod = 20 kHz</p> <p>Filtered FFT Output</p> <p>Thresholds for OpenMethod = NormalNoise:</p> <p>Filtered FFT Output</p>	<p>Supporting Table: P0325_P0330_OpenMethod_2</p> <p>(See Supporting Tables)</p> <p>> P0325_P0330_OpenCktThrshMin (20 kHz) AND < P0325_P0330_OpenCktThrshMax (20 kHz)</p> <p>> P0325_P0330_OpenCktThrshMin (Normal Noise) AND < P0325_P0330_OpenCktThrshMax (Normal Noise)</p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)</p> <p>Engine Air Flow</p> <p>(Engine Coolant Temperature</p> <p>OR OBD Coolant Enable Criteria</p> <p>Inlet Air Temperature</p>	<p>Yes</p> <p>≥ 2.0 seconds</p> <p>≥ 400 RPM and ≤ 8,500 RPM</p> <p>≥ 100 revs</p> <p>≥ 50 mg/cylinder and ≤ 2,000 mg/cylinder</p> <p>≥ -40 deg's C</p> <p>= TRUE)</p> <p>≥ -40 deg's C</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p>Weight Coefficient = 0.0100</p> <p>Updated each engine event</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit Low Bank 2	P0332	This diagnostic checks for an out of range low knock sensor signal	Sensor Input or Return Signal Line	< 8.0 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 400 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Knock Sensor (KS) Circuit High Bank 2	P0333	This diagnostic checks for an out of range high knock sensor signal	Sensor Input or Return Signal Line	> 39.00 Percent (of 5 Volt Reference)	Diagnostic Enabled? Engine Speed	Yes > 400 RPM and < 8,500 RPM	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Circuit	P0335	Diagnostic will fail if a crank sensor pulse was not received during a period of time; if crank sensor pulses are received the diagnostic will pass.	Time since last crankshaft position sensor pulse received	>= 4.0 seconds	Starter engaged AND (cam pulses being received OR (MAF_SensorFA AND Engine Air Flow	Test is Enabled = FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			No crankshaft pulses received	>= 0.3 seconds	Engine is Running Starter is not engaged	Test is Enabled	Continuous every 12.5 msec	
			No crankshaft pulses received		Engine is Running OR Starter is engaged No DTC Active:	Test is Enabled P0340 P0341	2 failures out of 10 samples One sample per engine revolution	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Crankshaft Position (CKP) Sensor A Performance	P0336	1. Fail counts will occur if the engine goes out of synchronization repeatedly over a period of time and will pass if the engine stays in synchronization. 2. Diagnostic will fail if synchronization gap is not found in a specified period of time and will pass if the synchronization gap is found. 3. Diagnostic will fail if the incorrect number of crank sensor teeth are detected in-between detecting the synchronization gap and will pass if the correct number of teeth are seen.	Time in which 10 or more crank re-synchronizations occur	< 10.0 seconds	Engine Air Flow Cam-based engine speed No DTC Active:	Test is Enabled >= 3.0 grams/second > 450 RPM P0335	Continuous every 250 msec	Type B, 2 Trips
			No crankshaft synchronization gap found	>= 0.4 seconds	Engine is Running Starter is not engaged	Test is Enabled	Continuous every 12.5 msec	
			Time since starter engaged without detecting crankshaft synchronization gap	>= 3.3 seconds	Starter engaged AND (cam pulses being received OR (MAF_SensorFA AND Engine Air Flow = FALSE > 3.0 grams/second))	Test is Enabled	Continuous every 100 msec	
			Crank pulses received in one engine revolution OR Crank pulses received in one engine revolution	< 1 pulses > 65,535 pulses	Engine is Running OR Starter is engaged No DTC Active:	Test is Enabled P0340 P0341	8 failures out of 10 samples One sample per engine revolution	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Circuit Bank 1 Sensor A	P0340	Diagnostic will fail if a cam sensor pulse was not received during a period of time; if cam sensor pulses are received the diagnostic will pass.	Time since last camshaft position sensor pulse received	>= 5.5 seconds	Starter engaged AND (crank pulses being received OR (MAF_SensorFA AND Engine Air Flow	Test is Enabled = FALSE > 3.0 grams/second))	Continuous every 100 msec	Type B, 2 Trips
			OR Time that starter has been engaged without a camshaft sensor pulse	>= 4.0 seconds				
			Fewer than 4 camshaft pulses received in a time	> 3.0 seconds	Engine is running Starter is not engaged	Test is Enabled	Continuous every 100 msec	
			No camshaft pulses received during 24 MEDRES events (There are 24 MEDRES events per engine cycle) Test begins when MEDRES region AND accumulated number of MEDRES events	= region 5 >= 0 counts	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged No DTC Active:	Test is Enabled CrankSensor_FA	Continuous, every MEDRES event until test completes, one test at every start attempt	
The number of camshaft pulses received during 100 engine cycles	= 0 pulses	Crankshaft is synchronized No DTC Active:	Test is Enabled CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle				

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Camshaft Position (CMP) Sensor Performance Bank 1 Sensor A	P0341	Diagnostic will fail if an incorrect number of cam sensor pulses are detected over a number of engine cycles and will pass if the number of cam pulses is correct.	The number of camshaft pulses received during 24 MEDRES events is OR (There are 24 MEDRES events per engine cycle)	< 4 pulses > 8 pulses	Crankshaft is synchronized Starter must be engaged to enable the diagnostic, but the diagnostic will not disable when the starter is disengaged	Test is Enabled CrankSensor_FA	Continuous, every MEDRES event until test completes, one test at every start attempt	Type B, 2 Trips
			Test begins when MEDRES region AND accumulated number of MEDRES events	= region 5 >= 0 counts	No DTC Active:			
			The number of camshaft pulses received during 100 engine cycles OR	< 398 pulses > 402 pulses	Crankshaft is synchronized No DTC Active:	Test is Enabled CrankSensor_FA	8 failures out of 10 samples Continuous every engine cycle	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT	P0351	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	≥ 30 k Ω impedance between signal and controller ground	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT	P0352	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	≥ 30 k Ω impedance between signal and controller ground	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT	P0353	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT	P0354	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #5 CIRCUIT	P0355	Diagnoses Cylinder #5 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #6 CIRCUIT	P0356	Diagnoses Cylinder #6 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #7 CIRCUIT	P0357	Diagnoses Cylinder #7 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	$\geq 30 \text{ k}\Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #8 CIRCUIT	P0358	Diagnoses Cylinder #8 Ignition Control (EST) output driver circuit for an Open Circuit fault.	High impedance during driver high state (indicates open circuit)	≥ 30 k Ω impedance between signal and controller ground	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 1	P0420	<p>NOTE: The information below applies to applications that use the Decel Catalyst Monitor Algorithm</p> <p>Oxygen Storage. The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (i.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (i.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Rich (intrusive rich) and Lean (decel fuel cutoff) A/F excursions</p> <p>Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration</p>	Normalized Ratio OSC Value (EWMA filtered)	< 0.35	<p>All enable criteria associated with P0420 can be found under P2270 - (O2 Sensor Signal Stuck Lean Bank 1 Sensor 2)</p> <p>Rapid Step Response (RSR) feature will initiate multiple tests:</p> <p>If the difference between current EWMA value and the current OSC Normalized Ratio value is</p> <p>and the current OSC Normalized Ratio value is</p> <p>Maximum number of RSR tests to detect failure when RSR is enabled.</p> <p>MAF</p> <p>Predicted catalyst temperature</p> <p>Front O2 Sensor or Front WRAF</p> <p>Rear O2 Sensor</p> <p>General Enable Criteria</p> <p>In addition to the p-codes listed under P2270, the following DTC's shall also</p>	<p>> 0.42</p> <p>< 0.10</p> <p>9</p> <p>> 3.00 g/s < 20.00 g/s</p> <p>< 950 ° C</p> <p>> 700.00 mV or > 1.25 EQR</p> <p>> 825.00 mV</p>	<p>1 test attempted per valid decel period</p> <p>Minimum of 1 test per trip</p> <p>Maximum of 3 tests per trip</p> <p>Frequency: Fueling Related : 12.5 ms</p> <p>OSC Measurements: 100 ms</p> <p>Temp Prediction: 12.5ms</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow)</p> <p>Normalized Ratio Calculation = (1-2) / (3-2)</p> <p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part.</p> <p>Refer to the P0420_WorstPassingOSCTableB1 and P0420_BestFailingOSCTableB1 in Supporting Tables tab for details</p> <p>The Catalyst Monitoring Test is completed during a decel fuel cutoff event. This fuel cutoff event occurs following a rich intrusive fueling event initiated by the O2 Sensor Signal Stuck Lean Bank 1 Sensor 2 test (P2270). Several conditions must be met in order to execute this test.</p> <p>Additional conditions and their related values</p>			<p>not be set:</p> <p>For switching O2 sensors:</p> <p>For WRAF O2 sensors:</p>	<p>O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA</p> <p>WRAF_Bank_1_FA WRAF_Bank_2_FA</p> <p>P0420_WorstPassingOSCTableB1</p> <p>P0420_BestFailingOSCTableB1</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		are listed in the "Secondary Parameters" and "Enable Conditions" section of this document for P2270 (O2 Sensor Signal Stuck Lean Bank 1 Sensor 2)						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Catalyst System Low Efficiency Bank 2	P0430	<p>Note: The information below applies to applications that use the Decel Catalyst Monitor Algorithm</p> <p>Oxygen Storage. The catalyst washcoat contains Cerium Oxide. Cerium Oxide reacts with NO and O2 during lean A/F excursions to store the excess oxygen (i.e. Cerium Oxidation). During rich A/F excursions, Cerium Oxide reacts with CO and H2 to release this stored oxygen (i.e. Cerium Reduction). This is referred to as the Oxygen Storage Capacity, or OSC. CatMon's strategy is to "measure" the OSC of the catalyst through forced Rich (intrusive rich) and Lean (decel fuel cutoff) A/F excursions</p> <p>Normalized Ratio OSC Value Calculation Information and Definitions = 1. Raw OSC Calculation = (post cat O2 Resp time - pre cat O2 Resp time) 2. BestFailing OSC value from a calibration</p>	Normalized Ratio OSC Value (EWMA filtered)	< 0.35	<p>All enable criteria associated with P0430 can be found under P2272 - (O2 Sensor Signal Stuck Lean Bank 2 Sensor 2)</p> <p>Rapid Step Response (RSR) feature will initiate multiple tests:</p> <p>If the difference between current EWMA value and the current OSC Normalized Ratio value is</p> <p>and the current OSC Normalized Ratio value is</p> <p>Maximum number of RSR tests to detect failure when RSR is enabled.</p> <p>MAF</p> <p>Predicted catalyst temperature</p> <p>Front O2 Sensor or Front WRAF</p> <p>Rear O2 Sensor</p> <p>General Enable Criteria</p> <p>In addition to the p-codes listed under P2272, the following DTC's shall also</p>	<p>> 0.42</p> <p>< 0.10</p> <p>9</p> <p>> 3.00 g/s < 20.00 g/s</p> <p>< 950 ° C</p> <p>> 700.00 mV or > 1.25 EQR</p> <p>> 825.00 mV</p>	<p>1 test attempted per valid decel period</p> <p>Minimum of 1 test per trip</p> <p>Maximum of 3 tests per trip</p> <p>Frequency: Fueling Related : 12.5 ms</p> <p>OSC Measurements: 100 ms</p> <p>Temp Prediction: 12.5ms</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>table (based on temp and exhaust gas flow) 3. WorstPassing OSC value (based on temp and exhaust gas flow)</p> <p>Normalized Ratio Calculation = (1-2) / (3-2)</p> <p>A Normalized Ratio of 1 essentially represents a good part and a ratio of 0 essentially represents a very bad part.</p> <p>Refer to the P0430_WorstPassingOSCTableB2 and P0430_BestFailingOSCTableB2 in Supporting Tables tab for details</p> <p>The Catalyst Monitoring Test is completed during a decel fuel cutoff event. This fuel cutoff event occurs following a rich intrusive fueling event initiated by the O2 Sensor Signal Stuck Lean Bank 2 Sensor 2 test (P2272). Several conditions must be met in order to execute this test.</p> <p>Additional conditions and their related values</p>			<p>not be set:</p> <p>For switching O2 sensors:</p> <p>For WRAF O2 sensors:</p>	<p>O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA</p> <p>WRAF_Bank_1_FA WRAF_Bank_2_FA</p> <p>P0430_WorstPassingOSCTableB2</p> <p>P0430_BestFailingOSCTableB2</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		are listed in the "Secondary Parameters" and "Enable Conditions" section of this document for P2272 (O2 Sensor Signal Stuck Lean Bank 2 Sensor 2)						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>the pressure drops (-62) Pa from peak pressure, the vent is then opened for 60 seconds to normalize the system pressure. The vent is again closed to begin the vacuum portion of the test (phase-2). As the fuel temperature continues to fall, a vacuum will begin forming. The vacuum will continue until it reaches a vacuum peak. When the pressure rises 62 Pa from vacuum peak, the test then completes. If the key is turned on while the diagnostic test is in progress, the test will abort.</p>			<p>Valid *****</p> <p>1. Startup OAT is less than previous trip EAT</p> <p>OR</p> <p>2. Startup ECT - previous trip EAT</p> <p>OR</p> <p>3. Engine off time</p> <p>OR</p> <p>4. At startup, time since previous EAT valid and able to learn</p> <p>OR</p> <p>5. EAT - current OAT</p> <p>OR</p> <p>6. EAT < current OAT and speed timer and current OAT - EAT</p> <p>Speed timer increments at 100 msec rate and increments vary based on vehicle speed as follows:</p> <p>vehicle speed < 10 mph - 0.2 seconds 10 mph < speed < 35 mph 0.10 seconds 35 mph < speed < 124 0.33 seconds 124 mph < speed < 124 0.33 seconds</p> <p>Speed timer can never be less than 0 seconds</p> <p>*****</p> <p>1. High Fuel Volatility</p> <p>During the volatility</p>	<p>*****</p> <p>≤ 0 °C</p> <p>≥ 3,600 seconds</p> <p>≤ 3,600 seconds</p> <p>0 °C ≤ difference ≤ 2 °C</p> <p>≥ 240 seconds</p> <p>≤ 2 °C</p> <p>*****</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>phase, pressure in the fuel tank is integrated vs. volatility time. If the integrated pressure is then test aborts and unsuccessful attempts is incremented. This value equates to an average integrated fuel tank pressure > 1,245 Pa. Please see P0442 Volatility Time as a Function of Estimate of Ambient Temperature in Supporting Tables.</p> <p>OR</p> <p>2. Vacuum Refueling Detected</p> <p>See P0454 Fault Code for information on vacuum refueling algorithm.</p> <p>OR</p> <p>3. Fuel Level Refueling Detected</p> <p>See P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>4. Vacuum Out of Range and No Refueling</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p>	<p>< -5</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>OR</p> <p>5. Vacuum Out of Range and Refueling Detected</p> <p>See P0451 Fault Code for information on vacuum sensor out of range and P0464 Fault Code for information on fuel level refueling.</p> <p>OR</p> <p>6. Vent Valve Override Failed</p> <p>Device control using an off-board tool to control the vent solenoid, cannot exceed during the EONV test</p> <p>OR</p> <p>7. Key up during EONV test</p> <p>No active DTCs:</p> <p>No Active DTC's TFTKO</p>	<p>0.50 seconds</p> <p>MAF_SensorFA ECT_Sensor_FA IAT_SensorFA VehicleSpeedSensor_FA IgnitionOffTimeValid AmbientAirDefault FuelLevelDataFault</p> <p>P0443 P0446 P0449 P0452 P0453 P0455 P0458 P0459</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						P0498 P0499 P0496 P1001 P1005 P11FF P130F U18A2		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Circuit (ODM) (No ELCP - Conventional EVAP Diagnostic)	P0443	Controller specific output driver circuit diagnoses the canister purge solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground.	Powertrain relay voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0458 may also set (Caniste r Purge Solenoid Short to Ground)

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent System Performance (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0446	This DTC will determine if a restriction is present in the vent solenoid, vent filler, vent hose or EVAP canister. This diagnostic runs with normal purge control and canister vent solenoid commanded open. The diagnostic fails when the FTP sensor vacuum measurement is above a vacuum threshold before it accumulates purge volume above a threshold. The diagnostic passes when it accumulates purge volume above a threshold before the FTP sensor vacuum measurement is above a vacuum threshold.	Vent Restriction Prep Test: Vented Vacuum for OR Vented Vacuum for Vent Restriction Test: Tank Vacuum for before Purge Volume After setting the DTC for the first time, 0 liters of fuel must be consumed before setting the DTC for the second time.	< -623 Pa 90 seconds > 1,245 Pa 90 seconds > 2,989 Pa 5 seconds ≥ 30 liters	Fuel Level System Voltage Startup IAT Startup ECT BARO No active DTCs: No Active DTC's TFTKO	10 % ≤ Percent ≤ 90 % ≥ 10.0 volts 4 °C ≤ Temperature ≤ 35 °C ≤ 35 °C ≥ 70 kPa MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited P0443 P0449 P0452 P0453 P0454 P0458 P0459 P0498 P0499 P1001 P1005 P11FF P130F U18A2	Once per Cold Start Time is dependent on driving conditions Maximum time before test abort is 1,400 seconds	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) Vent Solenoid Control Circuit (ODM) (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0449	Controller specific output driver circuit diagnoses the vent solenoid low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	≥ 200 K Ω impedance between output and controller ground	No active DTCs:	P1005 P130F U18A2	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0498 may also set (Vent Solenoid Short to Ground)

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Performance (No ELCP - Conventional EVAP Diagnostic)	P0451	<p>The DTC will be set if the fuel tank vacuum sensor is out of range when it tries to re-zero prior to the phase-1 or phase-2 portions of the engine-off natural vacuum small leak test.</p> <p>During the EONV test, the fuel tank vacuum sensor is re-zeroed. A re-zero occurs: 1) At the transition from the volatility phase to the pressure phase. 2) At the transition from the pressure phase to the vacuum phase.</p> <p>The re-zero test determines if the tank vacuum signal falls within a calibratable window about atmospheric pressure. If after some time, the tank vacuum signal does not fall to within the window, the re-zero test exits to the refueling rationality test.</p> <p>The refueling rationality test determines if a refueling event caused the re-zero problem. If so, the re-zero problem is ignored. If a refueling event is not</p>	<p>The tank vacuum sensor voltage is compared to a window about the nominal sensor voltage offset (~1.5 volts)</p> <p>Upper voltage threshold (voltage addition above the nominal voltage)</p> <p>Lower voltage threshold (voltage subtraction below the nominal voltage)</p> <p>The difference between tank vacuum sensor voltage and the nominal offset voltage is then normalized against the appropriate threshold listed above to produce a ratio between 0.0 and 1.0. This normalized re-zero ratio is then filtered with a EWMA (with 0= perfect pass and 1=perfect fail).</p> <p>When EWMA is the DTC light is illuminated.</p> <p>The DTC light can be turned off if the EWMA is and stays below the EWMA fail threshold for 3 additional consecutive trips.</p>	<p>0.2 volts</p> <p>0.2 volts</p> <p>> 0.73 (EWMA Fail Threshold),</p> <p>≤ 0.40 (EWMA Re-Pass Threshold)</p>	<p>This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes</p>		<p>This test is executed during an engine-off natural vacuum small leak test. The number of times that it executes can range from zero to two per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete.</p>	<p>Type A, 1 Trips</p> <p>EWMA</p> <p>Average run length: 6</p> <p>Run length is 2 trips after code clear or non-volatile reset</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>detected, then the results of the re-zero test are used to determine if there is a re-zero problem.</p> <p>1) An individual re-zero test generates a re-zero ratio. The ratio goes from 0.0 to 1.0.</p> <p>2) A 0.0 means that the re-zero pressure signal achieved exactly atmospheric pressure.</p> <p>3) A ratio of 1.0 means that the re-zero pressure did not get within the window.</p> <p>4) Re-zero pressure within the window generates values between 0.0 and 1.0.</p> <p>If a refueling event is not detected, then the resulting re-zero ratio is filtered using an exponentially weighted moving average (EWMA). When the EWMA exceeds a fail threshold, the vacuum re-zero test reports a failure. Once the vacuum re-zero test fails, the EWMA fall below a lower re-pass threshold before it can pass the vacuum re-zero test again.</p>						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Low Voltage (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0452	<p>This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too low out of range.</p> <p>The FTP sensor circuit out of range diagnostic compares the raw sensor voltage to a lower voltage threshold. It is an X out of Y diagnostic that runs continuously anytime the controller is awake.</p> <p>If the sensor voltage is below the lower voltage threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported for P0452 DTC. A pass is reported for P0452 DTC if the low sample counter reaches its threshold.</p>	<p>FTP sensor signal</p> <p>The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~3736 Pa).</p>	< 0.15 volts (3.0 % of Vref or ~ 1,495 Pa)	No active DTC's:	P1001 P1005 U18A2	<p>640 failures out of 800 samples</p> <p>12.5 ms / sample</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit High Voltage (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0453	<p>This DTC will detect a Fuel Tank Pressure (FTP) sensor signal that is too high out of range.</p> <p>The FTP sensor circuit out of range diagnostic compares the raw sensor voltage to an upper voltage threshold. It is an X out of Y diagnostic that runs continuously anytime the controller is awake.</p> <p>If the sensor voltage is above the upper voltage threshold, the high fail counter then increments. If the high fail counter reaches its threshold then a fail is reported for P0453 DTC. A pass is reported for P0453 DTC if the high sample counter reaches its threshold.</p>	<p>FTP sensor signal</p> <p>The normal operating range of the FTP sensor is 0.5 volts (~1245 Pa) to 4.5 volts (~3736 Pa).</p>	> 4.85 volts (97.0 % of Vref or ~ -3,985 Pa)	No active DTCs:	P1001 P1005 U18A2	<p>640 failures out of 800 samples</p> <p>12.5 ms / sample</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Pressure (FTP) Sensor Circuit Intermittent (No ELCP - Conventional EVAP Diagnostic)	P0454	<p>This DTC will detect intermittent tank vacuum sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.</p> <p>During the EONV test, an abrupt change in fuel tank vacuum is identified as a possible refueling event. If the abrupt change occurs while the vent valve is closed, the EONV small-leak test aborts and the refueling rationality test starts.</p> <p>If the refueling rationality test detects a refueling event, then the vacuum change is considered "rational." If the refueling rationality test does not detect a refueling event, then the vacuum change is considered "irrational."</p> <p>The vacuum change rationality diagnostic is an "X out of Y" test. 1) Each time the EONV test completes, the (Y) sample counter is incremented. 2) Each time the</p>	<p>If an abrupt change in tank vacuum is detected the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that a refueling event occurred. If a refueling is confirmed, then the test sample is considered passing. Otherwise, the sample is considered failing indicating an intermittent signal problem. An abrupt change is defined as a change in vacuum in the span of 1.0 seconds. But in 12.5 msec. A refueling event is confirmed if the fuel level has a persistent change of for 30 seconds during a 600 second refueling rationality test.</p>	<p>> 112 Pa < 249 Pa > 15 %</p>	<p>This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes and the canister vent solenoid is closed</p>		<p>This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.</p> <p>12.5 ms / sample</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		rationality test has an irrational result; the (X) fail counter is incremented. 3) If the (X) fail counter reaches the fail limit before the (Y) sample counter reaches the sample limit, the vacuum change rationality test fails. 4) If the (Y) sample counter reaches the limit before the (X) fail counter fails, the vacuum change rationality test passes.						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>P0455 occurred after a refueling event was detected and the MIL is off for P0455, the MIL will be commanded off after the first pass of P0455 is reported. If the first failure of P0455 did not occur after a refueling event was detected, the MIL will be commanded off on the ignition cycle after the third consecutive pass of P0455 is reported.the MIL will be commanded off on the ignition cycle after the third consecutive pass of P0455 is reported.</p> <p>On fuel systems without fuel caps</p> <p>The P0455 MIL will be commanded off on the ignition cycle after the third consecutive pass of P0455 is reported.</p>						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Purge Control Valve Circuit Low (No ELCP - Conventional EVAP Diagnostic)	P0458	Controller specific output driver circuit diagnoses the canister purge solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	$\leq 0.5 \Omega$ impedance between output and controller ground	Powertrain relay voltage	Voltage ≥ 11.0 volts	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0443 may also set (Caniste r Purge Solenoid Open Circuit)

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Fuel consumed without a Primary Fuel Level Change ***** 3a) If indicated fuel volume change is 3b) while fuel consumed by the engine is	3a) < 3 liters 3b) ≥ 22.2 liters				

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Low Voltage	P0462	This DTC will detect a primary fuel tank sensor out-of-range low.	Fuel level Sender % of 5V range	< 10 % or 83.09 liters	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit High Voltage	P0463	This DTC will detect a primary fuel tank level sensor out-of-range high.	Fuel level Sender % of 5V range	> 60 % or 4.45 liters	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Circuit Intermittent (No ELCP - Conventional EVAP Diagnostic)	P0464	<p>This DTC will detect intermittent fuel level sensor signals that would have caused the engine-off natural vacuum small leak test to abort due to an apparent re-fueling event.</p> <p>During the EONV test, a change in fuel level is identified as a possible refueling event. If the change occurs while the vent valve is closed, the EONV small-leak test aborts and the refueling rationality test starts.</p> <p>If the refueling rationality test detects a refueling event, the fuel level change is considered "rational." If the refueling rationality test does not detect refueling, the fuel level change is considered "irrational."</p> <p>The fuel level change rationality diagnostic is an "X out of Y" test. 1) Each time the EONV test completes, the (Y) sample counter is incremented. 2) Each time the rationality test has an</p>	<p>If a change in fuel level is detected, the engine-off natural vacuum test is aborted due to an apparent refueling event. Subsequent to the abort, a refueling rationality test is executed to confirm that an actual refueling event occurred. If a refueling event is confirmed, then the test sample is considered passing. Otherwise, if a refueling event is not confirmed, then the test sample is considered failing which indicates an intermittent signal problem.</p> <p>An intermittent fuel level signal problem is defined as: The fuel level changes by and does not remain for 30 seconds during a 600 second refueling rationality test.</p>	<p>> 15 % > 15 %</p>	<p>This test will execute whenever the engine-off natural vacuum small leak test (P0442) executes</p>		<p>This test is executed during an engine-off natural vacuum small leak test. The test can only execute up to once per engine-off period. The length of the test is determined by the refueling rationality test, which can take up to 600 seconds to complete. The test will report a failure if 2 out of 3 samples are failures.</p> <p>100 ms / sample</p>	<p>Type A, 1 Trips</p>

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		irrational result; the (X) fail counter is incremented. 3) If the (X) fail counter reaches the fail limit before the (Y) sample counter reaches the sample limit, the fuel level change rationality test fails. 4) If the (Y) sample counter reaches the limit before the (X) fail counter fails, the fuel level change rationality test passes.						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission (EVAP) System Flow During Non- Purge (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0496	<p>This DTC will determine if the purge solenoid is leaking to engine manifold vacuum.</p> <p>This test checks for purge valve leaks to intake manifold vacuum such that there would always be a small amount of purge flow present. It does this by sealing the EVAP system (purge and vent valve closed) and then monitors fuel tank vacuum level. The fuel tank vacuum level should not increase. If tank vacuum increases above a threshold, a malfunction is indicated.</p> <p>Additional Information</p> <p>This diagnostic test detects purge valve leaks to intake manifold vacuum. It is not intended to detect purge valve leaks to the atmosphere which are monitored by the EONV small leak diagnostic (P0442).</p> <p>The purge valve leak diagnostic exists to help service replace</p>	<p>Tank Vacuum for</p> <p>Test time</p>	<p>> 2,491 Pa 5 seconds</p> <p>≤ refer to P0496 Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level in Supporting Tables.</p> <p>Test time only increments when engine vacuum ≥ 10.0 kPa.</p>	<p>Fuel Level System Voltage BARO Startup IAT</p> <p>Startup ECT Engine Off Time</p> <p>No active DTCs:</p> <p>No Active DTC's TFTKO</p>	<p>10 % ≤ Percent ≤ 90 % ≥ 10.0 volts ≥ 70 kPa 4 °C ≤ Temperature ≤ 35 °C</p> <p>≤ 35 °C ≥ 28,800.0 seconds</p> <p>MAP_SensorFA TPS_FA VehicleSpeedSensor_FA IAT_SensorFA ECT_Sensor_FA AmbientAirDefault EnginePowerLimited</p> <p>P0443 P0449 P0452 P0453 P0454 P0458 P0459 P0498 P0499 P1001 P1005 P11FF P130F U18A2</p>	<p>Once per cold start</p> <p>Cold start: max time is 1,400 seconds</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		leaking purge valves that could otherwise be detected with the EONV small leak diagnostic (P0442).						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit Low (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0498	Controller specific output driver circuit diagnoses the vent solenoid low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	≤ 0.5 Ω impedance between output and controller ground	No active DTC's:	P1005 P130F U18A2	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0449 may also set (Vent Solenoid Open Circuit)

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Evaporative Emission System Vent Solenoid Control Circuit High (No ELCP - Conventional EVAP Diagnostic - with Fuel Tank Zone Module (FTZM))	P0499	Controller specific output driver circuit diagnoses the vent solenoid low sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds. If the P0499 is active, an intrusive test is performed with the vent solenoid commanded closed for 15 seconds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	≤ 0.5 Ω impedance between output and controller power	No active DTC's:	P1005 P130F U18A2	20 failures out of 25 samples 250 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Low Engine Speed Idle System	P0506	This DTC indicates that actual engine speed is lower than desired engine speed at idle so that it is out of speed control capability. Testing is performed when basic conditions are met. If filtered engine speed error exceeds a calibrated threshold for a calibrated duration, code is set. This testing is performed continuously per trip if basic conditions are met	Filtered Engine Speed Error. It is calculated with a calibrated filter coefficient Filter coefficient	> 91.00 rpm 0.00300	Baro Coolant Temp Engine run time Ignition voltage Time since gear change Time since a TCC mode change IAT Vehicle speed Commanded RPM delta Idle time For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa > 60 °C ≥ 30 sec 32 ≥ volts ≥ 11 ≥ 3 sec > 3 sec > -20 °C ≤ 1.24 mph, 2kph ≤ 25 rpm > 10 sec > 12.00 pct or < 75.00 pct PTO not active Transfer Case not in 4WD LowState	Diagnostic runs in every 12.5 ms loop Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					No active DTCs	Off-vehicle device control (service bay control) must not be active. following conditions not TRUE: (VeTESR_e_EngSpdReqIntvType = CeTESR_e_EngSpdMinLimit AND VeTESR_e_EngSpdReqRespType = CeTESR_e_NoSuggestion) Clutch is not depressed TC_BoostPresSnsrFA ECT_Sensor_FA EnginePowerLimited EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorCircuitFA EvapFlowDuringNonPurge_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA FuelInjectorCircuit_FA MAF_SensorFA EngineMisfireDetected_FA IgnitionOutputDriver_FA TPS_FA TPS_Performance_FA VehicleSpeedSensor_FA FuelLevelDataFault LowFuelConditionDiagnostic Clutch Sensor FA AmbPresDfltStatus		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					All of the above met for Idle time	P2771 > 10 sec The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
High Engine Speed Idle System	P0507	This DTC indicates that actual engine speed is higher than desired engine speed at idle so that it is out of speed control capability. Testing is performed when basic conditions are met. If filtered engine speed error exceeds a calibrated threshold for a calibrated duration, code is set. This testing is performed continuously per trip if basic conditions are met	Filtered Engine Speed Error. It is calculated with a calibrated filter coefficient Filter coefficient	< -182.00 rpm 0.00300	Baro Coolant Temp Engine run time Ignition voltage Time since gear change Time since a TCC mode change IAT Vehicle speed Commanded RPM delta For manual transmissions: Clutch Pedal Position or Clutch Pedal Position	> 70 kPa > 60 °C ≥ 30 sec 32 ≥ volts ≥ 11 ≥ 3 sec > 3 sec > -20 °C ≤ 1.24 mph, 2kph ≤ 25 rpm > 12.00 pct or < 75.00 pct PTO not active Transfer Case not in 4WD LowState Off-vehicle device control (service bay control) must not be active.	Diagnostic runs in every 12.5 ms loop Diagnostic reports pass or fail in 10 seconds once all enable conditions are met	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					for Idle time	The diagnostic does not run during autostop as engine is shutdown during that time (occurs in a hybrid or 12v start stop vehicle)		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>For the engine speeds and loads in which Dual Pulse is active:</p> <p>Dual Pulse Error induced misfires percentage</p> <p>Dual Pulse Error induced misfires percentage</p> <p>Engine Cycles</p> <p>The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:</p> <p>Catalyst Temperature AND Engine Run Time</p> <p>OR</p> <p>Engine Run Time</p> <p>OR</p>	<p>>= catalyst damaging misfire</p> <p>< 90% of the maximum achievable catalyst damaging misfire.</p> <p>>= 50</p> <p>>= 800.00 degC >= 1.00 seconds</p> <p>></p> <p>P050D_P1400_CatalystLightOffExtendedEngineRunTimeExit</p> <p>This Extended Engine run time exit table is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for details.</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Piston Protection Hot Coolant Enrichment Injector Flow Test General Enable DTC's Not Set:	Not Active Not Active Not Active AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFA CrankSensor_FA FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA AnyCamPhaser_TFTKO ClutchPstnSnsr_FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA FuelInjectorCircuit_TFTK O FHPR_b_FRP_SnsrCkt_F A FHPR_b_FRP_SnsrCkt_T FTKO FHPR_b_PumpCkt_FA FHPR_b_PumpCkt_TFTK O TransmissionEngagedStat e_FA EngineTorqueEstInaccura te FuelPumpRlyCktFA		

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Performance - Two Stage Oil Pump	P0521	<p>Determines if the Engine Oil Pressure (EOP) Sensor is stuck or biased in range. The engine oil pressure is compared against thresholds when engine is running and when engine is off. The engine oil pressure rationality diagnostic has two parts: engine running test and engine off test.</p> <p>The engine running test compares the measured oil pressure to threshold. If the measured oil pressure is out of the thresholds, then the error counter increments. The engine off test compares the measured oil pressure against thresholds after the engine has stopped rotating. If the measured oil pressure is out of the thresholds, then the error counter increments.</p>	<p>Two Stage Oil Pump EOP Sensor Test with Engine Running, High Pressure State</p> <p><u>To Fail when previously passing with the engine running:</u></p> <p>Filtered Engine Oil Pressure below expected threshold</p> <p>OR</p> <p>Filtered Engine Oil Pressure above expected threshold</p> <p><u>To pass when previously failing:</u></p> <p>Filtered Engine Oil Pressure above low threshold plus an offset</p> <p>OR</p>	<p>Filtered Oil Pressure < (P0521_P06DD_P06D E_OP_HiStatePressure * 1.00 - 133.0 kPa)</p> <p>OR</p> <p>Filtered Oil Pressure > (P0521_P06DD_P06D E_OP_HiStatePressure * 1.00 + 180.0 kPa)</p> <p>OR</p> <p>Filtered Oil Pressure > (P0521_P06DD_P06D E_OP_HiStatePressure * 1.00 - 133.0 kPa + 10.0 kPa)</p> <p>OR</p> <p>Filtered Oil Pressure < (</p>	<p>Two Stage Oil Pump is Present = TRUE</p> <p>Pump is in high pressure state</p> <p>Engine Running Diagnostic Status</p> <p>Engine Off Rationality Test Diagnostic Reporting Status</p> <p>Oil Pressure Sensor In Use</p> <p>Engine Running</p> <p>Ambient Air Pressure</p> <p>Oil Aeration (= TRUE if engine speed > 8,000 RPM for longer than 65,000.0 seconds)</p> <p>Filtered Engine Speed within range</p> <p>Modelled Oil Temperature within range</p> <p>Pump state change complete</p> <p>No active DTC's</p>	<p>TRUE</p> <p>Enabled</p> <p>Test not report a fail state</p> <p>Yes</p> <p>≥ 30.0 seconds</p> <p>≥ 70.0 kPa</p> <p>FALSE</p> <p>1,000 RPM ≤ Filtered Engine Speed ≤ 4,500 RPM</p> <p>40.0 deg C ≤ Oil Temp ≤ 120.0 deg C</p> <p>Time since state change > 0.50 s</p> <p>Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA EngOilPressureSensorCkt FA</p>	<p>≥ 40 errors out of 50 samples.</p> <p>Performed every 100 msec</p> <p>≥ 10 passes out of 50 samples.</p> <p>Performed every 100 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Filtered Engine Oil Pressure below high threshold minus an offset	P0521_P06DD_P06DE_OP_HiStatePressure * 1.00 + 180.0 kPa - 10.0 kPa) (Details on Supporting Tables Tab: P0521_P06DD_P06DE_OP_HiStatePressure)		AmbientAirDefault EngOilTempFA CrankSensor_FA		
			Two Stage Oil Pump EOP Sensor Test with Engine Running, Low Pressure State <u>To Fail when previously passing with the engine running:</u> Filtered Engine Oil Pressure below expected threshold OR Filtered Engine Oil Pressure above expected threshold	Filtered Oil Pressure < (P0521_P06DD_P06DE_OP_LoStatePressure * 1.00 - 133.0 kPa) OR Filtered Oil Pressure > (P0521_P06DD_P06DE_OP_LoStatePressure * 1.00 + 180.0 kPa)	Two Stage Oil Pump is Present = TRUE Pump is in low pressure state Engine Running Diagnostic Status Engine Off Rationality Test Diagnostic Reporting Status Oil Pressure Sensor In Use Engine Running Ambient Air Pressure Oil Aeration (= TRUE if engine speed > 8,000 RPM for longer than 65,000.0 seconds) Filtered Engine Speed within range	TRUE Enabled Test not report a fail state Yes ≥ 30.0 seconds ≥ 70.0 kPa FALSE 1,000 RPM ≤ Filtered Engine Speed ≤ 4,500 RPM	≥ 40 errors out of 50 samples. Performed every 100 msec	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p><u>To pass when previously failing:</u></p> <p>Filtered Engine Oil Pressure above low threshold plus an offset</p> <p>OR</p> <p>Filtered Engine Oil Pressure below high threshold minus an offset</p>	<p>Filtered Oil Pressure > (P0521_P06DD_P06DE_OP_LoStatePressure * 1.00 - 133.0 kPa + 10.0 kPa)</p> <p>OR</p> <p>Filtered Oil Pressure < (P0521_P06DD_P06DE_OP_LoStatePressure * 1.00 + 180.0 kPa - 10.0 kPa)</p> <p>(Details on Supporting Tables Tab: P0521_P06DD_P06DE_OP_LoStatePressure)</p>	<p>Modelled Oil Temperature within range</p> <p>Pump state change complete</p> <p>No active DTC's</p>	<p>40.0 deg C ≤ Oil Temp ≤ 120.0 deg C</p> <p>Time since state change > 0.50 s</p> <p>Time since state change > Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA EngOilPressureSensorCktFA AmbientAirDefault EngOilTempFA CrankSensor_FA</p>	<p>≥ 10 passes out of 50 samples.</p> <p>Performed every 100 msec</p>	
			<p>Two Stage Oil Pump EOP Sensor Test with Engine Off</p> <p>If enabled:</p> <p><u>To Fail when previously passing with the engine off:</u></p> <p>Filtered Engine Oil Pressure greater than threshold</p>	<p>Filtered Oil Pressure ≥ 40.0 kPa</p>	<p>Two Stage Oil Pump is Present = TRUE</p> <p>Engine Off Rationality Test Diagnostic Status</p> <p>Engine Running Rationality Test Diagnostic Status</p> <p>Modelled Oil Temperature No Engine Movement No active DTC's</p>	<p>TRUE</p> <p>Disabled</p> <p>Test not report a fail state</p> <p>≥ 60.0 deg C > 10.0 seconds EngineModeNotRunTimer_FA EngOilTempFA</p>	<p>≥ 20 errors out of 40 samples.</p> <p>Run once per trip</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						EngOilPressureSensorCkt FA CrankSensor_FA		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Circuit Low Voltage	P0522	Determines if the Engine Oil Pressure (EOP) Sensor circuit voltage is too low. This diagnostic compares the EOP circuit voltage to the reference voltage.	(Engine Oil Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	< 5.00 percent Deadband: < 5 percent or > 95 percent	Engine Speed Enable Engine Speed Disable Oil Pressure Sensor In Use Diagnostic Status	> 400 rpm < 350 rpm Yes Enabled	800 failures out of 1,600 samples Performed every 6.25 msec	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure (EOP) Sensor Circuit High Voltage	P0523	Determines if the Engine Oil Pressure (EOP) Sensor circuit voltage is too high. This diagnostic compares the EOP circuit voltage to the reference voltage.	(Engine Oil Pressure Sensor Circuit Voltage) ÷ 5 Volts) *100	> 95.00 percent Deadband: < 5 percent or > 95 percent	Oil Pressure Sensor In Use Diagnostic Status	Yes Enabled	800 failures out of 1,600 samples Performed every 6.25 msec	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Mutil- Functon Switch Circuit	P0564	Detect when cruise control multi-function switch circuit (analog) voltage is in an invalid range. "Emissions Neutral Default Action : When the BCM tells the ECM that the cruise control analog input voltage is in an invalid range, ECM sets the code and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."	Cruise Control analog circuit voltage must be "between ranges" for greater than a calibratable period of time.	The cruise control analog voltage A/D count ratio is considered to be "between ranges" when the ratio is measured in the following ranges: 0.28 -0.31, 0.415-0.445, 0.585 - 0.615 0.78 - 0.81, 1.005 - 1.035	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 0.500 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control On Switch Circuit	P0565	<p>Detects a failure of the cruise on/off switch in a continuously applied state</p> <p>"Emissions Neutral Default Action - When the BCM tells the ECM that the cruise control analog input voltage is in the Momentary Cruise On/Off range for too long, the code is set and cruise control is disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails." Only applicable for vehicles with a momentary on/off cruise switch architecture.</p>	Cruise Control On switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 20.00 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Resume Circuit	P0567	<p>Detects a failure of the cruise resume switch in a continuously applied state</p> <p>"Emissions Neutral Default Action : When the BCM tells the ECM that the cruise control analog input voltage is in the Resume range for too long, the code is set and cruise control is disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."</p>	Cruise Control Resume switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 89.000 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Set Circuit	P0568	<p>Detects a failure of the cruise set switch in a continuously applied state</p> <p>"Emissions Neutral Default Action : When the BCM tells the ECM that the cruise control analog input voltage is in the Set range for too long, the code is set and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."</p>	Cruise Control Set switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 89.000 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 89.000 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Cancel Switch Circuit	P056C	<p>Detects a failure of the cruise cancel switch in a continuously applied state</p> <p>"Emissions Neutral Default Action : When the BCM tells the ECM that the cruise control analog input voltage is in the Cancel range for too long, ECM sets the code and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."</p>	Cruise Control Cancel switch remains applied for greater than a calibratable period of time.	fail continuously in the applied state for greater than 20.00 seconds	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 20.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Range/ Performance	P057B	This diagnostic monitors the Brake Pedal Position Sensor for a stuck in range failure	.Brake pedal position sensor movement diagnostic cal is enabled 1.00	True	Brake Pedal Position Sensor Circuit Range / Performance Diagnostic Enable	1.00 ignition voltage > 10.00		MIL: Type A, 1 Trips
			Calculated EWMA value must be greater than calibratable threshold after calibratable number of tests have completed to report a "test passed" for P057B	EWMA value looked up in supporting table P057B KtBRKI_K_FastTestPointWeight P057B as a function of calculated brake pedal position delta EWMA value is > 0.80	calculated brake pedal position delta sample counter > 50.00 for fast test OR calculated brake pedal position delta sample counter > 1,000.00 for slow test	calculated brake pedal position delta > 3.25 OR (for slow test) shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 20.00	
			Calculated EWMA Value must be less than calibratable threshold after calibratable number of tests have completed to report a "test failed" for P057B. This test runs once per key cycle	EWMA value looked up in supporting table P057B KtBRKI_K_CmplTstPointWeight P057B as a function of calculated brake pedal position delta EWMA value is less than 0.40	no DTC's active (P057C, P057D)	shift lever has been in park once this key cycle vehicle speed >= 5.00 accelerator pedal position < 5.00	total number of EWMA tests > 2.00	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Low	P057C	detects short to ground for brake pedal position sensor	If x of y samples are observed below failure threshold, default brake pedal position to zero percent.	5.00	Brake Pedal Position Sensore Low Voltage Diagnostic Enable	1.00	20 / 32.00 counts	MIL: Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit High	P057D	detects open circuit for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	95.00	Brake Pedal Position Sensore High Voltage Diagnostic Enable	1.00	20.00 / 32.00 counts	MIL: Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Brake Pedal Position Sensor Circuit Intermittent/ Erratic	P057E	detects noisy / erratic ouput for brake pedal position sensor	If x of y samples are observed above failure threshold, default brake pedal position to zero percent and set DTC	25.00	Brake Pedal Position Sensor Circuit Intermittent / Erratic Diagnostic Enable	1.00	5.00 / 20.00 counts	MIL: Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi-function Circuit Low Voltage	P0580	detects short to ground failure for cruise multi-function switch circuit "Emissions Neutral Default Action : When the BCM tells the ECM that the cruise switch circuit voltage is too low for too long, ECM sets the code and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails." Only applicable for vehicles with a momentary on/off cruise switch architecture.	Cruise Control analog circuit voltage must be in an "Open Short To Ground" range for greater than a calibratable period of time.	The cruise control analog voltage A/D count ratio is considered to be "open short to ground when the ratio is measured in the following ranges: 0 - 0.185	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Multi-function Circuit High Voltage	P0581	detects short to power failure for cruise multi-function switch circuit "Emissions Neutral Default Action : When the BCM tells the ECM that the cruise switch circuit voltage is too high for too long, ECM sets the code and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails." Only applicable for vehicles with a momentary on/off cruise switch architecture.	Cruise Control analog circuit voltage must be in "Short To Power" range for greater than a calibratable period of time.	The cruise control analog voltage A/D count ratio is considered to be "short to power" when the ratio is measured in the following range: 1.005 - 1.035	CAN cruise switch diagnostic enable in ECM	1.00	fail continuously for greater than 2.00 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Active Grill Air Shutter A Performance /Stuck OFF	P059F	A 2-part diagnostic. Part 1 continuously monitors for failure to achieve a commanded shutter actuator position [Suspect Stuck Condition] when X failures occur in Y samples after an electronic command latency delay. A Part 1 failure result then enables Part 2 which makes a fixed number of repeat attempts to reach the commanded position [ReTry to clear obstruction]. The DTC is set when the calibrated fault threshold count of repeat attempts is reached without achieving the original commanded shutter position.	Smart Shutter Actuator 1 Position Response	<> Smart Shutter Actuator 1 Commanded Position percent	a. Ignition Run_Crank Active, b. Ignition Run_Crank AND Ignition Accessory AND ECU Awake, c. Command Shutter1 Enable	a. = TRUE, b. = FALSE AND = FALSE AND = TRUE, c. = 1.00	1.00 failures out of 1.00 samples 1 sample / 100 milliseconds	Type B, 2 Trips
			AND Shutter 1 Diagnostic Delay Threshold count	AND Counter > 99.00 counts				
			Shutter 1 Performance Test count	= 5.00 counts	a. Ignition Run_Crank Active, b. Ignition Run_Crank AND Ignition Accessory AND ECU Awake, c. Command Shutter1 Enable	a. = TRUE, b. = FALSE AND = FALSE AND = TRUE, c. = 1.00	1-5 actuator cycles [1 cycle typically requires 10-25 seconds]	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Active Grill Air Shutter B Performance /Stuck OFF	P05AE	A 2-part diagnostic. Part 1 continuously monitors for failure to achieve a commanded shutter actuator position [Suspect Stuck Condition] when X failures occur in Y samples after an electronic command latency delay. A Part 1 failure result then enables Part 2 which makes a fixed number of repeat attempts to reach the commanded position [ReTry to clear obstruction]. The DTC is set when the calibrated fault threshold count of repeat attempts is reached without achieving the original commanded shutter position.	Smart Shutter Actuator 2 Position Response	<> Smart Shutter Actuator 2 Commanded Position percent	a. Ignition Run_Crank Active, b. Ignition Run_Crank AND Ignition Accessory AND ECU Awake, c. Command Shutter2 Enable	a. = TRUE, b. = FALSE AND = FALSE AND = TRUE, c. = 1.00	1.00 failures out of 1.00 samples 1 sample / 100 milliseconds	Type B, 2 Trips
			AND Shutter 2 Diagnostic Delay Threshold count	AND Counter > 99.00 counts				
			Shutter 2 Performance Test count	= 5.00 counts	a. Ignition Run_Crank Active, b. Ignition Run_Crank AND Ignition Accessory AND ECU Awake, c. Command Shutter2 Enable	a. = TRUE, b. = FALSE AND = FALSE AND = TRUE, c. = 1.00	1-5 actuator cycles [1 cycle typically requires 10-25 seconds]	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Read Only Memory (ROM)	P0601	This DTC will be stored if the calibration check sum is incorrect or the flash memory detects an uncorrectable error via the Error Correcting Code.	The Primary Processor's calculated checksum does not match the stored checksum value. Covers all software and calibrations.	1 failure if the fault is detected during the first pass. 5.00 failures if the fault occurs after the first pass is complete.			Diagnostic runs continuously in the background.	Type A, 1 Trips
			The Primary Processor's Error Correcting Code hardware in the flash memory detects an error. Covers all software and calibrations.	254 failures detected via Error Correcting Code			Diagnostic runs continuously via the flash hardware.	
			The Primary Processor's calculated checksum does not match the stored checksum value for a selected subset of the calibrations.	2 consecutive failures detected or 5 total failures detected.			Diagnostic runs continuously. Will report a detected fault within 200 ms.	
				In all cases, the failure count is cleared when controller shuts down				

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Not Programmed	P0602	This DTC will be stored if the ECU is a service part that has not been programmed.	Service (reflash) controller calibration present	= 1		none	Diagnostic runs at powerup and once per second continuously after that	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM Long Term Memory Reset	P0603	This DTC detects an invalid NVM which includes a Static NVM, Perserved NVM, ECC ROM in NVM Flash Region, and Perserved NVM during shut down.	Static NVM region error detected during initialization				Diagnostic runs at controller power up.	Type A, 1 Trips
			Perserved NVM region error detected during initialization				Diagnostic runs at controller power up.	
			Perserved NVM region error detected during shut down.				Diagnostic runs at controller power down.	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ECM RAM Failure	P0604	Indicates that the ECM has detected a RAM fault. This includes Primary Processor System RAM Fault, Primary Processor Cache RAM Fault, Primary Processor TPU RAM Fault, Primary Processor Update Dual Store RAM Fault, Primary Processor Write Protected RAM Fault, and Secondary Processor RAM Fault. This diagnostic runs continuously.	Indicates that the primary processor is unable to correctly read data from or write data to system RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	Type A, 1 Trips
			Indicates that the primary processor is unable to correctly read data from or write data to cached RAM. Detects data read does not match data written >=	254 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor is unable to correctly read data from or write data to TPU RAM. Detects data read does not match data written >=	5 counts			Will finish first memory scan within 30 seconds at all engine conditions - diagnostic runs continuously (background loop)	
			Indicates that the primary processor detects a mismatch between the data and dual data is found during RAM updates. Detects a mismatch in data and dual data updates >	0.47369 s			When dual store updates occur.	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Indicates that the primary processor detects an illegal write attempt to protected RAM. Number of illegal writes are >	65,534 counts			Diagnostic runs continuously (background loop)	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Fault	P0606	Indicates that the ECM has detected an internal processor integrity fault. These include diagnostics done on the SPI Communication as well as a host of diagnostics for both the primary and secondary processors.	Time new seed not received exceeded			always running	0.450 seconds	Type A, 1 Trips
			MAIN processor receives seed in wrong order			always running	3 / 18 counts intermittent. 50 ms/count in the ECM main processor	
			2 fails in a row in the MAIN processor's ALU check			Test is Enabled: 1 (If 0, this test is disabled)	25 ms	
			2 fails in a row in the MAIN processor's configuration register masks versus known good data			Test is Enabled: 1 (If 0, this test is disabled)	12.5 to 25 ms	
			Checks number of stack over/under flow since last powerup reset >=	3.00		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to corrupt stack	
			Voltage deviation >	0.4950		Test is Enabled: 1 (If 0, this test is disabled)	5 / 10 counts or 0.150 seconds continuous; 50 ms/count in the ECM main processor	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occurred since last controller initialization.	3 (results in MIL), 5 (results in MIL and remedial action)		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Counter >=					
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		Test is Enabled: 1 (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM variable, depends on length of time to write flash to RAM	
			MAIN processor DMA transfer from Flash to RAM has 1 failure			Test is Enabled: 0 (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM	
			Safety critical software is not executed in proper order.	>= 1 incorrect sequence.		Test is Enabled: 1.00 (If 0, this test is disabled)	Fail Table, f(Loop Time). See supporting tables: P0606_PSW Sequence Fail f (Loop Time) / Sample Table, f (Loop Time)See supporting tables: P0606_PSW Sequence Sample f(Loop Time) counts 50 ms/count in the ECM main processor	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			MAIN processor determines a seed has not changed within a specified time period within the 50ms task.	Previous seed value equals current seed value.		Test is Enabled: 1 (If 0, this test is disabled)	Table, f(Loop Time). See supporting tables: P0606_Last Seed Timeout f (Loop Time)	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal ECM Processor Integrity Performance	P0607	Indicates that the ECM has detected an internal processor integrity performance.	Performs the failure diagnostic for the offline and online BIST results.			Test is enabled: 0. (If 0, this test is disabled)	5 counts background task/count in the ECM main processor	Type A, 1 Trips
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for flash memory. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		Test is enabled: 1. (If 0, this test is disabled)	variable, depends on length of time to access flash with corrupted memory	
			Checks for ECC (error correcting code) circuit test errors reported by the hardware for RAM memory circuit. Increments counter during controller initialization if ECC error occurred since last controller initialization. Counter >=	3 (results in MIL), 5 (results in MIL and remedial action)		Test is enabled: 1. (If 0, this test is disabled)	variable, depends on length of time to write flash to RAM variable, depends on length of time to write flash to RAM	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
ANDR ADC Fault	P060B	Indicates that the ECM has detected an ANDR ADC Fault.	Resistance deviation percent >	6.00 %	Run/Crank Voltage >	7.00 V	2 / 14 counts or 1.75 seconds continuous; 250 ms/count in the ECM main processor	
			Resistance deviation percent >	6.00 %	Run/Crank Voltage >	7.00 V	2 / 14 counts or 1.75 seconds continuous; 250 ms/count in the ECM main processor	
			Resistance deviation percent >	6.00 %	Run/Crank Voltage >	7.00 V	2 / 14 counts or 1.75 seconds continuous; 250 ms/count in the ECM main processor	
			Resistance deviation percent >	6.00 %	Run/Crank Voltage >	7.00 V	2 / 14 counts or 1.75 seconds continuous; 250 ms/count in the ECM main processor	
			Resistance deviation percent >	6.00 %	Run/Crank Voltage >	7.00 V	2 / 14 counts or 1.75 seconds continuous; 250 ms/count in the ECM main processor	
			Resistance deviation percent >	6.00 %	Run/Crank Voltage >	7.00 V	2 / 14 counts or 1.75 seconds continuous; 250 ms/count in the ECM main processor	
			Resistance deviation	6.00 %	Run/Crank Voltage >	7.00 V	2 / 14 counts or	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			percent >				1.75 seconds continuous; 250 ms/count in the ECM main processor	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Fuel Injector Control Performance	P062B	This DTC Diagnoses the internal fuel injector control module circuit for circuit faults.	Internal ECU Boost Voltage OR Internal ECU Boost Voltage OR Driver Status OR Driver Status	>= 90 Volts = Not Ready = Uninitialized	Battery Voltage	>= 8 or >= 11 Enabled when a code clear is not active or not exiting device control Engine is not cranking Powertrain Relay Voltage within range	High Voltage - 160 failures out of 200 samples Low Voltage - 160 failures out of 200 samples Driver Status Not Ready- 160 failures out of 200 samples Driver Status Uninitialized - Uninitialized state for >= 100 counts All at 12.5ms per sample	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Internal Control Module EEPROM Error	P062F	This DTC detects a NVM long term performance. There are two types of diagnostics that run during controller power up. One for HWIO reports that writing to NVM (at shutdown) will not succeed, and the other HWIO reports the assembly calibration integrity check has failed.	HWIO reports that writing to NVM (at shutdown) will not succeed				Diagnostic runs at controller power up.	Type B, 2 Trips
			HWIO reports the assembly calibration integrity check has failed				Diagnostic runs at controller power up.	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
VIN Not Programmed or Mismatched - Engine Control Module (ECM)	P0630	This DTC checks that the VIN is correctly written	At least one of the programmed VIN digits	= 00 or FF	OBD Manufacturer Enable Counter	= 0	250 ms / test Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #1 Circuit	P0641	Detects a continuous or intermittent short on the 5 volt reference circuit #1 by monitoring the reference percent Vref1 and failing the diagnostic when the percent Vref1 is too low or too high or if the delta between the filtered percent Vref1 and non-filtered percent Vref1 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref1 < or ECM percent Vref1 > or the difference between ECM filtered percent Vref1 and percent Vref1 >	4.875 % Vref1 5.125 % Vref1 0.0495 % Vref1	Diagnostic enabled AND [(Run/Crank voltage for Time period AND Starter engaged) OR (Run/Crank voltage AND Starter engaged)]	= 1 > 6.41 Volts = 0.03 Seconds = FALSE > 8.41 Volts = TRUE	19 / 39 counts; or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Open	P0650	Detects an inoperative malfunction indicator lamp control low side driver circuit. This diagnostic reports the DTC when an open circuit is detected.	Voltage low during driver off state (indicates open circuit)	Open circuit: ≥ 200 K Ω impedance between signal and controller ground	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11.00 volts	1 failures out of 1 samples 50 ms / sample	Type B, No MIL NO MIL Note: In certain controllers P263A may also set (MIL Control Short to Ground)

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #2 Circuit	P0651	Detects a continuous or intermittent short on the 5 volt reference circuit #2 by monitoring the reference percent Vref2 and failing the diagnostic when the percent Vref2 is too low or too high or if the delta between the filtered percent Vref2 and non-filtered percent Vref2 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref2 < or ECM percent Vref2 > or the difference between ECM filtered percent Vref2 and percent Vref2 >	4.875 % Vref2 5.125 % Vref2 0.0495 % Vref2	Diagnostic enabled AND [(Run/Crank voltage for Time period AND Starter engaged) OR (Run/Crank voltage AND Starter engaged)]	= 1 > 6.41 Volts = 0.03 Seconds = FALSE > 8.41 Volts = TRUE	19 / 39 counts; or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Open	P0685	Detects an open circuit in the Powertrain Relay driver. This diagnostic reports the DTC when an open circuit failure is present. Monitoring occurs when the output is powered off. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 K Ω ohms impedance between output and controller ground	Run/Crank Voltage	Voltage ≥ 11.00 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P0686 may also set (Powertr ain Relay Control Short to Ground).

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) Low	P0686	Detects a short to ground in the Powertrain Relay low side driver. This diagnostic reports the DTC when a short to ground failure is present. Monitoring occurs when the output is powered off. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to ground: ≤ 0.5 Ω impedance between output and controller ground	Run/Crank Voltage	Voltage ≥ 11.00 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controllers P0685 may also set (Powertrain Relay Control Open Circuit).

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Control (ODM) High	P0687	Detects a short to power in the Powertrain Relay low side driver. This diagnostic reports the DTC when a short to power failure is present. Monitoring occurs when the output is powered off. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to power: ≤ 0.5 Ω impedance between output and controller power	Run/Crank Voltage	Voltage ≥ 11.00 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Relay Feedback Circuit Low Voltage	P0689	Detects low voltage in the control module relay feedback circuit. This diagnostic reports the DTC when low voltage is present. Monitoring occurs when run crank voltage is above a calibrated value.	Control module relay feedback circuit low voltage	Powertrain relay voltage <= 5.00	Powertrain relay short low diagnostic enable Run Crank voltage Powertrain relay state	= 1.00 > 9.00 = ON	5 failures out of 6 samples 1000 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Powertrain Relay Feedback Circuit High	P0690	Detects higher than expected voltage in the powertrain relay feedback circuit. This diagnostic reports the DTC when higher than expected voltage is present. For example, the powertrain relay could be stuck on. Monitoring occurs when the relay is commanded "off" for a calibrated duration.	Powertrain Relay Voltage	>= 4.00 volts will increment the fail counter	Powertrain relay commanded "OFF" No active DTCs:	>= 2.00 seconds PowertrainRelayStateOn_ FA	50 failures out of 63 samples 100ms / Sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #3 Circuit	P0697	Detects a continuous or intermittent short on the 5 volt reference circuit #3 by monitoring the reference percent Vref3 and failing the diagnostic when the percent Vref3 is too low or too high or if the delta between the filtered percent Vref3 and non-filtered percent Vref3 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref3 < or ECM percent Vref3 > or the difference between ECM filtered percent Vref3 and percent Vref3 >	4.875 % Vref3 5.125 % Vref3 0.0495 % Vref3	Diagnostic enabled AND [(Run/Crank voltage for Time period AND Starter engaged) OR (Run/Crank voltage AND Starter engaged)]	= 1 > 6.41 Volts = 0.03 Seconds = FALSE > 8.41 Volts = TRUE	19 / 39 counts; or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
5 Volt Reference #4 Circuit	P06A3	Detects a continuous or intermittent short on the 5 volt reference circuit #4 by monitoring the reference percent Vref4 and failing the diagnostic when the percent Vref4 is too low or too high or if the delta between the filtered percent Vref4 and non-filtered percent Vref4 is too large. This diagnostic only runs when battery voltage is high enough.	ECM percent Vref4 < or ECM percent Vref4 > or the difference between ECM filtered percent Vref4 and percent Vref4 >	4.875 % Vref4 5.125 % Vref4 0.0495 % Vref4	Diagnostic enabled AND [(Run/Crank voltage for Time period AND Starter engaged) OR (Run/Crank voltage AND Starter engaged)]	= 1 > 6.41 Volts = 0.03 Seconds = FALSE > 8.41 Volts = TRUE	19 / 39 counts; or 0.1875 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 1 Performance	P06B6	This diagnostic checks for a fault with the internal test circuit used only for the '20 kHz' method of the Open Circuit Diagnostic	FFT Diagnostic Output	<p>> P06B6_P06B7_OpenT estCktThrshMin</p> <p>AND</p> <p>< P06B6_P06B7_OpenT estCktThrshMax</p> <p>See Supporting Tables</p>	<p>Diagnostic Enabled?</p> <p>Engine Run Time</p> <p>Engine Speed</p> <p>Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above)</p> <p>Engine Air Flow</p>	<p>Yes</p> <p>≥ 2.0 seconds</p> <p>> 400 RPM and < 4,000 RPM</p> <p>≥ 200 Revs</p> <p>≥ 50 mg/cylinder and ≤ 2,000 mg/cylinder</p>	<p>First Order Lag Filter with Weight Coefficient</p> <p>Weight Coefficient = 0.0100</p> <p>Updated each engine event</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Knock Sensor Processor 2 Performance	P06B7	This diagnostic checks for a fault with the internal test circuit used only for the '20 kHz' method of the Open Circuit Diagnostic	FFT Diagnostic Output	> P06B6_P06B7_OpenT estCktThrshMin AND < P06B6_P06B7_OpenT estCktThrshMax See Supporting Tables	Diagnostic Enabled? Engine Run Time Engine Speed Cumulative Number of Engine Revs (per key cycle) within min/max Engine Speed enable (above) Engine Air Flow	Yes ≥ 2.0 seconds > 400 RPM and < 4,000 RPM ≥ 200 Revs ≥ 50 mg/cylinder and ≤ 2,000 mg/cylinder	First Order Lag Filter with Weight Coefficient Weight Coefficient = 0.0100 Updated each engine event	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure Control Circuit/Open	P06DA	Controller specific output driver circuit diagnoses the oil pump low sided driver for an open circuit failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit ≥ 200 k Ω impedance between output and controller ground	Powertrain Relay Voltage Run/Crank Active Cranking State	≥ 11.00 = True = False	>= 40 errors out of 50 samples. Performed every 100 msec	Type B, 2 Trips Note: In certain controllers P06DB may also set (Engine Oil Pressure Control Circuit Short To Ground)

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure Control Circuit Low	P06DB	Controller specific output driver circuit diagnoses the oil pump low sided driver for a short to ground failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to Ground Circuit $\leq 0.5 \Omega$ impedance between output and controller ground	Powertrain Relay Voltage Run/Crank Active Cranking State	≥ 11.00 = True = False	≥ 40 errors out of 50 samples. Performed every 100 msec	Type B, 2 Trips Note: In certain controllers P06DA may also set (Engine Oil Pressure Control Circuit Open)

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Oil Pressure Control Circuit High	P06DC	Controller specific output driver circuit diagnoses the oil pump low sided driver for a short to power failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to Power $\leq 0.5 \Omega$ impedance between output and controller power	Powertrain Relay Voltage Run/Crank Active Cranking State	≥ 11.00 = True = False	≥ 40 errors out of 50 samples. Performed every 100 msec	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit Performance - Two Sided	P06DD	Diagnoses the two stage oil pump is stuck in the high pressure state. This diagnostic includes an intrusive test and a passive test. Intrusive test: The oil pump control is cycled off (high pressure) and on (low pressure) Y = 15 times at calibratable intervals. If a change in oil pressure above a calibration is not detected then the oil pressure is checked to determine if it is stuck. It takes X-out-of-Y failures to fail and set the appropriate code. Passive test: After the intrusive test passes, then a passive test will begin to run. The passive test will monitor the oil pressure changes associated with oil pump control state changes. If the passive test determines that the oil pressure change was less than desired then the intrusive test is retriggered.	<u>Fail from passing state:</u> Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is above a threshold	Oil Pressure delta = ABS [Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.5 seconds] Oil Pressure delta < P06DD_P06DE_OP_S tateChangeMin AND Filtered Oil Pressure ≥ (P0521_P06DD_P06D E_OP_HiStatePressu re + P0521_P06DD_P06D E_OP_LoStatePressu re) ÷ 2 (see P06DD details on Supporting Tables Tab P06DD_P06DE_OP_S tateChangeMin P0521_P06DD_P06D E_OP_HiStatePressu re P0521_P06DD_P06D E_OP_LoStatePressu re)	<u>Common Criteria:</u> Two Stage Oil Pump is Present Engine Running Ambient Air Pressure Oil Aeration (= TRUE if engine speed > 8,000 RPM for longer than 65,000.0 seconds) No active DTC's for diagnosis enable: Check oil pump TFTKO as a diagnostic enable when Enabled. No active DTC's for control enable: <u>Active Criteria:</u> One Sided Performance Test = Disabled	TRUE ≥ 30.0 seconds ≥ 70.0 kPa FALSE Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCkt FA AmbientAirDefault EngOilTempFA OilPmpTFTKO Enabled : OilPmpTFTKO Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA Enabled	≥ 12 errors out of 15 samples. Run once per trip or activated by the Passive Test	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Oil Pump in Low State</p> <p>Modelled Oil Temperature within range</p> <p>Filtered Engine Speed within range</p> <p>Delta Filtered Engine Speed within a range</p> <p>Engine Torque within range</p> <p>Filtered Oil Pressure within range</p>	<p>> 1.5 seconds</p> <p>40.0 deg C ≤ Oil Temp ≤ 110.0 deg C</p> <p>1,200 RPM ≤ Filtered Engine Speed ≤ 2,500 RPM</p> <p>ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] ≤ 50 RPM</p> <p>P06DD_P06DE_MinEnableTorque_OP ≤ Indicated Requested Engine Torque ≤ P06DD_P06DE_MaxEnableTorque_OP (see P06DD details on Supporting Tables Tab P06DD_P06DE_MinEnableTorque_OP P06DD_P06DE_MaxEnableTorque_OP)</p> <p>Filtered Engine Oil Pressure > P06DD_P06DE_MinOilPressureThresh (see P06DD details on Supporting Tables Tab P06DD_P06DE_MinOilPressureThresh)</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Expected Oil Pressure Delta within range</p> <p><u>Passive Criteria:</u></p> <p>Active Test Passed</p> <p>Filtered Engine Speed within range</p> <p>Modelled Oil Temperature within range</p> <p>Delta Filtered Engine Speed within a range</p> <p>Oil Pressure Delta within a range</p>	<p>83.0 kPa < ABS [P0521_P06DD_P06DE_OP_HiStatePressure - P0521_P06DD_P06DE_OP_LoStatePressure] < 200.0 kPa</p> <p>TRUE</p> <p>1,000 RPM ≤ Filtered Engine Speed ≤ 4,500 RPM</p> <p>40.0 deg C ≤ Oil Temp ≤ 120.0 deg C</p> <p>ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.00 seconds] ≤ 1,000 RPM</p> <p>Oil Pressure Delta < P06DD_P06DE_OP_StateChangeMin (see P06DD details on Supporting Tables Tab P06DD_P06DE_OP_StateChangeMin)</p>		
			<p><u>Fast Pass Condition</u></p> <p>Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is</p>	<p>Oil Pressure delta = ABS [Filtered Oil Pressure at beginning of state change -</p>	<p><u>Common Criteria:</u></p> <p>Two Stage Oil Pump is Present</p> <p>Engine Running</p>	<p>TRUE</p> <p>≥ 30.0 seconds</p>	<p>0 errors out of 5 samples.</p> <p>Run once per trip or activated by the Passive Test</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
			above a threshold	filtered oil pressure after 1.5 seconds] Oil Pressure delta < P06DD_P06DE_OP_S tateChangeMin AND Filtered Oil Pressure ≥ (P0521_P06DD_P06D E_OP_HiStatePressu re - P0521_P06DD_P06D E_OP_LoStatePressu re) ÷ 2 (see P06DD details on Supporting Tables Tab P06DD_P06DE_OP_S tateChangeMin P0521_P06DD_P06D E_OP_HiStatePressu re P0521_P06DD_P06D E_OP_LoStatePressu re)	filtered oil pressure after 1.5 seconds]	Ambient Air Pressure Oil Aeration (= TRUE if engine speed > 8,000 RPM for longer than 65,000.0 seconds) No active DTC's for diagnsotic enable: Check oil pump TFTKO as a diagnostic enable when Enabled. No active DTC's for control enable: <u>Active Criteria:</u> One Sided Performance Test = Disabled Oil Pump in Low State Modelled Oil Temperature within range Filtered Engine Speed within range	≥ 70.0 kPa FALSE Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA EngOilPressureSensorCkt FA AmbientAirDefault EngOilTempFA OilPmpTFTKO CrankSensor_FA Enabled : OilPmpTFTKO Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccura te EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA Enabled		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Engine Torque within range</p> <p>Delta Filtered Engine Speed within a range</p> <p>Filtered Oil Pressure within range</p> <p>Expected Oil Pressure Delta within range</p>	<p>RPM</p> <p>P06DD_P06DE_MinEnableTorque_OP \leq Indicated Requested Engine Torque \leq P06DD_P06DE_MaxEnableTorque_OP (see P06DD details on Supporting Tables Tab P06DD_P06DE_MinEnableTorque_OP P06DD_P06DE_MaxEnableTorque_OP)</p> <p>ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] \leq 50 RPM</p> <p>Filtered Engine Oil Pressure > P06DD_P06DE_MinOilPressThresh (see P06DD details on Supporting Tables Tab P06DD_P06DE_MinOilPressThresh)</p> <p>83.0 kPa < ABS [P0521_P06DD_P06DE_OP_HiStatePressure - P0521_P06DD_P06DE_OP_LoStatePressure] < 200.0 kPa</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Two Stage Oil Pump Control Circuit StuckOn - Two Sided	P06DE	<p>Diagnoses the two stage oil pump is stuck in the low pressure state. This diagnostic includes an intrusive test and a passive test.</p> <p>Intrusive test: The oil pump control is cycled off (high pressure) and on (low pressure) Y times at calibratable intervals. If a change in oil pressure above a calibration is not detected then the oil pressure is checked to determine if it is stuck. It takes X-out-of-Y failures to fail and set the appropriate code.</p> <p>Passive test: After the intrusive test passes, then a passive test will begin to run. The passive test will monitor the oil pressure changes associated with oil pump control state changes. If the passive test determines that the oil pressure change was less than desired then the intrusive test is retriggered.</p>	<p><u>Fail from a passing state:</u></p> <p>Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is below a threshold</p>	<p>Oil Pressure delta = ABS [Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.5 seconds]</p> <p>Oil Pressure delta < P06DD_P06DE_OP_StateChangeMin (see P06DE details on Supporting Tables Tab)</p> <p>Filtered Oil Pressure ≤ P0521_P06DD_P06DE_OP_HiStatePressure (re - P0521_P06DD_P06DE_OP_LoStatePressure) ÷ 2 (see P06DE details on Supporting Tables Tab)</p>	<p><u>Common Criteria:</u></p> <p>Two Stage Oil Pump is Present</p> <p>Engine Running</p> <p>Ambient Air Pressure</p> <p>Oil Aeration (= TRUE if engine speed > 8,000 RPM for longer than 65,000.0 seconds)</p> <p>No active DTC's for diagnostic enable:</p> <p>Check oil pump TFTKO as a diagnostic enable when Enabled.</p> <p>No active DTC's for control enable:</p> <p><u>Active Criteria:</u> One Sided Performance</p>	<p>TRUE</p> <p>≥ 30.0 seconds</p> <p>≥ 70.0 kPa</p> <p>FALSE</p> <p>Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCktFA AmbientAirDefault EngOilTempFA</p> <p>Enabled : OilPmpTFTKO</p> <p>Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccurate EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA</p> <p>Enabled</p>	<p>≥ 12 errors out of 15 samples.</p> <p>Run once per trip or activated by the Passive Test</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Test = Disabled Oil Pump in Low State Modelled Oil Temperature within range Filtered Engine Speed within range Engine Torque within range Delta Filtered Engine Speed within a range Filtered Oil Pressure within range Expected Oil Pressure Delta within range	> 1.5 seconds 40.0 deg C ≤ Oil Temp ≤ 110.0 deg C 1,200 RPM ≤ Filtered Engine Speed ≤ 2,500 RPM P06DD_P06DE_MinEnableTorque_OP ≤ Indicated Requested Engine Torque ≤ P06DD_P06DE_MaxEnableTorque_OP (see P06DE details on Supporting Tables Tab) ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] ≤ 50 RPM Filtered Engine Oil Pressure > P06DD_P06DE_MinOilPressThresh (see P06DD details on Supporting Tables Tab) 83.0 kPa < ABS [P0521_P06DD_P06DE_OP_HiStatePressure - P0521_P06DD_P06DE_OP_LoStatePressure] < 200.0 kPa		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<u>Passive Criteria:</u> Active Test Passed Filtered Engine Speed within range Modelled Oil Temperature within range Delta Filtered Engine Speed within a range Oil Pressure Delta < P06DD_P06DE_OP_StateChangeMin (see P06DE details on Supporting Tables Tab)	TRUE 1,000 RPM ≤ Filtered Engine Speed ≤ 4,500 RPM 40.0 deg C ≤ Oil Temp ≤ 120.0 deg C ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.00 seconds] ≤ 1,000 RPM TRUE		
			<u>Fast Pass Condition</u> Oil Pressure delta is less than a minimum delta pressure on a state change and the measured filtered oil pressure is below a threshold	Oil Pressure delta = ABS [Filtered Oil Pressure at beginning of state change - filtered oil pressure after 1.5 seconds] Oil Pressure delta <	<u>Common Criteria:</u> Two Stage Oil Pump is Present Engine Running Ambient Air Pressure Oil Aeration (= TRUE if engine speed	TRUE ≥ 30.0 seconds ≥ 70.0 kPa FALSE	0 errors out of 5 samples. Run once per trip or activated by the Passive Test	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				<p>P06DD_P06DE_OP_S tateChangeMin (P06DD Performance Test Details on Supporting Tables Tab)</p> <p>Filtered Oil Pressure ≤</p> <p>P0521_P06DD_P06D E_OP_HiStatePressu (re - P0521_P06DD_P06D E_OP_LoStatePressu re) / 2 (P06DD Performance Test Details on Supporting Tables Tab)</p>	<p>> 8,000 RPM for longer than 65,000.0 seconds)</p> <p>No active DTC's for diagnotic enable:</p> <p>Check oil pump TFTKO as a diagnostic enable when Enabled.</p> <p>No active DTC's for control :</p> <p><u>Active Criteria:</u> One Sided Performance Test = Disabled</p> <p>Oil Pump in Low State</p> <p>Modelled Oil Temperature within range</p> <p>Filtered Engine Speed within range</p> <p>Engine Torque within range</p>	<p>Fault bundles: MAF_SensorFA ECT_Sensor_FA IAT_SensorFA CrankSensor_FA EngOilPressureSensorCkt FA AmbientAirDefault EngOilTempFA</p> <p>Enabled : OilPmpTFTKO</p> <p>Enabled Fault bundles for control disable : OilPmpTFTKO EngineTorqueEstInaccura te EngOilPressureSensorFA PowertrainRelayFault CrankSensor_FA EngOilTempFA</p> <p>Enabled</p> <p>> 1.5 seconds</p> <p>40.0 deg C ≤ Oil Temp ≤ 110.0 deg C</p> <p>1,200 RPM ≤ Filtered Engine Speed ≤ 2,500 RPM</p> <p>P06DD_P06DE_MinEnab leTorque_OP ≤</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>Delta Filtered Engine Speed within a range</p> <p>Filtered Oil Pressure within range</p> <p>Expected Oil Pressure Delta within range</p>	<p>Indicated Requested Engine Torque ≤ P06DD_P06DE_MaxEnableTorque_OP (P06DD Performance Test Details on Supporting Tables Tab)</p> <p>ABS [Filtered RPM at beginning of State change - Filtered RPM after 1.0 seconds] ≤ 50 RPM</p> <p>Filtered Engine Oil Pressure > P06DD_P06DE_MinOilPressureThresh (see P06DD details on Supporting Tables Tab)</p> <p>83.0 kPa < ABS [P0521_P06DD_P06DE_OP_HiStatePressure - P0521_P06DD_P06DE_OP_LoStatePressure] < 200.0 kPa</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Module (TCM) Requested MIL Illumination	P0700	Monitors the TCM MIL request message to determine when the TCM has detected a MIL illuminating fault.	Transmission Control Module Emissions-Related DTC set and module is requesting MIL	Transmission Control Module Emissions-Related DTC set and module is requesting MIL		Time since power-up \geq 3 seconds	Continuous	Type A, No MIL

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module System Voltage Performance (Only on applications that use an FTZM)	P1002	Detects low system voltage performance of the fuel pump driver control module system. This diagnostic reports the DTC when the absolute value of the difference between the fuel pump driver battery voltage and the fuel pump driver run/crank voltage exceeds a calibrated value.	Fuel Pump Driver Control Module Run Crank voltage low and high	ABS (Fuel Pump Driver Control Module Battery voltage - Fuel Pump Driver Control Module Run Crank voltage) > 3.00	Fuel Tank Zone Module (FTZM) is present on vehicle Fuel Pump Driver Control Module System Voltage Performance diagnostic is enabled Fuel Tank Zone Module (FTZM) serial messages are available FTZM Run Crank Active is TRUE Starter motor not engaged Sensor Bus relay is commanded ON	= 1	50 failures out of 63 samples 12.5 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Reset Error	P1005	This DTC monitors for a reset error in the Fuel Pump Driver Control Module	If the received value for the time since the last FPDCM reset has reset and the newly received value or previous value is for out of total samples	<= 0.50 seconds >= 2.00 counts >= 400.00 counts	DTC is enabled Sensor bus relay Battery voltage P1000 U18A2	1.00 (1 indicates enabled) On > 11.00 Volts Not active Not active	Diagnostic runs in 50 ms loop.	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit High (Only on applications that use an FTZM)	P1007	Detects high voltage of the fuel pump driver control module ignition switch circuit. This diagnostic reports the DTC when the fuel pump driver control module ignition switch circuit voltage exceeds a calibrated value.	Fuel Pump Driver Control Module Ignition switch Run/Start position circuit high	FTZM Run Crank Active is TRUE	Fuel Tank Zone Module (FTZM) is present on vehicle Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit High diagnostic is enabled Fuel Tank Zone Module (FTZM) serial messages are available Run Crank Active Sensor Bus relay is commanded ON	= 1 = FALSE	40 failures out of 50 samples 50 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Temperature (Fuel Tank Zone Module) Too High Signal Message Counter Incorrect	P1009	This DTC monitors for an error in communication with the Fuel Pump Driver Control Module (FTZM) Temperature Too High Signal Message	Communication of the Alive Rolling Count or Protection Value from the Fuel Pump Driver Control Module over CAN bus is incorrect out of total samples	>= 8 counts >= 10 counts	All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	>= 3,000.00 seconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 100ms loop.	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V-W Circuit Open	P1029	<p>This DTC detects if any of the 3phase fuel pump control circuits is Open [system configuration "Brushless"]</p> <p>The diagnostic can detect open circuit faults when the fuel pump is not rotating. In the "stopped" state, small currents are injected into each motor phase circuit pair by an internal fixed source and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage falls into a specific range [adjusted for source voltage]. This process is completed in less than 1 millisecond. The FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are</p>	Phased-pair circuit voltage	3V <= V [back-EMF] <= 6V	<p>a) Sensed fuel pump speed</p> <p>b) Device configuration FCBR_e_ChassisFuelPre sSysType</p> <p>c) Diagnostic Enabled - KeFABR_b_OpenCktDiag Enbl</p> <p>d) CAN Sensor Bus message \$3EC_Avail</p> <p>e) Sensor Bus Relay On</p> <p>f) Sensor Bus B Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]</p>	<p>a) == 0 RPM</p> <p>b) CeFCBR_e_DSL_ECM_FTZM_BLDC_Sys</p> <p>c) == TRUE</p> <p>d) == TRUE</p> <p>e) == TRUE</p> <p>f) <> TRUE</p>	<p>40.00 failures / 80.00 samples</p> <p>1 sample / 12.5 ms</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		active at any moment. Brushless fuel pump speed is inferred using the rate of zero- crossings detection and number of motor pole- pairs. Speed is reported to the ECM as serial data every 10 milliseconds. This open circuit diagnostic follows "smart device" Component Technical Specifications.						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V- W Circuit Low	P102A	<p>This DTC detects if the fuel pump control circuit is shorted to low [Short to Ground]</p> <p>The diagnostic detects short-to-ground faults using 2 methods depending on whether the fuel pump is rotating. 1) In the "rotating" state, voltage drop across each phase-pair high-side drive is monitored, or 2) in the "stopped" state, small currents are injected into each motor phase circuit pair</p>	Phased-pair circuit voltage Difference	Vdelta > 0.145 V	<p>a) Device configuration FCBR_e_ChassisFuelPre sSysType</p> <p>b) Diagnostic KeFABR_b_GshtCktDiag Enbl</p> <p>c) CAN Sensor Bus message \$3EC_Avail</p> <p>d) Sensor Bus Relay On</p> <p>e) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_A RC_ChkErr]</p>	<p>a) == CeFCBR_e_DSL_ECM_F TZM_BLDC_Sys</p> <p>b) == TRUE</p> <p>c) == TRUE</p> <p>d) == TRUE</p> <p>e) <> TRUE</p>	<p>40.00 failures / 80.00 samples</p> <p>1 sample / 12.5 ms</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>by an internal fixed source and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage falls into a specific range [adjusted for source voltage].</p> <p>The FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are active at any moment. Brushless fuel pump speed is inferred using the rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 milliseconds.</p> <p>This open circuit diagnostic follows "smart device" Component Technical Specifications.</p>	Phased-pair circuit voltage	V [back-EMF] >= 6 V	<p>a) Sensed fuel pump speed</p> <p>b) Device configuration FCBR_e_ChassisFuelPre sSysType</p> <p>c) Diagnostic KeFABR_b_GshtCktDiag Enbl</p> <p>d) CAN Sensor Bus message \$3EC_Avail</p> <p>e) Sensor Bus Relay On</p> <p>f) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]</p>	<p>a) == 0 RPM</p> <p>b) == CeFCBR_e_DSL_ECM_FTZM_BLDLDC_Sys</p> <p>c) == TRUE</p> <p>d) == TRUE</p> <p>e) == TRUE</p> <p>f) <> TRUE</p>	<p>40.00 failures / 80.00 samples</p> <p>1 sample / 12.5 ms</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Phase U-V- W Circuit High	P102B	<p>This DTC detects if the fuel pump control circuit is shorted to high voltage [Short to Battery]</p> <p>The diagnostic detects short-to-battery faults using 2 methods depending on whether the fuel pump is rotating. 1) In the "rotating" state, voltage drop across each phase-pair low-side current shunt is monitored, or 2) in the "stopped" state, small currents are injected</p>	Phased-pair circuit voltage Difference	Vdelta > 0.4 V	<p>a) Device configuration FCBR_e_ChassisFuelPre sSysType</p> <p>b) Diagnostic KeFABR_b_PshtCktDiag Enbl</p> <p>c) CAN Sensor Bus message \$3EC_Avail</p> <p>d) Sensor Bus Relay On</p> <p>e) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_A RC_ChkErr]</p>	<p>a) == CeFCBR_e_DSL_ECM_F TZM_BLDC_Sys</p> <p>b) == TRUE</p> <p>c) == TRUE</p> <p>d) == TRUE</p> <p>e) <> TRUE</p>	<p>40.00 failures / 80.00 samples</p> <p>1 sample / 12.5 ms</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>into each motor phase circuit pair by an internal fixed source and corresponding back-EMF voltage is monitored. A fault is reported when the monitored voltage falls into a specific range [adjusted for source voltage].</p> <p>The FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are active at any moment. Brushless fuel pump speed is inferred using the rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 milliseconds.</p> <p>This open circuit diagnostic follows "smart device" Component Technical Specifications.</p>	Phased-pair circuit voltage	V[backEMF] > 6 V	<p>a) Sensed fuel pump speed</p> <p>b) Device configuration FCBR_e_ChassisFuelPre sSysType</p> <p>b) Diagnostic KeFABR_b_PshtCktDiag Enbl</p> <p>c) CAN Sensor Bus message \$3EC_Avail</p> <p>d) Sensor Bus Relay On</p> <p>e) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]</p>	<p>a) == 0 RPM</p> <p>b) == CeFCBR_e_DSL_ECM_FTZM_BLDC_Sys</p> <p>b) == TRUE</p> <p>c) == TRUE</p> <p>d) == TRUE</p> <p>e) <> TRUE</p>	<p>40.00 failures / 80.00 samples</p> <p>1 sample / 12.5 ms</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor A / C Correlation (applications with LIN MAF)	P10BC	<p>Detects a performance failure in the Barometric Pressure (BARO) sensor, such as when a BARO value is stuck in range.</p> <p>With this monitor, the BARO sensor is compared to a redundant sensor called BARO C. If the BARO sensor value is not similar to the BARO C sensor value, then the BARO Sensor A/C Correlation diagnostic will fail.</p>	Difference between BARO A Sensor reading and BARO C Sensor reading	> 15.0 kPa	LIN Communications established with MAF		<p>160 failures out of 200 samples</p> <p>1 sample every 25 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Signal Message Counter Incorrect	P1100	This DTC monitors for an error in communication with the Fuel Pump Control Module (FTZM) Fuel Level Sensor 2 Signal Message Counter	Communication of the Fuel Level Sensor 2 Signal Message Counter from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for out of total samples	 >= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Inlet Airflow System Performance (naturally aspirated)	P1101	<p>Detects a performance failure in the Manifold Pressure (MAP) sensor, Throttle Position sensor (TPS) or Mass Air Flow (MAF) sensor that cannot be uniquely identified as a failure in one individual sensor. This diagnostic can set when more than one of these sensors has a performance concern.</p> <p>This diagnostic is performed using the Intake Flow Rationality Diagnostic (IFRD). IFRD calculates modeled values of sensors from these three sensors.</p> <p>These modeled values are compared against the actual sensor values to see if they are similar. If they are similar, then the model passes. If they are not similar, then that model is considered to be failed. Certain combinations of model passes and model failures can be interpreted to be caused by a performance issue with the system, but no</p>	<p>Filtered Throttle Model Error</p> <p>AND</p> <p>ABS(Measured Flow – Modeled Air Flow) Filtered</p> <p>OR</p> <p>ABS(Measured MAP – MAP Model 1) Filtered</p> <p>AND</p> <p>ABS(Measured MAP – MAP Model 2) Filtered</p>	<p>> 300 kPa*(g/s)</p> <p>> 25.0 grams/sec</p> <p>> 22.0 kPa)</p> <p>> 22.0 kPa</p>	<p>Engine Speed Engine Speed</p> <p>(Coolant Temp OR OBD Coolant Enable Criteria</p> <p>(Coolant Temp OR OBD Max Coolant Achieved</p> <p>Intake Air Temp Intake Air Temp</p> <p>Minimum total weight factor (all factors multiplied together)</p> <p>See Residual Weight Factor tables.</p>	<p>>= 400 RPM <= 5,400 RPM</p> <p>>= -9 Deg C</p> <p>= TRUE)</p> <p><= 130 Deg C</p> <p>= FALSE)</p> <p>>= -20 Deg C <= 129 Deg C</p> <p>>= 0.50</p> <p>Filtered Throttle Model Error multiplied by P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM</p> <p>Modeled Air Flow Error multiplied by P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM and P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est</p>	<p>Continuous</p> <p>Calculation are performed every 12.5 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		single failed sensor can uniquely be identified. In this case, the Inlet Airflow System Performance diagnostic will fail.			<p>No Active DTCs:</p> <p>No Pending DTCs:</p>	<p>MAP Model 1 Error multiplied by P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM</p> <p>MAP Model 2 Error multiplied by P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM</p> <p>MAP_SensorCircuitFA EGRValvePerformance_FA A MAF_SensorCircuitFA CrankSensor_FA ECT_Sensor_FA IAT_SensorFA</p> <p>EGRValve_FP ECT_Sensor_Ckt_FP IAT_SensorCircuitFP</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 1 Signal Message Counter Incorrect	P1200	This DTC monitors for an error in communication with the Fuel Pump Control Module (FTZM) Fuel Level Sensor 1 Signal Message Counter	Communication of the Fuel Level Sensor 1 Signal Message Counter from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for out of total samples	 >= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 low side circuit shorted to high side circuit	P1248	Controller specific output driver circuit diagnoses injector 1 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 low side circuit shorted to high side circuit	P1249	Controller specific output driver circuit diagnoses injector 2 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 low side circuit shorted to high side circuit	P124A	Controller specific output driver circuit diagnoses injector 3 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 low side circuit shorted to high side circuit	P124B	Controller specific output driver circuit diagnoses injector 4 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 low side circuit shorted to high side circuit	P124C	Controller specific output driver circuit diagnoses injector 5 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 low side circuit shorted to high side circuit	P124D	Controller specific output driver circuit diagnoses injector 6 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 low side circuit shorted to high side circuit	P124E	Controller specific output driver circuit diagnoses injector 7 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 low side circuit shorted to high side circuit	P124F	Controller specific output driver circuit diagnoses injector 8 high sided driver for a short to low sided driver failure when the output is powered on by comparing a voltage measurement to controller specific voltage threshold	Voltage measurement outside of controller specific acceptable range during driver on state indicates high sided driver for a short to low sided driver failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for high sided driver for a short to low sided driver failure.	25 amp >= through low side driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Over Temperature	P1255	To detect if an internal fuel pump driver over-temperature condition exists under normal operating conditions. The FTZM ERFs control may adjust the PWM slew rate or frequency as a self-protection method, but may not reduce pump rotational speed or impact pumping performance in any way due to an over-temperature condition.	Fuel Pump Driver Temperature	T > 160 degC	a) Diagnostic enabled [KeFABR_b_OvertempDiagEnbl] b) Sensor Bus Relay On c) CAN Sensor Bus message \$3EC_Available d) Sensor Bus Message \$3EC Temp Signal Message Counter Incorrect [CFMR_b_FTZM_Info7_ARC_ChkErr]	a) == TRUE b) == TRUE c) == TRUE d) <> TRUE	5.00 failures / 10.00 samples 1 sample / 100 millisec	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail High Pressure Sensor 2 Out of Range	P127C	<p>This DTC diagnose SENT high pressure sensor 2 that is too low out of range.</p> <p>If the sensor digital value (representing the reference voltage) is below the lower digital threshold, the low fail counter then increments. If the low fail counter reaches its threshold then a fail is reported. A pass is reported for this DTC if the low sample counter reaches its threshold.</p>	High Pressure Rail Sensor 2 SENT digital read value	=< 94			Time Based: 400 Failuer out of 500 Samples 6.25 ms per Sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure Sensor 1 Internal Performance	P128A	This DTC determines if there is internal error within the SENT pressure sensor 1 (i.e. Broken wire bond internal to the SENT Sensor). Once the internal error is detected a fixed faulted digital values is communicated to the ECU.	Digital pressure sesnor 1 value	>= 4,089	SENT Fuel Rail Pressure Sensor Internal Performance Enable No Fault Pending	Enabled when a code clear is not active or not exiting device control True P16E4 P16E5 P128F	400 failures out of 500 samples 6.25 ms per Sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure Sensor 2 Internal Performance	P128B	This DTC determines if there is internal error within the SENT pressure sensor 2 (i.e. Broken wire bond internal to the SENT Sensor). Once the internal error is detected a fixed faulted digital values is communicated to the ECU.	Digital pressure sesnor 2 value	>= 4,089	SENT Fuel Rail Pressure Sensor Internal Performance Enable No Fault Pending	Enabled when a code clear is not active or not exiting device control True P16E4 P16E5 P128F	400 failures out of 500 samples 6.25 ms per Sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure & Temperature Sensor Pressure Message Incorrect	P128F	This DTC determines if there is any SENT signal waveform for discrepancies (i.e. too many pulse, too few pulse, clock shift). The SENT HWIO Determines message waveform fault (i.e.too many pulse, too few pulse, clock shift) and if the message age is too long.	SENT HWIO Determines message fault (i.e.too many pulse, too few pulse, clock shift) Message Age	= true > 1.69 ms	SENT signal Serial waveform diagnostics enable SENT power up delay No Fault Active on	True >= 0.00 seconds Enabled when a code clear is not active or not exiting device control P16E4 P16E5	400 failures out of 500 samples 6.25 ms per sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit Low (Only on applications that use an FTZM)	P129D	Detects low voltage of the fuel pump driver control module ignition switch circuit. This diagnostic reports the DTC when the fuel pump driver control module ignition switch circuit voltage is below a calibrated value.	Fuel Pump Driver Control Module Ignition switch Run/Start position circuit low	FTZM Run Crank Active is FALSE	Fuel Tank Zone Module (FTZM) is present on vehicle Fuel Pump Driver Control Module Ignition Switch Run/Start Position Circuit High diagnostic is enabled Fuel Tank Zone Module (FTZM) serial messages are available Run Crank Active Sensor Bus relay is commanded ON	= 1 = TRUE	40 failures out of 50 samples 50 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Fuel Pump Speed Signal Incorrect	P129F	FTZM ERFS control samples back-Electromotive Force [EMF] for zero voltage-level crossings as a detection method to enable closed loop control brushless commutation. Back EMF is an electrical characteristic of the inactive phase of the 3-phase signal wherein only 2 phases are active at any moment. Brushless pump speed is inferred using rate of zero-crossings detection and number of motor pole-pairs. Speed is reported to the ECM as serial data every 10 millisecons. Diagnostic software [FABR ring] calculates the error between the commanded, arbitrated fuel pump speed [FCBR ring] and the FTZM sensed fuel pump speed. The error is filtered and evaluated against calibratable threshold limits to determine pass/fail status. Any failure that exists on the fuel pump output circuit (3 phases) will be manifested in a Fuel Pump Speed	Sensed Filtered Fuel Pump Speed Error	> Speed Error Low Threshold [Supporting Table] P129F Threshold Low OR < Speed Error High Threshold [Supporting Table] P129F Threshold High	a) Diagnostic Enabled FABR Speed Rationality Diagnostic b) CAN Sensor Bus message \$0CB_Available c) FABR Fuel Control Enable Fault Active d) Fuel Pmp Speed Command Alive Rolling Count and Checksum Error [CAN Bus B \$0CE] [CFMR_b_FTZM_Cmd1_ARC_ChkErr] e) FABR Fuel Pump Ckt FA f) FABR Driver OverTemp FA g) Run_Crank input Voltage h) Sensor Bus Relay On j) CAN Sensor Bus message \$0CB Data Fault [CFMR_b_FTZM_Info8_ARC_ChkErr] k) CAN Sensor Bus message \$0CB Comm Fault [CFMR_b_FTZM_Info8_UcodeCmFA] l) Fuel Pmp Spd Command ARC and Checksum Comm Fault Code [CFMR_b_FTZM_Cmd1_UcodeCmFA] m) Timer - FABR Rising Edge Diagnostic Delay n) Timer - FABR Falling Edge Diagn Delay	a) == TRUE b) == TRUE c) <> TRUE d) <> TRUE e) <> TRUE f) <> TRUE g) > 9.00 volts h) == TRUE j) <> TRUE k) <> TRUE l) <> TRUE m) > 2.20 seconds n) > 1.00 seconds	1 sample / 12.5 msec	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		Rationality Diagnostic fault. Reported fuel pump speed data will only be consumed in this same diagnostic.						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Driver Control Module Enable Circuit Performance	P12A6	The purpose of the Fuel Pump Driver Control Module Enable Circuit Performance diagnostic is to detect if the state of the fuel control enable circuit is valid. This is done by comparing the fuel control enable circuit state [high or low] sensed by the Fuel Tank Zone Module device to the commanded state of the fuel control enable signal from the ECM [in serial data]. When the sensed state does not match the commanded state, the fail counter increments.	Sensed Fuel Control Enable circuit state [Fuel Tank Zone Module device]	<> Fuel Control Enable Active command [serial data]	a) Diagnostic enabled [KeFABR_b_FuelCntrlEnb DiagEnb] b) Sensor Bus message \$0CC Fuel Pump Command Message Signal Counter Incorrect [CFMR_b_FTZM_Info2_ARC_ChkErr] c) CAN Sensor Bus message \$0CC_Available d) Sensor Bus Relay On e) Timer [FABR_t_RunCrankActive]	a) == TRUE b) <> TRUE c) == TRUE d) == TRUE e) >= 0.51 seconds	40.00 failures / 80.00 samples 1 sample / 12.5 millisec	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump Control Module (Fuel Tank Zone Module) Control Signal Message Counter Incorrect	P12A8	This DTC monitors for an error in communication with the Fuel Pump Control Module (FTZM) Control Signal Message	Communication of the Alive Rolling Count or Protection Value from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for out of total samples	 >= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Coil Positive Voltage Circuit Group 1 * * SIDI ONLY * *	P135A	This diagnostic checks for minimum voltage at the fuse which supplies power to the Ignition Coils (applicable only for SIDI applications). A diagnostic failure indicates a blown fuse.	Ignition Module Supply Voltage.	< 2.5 Volts	Diagnostic Enabled? Three possible Ignition Coil Power Sources (only 1 used): Ignition Coil Power Source = <u>Case 1: Battery</u> Delay starting at Key-On <u>Case 2: Ignition Run/ Crank</u> Ignition Run/Crank Voltage <u>Case 3: PT Relay</u> PT Relay Voltage	Yes PT Relay 5 Engine Revs > 5.0 volts > 11.0 volts	50 Failures out of 63 Samples 6.25 msec rate	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Coil Positive Voltage Circuit Group 2 * * SIDI ONLY * *	P135B	This diagnostic checks for minimum voltage at the fuse which supplies power to the Ignition Coils (applicable only for SIDI applications). A diagnostic failure indicates a blown fuse.	Ignition Module Supply Voltage.	< 2.5 Volts	Diagnostic Enabled? Three possible Ignition Coil Power Sources (only 1 used): Ignition Coil Power Source =	Yes PT Relay	50 Failures out of 63 Samples 6.25 msec rate	Type: Type A, 1 Trips
					<u>Case 1: Battery</u> Delay starting at Key-On	5 Engine Revs		
					<u>Case 2: Ignition Run/Crank</u> Ignition Run/Crank Voltage	> 5.0 volts		
					<u>Case 3: PT Relay</u> PT Relay Voltage	> 11.0 volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cold Start Emissions Reduction System Fault	P1400	Model based test computes power from exhaust flow and thermal energy resulting from elevated idle speed and retarded spark advance. Detects if the cold start emission reduction system has failed resulting in the delivered power being out of range.	<p>Average desired accumulated exhaust power - Average actual accumulated exhaust power (too much energy delivered to catalyst)</p> <p>Average desired accumulated exhaust power - Average actual accumulated exhaust power (too little energy delivered to catalyst)</p> <p>(EWMA filtered)</p> <p>Average Power = output of P1400_EngineSpeedResidual_Table * output of P1400_SparkResidual_Table NOTE: Desired accumulated power would use the desired catalyst light off spark and desired engine speed and the actual accumulated power would use the final commanded spark and actual engine speed. Refer to the Supporting Tables for details</p>	<p>< -32.00 KJ/s (high RPM failure mode)</p> <p>> 4.50 KJ/s (low RPM failure mode)</p>	<p>Cold Start Emission Reduction Strategy Diagnostic is Enabled</p> <p>To enable the diagnostic, the Cold Start Emission Reduction Strategy must be Active per the following:</p> <p>Catalyst Temperature AND Engine Coolant AND Engine Coolant AND Barometric Pressure</p> <p>The Cold Start Emission Reduction strategy must not be exiting. The strategy will exit per the following:</p> <p>Catalyst Temperature AND Engine Run Time</p> <p>OR</p> <p>Engine Run Time</p> <p>OR</p>	<p>< 550.00 degC > 6.00 degC <= 66.00 degC >= 72.00 KPa</p> <p>>= 800.00 degC >= 1.00 seconds</p> <p>> P050D_P1400_CatalystLightOffExtendedEngineRunTimeExit</p> <p>This Extended Engine run time exit is a function of percent ethanol and Catmons NormRatioEWMA. Refer to "Supporting Tables" for</p>	<p>Runs once per trip when the cold start emission reduction strategy is active</p> <p>Frequency: 100ms Loop</p> <p>Test completes after 10 seconds of accumulated qualified data.</p>	EWMA Based - Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
						<p>details.</p> <p>Barometric Pressure < 72.00 KPa</p> <p>Other Enable Criteria:</p> <p>OBD Manufacturer Enable Counter 0</p> <p>Vehicle Speed < 1.24 MPH</p> <p>Allow diagnostic to calculate residual in an off-idle state. If the value of the OffIdleEnable is equal to 1 then the "DriverOffAccelPedal" will not be checked. However, if the value of OffIdleEnable is 0 then driver must be off the accel pedal</p> <p>0 (A value of 1 allows diagnostic to run and calculate the residual while off idle. A value of 0 requires calculation of the residual at idle)</p> <p>A change in throttle position (tip-in/tip-out) will initiate a delay in the calculation of the average qualified residual value. Therefore when the:</p> <p>Pedal Close Delay Timer > 2.00 seconds</p> <p>the diagnostic will continue the calculation.</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>A change in gear will initiate a delay in the calculation of the average qualified residual value to allow time for the actual engine speed and actual final commanded spark to achieve their desired values. Therefore, when the:</p> <p>Gear Shift Delay Timer</p> <p>the diagnostic will continue the calculation</p> <p>For Manual Transmission vehicles:</p> <p>Clutch Pedal Position</p> <p>Clutch Pedal Position</p> <p>The diagnostic will delay calculation of the residual value and potentially weight the residual calculation differently based on engine run time. This is to ensure the diagnostic is operating in idle speed control as well as during the peak catalyst light off period.</p> <p>The time weighting factor must be :</p>	<p>> 2.00 seconds</p> <p>> 12.00 %</p> <p>< 75.00 %</p> <p>> 0 These are scalar values</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>General Enable:</p> <p>DTC's Not Set:</p>	<p>that are a function of engine run time. Refer to P1400_ColdStartDiagnosticDelayBasedOnEngineRunTime and the cal axis, P1400_ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis in the "Supporting Tables" for details.</p> <p>AcceleratorPedalFailure ECT_Sensor_FA IAT_SensorCircuitFA MnfdTempSensorCktFP CrankSensor_FA FuelInjectorCircuit_FA MAF_SensorFA MAP_SensorFA EngineMisfireDetected_FA ClutchPstnSnsr FA IAC_SystemRPM_FA IgnitionOutputDriver_FA TPS_FA VehicleSpeedSensor_FA 5VoltReferenceMAP_OOR_Fit TransmissionEngagedState_FA EngineTorqueEstInaccurate</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor A Reference Feedback Range/ Performance [For use on vehicles with FTZM]	P1434	This DTC will detect a fault in Primary fuel tank level sensor 5V reference by comparing DEC ECU commanded signal period and pulse width values against measured period and pulse width reported by the smart device	Reference Voltage 0 Period Error Maximum [Measured Ref V Period - Commanded Ref V Period]	> 25.00 millise	a) CAN serial data available [\$2D7] b) Calibration - Reference Voltage Command Source c) Timer - Reference Voltage Pulse Width Available Synchronization d) Timer - Reference Voltage Period Available Delay e) Diagnostic System Disabled f) FTZM Serial Data Info4 Rolling Counter Check Error g) Reference Voltage Performance 0 Diagnostic Enabled	a) == True b) == ECM c) > 1.25 sec d) > 0.75 sec e) <> True f) <> True g) == TRUE	250 ms / sample	Type B, 2 Trips
			Reference Voltage 0 Pulse Width Error Maximum [Measured Ref V PW - Commanded Ref V PW]	> 1.50 millise	a) CAN serial data available [\$2D7] b) Calibration - Reference Voltage Command Source c) Timer - Reference Voltage Pulse Width Available Synchronization d) Timer - Reference Voltage Period Available Delay e) Diagnostic System Disabled	a) == True b) == ECM c) > 1.25 sec d) > 0.75 sec e) <> True	250 ms / sample 16 Failures / 20 Samples	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					f] FTZM Serial Data Info4 Rolling Counter Check Error g] Reference Voltage Performance 0 Diagnostic Enabled	f] <> True g] == TRUE		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor B Reference Feedback Range/ Performance [For use on vehicles with FTZM and Secondary Fuel Tank]	P143E	This DTC will detect a fault in Secondary fuel tank level sensor 5V reference by comparing DEC ECU commanded signal period and pulse width values against measured period and pulse width reported by the smart device	Reference Voltage 1 Period Error Maximum [Measured Ref V Period - Commanded Ref V Period]	> 25.00 millisecc	a) CAN serial data available [\$2D7] b) Calibration - Reference Voltage Command Source c) Timer - Reference Voltage Pulse Width Available Synchronization d) Timer - Reference Voltage Period Available Delay e) Diagnostic System Disabled f) FTZM Serial Data Info4 Rolling Counter Check Error g) Reference Voltage Performance 1 Diagnostic Enabled	a) == True b) == ECM c) > 1.25 sec d) > 0.75 sec e) <> True f) <> True g) == TRUE	250 ms / sample 16 Failures / 20 Samples	Type B, 2 Trips
			Reference Voltage 1 Pulse Width Error Maximum [Measured Ref V PW - Commanded Ref V PW]	> 1.50 millisecc	a) CAN serial data available [\$2D7] b) Calibration - Reference Voltage Command Source c) Timer - Reference Voltage Pulse Width Available Synchronization d) Timer - Reference Voltage Period Available Delay e) Diagnostic System Disabled	a) == True b) == ECM c) > 1.25 sec d) > 0.75 sec e) <> True	250 ms / sample 16 Failures / 20 Samples	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					f] FTZM Serial Data Info4 Rolling Counter Check Error g] Reference Voltage Performance 1 Diagnostic Enabled	f] <> True g] == TRUE		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Mass Air Flow Sensor A Signal Message Counter Incorrect	P14B6	This DTC monitors for an error in communication with the Mass Air Flow Sensor A	Communication of the Alive Rolling Count Press_2B_C03 from the Mass Air Flow Sensor A over LIN bus is incorrect for out of total samples Or Communication of the Alive Rolling Count TmpHum_2A_C03 from the Mass Air Flow Sensor A over LIN bus is incorrect for out of total samples	>= 8.00 counts >= 10.00 counts >= 8.00 counts >= 10.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	LIN bus communication executes in 500ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Engine Speed Request Circuit	P150C	This DTC monitors for an error in communication with the Transmission Engine Speed Request signal in 1D	Communication of the Alive Rolling Count or Protection Value in the Transmission Engine Speed signal over CAN bus is incorrect for out of total samples	 >= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 25ms loop.	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Communication Error with Active Grill Air Shutter Module "A"	P151E	This DTC monitors for an internal error or error in communication with the Active Grill Air Shutter Module A	Communication of the Alive Rolling Count from the Shutter Module over LIN bus is incorrect or the Shutter Module signals it has an internal error for out of total samples	 >= 8.00 counts >= 10.00 counts	All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	>= 3,000.00 seconds = Run >= 11.00 Volts >= 11.00 Volts	LIN bus communication executes in 500ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Communication Error with Active Grill Air Shutter Module "B"	P151F	This DTC monitors for an internal error or error in communication with the Active Grill Air Shutter Module B	Communication of the Alive Rolling Count from the Shutter Module over LIN bus is incorrect or the Shutter Module signals it has an internal error for out of total samples	 >= 8.00 counts >= 10.00 counts	All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	>= 3,000.00 seconds = Run >= 11.00 Volts >= 11.00 Volts	LIN bus communication executes in 500ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Switch State Undertermin ed	P155A	<p>Detects when cruise switch state cannot be determined, such as low voltage conditions</p> <p>"Emissions Neutral Default Action : When the BCM tells the ECM that the cruise switch "Data Invalid" (latched on/off switch architectures) or "Indeterminate" (momentary on/off switch architectures) is detected for too long, ECM sets the code and cruise control will be disabled and disengaged for the remainder of the key cycle regardless of current pass/fail condition once it fails."</p>	cruise switch state is received as "undetermined" for greater than a calibratable time	fail continuously for greater than 0.5 seconds			fail continuously for greater than 0.5 seconds	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Cruise Control Calibration Incorrect	P158A	Type of cruise in Body Control Module does not match that in the Engine Control Module for 2.5 seconds "Emissions Neutral Default Action : This diagnostic compares the BCM and the ECM configuration calibrations of whether No Cruise, Conventional Cruise Control, or ACC is available on the vehicle. If the calibration for the cruise system type in the ECM does not match the value in \$4E9 signal Vehicle Speed Control System Type, a P158A DTC is set and cruise control is disabled."	Type of cruise system in GMLAN \$4E9 does not match with that in the Engine Control Module for a fix time.	2.5 seconds	DID \$40 from BCM says cruise system is present (ECM receives programmable information from Body Control Module) OR ECM will not receive Programmable information for Cruise from Body Control Module	True	fail continuously for greater than 2.5 seconds.	Type C, No SVS "Emissions Neutral Diagnostics – Special Type C"

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Analog Mode Switch Circuit High	P15A0	This DTC will detect an analog driver mode switch input that is too high out of range.	For button type Normal_Button Analog Mode Switch high voltage threshold % of 5V range For button type Enhanced_Button Analog Mode Switch high voltage threshold % of 5V range For button type Multiple_Button Analog Mode Switch high voltage threshold % of 5V range	 >= 88.80 % >= 94.10 % >= 95.30 %	Vehicle mode analog switch button type	= CeDMDG_e_Seven_Butt ons	200 failures out of 250 samples 25 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Analog Mode Switch Performance	P15A1	This DTC will detect an analog driver mode switch input that is in an indeterminate range.	<p>For button type Normal_Button</p> <p>Analog Mode Switch indeterminate region % of 5V range</p> <p>For button type Enhanced_Button</p> <p>Analog Mode Switch indeterminate regions % of 5V range</p> <p>For button type Multiple_Button</p> <p>Analog Mode Switch indeterminate regions % of 5V range</p>	<p>66.80 % ≤ % of 5 volts < 72.80 %</p> <p>63.50 % ≤ % of 5 volts < 65.50 %</p> <p>83.50 % ≤ % of 5 volts < 85.50 %</p> <p>52.90 % ≤ % of 5 volts < 54.10 %</p> <p>74.10 % ≤ % of 5 volts < 75.30 %</p> <p>87.50 % ≤ % of 5 volts < 88.60 %</p>	Vehicle mode analog switch button type	= CeDMDG_e_Seven_Butt ons	<p>200 failures out of 250 samples</p> <p>25 ms / sample</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Ignition voltage out of correlation error(P1682) not active and Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -12.0 degC -12 <= Temp degC <= 132		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Battery Voltage Signal Message Counter Incorrect	P167F	This DTC monitors for an error in the FTZM Battery Voltage Signal Message Counter	Communication of the Alive Rolling Count or Protection Value from the Fuel Pump Control Module (FTZM) over CAN bus is incorrect for out of total samples	 >= 8 counts >= 10 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage Sensor Bus Relay	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts = On (if present)	Executes in 10ms loop.	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation	P1682	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage and the Powertrain Relay Ignition Voltage. The diagnostic monitors the difference in voltage between Run/Crank Voltage and the Powertrain Relay Ignition Voltage and fails the diagnostic when the voltage difference is too high. This diagnostic only runs when the powertrain is commanded on and the Run/Crank Voltage is greater than a threshold based on IAT or the powertrain ignition voltage is high enough the Run/Crank voltage is high enough.	Run/Crank – PT Relay Ignition >	3.00 Volts		Powertrain Relay commanded on AND (Run/Crank voltage > Table, f(IAT). See supporting tables: P1682_PT Relay Pull-in Run/Crank Voltage f(IAT) OR PT Relay Ignition voltage > 5.50 Volts) AND Run/Crank voltage > 5.50 Volts	240 / 480 counts; or 0.175 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit Low (Gasoline applications ONLY)	P16A0	Detects a continuous or intermittent short low or open fault in the TPS SENT Communication Circuit by monitoring the voltage and failing the diagnostic when the voltage for the wave pulse is below state threshold as defined by SAE J2716 SENT Protocol. This diagnostic only runs when battery voltage is high enough.	Voltage for wave pulse is below state threshold as defined by SAE J2716 SENT Protocol	0.5 V	Run/Crank voltage	> 6.41 Volts	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit High (Gasoline applications ONLY)	P16A1	Detects a continuous or intermittent short high fault in the TPS SENT Communication Circuit by monitoring the voltage and failing the diagnostic when the voltage for the wave pulse is above state threshold as defined by SAE J2716 SENT Protocol. This diagnostic only runs when battery voltage is high enough. Detects a High Circuit Fault in the TPS SENT Communication Circuit	Voltage for wave pulse is above state threshold as defined by SAE J2716 SENT Protocol	4.1 V	Run/Crank voltage	> 6.41 Volts	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
TPS SENT Comm Circuit Performance (Gasoline applications ONLY)	P16A2	Detects a message fault in the TPS SENT Communication Circuit by monitoring the message pulse time and failing the diagnostic when the time for the pulse is above a low time threshold or above a high time threshold or if the message age limit is greater than a time threshold. This diagnostic only runs when battery voltage is high enough. Detects a Message Fault in the TPS SENT Communication Circuit	Message Pulse < Message Pulse > or Message Age Limit >= or Signal CRC fails	0.125977 ms 0.209991 ms 3.125 ms	Run/Crank voltage	> 6.41 Volts	79 / 159 counts; 57 counts continuous; 3.125 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Ignition Voltage Correlation #2	P16A7	Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage and the Powertrain Relay Ignition Voltage #2. The diagnostic monitors the difference in voltage between Run/Crank Voltage and the Powertrain Relay Ignition Voltage and fails the diagnostic when the voltage difference is too high. This diagnostic only runs when the powertrain is commanded on and the Run/Crank Voltage is greater than a threshold based on IAT or the powertrain ignition voltage is high enough the Run/Crank voltage is high enough. Detect a continuous or intermittent out of correlation between the Run/Crank Ignition Voltage & the Powertrain Relay Ignition Voltage #2.	Run/Crank – PT Relay Ignition >	3.00 Volts		Powertrain commanded on AND (Run/Crank voltage > Table, f(IAT). See supporting tables: P1682_PT Relay Pull-in Run/Crank Voltage f(IAT) OR PT Relay Ignition voltage > 5.50 Volts) AND Run/Crank voltage > 5.50 Volts	240 / 480 counts; or 0.175 sec continuous; 12.5 ms/count in main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Controls Ignition Relay Feedback Circuit 2 Low Voltage - (GEN III Controllers ONLY)	P16AF	Detects low voltage in the engine controls ignition relay feedback circuit 2. This diagnostic reports the DTC when low voltage is present. Monitoring occurs when run crank voltage is above a calibrated value.	Engine controls ignition relay feedback circuit 2 low voltage	Relay voltage <= 5.00	Powertrain relay low diag enable Powertrain relay voltage Run Crank voltage Powertrain relay state	= 1.00 >= 11.00 > 9.00 = ON	5 failures out of 6 samples 1000 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Controls Ignition Relay Feedback Circuit 2 High Voltage - (GEN III Controllers ONLY)	P16B3	Detects high voltage in the engine controls ignition relay feedback circuit 2. This diagnostic reports the DTC when high voltage is present. Monitoring occurs when the relay state is inactive.	Engine controls ignition relay feedback circuit 2 high voltage	Relay voltage >= 4.00	Powertrain relay high diag enable Powertrain relay state	= 1.00 = INACTIVE	50 failures out of 63 samples 100 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Bus Relay Control Circuit Open	P16D7	Detects an open circuit in the sensor bus relay circuit. This diagnostic reports the DTC when an open circuit is present. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver off state indicates open circuit failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for an open circuit.	Open Circuit: ≥ 200 K Ω ohms impedance between output and controller ground	Run/Crank Voltage	Voltage ≥ 11.00 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controlle rs P16D8 may also set (Sensor Bus Relay Control Circuit Low).

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Bus Relay Control Circuit Low	P16D8	Detects a short to ground in the sensor bus relay circuit. This diagnostic reports the DTC when a short to ground is present. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	Short to ground: ≤ 0.5 Ω impedance between output and controller ground	Run/Crank Voltage	Voltage ≥ 11.00 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips Note: In certain controllers P16D7 may also set (Sensor Bus Relay Control Circuit Open).

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Sensor Bus Relay Control Circuit High	P16D9	Detects a short to power in the sensor bus relay circuit. This diagnostic reports the DTC when a short to power is present. A decision is made by comparing a voltage measurement to a controller specific voltage threshold.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	Short to power: ≤ 0.5 Ω impedance between output and controller power	Run/Crank Voltage	Voltage ≥ 11.00 volts	8 failures out of 10 samples 250 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure & Temperature Sensor Communicati on Circuit 3 Low Voltage	P16E4	This DTC determines if the SENT signal shorted low, this is determined by monitoring the number pulses on the SENT signal line received at the ECU and the SENT Signal Line State always indicating low.	The number pulses on the SENT signal line SENT Signal Line State	<= 5 = Low	SENT Sensor Communication Circuit Diagnostic Enabled SENT power up delay	True >= 0.00 seconds Enabled when a code clear is not active or not exiting device control	400 failures out of 500 samples 6.25 ms per sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SENT Fuel Rail Pressure & Temperature Sensor Communicati on Circuit 3 High Voltage	P16E5	This DTC determines if the SENT signal shorted low, this is determined by monitoring the number pulses on the SENT signal line received at the ECU and the SENT Signal Line State always indicating high.	The number pulses on the SENT signal line SENT Signal Line State	<= 5 = High	SENT Sensor Communication Circuit Diagnostic Enabled SENT power up delay	True >= 0.00 seconds Enabled when a code clear is not active or not exiting device control	400 failures out of 500 samples 6.25 ms per sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module Redundant Memory Performance (Gasoline applications ONLY)	P16F3	Detect Processor Calculation faults due to RAM corruptions, ALU failures and ROM failures For all of the following cases: If the individual diagnostic threshold is equal to 2048 ms, this individual case is not applicable. If any of the following cases are X out of Y diagnostics and the fail (x) is greater than the sample (Y), this individual case is also not applicable.	Equivalence Ratio torque compensation exceeds threshold	-100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	Type A, 1 Trips
			Absolute difference between Equivalence Ratio torque compensation and its dual store out of bounds given by threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of Accessory torque and its redundant calculation is out of bounds given by threshold range	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of Filtered Air-per-cylinder and its redundant calculation is out of bounds given by threshold range	36.19 mg	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference between the previous Final Advance and the current Final Advance not Adjusted for Equivalence Ratio is out of bounds given by threshold range	15.00 degrees		Engine speed >0rpm	Up/down timer 432 ms continuous, 0.5 down time multiplier	
			Torque Learn offset is out of bounds given by threshold range	High Threshold 0.00 Nm Low Threshold 0.00	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Nm				
			One step ahead calculation of air-per-cylinder and two step ahead is greater than threshold	80.00 mg		Engine speed > 570 rpm	Up/down timer 459 ms continuous, 0.5 down time multiplier	
			Difference between Unmanaged Spark and PACS Spark is greater than threshold	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Zero pedal axle torque is out of bounds given by threshold range	High Threshold 1,503.00 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Creep Coast Axle Torque is out of bounds given by threshold range	High Threshold 1,503.00 Nm Low Threshold -65,535.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of Friction torque and its redundant calculation is out of bounds given by threshold range	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Arbitrated Air-Per-Cylinder filter coefficient is out of bounds given by threshold range	High Threshold 1.000 Low Threshold 0.074	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Launch spark is active but the launch spark redundant path indicates it should not be active	N/A		Engine speed < 7,900.00 or 8,000.00 rpm (hysteresis pair)	Up/down timer 159 ms continuous, 0.5 down time multiplier	
			Rate limited vehicle speed and its dual store do not equal	N/A		Time since first CAN message with vehicle speed >= 0.500 sec	10 / 20 counts; 25.0msec/count	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Commanded engine torque due to fast actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded engine torque due to slow actuators and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			TOS to wheel speed conversion factor is out of bounds given by threshold range	High Threshold: 1.10 T/C Range Hi 0.10 T/C Range Lo Low Threshold: 1.10 T/C Range Hi 0.10 T/C Range Lo	Ignition State	Accessory, run or crank	255 / 6 counts; 25.0msec/count	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Cylinders active greater than commanded	2 cylinders		Engine run flag = TRUE > 2.00 s Number of cylinder events since engine run > 24 No fuel injector faults active	Up/down timer 459 ms continuous, 0.5 down time multiplier	
			Transfer case neutral request from four wheel drive logic does not match with operating conditions	N/A	Ignition State	Accessory, run or crank Transfer case range valid and not over-ridden FWD Apps only	7.00 / 10.00 counts; 25.0msec/count	
			Driver progression mode and its dual store do not equal	N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier	
			Predicted torque for uncorrected zero pedal determination is greater than calculated limit.	Table, f(Engine, Oil Temp). P16F3_Speed Control External Load f(Oil Temp, RPM) + 100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Predicted Request Without Motor is greater than its redundant calculation plus threshold	99.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Immediate Request Without Motor is greater than its redundant calculation plus threshold	99.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							down time multiplier	
			Positive Torque Offset is greater than its redundant calculation plus threshold OR Positive Torque Offset is less than its redundant calculation minus threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Commanded Predicted Engine Request is greater than its redundant calculation plus threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, down time	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							multiplier 0.5	
			Commanded Hybrid Predicted Crankshaft Request is greater than its redundant calculation plus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Hybrid Immediate Crankshaft Request is less than its redundant calculation minus threshold	4,096.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Regeneration Brake Assist is not within a specified range	Brake Regen Assist < 0 Nm or Brake Regen Assist > 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Cylinder Spark Delta Correction exceeds the absolute difference as compared to Unadjusted Cylinder Spark Delta	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			1. Cylinder Torque Offset exceeds step size threshold	1. 100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			OR					

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			2. Sum of Cylinder Torque Offset exceeds sum threshold	2. 100.00 Nm				
			Engine Capacity Minimum Immediate Without Motor is greater than its dual store plus threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Engine Capacity Minimum Engine Off is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Capacity Minimum Engine Immediate Without Motor is greater than threshold	0 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Engine Request is greater than its redundant calculation plus threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 159 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Speed Lores Intake Firing timing (event based) calculation does not equal its redundant calculation	N/A		Engine speed greater than 0rpm	Up/down timer 159 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque request exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: P16F3_Speed Control External Load f(Oil Temp, RPM) + 100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Idle speed control calculated predicted minimum torque without reserves exceeds calculated torque limit	Table, f(Oil Temp, RPM). See supporting tables: P16F3_Speed Control External Load f(Oil Temp, RPM) +	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				100.00 Nm				
			Difference between Driver Requested Immediate Torque primary path and its secondary exceeds threshold	1,503.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Driver Immediate Request is less than its redundant calculation minus threshold	1,503.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded Immediate Request is greater than its redundant calculation plus threshold	1,503.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			OR Commanded Immediate Request is less than its redundant calculation minus threshold				multiplier	
			Commanded Immediate Response Type is set to Inactive	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Difference between Cruise Axle Torque Arbitrated Request and Cruise Axle Torque Request exceeds threshold	56.36 Nm		Cruise has been engaged for more than 4.00 seconds	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired engine torque request greater than redundant calculation plus threshold	99.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Engine min capacity above threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 74 ms continuous, 0.5 down time multiplier	
			No fast unmanaged retarded spark above the applied spark plus the threshold	15.00 Degree		Engine speed greater than 0rpm	Up/down timer 432 ms continuous, 0.5 down time multiplier	
			Absolute difference of adjustment factor based on temperature and its dual store above threshold	2.76 m/s	Ignition State	Accessory, run or crank	Up/down timer 103 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			1. Absolute difference of redundant calculated engine speed above threshold	500 RPM		Engine speed greater than 0 RPM	Up/down timer 159 ms continuous, 0.5 down time multiplier	
			After throttle blade pressure and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Speed Control's Predicted Torque Request and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine oil temperature and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 247 ms continuous, 0.5 down time multiplier	
			Desired throttle position greater than redundant calculation plus threshold	8.41 percent	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the rate limited pre-throttle pressure and its redundant calculation greater than threshold	0.06 kpa	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Throttle desired torque above desired torque plus threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Desired filtered throttle torque exceeds the threshold plus the higher of desired throttle torque or modeled throttle torque	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque feedback proportional term is out of allowable range or its dual store copy does not match	High Threshold 50.00 Nm Low Threshold -50.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Torque feedback integral term magnitude or rate of change is out of allowable range or its dual store	High Threshold 93.75 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			copy do not match	Low Threshold -100.00 Nm Rate of change threshold 6.25 Nm/loop			down time multiplier	
			Difference of Final Torque feedback proportional plus integral term and its redundant calculation is out of bounds given by threshold range	High Threshold 100.00 Nm Low Threshold - 100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of torque desired throttle area and	High Threshold	Ignition State	Accessory, run or crank	Up/down timer 475	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			its redundant calculation is out of bounds given by threshold range	3.40 % Low Threshold - 3.40 %			ms continuous, 0.5 down time multiplier	
			Difference of torque model coefficients and its redundant calculation is out of bounds given by threshold range	High Threshold 0.0001046 Low Threshold - 0.0001046	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference of base friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 100.00 Nm Low Threshold - 100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Accessory drive friction torque is out of bounds given by threshold range	High Threshold 100.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			AC friction torque is greater than commanded by AC control software or less than threshold limit	High Threshold 40.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Difference of Oil temperature delta friction torque and its redundant calculation is out of bounds given by threshold range	High Threshold 100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				Low Threshold - 100.00 Nm				
			Generator friction torque is out of bounds given by threshold range	High Threshold 100.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between the Supercharger friction torque and its redundant calculation greater than threshold	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Filtered Torque error magnitude or its increase rate of change is out of	High Threshold 100.00		Engine speed >0rpm MAF, MAP and Baro DTCs are false	Up/down timer 475 ms continuous.	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			allowable range or its dual store copy do not match	Nm Low Threshold -100.00 Nm Rate of change threshold 6.25 Nm/loop			0.5 down time multiplier	
			Torque error compensation is out of bounds given by threshold range	High Threshold 100.00 Nm Low Threshold 0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Delta Torque Baro compensation is out of bounds given by threshold	High Threshold 13.14	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous,	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			range	Nm Low Threshold -19.80 Nm			0.5 down time multiplier	
			1. Difference of reserve torque value and its redundant calculation exceed threshold OR 2. Reserve request does not agree with operating conditions or Difference of final predicted torque and its redundant calculation exceed threshold OR 3. Rate of change of reserve torque exceeds threshold, increasing direction only OR 4. Reserve engine torque above allowable capacity threshold	1. 99.00 Nm 2. N/A 3. 99.00 Nm 4. 99.00 Nm	3. & 4.: Ignition State	1. & 2.: Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 100.00 Nm 3. & 4.: Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Engine Vacuum and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated Intake Manifold Pressure during engine event versus during time event is greater than threshold	Table, f(Desired Engine Torque). See supporting tables: P16F3_Delta MAP Threshold f(Desired Engine Torque)		Engine speed >0rpm	Up/down timer 159 ms continuous, 0.5 down time multiplier	
			Min. Axle Torque Capacity is greater than threshold	0.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Driver Predicted Request is greater than its redundant calculation plus threshold OR	1,503.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Driver Predicted Request is less than its redundant calculation minus threshold					
			Cold Delta Friction Torque and its dual store do not match	N/A	Ignition State	Accessory, run or crank	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Predicted torque for zero pedal determination is greater than calculated limit.	Table, f(Oil Temp, RPM). See supporting tables: Speed Control External Load f(Oil Temp, RPM) + 100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Commanded Predicted	1 Nm	Ignition State	Accessory, run or crank	Up/down timer	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Axle Torque and its dual store do not match				475 ms continuous, 0.5 down time multiplier	
			Steady State Estimated Engine Torque and its dual store are not equal	N/A		AFM not changing from Active to Inactive and preload torque not changing and one loop after React command Engine speed >0rpm	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Difference of Weighting factor for number of cylinders fueled and its redundant calculation is above threshold	0.26		Engine run flag = TRUE > 10.00 s	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Difference of minimum spark advance limit and its redundant calculation is out of bounds given by threshold range	15.00 degrees	Ignition State	Accessory, run or crank	Up/down timer 159 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of commanded spark advance and adjusted delivered is out of bounds given by threshold range	15.00 degrees		Engine speed >0rpm	Up/down timer 432 ms continuous, 0.5 down time multiplier	
			Absolute difference between Estimated Engine Torque and its dual store are above a threshold	100.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Absolute difference between Estimated Engine Torque without reductions due to torque control and its dual store are above a threshold	100.00 Nm		Engine speed >0rpm	Up/down timer 475 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Difference of desired spark advance for managed torque and its redundant calculation is out of bounds given by threshold range	15.00 degrees		Torque reserve (condition when spark control greater than optimum to allow fast transitions for torque disturbances) > 100.00 Nm	Up/down timer 459 ms continuous, 0.5 down time multiplier	
			Absolute difference of Engine Capacity Minimum Running Immediate Brake Torque Excluding Cylinder Sensitivity and its redundant calculation is out of bounds given by threshold range	100 Nm		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			One step ahead calculation of air-per-cylinder greater than two step ahead calculation by threshold for time	Threshold: Dynamically calculated based on current engine conditions Fault Pending Threshold: 100		Engine speed > 570 rpm	Up/down timer 459 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
				ms				
			Rate limited cruise axle torque request and its dual store do not match within a threshold	56.36 Nm	Ignition State	Accessory, run or crank	Up/down timer 163 ms continuous, 0.5 down time multiplier	
			1. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its redundant calculation is out of bounds given by threshold range OR 2. Absolute difference of Calculated accelerator pedal position compensated for carpet learn and error conditions and its dual store do not equal OR	1. 3.50 % 2. N/A 3. N/A	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			3. Absolute difference of Calculated accelerator pedal position and its dual store do not equal					
			Commanded axle torque is greater than its redundant calculation by threshold	1,503.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Commanded axle torque is less than its redundant calculation by threshold	2,254.50 Nm	Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Preload timer and its redundant calculation do not equal	N/A	Ignition State	Accessory, run or crank AFM apps only	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			AC friction torque is greater than commanded by AC control software	40.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Engine Speed Lores Intake Firing (time based) calculation does not equal its redundant calculation	N/A		Engine speed >0rpm	Up/down timer 175 ms continuous, 0.5 down time multiplier	
			Absolute difference of the calculated spark offset for equivalence ratio and its redundant calculation is greater than a threshold	15.00 degrees		Engine speed >0rpm	Up/down timer 159 ms continuous, 0.5 down time multiplier	
			Transmission Torque Request calculations do not equal their dual stores	N/A		Run or Crank = TRUE > 0.50 s	16 / 32 counts; 25.0msec/count	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Absolute difference of the predicted motor torque ACS and its redundant calculation is greater than a threshold	0.01 Nm			Up/down timer 2,048 ms continuous, 0.5 down time multiplier	
			Absolute difference of maximum throttle area and its redundant calculation is greater than a threshold	15 mm ²			Up/down timer 103 ms continuous, 0.5 down time multiplier	
			Absolute difference of Desired TIAP and its redundant calculation is greater than a threshold	5.00 kPa			Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Pedal learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Throttle learns and their redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5 down time multiplier	
			Desired Throttle Position and its redundant calculation do not equal		Ignition State	Accessory, run or crank	Up/down timer 475 ms continuous, 0.5	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
							down time multiplier	
			Calculated or Commanded Engine to Axle ratio is lower than a threshold -OR- Engine to Axle Offset is greater than a threshold	0.9 100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 175.00 ms continuous, 0.5 down time multiplier	
			Difference between Cruise Arbitration Request and its redundant calculation exceeds a threshold -OR- Difference between Cruise Acceleration Request and its redundant calculation exceeds a threshold	100.00 Nm 0.10 KPH/Second	Ignition State	Accessory, run or crank	Up/down timer 500.00 ms continuous, 0.5 down time multiplier	
			Delivered fraction does not match commanded fraction within a specified time limit	0.0000	Engine State	Running	Up/down timer 200.00 ms continuous, 0.5 down time multiplier	
			Difference between delivered cylinder deactivation does not match commanded cylinder deactivation is greater than a threshold	64.00	Engine State	Running	Up/down timer 500.00 ms continuous, 0.5 down time multiplier	
			Difference between commanded Engine	100.00 Nm	Ignition State	Accessory, run or crank	Up/down timer 2,047.97	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			Torque and its redundant calculation is greater than a threshold -OR- Difference between commanded Engine Torque and its redundant calculation is less than a threshold	65,535.00 Nm			ms continuous, 0.5 down time multiplier	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transfer Case Control Module Transfer Case Command State Rationality - 4WD high or 4WD low command not 4wd high or 4WD low ratio	P17D4	The diagnostic monitor compares measured transfer case ratio to the transfer case control module commanded transfer case state. When the measured transfer case gear ratio is 4WD neutral ratio, while, the transfer case control module command state is 4WD high ratio or 4WD low ratio, the DTC is set. The 4WD neutral ratio regions are considered ratios outside the nominal 4WD high and nominal 4WD low ratios. The 4WD ratio is calculated as transmission output shaft speed divided by the transfer case output shaft speed, both speed are measured values based on speed sensors.	transfer case control module transfer case command state AND measured transfer case ratio is NOT in 4WD low ratio window AND measured transfer case ratio is NOT in 4WD high ratio window AND measured transfer case ratio is NOT in 4WD low ratio window AND measured transfer case ratio is NOT in 4WD high ratio window OR vehicle is stopped: transfer case output shaft speed transmission output shaft speed vehicle stopped secondary parameter thresholds met (measured transfer case ratio = transmission output speed / transfer case output speed)	≠ 4WD neutral 4WD low ratio window ≤ 3.00 ≥ 2.40 4WD high ratio window ≤ 1.30 ≥ 0.70 ≥ 2.90 ≤ 2.00 ≥ 1.20 ≤ 0.80 ≤ 10.0 RPM ≥ 500.0 RPM	vehicle stopped: transmission output shaft speed engine torque engine speed accelerator pedal position accelerator pedal position brake pedal position transmission gear is forward gear: transmission output shaft speed engine torque engine speed accelerator pedal position accelerator pedal position brake pedal position transmission gear is reverse gear: transmission output shaft speed engine torque engine speed accelerator pedal position accelerator pedal position brake pedal position vehicle speed diagnostic monitor enable PTO active engine power limited DTCs not fault active	≥ 500.0 RPM ≥ 100.0 Nm ≥ 300.0 RPM ≥ 5.0 % hysteresis high NOT ≤ 3.0 % hysteresis low ≤ 100.0 % ≥ 500.0 RPM ≥ -20.0 Nm ≥ 0.0 RPM ≥ 0.0 % hysteresis high NOT ≤ 0.0 % hysteresis low ≤ 100.0 % ≥ 500.0 RPM ≥ 90.0 Nm ≥ 300.0 PRM ≥ 6.0 % hysteresis high NOT ≤ 3.0 % hysteresis low ≤ 100.0 % >= 3.00 = 1 Boolean = FALSE = FALSE CrankSensor_FA VehicleSpeedSensor_FA	fail time ≥ 10.50 seconds out of sample time ≥ 15.00 seconds update rate 12.5 milliseconds	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			update rate 12.5 milliseconds			EngineTorqueEstInaccu rate P057B, P057C, P057D, P057E, P279A, P279B, P279C, P0502, P0503, P0722, P0723, P2160, P2161		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Axle Torque Secondary Signal Message Counter Incorrect	P1899	This DTC monitors for an error in communication with the Axle Torque Secondary Signal	Communication of the Alive Rolling Count or Protection of the Axle Torque Secondary Signal over CAN bus is incorrect for out of total samples	 >= 15.00 counts >= 16.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 10ms loop.	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Four Wheel Drive Range Secondary Signal Message Counter Incorrect	P189A	This DTC monitors for an error in communication with the Secondary Axle Operational Mode Signal	Communication of the Alive Rolling Count or Protection of the Secondary Axle Operational Mode Signal over CAN bus is incorrect for out of total samples	 >= 15.00 counts >= 16.00 counts	Message frame All the following conditions are met for Power Mode Powertrain Relay Voltage Run/Crank Ignition Voltage	= Is available >= 3,000.00 milliseconds = Run >= 11.00 Volts >= 11.00 Volts	Executes in 10ms loop.	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Park Assistance System Performance	P18CB	Determines if Park assist active bit from EBCM is valid	Speed Error - APA active (\$1C6/\$1C7) above a vehicle speed threshold OR Initialization Error - APA active (\$1C6/\$1C7) without an active torque request OR Exit Error - APA transitions to inactive during active torque request above a vehicle speed threshold	> 10.00 APA active boolean transitions from False to True with Torque Intervention = No request APA active boolean transitions from True to False with Torque Intervention <> No request when vehicle speed is > 1.00	Active Communication with EBCM Power Mode Engine Running Status of traction in GMLAN message (\$4E9) Run/Crank Active Ignition Voltage	Received serial data = Run = True = Traction Present > 0.50 seconds > 6.41 volts	>= 6 failures out of 10 Performed every 12.5ms >= 6 failures out of 10 Performed every 12.5ms When transition occurs, no number of samples Performed every 12.5ms	Type C, No SVS Emissions Neutral Diagnostic - Type C

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
			<p>After a Refuel Event *****</p> <p>3a) If primary tank volume change from Engine Off to next Engine On condition is 3b) then secondary tank volume change must be</p> <p>OR</p> <p>4. *****</p> <p>Fuel consumed without a Secondary Fuel Level Change *****</p> <p>4a) If engine is running, and the fuel consumed is 4b) then secondary tank volume change must be</p> <p>OR</p> <p>5. *****</p> <p>Secondary Tank Full Indication Stuck During Fuel Transfer *****</p> <p>5a) If secondary tank fuel level [Full definition] is AND 5b) If engine is running, and fuel consumed is 5c) then secondary tank volume change must be</p>	<p>3a) ≥ 1,023.98 liters</p> <p>3b) ≥ 5.00 liters</p> <p>4a) ≥ 30 liters</p> <p>4b) ≥ 5.00 liters</p> <p>5a) > 136 liters</p> <p>5b) ≥ 30 liters</p> <p>5c) ≥ 5.00 liters</p>	<p>4a) Secondary tank volume [Not Empty] AND 4b) Secondary tank volume [Not Full]</p> <p>5) Secondary Fuel Transfer Pump On Time</p>	<p>4a) ≥ 7 liters</p> <p>4b) < 136 liters</p> <p>5) ≥ 600 seconds</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Circuit Low Voltage (For use on vehicles with two fuel senders)	P2067	This DTC will detect a fuel sender out-of-range low in the secondary fuel tank.	Fuel level Sender % of 5V range	< 10 % or 137.41 liters	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Level Sensor 2 Circuit High Voltage (For use on vehicles with two fuel senders)	P2068	This DTC will detect a fuel level sensor out-of-range high in the secondary fuel tank.	Fuel level Sender % of 5V range	> 60 % or 7.77 liters	a) Diagnostic enabled status b) Fuel Level Sensor Initialized status c) Fuel Level Sensor Data Available Status d) Communication faults status	a) == True b) == True c) == True d) <> True	100 failures out of 125 samples 100 ms / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit Low-- Bank 1	P2088	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	$\leq 0.5 \Omega$ impedance between signal and controller ground	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Intake Camshaft Actuator Solenoid Circuit High – Bank 1	P2089	Controller specific output driver circuit diagnoses the CAM phaser oil control valve solenoid high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	$\leq 0.5 \Omega$ impedance between signal and controller power	System supply voltage Output driver is commanded on Ignition switch is in crank or run position	> 11.00 Volts	20 failures out of 25 samples 250 ms /sample, continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Lean Bank 1	P2096	<p>Determines if the post catalyst O2 sensor based fuel control system is indicating a lean exhaust gas condition. If the lean condition is such that the control system utilizes all or most of its available high limit authority (high limit = 100% authority), then P2096 will set.</p> <p>The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset.</p> <p>Note: When the post catalyst O2 voltage is too lean, the post catalyst O2 integral and proportional offset control is increased (positive % authority). This applies a rich bias to fuel control in an attempt to counteract the lean condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral</p>	<p>The Average Integral Offset % Authority</p> <p>AND</p> <p>The Average Total Offset % Authority</p> <p>(Note: any value greater than or equal to +100% effectively nullifies the Average Total Offset % Authority criteria)</p> <p>High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 35 % for >= 5.0 seconds AND the % Authority metric is approaching the failure threshold.</p> <p>Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 30 % for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.</p>	<p>>= 90.0 %</p> <p>>= 75.0 %</p> <p>If the P2096 is actively failing then the Average Integral Offset must be < 50.0 % and the Average Total Offset must be < 200.0 % for the diagnostic to report a pass.</p>	<p>The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration</p> <p>Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp.</p> <p>PTO Intrusive diag. fuel control Ethanol Estimation in Progress</p> <p>O2 Heater Learned Resistance</p> <p>Long Term Secondary Fuel Trim Enabled for (see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables)</p> <p>High Vapor Conditions</p> <p>Green Cat System Condition</p>	<p>No No Yes Yes Yes</p> <p>>= 70 kPa >= 0.0 g/s <= 10,000.0 >= 0 kPa <= 256 >= -20 deg. C <= 200 >= -20 deg. C (or OBD Coolant Enable Criteria = TRUE)</p> <p>Not Active Not Active Not Active</p> <p>= Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>>= 0.1 seconds</p> <p>Not Present</p> <p>= Not Valid, Green Cat System condition is considered valid until the</p>	<p>Frequency: Continuous Monitoring in 100ms loop.</p> <p>The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 100.0 seconds (1,000 samples) before comparing to their respective failure thresholds.</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of "0" (i.e. 0% authority) and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean).			No Fault Active for:	accumulated air flow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is above 22 grams/sec. AmbientAirDefault AIR System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorFA CamSensorAnyLocationFA EvapEmissionSystem_FA EvapFlowDuringNonPurge_FA FuelTankPressureSnrCkt_FA EvapPurgeSolenoidCircuit_FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorTFTKO MAP_SensorFA MAP_EngineVacuumStatus EngineMisfireDetected_FA A/F Imbalance Bank1 O2S_Bank_1_Sensor_1_FA		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>For the cells identified as enabled (i.e. those containing a "Yes" at the beginning of the Enable Conditions column), the minimum accumulated samples required before the fuel control metric is considered usable for that cell (1 sample = 100ms):</p> <p>Deceleration 300 Idle 300 Cruise 300 Light Acceleration 300 Heavy Acceleration 300</p> <p>(Note: A value in any of the above operating "cells" that is an order of magnitude (or more) higher than other cells is an indication that the diagnostic is not capable of diagnosing in that cell).</p>	<p>O2S_Bank_1_Sensor_2_ FA</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Rich Bank 1	P2097	<p>Determines if the post catalyst O2 sensor based fuel control system is indicating a rich exhaust gas condition. If the rich condition is such that the control system utilizes all or most of its available low limit authority (low limit = -100% authority), then P2097 will set.</p> <p>The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset.</p> <p>Note: When the post catalyst O2 voltage is too rich, the post catalyst O2 integral and proportional offset control is decreased (negative % authority). This applies a lean bias to fuel control in an attempt to counteract the rich condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral</p>	<p>The Average Integral Offset % Authority</p> <p>AND</p> <p>The Average Total Offset % Authority</p> <p>(Note: any value less than or equal to -100% effectively nullifies the Average Total Offset % Authority criteria)</p> <p>High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 35 % for >= 5.0 seconds.</p> <p>Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 30 % for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.</p>	<p><= -90.0 %</p> <p><= -75.0 %</p> <p>If the P2097 is actively failing then the Average Integral Offset must be > -50.0 % and the Average Total Offset must be > -200.0 % for the diagnostic to report a pass.</p>	Same as P2096	Same as P2096	<p>Frequency: Continuous Monitoring in 100ms loop.</p> <p>The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 100.0 seconds (1,000 samples) before comparing to their respective failure thresholds.</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of "0" (i.e. 0% authority) and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean).						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Lean Bank 2	P2098	<p>Determines if the post catalyst O2 sensor based fuel control system is indicating a lean exhaust gas condition. If the lean condition is such that the control system utilizes all or most of its available high limit authority (high limit = 100% authority), then P2098 will set.</p> <p>The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset.</p> <p>Note: When the post catalyst O2 voltage is too lean, the post catalyst O2 integral and proportional offset control is increased (positive % authority). This applies a rich bias to fuel control in an attempt to counteract the lean condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral</p>	<p>The Average Integral Offset % Authority</p> <p>AND</p> <p>The Average Total Offset % Authority</p> <p>(Note: any value greater than or equal to +100% effectively nullifies the Average Total Offset % Authority criteria)</p> <p>High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 35 % for >= 5.0 seconds AND the % Authority metric is approaching the failure threshold.</p> <p>Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 30 % for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.</p>	<p>>= 90.0 %</p> <p>>= 75.0 %</p> <p>If the P2098 is actively failing then the Average Integral Offset must be < 50.0 % and the Average Total Offset must be < 200.0 % for the diagnostic to report a pass.</p>	<p>The diagnostic is enabled during: Deceleration Idle Cruise Light Acceleration Heavy Acceleration</p> <p>Ambient Air Pressure Engine AirFlow Intake Manifold Pressure Induction Air Temperature Start-up Coolant Temp.</p> <p>PTO Intrusive diag. fuel control Ethanol Estimation in Progress</p> <p>O2 Heater Learned Resistance</p> <p>Long Term Secondary Fuel Trim Enabled for (see "Long Term Secondary Fuel Trim Enable Criteria" in Supporting Tables)</p> <p>High Vapor Conditions</p> <p>Green Cat System Condition</p>	<p>No No Yes Yes Yes</p> <p>>= 70 kPa >= 0.0 g/s <= 10,000.0 >= 0 kPa <= 256 >= -20 deg. C <= 200 >= -20 deg. C (or OBD Coolant Enable Criteria = TRUE)</p> <p>Not Active Not Active Not Active</p> <p>= Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>>= 0.1 seconds</p> <p>Not Present</p> <p>= Not Valid, Green Cat System condition is considered valid until the</p>	<p>Frequency: Continuous Monitoring in 100ms loop.</p> <p>The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 100.0 seconds (1,000 samples) before comparing to their respective failure thresholds.</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of "0" (i.e. 0% authority) and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean).			No Fault Active for:	accumulated air flow is greater than 720,000 grams. Airflow accumulation is only enabled when estimated Cat temperature is above 600 Deg C and airflow is above 22 grams/sec. AmbientAirDefault AIR System FA Ethanol Composition Sensor FA ECT_Sensor_FA EGRValveCircuit_FA EGRValvePerformance_FA IAT_SensorFA CamSensorAnyLocationFA EvapEmissionSystem_FA EvapFlowDuringNonPurge_FA FuelTankPressureSnsrCkt_FA EvapPurgeSolenoidCircuit_FA EvapSmallLeak_FA EvapVentSolenoidCircuit_FA FuelInjectorCircuit_FA MAF_SensorFA MAF_SensorTFTKO MAP_SensorFA MAP_EngineVacuumStatus EngineMisfireDetected_FA A/F Imbalance Bank2 O2S_Bank_2_Sensor_1_FA		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>For the cells identified as enabled (i.e. those containing a "Yes" above), the minimum accumulated samples required before the fuel control metric is considered usable for that cell (1 sample = 100ms):</p> <p>Deceleration Idle 300 Cruise 300 Light Acceleration 300 Heavy Acceleration 300</p> <p>Note: A value in any of the above operating "cells" that is an order of magnitude (or more) higher than other cells is an indication that the diagnostic is not capable of diagnosing in that cell).</p>	<p>O2S_Bank_2_Sensor_2_ FA</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Post Catalyst Fuel Trim System Too Rich Bank 2	P2099	<p>Determines if the post catalyst O2 sensor based fuel control system is indicating a rich exhaust gas condition. If the rich condition is such that the control system utilizes all or most of its available low limit authority (low limit = -100% authority), then P2099 will set.</p> <p>The monitor can be calibrated to fail based on the Average Integral Offset % Authority, the Average Total Offset % Authority or both combined. The Average Total Offset metric consists of the average of the Integral Offset+ Proportional Offset.</p> <p>Note: When the post catalyst O2 voltage is too rich, the post catalyst O2 integral and proportional offset control is decreased (negative % authority). This applies a lean bias to fuel control in an attempt to counteract the rich condition. A perfectly balanced control system (no rich or lean bias required) is represented by integral</p>	<p>The Average Integral Offset % Authority</p> <p>AND</p> <p>The Average Total Offset % Authority</p> <p>(Note: any value less than or equal to -100% effectively nullifies the Average Total Offset % Authority criteria)</p> <p>High Vapor Feature: The diagnostic is at risk of reporting a false fail when excessively High Vapor (HV) conditions are present. This HV condition is indicated when the purge valve is open AND percent vapor is >= 35% for >= 5.0 seconds.</p> <p>Diagnosis resumes if the purge valve is closed OR the percent vapor is <= 30% for >= 5.0 seconds. This was done to minimize disabling the diagnostic for longer than necessary.</p>	<p>>= -90.0 %</p> <p>.</p> <p>>= -75.0 %</p> <p>If the P2099 is actively failing then the Average Integral Offset must be < -50.0 % and the Average Total Offset must be < -200.0 % for the diagnostic to report a pass.</p>	Same as P2098	Same as P2098	<p>Frequency: Continuous Monitoring in 100ms loop.</p> <p>The Integral and Total Offset % Authority metrics are sampled every 100ms and an average is calculated every 100.0 seconds (1,000 samples) before comparing to their respective failure thresholds.</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		and proportional offset values of "0" (i.e. 0% authority) and a post catalyst O2 sensor that is within its optimal operating range (neither rich nor lean).						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Throttle Actuator Position Performance	P2101	1) Detect a throttle positioning error. This is determined if the difference between measured throttle position and modeled throttle position is greater than a threshold or less than a threshold. This diagnostic only runs when the engine is running and the ignition voltage is high enough and there is not an ignition voltage failure and the throttle position minimum learn is not active and the throttle is being controlled 2) Throttle control is driving the throttle in the incorrect direction. This is determined if the throttle position is greater than a threshold percent and the powertrain relay voltage is high enough and the throttle position minimum learn is active.	Difference between measured throttle position and modeled position, (modeled = MAX (Commanded vs. Commanded Filtered)) > OR Difference between modeled position (modeled = MIN (Commanded vs. Commanded Filtered)) and measured throttle position >	8.41 percent 8.41 percent	TPS minimum learn is not active AND Powertrain Relay Contact1 Fault is FALSE (no P1682 fault) AND Throttle Control is not in Service or DVT control Throttle is being Controlled AND ((Engine Running AND Run/Crank Voltage) OR Run Crank Voltage)	> 5.50 Volts > 8.41 Volts	15 counts; 12.5 ms/count in the primary processor	Type A, 1 Trips
			Throttle Position >	36.00 percent	TPS minimum learn active AND Powertrain Relay Contact1 Fault is FALSE (no P1682 fault) AND Throttle Control is not in Service or DVT control	= TRUE	11 counts; 12.5 ms/count in the primary processor	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Lo	P2122	Detects a continuous or intermittent short low or open in the APP sensor #1 by monitoring the APP1 sensor percent Vref and failing the diagnostic when the APP1 percent Vref is too low. This diagnostic only runs when battery voltage is high enough. Detects a continuous or intermittent short low or open in the APP sensor #1 on the Main processor.	APP1 percent Vref	< 0.4625 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P06A3	19 / 39 counts; or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1 Hi	P2123	Detects a continuous or intermittent short high in the APP sensor #1 by monitoring the APP1 sensor percent Vref and failing the diagnostic when the APP1 percent Vref is too high. This diagnostic only runs when battery voltage is high enough. Detect a continuous or intermittent short high in the APP sensor #1 on the Main processor.	APP1 percent Vref >	4.7500 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P06A3	19 / 39 counts; or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Lo	P2127	Detects a continuous or intermittent short low or open in the APP sensor #2 by monitoring the APP2 sensor percent Vref and failing the diagnostic when the APP2 percent Vref is too low. This diagnostic only runs when battery voltage is high enough. Detects a continuous or intermittent short low or open in the APP sensor #2 on the Main processor.	APP2 percent Vref <	0.3250 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P0697	19 / 39 counts; or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 2 Hi	P2128	Detects a continuous or intermittent short high in the APP sensor #2 by monitoring the APP2 sensor percent Vref and failing the diagnostic when the APP2 percent Vref is too high. This diagnostic only runs when battery voltage is high enough. Detect a continuous or intermittent short high in the APP sensor #2 on the Main processor.	APP2 percent Vref >	2.6000 % Vref	Run/Crank voltage No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts P0697	19 / 39 counts; or 14 counts continuous; 12.5 ms/count in the main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Throttle Position (TP) Sensor 1-2 Correlation	P2135	Detect a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor. 1.) The diagnostic monitors the difference in position between TPS1 and the TPS2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. 2.) The diagnostic monitors the difference in reference voltage between normalized min TPS1 and the normalized min TPS2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. Detects a continuous or intermittent correlation fault between TPS sensors #1 and #2 on Main processor	Difference between TPS1 displaced and TPS2 displaced >	6.797 % offset at min. throttle position with a linear threshold to 9.720 % at max. throttle position	Run/Crank voltage No TPS sensor faults No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts (P0122, P0123, P0222, P0223) P06A3	79 / 159 counts; or 58 counts continuous; 3.125 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min TPS1) and (normalized min TPS2) >	5.000 % Vref	Run/Crank voltage No TPS sensor faults No 5V reference error or fault for # 4 5V reference circuit	> 6.41 Volts (P0122, P0123, P0222, P0223) P06A3	79 / 159 counts; or 58 counts continuous; 3.125 ms/count in the main processor	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Accelerator Pedal Position (APP) Sensor 1-2 Correlation	P2138	Detect a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor. 1.) The diagnostic monitors the difference in position between APP1 and the APP2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. 2.) The diagnostic also monitors the difference in reference voltage between normalized min APP1 and the normalized min APP2 and fails the diagnostic when the difference is too high. This diagnostic only runs when the battery voltage is high enough. Detects a continuous or intermittent correlation fault between APP sensors #1 and #2 on Main processor	Difference between APP1 displaced and APP2 displaced >	5.000 % offset at min. pedal position with a linear threshold to 10.001 % at max. pedal position	Run/Crank voltage No APP sensor faults No 5V reference errors or faultst for # 3 & # 4 5V reference circuits	> 6.41 Volts (P2122, P2123,P2127, P2128) (P06A3, P0697)	19 / 39 counts intermittent; or 15 counts continuous, 12.5 ms/count in the main processor	Type A, 1 Trips
			Difference between (normalized min APP1) and (normalized min APP2) >	3.500 % Vref	Run/Crank voltage No APP sensor faults No 5V reference errors or faultst for # 3 & # 4 5V reference circuits	> 6.41 Volts (P2122, P2123,P2127, P2128) (P06A3, P0697)	19 / 39 counts intermittent; or 15 counts continuous, 12.5 ms/count in the main processor	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 high side circuit shorted to ground	P2147	Controller specific output driver circuit diagnoses Injector 1 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 1 high side circuit shorted to power	P2148	Controller specific output driver circuit diagnoses Injector 1 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 high side circuit shorted to ground	P2150	Controller specific output driver circuit diagnoses Injector 2 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 2 high side circuit shorted to power	P2151	Controller specific output driver circuit diagnoses Injector 2 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 high side circuit shorted to ground	P2153	Controller specific output driver circuit diagnoses Injector 3 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 3 high side circuit shorted to power	P2154	Controller specific output driver circuit diagnoses Injector 3 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 high side circuit shorted to ground	P2156	Controller specific output driver circuit diagnoses Injector 4 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 4 high side circuit shorted to power	P2157	Controller specific output driver circuit diagnoses Injector 4 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Vehicle Speed – Output Shaft Speed Correlation	P215B	Detect invalid vehicle speed source. This failure is set by two different conditions. Either the absolute difference between wheel speed vehicle speed and TOS vehicle speed is too high, or secure vehicle speed is not available.	The absolute difference between wheel speed vehicle speed and TOS vehicle speed greater than > OR Secure vehicle speed source is unavailable	6.21 mph		Time since first CAN activity > 0.5000 s Secure vehicle speed source is TOS vehicle speed or wheel speed vehicle speed Trans engaged state is equal to engaged.	400 / 800 counts for wheel speed correlation or 400 / 800 counts for TOS correlation; 25ms/count	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 high side circuit shorted to ground	P216B	Controller specific output driver circuit diagnoses Injector 5 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 5 high side circuit shorted to power	P216C	Controller specific output driver circuit diagnoses Injector 5 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 high side circuit shorted to ground	P216E	Controller specific output driver circuit diagnoses Injector 6 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 6 high side circuit shorted to power	P216F	Controller specific output driver circuit diagnoses Injector 6 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Minimum Throttle Position Not Learned	P2176	Detect when the throttle position minimum learn on the main processor is not learned. This diagnostic detects this by monitoring if the throttle position is greater than a threshold and the number of learn attempts is greater than a threshold. This diagnostic only runs when the battery voltage is high enough and the throttle position minimum learn is active. Throttle position sensors were not in the minmum learn window after multiple attempts to learn the minimum.	During TPS min learn on the Main processor, TPS percent Vref > AND Number of learn attempts >	0.5740 % Vref 10 counts	Run/Crank voltage TPS minimum learn is active No previous TPS min learn values stored in long term memory	> 6.41 Volts = TRUE	2.0 secs	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 high side circuit shorted to ground	P217B	Controller specific output driver circuit diagnoses Injector 7 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 7 high side circuit shorted to power	P217C	Controller specific output driver circuit diagnoses Injector 7 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 high side circuit shorted to ground	P217E	Controller specific output driver circuit diagnoses Injector 8 high sided driver for a short to ground failure when the output is powered on by comparing a voltage measurement to controller specific voltage thresholds	Voltage measurement outside of controller specific acceptable range during driver on state indicates short to ground failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to ground.	25 amp >= through High Side Driver	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Injector 8 high side circuit shorted to power	P217F	Controller specific output driver circuit diagnoses Injector 7 high sided driver for a short to power failure when the output is powered off by comparing a voltage measurement to controller specific voltage thresholds.	Voltage measurement outside of controller specific acceptable range during driver off state indicates short to power failure. Controller specific output driver circuit voltage thresholds are set to meet the following controller specification for a short to power.	<= 1 volt between signal and controller power	Battery Voltage Engine Run Time	>= 11 Volts >= 0 Seconds P062B not FA or TFTK	10.00 failures out of 20.00 samples 100 ms /sample Continuous	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 1 Air-Fuel Ratio Imbalance	P219A	<p>This monitor determines if there is an Air Fuel Imbalance in the fueling system for a cylinder on Bank 1. Detection is based on a the pre catalyst oxygen sensor voltage. The pre catalyst O2 voltage is used to generate a variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without).</p> <p>The observed Variance is dependent on engine speed and load and is normalized by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric.</p> <p>The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (see Supporting Table</p>	<p>Standard Mode Filtered Ratio</p> <p>Optional Mode Filtered Ratio</p> <p>For this program the Optional Mode is NOT used</p>	<p>> 0.55</p> <p>If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.40 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing.</p> <p>> 0.50</p> <p>If the diagnostic has reported a failure on the prior trip, the Optional Mode Filtered Ratio must fall below 0.35 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing.</p>	<p>System Voltage</p> <p>Fuel Level</p> <p>Engine Coolant Temperature</p> <p>Cumulative engine run time</p> <p>Diagnostic enabled at Idle (regardless of other operating conditions)</p> <p>Engine speed range</p> <p>Engine speed delta during a short term sample period</p> <p>Mass Airflow (MAF) range</p> <p>Cumulative delta MAF during a short term sample period</p> <p>Filtered MAF delta between samples Note: first order lag filter coefficient applied to MAF = 0.050</p> <p>Air Per Cylinder (APC)</p>	<p>no lower than 10.0 Volts for more than 0.2 seconds</p> <p>> 10.0 % The diagnostic will disregard the fuel level criteria if the fuel sender is faulty.</p> <p>> -20 deg. C (or OBD Coolant Enable Criteria = TRUE)</p> <p>> 0.0 seconds</p> <p>No</p> <p>900 to 3,800 RPM</p> <p>< 200 RPM</p> <p>7 to 700 g/s</p> <p>< 6 g/s</p> <p>< 0.90 g/s</p> <p>150 to 850 mg/cylinder</p>	<p>Minimum of 1 test per trip, up to 8 tests per trip during RSR or FIR.</p> <p>The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example, 10.50 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such significantly more operating time is required than is indicated above. Generally, a report will be</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>P219A Variance Threshold Bank1 Table) and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table (see Supporting Table P219A Normalizer Bank1 Table). This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (see Supporting Table P219A Quality Factor Bank1 Table) . This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used.</p> <p>Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered</p>			<p>APC delta during short term sample period</p> <p>Filtered APC delta between samples Note: first order lag filter coefficient applied to APC = 0.050</p> <p>Spark Advance</p> <p>Throttle Area (percent of max)</p> <p>Intake Cam Phaser Angle</p> <p>Exhaust Cam Phaser Angle</p> <p>-----</p> <p>Electronic Waste Gate (eWG) present</p> <p>If eWG = yes then Waste Gate Position</p> <p>Intrusive eWG Feature</p> <p>If intrusive Waste Gate positin is enabled then the electronic Waste Gate will be commanded to the following range when the other enable conditions have been met.</p> <p>Intrusive Waste Gate Position Min</p> <p>Intrusive Waste Gate Position Max</p> <p>-----</p>	<p>< 80 mg/cylinder</p> <p>< 7.00 percent</p> <p>5 to 55 degrees</p> <p>2 to 100 percent</p> <p>0 to 30 degrees</p> <p>0 to 30 degrees</p> <p>-----</p> <p>No</p> <p>0.0 to 101.0</p> <p>Disabled</p> <p>-----</p> <p>0.0</p> <p>101.0</p> <p>-----</p>	<p>made within 5 minutes of operation.</p> <p>For RSR or FIR, 16 tests must complete before the diagnostic can report.</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>Ratio.</p> <p>The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific.</p> <p>Some applications may need to command a unique cam phaser value before performing the above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use his feature.</p> <p>For programs using Active Fuel Management or Multiple Cam profiles a secondary Imbalance Ratio can be calculated while in the secondary operating modes. This secondary ratio is an optional calculation and is labeled as the "Optional Mode Ratio". The Optional Mode Ratio is calculated the same as explained above with the following supporting</p>			<p>Active Fuel Management Firing Fraction</p> <p>if the Optional Mode is enabled (see Malfunction Criteria) Active Fuel Management Firing fraction for Optional Mode calculations</p> <p>Intrusive Firing Fraction during Fast Initial Response or Rapid Step Response</p> <p>If the intrusive Firing Fraction feature is enabled the Active Fuel Management firing fraction will be forced to a value above this threshold when in Fast Initial Response or in Rapid Step Response.</p> <p>-----</p> <p>For programs using multi-step cam profiles:</p> <p>High Lift Cam Profile will use:</p> <p>Low Lift Cam Profile will use:</p> <p>Quality Factor (QF) QF calibrations are located in a 17x17 lookup</p>	<p>0.99 to 1.10</p> <p>0.99 to 0.01</p> <p>Disabled</p> <p>>= 0.99</p> <p>-----</p> <p>Standard Mode Filtered Ratio</p> <p>Standard Mode Filtered Ratio</p> <p>>= 0.99</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		tables: P219A Variance Threshold Bank1 Opt Table P219A Normalizer Bank1 Opt Table , and P219A Quality Factor Bank1 Opt Table			table versus engine speed and load (see Supporting Table P219A Quality Factor Bank1 Table). QF values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data. Fuel Control Status Closed Loop and Long Term FT Enabled for: Device Control AIR pump CASE learn EGR EVAP Engine Over Speed Protection Idle speed control PTO Injector base pulse width O2 learned htr resistance Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is	>= 1.2 seconds (Please see " Closed Loop Enable Clarification " and " Long Term FT Enable Criteria " in Supporting Tables) Not active Not on Not active Not intrusive Not intrusive Not Active Normal Not Active Above min pulse limit = Valid (the O2 heater resistance has learned since NVM reset) >= 0.55		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>AND it exceeds the last Filtered ratio by</p> <p>Once triggered, the filtered ratio is reset to:</p> <p>Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to:</p> <p>No Fault Active for:</p>	<p>>= 0.75</p> <p>0.00</p> <p>0.00</p> <p>EngineMisfireDetected_FA MAP_SensorFA MAF_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDefaulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbxFA CamSensorAnyLocationFA FuelTrimSystemB1_FA O2S_Bank_1_Sensor_1_FA O2S_Bank_1_Sensor_2_FA WRAF_Bank_1_FA</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Bank 2 Air-Fuel Ratio Imbalance	P219B	<p>This monitor determines if there is an Air Fuel Imbalance in the fueling system for a cylinder on a Bank 2. Detection is based on a the pre catalyst oxygen sensor voltage. The pre catalyst O2 voltage is used to generate a variance metric that represents the statistical variation of the O2 sensor voltage over a given engine cycle. This metric is proportional to the air-fuel ratio imbalance (variance is higher with an imbalance than without).</p> <p>The observed Variance is dependant on engine speed and load and is normalized by comparing it to a known "good system" result for that speed and load, and generating a Ratio metric.</p> <p>The Ratio metric is calculated by selecting the appropriate threshold calibration from a 17x17 table (see Supporting Table</p>	<p>Standard Mode Filtered Ratio</p> <p>Optional Mode Filtered Ratio</p> <p>For this program the Optional Mode is NOT used</p>	<p>> 0.50</p> <p>If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.35 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing.</p> <p>> 0.60</p> <p>If the diagnostic has reported a failure on the prior trip, the Filtered Ratio must fall below 0.45 in order to report a pass. This feature prevents the diagnostic from toggling between failing and passing</p>	<p>System Voltage</p> <p>Fuel Level</p> <p>Engine Coolant Temperature</p> <p>Cumulative engine run time</p> <p>Diagnostic enabled at Idle (regardless of other operating conditions)</p> <p>Engine speed range</p> <p>Engine speed delta during a short term sample period</p> <p>Mass Airflow (MAF) range</p> <p>Cumulative delta MAF during a short term sample period</p> <p>Filtered MAF delta between samples</p> <p>Note: first order lag filter coefficient applied to MAF = 0.050</p> <p>Air Per Cylinder (APC)</p>	<p>no lower than 10.0 Volts for more than 0.2 seconds</p> <p>> 10.0 % The diagnostic will disregard the fuel level criteria if the fuel sender is faulty.</p> <p>> -20 deg. C (or OBD Coolant Enable Criteria = TRUE)</p> <p>> 0.0 seconds</p> <p>No</p> <p>900 to 3,800RPM</p> <p>< 200 RPM</p> <p>7 to 700 g/s</p> <p>< 6 g/s</p> <p>< 0.90 g/s</p> <p>150 to 850 mg/cylinder</p>	<p>Minimum of 1 test per trip, up to 7 tests per trip during RSR or FIR. The front O2 sensor voltage is sampled once per cylinder event. Therefore, the time required to complete a single test (when all enable conditions are met) decreases as engine speed increases. For example, 10.50 seconds of data is required at 1000 rpm while double this time is required at 500 rpm and half this time is required at 2000 rpm. This data is collected only when enable conditions are met, and as such significantly more operating time is required than is indicated above. Generally, a report will be made within 5</p>	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>P219B Variance Threshold Bank2 Table) and subtracting it from the measured Variance. The result is then divided by a normalizer calibration from another 17 x 17 table (see Supporting Table P219B Normalizer Bank2 Table) This quotient is then multiplied by a quality factor calibration from a 17 x 17 table (see Supporting Table P219B Quality Factor Bank2 Table) . This result is referred to as the Ratio. Note that the quality factor ranges between 0 and 1 and represents robustness to false diagnosis in the current operating region. Regions with low quality factors are not used.</p> <p>Finally, a EWMA filter is applied to the Ratio metric to generate the Filtered Ratio malfunction criteria metric. Generally, a normal system will result in a negative Filtered Ratio while a failing system will result in a positive Filtered</p>			<p>APC delta during short term sample period</p> <p>Filtered APC delta between samples Note: first order lag filter coefficient applied to APC = 0.050</p> <p>Spark Advance</p> <p>Throttle Area (percent of max)</p> <p>Intake Cam Phaser Angle</p> <p>Exhaust Cam Phaser Angle</p> <hr/> <p>Electronic Waste Gate (eWG) present</p> <p>If eWG = yes then</p> <p>Waste Gate Position</p> <p>Intrusive eWG Feature</p> <p>If intrusive Waste Gate positin is enabled then the electronic Waste Gate will be commanded to the following range when the other enable conditions have been met.</p> <p>Intrusive Waste Gate Position Min</p> <p>Intrusive Waste Gate</p>	<p>< 80 mg/cylinder</p> <p>< 7.00 percent</p> <p>5 to 55 degrees</p> <p>2 to 100 percent</p> <p>0 to 30 degrees</p> <p>0 to 30 degrees</p> <p>No</p> <p>0.0 to 101.0</p> <p>Disabled</p> <p>0.0</p> <p>101.0</p>	<p>minutes of operation.</p> <p>For RSR or FIR, 14 tests must complete before the diagnostic can report. See P219A info</p>	

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		<p>Ratio.</p> <p>The range of the Filtered Ratio metric is application specific since both the emissions sensitivity and relationship between imbalance and the Variance metric are application specific.</p> <p>Some applications may need to command a unique cam phaser value before performing the above calculations since cam phasing has been shown to have an impact on overall signal quality. This application Does Not Use this feature.</p> <p>For programs using Active Fuel Management or Multiple Cam profiles a secondary Imbalance Ratio can be calculated while in the secondary operating modes. This secondary ratio is an optional calculation and is labeled as the "Optional Mode Ratio". The Optional Mode Ratio is calculated the same as explained above with the following supporting</p>			<p>Position Max</p> <hr/> <p>Active Fuel Management Firing Fraction</p> <p>if the Optional Mode is enabled (see Malfunction Criteria) Active Fuel Management Firing fraction for Optional Mode calculations</p> <p>Intrusive Firing Fraction during Fast Initial Response or Rapid Step Response</p> <p>If the intrusive Firing Fraction feature is enabled the Active Fuel Management firing fraction will be forced to a value above this threshold when in Fast Initial Response or in Rapid Step Response.</p> <hr/> <p>For programs using multi-step cam profiles:</p> <p>High Lift Cam Profile will use:</p> <p>Low Lift Cam Profile will use:</p> <p>Quality Factor (QF) QF calibrations are</p>	<p>0.99 to 1.10</p> <p>0.99 to 0.01</p> <p>Disabled</p> <p>>= 0.99</p> <hr/> <p>Standard Mode Filtered Ratio</p> <p>Standard Mode Filtered Ratio</p> <p>>= 0.99</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		tables: P219B Variance Threshold Bank2 Opt Table , P219B Normalizer Bank2 Opt Table , and P219B Quality Factor Bank2 Table			located in a 17x17 lookup table versus engine speed and load (Supporting Table P219B Quality Factor Bank2 Table). QF values less than "1" indicate that we don't have 4sigma/2sigma robustness in that region. The quality of the data is determined via statistical analysis of Variance data. Fuel Control Status Closed Loop and Long Term FT Enabled for: Device Control AIR pump CASE learn EGR EVAP Engine Over Speed Protection Idle speed control PTO Injector base pulse width O2 learned htr resistance Rapid Step Response (RSR): RSR will trigger if the Ratio result from the last test is	>= 1.2 seconds (Please see "Closed Loop Enable Clarification" and "Long Term FT Enable Criteria" in Supporting Tables) Not active Not on Not active Not intrusive Not intrusive Not Active Normal Not Active Above min pulse limit = Valid (the O2 heater resistance has learned since NVM reset) >= 0.50		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>AND it exceeds the last Filtered ratio by</p> <p>Once triggered, the filtered ratio is reset to:</p> <p>Fast Initial Response (FIR): FIR will trigger when an NVM reset or code clear occurs. Once triggered, the filtered ratio is reset to:</p> <p>No Fault Active for:</p>	<p>>= 0.75</p> <p>0.00</p> <p>0.00</p> <p>EngineMisfireDetected_FA MAP_SensorFA MAF_SensorFA ECT_Sensor_FA TPS_ThrottleAuthorityDefaulted FuelInjectorCircuit_FA AIR System FA EvapExcessPurgePsbl_FA CamSensorAnyLocationFA FuelTrimSystemB2_FA O2S_Bank_2_Sensor_1_FA O2S_Bank_2_Sensor_2_FA WRAF_Bank_2_FA</p>		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Low (applications with LIN MAF)	P2228	<p>Detects an erroneously low value being reported over the LIN serial connection from the BARO sensor. The diagnostic monitors the BARO sensor pressure output and fails the diagnostic when the pressure is too low.</p> <p>The BARO sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure. The BARO pressure value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	BARO Pressure	< 50.0 kPa	LIN Communications established with MAF		<p>160 failures out of 200 samples</p> <p>1 sample every 25 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit High (applications with LIN MAF)	P2229	<p>Detects an erroneously high value being reported over the LIN serial connection from the BARO sensor. The diagnostic monitors the BARO sensor pressure output and fails the diagnostic when the pressure is too high.</p> <p>The BARO sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure. The BARO pressure value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	BARO Pressure	> 115.0 kPa	LIN Communications established with MAF		<p>160 failures out of 200 samples</p> <p>1 sample every 25 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure (BARO) Sensor Circuit Intermittent (applications with LIN MAF)	P2230	<p>Detects a noisy or erratic signal in the barometric pressure (BARO) circuit by monitoring the BARO sensor and failing the diagnostic when the BARO signal has a noisier output than is expected.</p> <p>When the value of BARO in kilopascals (kPa) is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of BARO readings. The result of this summation is called a "string length".</p> <p>Since the BARO signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic BARO signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current BARO reading - BARO reading from 25 milliseconds previous)</p>	<p>> 100 kPa</p> <p>40 consecutive BARO readings</p>	LIN Communications established with MAF		<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Lean Bank 1 Sensor 2	P2270	<p>The P2270 diagnostic is the first in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, & P013B. This DTC determines if the secondary O2 sensor is stuck in a normal lean voltage range and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary O2 sensor does not achieve the required rich voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post O2 sensor signal</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Stuck Lean Voltage Test</p>	<p>< 825 mvolts</p> <p>> 180 grams</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013A, P013B, P013E, P013F, P2270 or P2271</p> <p>> 10.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Only when FuelLevelDataFault Pedal position Engine Airflow Closed loop integral Closed Loop Active Evap Ethanol Estimation in Progress Post fuel cell Crankshaft Torque EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Transmission Temp Predicted Catalyst temp Fuel State	is above 22.0 grams/sec. = False = False ≤ 100.0 % 4.0 ≤ gps ≤ 20.0 0.75 ≤ C/L Int ≤ 1.12 = TRUE (Please see “ Closed Loop Enable Clarification ” in Supporting Tables). not in control of purge = Not Active (Please see “ Ethanol Estimation in Progress ” in Supporting Tables). = Enabled, refer to Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests for additional info. < 125.0 Nm = not active = not active ≥ 60.0 sec ≥ -40.0 °C 575 ≤ °C ≤ 1,024 = DFCO possible		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>=====</p> <p>All of the above met for at least 0.0 seconds, and then check the following</p> <p>Engine Speed to initially enable test</p> <p>Engine Speed range to keep test enabled (after initially enabled)</p> <p>Vehicle Speed to initially enable test</p> <p>Vehicle Speed range to keep test enabled (after initially enabled)</p> <p>=====</p> <p>All of the above met for at least 1.5 seconds, and then the Force Cat Rich intrusive stage is requested.</p> <p>=====</p> <p>During Stuck Lean test the following must stay TRUE or the test will abort:</p> <p>Commanded Fuel Crankshaft Torque</p>	<p>=====</p> <p>800 ≤ RPM ≤ 2,500</p> <p>750 ≤ RPM ≤ 2,650</p> <p>40.4 ≤ MPH ≤ 82.0</p> <p>36.0 ≤ MPH ≤ 87.0</p> <p>0.95 ≤ EQR ≤ 1.10</p> <p>< 125.0 Nm</p>		

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Rich Bank 1 Sensor 2	P2271	<p>The P2271 diagnostic is the fourth in a sequence of six intrusive secondary O2 monitors which include DTCs P2270, P013E, P013A, P2271, P013F, & P013B. This DTC determines if the secondary O2 sensor is stuck in a normal rich voltage range and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary O2 sensor does not achieve the required lean voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post O2 sensor signal</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Stuck Rich Voltage Test</p>	<p>> 150 mvolts</p> <p>> 12.0 grams</p>	<p>No Active DTC's</p> <p>B1S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013A, P013B, P013E, P013F or P2270</p> <p>> 10.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 (if applicable) in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Only when FuelLevelDataFault Fuel State DTC's Passed ===== After above conditions are met: DFCO mode is continued (w/o driver initiated pedal input).	is above 22.0 grams/sec. = False = False = DFCO possible = P2270 = P013E = P013A =====		

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Lean Bank 2 Sensor 2	P2272	<p>The P2272 diagnostic is the first in a sequence of six intrusive secondary O2 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, & P013D. This DTC determines if the secondary O2 sensor is stuck in a normal lean voltage range and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic increases the delivered fuel while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary O2 sensor does not achieve the required rich voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post O2 sensor signal</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Stuck Lean Voltage Test</p>	<p>< 825 mvolts</p> <p>> 180 grams.</p>	<p>No Active DTC's</p> <p>B2S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013C, P013D, P014A, P014B, P2272 or P2273</p> <p>> 10.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Only when FuelLevelDataFault Pedal position Engine Airflow Closed loop integral Closed Loop Active Evap Ethanol Estimation in Progress Post fuel cell Crankshaft Torque EGR Intrusive diagnostic All post sensor heater delays O2S Heater (post sensor) on Time Transmission Temp Predicted Catalyst temp Fuel State	is above 22.0 grams/sec. = False = False ≤ 100.0 % 4.0 ≤ gps ≤ 20.0 0.75 ≤ C/L Int ≤ 1.12 = TRUE (Please see “ Closed Loop Enable Clarification ” in Supporting Tables). not in control of purge = Not Active (Please see “ Ethanol Estimation in Progress ” in Supporting Tables). = Enabled, refer to Multiple DTC Use - Block learn cells to enable Post oxygen sensor tests for additional info. < 125.0 Nm = not active = not active ≥ 60.0 sec ≥ -40.0 °C 575 ≤ °C ≤ 1,024 = DFCO possible		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					<p>=====</p> <p>All of the above met for at least 0.0 seconds, and then check the following</p> <p>Engine Speed to initially enable test Engine Speed range to keep test enabled (after initially enabled)</p> <p>Vehicle Speed to initially enable test Vehicle Speed range to keep test enabled (after initially enabled)</p> <p>=====</p> <p>All of the above met for at least 1.5 seconds, and then the Force Cat Rich intrusive stage is requested.</p> <p>=====</p> <p>During Stuck Lean test the following must stay TRUE or the test will abort: Commanded Fuel Crankshaft Torque</p>	<p>=====</p> <p>800 ≤ RPM ≤ 2,500</p> <p>750 ≤ RPM ≤ 2,650</p> <p>40.4 ≤ MPH ≤ 82.0</p> <p>36.0 ≤ MPH ≤ 87.0</p> <p>0.95 ≤ EQR ≤ 1.10 < 125.0 Nm</p>		

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
O2 Sensor Signal Stuck Rich Bank 2 Sensor 2	P2273	<p>The P2273 diagnostic is the fourth in a sequence of six intrusive secondary O2 monitors which include DTCs P2272, P014A, P013C, P2273, P014B, & P013D. This DTC determines if the secondary O2 sensor is stuck in a normal rich voltage range and thereby can no longer be used for secondary O2 sensor fuel control or for catalyst monitoring. This diagnostic commands fuel cut off while monitoring the sensor signal and the accumulated mass air flow.</p> <p>This fault is set if the secondary O2 sensor does not achieve the required lean voltage before the accumulated mass air flow threshold is reached.</p>	<p>Post O2 sensor signal</p> <p>AND</p> <p>The Accumulated mass air flow monitored during the Stuck Rich Voltage Test</p>	<p>> 150 mvolts</p> <p>> 12.0 grams.</p>	<p>No Active DTC's</p> <p>B2S2 DTC's Not Active this key cycle</p> <p>System Voltage Learned heater resistance</p> <p>Green O2S Condition</p>	<p>TPS_ThrottleAuthorityDefaulted ECT_Sensor_FA IAT_SensorFA MAF_SensorFA MAP_SensorFA AIR System FA FuelInjectorCircuit_FA FuelTrimSystemB1_FA FuelTrimSystemB2_FA EngineMisfireDetected_FA Ethanol Composition Sensor FA O2S_Bank_1_TFTKO O2S_Bank_2_TFTKO</p> <p>P013C, P013D, P014A, P014B or P2272</p> <p>> 10.0 Volts = Valid (the heater resistance has learned since NVM reset, see enable conditions for "HO2S Heater Resistance DTC's")</p> <p>= Not Valid, Green O2S condition is considered valid until the accumulated air flow is greater than Multiple DTC Use_Green Sensor Delay Criteria - Limit for the following locations: B1S2, B2S2 in Supporting Tables tab. Airflow accumulation is only enabled when airflow</p>	<p>Frequency: Once per trip Note: if NaPOPD_b_ResetFastRespFunc = FALSE for the given Fuel Bank OR NaPOPD_b_RapidResponseActive = TRUE, multiple tests per trip are allowed.</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Low Fuel Condition Only when FuelLevelDataFault Fuel State DTC's Passed ===== After above conditions are met: DFCO mode is continued (wo driver initiated pedal input).	is above 22.0 grams/sec. = False = False = DFCO possible = P2272 = P014A = P013C =====		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor C Circuit Low (applications with LIN MAF)	P227C	<p>Detects an erroneously low value being reported over the LIN serial connection from the BARO C sensor. The diagnostic monitors the BARO C sensor pressure output and fails the diagnostic when the pressure is too low.</p> <p>The BARO C sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure. The BARO C pressure value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	BARO C Pressure	< 50.0 kPa	LIN Communications established with MAF		<p>160 failures out of 200 samples</p> <p>1 sample every 25 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor C Circuit High (applications with LIN MAF)	P227D	<p>Detects an erroneously high value being reported over the LIN serial connection from the BARO C sensor. The diagnostic monitors the BARO C sensor pressure output and fails the diagnostic when the pressure is too high.</p> <p>The BARO C sensor is a pressure transducer which outputs a voltage proportional to the absolute pressure. The BARO C pressure value is transmitted to the ECM by the MAF sensor using the LIN serial communication protocol.</p>	BARO C Pressure	> 115.0 kPa	LIN Communications established with MAF		<p>160 failures out of 200 samples</p> <p>1 sample every 25 msec</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Barometric Pressure Sensor C Circuit Intermittent/Erratic (applications with LIN MAF)	P227E	<p>Detects a noisy or erratic signal in the barometric pressure (BARO) C circuit by monitoring the BARO C sensor and failing the diagnostic when the BARO C signal has a noisier output than is expected.</p> <p>When the value of BARO C in kilopascals (kPa) is determined, a delta is calculated between the current reading and the previous reading. The absolute value of these deltas is summed over a number of BARO C readings. The result of this summation is called a "string length".</p> <p>Since the BARO C signal is anticipated to be relatively smooth, a string length of a particular magnitude indicates a noisy or erratic BARO C signal. The diagnostic will fail if the string length is too high.</p>	<p>String Length</p> <p>Where: "String Length" = sum of "Diff" calculated over</p> <p>And where: "Diff" = ABS(current BARO C reading - BARO C reading from 25 milliseconds previous)</p>	<p>> 100 kPa</p> <p>40 consecutive BARO C readings</p>	LIN Communications established with MAF		<p>4 failures out of 5 samples</p> <p>Each sample takes 1.0 seconds</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance	P228C	This DTC determines if the high pressure pump is not able to maintain target pressure. The fault is set if the measured fuel rail pressure is lower than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	>= P228C P2C1F - High Pressure Pump Control (HPC) fail threshold of pressure too low Mpa (see supporting tables)	High Pressure Pump Performance Diagnostic Enable Battery Voltage Low Side Fuel Pressure Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and	True >= 11 Volts > 0.275 MPa Enabled when a code clear is not active or not exiting device control Engine is not cranking	Positive Pressure Error - 10.00 second failures out of 12.50 second samples	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Engine movement detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -12.0 degC -12 <=Temp degC <= 132		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance	P228D	This DTC determines if the high pressure pump is delivering high pressure that desired pressure. The fault is set if the measured fuel rail pressure is higher than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	<= P228D P2C20 - High Pressure Pump Control (HPC) fail threshold for pressure too high Mpa (see supporting tables)	High Pressure Pump Performance Diagnostic Enable Battery Voltage Low Side Fuel Pressure Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement	True >= 11 Volts > 0.275 MPa Enabled when a code clear is not active or not exiting device control Engine is not cranking	Negative Pressure Error - 10.00 second failures out of 12.50 second samples	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -12.0 DegC -12 <= Temp degC <= 132		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT LOW	P2300	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 11.0	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #1 CIRCUIT High	P2301	Diagnoses Cylinder #1 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT Low	P2303	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #2 CIRCUIT High	P2304	Diagnoses Cylinder #2 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT Low	P2306	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #3 CIRCUIT High	P2307	Diagnoses Cylinder #3 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT Low	P2309	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller ground	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #4 CIRCUIT High	P2310	Diagnoses Cylinder #4 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #5 CIRCUIT Low	P2312	Diagnoses Cylinder #5 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage Low during driver high state (indicates short-to-ground)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #5 CIRCUIT High	P2313	Diagnoses Cylinder #5 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #6 CIRCUIT Low	P2315	Diagnoses Cylinder #6 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #6 CIRCUIT High	P2316	Diagnoses Cylinder #6 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #7 CIRCUIT Low	P2318	Diagnoses Cylinder #7 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #7 CIRCUIT High	P2319	Diagnoses Cylinder #7 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #8 CIRCUIT Low	P2321	Diagnoses Cylinder #8 Ignition Control (EST) output driver circuit for a Short to Ground fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage low during driver high state (indicates short-to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
IGNITION CONTROL #8 CIRCUIT High	P2322	Diagnoses Cylinder #8 Ignition Control (EST) output driver circuit for a Short to Power fault	The ECM detects that the commanded state of the driver and the actual state of the control circuit do not match. Voltage high during driver low state (indicates short- to-power)	$\leq 100 \Omega$ impedance between signal and controller power	Engine running Ignition Voltage	> 11.0 Volts	50 Failures out of 63 Samples 100 msec rate	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transmission Control Torque Request Circuit	P2544	Determines if the torque request from the TCM is valid	Protect error - Serial Communication message 2's complement not equal (\$189/\$199) OR Rolling count error - Serial Communication message (\$189/\$199) rolling count index value OR Range Error - Serial Communication message - (\$189/\$199) TCM Requested Torque Increase OR Multi-transition error - Trans torque intervention type request change	Message <> two's complement of message Message <> previous message rolling count value + one > 600 Nm Requested torque intervention type toggles from not increasing request to increasing request	Diagnostic Status Power Mode Ignition Voltage Engine Running Run/Crank Active No Serial communication loss to TCM (U0101)	Enabled = Run > 6.41 volts = True > 0.50 Sec No loss of communication	>= 16 failures out of 20 samples. Performed on every received message >= 6 Rolling count errors out of 10 samples. Performed on every received message >= 6 range errors out of 10 samples. Performed on every received message >= 3 multi-transitions out of 5 samples. Performed every 200 msec	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Hood Switch Performance	P257D	This DTC monitors the hood switch rationality	<p>Hood Switch position is in an invalid position.</p> <p>Type of Switch: CeHSWR_e_Enumerate d</p> <p>With an enumerated type switch the hood switch reading is invalid in these ranges</p> <p>With a discrete type switch the hood switch reading is invalid when</p> <p>With a percentage type switch the hood switch reading is invalid in these ranges</p> <p>With a resistance type switch the hood switch reading is invalid in these ranges</p>	<p>1281 Ohms to 1404 Ohms</p> <p>Hood Switch 1 and Hood Switch 2 are in the same state (States not equal is proper function)</p> <p>71.50 % to 67.80 % or 45.70 % to 43.40 % or 17.20 % to 14.60 %</p> <p>6,775.00 Ohms to 3,367.10 Ohms or 1,585.00 Ohms to 1,352.20 Ohms or 310.40 Ohms to 300.00 Ohms</p>	<p>The diagnostic is enabled</p> <p>Enabled when Run/Crank is active only, otherwise Run/Crank is not used as an enable</p>	<p>= 1 (1 indicates enabled)</p> <p>= 1 (1 indicates Run/Crank active enabled)</p>	<p>400 failed samples within 500 total samples</p> <p>Diagnostic runs in the 12.5 ms loop</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Hood Switch Short to Ground / Low Voltage	P257E	This DTC monitors the hood switch for a short to ground or low voltage condition	Hood Switch position reading is outside an expected bounds for Type of Switch: CeHSWR_e_Enumerated With an enumerated type switch the bound is hood switch reading With a discrete type switch the bounds are With a percentage type switch the bound is hood switch reading With a resistance type switch the bound is hood switch reading	 ≤ 325 Ohms Hood Switch 1 and Hood Switch 2 are in the same state (States not equal is proper function) ≤ 14.60 % ≤ 300.00 Ohms	The diagnostic is enabled Enabled when Run/Crank is active only, otherwise Run/Crank is not used as an enable	= 1 (1 indicates enabled) = 1 (1 indicates Run/Crank active enabled)	400 failed samples within 500 total samples Diagnostic runs in the 12.5 ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Hood Switch Short to Voltage / High Voltage	P257F	This DTC monitors the hood switch for a short to voltage or high voltage condition	Hood Switch position reading is outside an expected bounds for Type of Switch: CeHSWR_e_Enumerated With an enumerated type switch the bound is hood switch reading With a discrete type switch the bounds are With a percentage type switch the bound is hood switch reading With a resistance type switch the bound is hood switch reading	 >= 3620 Ohms Hood Switch 1 and Hood Switch 2 are in the same state (States not equal is proper function) >= 71.50 % >= 6,775.00 Ohms	The diagnostic is enabled Enabled when Run/Crank is active only, otherwise Run/Crank is not used as an enable	= 1 (1 indicates enabled) = 1 (1 indicates Run/Crank active enabled)	400 failed samples within 500 total samples Diagnostic runs in the 12.5 ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Power Off Timer Performance	P262B	<p>This DTC determines if the hardware timer does not initialize or count properly. There are two tests to ensure proper functioning of the timer: Count Up Test (CUT) and Range Test (RaTe).</p> <p>Count Up Test (CUT): Verifies that the HWIO timer is counting up with the proper increment.</p> <p>Range Test (RaTe): When the run/crank is not active both the hardware and mirror timers are started. The timers are compared when module shutdown is initiated or run/crank becomes active.</p>	<p>Count Up Test: Time difference between the current read and the previous read of the timer</p> <p>Range Test: The variation of the HWIO timer and mirror timer is</p>	<p>> 1.50 seconds</p> <p>> 0.25 %.</p>			<p>Count Up Test: 8 failures out of 40 samples</p> <p>1 sec / sample</p> <p>Continuous while run/crank is not active and until controller shutdown is initiated.</p> <p>Range Test: Once per trip when controller shutdown is initiated or run/crank becomes active.</p>	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Pump "A" Low Flow / Performance	P2635	This DTC detects degradation in the performance of the electronically regulated fuel system by calculating the difference between the sensed, filtered system [line] pressure versus the ECM-commanded pressure [error calculation]. The calculated error is then compared to calibrated fault threshold tables for a fault decision.	Sensed Filtered Fuel System [line] pressure error	<= Low Threshold [Supporting Table] P2635 Threshold Low OR >= High Threshold [Supporting Table] P2635 Threshold High	a) Diagnostic enabled [FDBR_b_FSRD] b) Timer Engine Running [FDBR_t_EngModeRunCoarse] c1) Fuel Flow Rate Valid c2) Ambient Air Pressure Value Defaulted c3) FDB_FuelPresSnrCktFA c4) Reference Voltage Fault Status [DTC P0641] c5) Exhaust AfterTreatment Fuel Injector A Control Circuit Short Low Fault [HCIR_b_GshtFA DTC P20CD] c6) Fuel Pres Sensor Performance Fault Active [DTC P018B] c7) Use Calculated Flow Performance Fault Thresholds [FDBR_b_UseCalcFSRD_FitThrshs] c8) Engine Speed Status Valid c9) FAB_FuelPmpCktFA c10) Fuel Control Enable	a) == TRUE b) >= 30.00 seconds c1) == TRUE c2) <> TRUE c3) <> TRUE c4) <> TRUE c5) <> TRUE c6) <> TRUE c7) <> TRUE c8] == TRUE c9] <> TRUE c10) <> TRUE	1 sample / 12.5 millisec	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Fault Active [DTC P12A6] c11) Fuel Pump Driver Module OverTemp Fault Active [DTC P1255] c12) Fuel Pump Speed Fault Active [DTC P129F] c13) CAN Sensor Bus message \$0C3 Comm Fault [CFMR_b_FTZM_Info1_UcodeCmFA DTC P165C] c14) CAN Sensor Bus Fuel Pmp Spd Command ARC and Checksum Comm Fault Code [CFMR_b_FTZM_Cmd1_UcodeCmFA DTC] c15) Sensor Configuration [FDBR_e_FuelPresSnsrConfig] c16) Sensor Bus Relay On d) Emissions Fuel Level Low [Message \$3FB] e) Fuel Control Enable f) Fuel Pump Control State g) Run_Crank input circuit voltage h) High Pres Fuel Pump	c11) <> TRUE c12) <> TRUE c13) <> TRUE c14) <> TRUE c15) == CeFDBR_e_WiredTo_FTZM c16) == TRUE d) <> TRUE e) == TRUE f) == NORMAL g) 11.00 volts <= Run_Crank_V <= 32.00 volts h) <> TRUE		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Mode Management Enabled j) High Pres Fuel Pump Control Mode k) Instantaneous Fuel Flow [FCBR_dm_InstFuelFlow] m1) Fuel Pmp Speed Command Alive Rolling Count and Checksum Error [CAN Bus B \$0CE] [CFMR_b_FTZM_Cmd1_ARC_ChkErr DTC] m2) CAN Sensor Bus message \$0C3_Available m3) Fuel Pres Sensor Ref Voltage Status Message Counter Incorrect Alive Rolling Count and Checksum Error [CAN Bus B \$0C3] [CFMR_b_FTZM_Info1_ARC_ChkErr DTC] n) Timer - Diagnostic Enable	j) <> Disabled Mode AND a8b) <> ZeroFlow Mode k) 0.05 grams/sec <= InstFuelFlow <= Max Allowed Flow [Supporting Table] P2635 Max Fuel Flow m1) <> TRUE m2) == TRUE m3) <> TRUE n) > 2.00 seconds		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) Low	P263A	Detects an inoperative malfunction indicator lamp control circuit. This diagnostic reports the DTC when a short to ground is detected.	Voltage low during driver off state (indicates short-to-ground)	Short to ground: ≤ 0.5 Ω impedance between output and controller ground	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11.00 volts	1 failures out of 1 samples 50 ms / sample	Type B, No MIL NO MIL Note: In certain controllers P0650 may also set (MIL Control Open Circuit)

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Malfunction Indicator Lamp (MIL) Control Circuit (ODM) High	P263B	Detects an inoperative malfunction indicator lamp control circuit. This diagnostic reports the DTC when a short to power is detected.	Voltage high during driver on state (indicates short to power)	Short to power: ≤ 0.5 Ω impedance between output and controller power	Run/Crank Voltage Remote Vehicle Start is not active	Voltage ≥ 11.00 volts	4 failures out of 5 samples 50 ms / sample	Type B, No MIL NO MIL

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transfer Case Control Module Transfer Case Command State Rationality - 4WD high command not 4WD high ratio	P279A	Monitor measured transfer case gear ratio is 4WD low ratio or neutral while the transfer case control module command state is 4WD high. The 4WD measured transfer case ratio is calculated as transmission output shaft speed divided by the transfer case output shaft speed, both speed are measured values based on speed sensors.	transfer case control module transfer case command state AND measured transfer case ratio is in 4WD low ratio window OR measured transfer case ratio is in neutral window AND measured transfer case ratio is in 4WD low ratio window (measured transfer case ratio = transmission output speed / transfer case output speed) update rate 12.5 milliseconds	= 4WD high 4WD low ratio window ≤ 3.00 ≥ 2.40 neutral ratio window ≥ 1.30 ≤ 0.70 OR ≥ 3.00 ≤ 2.40 4WD low ratio window ≤ 2.90 ≥ 2.50	transmission gear is forward gear: transmission output shaft speed engine torque engine speed accelerator pedal position brake pedal position transmission gear is reverse gear: transmission output shaft speed engine torque engine speed accelerator pedal position brake pedal position vehicle speed diagnostic monitor enable PTO active engine power limited DTCs not fault active	≥ 500.0 RPM ≥ 70.0 Nm ≥ 300.0 RPM ≥ 5.0 % ≤ 100.0 % ≥ 500.0 RPM ≥ 80.0 Nm ≥ 300.0 PRM ≥ 5.0 % ≤ 100.0 % >= 3.00 = 1 Boolean = FALSE = FALSE CrankSensor_FA VehicleSpeedSensor_FA EngineTorqueEstInaccuracy P057B, P057C, P057D, P057E P17D4, P279B, P279C P0502, P0503, P0722, P0723, P2160, P2161	fail time ≥ 7.00 seconds out of sample time ≥ 10.00 seconds update rate 12.5 milliseconds	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transfer Case Control Module Transfer Case Command State Rationality - 4WD low command not 4WD low ratio	P279B	Monitor measures transfer case gear ratio is 4WD high ratio or neutral while the transfer case control module command state is 4WD low. The 4WD measured transfer case ratio is calculated as transmission output shaft speed divided by the transfer case output shaft speed, both speed are measured values based on speed sensors.	transfer case control module transfer case command state AND measured transfer case ratio is in 4WD high ratio window OR measured transfer case ratio is in neutral window AND measured transfer case ratio is in 4WD high ratio window (measured transfer case ratio = transmission output speed / transfer case output speed) update rate 12.5 milliseconds	= 4WD low 4WD high ratio window ≤ 1.30 ≥ 0.70 neutral ratio window ≥ 1.30 ≤ 0.70 OR ≥ 3.00 ≤ 2.40 4WD high ratio window ≤ 1.20 ≥ 0.80	transmission gear is forward gear: transmission output shaft speed engine torque engine speed accelerator pedal position brake pedal position transmission gear is reverse gear: transmission output shaft speed engine torque engine speed accelerator pedal position brake pedal position vehicle speed diagnostic monitor enable PTO active engine power limited DTCs not fault active	≥ 500.0 RPM ≥ 65.0 Nm ≥ 300.0 RPM ≥ 5.0 % ≤ 100.0 % ≥ 500.0 RPM ≥ 80.0 Nm ≥ 300.0 PRM ≥ 5.0 % ≤ 100.0 % >= 3.00 = 1 Boolean = FALSE = FALSE CrankSensor_FA VehicleSpeedSensor_FA EngineTorqueEstInaccuracy P057B, P057C, P057D, P057E P17D4, P279A, P279C P0502, P0503, P0722, P0723, P2160, P2161	fail time ≥ 7.00 seconds out of sample time ≥ 10.00 seconds update rate 12.5 milliseconds	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Transfer Case Control Module Transfer Case Command State Rationality - 4WD neutral command not 4WD neutral ratio	P279C	Monitor measured transfer case gear ratio is 4WD high ratio or 4WD low ratio while the transfer case control module command state is 4WD neutral. The 4WD measured transfer case ratio is calculated as transmission output shaft speed divided by the transfer case output shaft speed, both speed are measured values based on speed sensors.	transfer case control module transfer case command state AND measured transfer case ratio is in 4WD low ratio window OR measured transfer case ratio is in 4WD high ratio window AND measured transfer case ratio is in 4WD low ratio window or in 4WD high ratio window (measured transfer case ratio = transmission output speed / transfer case output speed) update rate 12.5 milliseconds	= 4WD neutral 4WD low ratio window ≤ 3.00 ≥ 2.40 4WD high ratio window ≥ 1.30 ≤ 0.70 4WD neutral ratio window ≤ 2.90 ≥ 2.50 OR ≤ 1.20 ≥ 0.80	transmission gear is forward gear: transmission output shaft speed engine torque engine speed accelerator pedal position brake pedal position transmission gear is reverse gear: transmission output shaft speed engine torque engine speed accelerator pedal position brake pedal position vehicle speed diagnostic monitor enable PTO active engine power limited DTCs not fault active	≥ 300.0 RPM ≥ -20.0 Nm ≥ 0.0 RPM ≥ 0.0 % ≤ 100.0 % ≥ 500.0 RPM ≥ 80.0 Nm ≥ 300.0 PRM ≥ 5.0 % ≤ 100.0 % ≥ 3.00 = 1 Boolean = FALSE = FALSE CrankSensor_FA VehicleSpeedSensor_FA EngineTorqueEstInaccuracy P057B, P057C, P057D, P057E P17D4, P279A, P279B P0502, P0503, P0722, P0723, P2160, P2161	fail time ≥ 10.50 seconds out of sample time ≥ 15.00 seconds update rate 12.5 milliseconds	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Internal Control Module SIDI High Pressure Pump min/max authority During Catalyst Warm Up	P2C1E	This DTC determines when the high pressure pump control has reached to its max or min authority during Cataylst Warm up	High Pressure Fuel Pump Delivery Angle OR High Pressure Fuel Pump Delivery Angle	$\geq 124^\circ$ $\leq 0^\circ$	Catalyst Warm Up High Pressure Pump Performance Diagnostic Enable Battery Voltage Low Side Fuel Pressure Barometric Pressure Inlet Air Temp Fuel Temp Catalyst Warm up enabled (See Definition in Supporting Material below) Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or	True ≥ 11 Volts > 0.275 MPa Enabled when a code clear is not active or not exiting device control Engine is not cranking ≥ 70.0 KPA ≥ -12.0 degC $-12 \leq \text{Temp degC} \leq 132$ = True	Windup High/Low 10.00 seconds failures out of 12.50 Seconds samples	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active			

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance During Catalyst Warm Up	P2C1F	This DTC determines if the high pressure pump is not able to maintain target pressure Catalyst Warm Up. The fault is set if the measured fuel rail pressure is lower than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	>= P228C P2C1F - High Pressure Pump Control (HPC) fail threshold of pressure too low Mpa (see supporting tables)	Catalyst Warm Up High Pressure Pump Performance Diagnostic Enable Battery Voltage Low Side Fuel Pressure Catalyst Warm up enabled (See Definition in Supporting Material below) Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not active and	True >= 11 Volts > 0.275 MPa = True Enabled when a code clear is not active or not exiting device control Engine is not cranking	Positive Pressure Error - 10.00 second failures out of 12.50 second samples	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true and Manufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -12.0 degC -12 <=Temp degC <= 132		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
SIDI High Pressure Pump Performance During Catalyst Warm Up	P2C20	This DTC determines if the high pressure pump is delivering high pressure that desired pressure Catalyst Warm Up. The fault is set if the measured fuel rail pressure is higher than desired fuel pressure by a value that can impact emission and drivability for a number of pump events.	Fuel Pressure Error (Desired Pressure - Measure Pressure)	<= P228D P2C20 - High Pressure Pump Control (HPC) fail threshold for pressure too high Mpa (see supporting tables)	Catalyst Warm Up High Pressure Pump Performance Diagnostic Enable Battery Voltage Low Side Fuel Pressure Catalyst Warm up enabled (See Definition in Supporting Material below) Additional Enable Conditions: All must be true (High Pressure Pump is enabled and High Fuel pressure sensor ckt is Not (FA,FP or TFTKO) and High Pressure fuel pump ckt is Not (FA,FP or TFTKO) and Cam or Crank Sensor Not FA and IAT,IAT2,ECT Not FA and Low side Fuel Pump Relay ckt Not FA and Estimate fuel rail pressure is valid and Green Engine (In assembly plant) is not enabled and Not if low fuel condition and Low side Fuel Pump is on and Injector Flow Test is not	True >= 11 Volts > 0.275 MPa = True Enabled when a code clear is not active or not exiting device control Engine is not cranking	Negative Pressure Error - 10.00 second failures out of 12.50 second samples	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					active and Device control commanded pressure is false and Device control pump ckt enabled on is false and Engine movement detected is true andManufacturers enable counter is 0) Flex Fuel Sensor Not FA Ignition voltage out of correlation error(P1682) not active Barometric Pressure Inlet Air Temp Fuel Temp	>= 70.0 KPA >= -12.0 DegC -12 <= Temp degC <= 132		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 1	P30D6	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>= 6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 2	P30D7	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>= 6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 3	P30D8	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>= 6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 4	P30D9	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>= 6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 5	P30DA	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>= 6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 6	P30DB	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>= 6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 7	P30DC	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>= 6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Control Module Serial Peripheral Interface Bus 8	P30DD	This DTC detects intermittent and continuous invalid SPI messages. This is based on the detection of missing or invalid receive message within the main processor before receiving a valid message.	This function detects a serial communications fault based upon the detection of missing or invalid (receive) message within the main processor.		Run/Crank voltage	>= 6.41 Volts, else the failure will be reported for all conditions	In the primary processor, 8 / 16 counts intermittent 12.5 ms /count in the ECM main processor	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending Power Mode is not run/ crank Battery voltage	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled) >= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending Power Mode is not run/ crank Battery voltage	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled) >= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If calibratable low voltage disable mode is not Never Disabled Low voltage disable mode: OBDII If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending Power Mode is not run/ crank Battery voltage	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled) >= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If calibratable low voltage disable mode is not Never Disabled Low voltage disable mode: OBDII If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending Power Mode is not run/ crank Battery voltage	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled) >= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If calibratable low voltage disable mode is not Never Disabled Low voltage disable mode: OBDII If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending Power Mode is not run/ crank Battery voltage	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled) >= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If calibratable low voltage disable mode is not Never Disabled Low voltage disable mode: OBDII If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending Power Mode is not run/ crank Battery voltage	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled) >= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.	
Lost Communicati on With Body Control Module	U0140	This DTC monitors for a loss of communication with the Body Control Module.	Message is not received from controller for		General Enable Criteria:	>= 3,000.00 milliseconds	Diagnostic runs in 12.5 ms loop	Type C, No SVS "Emissio ns Neutral Diagnost ics – Type C"	
			Message \$0F1	≥ 500.00 milliseconds	All below criteria have been met for				
			Message \$12A	≥ 10,000.00 milliseconds	If message is on Bus A: U0073 not active				
			Message \$1E1	≥ 500.00 milliseconds	If message is on Bus B: U0074 not active				
			Message \$1F1	≥ 500.00 milliseconds	If message is on Bus S: U0076 not active				
			Message \$1F3	≥ 10,000.00 milliseconds	CAN channel is requesting full communications				
			Message \$3C9	≥ 10,000.00 milliseconds	Normal CAN transmission on Bus is enabled				
			Message \$3CB	≥ 10,000.00 milliseconds	If bus type is Sensor Bus, sensor bus relay is on				
			Message \$3F1	≥ 10,000.00 milliseconds	Accessory mode to off mode not pending				
			Message \$451	≥ 500.00 milliseconds	Battery voltage				> 11.00 Volts
			Message \$4D7	≥ 10,000.00 milliseconds	Conroller is an OBD controller Or Battery Voltage				<= 18.00 Volts
			Message \$4E1	≥ 10,000.00 milliseconds	Controller type: OBD Controller				
Message \$4E9	≥ 10,000.00 milliseconds	If power mode = Run/ Crank: Power Mode is run							

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If calibratable low voltage disable mode is not Never Disabled Low voltage disable mode: OBDII If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending Power Mode is not run/ crank Battery voltage	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled) >= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If calibratable low voltage disable mode is not Never Disabled Low voltage disable mode: OBDII If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending Power Mode is not run/ crank Battery voltage	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled) >= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If power mode = Run/ Crank: Power Mode is run If calibratable low voltage disable mode is not Never Disabled Low voltage disable mode: OBDII If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled)		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Mode is not run/ crank Battery voltage	>= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If power mode = Run/ Crank: Power Mode is run If calibratable low voltage disable mode is not Never Disabled Low voltage disable mode: OBDII If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled)		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Power Mode is not run/ crank Battery voltage	>= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending Power Mode is not run/ crank Battery voltage	>= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled) >= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Fuel Tank Zone Module Configuration Error	U101A	FTZM Pump Control Configuration Management provides a method for a Diagnostic and Emissions-Critical Electronic Control Unit (DEC ECU) to communicate configuration information to an OBD Smart Device (SD); in this case the FTZM. The FTZM contains pre-loaded sets of calibrations, each of which specifies proper tuning values for electronic commutation of corresponding fuel pump motor variants including a default value that denotes a non-operational [factory default] pump variant. This configuration management feature provides a method to reduce the number of FTZM end-item part numbers. The Configuration Error Diagnostic runs every 100ms to verify that a calibration index value is present that is not the factory default value. When the diagnostic identifies that the default index value is loaded, the	FTZM Fuel Pump Configuration Calibration Index Value	= Factory Default Index Value OR = Not Configured Index Value [device failed to accept calibration value on 1st wake-up]	a) Diagnostic enabled; b) Device feedback Faulted; c) Diagnostic system disabled; d) CAN serial data message \$3C8 received	a) = 1.00 [1=TRUE; 0 <> True] b) <> True; c) <> True; d) = TRUE	6.00 failures of 8.00 samples ; 100 millisecond / sample	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
		DTC is set.						

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If calibratable low voltage disable mode is not Never Disabled Low voltage disable mode: OBDII If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown not impending Power Mode is not run/ crank Battery voltage	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled) >= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					LIN channel Wakeup Method: Diagnostic is enabled LIN channel is enabled LIN channel is requesting full communications LIN module is initialized The following criteria have been enabled for: Accessory mode to off mode not pending Battery voltage Conroller is an OBD controller Or Battery Voltage	Global A: 1.00 (1 indicates enabled) Global B: 0.00 (1 indicates enabled) Global A: 1.00 (1 indicates enabled) Global B: 0.00 (1 indicates enabled) >= 3,000.00 milliseconds > 11.00 Volts <= 18.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Engine Control Module LIN Bus 2	U1346	This DTC monitors for a LIN bus off condition on LIN Bus 2.	<p>Loss of Communication Method:</p> <p>The total number of diagnostic enabled slave nodes on LIN Bus 2</p> <p>Or</p> <p>LIN channel Wakeup Method:</p> <p>LIN channel wakeup repetition counter</p>	<p>= Total number of slave nodes on LIN Bus 2 that have reported lost communications DTCs</p> <p>>= 10.00 counts</p>	<p>Loss of Communication Method:</p> <p>Diagnostic is enabled</p> <p>LIN channel is enabled</p> <p>LIN module is initialized</p> <p>The following criteria have been enabled for:</p> <p>LIN channel is requesting full communications</p> <p>Accessory mode to off mode not pending</p> <p>Battery voltage</p> <p>Conroller is an OBD controller</p> <p>Or</p> <p>Battery Voltage</p> <p>Controller type: OBD Controller</p> <p>If power mode = Run/ Crank:</p> <p>Power Mode is run</p> <p>If calibratable low voltage disable mode is not Never Disabled</p> <p>Low voltage disable mode: OBDII</p> <p>If OBDII:</p>	<p>1.00 (1 indicates enabled)</p> <p>1.00 (1 indicates enabled)</p> <p>>= 3,000.00 milliseconds</p> <p>> 11.00 Volts</p> <p><= 18.00 Volts</p>	Dependent on bus loading.	Type A, 1 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					Run/Crank ignition voltage	>= 11.00 Volts		
					If EOBD: Run/Crank ignition voltage	>= 9.00 Volts		
					If Secure: Starter motor engaged for Or Run/Crank ignition voltage	> 15.00 milliseconds > 8.41 Volts		
					If Hybrid Secure: Run/Crank ignition voltage	>= 6.41 Volts		
					If power mode = Accessory			
					Off key cycle diagnostics are enabled Or Controller is an OBD controller	0.00 (1 indicates enabled)		
					Controller shutdown not impending			
					Power Mode is not run/ crank			
					Battery voltage	>= 11.00 Volts		
					LIN channel Wakeup Method:			
					Diagnostic is enabled	1.00 (1 indicates enabled)		
					LIN channel is enabled	1.00 (1 indicates enabled)		
					LIN channel is requesting			

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					full communications LIN module is initialized The following criteria have been enabled for: Accessory mode to off mode not pending Battery voltage Controller is an OBD controller Or Battery Voltage	>= 3,000.00 milliseconds > 11.00 Volts <= 18.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If calibratable low voltage disable mode is not Never Disabled Low voltage disable mode: OBDII If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending Power Mode is not run/ crank Battery voltage	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled) >= 11.00 Volts		

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Lost Communication with ECM	U18D5	This DTC monitors for a CGM Lost Communication with ECM error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the CGM Lost Communication with ECM DTC has set in the CGM.		General Enable Criteria: Message \$3CF Central Gateway Module ECM	is being received is present on the bus is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Lost Communication with TCM	U18D7	This DTC monitors for a CGM Lost Communication with TCM error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the CGM Lost Communication with TCM DTC has set in the CGM.		General Enable Criteria: Message \$3CF Central Gateway Module TCM	is being received is present on the bus is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
CGM Lost Communication with BSCM1	U18DC	This DTC monitors for a CGM Lost Communication with BSCM1 error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the CGM Lost Communication with BSCM1 DTC has set in the CGM.		General Enable Criteria: Message \$3CF Central Gateway Module BSCM1	is being received is present on the bus is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Central Gateway Module High Speed CAN Bus Off	U2413	This DTC monitors for a Central Gateway Module High Speed CAN Bus Off error as determined by the CGM	The CGM Diagnostic Status Message signal in GMLAN frame \$3CF indicates that the Central Gateway Module High Speed CAN Bus Off DTC has set in the CGM.		General Enable Criteria: Message \$3CF Central Gateway Module	is being received is present on the bus	Diagnostic runs in 12.5 ms loop	Type B, 2 Trips

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Front Object Detection Control Module Torque Request Signal Message Counter Incorrect	P15F6	<p>Detects rolling count or protection value errors in Collision Preparation System Axle Torque Command serial data signal</p> <p>"Emissions Neutral Default Action : When the ECM determines that a serial communication fault has occurred with the EOCM in frame \$2CD, the code is set and the Collision Preparation System is disabled." Only applicable for applications with Full Speed Range Adaptive Cruise Control and Collision Preparation System feature.</p>	If x of y rolling count / protection value faults occur, disable collision preparation system for duration of fault		Front Object Detection Module Torque Request Serial Data Error Diagnostic Enable	1.00	4 / 10 counts	Type C, No SVS , "Emissions Neutral Diagnost ics – special type C"

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
Automatic Braking Engine Torque Request Signal Message Incorrect	P15F8	<p>Detects rolling count or protection value errors Rear Virtual Bumper Axle Torque Command serial data signal</p> <p>"Emissions Neutral Default Action : When the ECM determines that a serial communication fault has occurred with the EOCM in frame \$2F9, the code is set and the auto braking feature is disabled for the remainder of the key cycle." Only applicable for applications with Full Speed Range Adaptive Cruise Control and Collision Preparation System feature.</p>	<p>If x of y rolling count / protection value faults occur, disable rear virtual bumper or collision preparation system for duration of fault</p>		Automatic Braking Engine Torque Request Serial Data Error Diagnostic Enable	1.00	4 / 10 counts	Type C, No SVS , "Emissions Neutral Diagnostics – special type C"

20 OBDG03D ECM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illum.
					If calibratable low voltage disable mode is not Never Disabled Low voltage disable mode: OBDII If OBDII: Run/Crank ignition voltage If EOBD: Run/Crank ignition voltage If Secure: Starter motor engaged for Or Run/Crank ignition voltage If Hybrid Secure: Run/Crank ignition voltage If power mode = Accessory: Off key cycle diagnostics are enabled Or Controller is an OBD controller Controller shutdown is not impending Power Mode is not run/ crank Battery voltage	>= 11.00 Volts >= 9.00 Volts > 15.00 milliseconds > 8.41 Volts >= 6.41 Volts 0.00 (1 indicates enabled) >= 11.00 Volts		

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0011_CamPosErrorLimlc1

Description: Maximum Intake Cam 1 phase error as a function of engine speed and engine oil temperature.

Value Units: Maximum Intake Cam 1 phase error (degCAM)

X Unit: Engine Oil Temperature (degC)

Y Units: Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
1,200	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
1,600	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
2,000	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
2,400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
2,800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
3,200	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
3,600	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
4,000	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
4,400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
4,800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
5,200	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
5,600	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
6,000	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
6,400	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0
6,800	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0	8.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0011_P0021_P05CC_P05CD_EngOilPressEnbllc

Description: Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met

Value Units: Time (sec)

X Unit: Engine Coolant Temperature (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0011_P0021_P05CC_P05CD_HiEngSpdHiDsbllc

Description: Minimum engine speed to disable Intake cam

Value Units: Engine Speed (rpm)

X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000	7,000

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0011_P0021_P05CC_P05CD_HiEngSpdLoEnbllc

Description: Maximum engine speed to enable Intake cam - works as hysteresis.

Value Units: Engine Speed (rpm)

X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800	6,800

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0011_P0021_P05CC_P05CD_LoPresHiEnbllc

Description: Intake cam is enabled when oil pressure exceeds this value

Value Units: Engine Speed (rpm)

X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0011_P0021_P05CC_P05CD_LoPresLoDsbllc

Description: Intake cam is disabled when oil pressure falls below this value

Value Units: Engine Oil Pressure (kPa)

X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	170	170	170	170	160	150	150	150	150	150	150	150	150	150	160	170	170

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0011_P0021_P05CC_P05CD_LoRpmHiEnbllc

Description: Intake cam is enabled when engine speed exceeds this value.

Value Units: Engine Speed (rpm)

X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	825	825	825	825	800	800	800	800	800	800	800	800	875	925	1,175	1,325	1,825

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0011_P0021_P05CC_P05CD_LoRpmLoDsbllc

Description: Intake cam is disabled when engine speed is below this value.

Value Units: Engine Speed (rpm)

X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	800	800	800	800	750	750	750	750	750	750	750	750	750	750	800	800	800

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0011_P0021_P05CC_P05CD_P0014_P0024_P05CE_P05CF_ColdStartEngRunning

Description: Engine running time must be greater than this threshold during a cold start to enable cam phasing

Value Units: Time (sec)
X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	15	15	14	13	12	11	10	9	8	7	6	5	4	4	4	4	4

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0011_P05CC_StablePositionTimeIc1

Description: Minimum time for Intake Cam 1 phase position to be stable to enable performance diagnostic.

Value Units: Minimum time (sec)
X Unit: Engine Oil Temperature (degC)
Y Units: Engine Speed (rpm)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
1,200	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
1,600	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
2,000	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
2,400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
2,800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
3,200	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
3,600	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
4,000	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
4,400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
4,800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
5,200	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
5,600	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
6,000	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
6,400	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4
6,800	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4	3.4

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0014_P0024_P05CE_P05CF_EngOilPressEnblEc

Description: Delay time before the oil pressure enable flag is set assuming all the oil pressure enable criteria are met

Value Units: Time (sec)

X Unit: Engine Coolant Temperature (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0014_P0024_P05CE_P05CF_HiEngSpdHiDsbIEc

Description: Exhaust cam is disabled when engine speed exceeds this value

Value Units: Engine Speed (rpm)

X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0014_P0024_P05CE_P05CF_HiEngSpdLoEnblEc

Description: Exhaust cam is enabled when engine speed remains below this value

Value Units: Engine Speed (rpm)

X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoPresHiEnbIEc

Description: Exhaust cam is enabled when oil pressure exceeds this value

Value Units: Engine Oil Pressure (kPa)

X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180	180

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoPresLoDsblEc

Description: Exhaust cam is disabled when oil pressure falls below this value

Value Units: Engine Oil Pressure (kPa)

X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	125	125	125	125	125	125	125	125	125	125	125	125	125	125	125	125	125

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoRpmHiEnbIEc

Description: Exhaust cam is enabled when engine speed exceeds this value.

Value Units: Engine Speed (rpm)

X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	825	825	825	825	800	800	800	800	800	800	800	800	875	925	1,175	1,325	1,825

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0014_P0024_P05CE_P05CF_LoRpmLoDsblEc

Description: Exhaust cam is disabled when engine speed is below this value.

Value Units: Engine Speed (rpm)

X Unit: Engine Oil Temp (degC)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	750	750	750	750	750	750	750	750	750	750	750	750	750	750	750	750	750

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

Description: P0016, P0017, P0018, P0019: Cam Correlation Oil Temperature Threshold

Value Units: Engine Run Time- Seconds

X Unit: Oil Temperature- C

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	20.0	10.0	7.0	5.0	3.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	2.0	2.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0016-0019 Mid-Park Phaser Delay

Description: P0016-0019 Mid-Park Phaser Park Delay. Total delay is twice the calibration value as both 'hi' side and 'lo' side park check sequences are delayed by the stated calibration values

Value Units: Time - seconds

X Unit: Oil Temperature - degC

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	600.0	600.0	320.0	36.0	36.0	36.0	36.0	20.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0	6.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0071: OAT Performance Drive Equilibrium Engine Off

Description: OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine off (for hybrid applications)

Value Units: Counter Increment Value (Unitless)

X Unit: Vehicle Speed (KPH)

y/x	0.0	20.0	30.0	45.0	60.0	75.0	90.0	105.0	120.0
1.0	0.0	4.0	6.0	6.8	7.3	7.8	8.0	8.0	8.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0071: OAT Performance Drive Equilibrium Engine Running

Description: OAT Performance Diagnostic counter increment for determining OAT-IAT equilibrium for engine running

Value Units: Counter Increment Value (Unitless)

X Unit: Vehicle Speed (KPH)

Y Units: Engine Air Flow (Grams/Second)

y/x	0.0	20.0	30.0	45.0	60.0	75.0	90.0	105.0	120.0
0.0	-0.2	0.1	0.2	0.3	0.4	0.4	0.5	0.5	0.5
15.0	-0.2	0.1	0.2	0.3	0.4	0.4	0.5	0.5	0.5
25.0	-0.2	0.1	0.2	0.3	0.4	0.4	0.5	0.5	0.5
35.0	-0.2	0.1	0.2	0.3	0.4	0.4	0.5	0.5	0.5
45.0	-0.2	0.1	0.2	0.3	0.4	0.4	0.5	0.5	0.5
55.0	-0.2	0.1	0.2	0.3	0.4	0.4	0.5	0.5	0.5
65.0	-0.2	0.1	0.2	0.3	0.4	0.4	0.5	0.5	0.5
75.0	-0.2	0.1	0.2	0.3	0.4	0.4	0.5	0.5	0.5
85.0	-0.2	0.1	0.2	0.3	0.4	0.4	0.5	0.5	0.5

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP1 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP1 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
 X Unit: Engine Speed (RPM)

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: MAP2 Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 MAP2 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)
X Unit: Engine Speed (RPM)

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0101, P0106, P0121, P012B, P0236, P1101: TPS Residual Weight Factor based on RPM

Description: P0101_P0106_P0121_P012B_P0236_P1101 TPS Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)

X Unit: Engine Speed (RPM)

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P050D_P1400_CatalystLightOffExtendedEngineRunTimeExit

Description: Exit Catalyst Warm-up mode if Engine Run Time is greater than this value. This table is based on percent ethanol (x-axis) and catmon's NormRatio_EWMA value (y-axis). The NormRatio_EWMA value determines the state of the catalyst. Typically, NormRatio_EWMA values below 0.35 (0 is bad and 1 is good) represent catalysts that have degraded. The emission performance of these degraded catalysts can be improved by extending catalyst light off of GetE85R_Pct_FFS_CompAtEngFloat.

y/x	0	25	50	75	100
0.000	20	20	20	20	20
0.125	20	20	20	20	20
0.250	20	20	20	20	20
0.375	20	20	20	20	20
0.500	20	20	20	20	20
0.625	20	20	20	20	20
0.750	20	20	20	20	20
0.875	20	20	20	20	20
1.000	20	20	20	20	20

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P1400_ColdStartDiagnosticDelayBasedOnEngineRunTime

Description: Quality weight-based on engine run time. This allows adjustment of the weighting factors at various engine run times in order to prevent the updating of the cumulative quality timer or to change the value of the average qualified residual energy calculation to prevent false Fails of the diagnostic under circumstances inappropriate to update the calculation of the average qualified residual value.

y/x	0	1	1	5	11	16	21	27	32
1	0	0	0	1	1	1	1	1	1

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P1400_ColdStartDiagnosticDelayBasedOnEngineRunTimeCalAxis

Description: This is the x-axis for the KtCSED_K_TimeWght calibration table. Refer to the description for KtCSED_K_TimeWght for details.

y/x	1	2	3	4	5	6	7	8	9
1	0	1	1	5	11	16	21	27	32

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P1400_EngineSpeedResidual_Table

Description: This 1x17 table of engine exhaust flow values is used to calculate both the desired and the actual engine exhaust flow based on desired and actual engine speed. The desired engine exhaust flow is gathered from the desired engine speed (VeSPDR_n_EngDsrd). The value used for the actual engine exhaust flow is based on the actual engine RPM value.

y/x	0	500	600	650	700	750	800	850	900	1,050	1,100	1,150	1,200	1,250	1,300	1,450	1,800
1	0	4	4	4	4	4	6	8	10	12	12	12	12	12	12	12	18

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P1400_SparkResidual_Table

Description: Predicted engine-out energy potential based on either the desired cold start spark advance value or the actual spark advance value. ExhEngyPerUnitMass calibration is used to calculate both desired exhaust energy and actual energy. The desired and actual exhaust energy per unit mass values are used in part to calculate the desired exhaust energy per unit time and actual exhaust energy per unit time. Both desired and actual go into the residual exhaust energy per unit time calculation.

y/x	-20	-16	-12	-8	-5	0	4	8	12
1	2.50	2.19	2.00	1.81	1.75	0.88	0.75	0.69	0.56

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on MAF Est

Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on MAF Est

Value Units: Weight Factor (Unitless)

X Unit: Estimated Engine Air Flow (Grams/Second)

y/x	0	50	70	73	76	79	82	85	89	95	100	110	120	150	200	280	350
1	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0101, P0106, P010B, P0121, P012B, P0236, P1101: MAF1 Residual Weight Factor based on RPM

Description: P0101_P0106_P010B_P0121_P012B_P0236_P1101 MAF1 Residual Weight Factor based on RPM

Value Units: Weight Factor (Unitless)

X Unit: Engine Speed (RPM)

y/x	0	400	750	1,100	1,450	1,800	2,150	2,500	2,850	3,200	3,550	3,900	4,250	4,600	4,950	5,300	6,000
1	0.000	1.000	1.000	1.000	1.000	1.000	1.000	1.000	0.900	0.800	0.750	0.700	0.700	0.700	0.700	0.700	0.700

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0116_Fail if power up ECT exceeds IAT by these values

Description: KtECTD_T_HSC_FastFailTempDiff

Value Units: Fast Failure temp difference (°C)

X Unit: IAT Temperature at Power up (°C)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	80	80	80	60	60	40	40	30	30	30	30	30	30	30	30	30	30

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0128_Maximum Accumulated Energy for Start-up ECT conditions - Alternate

Description: KtECTR_E_CTR_WrmUpEnrgyLimTest1

Value Units: Cooling system energy failure threshold (kJ)

X Unit: Minimum ECT for the key cycle (°C)

y/x	-20	-7	10	30	45	60	85
1	13,397	11,632	9,324	6,608	4,571	2,535	2,535

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0128_Maximum Accumulated Energy for Start-up ECT conditions - Primary

Description: KtECTR_E_CTR_WrmUpEnrgyLimTest0

Value Units: Cooling system energy failure threshold (kJ)

X Unit: Minimum ECT for the key cycle (°C)

y/x	-20	-7	10	30	45	60	85
1	16,901	14,973	12,452	9,486	7,261	5,036	5,036

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0606_Last Seed Timeout f(Loop Time)

Description: The max time for the Last Seed Timeout as a function of operating loop time sequence.

P0606_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000	200.000

P0606_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	200.000	500.000	500.000	1,000.000	1,000.000	8,191.875	8,191.875	8,191.875

Initial Supporting table - P0606_PSW Sequence Fail f(Loop Time)

Description: Fail threshold for PSW per operating loop.

P0606_PSW Sequence Fail f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	5	3	5	3	5	3	5	3

P0606_PSW Sequence Fail f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	5	3	5	3	5	5	5	5

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0606_PSW Sequence Sample f(Loop Time)

Description: Sample threshold for PSW per operating loop.

P0606_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	4	4	4	4	4	4	4	4

P0606_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	4	4	4	4	4	4	4	4

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P16F3_Delta MAP Threshold f(Desired Engine Torque)

Description: Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	13.35	13.35	13.35	13.35	13.35	13.35

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P16F3_Speed Control External Load f(Oil Temp, RPM)

Description: Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

y/x	-40.00	-15.00	5.00	32.00	55.00	90.00
350.00	439.00	439.00	439.00	434.28	412.25	256.54
450.00	439.00	439.00	439.00	353.08	333.68	210.57
570.00	439.00	388.61	349.08	248.10	230.94	154.38
650.00	422.36	370.44	335.83	240.40	224.49	136.36
750.00	400.06	351.40	323.93	250.50	234.14	118.05
850.00	398.50	356.58	332.39	271.68	255.33	138.64
950.00	400.59	359.12	332.62	287.61	265.17	145.41
1,050.00	392.72	351.60	323.18	289.73	262.24	150.96
1,150.00	349.22	309.95	282.61	238.46	213.69	126.20
1,350.00	285.43	248.11	222.07	176.68	155.25	115.00
1,600.00	198.80	166.04	141.72	97.85	80.07	87.00
2,150.00	140.94	109.38	87.12	44.66	31.23	25.00
2,400.00	120.41	89.25	67.68	26.87	14.88	3.20
3,100.00	85.47	54.94	34.45	-4.41	-14.11	-21.86
4,000.00	63.09	32.84	12.84	-24.15	-32.82	-42.54
4,900.00	48.80	18.55	-1.45	-38.44	-47.10	-56.85
5,800.00	33.49	3.24	-16.76	-53.56	-62.22	-72.79

20 OBDG03D ECM Supporting Tables

Initial Supporting table - 1st_FireAftrMisfr_Acel

Description: Used for P0300 - P0308, Multiplier for establishing the expected acceleration of the cylinder after the misfire

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,800	2,200	2,600	3,000	3,001	5,000	6,000	7,000
8	0.65	0.65	0.69	0.66	0.66	0.76	0.66	0.68	0.65	0.65	0.66	0.65	0.67	0.67	0.67	0.67	0.67
12	0.64	0.54	0.53	0.54	0.51	0.57	0.60	0.65	0.50	0.60	0.65	0.65	0.67	0.67	0.67	0.67	0.67
16	0.55	0.24	0.38	0.45	0.40	0.42	0.48	0.54	0.38	0.57	0.62	0.61	0.60	0.60	0.60	0.60	0.60
20	0.41	0.41	0.31	0.40	0.36	0.39	0.42	0.48	0.41	0.53	0.58	0.60	0.58	0.58	0.58	0.58	0.58
24	0.30	0.30	0.29	0.37	0.30	0.34	0.37	0.43	0.40	0.51	0.57	0.60	0.62	0.62	0.62	0.62	0.62
30	0.20	0.20	0.27	0.33	0.27	0.29	0.33	0.38	0.40	0.48	0.56	0.58	0.59	0.59	0.59	0.59	0.59
40	0.10	0.10	0.25	0.29	0.23	0.25	0.29	0.35	0.43	0.47	0.52	0.55	0.58	0.58	0.58	0.58	0.58
60	0.10	0.10	0.22	0.24	0.20	0.22	0.26	0.33	0.45	0.46	0.48	0.54	0.58	0.58	0.58	0.58	0.58
100	0.10	0.10	0.18	0.20	0.18	0.20	0.24	0.34	0.50	0.46	0.48	0.52	0.57	0.57	0.57	0.57	0.57

20 OBDG03D ECM Supporting Tables

Initial Supporting table - 1st_FireAftrMisfr_Jerk

Description: Used for P0300 - P0308, Multiplier for establishing the expected Jerk of the cylinder after the misfire

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,800	2,200	2,600	3,000	3,001	5,000	6,000	7,000
8	-0.80	-0.82	-0.80	-0.80	-0.80	-0.80	-0.78	-0.71	-0.75	-0.84	-0.76	-0.87	-0.67	-0.67	-0.67	-0.67	-0.67
12	-0.91	-0.97	-0.91	-0.91	-0.95	-0.98	-0.90	-0.93	-1.08	-1.08	-1.09	-0.95	-1.08	-1.08	-1.08	-1.08	-1.08
16	-1.10	-1.10	-1.10	-1.10	-1.06	-0.97	-1.03	-1.03	-1.03	-1.04	-0.98	-0.88	-0.90	-0.90	-0.90	-0.90	-0.90
20	-1.25	-1.21	-1.12	-1.25	-1.07	-0.99	-1.04	-0.98	-1.06	-1.00	-0.95	-0.88	-0.89	-0.89	-0.89	-0.89	-0.89
24	-1.28	-1.25	-1.22	-1.32	-1.02	-1.00	-1.05	-1.02	-1.06	-1.01	-0.96	-0.94	-0.91	-0.91	-0.91	-0.91	-0.91
30	-1.31	-1.28	-1.27	-1.40	-1.05	-1.03	-1.06	-1.07	-1.06	-1.02	-0.98	-0.97	-0.90	-0.90	-0.90	-0.90	-0.90
40	-1.33	-1.31	-1.31	-1.42	-1.12	-1.10	-1.11	-1.16	-1.07	-1.02	-0.98	-0.92	-0.89	-0.89	-0.89	-0.89	-0.89
60	-1.33	-1.33	-1.37	-1.42	-1.20	-1.17	-1.17	-1.16	-1.07	-1.05	-0.95	-0.92	-0.95	-0.95	-0.95	-0.95	-0.95
100	-1.33	-1.33	-1.41	-1.39	-1.24	-1.23	-1.23	-1.16	-1.07	-1.04	-0.95	-0.89	-0.90	-0.90	-0.90	-0.90	-0.90

20 OBDG03D ECM Supporting Tables

Initial Supporting table - 1stFireAfterMisJerkAFM

Description: Used for P0300 - P0308, Multiplier for establishing the expected jerk of the cylinder after the misfire if Active Fuel Management cylinder deact mode is active

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1	1	1	1	1	1	1	1	1
12	1	1	1	1	1	1	1	1	1
16	1	1	1	1	1	1	1	1	1
20	1	1	1	1	1	1	1	1	1
24	1	1	1	1	1	1	1	1	1
30	1	1	1	1	1	1	1	1	1
40	1	1	1	1	1	1	1	1	1
60	1	1	1	1	1	1	1	1	1
100	1	1	1	1	1	1	1	1	1

20 OBDG03D ECM Supporting Tables

Initial Supporting table - 1stFireAftrMisAcelAFM

Description: Used for P0300 - P0308, Multiplier for establishing the expected acceleration of the cylinder after the misfire if Active Fuel Management cylinder deact mode is active

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1	1	1	1	1	1	1	1	1
12	1	1	1	1	1	1	1	1	1
16	1	1	1	1	1	1	1	1	1
20	1	1	1	1	1	1	1	1	1
24	1	1	1	1	1	1	1	1	1
30	1	1	1	1	1	1	1	1	1
40	1	1	1	1	1	1	1	1	1
60	1	1	1	1	1	1	1	1	1
100	1	1	1	1	1	1	1	1	1

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Abnormal Cyl Mode

Description: Used for P0300-P0308. Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Cylinder Mode Equation)

Value Units: Number of consecutive number of decelerating cylinders (integer)

X Unit: thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	4	4	4	4	4	4	4	4	4

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Abnormal Rev Mode

Description: Used for P0300-P0308. Abnormal Rev Mode Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (Rev Mode Equation)

Value Units: Number of consecutive number of decelerating cylinders (integer)

X Unit: thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Abnormal SCD Mode

Description: Used for P0300-P0308. Number of consecutive number of decelerating cylinders after the misfire that would be considered abnormal. (SCD Mode Equation)

Value Units: Number of consecutive number of decelerating cylinders (integer)

X Unit: thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	4	4	4	4	4	4	4	4	4

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Bank_SCD_Decel

Description: Used for P0300 - P0308, Multitplier to SCD decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
12	0.75	0.75	0.57	0.65	0.62	0.59	0.60	0.61	0.75
16	0.69	0.69	0.34	0.51	0.55	0.49	0.43	0.41	0.45
18	0.60	0.60	0.23	0.46	0.47	0.49	0.41	0.40	0.41
20	0.64	0.64	0.18	0.29	0.28	0.45	0.39	0.41	0.38
24	0.75	0.75	0.17	0.20	0.19	0.48	0.42	0.39	0.35
30	0.75	0.75	0.13	0.13	0.15	0.40	0.37	0.35	0.34
40	0.75	0.75	0.11	0.11	0.14	0.41	0.38	0.36	0.42
60	0.75	0.75	0.11	0.11	0.15	0.49	0.47	0.47	0.56
98	0.75	0.75	0.11	0.10	0.15	0.58	0.57	0.60	0.66

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Bank_SCD_Jerk

Description: Used for P0300 - P0308, Multplier to Medres SCD jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
12	0.95	0.95	1.00	0.98	0.91	0.83	0.97	1.00	1.00
16	0.77	0.77	0.87	0.81	0.83	0.68	0.77	0.86	0.81
18	0.68	0.68	0.65	0.71	0.85	0.75	0.79	0.82	0.77
20	0.60	0.60	0.54	0.46	0.77	0.81	0.76	0.84	0.80
24	0.59	0.59	0.48	0.38	0.75	0.79	0.75	0.79	0.72
30	0.54	0.54	0.38	0.27	0.60	0.65	0.65	0.70	0.68
40	0.46	0.46	0.33	0.22	0.65	0.67	0.65	0.67	0.76
60	0.46	0.46	0.32	0.23	0.83	0.80	0.77	0.78	0.88
98	0.41	0.41	0.31	0.23	1.02	0.87	0.91	0.96	1.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - BankCylModeDecel

Description: Used for P0300 - P0308, Multiplier to Lores Decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,800	2,200	2,600	3,000	3,001	5,000	6,000	7,000
12	0.75	0.75	0.75	0.75	0.46	0.48	0.48	0.56	0.64	0.69	0.50	0.69	0.78	0.78	0.78	0.78	0.78
16	0.61	0.56	0.52	0.50	0.37	0.29	0.29	0.25	0.17	0.19	0.25	0.32	0.48	0.48	0.48	0.48	0.48
18	0.42	0.52	0.63	0.57	0.34	0.32	0.28	0.22	0.14	0.16	0.22	0.25	0.28	0.28	0.28	0.28	0.28
20	0.54	0.54	0.54	0.55	0.37	0.35	0.27	0.23	0.13	0.15	0.22	0.25	0.24	0.24	0.24	0.24	0.24
24	0.58	0.60	0.62	0.56	0.43	0.36	0.26	0.23	0.14	0.18	0.24	0.25	0.26	0.26	0.26	0.26	0.26
30	0.60	0.62	0.64	0.67	0.43	0.37	0.26	0.22	0.18	0.19	0.25	0.25	0.24	0.24	0.24	0.24	0.24
40	0.52	0.55	0.58	0.56	0.53	0.37	0.28	0.22	0.21	0.23	0.28	0.28	0.24	0.24	0.24	0.24	0.24
60	0.46	0.49	0.52	0.49	0.45	0.37	0.32	0.26	0.22	0.26	0.29	0.30	0.25	0.25	0.25	0.25	0.25
98	0.39	0.36	0.34	0.30	0.37	0.37	0.35	0.31	0.26	0.27	0.31	0.30	0.25	0.25	0.25	0.25	0.25

20 OBDG03D ECM Supporting Tables

Initial Supporting table - BankCylModeJerk

Description: Used for P0300 - P0308, Multplier to Lores Jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,800	2,200	2,600	3,000	3,001	5,000	6,000	7,000
12	1.00	1.00	1.00	1.00	1.00	0.89	0.96	1.00	1.00	1.15	1.38	1.50	1.46	1.46	1.46	1.46	1.46
16	1.00	1.00	1.00	1.00	0.83	0.71	0.78	0.79	0.70	0.70	0.75	0.81	0.85	0.85	0.85	0.85	0.85
18	1.00	1.00	1.00	1.00	0.75	0.68	0.74	0.72	0.65	0.66	0.65	0.71	0.71	0.71	0.71	0.71	0.71
20	0.91	0.95	1.00	1.00	0.72	0.69	0.71	0.69	0.62	0.67	0.62	0.67	0.70	0.70	0.70	0.70	0.70
24	0.80	0.88	0.95	0.96	0.82	0.75	0.71	0.71	0.63	0.68	0.65	0.70	0.70	0.70	0.70	0.70	0.70
30	0.71	0.78	0.86	0.86	0.77	0.74	0.67	0.73	0.63	0.67	0.70	0.69	0.69	0.69	0.69	0.69	0.69
40	0.70	0.70	0.70	0.70	0.70	0.72	0.67	0.74	0.67	0.64	0.70	0.67	0.72	0.72	0.72	0.72	0.72
60	0.70	0.70	0.70	0.70	0.70	0.71	0.67	0.71	0.66	0.60	0.66	0.65	0.71	0.71	0.71	0.71	0.71
98	0.70	0.70	0.70	0.70	0.70	0.70	0.67	0.70	0.68	0.58	0.66	0.63	0.65	0.65	0.65	0.65	0.65

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Catalyst_Damage_Misfire_Percentage

Description: Catalyst Damaging Misfire Percentage" Table whenever secondary conditions are met.

Value Units: percent misfire over 200 revolutions (%)

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	0	1,000	2,000	3,000	4,000	5,000	6,000	7,000
0	11.2	11.2	11.2	6.3	4.8	4.8	4.8	4.8
10	11.2	11.2	11.2	6.3	4.8	4.8	4.8	4.8
20	8.3	8.3	8.3	6.3	4.8	4.8	4.8	4.8
30	6.3	6.3	6.3	6.3	4.8	4.8	4.8	4.8
40	6.3	6.3	6.3	4.8	4.8	4.8	4.8	4.8
50	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
60	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
70	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
80	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
90	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8
100	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8

20 OBDG03D ECM Supporting Tables

Initial Supporting table - ClyAfterAFM_Decel

Description: Used for P0300 - P0308, Multiplier to Lores decel to account for different pattern of misfire after a deactivated cylinder. Similar to the second cylinder of consecutive cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - ClyBeforeAFM_Jerk

Description: Used for P0300 - P0308, Multiplier to Lores decel to account for different pattern of misfire before a deactivated cylinder, but after an active cylinder that follows an deactive cylinder on engine that supports cylinder deactivation in non even fire patterns.. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - CombustModelIdleTbl

Description: Used for P0300 - P0308, Only used on Diesel engines. Combustion modes that will force use of Idle table. A value of CeCMBR_i_CombModesMax means not selected.

Value Units: Enumerated value of differant combustion modes (enumeration)

X Unit: Current Combustion Mode (enumeration)

CombustModelIdleTbl - Part 1

y/x	0	1	2	3	4	5
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max

CombustModelIdleTbl - Part 2

y/x	6	7	8	9	10	11
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max

CombustModelIdleTbl - Part 3

y/x	12	13	14	15	16	
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	

20 OBDG03D ECM Supporting Tables

Initial Supporting table - ConsecCylModDecel

Description: Used for P0300 - P0308, Multiplier to Lores decel to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,800	2,200	2,600	3,000	3,001	5,000	6,000	7,000
8	1.10	1.28	1.28	1.16	1.29	1.16	1.05	1.15	1.18	1.45	1.37	1.38	1.44	1.44	1.44	1.44	1.44
12	1.00	1.00	1.00	1.00	1.00	1.02	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.95	0.94	0.98	0.96	0.94	0.94	0.94	0.94	0.94
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.97	0.90	0.90	0.90	0.89	0.90	0.90	0.90	0.90	0.90
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.90	0.90	0.90	0.90	0.89	0.89	0.89	0.89	0.89
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.95	0.95	0.90	0.90	0.88	0.88	0.88	0.88	0.88
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.97	1.00	1.00	1.00	0.92	0.92	0.92	0.92	0.92

20 OBDG03D ECM Supporting Tables

Initial Supporting table - ConsecCylModeJerk

Description: Used for P0300 - P0308, Multiplier to Lores Jerk to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,800	2,200	2,600	3,000	3,001	5,000	6,000	7,000
8	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0	0	0	0	0	-1	-1	-1	-1	-1
16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
24	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
30	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
40	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
60	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
98	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - ConsecSCD_Decel

Description: Used for P0300 - P0308, Multitplier to medres decel to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	0.95	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	0.70	0.73	0.68	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	0.55	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - ConsecSCD_Jerk

Description: Used for P0300 - P0308, Multiplier to medres Jerk to account for different pattern of the second cylinder of consecutive misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	-0.06	-0.06	-0.12	-0.15	-0.19	-0.28	-0.21	-0.11	-0.11
12	-0.07	-0.07	-0.12	-0.18	-0.18	-0.19	-0.20	-0.19	-0.24
16	-0.05	-0.05	-0.09	-0.13	-0.14	-0.14	-0.15	-0.17	-0.19
20	-0.03	-0.03	-0.05	-0.06	-0.11	-0.15	-0.12	-0.16	-0.19
24	-0.03	-0.03	-0.03	-0.04	-0.09	-0.13	-0.10	-0.12	-0.15
30	-0.02	-0.02	-0.02	-0.03	-0.06	-0.09	-0.07	-0.09	-0.10
40	-0.02	-0.02	-0.02	-0.02	-0.05	-0.07	-0.05	-0.06	-0.08
60	-0.01	-0.01	-0.01	-0.01	-0.05	-0.06	-0.04	-0.05	-0.06
98	-0.01	-0.01	-0.01	-0.01	-0.04	-0.05	-0.03	-0.04	-0.05

20 OBDG03D ECM Supporting Tables

Initial Supporting table - CylAfterAFM_Jerk

Description: Used for P0300 - P0308, Multiplier to Lores Jerk to account for different pattern of misfire after a deactivated cylinder. Similar to the second cylinder of consecutive cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1	1	1	1	1	1	1	1	1
12	1	1	1	1	1	1	1	1	1
16	1	1	1	1	1	1	1	1	1
20	1	1	1	1	1	1	1	1	1
24	1	1	1	1	1	1	1	1	1
30	1	1	1	1	1	1	1	1	1
40	1	1	1	1	1	1	1	1	1
60	1	1	1	1	1	1	1	1	1
98	1	1	1	1	1	1	1	1	1

20 OBDG03D ECM Supporting Tables

Initial Supporting table - CylBeforeAFM_Decel

Description: Used for P0300 - P0308, Multiplier to Lores decel to account for different pattern of misfire before a deactivated cylinder, but after an active cylinder that follows an deactive cylinder on engine that supports cylinder deactivation in non even fire patterns.. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - CylModeDecel

Description: Used for P0300-P0308. Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Value Units: Delta time per cylinder (usec)

X Unit: RPM

Y Units: percent load of max indicated torque (%)

CylModeDecel - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	2,050	1,500	950	544	350	243	179	155	127	70	53	34	28
6	2,061	1,500	939	507	349	234	175	155	125	68	51	34	28
8	2,264	1,600	937	507	348	232	171	152	123	68	50	35	29
10	2,640	1,800	960	598	414	287	190	150	121	68	48	36	28
12	3,515	2,270	1,025	713	517	352	256	189	136	87	60	43	32
14	3,900	2,603	1,306	872	611	433	314	224	169	111	73	51	38
16	4,194	2,878	1,562	1,025	698	493	368	268	198	132	85	61	45
18	4,454	3,070	1,686	1,185	782	540	401	308	218	149	96	69	51
20	4,751	3,261	1,771	1,305	844	591	438	341	246	165	109	78	56
22	5,077	3,464	1,851	1,363	901	674	491	375	269	183	118	84	62
24	5,513	3,715	1,918	1,421	960	747	546	418	300	202	129	90	67
26	5,689	3,841	1,993	1,479	1,024	813	605	460	331	219	140	96	72
30	6,336	4,238	2,140	1,595	1,140	937	699	536	386	254	163	113	83
40	8,191	5,356	2,520	1,911	1,440	1,247	958	738	531	334	222	156	113
60	12,005	7,626	3,248	2,524	2,040	1,855	1,452	1,128	818	518	345	234	170
78	15,155	9,526	3,897	3,064	2,568	2,362	1,878	1,458	1,064	672	456	312	227
97	18,760	11,697	4,635	3,696	3,173	2,937	2,358	1,830	1,342	850	585	393	289

CylModeDecel - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	20	16	13	11	9	6	6	4	4	3	3	2	2
6	20	16	13	11	9	6	6	4	4	3	3	2	2
8	21	16	13	11	9	6	6	4	4	3	3	2	2
10	22	16	13	11	9	6	6	4	4	3	3	2	2
12	24	16	13	11	9	8	5	4	4	3	3	2	2
14	26	19	16	12	10	8	5	4	4	3	3	2	2
16	33	24	19	16	13	9	5	4	4	3	3	3	3
18	37	28	22	18	15	10	6	5	4	3	3	3	3
20	42	31	24	20	17	10	7	5	5	4	3	2	2
22	45	33	26	22	18	11	7	6	5	4	3	2	2
24	49	36	29	24	20	12	8	6	5	4	3	3	3

20 OBDG03D ECM Supporting Tables

Initial Supporting table - CylModeDecel

26	52	39	31	26	21	13	9	6	6	4	3	3	3
30	59	46	36	30	25	16	10	7	6	5	3	3	3
40	80	63	49	40	33	21	12	9	7	5	4	3	3
60	125	95	73	59	48	33	21	13	10	7	5	5	5
78	163	124	96	77	64	42	27	16	12	9	6	6	6
97	209	158	122	98	81	53	34	20	15	11	7	6	6

20 OBDG03D ECM Supporting Tables

Initial Supporting table - CylModeJerk

Description: Crankshaft jerk threshold. Thresholds are a function of rpm and % engine Load.

Value Units: Change in Delta time per cylinder from last cylinder (usec)

Y Units: percent load of max indicated torque (%)

CylModeJerk - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	2,338	1,556	774	454	282	189	162	130	121	77	47	33	24
6	2,347	1,544	741	443	278	183	162	128	118	75	47	33	24
8	2,469	1,600	732	446	298	188	150	128	114	68	45	32	24
10	2,869	1,800	731	498	326	238	175	124	111	57	40	32	25
12	3,107	2,013	919	623	449	317	227	165	113	66	47	33	27
14	3,227	2,199	1,171	800	549	375	277	202	150	87	58	40	30
16	3,432	2,409	1,386	938	628	426	327	242	173	112	68	48	38
18	3,809	2,670	1,531	1,117	722	470	370	281	204	128	78	56	45
20	4,136	2,906	1,676	1,281	810	529	411	318	235	142	87	64	51
22	4,437	3,129	1,821	1,386	893	604	459	365	267	161	98	71	56
24	4,888	3,415	1,941	1,445	962	696	524	400	287	175	110	79	60
26	5,179	3,608	2,037	1,510	1,024	776	590	450	314	190	120	87	65
30	5,846	4,008	2,170	1,633	1,140	935	701	538	359	224	144	103	77
40	7,628	5,074	2,520	1,913	1,440	1,245	956	731	473	295	203	143	102
60	11,120	7,193	3,266	2,466	2,040	1,808	1,452	1,116	743	459	323	219	160
78	14,383	9,168	3,953	2,949	2,568	2,316	1,878	1,458	980	588	428	293	213
97	18,008	11,372	4,736	3,528	3,120	2,843	2,358	1,830	1,251	753	543	374	269

CylModeJerk - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	19	15	12	9	8	0	0	0	0	0	0	0	0
6	19	15	12	9	8	0	0	0	0	0	0	0	0
8	19	15	12	9	8	0	0	0	0	0	0	0	0
10	18	13	11	9	7	0	0	0	0	0	0	0	0
12	17	13	10	8	7	0	0	0	0	0	0	0	0
14	20	15	12	9	8	0	0	0	0	0	0	0	0
16	27	21	16	13	10	0	0	0	0	0	0	0	0
18	32	24	19	15	12	0	0	0	0	0	0	0	0
20	37	28	22	18	14	0	0	0	0	0	0	0	0
22	41	31	23	19	15	0	0	0	0	0	0	0	0
24	45	34	25	21	17	0	0	0	0	0	0	0	0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - CylModeJerk

26	49	36	27	22	19	0	0	0	0	0	0	0	0
30	55	42	31	26	21	0	0	0	0	0	0	0	0
40	75	59	45	35	29	0	0	0	0	0	0	0	0
60	118	93	70	53	43	0	0	0	0	0	0	0	0
78	156	123	93	69	62	0	0	0	0	0	0	0	0
97	197	157	120	90	78	0	0	0	0	0	0	0	0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - DeacCylInversionDecel

Description: Used for P0300 - P0308, Negative Torque can cause crank readings to invert (active cylinders appear weak & deactivated cylinders appear "strong" If deactivated cylinders don't decelerate at least this amount then the crank signal is inverting. Function of speed and load.

Value Units: Delta time per cylinder (usec)
X Unit: RPM
Y Units: percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
12	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
16	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
20	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
24	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
30	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
40	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
60	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
98	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384

20 OBDG03D ECM Supporting Tables

Initial Supporting table - DeacCylInversionJerk

Description: Used for P0300 - P0308, Negative Torque can cause crank readings to invert (active cylinders appear weak & deactivated cylinders appear "strong" If deactivated cylinders don't jerk at least this amount then the crank signal is inverting. Function of speed and load.

Value Units: Change in Delta time per cylinder from last cylinder (usec)

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
12	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
16	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
20	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
24	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
30	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
40	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
60	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384
98	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384	-16,384

Initial Supporting table - EngineOverSpeedLimit

Description: Engine OverSpeed Limit versus gear

Value Units: RPM

X Unit: Enumeration of transmission gear state (enumeration)

EngineOverSpeedLimit - Part 1

y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGr2	CeTGRR_e_TransGr3	CeTGRR_e_TransGr4	CeTGRR_e_TransGr5	CeTGRR_e_TransGr6	CeTGRR_e_TransGr9
1	5,600	5,600	5,600	5,600	5,600	5,600	5,600

EngineOverSpeedLimit - Part 2

y/x	CeTGRR_e_TransGr1	CeTGRR_e_TransGrN	CeTGRR_e_TransGrR	CeTGRR_e_TransGrP	CeTGRR_e_TransGr7	CeTGRR_e_TransGr8	
	0	eut	vrs	ark			
1	5,600	4,000	5,600	4,000	5,600	5,600	

20 OBDG03D ECM Supporting Tables

Initial Supporting table - InfrequentRegen

Description: Used for P0300-P0308. Only used on Diesel engines. Initiates a misfire delay when the current combustion mode matches a selection in the table. A value of CeCMBR_i_CombModesMax means not selected.

Value Units: Enumerated value of different combustion modes (enumeration)

X Unit: Current Combustion Mode (enumeration)

InfrequentRegen - Part 1

y/x	0	1	2	3	4	5
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max

InfrequentRegen - Part 2

y/x	6	7	8	9	10	11
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max

InfrequentRegen - Part 3

y/x	12	13	14	15	16	
1	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	CeCMBR_i_CombModes Max	

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Number of Normals

Description: Used for P0300-P0308. Number of Normals for the Driveline Ring Filter
 After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

Value Units: Number of Engine cycles after isolated misfire (Engine cycles)

X Unit: thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	3	3	3	3	3	3	3	3	3

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P00C6 - High Pressure Pump Control Mode timeout

Description: High Pressure Pump Control Mode timeout

Value Units: Time (Seconds)

X Unit: Coolant Temperature (Deg C)

y/x	-40	-35	-30	-25	-20	-10	0	8	16	20	24	32	40	60	80	90	112
1	10.0	10.0	10.0	10.0	10.0	10.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0	5.0

20 OBDG03D ECM Supporting Tables

Supporting table - P00C6 - maximum acceptable counts of fuel rail pressure below KtFHPD_p_HPS_PressFallLoThrsh after High Pressure Start

Description: The maximum acceptable counts of fuel rail pressure below KtFHPD_p_HPS_PressFallLoThrsh after High Pressure Start (HPS) is executed but before engine is in run mode.

Value Units: maximum acceptable counts of fuel rail pressure below KtFHPD_p_HPS_PressFallLoThrsh after High Pressure Start (Count)

X Unit: Coolant Temperature (Deg C)

Y Units: Ethanol Precent (%)

y/x	-40	-35	-30	-25	-20	-10	0	8	16	20	24	32	40	60	80	90	112
0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
13	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
25	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
38	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
50	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
63	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
75	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
88	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0
100	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0	10.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P00C6 - Minimum acceptable value of fuel rail pressure after High Pressure Start

Description: The minimum acceptable value of fuel rail pressure after High Pressure Start (HPS) is executed. This ensures the pressure does not fall off drastically after High Pressure Start (HPS) is executed, but before engine is in run mode.

Value Units: Minimum acceptable value of fuel rail pressure after High Pressure Start (Mpa)

X Unit: Coolant Temperature (Deg C)

Y Units: Ethanol Precent (%)

y/x	-40	-35	-30	-25	-20	-10	0	8	16	20	24	32	40	60	80	90	112
0	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
13	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
25	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
38	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
50	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
63	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
75	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
88	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
100	2.0	2.0	2.0	2.0	2.0	2.0	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P00C6 - Minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery

Description: This calibration is the minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery

Value Units: Minimum pressure in MPa that will exit High Pressure Start mode and allow fuel delivery

X Unit: Coolant Temperature (Deg C)

Y Units: Ethanol Precent (%)

y/x	-40	-35	-30	-25	-20	-10	0	8	16	20	24	32	40	60	80	90	112
0	9.0	9.0	8.5	8.5	8.0	4.0	4.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
13	9.0	9.0	8.5	8.5	8.0	4.0	4.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
25	12.0	12.0	12.0	12.0	8.0	6.0	4.0	3.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
38	13.0	13.0	13.0	13.0	10.0	8.6	4.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
50	13.0	13.0	13.0	13.0	10.0	8.6	4.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
63	13.0	13.0	13.0	13.0	10.0	8.6	6.0	5.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
75	13.0	13.0	13.0	13.0	10.0	8.6	6.0	5.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
88	13.0	13.0	13.0	13.0	10.0	8.6	7.0	6.0	5.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
100	13.0	13.0	13.0	13.0	10.0	8.6	7.5	7.0	6.0	5.0	4.0	3.0	3.0	3.0	3.0	3.0	3.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0420_BestFailingOSCTableB1

Description: This table is a 9x17 table of baseline Best Failing (e.g. threshold converter) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow,the BestFailing OSC value is found within this table for the measured temp and airflow and is used along with the OSC_TimeRaw (and the WorstPassing value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the identified BPU converter that is used for MIL illumination across the specific temp and airflow range for a given program.

y/x	7.02	7.67	8.33	8.99	9.65	10.31	10.97	11.63	12.29	12.95	13.61	14.27	14.93	15.58	16.24	16.90	17.56
586.00	0.76	0.73	0.70	0.67	0.64	0.60	0.57	0.55	0.53	0.50	0.48	0.45	0.43	0.41	0.39	0.37	0.36
627.00	0.78	0.75	0.72	0.70	0.66	0.62	0.59	0.57	0.54	0.52	0.49	0.47	0.44	0.42	0.40	0.38	0.37
667.00	0.81	0.78	0.75	0.72	0.68	0.64	0.61	0.58	0.56	0.53	0.51	0.48	0.46	0.44	0.42	0.40	0.38
707.00	0.83	0.80	0.78	0.74	0.70	0.66	0.63	0.60	0.58	0.55	0.52	0.50	0.47	0.45	0.43	0.41	0.39
748.00	0.86	0.83	0.80	0.77	0.73	0.68	0.65	0.62	0.60	0.57	0.54	0.51	0.49	0.47	0.45	0.43	0.41
788.00	0.89	0.86	0.83	0.79	0.75	0.71	0.67	0.64	0.62	0.58	0.56	0.53	0.50	0.48	0.46	0.44	0.42
828.00	0.92	0.89	0.86	0.82	0.78	0.73	0.69	0.66	0.63	0.60	0.57	0.55	0.52	0.50	0.48	0.46	0.44
869.00	0.95	0.92	0.89	0.85	0.80	0.75	0.72	0.68	0.66	0.62	0.59	0.57	0.54	0.52	0.49	0.47	0.45
909.00	0.99	0.96	0.92	0.88	0.83	0.78	0.74	0.71	0.68	0.64	0.61	0.58	0.56	0.53	0.51	0.49	0.47

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0420_WorstPassingOSCTableB1

Description: This table is a 9x17 table of WorstPassing (e.g. 120k) OSC times for catalyst Bank 1. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the WorstPassing OSC value is found within this table for the measured temp and airflow and is used along with the OSC_TimeRaw (and the BestFailing OSC value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the WPA part across the temp and airflow range.

y/x	7.02	7.67	8.33	8.99	9.65	10.31	10.97	11.63	12.29	12.95	13.61	14.27	14.93	15.58	16.24	16.90	17.56
586.00	1.15	1.08	1.01	0.95	0.91	0.85	0.80	0.77	0.74	0.71	0.68	0.64	0.61	0.58	0.56	0.54	0.54
627.00	1.17	1.10	1.03	0.97	0.93	0.87	0.82	0.79	0.76	0.73	0.69	0.66	0.62	0.59	0.57	0.56	0.55
667.00	1.20	1.13	1.06	1.00	0.95	0.89	0.84	0.81	0.78	0.74	0.71	0.67	0.63	0.61	0.58	0.57	0.56
707.00	1.22	1.16	1.08	1.02	0.97	0.91	0.86	0.83	0.79	0.76	0.72	0.69	0.65	0.62	0.60	0.58	0.57
748.00	1.25	1.18	1.11	1.05	1.00	0.93	0.88	0.85	0.81	0.78	0.74	0.70	0.66	0.63	0.61	0.60	0.59
788.00	1.28	1.21	1.14	1.07	1.02	0.96	0.90	0.87	0.83	0.79	0.76	0.72	0.68	0.65	0.63	0.61	0.60
828.00	1.31	1.24	1.17	1.10	1.04	0.98	0.92	0.89	0.85	0.81	0.77	0.74	0.70	0.67	0.64	0.63	0.62
869.00	1.34	1.27	1.20	1.13	1.07	1.00	0.95	0.91	0.87	0.83	0.79	0.75	0.71	0.68	0.66	0.64	0.63
909.00	1.38	1.30	1.24	1.16	1.10	1.03	0.97	0.93	0.89	0.85	0.81	0.77	0.73	0.70	0.68	0.66	0.65

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0430_BestFailingOSCTableB2

Description: This table is a 9x17 table of baseline Best Failing (e.g. threshold converter) OSC times for catalyst Bank 2. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow,the BestFailing OSC value is found within this table for the measured temp and airflow and is used along with the OSC_TimeRaw (and the WorstPassing value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the identified BPU converter that is used for MIL illumination across the specific temp and airflow range for a given program.

y/x	7.02	7.67	8.33	8.99	9.65	10.31	10.97	11.63	12.29	12.95	13.61	14.27	14.93	15.58	16.24	16.90	17.56
586.00	0.73	0.70	0.67	0.64	0.61	0.57	0.54	0.52	0.50	0.47	0.45	0.42	0.40	0.38	0.36	0.34	0.33
627.00	0.75	0.72	0.69	0.67	0.63	0.59	0.56	0.54	0.51	0.49	0.46	0.44	0.41	0.39	0.37	0.36	0.34
667.00	0.78	0.75	0.72	0.69	0.65	0.61	0.58	0.55	0.53	0.50	0.48	0.45	0.43	0.41	0.39	0.37	0.35
707.00	0.80	0.78	0.75	0.71	0.67	0.63	0.60	0.57	0.55	0.52	0.49	0.47	0.44	0.42	0.40	0.38	0.36
748.00	0.83	0.80	0.77	0.74	0.70	0.65	0.62	0.59	0.57	0.54	0.51	0.48	0.46	0.44	0.42	0.40	0.38
788.00	0.86	0.83	0.80	0.76	0.72	0.68	0.64	0.61	0.59	0.55	0.53	0.50	0.47	0.45	0.43	0.41	0.39
828.00	0.89	0.86	0.83	0.79	0.75	0.70	0.66	0.63	0.61	0.57	0.54	0.52	0.49	0.47	0.45	0.43	0.41
869.00	0.92	0.89	0.86	0.82	0.77	0.72	0.69	0.65	0.63	0.59	0.56	0.54	0.51	0.49	0.46	0.44	0.42
909.00	0.96	0.92	0.89	0.85	0.80	0.75	0.71	0.67	0.65	0.61	0.58	0.55	0.53	0.50	0.48	0.46	0.44

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0430_WorstPassingOSCTableB2

Description: This table is a 9x17 table of WorstPassing (e.g. 120k) OSC times for catalyst Bank 2. The axis' for this table include the average airflow and the catalyst temperature. After OSC is measured for a specific temp and airflow, the WorstPassing OSC value is found within this table for the measured temp and airflow and is used along with the OSC_TimeRaw (and the BestFailing OSC value) to calculate the Normalized Ratio for that specific test. The values in this table are based on the measured OSC for the WPA part across the temp and airflow range.

y/x	7.02	7.67	8.33	8.99	9.65	10.31	10.97	11.63	12.29	12.95	13.61	14.27	14.93	15.58	16.24	16.90	17.56
586.00	1.15	1.08	1.01	0.95	0.91	0.85	0.80	0.77	0.74	0.71	0.68	0.64	0.61	0.58	0.56	0.54	0.54
627.00	1.17	1.10	1.03	0.97	0.93	0.87	0.82	0.79	0.76	0.73	0.69	0.66	0.62	0.59	0.57	0.56	0.55
667.00	1.20	1.13	1.06	1.00	0.95	0.89	0.84	0.81	0.78	0.74	0.71	0.67	0.63	0.61	0.58	0.57	0.56
707.00	1.22	1.16	1.08	1.02	0.97	0.91	0.86	0.83	0.79	0.76	0.72	0.69	0.65	0.62	0.60	0.58	0.57
748.00	1.25	1.18	1.11	1.05	1.00	0.93	0.88	0.85	0.81	0.78	0.74	0.70	0.66	0.63	0.61	0.60	0.59
788.00	1.28	1.21	1.14	1.07	1.02	0.96	0.90	0.87	0.83	0.79	0.76	0.72	0.68	0.65	0.63	0.61	0.60
828.00	1.31	1.24	1.17	1.10	1.04	0.98	0.92	0.89	0.85	0.81	0.77	0.74	0.70	0.67	0.64	0.63	0.62
869.00	1.34	1.27	1.20	1.13	1.07	1.00	0.95	0.91	0.87	0.83	0.79	0.75	0.71	0.68	0.66	0.64	0.63
909.00	1.38	1.30	1.24	1.16	1.10	1.03	0.97	0.93	0.89	0.85	0.81	0.77	0.73	0.70	0.68	0.66	0.65

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0461 P2066 P2636 Transfer Pump On Time Table

Description: TransferPumpOnTimeLimit (seconds) as function of Fuel Level (%) [Kt FLVC t XferFuelPmpOnTimLim]

Value Units: seconds
X Unit: percent fuel level

P0461 P2066 P2636 Transfer Pump On Time Table - Part 1

y/x	0.0	3.1	6.3	9.4	12.5	15.6	18.8	21.9	25.0	28.1	31.3	34.4	37.5	40.6	43.8	46.9	50.0
1	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0

P0461 P2066 P2636 Transfer Pump On Time Table - Part 2

y/x	53.1	56.3	59.4	62.5	65.6	68.8	71.9	75.0	78.1	81.3	84.4	87.5	90.6	93.8	96.9	100.0	
1	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	3,000.0	

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Pair_SCD_Decel

Description: Used for P0300 - P0308, Multitplier to SCD_Decel to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	0.71	0.80	0.84	0.87	0.71	0.71	0.66	0.88
12	1.00	0.78	0.73	0.85	0.78	0.79	0.83	0.88	0.77
16	0.95	0.82	0.77	0.87	0.96	0.95	0.87	0.82	0.87
20	0.92	0.85	0.80	0.88	0.95	0.96	0.97	0.93	0.90
24	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90
30	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90
40	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90
60	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90
98	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90	0.90

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Pair_SCD_Jerk

Description: Used for P0300 - P0308, Multitplier to P0300_SCD_Jerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	1.00	1.00	1.00	1.00	1.04	1.01	1.00	1.00
12	1.00	1.00	0.92	1.00	0.93	0.96	1.00	1.00	1.00
16	1.00	0.79	0.91	1.00	0.87	0.89	0.95	1.00	1.00
20	1.00	0.63	0.60	0.62	0.88	1.00	1.00	1.00	1.00
24	1.00	0.61	0.53	0.53	0.84	1.00	0.98	1.00	0.93
30	1.00	0.57	0.45	0.38	0.67	0.82	0.83	0.89	0.80
40	1.00	0.53	0.40	0.31	0.71	0.83	0.81	0.81	0.84
60	1.00	0.57	0.43	0.32	0.88	1.00	0.94	0.89	0.96
98	1.00	0.63	0.43	0.32	1.12	1.12	1.10	1.00	1.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - PairCylModeDecel

Description: Used for P0300 - P0308, Multitplier to Cyl Mode Deceleration to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multitplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,800	2,200	2,600	3,000	3,001	5,000	6,000	7,000
8	0.85	0.84	0.83	0.81	0.80	0.91	0.79	0.89	1.07	1.10	0.98	1.08	0.94	0.94	0.94	0.94	0.94
12	0.82	0.82	0.82	0.82	0.83	0.73	0.74	0.81	0.80	0.78	0.75	0.81	0.83	0.83	0.83	0.83	0.83
16	0.85	0.85	0.85	0.85	0.85	0.85	0.83	0.83	0.78	0.74	0.71	0.71	0.72	0.72	0.72	0.72	0.72
20	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.77	0.74	0.77	0.71	0.67	0.67	0.67	0.67	0.67
24	0.85	0.85	0.85	0.85	0.85	0.84	0.83	0.84	0.79	0.81	0.76	0.74	0.69	0.69	0.69	0.69	0.69
30	0.85	0.85	0.85	0.85	0.80	0.80	0.77	0.79	0.76	0.80	0.81	0.76	0.73	0.73	0.73	0.73	0.73
40	0.85	0.85	0.85	0.79	0.68	0.68	0.64	0.66	0.70	0.71	0.82	0.74	0.77	0.77	0.77	0.77	0.77
60	0.85	0.85	0.85	0.70	0.55	0.55	0.52	0.57	0.62	0.63	0.78	0.75	0.81	0.81	0.81	0.81	0.81
98	0.65	0.75	0.85	0.65	0.46	0.46	0.45	0.51	0.58	0.58	0.73	0.69	0.77	0.77	0.77	0.77	0.77

20 OBDG03D ECM Supporting Tables

Initial Supporting table - PairCylModeJerk

Description: Used for P0300 - P0308, Multiplier to P0300_CylModeJerk to account for different pattern of Paired cylinder misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,800	2,200	2,600	3,000	3,001	5,000	6,000	7,000
8	1.00	1.05	1.12	1.22	1.00	1.17	1.18	1.23	1.07	1.25	1.08	1.22	1.13	1.13	1.13	1.13	1.13
12	0.94	0.97	0.96	0.90	1.00	0.91	0.91	1.07	1.02	1.08	1.06	1.15	1.15	1.15	1.15	1.15	1.15
16	1.00	0.94	0.96	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	0.90	1.00	1.00	0.99	0.97	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.03	1.03	1.03	1.03	1.03
30	1.00	1.00	1.00	1.00	1.00	1.00	0.98	1.00	1.00	0.96	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	0.93	0.96	1.01	0.94	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.90	0.90	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.92	0.88	1.00	1.00	0.94	0.94	0.94	0.94	0.94

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Random_SCD_Decel

Description: Used for P0300 - P0308, Multitplier to SCD_Decel to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05
20	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10
24	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10
30	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10
40	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10
60	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10
98	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10	1.10

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Random_SCD_Jerk

Description: Used for P0300 - P0308, Multitplier to Random_SCD_Jerk to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RandomAFM_Decl

Description: Used for P0300 - P0308, Multiplier to Cylinder_Decel while in Cylinder Deactivation mode to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RandomAFM_Jerk

Description: Used for P0300 - P0308, Multiplier to Cylinder_Jerk while in Cylinder Deactivation mode to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	800	1,000	1,200	1,600	2,000	2,400	2,600	3,000	3,500
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RandomCylModDecel

Description: Used for P0300 - P0308. Multiplier to CylMode_Decel. account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: Multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,800	2,200	2,600	3,000	3,001	5,000	6,000	7,000
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.05	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.05	1.15	1.15	1.15	1.15	1.15	1.15	1.15	1.15
16	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.25	1.30	1.25	1.30	1.30	1.30	1.30	1.30
20	1.20	1.25	1.30	1.27	1.25	1.15	1.20	1.20	1.22	1.25	1.30	1.30	1.30	1.30	1.30	1.30	1.30
24	1.20	1.20	1.20	1.20	1.20	1.20	1.20	1.20	1.22	1.25	1.30	1.30	1.30	1.30	1.30	1.30	1.30
30	1.20	1.20	1.20	1.20	1.20	1.20	1.20	1.20	1.20	1.25	1.30	1.30	1.30	1.30	1.30	1.30	1.30
40	1.20	1.20	1.20	1.20	1.20	1.20	1.20	1.15	1.15	1.20	1.30	1.30	1.30	1.30	1.30	1.30	1.30
60	1.20	1.20	1.20	1.20	1.20	1.20	1.20	1.15	1.14	1.18	1.25	1.30	1.30	1.30	1.30	1.30	1.30
98	1.20	1.20	1.20	1.20	1.20	1.20	1.20	1.15	1.10	1.14	1.20	1.20	1.20	1.20	1.20	1.20	1.20

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RandomCylModJerk

Description: Used for P0300 - P0308, Multiplier to CylMode_Jerk to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	500	600	700	800	900	1,000	1,100	1,200	1,400	1,800	2,200	2,600	3,000	3,001	5,000	6,000	7,000
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
20	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
24	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
30	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
40	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
60	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RandomRevModDecl

Description: Used for P0300 - P0308, Multiplier to RevMode_Decel to account for different pattern of light level misfire. Multipliers are a function of engine rpm and % engine Load.

Value Units: multiplier

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	3,001	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000
8	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
12	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
16	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05
20	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05
24	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05
30	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05
40	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05	1.05
60	1.10	1.10	1.10	1.10	1.05	1.05	1.05	1.05	1.05
98	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RepetSnapDecayAdjst

Description: Used for P0300 - P0308, If misfire is present in consecutive engine cycles, this multiplier is applied to the misfire jerk threshold and compared to a crankshaft snap value after the misfire has taken place.. Table lookup as a function of engine rpm.

Value Units: multiplier
X Unit: RPM

y/x	900	1,100	1,400	1,800	2,200	2,600	3,000	4,000	5,000
1	1.00	1.31	1.17	1.08	1.17	1.00	1.00	1.00	1.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RevMode_Decel

Description: Used for P0300-P0308. Crankshaft decel threshold. Thresholds are a function of rpm and % engine Load.

Value Units: Delta time between revolutions (usec)

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	1,100	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	102	51	38	30	26	20	20	20
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	102	51	38	30	26	20	20	20
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	102	51	38	30	26	20	20	20
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	102	51	38	30	26	20	20	20
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	112	63	46	33	27	20	20	20
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	129	78	55	37	29	21	21	21
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	149	98	66	44	33	22	22	22
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	174	113	75	49	36	25	25	25
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	197	126	82	53	40	29	29	29
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	215	139	90	58	43	32	32	32
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	234	150	95	63	48	34	34	34
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	252	160	101	69	51	37	37	37
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	285	180	112	79	60	43	42	42
40	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	356	216	139	101	83	59	59	59
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	498	286	193	150	129	93	93	93
78	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	627	373	240	192	168	122	122	122
97	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	773	472	295	238	217	155	155	155

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Ring Filter

Description: Used for P0300-P0308. Driveline Ring Filter
 After a low level misfire, another misfire may not be detectable until driveline ringing ceases. If no ringing seen, stop filter early.

Value Units: Number of Engine cycles after isolated misfire (Engine cycles)

X Unit: thousands of RPM (rpm/1000)

y/x	0	1	2	3	4	5	6	7	8
1	7	7	7	7	7	7	7	7	7

20 OBDG03D ECM Supporting Tables

Initial Supporting table - SCD_Decel

Description: Used for P0300-P0308 Crankshaft decel threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Value Units: Delta time per cylinder (usec)

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	607	607	376	220	148	100	77	54	48	32,767	32,767	32,767	32,767
6	590	590	371	200	136	99	77	54	48	32,767	32,767	32,767	32,767
8	610	610	402	204	139	94	74	61	48	32,767	32,767	32,767	32,767
10	658	658	413	237	162	113	78	65	46	32,767	32,767	32,767	32,767
12	734	734	418	282	210	142	105	77	53	32,767	32,767	32,767	32,767
14	858	858	517	329	245	176	133	89	66	32,767	32,767	32,767	32,767
16	1,195	1,195	673	398	280	200	154	110	79	32,767	32,767	32,767	32,767
18	1,586	1,586	1,164	453	317	225	165	125	82	32,767	32,767	32,767	32,767
20	2,066	2,066	1,594	591	421	267	207	156	117	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
40	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
78	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
97	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

20 OBDG03D ECM Supporting Tables

Initial Supporting table - SCD_Jerk

Description: Used for P0300-P0308. Crankshaft jerk threshold. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Value Units: Change in Delta time per cylinder from last cylinder (usec)

X Unit: RPM

Y Units: percent load of max indicated torque (%)

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	886	886	376	188	126	85	73	54	49	32,767	32,767	32,767	32,767
6	766	766	347	176	124	76	67	57	48	32,767	32,767	32,767	32,767
8	716	716	347	189	134	77	61	55	42	32,767	32,767	32,767	32,767
10	666	666	316	187	139	98	71	60	40	32,767	32,767	32,767	32,767
12	752	752	423	237	194	136	94	67	51	32,767	32,767	32,767	32,767
14	873	873	523	348	245	174	116	92	74	32,767	32,767	32,767	32,767
16	1,278	1,278	680	399	290	200	138	102	80	32,767	32,767	32,767	32,767
18	1,618	1,618	1,033	500	319	213	149	119	91	32,767	32,767	32,767	32,767
20	2,032	2,032	1,375	643	422	244	196	152	120	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
40	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
60	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
78	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
97	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

20 OBDG03D ECM Supporting Tables

Initial Supporting table - SnapDecayAfterMisfire

Description: Used for P0300 - P0308, multiplier times the ddt_jerk value used to detect misfire at that speed and load to see if size of disturbance has died down as expected of real misfire. Table lookup as a function of engine rpm and trans gear ratio.

Value Units: multiplier

X Unit: RPM

Y Units: gear ratio

y/x	900	1,100	1,400	1,800	2,200	2,600	3,000	4,000	5,000
1	1.17	1.23	1.50	1.65	1.42	1.97	2.00	2.00	2.00
1	1.17	1.23	1.50	1.65	1.42	1.97	2.00	2.00	2.00
1	1.17	1.23	1.50	1.65	1.42	1.97	2.00	2.00	2.00
1	1.10	1.14	1.54	1.28	1.25	1.15	1.43	1.43	1.43
2	1.97	2.00	2.00	1.44	1.39	1.67	1.67	1.67	1.67
2	1.92	1.41	1.39	1.63	1.54	1.80	1.83	1.83	1.83
3	1.88	1.41	1.57	1.47	1.59	2.00	2.00	2.00	2.00
4	2.00	1.67	1.83	1.47	1.59	2.00	2.00	2.00	2.00
7	2.00	1.67	1.83	1.47	1.59	2.00	2.00	2.00	2.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - TOSSRoughRoadThres

Description: Used for P0300-P0308. Only used if Rough Road source = TOSS: dispersion value on Transmission Output Speed Sensor above which rough road is indicated present

Value Units: change in rpm per sec (rpm)

X Unit: Engine Speed (RPM)

Y Units: Transmission Speed (RPM)

y/x	600	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,500	4,000	4,500	5,000	5,500	6,000
100	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
300	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
500	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
600	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
700	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
800	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
900	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,000	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,100	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,200	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,300	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
1,400	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - WaitToStart

Description: Used for P0300-P0308. Number of engine cycles to delay if diesel engine is cranked before wait to start lamp is extinguished. This lookup table determines the delay length by taking into account the coolant temperature.

Value Units: Number of Engine Cycles (integer)

X Unit: Engine Coolant (deg C)

y/x	-20	-10	0	10	20	30	40	50	60
1	0	0	0	0	0	0	0	0	0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - WSSRoughRoadThres

Description: Used for P0300-P0308. Only used if Wheel speed from ABS is used. If difference between wheel speed readings is larger than this limit, rough road is present

Value Units: acceleration
X Unit: Vehicle Speed (KPH)

y/x	0	12	24	36	48	60	72	85	97	109	121	133	145	157	169	181	193
1	0.40002	0.42004	0.43994	0.45996	0.47998	0.50000	0.52002	0.54004	0.56006	0.57996	0.59998	0.62000	0.64001	0.66003	0.68005	0.69995	0.71997

20 OBDG03D ECM Supporting Tables

Initial Supporting table - ZeroTorqueAFM

Description: Used for P0300-P0308. Zero torque engine load while in Active Fuel Management. %of Max Brake Torque along the Neutral rev line, as a function of RPM and Baro

Value Units: Percent of Maximum Brake torque (%)

X Unit: RPM

Y Units: Barometric Pressure (kPa)

ZeroTorqueAFM - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
65	-3.50	-3.50	-3.50	-2.50	-2.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00
75	-3.50	-3.50	-3.50	-2.50	-2.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00
85	-3.50	-3.50	-3.50	-2.50	-2.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00
95	-3.50	-3.50	-3.50	-2.50	-2.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00
105	-3.50	-3.50	-3.50	-2.50	-2.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00	-1.00

ZeroTorqueAFM - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
65	-1.00	-1.00	-1.00	-1.00	-1.00	-0.15	2.35	4.85	7.35	9.85	12.35	14.85	17.35
75	-1.00	-1.00	-1.00	-1.00	-1.00	-0.15	2.35	4.85	7.35	9.85	12.35	14.85	17.35
85	-1.00	-1.00	-1.00	-1.00	-1.00	-0.15	2.35	4.85	7.35	9.85	12.35	14.85	17.35
95	-1.00	-1.00	-1.00	-1.00	-1.00	-0.15	2.35	4.85	7.35	9.85	12.35	14.85	17.35
105	-1.00	-1.00	-1.00	-1.00	-1.00	-0.15	2.35	4.85	7.35	9.85	12.35	14.85	17.35

20 OBDG03D ECM Supporting Tables

Initial Supporting table - ZeroTorqueEngLoad

Description: Used for P0300-P0308. %of Max Brake Torque that represents Zero Brake torque along the Neutral rev line, as a function of RPM and Baro

Value Units: Percent of Maximum Brake torque (%)

X Unit: RPM

Y Units: Barometric Pressure (kPa)

ZeroTorqueEngLoad - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
65	-2.86	-2.86	-2.86	-2.89	-3.02	-3.02	-3.01	-2.96	-2.55	-1.13	-0.81	-0.72	-0.69
75	-2.61	-2.61	-2.61	-2.64	-2.77	-2.77	-2.76	-2.71	-2.30	-0.88	-0.56	-0.47	-0.44
85	-2.36	-2.36	-2.36	-2.39	-2.52	-2.52	-2.51	-2.46	-2.05	-0.63	-0.31	-0.22	-0.19
95	-2.11	-2.11	-2.11	-2.14	-2.27	-2.27	-2.26	-2.21	-1.80	-0.38	-0.06	0.03	0.06
105	-1.86	-1.86	-1.86	-1.89	-2.02	-2.02	-2.01	-1.96	-1.55	-0.13	0.19	0.28	0.31

ZeroTorqueEngLoad - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
65	-0.67	-0.65	-0.65	-0.65	-0.63	-0.38	3.68	8.88	14.08	19.28	24.47	29.68	40.08
75	-0.42	-0.40	-0.40	-0.40	-0.38	-0.13	4.33	9.53	14.73	19.93	25.12	30.33	40.73
85	-0.17	-0.15	-0.15	-0.15	-0.13	0.12	4.83	10.03	15.23	20.43	25.62	30.83	41.23
95	0.08	0.10	0.10	0.10	0.12	0.37	5.33	10.53	15.73	20.93	26.12	31.33	41.73
105	0.33	0.35	0.35	0.35	0.37	0.62	5.98	11.18	16.38	21.58	26.77	31.98	42.38

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KaFCLP_U_SlphrIntglOfst_Thrsh

Description: Integral Offset voltage thresholds (bank and cell specific calcs) used with KeFCLP_Pct_CatAccuSlphrPostDsbl to check for sulphur poisoning.

Value Units: millivolts
X Unit: Post Catalyst Number

y/x	CiOXYR_O2_PostCat1	CiOXYR_O2_PostCat2
CiFCLP_Decel	1,000	1,000
CiFCLP_Idle	1,000	1,000
CiFCLP_Cruise	1,000	1,000
CiFCLP_LightAccel	1,000	1,000
CiFCLP_HeavyAccel	1,000	1,000

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KcFCLP_Cnt_O2RdyCyclesThrsh

Description: Number of times a post oxygen sensor value must be in range before declaring it ready

Value Units: Time (events * 12.5 milliseconds)

y/x	1
1	10

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KcFULC_O2_SensorReadyEvents

Description: Number of times a pre oxygen sensor value must be in range before declaring it ready

Value Units: Time (events * 12.5 milliseconds)

y/x	1
1	10

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeEOSD_U_RichThrsh

Description: The oxygen sensor voltage above which a sensor will be considered failing during a Rich Test.

Value Units: Volts

y/x	1
1	1,050

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_dm_IntegrationAirflowMax

Description: Maximum allowed estimated airflow for post O2 integral terms to be updated.

Value Units: Grams per Second

y/x	1
1	512

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_Pct_CatAccuSlphrPostDsbl

Description: Sulphur percent threshold above which post integral learning is disabled if the threshold criteria KaFCLP_U_SlphrIntglOfst_Thrsh is also met.

Value Units: Percent

y/x	1
1	75

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMax

Description: Maximum allowed estimated catalytic converter temperature for post O2 integral terms to be updated.

Value Units: Celcius

y/x	1
1	950

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeFCLP_T_IntegrationCatalystMin

Description: Minimum allowed estimated catalytic converter temperature to begin using post O2 integration correction terms. Converter temperature must remain above this threshold to ramp-in the post O2 integration adjustments. Once the ramp-in has started, a converter temperature below this threshold will freeze the ramp-in multiplier. Post O2 integration will not be allowed below this converter temperature

Value Units: Celcius

y/x	1
1	500

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeFULC_T_WRAF_SensorReadyThrsh

Description: Pumping cell temperature threshold above which the wideband oxygen sensor will be considered ready for use

Value Units: Degrees Celcius

y/x	1
1	700

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeWRSC_T_HtrCntrlCL

Description: WRAF heater temperature enabling threshold for transition from Open Loop to Closed Loop

Value Units: Degrees Celcius

y/x	1
1	628

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KeWRSI_T_PumpCurrentEnable

Description: WRAF heater temperature threshold for enabling the sensor pump current

Value Units: Degrees Celcius

y/x	1
1	628

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KfFCLL_T_AdaptiveLoCoolant

Description: LTM learning is inhibited if the engine coolant temperature is below this calibration.

Value Units: Degrees Celcius

y/x	1
1	39

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KfFCLP_U_O2ReadyThrshLo

Description: Voltage limit checked against when determining if a post converter oxygen sensor is in range

Value Units: millivolts

y/x	1
1	1,100

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KfFULC_U_O2_SensorReadyThrshLo

Description: Voltage limit checked against when determining if a pre converter oxygen sensor is in range

Value Units: millivolts

y/x	1
1	1,795

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFCLL_p_AdaptiveLowMAP_Limit

Description: Long term fuel learning is disabled below this MAP limit as a function of barometric pressure.

Value Units: KPa

X Unit: KPa

y/x	65	70	75	80	85	90	95	100	105
1	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0	20.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP_t_PostIntgIDisableTime

Description: Disable integral offset after engine start for this amount of time as a function of start up coolant temperature.

Value Units: Time in seconds

X Unit: Degrees Celcius

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	220.0	220.0	220.0	196.0	120.0	72.0	60.0	60.0	52.0	41.0	35.0	32.0	36.0	40.0	44.0	60.0	60.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFCLP_t_PostIntgIRampInTime

Description: Time required to ramp integral offset to desired value as a function of start up coolant temperature.

Value Units: Time in seconds

X Unit: Degrees Celcius

y/x	-40	-29	-18	-6	5	16	28	39	50	61	73	84	95	106	118	129	140
1	60.0	60.0	60.0	60.0	60.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA_t_ClosedLoopAutostart

Description: Engine run time following an autostart, as a function of begin run coolant, which must be exceeded to enable CLOSED LOOP.

Value Units: Time in seconds

X Unit: Degrees Celcius

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	10.0	10.0	10.0	10.0	10.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Closed Loop Enable Clarification - KtFSTA_t_ClosedLoopTime

Description: Engine run time, as a function of startup coolant temperature, which must be exceeded to enable CLOSED LOOP.

Value Units: Time in seconds

X Unit: Degrees Celcius

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	360.0	300.0	240.0	180.0	130.0	55.0	45.0	35.0	20.0	10.0	8.0	5.0	10.0	10.0	10.0	10.0	10.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0442 Volatility Time as a Function of Estimate of Ambient Temperature

Description: EONV volatility time as a function of estimated ambient temperature

Value Units: Volatility time (seconds)

X Unit: Estimated Ambient Temperature (Deg C)

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	30	30	30	30	30	30	45	200	200	200	200	200	200	200	200	200	200

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0442 Engine Off Time Before Vehicle Off Maximum as a Function of Estimated Ambient Temperature

Description: Maximum engine off time before vehicle off time as a function of estimated ambient temperature (EAT)

Value Units: Maximum Engine Off Time Before Vehicle Off Time (seconds)

X Unit: Estimated Ambient Temperature (Deg C)

y/x	-10	-4	1	7	13	18	24	29	35	41	46	52	58	63	69	74	80
1	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0442 EONV Pressure Threshold (Pascals)

Description: EONV pressure threshold as a function of fuel level and estimated ambient temperature (EAT)

Value Units: EONV Pressure Threshold (Pascals)

X Unit: Fuel Level (percent) from 0 to 100 with step size 6.25

Y Units: Estimated Ambient Temperature (deg C) from -10 to 80 with step size 5.625

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
2	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
3	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
4	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
6	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
7	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
8	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
9	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
10	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
11	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
12	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
13	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
14	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
15	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
16	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5
17	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5	-124.5

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0496 Purge Valve Leak Test Engine Vacuum Test Time (Cold Start) as a Function of Fuel Level

Description: Purge valve leak test engine vacuum test time as a function of fuel level

Value Units: Purge Valve Leak Test Engine Vacuum Test Time (seconds)

X Unit: Fuel Level (percent)

y/x	0	6	12	19	25	31	37	44	50	56	62	69	75	81	87	94	100
1	132	129	126	123	119	116	113	110	107	104	101	97	94	91	88	85	82

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P01F0 - Heat To Coolant Min 2D

Description: KtETHD_P_CDD_HeatToCoolantMin

Value Units: Indicated Power (kW)

X Unit: Firing Fraction

Y Units: Ambient temperature (°C)

y/x	0.00	0.25	0.50	0.75	1.00
-20.0	15.0	15.0	15.0	15.0	15.0
-9.0	15.0	15.0	15.0	15.0	15.0
10.0	15.0	15.0	15.0	15.0	15.0
20.0	15.0	15.0	15.0	15.0	15.0
50.0	15.0	15.0	15.0	15.0	15.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P219A Quality Factor Bank1 Table

Description: Bank 1 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

Value Units: Unitless Scalar

X Unit: Engine Speed (RPM)

Y Units: Air Per Cylinder (APC) (mg/cylinder)

y/x	800	1,020	1,240	1,460	1,680	1,900	2,120	2,340	2,560	2,780	3,000	3,220	3,440	3,660	3,900	4,200	4,500
120	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
160	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
200	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
240	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
280	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
320	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
360	0.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
400	1.00	1.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
440	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
480	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
520	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
560	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
600	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
700	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
750	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P219B Quality Factor Bank2 Table

Description: Bank 2 lookup table of Quality Factors used in the calculation of the Ratio for the current sample period

Value Units: Unitless Scalar

X Unit: Engine Speed (RPM)

Y Units: Air Per Cylinder (APC) (mg/cylinder)

y/x	800	1,020	1,240	1,460	1,680	1,900	2,120	2,340	2,560	2,780	3,000	3,220	3,440	3,660	3,900	4,200	4,500
120	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
160	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
200	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
240	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
280	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
320	0.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
360	1.00	0.00	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
400	1.00	1.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
440	1.00	1.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
480	1.00	1.00	1.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00
520	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
560	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00
600	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
640	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
700	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00
750	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
800	0.00	0.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P057B KtBRKI_K_CmpltTestPointWeight

Description:

y/x	0.000	0.010	0.025	0.033	0.050	0.250	0.500	0.750	1.000
1	0	0	0	1	1	1	1	1	1

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P057B KtBRKI_K_FastTestPointWeight

Description:

y/x	0.000	0.010	0.025	0.033	0.050	0.250	0.500	0.750	1.000
1	0	0	0	1	1	1	1	1	1

20 OBDG03D ECM Supporting Tables

Initial Supporting table - DFCO_CoolEnlHi_Temp

Description:

y/x	-40	0	25
1	30.0	30.0	30.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - DFCO_DelayAfterStart_Time

Description:

y/x	-30	20	55	70	90
1	30.0	30.0	30.0	30.0	30.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - DFCO_DsblLo_Vehicle_Speed

Description:		
y/x	CeTCOR_e_NonEcoMode	CeTCOR_e_EcoMode
CeTGRR_e_TransGr1	0	0
CeTGRR_e_TransGr2	0	0
CeTGRR_e_TransGr3	0	0
CeTGRR_e_TransGr4	0	0
CeTGRR_e_TransGr5	0	0
CeTGRR_e_TransGr6	0	0
CeTGRR_e_TransGr9	0	0
CeTGRR_e_TransGr10	0	0
CeTGRR_e_TransGrNeut	0	0
CeTGRR_e_TransGrRvrs	0	0
CeTGRR_e_TransGrPark	0	0
CeTGRR_e_TransGr7	0	0
CeTGRR_e_TransGr8	0	0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - DFCO_EnbIHi_Vehicle_Speed

Description:		
y/x	CeTCOR_e_NonEcoMode	CeTCOR_e_EcoMode
CeTGRR_e_TransGr1	20.0	20.0
CeTGRR_e_TransGr2	30.0	30.0
CeTGRR_e_TransGr3	32.0	32.0
CeTGRR_e_TransGr4	36.0	36.0
CeTGRR_e_TransGr5	0.0	0.0
CeTGRR_e_TransGr6	0.0	0.0
CeTGRR_e_TransGr9	0.0	0.0
CeTGRR_e_TransGr10	0.0	0.0
CeTGRR_e_TransGrNeut	0.0	0.0
CeTGRR_e_TransGrRvrs	0.0	0.0
CeTGRR_e_TransGrPark	0.0	0.0
CeTGRR_e_TransGr7	0.0	0.0
CeTGRR_e_TransGr8	0.0	0.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - DFCO_EngSpdEnblOfst

Description:

y/x	-2,500	-2,150	-1,500	-500	-200	-150	-100	-8	0
1	500	100	50	0	0	0	0	0	0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - CalculatedPerfMaxIc1

Description: Maximum desired camshaft position for Intake CAM - Bank1

Value Units: Maximum desired camshaft position (degCam)

X Unit: Engine Oil Temperature (degC)

[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]

[-40 -28 -16 -4 8 20 32 44 56 68 80 92 104 116 128 140 152]

Y Units: Engine Speed (rpm)

[1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17]

[400 800 1200 1600 2000 2400 2800 3200 3600 4000 4400 4800 5200 5600 6000 6400 6800]

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
2	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
3	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
4	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
5	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
6	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
7	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
8	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
9	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
10	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
11	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
12	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
13	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
14	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
15	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
16	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0
17	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0	23.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0196_FastFailTempDiff

Description: EOT Sensor Cold Start Fast Fail Threshold

Value Units: Threshold between power-up engine oil temperature and power-up engine coolant temperature (Deg C)

X Unit: PowerUp coolant temperature (deg C)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	80.0	80.0	80.0	60.0	60.0	40.0	40.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0	30.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0196_TotalAccumulatedFlow

Description: Total accumulated air consumed by engine since engine start as a function of powerup undefaulted Oil Temperature

Value Units: Minimum accumulated (total) air grams consumed by engine (gram)

X Unit: PowerUp coolant temperature (deg C)

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	15,000	14,000	13,000	12,000	11,000	10,000	9,000	8,000	7,000	6,000	5,000	4,000	5,000	4,000	3,000	3,000	3,000

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0324_PerCyl_ExcessiveKnock_Threshold

Description: Fail threshold for the Knock Performance per-cylinder Excessive Knock Diagnostic

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19	1.19

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0325_P0330_OpenCktThrshMax (20 kHz)

Description: Knock Open Circuit Diagnostic Maximum Threshold when using the 20 kHz method (see "OpenMethod" description)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	5.7148	5.7148	5.6797	5.6719	5.5723	5.5879	5.5508	5.5508	5.5410	5.1797	4.6504	4.1230	4.1230	4.1230	4.1230	4.1230	4.1230

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0325_P0330_OpenCktThrshMax (Normal Noise)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

y/x	2,700	2,900	3,000	3,250	3,500	3,750	4,000	4,250	4,500	4,750	5,000	5,500	6,000	6,500	7,000	7,500	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0325_P0330_OpenCktThrshMin (20 kHz)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the 20 kHz method (see "OpenMethod" description)

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	2.6348	2.6211	2.6074	2.5996	2.5703	2.5605	2.5273	2.4941	2.4902	2.4219	2.2539	2.2539	2.2539	2.2539	2.2539	2.2539	2.2539

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0325_P0330_OpenCktThrshMin (Normal Noise)

Description: Knock Open Circuit Diagnostic Minimum Threshold when using the Normal Noise method (see "OpenMethod" description): When using the Normal Noise method (see "OpenMethod" description).

y/x	2,700	2,900	3,000	3,250	3,500	3,750	4,000	4,250	4,500	4,750	5,000	5,500	6,000	6,500	7,000	7,500	8,500
1	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000	0.0000

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0325_P0330_OpenMethod_2

Description: Defines which Knock Open Circuit Diagnostic method to use.

P0325_P0330_OpenMethod_2 - Part 1

y/x	0	1	2	3	4
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz

P0325_P0330_OpenMethod_2 - Part 2

y/x	5	6	7	8	9
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz

P0325_P0330_OpenMethod_2 - Part 3

y/x	10	11	12	13	14
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz

P0325_P0330_OpenMethod_2 - Part 4

y/x	15	16			
1	CeKNKD_e_Open_20KHz	CeKNKD_e_Open_20KHz			

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0326_P0331_AbnormalNoise_CylsEnabled

Description: Specifies which cylinders will be used for the Abnormal Noise portion of the performance diagnostics (1 = cylinder used, 0 = cylinder not used)

y/x	0	1	2	3	4	5	6	7
1	1	1	1	1	1	1	1	1

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0326_P0331_AbnormalNoise_Threshold

Description: Fail threshold for the Knock Performance Abnormal Noise Diagnostic

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.064	0.064	0.064	0.064	0.068	0.100	0.152	0.243	0.718	0.851	1.855	1.855	1.855	1.855	1.855	1.855	1.855

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0521_P06DD_P06DE_OP_HiStatePressure

Description: Two Stage Oil Pump Oil Pressure in High State

Value Units: Nominal high state oil pressure (kPa)

X Unit: Engine oil temperature, °C

y/x	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0
1,000.0	416.0	392.6	382.3	372.5	360.8	347.0	333.9	303.5	289.8
1,500.0	438.4	426.1	416.7	406.5	395.4	384.4	374.1	336.9	312.2
2,000.0	461.6	452.6	440.7	430.5	419.3	409.0	395.6	358.1	329.4
2,500.0	479.9	464.6	451.5	439.9	426.8	415.7	403.8	370.5	342.7
3,000.0	491.4	467.7	451.2	439.5	428.8	419.0	403.3	368.1	343.3
3,500.0	477.2	468.7	455.7	445.1	434.2	422.2	407.6	383.1	357.8
4,000.0	487.2	478.0	467.0	457.2	442.0	424.4	411.1	392.4	371.1
4,500.0	472.4	463.3	464.6	459.9	443.1	403.9	394.1	395.3	377.2
5,000.0	464.4	455.6	460.7	456.3	438.3	397.1	387.8	395.4	377.8

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0521_P06DD_P06DE_OP_LoStatePressure

Description: Two Stage Oil Pump Oil Pressure in Low State

Value Units: Nominal low state oil pressure (kPa)

X Unit: Engine oil temperature (deg C)

y/x	40	50	60	70	80	90	100	110	120
1,000	310	296	288	282	276	270	261	242	228
1,500	332	315	303	297	293	285	275	264	248
2,000	352	338	323	314	306	297	287	274	262
2,500	370	358	341	329	317	305	294	283	277
3,000	385	369	349	336	324	311	297	281	279
3,500	366	367	350	338	326	313	300	282	269
4,000	375	379	363	348	333	318	301	300	293
4,500	411	407	378	359	349	332	323	329	323
5,000	439	425	394	376	369	352	343	358	347

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P06B6_P06B7_OpenTestCktThrshMax

Description: Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.254	0.254	0.240	0.242	0.268	0.338	0.383	0.506	0.643	0.844	0.998	1.150	1.150	1.150	1.150	1.150	1.150

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P06B6_P06B7_OpenTestCktThrshMin

Description: Knock Open Circuit Minimum Threshold for Internal Circuit Diagnostic. Used only when the 20 kHz method is being used (see "OpenMethod" description). The Open Test Circuit ensures that the internal circuit used to generate the 20 kHz signal for the Open Circuit diags (P0325, P0330) is within range.

y/x	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	5,500	6,000	6,500	7,000	7,500	8,000	8,500
1	0.127	0.127	0.129	0.129	0.131	0.146	0.189	0.221	0.326	0.426	0.541	0.541	0.541	0.541	0.541	0.541	0.541

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P06DD_P06DE_MaxEnableTorque_OP

Description: Two Stage Oil Pump Rationality Test Torque Max Enable Threshold

Value Units: Maximum engine torque (Nm)

X Unit: Engine speed (RPM)

y/x	1,000.0	1,250.0	1,500.0	1,750.0	2,000.0	2,250.0	2,500.0	2,750.0	3,000.0
1.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0	1,000.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P06DD_P06DE_MinEnableTorque_OP

Description: Two Stage Oil Pump Rationality Test Torque Min Enable Threshold

Value Units: Min engine torque (Nm)

X Unit: Engine speed (RPM)

y/x	1,000.0	1,250.0	1,500.0	1,750.0	2,000.0	2,250.0	2,500.0	2,750.0	3,000.0
1.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P06DD_P06DE_MinOilPresT_{res}

Description: Intrusive diagnostic minimum pressure limit that is a function of Engine Speed and Oil Temperature

Value Units: Minimum engine oil pressure threshold (kPa)

X Unit: Engine oil temperature (deg C)

y/x	40	50	60	70	80	90	100	110	120
1,000	25	32	38	45	52	59	65	68	71
1,500	25	32	38	45	52	59	65	68	71
2,000	25	32	38	45	52	59	65	68	71
2,500	25	32	38	45	52	59	65	68	71
3,000	25	32	38	45	52	59	65	68	71
3,500	25	32	38	45	52	59	65	68	71
4,000	25	32	38	45	52	59	65	68	71
4,500	25	32	38	45	52	59	65	68	71
5,000	25	32	38	45	52	59	65	68	71

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P06DD_P06DE_OP_StateChangeMin

Description: Minimum allowed pressure change on a Two Stage Oil Pump state change

Value Units: Min pressure change (kPa)

X Unit: Engine oil temperature (deg C)

y/x	40.0	50.0	60.0	70.0	80.0	90.0	100.0	110.0	120.0
1,000.0	42.3	38.8	37.9	36.1	33.8	30.9	29.0	20.0	20.0
1,500.0	42.5	44.3	45.4	43.7	40.8	39.8	39.5	23.8	20.0
2,000.0	43.8	46.0	47.1	46.6	45.5	45.0	43.5	36.7	32.2
2,500.0	43.8	42.8	44.4	44.6	43.9	44.1	43.8	39.3	35.2
3,000.0	42.6	39.6	40.7	41.5	41.8	43.2	42.5	39.1	34.9
3,500.0	44.4	40.6	42.2	42.8	43.2	43.8	43.1	39.3	39.3
4,000.0	44.8	39.4	41.5	43.5	43.7	42.6	43.9	42.3	39.0
4,500.0	50.0	46.8	46.8	48.4	46.5	48.8	43.3	42.6	39.8
5,000.0	50.0	48.6	45.1	48.2	45.8	48.8	42.9	41.6	39.4

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Minimum Non-Purge Samples for Purge Vapor Fuel

Description: Number of Fuel Trim Monitor sample counts required to allow the Purge Vapor Fuel value to inhibit the Intrusive Rich test

Value Units: Sample Counts per loop rate of 100ms (divide by 10 to get seconds)

X Unit: Long Term Fuel Trim Cell I.D. (no units) (Only PurgeOff cells are used)

Minimum Non-Purge Samples for Purge Vapor Fuel - Part 1

y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	65,535	65,535	65,535	65,535

Minimum Non-Purge Samples for Purge Vapor Fuel - Part 2

y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	65,535	65,535	65,535	65,535

Minimum Non-Purge Samples for Purge Vapor Fuel - Part 3

y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	65,535	65,535	65,535	65,535

Minimum Non-Purge Samples for Purge Vapor Fuel - Part 4

y/x	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	65,535	65,535	65,535	65,535

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage

Description: Identifies which Long Term Fuel Trim Cell I.D.s are used for diagnosis. Only cells identified as "CeFADD_e_NonSelectedCell" are not used for diagnosis.

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 1

y/x	CeFADR_e_Cell00_PurgOnAirMode 5	CeFADR_e_Cell01_PurgOnAirMode 4	CeFADR_e_Cell02_PurgOnAirMode 3	CeFADR_e_Cell03_PurgOnAirMode 2
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 2

y/x	CeFADR_e_Cell04_PurgOnAirMode 1	CeFADR_e_Cell05_PurgOnAirMode 0	CeFADR_e_Cell06_PurgOnIdle	CeFADR_e_Cell07_PurgOnDecel
1	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell	CeFADD_e_SelectedPurgeCell

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 3

y/x	CeFADR_e_Cell08_PurgOffAirMode 5	CeFADR_e_Cell09_PurgOffAirMode 4	CeFADR_e_Cell10_PurgOffAirMode 3	CeFADR_e_Cell11_PurgOffAirMode 2
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell

P0171_P0172_P0174_P0175 Long-Term Fuel Trim Cell Usage - Part 4

y/x	CeFADR_e_Cell12_PurgOffAirMode 1	CeFADR_e_Cell13_PurgOffAirMode 0	CeFADR_e_Cell14_PurgOffIdle	CeFADR_e_Cell15_PurgOffDecel
1	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell	CeFADD_e_SelectedNonPurgeCell

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Startup Engine Coolant adjustment to Minimum accumulation time

Description: Time offset added to the minimum accumulation time based on Startup Coolant.

Value Units: Counts (10 counts equals 1 second)

X Unit: Degree C

y/x	-40	-28	-16	-4	8	20	32	44	56	68	80	92	104	116	128	140	152
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0068_Delta MAF Threshold f(TPS)

Description: Table of delta MAF values as a function of desired throttle position. The output of this table provides a delta MAF that if the measured minus the estimated MAF exceeds, is considered a fail.

Value Units: Delta MAF Values (dm)

X Unit: Desired Throttle Position (Pct)

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	11.91	16.59	21.23	26.30	32.36	255.00	255.00	255.00	255.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0068_Delta MAP Threshold f(TPS)

Description: Table of delta MAP values as a function of desired throttle position. The output of this table provides a delta MAP that if the measured minus the estimated MAP exceeds, is considered a fail.

Value Units: Delta MAP Values (kPa)

X Unit: Desired Throttle Position (Pct)

y/x	5.00	10.00	15.00	20.00	25.00	30.00	35.00	40.00	100.00
1.00	14.87	17.82	17.45	15.98	13.35	255.00	255.00	255.00	255.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0068_Maximum MAF f(RPM)

Description: Table of maximum MAF values vs. engine speed. This is the maximum MAF the engine can see under all ambient conditions.

Value Units: Delta MAF Values (dm)

X Unit: Engine Speed (RPM)

y/x	600.00	1,400.00	2,200.00	3,000.00	3,800.00	4,600.00	5,400.00	6,200.00	7,000.00
1.00	30.00	68.00	112.00	155.00	207.00	262.00	298.00	305.00	305.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0068_Maximum MAF f(Volts)

Description: Table of maximum MAF values vs. system voltage. The output of the air meter is clamped to lower values as system voltage drops off.

Value Units: Delta MAF Values (dm)

X Unit: System Voltage (V)

y/x	6.00	7.00	8.00	9.00	10.00	11.00	12.00	13.00	14.00
1.00	69.70	180.36	376.20	511.99	511.99	511.99	511.99	511.99	511.99

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0606_Last Seed Timeout f(Loop Time)

Description: The max time for the Last Seed Timeout as a function of operating loop time sequence.

Value Units: Max Time for Last Seed Timeout (ms)

X Unit: Operating Loop Sequence (enum)

P0606_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000	200.000

P0606_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	200.000	500.000	500.000	1,000.000	1,000.000	8,191.875	8,191.875	8,191.875

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0606_PSW Sequence Fail f(Loop Time)

Description: Fail threshold for PSW per operating loop.

Value Units: Fail threshold for PSW (count)

X Unit: Operating Loop (enum)

P0606_PSW Sequence Fail f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	5	3	5	3	5	3	5	3

P0606_PSW Sequence Fail f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	5	3	5	3	5	5	5	5

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0606_PSW Sequence Sample f(Loop Time)

Description: Sample threshold for PSW per operating loop.

Value Units: Sample threshold for PSW (count)

X Unit: Operating Loop (enum)

P0606_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	4	4	4	4	4	4	4	4

P0606_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	4	4	4	4	4	4	4	4

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P1682_PT Relay Pull-in Run/Crank Voltage f(IAT)

Description: The Run/Crank voltages required to pull in the PT relay as a function of induction air temperature.

Value Units: Run/Crank Voltages required to pull in PT Relay (V)

X Unit: Induction Air Temperature (deg C)

y/x	23.0	85.0	95.0	105.0	125.0
1	7.000	8.699	9.000	9.199	10.000

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P16F3_Delta MAP Threshold f(Desired Engine Torque)

Description: Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

Value Units: Torque Security Threshold for Engine Sync and Time Based Delta Pressure (kPa)

X Unit: Desired Engine Torque (Nm)

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	13.35	13.35	13.35	13.35	13.35	13.35

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P16F3_Speed Control External Load f(Oil Temp, RPM)

Description: Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

Value Units: External Load Table for SPDR (Nm)

X Unit: Engine Oil Temperature (deg C)

Y Units: Engine Speed (RPM)

y/x	-40.00	-15.00	5.00	32.00	55.00	90.00
350.00	439.00	439.00	439.00	434.28	412.25	256.54
450.00	439.00	439.00	439.00	353.08	333.68	210.57
570.00	439.00	388.61	349.08	248.10	230.94	154.38
650.00	422.36	370.44	335.83	240.40	224.49	136.36
750.00	400.06	351.40	323.93	250.50	234.14	118.05
850.00	398.50	356.58	332.39	271.68	255.33	138.64
950.00	400.59	359.12	332.62	287.61	265.17	145.41
1,050.00	392.72	351.60	323.18	289.73	262.24	150.96
1,150.00	349.22	309.95	282.61	238.46	213.69	126.20
1,350.00	285.43	248.11	222.07	176.68	155.25	115.00
1,600.00	198.80	166.04	141.72	97.85	80.07	87.00
2,150.00	140.94	109.38	87.12	44.66	31.23	25.00
2,400.00	120.41	89.25	67.68	26.87	14.88	3.20
3,100.00	85.47	54.94	34.45	-4.41	-14.11	-21.86
4,000.00	63.09	32.84	12.84	-24.15	-32.82	-42.54
4,900.00	48.80	18.55	-1.45	-38.44	-47.10	-56.85
5,800.00	33.49	3.24	-16.76	-53.56	-62.22	-72.79

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P228C P2C1F - High Pressure Pump Control (HPC) fail threshold of pressure too low

Description: The High Pressure Pump Control (HPC) fail threshold of pressure too low test as a function of desired fuel pressure.

Value Units: Pressure Error - Desired pressure - Actual Pressure (Mpa)

X Unit: Desired Pressure (Mpa)

y/x	2	3	4	15	20	25	28	32	36
1	0	2	3	3	3	3	3	3	3

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P228D P2C20 - High Pressure Pump Control (HPC) fail threshold for pressure too high

Description: The High Pressure Pump Control (HPC) fail threshold for pressure too high test as a function of desired fuel pressure.

Value Units: Pressure Error - Desired pressure - Actual Pressure (Mpa)

X Unit: Desired Pressure (Mpa)

y/x	2	3	4	15	20	25	28	32	36
1	-3	-3	-3	-3	-3	-3	-3	-3	-3

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0606_Last Seed Timeout f(Loop Time)

Description: The max time for the Last Seed Timeout as a function of operating loop time sequence.

Value Units: Max Time for Last Seed Timeout (ms)

X Unit: Operating Loop Sequence (enum)

P0606_Last Seed Timeout f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	200.000	200.000	200.000	200.000	200.000	200.000	200.000	200.000

P0606_Last Seed Timeout f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	200.000	500.000	500.000	1,000.000	1,000.000	8,191.875	8,191.875	8,191.875

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0606_PSW Sequence Fail f(Loop Time)

Description: Fail threshold for PSW per operating loop.

Value Units: Fail threshold for PSW (count)

X Unit: Operating Loop (enum)

P0606_PSW Sequence Fail f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	5	3	5	3	5	3	5	3

P0606_PSW Sequence Fail f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	5	3	5	3	5	5	5	5

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0606_PSW Sequence Sample f(Loop Time)

Description: Sample threshold for PSW per operating loop.

Value Units: Sample threshold for PSW (count)

X Unit: Operating Loop (enum)

P0606_PSW Sequence Sample f(Loop Time) - Part 1

y/x	CePISR_e_2p5msSeq	CePISR_e_3p125msSeq	CePISR_e_5msSeq	CePISR_e_6p25msSeq	CePISR_e_10msSeq	CePISR_e_12p5msSeq	CePISR_e_20msSeq	CePISR_e_25msSeq
1	4	4	4	4	4	4	4	4

P0606_PSW Sequence Sample f(Loop Time) - Part 2

y/x	CePISR_e_40msSeq	CePISR_e_50msSeq	CePISR_e_80msSeq	CePISR_e_100msSeq	CePISR_e_250msSeq	CePISR_e_EventA_Seq	CePISR_e_EventB_Seq	CePISR_e_EventC_Seq
1	4	4	4	4	4	4	4	4

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P16F3_Delta MAP Threshold f(Desired Engine Torque)

Description: Engine Sync based and Time based delta pressure threshold above which Torque Security error is reported.

Value Units: Torque Security Threshold for Engine Sync and Time Based Delta Pressure (kPa)

X Unit: Desired Engine Torque (Nm)

y/x	0.00	50.00	100.00	150.00	200.00	300.00
1.00	13.35	13.35	13.35	13.35	13.35	13.35

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P16F3_Speed Control External Load f(Oil Temp, RPM)

Description: Specifies the external load table for SPDR torque security as a function of engine oil temperature and engine RPM.

Value Units: External Load Table for SPDR (Nm)

X Unit: Engine Oil Temperature (deg C)

Y Units: Engine Speed (RPM)

y/x	-40.00	-15.00	5.00	32.00	55.00	90.00
350.00	439.00	439.00	439.00	434.28	412.25	256.54
450.00	439.00	439.00	439.00	353.08	333.68	210.57
570.00	439.00	388.61	349.08	248.10	230.94	154.38
650.00	422.36	370.44	335.83	240.40	224.49	136.36
750.00	400.06	351.40	323.93	250.50	234.14	118.05
850.00	398.50	356.58	332.39	271.68	255.33	138.64
950.00	400.59	359.12	332.62	287.61	265.17	145.41
1,050.00	392.72	351.60	323.18	289.73	262.24	150.96
1,150.00	349.22	309.95	282.61	238.46	213.69	126.20
1,350.00	285.43	248.11	222.07	176.68	155.25	115.00
1,600.00	198.80	166.04	141.72	97.85	80.07	87.00
2,150.00	140.94	109.38	87.12	44.66	31.23	25.00
2,400.00	120.41	89.25	67.68	26.87	14.88	3.20
3,100.00	85.47	54.94	34.45	-4.41	-14.11	-21.86
4,000.00	63.09	32.84	12.84	-24.15	-32.82	-42.54
4,900.00	48.80	18.55	-1.45	-38.44	-47.10	-56.85
5,800.00	33.49	3.24	-16.76	-53.56	-62.22	-72.79

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0191 - High fail limit of fuel control due to high pressure sensor skewed High

Description: High fail limit of fuel control due to high pressure sensor skewed High error as Function of desired pressure

Value Units: Ratio

X Unit: Desired Pressure (Mpa)

y/x	1.50	3.00	4.00	15.00	20.00	25.00	27.50	32.00	36.00
1.00	1.20	1.20	1.20	1.20	1.20	1.20	1.20	1.09	1.05

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P0191 - Low fail limit of fuel control due to pressure sensor skewed low

Description: Low fail limit of fuel control due to pressure sensor skewed low error as Function of desired pressure

Value Units: Ratio

X Unit: Desired Pressure (Mpa)

y/x	1.50	3.00	4.00	15.00	20.00	25.00	27.50	32.00	36.00
1.00	0.86	0.86	0.86	0.86	0.86	0.86	0.86	0.92	0.95

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P129F Threshold High

Description: P129F Filtered Fuel Pump Speed Error High Threshold [over-performing motor]
Instantaneously calculated filtered pump speed error measured is higher than commanded

Value Units: revs / min

X Unit: revs / min [commanded pump speed]

Y Units: kiloPascals [requested fuel pressure]

y/x	200.0	300.0	400.0	500.0	600.0
1,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
2,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
3,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
4,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
5,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
6,000.0	-675.0	-675.0	-675.0	-675.0	-675.0
7,000.0	-1,200.0	-1,200.0	-1,200.0	-1,200.0	-1,200.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P129F Threshold Low

Description: P129F Filtered Fuel Pump Speed Error Low Threshold [under-performing motor]
Instantaneously calculated filtered pump speed error measured is lower than commanded

Value Units: revs / min

X Unit: revs / min [commanded pump speed]

Y Units: kiloPascals [requested fuel pressure]

y/x	200.0	300.0	400.0	500.0	600.0
1,000.0	675.0	675.0	675.0	675.0	675.0
2,000.0	675.0	675.0	675.0	675.0	675.0
3,000.0	675.0	675.0	675.0	675.0	675.0
4,000.0	675.0	675.0	675.0	675.0	675.0
5,000.0	675.0	675.0	675.0	675.0	675.0
6,000.0	675.0	675.0	675.0	675.0	675.0
7,000.0	1,200.0	1,200.0	1,200.0	1,200.0	1,200.0

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P228C P2C1F - High Pressure Pump Control (HPC) fail threshold of pressure too low

Description: The High Pressure Pump Control (HPC) fail threshold of pressure too low test as a function of desired fuel pressure.

Value Units: Pressure Error - Desired pressure - Actual Pressure (Mpa)

X Unit: Desired Pressure (Mpa)

y/x	2	3	4	15	20	25	28	32	36
1	0	2	3	3	3	3	3	3	3

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P228D P2C20 - High Pressure Pump Control (HPC) fail threshold for pressure too high

Description: The High Pressure Pump Control (HPC) fail threshold for pressure too high test as a function of desired fuel pressure.

Value Units: Pressure Error - Desired pressure - Actual Pressure (Mpa)

X Unit: Desired Pressure (Mpa)

y/x	1.50	3.00	4.00	15.00	20.00	25.00	27.50	32.00	36.00
1	-3.00	-3.00	-3.00	-3.00	-3.00	-3.00	-3.00	-3.00	-3.00

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P2635 Max Fuel Flow

Description: P2635 Maximum Fuel Flow Disable Criteria
 Maximum allowed fuel flow values above which the diagnostic is disabled

Value Units: grams / second
X Unit: kilopascals [commanded fuel pressure]
Y Units: volts [device supply]

y/x	250	300	350	400	450	500	550	600	700
5	512	512	512	512	512	512	512	512	512
6	512	512	512	512	512	512	512	512	512
8	512	512	512	512	512	512	512	512	512
9	512	512	512	512	512	512	512	512	512
11	512	512	512	512	512	512	512	512	512
12	512	512	512	512	512	512	512	512	512
14	512	512	512	512	512	512	512	512	512
15	512	512	512	512	512	512	512	512	512
17	512	512	512	512	512	512	512	512	512
18	512	512	512	512	512	512	512	512	512
20	512	512	512	512	512	512	512	512	512
21	512	512	512	512	512	512	512	512	512
23	512	512	512	512	512	512	512	512	512
24	512	512	512	512	512	512	512	512	512
26	512	512	512	512	512	512	512	512	512
27	512	512	512	512	512	512	512	512	512
29	512	512	512	512	512	512	512	512	512

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P2635 Threshold High

Description: P2635 Filtered Fuel Pressure Error High Threshold [under-performing pump]
Instantaneously calculated filtered fuel pressure error

Value Units: kilopascals

X Unit: kilopascals [commanded fuel pressure]

Y Units: grams / sec [fuel flow]

y/x	250	300	350	400	450	500	550	600	700
0	30	38	45	53	60	68	75	100	280
2	30	38	45	53	60	68	75	100	280
3	30	38	45	53	60	68	75	100	280
5	30	38	45	53	60	68	75	100	280
6	30	38	45	53	60	68	75	100	280
8	30	38	45	53	60	68	75	100	280
9	30	38	45	53	60	68	75	100	280
11	30	38	45	53	60	68	75	100	280
12	30	38	45	53	60	68	75	100	280
14	30	38	45	53	60	68	75	100	280
15	30	38	45	53	60	68	75	100	280
17	30	38	45	53	60	68	75	100	280
18	30	38	45	53	60	68	75	100	280
20	30	38	45	53	60	68	75	100	280
21	30	38	45	53	60	68	75	100	280
23	30	38	45	53	60	68	75	100	280
24	30	38	45	53	60	68	75	100	280
26	30	38	45	53	60	68	75	100	280
27	30	38	45	53	60	68	75	100	280
29	30	38	45	53	60	68	75	100	280
30	30	38	45	53	60	68	75	100	280
32	30	38	45	53	60	68	75	100	280
33	30	38	45	53	60	68	75	100	280
35	30	38	45	53	60	68	75	100	280
36	30	38	45	53	60	68	75	100	280
38	30	38	45	53	60	68	75	100	280
39	30	38	45	53	60	68	75	100	280
41	30	38	45	53	60	68	75	100	280
42	30	38	45	53	60	68	75	100	280
44	30	38	45	53	60	68	75	100	280
45	30	38	45	53	60	68	75	100	280

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P2635 Threshold High

47	30	38	45	53	60	68	75	100	280
48	30	38	45	53	60	68	75	100	280

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P2635 Threshold Low

Description: P2635 Filtered Pressure Error Low Threshold [over-performing pump]
Instantaneously calculated filtered fuel pressure error

Value Units: kilopascals

X Unit: kilopascals [commanded fuel pressure]

Y Units: grams / second [fuel flow]

y/x	250	300	350	400	450	500	550	600	700
0	-260	-210	-160	-110	-60	-68	-75	-83	-90
2	-145	-125	-103	-81	-60	-68	-75	-83	-90
3	-30	-38	-45	-53	-60	-68	-75	-83	-90
5	-30	-38	-45	-53	-60	-68	-75	-83	-90
6	-30	-38	-45	-53	-60	-68	-75	-83	-90
8	-30	-38	-45	-53	-60	-68	-75	-83	-90
9	-30	-38	-45	-53	-60	-68	-75	-83	-90
11	-30	-38	-45	-53	-60	-68	-75	-83	-90
12	-30	-38	-45	-53	-60	-68	-75	-83	-90
14	-30	-38	-45	-53	-60	-68	-75	-83	-90
15	-30	-38	-45	-53	-60	-68	-75	-83	-90
17	-30	-38	-45	-53	-60	-68	-75	-83	-90
18	-30	-38	-45	-53	-60	-68	-75	-83	-90
20	-30	-38	-45	-53	-60	-68	-75	-83	-90
21	-30	-38	-45	-53	-60	-68	-75	-83	-90
23	-30	-38	-45	-53	-60	-68	-75	-83	-90
24	-30	-38	-45	-53	-60	-68	-75	-83	-90
26	-30	-38	-45	-53	-60	-68	-75	-83	-90
27	-30	-38	-45	-53	-60	-68	-75	-83	-90
29	-30	-38	-45	-53	-60	-68	-75	-83	-90
30	-30	-38	-45	-53	-60	-68	-75	-83	-90
32	-30	-38	-45	-53	-60	-68	-75	-83	-90
33	-30	-38	-45	-53	-60	-68	-75	-83	-90
35	-30	-38	-45	-53	-60	-68	-75	-83	-90
36	-30	-38	-45	-53	-60	-68	-75	-83	-90
38	-30	-38	-45	-53	-60	-68	-75	-83	-90
39	-30	-38	-45	-53	-60	-68	-75	-83	-90
41	-30	-38	-45	-53	-60	-68	-75	-83	-90
42	-30	-38	-45	-53	-60	-68	-75	-83	-90
44	-30	-38	-45	-53	-60	-68	-75	-83	-90
45	-30	-38	-45	-53	-60	-68	-75	-83	-90

20 OBDG03D ECM Supporting Tables

Initial Supporting table - P2635 Threshold Low

47	-30	-38	-45	-53	-60	-68	-75	-83	-90
48	-30	-38	-45	-53	-60	-68	-75	-83	-90

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RufCyl_Decel

Description: Used for P0300-P0308. Crankshaft decel threshold during Idle or GPF regen. Thresholds are a function of rpm and % engine Load.

Value Units: Delta time per cylinder (usec)

X Unit: rpm

Y Units: percent load of max indicated torque (%)

RufCyl_Decel - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	1,650	1,500	943	575	400	260	177	146	134	68	49	28	20
6	1,650	1,500	925	575	400	260	181	147	132	61	46	28	20
8	1,760	1,600	925	600	425	307	204	146	132	60	47	30	20
10	1,980	1,800	1,100	675	475	345	237	145	132	58	49	35	28
12	2,200	1,986	1,200	750	550	385	280	152	129	58	50	42	33
14	2,750	2,173	1,300	850	641	440	326	180	133	70	59	53	40
16	3,025	2,326	1,400	950	700	491	367	217	137	81	69	62	46
18	3,135	2,508	1,500	1,065	755	545	400	269	153	103	94	73	52
20	3,245	2,665	1,600	1,167	791	598	425	314	182	130	118	86	59
22	3,410	2,837	1,700	1,265	826	663	460	354	219	155	137	97	65
24	3,575	2,985	1,800	1,356	862	720	497	393	257	180	157	108	75
26	3,740	3,142	1,900	1,438	890	774	535	429	294	204	177	118	84
28	3,850	3,284	1,994	1,521	931	812	570	465	331	235	196	129	90
30	3,960	3,431	2,084	1,608	977	861	612	501	370	266	209	138	95
32	4,228	3,568	2,183	1,684	1,027	904	656	536	406	293	224	145	101
34	4,498	3,695	2,287	1,750	1,075	960	691	575	440	318	239	154	108
36	4,765	3,822	2,412	1,845	1,138	1,016	726	614	484	339	254	165	114

RufCyl_Decel - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RufCyl_Decel

26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RufCyl_Jerk

Description: Crankshaft jerk threshold during Idle or GPF regen. Thresholds are a function of rpm and % engine Load.

Value Units: Delta time per cylinder (usec)

X Unit: rpm

Y Units: percent load of max indicated torque (%)

RufCyl_Jerk - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	1,650	1,500	925	575	400	261	160	143	127	73	50	40	24
6	1,650	1,500	925	575	400	257	164	141	124	71	49	39	23
8	1,760	1,600	985	600	425	290	182	139	124	70	47	39	22
10	1,980	1,800	1,100	675	475	335	222	136	123	70	48	39	28
12	2,200	1,961	1,200	750	550	380	266	136	117	71	52	45	34
14	2,522	2,129	1,300	850	619	433	309	160	120	80	60	54	38
16	2,796	2,267	1,400	950	676	485	350	211	122	88	71	63	43
18	2,983	2,406	1,500	1,060	727	535	391	256	144	109	92	73	52
20	3,187	2,561	1,600	1,170	778	585	431	301	180	136	110	83	59
22	3,410	2,716	1,700	1,260	829	634	468	343	216	164	130	93	65
24	3,575	2,879	1,800	1,355	880	684	508	383	252	190	152	105	74
26	3,740	3,054	1,881	1,455	939	740	548	424	292	225	170	116	82
28	3,901	3,189	1,950	1,553	994	790	588	460	329	254	190	126	88
30	4,083	3,348	2,000	1,642	1,054	843	627	497	366	276	205	134	95
32	4,265	3,490	2,060	1,736	1,118	904	667	535	400	303	219	142	101
34	4,497	3,617	2,124	1,815	1,185	958	705	576	436	328	236	150	108
36	4,674	3,763	2,187	1,913	1,257	1,012	744	613	473	356	254	160	114

RufCyl_Jerk - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RufCyl_Jerk

26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RufSCD_Decel

Description: Used for P0300-P0308. Crankshaft decel threshold while in SCD mode during Idle or GPF regen. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load. Note: Misfire's Load term is %, but not PID\$04. PID \$04 is not robust to temperature and altitude shifts. (especially decel and jerk thresholds since they track actual air trapped in cylinder)

Value Units: Delta time per cylinder (usec)
X Unit: rpm
Y Units: percent load of max indicated torque (%)

RufSCD_Decel - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	607	607	376	220	148	100	77	54	48	32,767	32,767	32,767	32,767
6	590	590	371	200	136	99	77	54	48	32,767	32,767	32,767	32,767
8	610	610	402	204	139	94	74	61	48	32,767	32,767	32,767	32,767
10	658	658	413	237	162	113	78	65	46	32,767	32,767	32,767	32,767
12	734	734	418	282	210	142	105	77	53	32,767	32,767	32,767	32,767
14	858	858	517	329	245	176	133	89	66	32,767	32,767	32,767	32,767
16	1,195	1,195	673	398	280	200	154	110	79	32,767	32,767	32,767	32,767
18	1,586	1,586	1,164	453	317	225	165	125	82	32,767	32,767	32,767	32,767
20	2,066	2,066	1,594	591	421	267	207	156	117	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

RufSCD_Decel - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RufSCD_Decel

22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RufSCD_Jerk

Description: Used for P0300-P0308. Crankshaft jerk threshold while in SCD mode during Idle or GPF regen. SCD mode uses smaller windows near TDC. Thresholds are a function of rpm and % engine Load.

Value Units: Delta time per cylinder (usec)

X Unit: rpm

Y Units: percent load of max indicated torque (%)

RufSCD_Jerk - Part 1

y/x	400	500	600	700	800	900	1,000	1,100	1,200	1,400	1,600	1,800	2,000
3	886	886	376	188	126	85	73	54	49	32,767	32,767	32,767	32,767
6	766	766	347	176	124	76	67	57	48	32,767	32,767	32,767	32,767
8	716	716	347	189	134	77	61	55	42	32,767	32,767	32,767	32,767
10	666	666	316	187	139	98	71	60	40	32,767	32,767	32,767	32,767
12	752	752	423	237	194	136	94	67	51	32,767	32,767	32,767	32,767
14	873	873	523	348	245	174	116	92	74	32,767	32,767	32,767	32,767
16	1,278	1,278	680	399	290	200	138	102	80	32,767	32,767	32,767	32,767
18	1,618	1,618	1,033	500	319	213	149	119	91	32,767	32,767	32,767	32,767
20	2,032	2,032	1,375	643	422	244	196	152	120	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

RufSCD_Jerk - Part 2

y/x	2,200	2,400	2,600	2,800	3,000	3,001	3,500	4,000	4,500	5,000	5,500	6,000	7,000
3	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
6	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
8	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
10	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
12	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
14	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
16	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
18	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
20	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
22	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

20 OBDG03D ECM Supporting Tables

Initial Supporting table - RufSCD_Jerk

24	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
26	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
28	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
30	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
32	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
34	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767
36	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767	32,767

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Misfire_IMEP_BinID_Load_Axis

Description: Cylinder LOAD for defining Y AXIS in Misfire_IMEP_BinID_versus_Speed_and_Load

Value Units: Indicated Mean Effective Pressure

X Unit: Bin ID row number

y/x	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	0	200	400	600	800	1,000	1,200	1,400	1,600	1,800	2,000	2,200	2,400	2,600	2,800	3,000	3,200

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Misfire_IMEP_BinID_RPM_Axis

Description: Cylinder RPM for defining the X AXIS in Misfire_IMEP_BinID_versus_Speed_and_Load

Value Units: RPM
X Unit: BinID Column number

y/x	1	2	3	4	5	6	7	8	9
1	0	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Misfire_IMEP_BinID_vs_RPM_Load

Description: Misfire calibrations used with Crankshaft Based IMEP (Indicated Mean Effective Pressure) estimation do not interpolate versus speed and load. Instead they use unique calibrations within each small speed load "bin". Each Bin has its own "bin ID". This Bin ID keeps all the Crank Based IMEP estimate calculations and various Misfire calibrations synchronized while minimizing through put. Each speed load range defines a unique "Bin ID" in this Bin ID table. The BinID tables Y axis is cylinder load, and X axis is rpm as defined in Misfire_IMEP_BinID_Load_Axis and Misfire_IMEP_BinID_RPM_Axis tables

Value Units: Bin ID

X Unit: RPM range

Y Units: Cylinder Load Range

y/x	0	1	2	3	4	5	6	7	8
0	0	17	34	51	68	85	102	119	136
1	1	18	35	52	69	86	103	120	137
2	2	19	36	53	70	87	104	121	138
3	3	20	37	54	71	88	105	122	139
4	4	21	38	55	72	89	106	123	140
5	5	22	39	56	73	90	107	124	141
6	6	23	40	57	74	91	108	125	142
7	7	24	41	58	75	92	109	126	143
8	8	25	42	59	76	93	110	127	144
9	9	26	43	60	77	94	111	128	145
10	10	27	44	61	78	95	112	129	146
11	11	28	45	62	79	96	113	130	147
12	12	29	46	63	80	97	114	131	148
13	13	30	47	64	81	98	115	132	149
14	14	31	48	65	82	99	116	133	150
15	15	32	49	66	83	100	117	134	151
16	16	33	50	67	84	101	118	135	152

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Misfire_IMEP_Thresh_vs_BinID

Description: Crankshaft Indicated Mean Effective Pressure (IMEP) Estimate that below which will be considered misfire. Misfire calibrations used with Crankshaft Based IMEP (Indicated Mean Effective Pressure) estimation do not interpolate versus speed and load. Instead they use unique calibrations within each small speed load region or "bin". Each Bin has its own "BinID". This BinID keeps all the Crank Based IMEP estimate calculations and various Misfire calibrations synchronized while minimizing through put. Each speed load range defines a unique "Bin ID" in this Bin ID table.

The BinID table's Y axis is cylinder load, and X axis is rpm as defined in Misfire_IMEP_BinID_Load_Axis and Misfire_IMEP_BinID_RPM_Axis tables

Value Units: KPa

X Unit: BinID

Misfire_IMEP_Thresh_vs_BinID - Part 1

y/x	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Misfire_IMEP_Thresh_vs_BinID - Part 2

y/x	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Misfire_IMEP_Thresh_vs_BinID - Part 3

y/x	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Misfire_IMEP_Thresh_vs_BinID - Part 4

y/x	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Misfire_IMEP_Thresh_vs_BinID - Part 5

y/x	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Misfire_IMEP_Thresh_vs_BinID - Part 6

y/x	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100	101
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Misfire_IMEP_Thresh_vs_BinID - Part 7

y/x	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Misfire_IMEP_Thresh_vs_BinID - Part 8

y/x	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

Misfire_IMEP_Thresh_vs_BinID - Part 9

y/x	136	137	138	139	140	141	142	143	144	145	146	147	148	149	150	151	152
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

20 OBDG03D ECM Supporting Tables

Initial Supporting table - Misfire_IMEP_Thresh_vs_BinID

1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
Transmission Control Module (TCM)	P0601	Transmission Electro-Hydraulic Control Module Read Only Memory	Incorrect program/calibrations checksum	= TRUE Boolean		MIL not Illuminated for DTC's: TCM: P0601 ECM: None	>= 5 Fail Counts	One Trip
Transmission Control Module (TCM)	P0603	Transmission Electro-Hydraulic Control Module Long-Term Memory Reset	Non-volatile memory (static or dynamic) checksum failure at Powerup	= TRUE Boolean		MIL not Illuminated for DTC's: TCM: P0603 ECM: None	Runs Continuously	One Trip
Transmission Control Module (TCM)	P0604	Transmission Electro-Hydraulic Control Module Random Access Memory	RAM Read/Write Failure (Single Word)	= TRUE Boolean		MIL not Illuminated for DTC's: TCM: P0604 ECM: None	>= 5 Fail Counts = 16 Sample Counts	One Trip
Transmission Control Module (TCM)	P062F	Transmission Electro-Hydraulic Control Module Long Term Memory Performance	TCM Non-Volatile Memory bit Incorrect flag at Powerdown	= TRUE Boolean		MIL not Illuminated for DTC's: TCM: P062F ECM: None	Runs Continuously	One Trip
Transmission Control Module (TCM)	P0634	Transmission Electro-Hydraulic Control Module Internal Temperature Too High	<u>Fail Case 1</u> Substrate Temperature	>= 142.1015625 °C			>= 5 Fail Time (Sec)	One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			<u>Fail Case 2</u>					
			Substrate Temperature	>= 50 °C			>= 2 Fail Time (Sec)	
			Ignition Voltage	>= 18 Volts				
			Note: either fail case can set the DTC					
					Ignition Voltage Lo >= 8.5996094 Volts Ignition Voltage Hi <= 31.999023 Volts Substrate Temp Lo >= 0 °C Substrate Temp Hi <= 170 °C Substrate Temp Between Temp Range for Time >= 0.25 Sec P0634 Status is ≠ Test Failed This Key On or Fault Active			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
High Side Driver 1	P0658	Actuator Supply Voltage Circuit Low	The HWIO reports a low voltage (open or ground short) error flag	= TRUE Boolean			>= 4 Fail Counts out of 6 Sample Counts	One Trip
						P0658 Status is not = Test Failed This Key On or Fault Active High Side Driver 1 On = True Boolean Disable Conditions: MIL not Illuminated for DTC's: TCM: None ECM: None		
Transmission Control Module (TCM)	P0667	TCM Internal Temp (substrate) Sensor Circuit Range/Performance	If transmission oil temp to substrate temp Δ >	Refer to Table 19 in supporting documents °C				Two Trips
			If TCM substrate temp to power up temp Δ >	Refer to Table 20 in supporting documents °C				
			Both conditions above required to increment fail counter				>= 3000 Fail Counts (100ms loop) Out of 3750 Sample Counts (100ms loop)	
			Note: table reference temp = to the median temp of trans oil temp, substrate temp and power up temp.					

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Non-continuous (intermittent) fail conditions will delay resetting fail counter until				>= 700 Pass Counts (100ms loop) Out of 875 Sample Counts (100ms loop)	
					Engine Torque Signal Valid Accelerator Position Signal Valid Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for Brake torque active	= TRUE Boolean = TRUE Boolean >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec = FALSE		
					Below describes the brake torque entry criteria Engine Torque Throttle Transmission Input Speed Vehicle Speed Transmission Range Transmission Range PTO Set Brake Torque Active TRUE if above conditions are met for:	>= 90 N*m >= 30.000305 Pct <= 200 RPM <= 8 Kph ≠ Park ≠ Neutral = Not Active >= 7 sec		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Below describes the brake torque exit criteria Brake torque entry criteria = Not Met Clutch hydraulic pressure ≠ Hydraulic Air Purge Event Clutch used to exit brake torque active = CeTFTD_e_C3_RatE_nbl The above clutch pressure is greater than this value for one loop >= 600 kpa Set Brake Torque Active FALSE if above conditions are met for: >= 20 Sec P0667 Status is ≠ Test Failed This Key On or Fault Active			
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: P0658, P0668, P0669, P06AD, P06AE, P0716, P0712, P0713, P0717, P0722, P0723, P0962, P0963, P0966, P0967, P0970, P0971, P215C, P2720, P2721, P2729, P2730 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Transmission Control Module (TCM)	P0668	TCM internal temperature (substrate) thermistor failed at a low voltage	Type of Sensor Used	= CeTFTL_e_VoltageDirectProp				Two Trips

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	MIL Illum.
			If TCM Substrate Temperature Sensor = Direct Proportional and Temp	<= -249 °C				
			If TCM Substrate Temperature Sensor = Indirect Proportional and Temp	>= -249 °C				
			Either condition above will satisfy the fail conditions				>= 60 Fail Timer (Sec)	
					Ignition Voltage Lo	>= 8.5996094 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					P0668 Status is	≠ Test Failed This Key On or Fault Active		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Transmission Control Module (TCM)	P0669	TCM internal temperature (substrate) thermistor failed at a high voltage	Type of Sensor Used	= CeTFTI_e_VoltageDirectProp				Two Trips
			If TCM Substrate Temperature Sensor = Direct Proportional and Temp	>= 249 °C				
			If TCM Substrate Temperature Sensor = Indirect Proportional and Temp	<= 249 °C				
			Either condition above will satisfy the fail conditions				>= 60 Fail Timer (Sec)	
					Ignition Voltage Lo	>= 8.5996094 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	MIL Illum.
					Engine Speed is within the allowable limits for P0669 Status is For Hybrids, below conditions must also be met Estimated Motor Power Loss Estimated Motor Power Loss greater than limit for time Lost Communication with Hybrid Processor Control Module Estimated Motor Power Loss Fault	>= 5 Sec ≠ Test Failed This Key On or Fault Active >= 0 kW >= 0 Sec = FALSE = FALSE		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723 ECM: None		
Transmission Control Module (TCM)	P06AC	TCM Power-up Temp Sensor Circuit Range/Performance	If TCM power-up temp to substrate temp Δ > If transmission oil temp to power up temp Δ >	Refer to Table 20 in supporting documents °C Refer to Table 18 in supporting documents °C				Two Trips
			Both conditions above required to increment fail counter Note: table reference temp = to the median temp of trans oil temp, substrate temp and power up temp.				>= 3000 Fail Counts (100ms loop) Out of 3750 Sample Counts (100ms loop)	

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Non-continuous (intermittent) fail conditions will delay resetting fail counter until				>= 700 Pass Counts (100ms loop) Out of 875 Sample Counts (100ms loop)	
					Engine Torque Signal Valid Accelerator Position Signal Valid Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for Brake torque active	= TRUE Boolean = TRUE Boolean >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec = FALSE		
					Below describes the brake torque entry criteria Engine Torque Throttle Transmission Input Speed Vehicle Speed Transmission Range Transmission Range PTO Set Brake Torque Active TRUE if above conditions are met for:	>= 90 N*m >= 30.000305 Pct <= 200 RPM <= 8 Kph ≠ Park ≠ Neutral = Not Active >= 7 sec		
					Below describes the brake torque exit criteria Brake torque entry criteria Clutch hydraulic pressure Clutch used to exit brake torque active The above clutch pressure is greater than this value for one loop	= Not Met Clutch ≠ Hydraulic Air Purge Event = CeTFTD_e_C3_RatIE nbl >= 600 kpa		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Set Brake Torque Active FALSE if above conditions are met for: P06AC Status is	>= 20 Sec ≠ Test Failed This Key On or Fault Active		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: P0658, P0668, P0669, P06AD, P06AE, P0716, P0712, P0713, P0717, P0722, P0723, P0962, P0963, P0966, P0967, P0970, P0971, P215C, P2720, P2721, P2729, P2730 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Transmission Control Module (TCM)	P06AD	TCM power-up thermistor circuit voltage low	Power Up Temp	<= -59 °C			>= 60 Fail Time (Sec)	Two Trips
					Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for P06AD Status is	>= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec ≠ Test Failed This Key On or Fault Active		
					For Hybrids, below conditions must also be met Estimated Motor Power Loss Estimated Motor Power Loss greater than limit for time	>= 0 kW >= 0 Sec		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Lost Communication with Hybrid Processor Control Module Estimated Motor Power Loss Fault MIL not Illuminated for DTC's:	= FALSE = FALSE TCM: P0716, P0717, P0722, P0723 ECM: None		
Transmission Control Module (TCM)	P06AE	TCM power-up thermistor circuit voltage high	Power Up Temp	>= 164 °C	Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for P06AE Status is	>= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec Test Failed This Key On or Fault Active	>= 60 Fail Time (Sec)	Two Trips
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: None ECM: None		
Transmission Fluid Temperature Sensor (TFT)	P0711	Trans Fluid Temp Sensor Circuit Range/Performance	If transmission oil temp to substrate temp Δ If transmission oil temp to power up temp Δ	> 19 in °C supporting documents > 18 in °C supporting documents				Two Trips

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Both conditions above required to increment fail counter Note: table reference temp = to the median temp of trans oil temp, substrate temp and power up temp.				>= 3000 Fail Counts (100ms loop) Out of 3750 Sample Counts (100ms loop)	
			Non-continuous (intermittent) fail conditions will delay resetting fail counter until				>= 700 Pass Counts (100ms loop) Out of 875 Sample Counts (100ms loop)	
					Engine Torque Signal Valid Accelerator Position Signal Valid Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for Brake torque active	= TRUE Boolean = TRUE Boolean >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec = FALSE		
					Below describes the brake torque entry criteria Engine Torque Throttle Transmission Input Speed Vehicle Speed Transmission Range Transmission Range PTO Set Brake Torque Active TRUE if above conditions are met for:	>= 90 N*m >= 30.000305 Pct <= 200 RPM <= 8 Kph ≠ Park ≠ Neutral = Not Active >= 7 sec		
					Below describes the brake torque exit criteria Brake torque entry criteria Clutch hydraulic pressure	= Not Met ≠ Clutch Hydraulic Air Purge Event		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Clutch used to exit brake torque active	= CeTFTD_e_C3_RatE_nbl		
					The above clutch pressure is greater than this value for one loop	>= 600 kpa		
					Set Brake Torque Active FALSE if above conditions are met for:	>= 20 Sec		
					P0711 Status is	≠ Test Failed This Key On or Fault Active		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0658, P0668, P0669, P06AD, P06AE, P0716, P0712, P0713, P0717, P0722, P0723, P0962, P0963, P0966, P0967, P0970, P0971, P215C, P2720, P2721, P2729, P2730 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
Transmission Fluid Temperature Sensor (TFT)	P0712	Transmission fluid temperature thermistor failed at a low voltage	Type of Sensor Used =	CeTFTL_e_Vol tageDirectProp				Two Trips
			If Transmission Fluid Temperature Sensor = Direct Proportional and Temp	<=	-74 °C			
			If Transmission Fluid Temperature Sensor = Indirect Proportional and Temp	>=	-74 °C			
			Either condition above will satisfy the fail conditions				>= 60 Fail Time (Sec)	
					Ignition Voltage Lo	>= 8.5996094 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					P0712 Status is	≠ Test Failed This Key On or Fault Active		
					For Hybrids, below conditions must also be met			
					Estimated Motor Power Loss	>= 0 kW		
					Estimated Motor Power Loss greater than limit for time	>= 0 Sec		
					Lost Communication with Hybrid Processor Control Module	= FALSE		
					Estimated Motor Power Loss Fault	= FALSE		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723 ECM: None		
Transmission Fluid Temperature Sensor (TFT)	P0713	Transmission fluid temperature thermistor failed at a high voltage	Type of Sensor Used =	CeTFTL_e_Vol tageDirectProp				Two Trips

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			If Transmission Fluid Temperature Sensor = Direct Proportional and Temp If Transmission Fluid Temperature Sensor = Indirect Proportional and Temp Either condition above will satisfy the fail conditions	>= 174 °C <= 174 °C			>= 60 Fail Time (Sec)	
					Ignition Voltage Lo >= 8.5996094 Volts Ignition Voltage Hi <= 31.999023 Volts Engine Speed Lo >= 400 RPM Engine Speed Hi <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec P0713 Status is ≠ Test Failed This Key On or Fault Active	TCM: P0713, P0716, P0717, P0722, P0723 ECM: None		
Transmission Input Speed Sensor (TISS)	P0716	Input Speed Sensor Performance	Transmission Input Speed Sensor Drops	>= 900 RPM			>= 0.8 Fail Time (Sec)	One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Engine Torque is Engine Torque is Engine Speed Engine Speed Engine Speed is within the allowable limits for Vehicle Speed is Throttle Position is ----- Transmission Input Speed is The previous requirement has been satisfied for ----- The change (loop to loop) in transmission input speed is The previous requirement has been satisfied for Throttle Position Signal Valid Engine Torque Signal Valid Ignition Voltage Ignition Voltage P0716 Status is not = Test Failed This Key On or Fault Active	>= 0 N*m <= 8191.875 N*m >= 400 RPM <= 7500 RPM >= 5 Sec >= 10 Kph >= 0 Pct >= 0 RPM >= 0 Sec < 8191.875 RPM/Loop >= 0 Sec = TRUE Boolean = TRUE Boolean >= 8.5996094 Volts <= 31.999023 Volts = Test Failed This Key On or Fault Active		
					Disable Conditions: MIL not Illuminated for DTC's: TCM: P0717, P0752, P0973, P0974 ECM: P0101, P0102, P0103, P0121, P0122, P0123			
Transmission Input Speed Sensor (TISS)	P0717	Input Speed Sensor Circuit Low Voltage	<u>Fail Case 1</u> Transmission Input Speed is	< 33 RPM			>= 4.5 Fail Time (Sec)	One Trip
			<u>Fail Case 2</u> When P0722 DTC Status equal to Test Failed and Transmission Input Speed is	< 653.125 RPM	Controller uses a single power supply for the speed sensors	= 1 Boolean		
					Engine Torque is Engine Torque is	>= 80 N*m <= 8191.875 N*m		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Vehicle Speed Engine Torque Signal Valid Ignition Voltage Ignition Voltage Engine Speed Engine Speed Engine Speed is within the allowable limits for P0717 Status is not MIL not Illuminated for DTC's:	>= 10 Kph = TRUE Boolean >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec Test Failed This Key On or Fault Active TCM: P0722, P0723 ECM: P0101, P0102, P0103		
Transmission Output Speed Sensor (TOSS)	P0722	Output Speed Sensor Circuit Low Voltage	Transmission Output Speed Sensor Raw Speed	<= 35 RPM			>= 4.5 Fail Time (Sec)	One Trip
					P0722 Status is not Transmission Input Speed Check Engine Torque Check Throttle Position Transmission Fluid Temperature Disable this DTC if the PTO is active Engine Torque Signal Valid Throttle Position Signal Valid Ignition Voltage is Ignition Voltage is Engine Speed is Engine Speed is	= Test Failed This Key On or Fault Active = TRUE Boolean = TRUE Boolean >= 8.0001831 Pct >= -40 °C = 1 Boolean = TRUE Boolean = TRUE Boolean >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Engine Speed is within the allowable limits for	>= 5 Sec		
					Enable_Flags Defined Below The Engine Torque Check is TRUE, if either of the two following conditions are TRUE Engine Torque Condition 1 Range Shift Status OR Transmission Range is Engine Torque is Engine Torque is Engine Torque Condition 2 Engine Torque is Engine Torque is	≠ Range shift completed ENUM = Park or Neutral ≥ 8191.75 N*m ≤ 8191.75 N*m ≥ 50 N*m ≤ 8191.75 N*m		
					The Transmission Input Speed (TIS) Check is TRUE, if either of the two following conditions are TRUE TIS Check Condition 1 Transmission Input Speed is Transmission Input Speed is TIS Check Condition 2 Engine Speed without the brake applied is Engine Speed with the brake applied is Engine Speed is Controller uses a single power supply for the speed sensors	≥ 653.125 RPM ≤ 5350 RPM ≥ 3200 RPM ≥ 3200 RPM ≤ 8191.875 RPM = 1 Boolean		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Powertrain Brake Pedal is Valid	= TRUE Boolean		
					Disable Conditions:	MIL not Illuminated for DTC's: TCM: P0716, P0717, P0723 ECM: P0101, P0102, P0103, P0121, P0122, P0123		
Transmission Output Speed Sensor (TOSS)	P0723	Output Speed Sensor Circuit Intermittent	Transmission Output Speed Sensor Raw Speed Output Speed Delta Output Speed Drop AND Transmission Range is	>= 105 RPM <= 8192 RPM > 650 RPM = Driven range (R,D)			>= 0 Enable Time (Sec) >= 0 Enable Time (Sec) >= 1.5 Output Speed Drop Recovery Fail Time (Sec)	One Trip
					Range_Disable OR Neutral_Range_Enable And Neutral_Speed_Enable are TRUE concurrently	= FALSE See Below = TRUE See Below = TRUE See Below		
					Transmission_Range_Enable Transmission_Input_Speed_En able No Change in Transfer Case Range (High <-> Low) for P0723 Status is not Disable this DTC if the PTO is active	= TRUE See Below = TRUE See Below >= 5 Seconds = Test Failed This Key On or Fault Active = 1 Boolean		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Ignition Voltage is Ignition Voltage is Engine Speed is Engine Speed is Engine Speed is within the allowable limits for	>= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec		
					Enable_Flags Defined Below			
					Transmission_Input_Speed_En able is TRUE when either TIS Condition 1 or TIS Condition 2 is TRUE: TIS Condition 1 is TRUE when both of the following conditions are satisfied for Input Speed Delta Raw Input Speed TIS Condition 2 is TRUE when ALL of the next two conditions are satisfied Input Speed A Single Power Supply is used for all speed sensors	>= 0 Enable Time (Sec) <= 4095.875 RPM >= 500 RPM = 0 RPM = TRUE Boolean		
					Neutral_Range_Enable is TRUE when any of the next 3 conditions are TRUE Transmission Range is Transmission Range is Transmission Range is And when a drop occurs	= Neutral ENUM = Reverse/N eutral ENUM = Neutral/Dri ve Transitiona l ENUM		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Loop to Loop Drop of Transmission Output Speed is -----	> 650 RPM		
					Range_Disable is TRUE when any of the next three conditions are TRUE Transmission Range is Transmission Range is Input Clutch is not -----	= Park ENUM = Park/Reverse Transitional ENUM = ON (Fully Applied) ENUM		
					Neutral_Speed_Enable is TRUE when All of the next three conditions are satisfied for Transmission Output Speed The loop to loop change of the Transmission Output Speed is The loop to loop change of the Transmission Output Speed is -----	> 1.5 Seconds > 130 RPM < 20 RPM > -10 RPM		
					Transmission_Range_Enable is TRUE when one of the next six conditions is TRUE Transmission Range is Transmission Range is Transmission Range is -----	= Neutral Reverse/Neutral Transitional ENUM = Neutral/Drive Transitional ENUM		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	MIL Illum.
					Time since a driven range (R,D) has been selected	>= Table Based Time Please Refer to Table 21 in supporting documents Sec		
					Transmission Output Speed Sensor Raw Speed	>= 500 RPM		
					Output Speed when a fault was detected	>= 500 RPM		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0973, P0974, P0976, P0977 ECM: P0101, P0102, P0103, P0121, P0122, P0123		
Torque Converter Clutch (TCC)	P0741	TCC System Stuck OFF	TCC Pressure Either Condition (A) or (B) Must be Met	>= 750 Kpa			>= 2 Enable Time (Sec)	Two Trips
			(A) TCC Slip Error @ TCC On Mode	>= 1 in Supporting Documents RPM			>= 5 Fail Time (Sec)	
			(B) TCC Slip @ Lock On Mode If Above Conditions Have been Met, and Fail Timer Expired, Increment Fail Counter	>= 130 RPM			>= 5 Fail Time (Sec) >= 2 TCC Stuck Off Fail Counter	
					TCC Mode	= On or Lock		
					Ignition Voltage Lo	>= 8.5996094 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					Engine Speed	>= 400 RPM		
					Engine Speed	<= 7500 RPM		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Engine Speed is within the allowable limits for Engine Torque Lo Engine Torque Hi Throttle Position Lo Throttle Position Hi 2nd Gear Ratio Lo 2nd Gear Ratio High 3rd Gear Ratio Lo 3rd Gear Ratio High 4th Gear Ratio Lo 4th Gear Ratio High 5th Gear Ratio Lo 5th Gear Ratio Hi 6th Gear Ratio Lo 6th Gear Ratio High Transmission Fluid Temperature Lo Transmission Fluid Temperature Hi PTO Not Active Engine Torque Signal Valid Throttle Position Signal Valid Dynamic Mode	>= 5 Sec >= 50 N*m <= 8191.875 N*m >= 8.0001831 Pct <= 99.998474 Pct >= 2.1948242 Ratio <= 2.5251465 Ratio >= 1.4228516 Ratio <= 1.637085 Ratio >= 1.069458 Ratio <= 1.2304688 Ratio >= 0.7905273 Ratio <= 0.9095459 Ratio >= 0.6230469 Ratio <= 0.7169189 Ratio >= -6.65625 °C <= 130 °C = TRUE Boolean = TRUE Boolean = TRUE Boolean = FALSE Boolean		
					P0741 Status is	Test Failed This Key On or Fault Active		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P0742, P2763, P2764 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
Torque Converter Clutch (TCC)	P0742	TCC System Stuck ON	TCC Slip Speed TCC Slip Speed If Above Conditions Have been Met, and Fail Timer Expired, Increment Fail Counter	>= -50 RPM <= 13 RPM			>= 1.5 Fail Time (Sec) >= 6 Fail Counter	One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					TCC Mode	= Off		
					Enable test if Cmnd Gear = 1stFW and value true	= 1 Boolean		
					Enable test if Cmnd Gear = 2nd and value true	= 0 Boolean		
					Engine Speed Hi	<= 6000 RPM		
					Engine Speed Lo	>= 500 RPM		
					Vehicle Speed Hi	<= 511 KPH		
					Vehicle Speed Lo	>= 1 KPH		
					Engine Torque Hi	<= 8191,875 Nm		
					Engine Torque Lo	>= 80 Nm		
					Current Range	≠ Neutral Range		
					Current Range	≠ Reverse Range		
					Transmission Sump Temperature	<= 130 °C		
					Transmission Sump Temperature	>= 18 °C		
					Throttle Position Hyst High AND	>= 5.0003052 Pct		
					Max Vehicle Speed to Meet Throttle Enable	<= 8 KPH		
					Once Hyst High has been met, the enable will remain while Throttle Position	>= 2.0004272 Pct		
					Disable for Throttle Position	>= 75 Pct		
					Disable if PTO active and value true	= 1 Boolean		
					Disable if in D1 and value true	= 1 Boolean		
					Disable if in D2 and value true	= 1 Boolean		
					Disable if in D3 and value true	= 1 Boolean		
					Disable if in D4 and value true	= 1 Boolean		
					Disable if in D5 and value true	= 1 Boolean		
					Disable if in MUMD and value true	= 1 Boolean		
					Disable if in TUTD and value true	= 1 Boolean		
					4 Wheel Drive Low Active	= FALSE Boolean		
					Disable if Air Purge active and value false	= 0 Boolean		
					RVT Diagnostic Active	= FALSE Boolean		
					Ignition Voltage	>= 8.5996094 V		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Ignition Voltage <= 31.999023 V Vehicle Speed <= 511 KPH Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec Engine Torque Signal Valid = TRUE Boolean Throttle Position Signal Valid = TRUE Boolean P0742 Status is ≠ Test Failed This Key On or Fault Active Disable Conditions:	MIL not Illuminated for DTC's: TCM: P0716, P0717, P0722, P0723, P0741, P2763, P2764 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Mode 2 Multiplex Valve	P0751	Shift Solenoid Valve A Stuck Off	Commaned Gear Slip >= 400 RPM Commanded Gear = 1st Lock rpm Gear Ratio <= 1.209594727 Gear Ratio >= 1.094360352 If the above parameters are true				>= 0.2 Fail Tmr = 5 Fail Counts ≠ 0 Neutral Timer (Sec) >= 0.3 Fail Timer (Sec) >= 8 Counts	Two Trips
					Ignition Voltage Lo >= 8.5996094 Volts Ignition Voltage Hi <= 31.999023 Volts Engine Speed Lo >= 400 RPM Engine Speed Hi <= 7500 RPM			

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Engine Speed is within the allowable limits for Transmission Fluid Temperature Range Shift State TPS OR Output Speed Throttle Position Signal Valid from ECM Engine Torque Signal Valid from ECM, High side driver is enabled High-Side Driver is Enabled Input Speed Sensor fault Output Speed Sensor fault Default Gear Option is not present	>= 5 Sec >= -6.65625 °C = Range Shift Completed ENUM >= 0.5004883 % >= 67 RPM = TRUE Boolean = TRUE Boolean = TRUE Boolean = FALSE Boolean = FALSE Boolean = TRUE		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Mode 2 Multiplex Valve	P0752	Shift Solenoid Valve A Stuck On	Gear Box Slip Commanded Gear	>= 400 RPM = 3rd Gear				One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.	
			Commanded Gear has Achieved 1st Locked OR 1st Free-Wheel OR 2nd with Mode 2 Sol. Commanded On If the above parameters are true	= TRUE Boolean			Please Refer to Table 16 in Neutral Timer Supporting Documents (Sec)		
			Command 4th Gear once Output Shaft Speed If Gear Ratio And Gear Ratio	<= 400 RPM >= 3.825683594 <= 4.228393555				>= 1.5 Fail Timer (Sec) >= 5 Counts	
					Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for High-Side Driver is Enabled Throttle Position Signal Valid from ECM Output Speed OR TPS Range Shift State Transmission Fluid Temperature Input Speed Sensor fault Output Speed Sensor fault Default Gear Option is not present	>= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec = TRUE Boolean = TRUE Boolean >= 67 RPM >= 0.5004883 % = Range Shift Completed ENUM >= -6.65625 °C = FALSE Boolean = FALSE Boolean = TRUE			

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Mode 2 Multiplex Valve	P0756	Shift Solenoid Valve B Stuck Off	<u>Fail Case 1</u> Commanded Gear = 1st Locked Gear Box Slip >= 400 RPM Intrusive Shift to 2nd Commanded Gear Previous = 1st Locked Gear Gear Ratio <= 2.482177734 Gear Ratio >= 2.245849609 If the above parameters are true				Please Refer to Table 5 in Neutral Timer Supporting Documents (Sec) >= 1 sec >= 3 counts	One Trip
					Ignition Voltage Lo >= 8.5996094 Volts Ignition Voltage Hi <= 31.999023 Volts Engine Speed Lo >= 400 RPM Engine Speed Hi <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec Output Speed >= 67 RPM OR TPS >= 0.5004883 % Range Shift State = Range Shift ENUM Completed Transmission Fluid Temperature >= -6.65625 °C High-Side Driver is Enabled = TRUE Boolean Throttle Position Signal Valid from ECM = TRUE Boolean			

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	MIL Illum.
					Input Speed Sensor fault = FALSE Boolean Output Speed Sensor fault = FALSE Boolean Default Gear Option is not present = TRUE			
					Disable Conditions:	MIL not Illuminated for DTC's: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P0776	Pressure Control (PC) Solenoid B Stuck Off [C35R]	<u>Fail Case 1</u> Case: Steady State 3rd Gear Commanded Gear = 3rd Gear Gearbox Slip >= 400 RPM Command 4th Gear once Output Shaft Speed <= 400 RPM If Gear Ratio >= 1.094360352 And Gear Ratio <= 1.209594727 If the above conditions are true, Increment 3rd gear fail counter and C35R Fail counter				Please Refer to Table 16 in Neutral Timer Supporting (Sec) Documents >= 3 Fail Timer (Sec) >= 3 3rd Gear Fail Counts or >= 14 3-5R Clutch Fail Counts	One Trip
			<u>Fail Case 2</u> Case: Steady State 5th Gear Commanded Gear = 5th Gear					

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Gearbox Slip	>= 400 Rpm			>= Please Refer to Table 5 in Supporting Documents Neutral Timer (Sec)	
			Intrusive Test: Command 6th Gear					
			If attained Gear=6th gear Time	>= Please refer to Table 3 in supporting documents Shift Time (Sec)				
			If the above conditions are true, Increment 5th gear fail counter and C35R Fail counter				>= 3 5th Gear Fail Counts or >= 14 3-5R Clutch Fail Counts	
					PRNDL State defaulted	= FALSE Boolean		
					inhibit RVT	= FALSE Boolean		
					IMS fault pending indication	= FALSE Boolean		
					TPS validity flag	= TRUE Boolean		
					Hydraulic System Pressurized	= TRUE Boolean		
					Minimum output speed for RVT	>= 67 RPM		
					A OR B			
					(A) Output speed enable	>= 67 RPM		
					(B) Accelerator Pedal enable	>= 0.5004883 Pct		
					Common Enable Criteria			
					Ignition Voltage Lo	>= 8.5996094 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					Throttle Position Signal valid	= TRUE Boolean		
					HSD Enabled	= TRUE Boolean		
					Transmission Fluid Temperature	>= -6.65625 °C		
					Input Speed Sensor fault	= FALSE Boolean		
					Output Speed Sensor fault	= FALSE Boolean		
					Default Gear Option is not present	= TRUE		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P0777	Pressure Control (PC) Solinoid B Stuck On [C35R] (Steady State)	<u>Fail Case 1</u> Case: Steady State 1st Attained Gear slip If the Above is True for Time Intrusive test: (CBR1 clutch exhausted) Gear Ratio Gear Ratio If the above parameters are true	>= 400 RPM Table Based Time Please Refer to Table Enable Time 4 in (Sec) supporting documents <= 1.608642578 >= 1.455444336			>= 1.1 Fail Timer (Sec) >= 2 Fail Count in 1st Gear or >= 3 Total Fail Counts	One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			<p>Fail Case 2</p> <p>Case: Steady State 2nd gear</p> <p>Max Delta Output Speed Hysteresis</p> <p>Min Delta Output Speed Hysteresis</p> <p>If the Above is True for Time</p> <p>Intrusive test: (CB26 clutch exhausted)</p> <p>Gear Ratio</p> <p>Gear Ratio</p> <p>If the above parameters are true</p>	<p>Table Based value Please Refer to Table</p> <p>22 in rpm/sec</p> <p>supporting documents</p> <p>Table Based value Please Refer to Table</p> <p>23 in rpm/sec</p> <p>supporting documents</p> <p>Table Based Time Please Refer to Table</p> <p>17 in Sec</p> <p>supporting documents</p> <p>1.608642578</p> <p>1.455444336</p>			<p>>= 1.1 Fail Timer (Sec)</p> <p>>= 3 Fail Count in 2nd Gear or Total Fail Counts</p> <p>>= 3</p>	

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			<p><u>Fail Case 3</u> Case: Steady State 4th gear</p> <p>Max Delta Output Speed Hysteresis >=</p> <p>Min Delta Output Speed Hysteresis >=</p> <p>If the Above is True for Time >=</p> <p>Intrusive test: (C1234 clutch exhausted) Gear Ratio <= 0.89465332 Gear Ratio >= 0.809448242 If the above parameters are true</p>	<p>Table Based value Please Refer to Table 22 in rpm/sec supporting documents</p> <p>Table Based value Please Refer to Table 23 in rpm/sec supporting documents</p> <p>Table Based Time Please Refer to Table 17 in Sec supporting documents</p>			<p>>= 1.1 Fail Timer (Sec)</p> <p>>= 3 Fail Count in 4th Gear or Total Fail Counts</p> <p>>= 3</p>	

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Fail Case 4 Case: Steady State 6th gear	Table Based value Please Refer to Table 22 in rpm/sec supporting documents				
			Max Delta Output Speed Hysteresis	>=				
			Min Delta Output Speed Hysteresis	>=	Table Based value Please Refer to Table 23 in rpm/sec supporting documents			
			If the Above is True for Time	>=	Table Based Time Please Refer to Table 17 in Sec supporting documents			
			Intrusive test: (CB26 clutch exhausted)					
			Gear Ratio	<=	0.89465332		>= 1.1	Fail Timer (Sec)
			Gear Ratio	>=	0.809448242		>= 3	counts
			If the above parameters are true				>= 1.1	Fail Timer (Sec)
							>= 3	Fail Count in 6th Gear or Total Fail Counts
					PRNDL State defaulted	= FALSE Boolean		
					inhibit RVT	= FALSE Boolean		
					IMS fault pending indication	= FALSE Boolean		
					output speed	>= 0 RPM		
					TPS validity flag	= TRUE Boolean		
					HSD Enabled	= TRUE Boolean		
					Hydraulic_System_Pressurized	= TRUE Boolean		
					A OR B			

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					(A) Output speed enable (B) Accelerator Pedal enable Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for if Attained Gear=1st FW Accelerator Pedal enable if Attained Gear=1st FW Engine Torque Enable if Attained Gear=1st FW Engine Torque Enable Transmission Fluid Temperature Input Speed Sensor fault Output Speed Sensor fault	>= 67 Nm >= 0.5004883 Nm >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec >= 5.0003052 Pct >= 5 Nm <= 8191,875 Nm >= -6.65625 °C = FALSE Boolean = FALSE Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P0777	Pressure Control (PC) Solenoid B StuckOn [C35R] (Dymanic)	Primary Offgoing Clutch is exhausted (See Table 12 in Supporting Documents for Exhaust Delay Timers) Primary Oncoming Clutch Pressure Command Status Primary Offgoing Clutch Pressure Command Status	= TRUE Boolean = Maximum pressurized = Clutch exhaust command				One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Range Shift Status	≠ Initial Clutch Control				
			Attained Gear Slip	<= 40 RPM				
			If the above conditions are true run appropriate Fail 1 Timers Below:					
			fail timer 1 (3-1 shifting with Closed Throttle)	>= 0.5	Fail Time (Sec)			
			fail timer 1 (3-2 shifting with Throttle)	>= 0.349609375	Fail Time (Sec)			
			fail timer 1 (3-2 shifting with Closed Throttle)	>= 0.5	Fail Time (Sec)			
			fail timer 1 (3-4 shifting with Throttle)	>= 0.299804688	Fail Time (Sec)			
			fail timer 1 (3-4shifting with Closed Throttle)	>= 0.5	Fail Time (Sec)			
			fail timer 1 (3-5 shifting with Throttle)	>= 0.299804688	Fail Time (Sec)			
			fail timer 1 (3-5 shifting with Closed Throttle)	>= 0.5	Fail Time (Sec)			
			fail timer 1 (5-3 shifting with Throttle)	>= 0.299804688	Fail Time (Sec)			
			fail timer 1 (5-3 shifting with Closed Throttle)	>= 0.5	Fail Time (Sec)			
			fail timer 1 (5-4 shifting with Throttle)	>= 0.299804688	Fail Time (Sec)			
			fail timer 1 (5-4 shifting with Closed Throttle)	>= 0.5	Fail Time (Sec)			
			fail timer 1 (5-6 shifting with Throttle)	>= 0.299804688	Fail Time (Sec)			
			fail timer 1 (5-6 shifting with Closed Throttle)	>= 0.5	Fail Time (Sec)			

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			<p>If Attained Gear Slip is Less than Above Cal Increment Fail Timers</p> <p>If fail timer is greater than threshold increment corresponding gear fail counter and total fail counter</p> <p>3rd gear fail counter</p> <p>5th gear fail counter</p> <p>Total fail counter</p>				<p>Total Fail Time = (Fail 1 + Fail 2) See Enable Timers for Fail</p> <p>>= Timer 1, and Reference Supporting Table 15 for Fail Timer 2</p> <p>sec</p> <p>>= 3 3rd gear fail counts</p> <p>OR</p> <p>>= 3 5th gear fail counts</p> <p>OR</p> <p>>= 5 total fail counts</p>	
					<p>TUT Enable temperature</p> <p>Input Speed Sensor fault</p> <p>Output Speed Sensor fault</p> <p>Command / Attained Gear</p> <p>High Side Driver ON</p> <p>output speed limit for TUT</p> <p>input speed limit for TUT</p> <p>PRNDL state defaulted</p> <p>IMS Fault Pending</p> <p>Service Fast Learn Mode</p> <p>HSD Enabled</p> <p>Default Gear Option is not present</p>	<p>>= -6.65625 °C</p> <p>= FALSE Boolean</p> <p>= FALSE Boolean</p> <p>≠ 1st Boolean</p> <p>= TRUE Boolean</p> <p>>= 100 RPM</p> <p>>= 150 RPM</p> <p>= FALSE Boolean</p> <p>= FALSE Boolean</p> <p>= FALSE Boolean</p> <p>= TRUE Boolean</p> <p>= TRUE</p>		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			<u>Fail Case 2</u> Case: Steady State 5th Gear Gear slip >= 400 RPM Intrusive test: commanded 6th gear If attained Gear ≠ 6th for time >= Please Refer to Table 3 in Supporting Documents Shift Time (Sec) if the above conditions have been met Increment 5th Gear Fail Counter and C456 Fail Counters				Please See Table 5 For Neutral Time Cal >= Neutral Timer (Sec) >= 3 5th Gear Fail Count OR >= 14 C456 Fail Counts	
			<u>Fail Case 3</u> Case: Steady State 6th Gear Gear slip >= 400 RPM Intrusive test: commanded 5th gear If attained Gear ≠ 5th for time >= Please refer to Table 3 in Supporting Documents Shift Time (Sec) if the above conditions have been met Increment 6th Gear Fail Counter and C456 Fail Counter and C456 Fail Counter				Please See Table 5 For Neutral Time Cal >= Neutral Timer (Sec) >= 3 6th Gear Fail Count OR >= 14 C456 Fail Counts	

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					PRNDL State defaulted inhibit RVT IMS fault pending indication TPS validity flag Hydraulic System Pressurized Minimum output speed for RVT A OR B (A) Output speed enable (B) Accelerator Pedal enable Common Enable Criteria Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for Throttle Position Signal valid HSD Enabled Transmission Fluid Temperature Input Speed Sensor fault OutputSpeed Sensor fault Default Gear Option is not present	= FALSE Boolean = FALSE Boolean = FALSE Boolean = TRUE Boolean = TRUE Boolean >= 67 RPM >= 67 RPM >= 0.5004883 Pct >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec = TRUE Boolean = TRUE Boolean >= -6.65625 °C = FALSE Boolean = FALSE Boolean = TRUE		
					Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E	
Variable Bleed Solenoid (VBS)	P0797	Pressure Control (PC) Solenoid C Stuck On [C456] (Steady State)	Fail Case 1 Case: Steady State 1st Attained Gear slip	>= 400 RPM				One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			<p>If the Above is True for Time</p> <p>Intrusive test: (CBR1 clutch exhausted)</p> <p>Gear Ratio</p> <p>Gear Ratio</p> <p>If the above parameters are true</p>	<p>Table Based Time Please Refer to Table Enable Time 4 in (Sec) supporting documents</p> <p><= 1.209594727</p> <p>>= 1.094360352</p>			<p>>= 1.1 Fail Timer (Sec)</p> <p>>= 2 Fail Count in 1st Gear or Total Fail Counts</p> <p>>= 3</p>	

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Fail Case 2 Case Steady State 2nd	Table Based value Please Refer to Table 22 in rpm/sec supporting documents				
			Max Delta Output Speed Hysteresis	>=				
			Min Delta Output Speed Hysteresis	>=	Table Based value Please Refer to Table 23 in rpm/sec supporting documents			
			If the Above is True for Time	>=	Table Based Time Please Refer to Table 17 in Sec supporting documents			
			Intrusive test: (CB26 clutch exhausted)					
			Gear Ratio	<=	1.209594727			
			Gear Ratio	>=	1.094360352			
			If the above parameters are true				>= 1.1	Fail Timer (Sec)
							>= 3	Fail Count in 2nd Gear or
							>= 3	Total fail counts

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	MIL Illum.
					(B) Accelerator Pedal enable Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for if Attained Gear=1st FW Accelerator Pedal enable if Attained Gear=1st FW Engine Torque Enable if Attained Gear=1st FW Engine Torque Enable Transmission Fluid Temperature Input Speed Sensor fault Output Speed Sensor fault Default Gear Option is not present	>= 0.5004883 Nm >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec >= 5.0003052 Pct >= 5 Nm <= 8191.875 Nm >= -6.65625 °C = FALSE Boolean = FALSE Boolean = TRUE		
					Disable Conditions:	MIL not Illuminated for DTC's: TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P0797	Pressure Control (PC) Solenoid C Stuck On [C456] (Dynamic)	Primary Offgoing Clutch is exhausted (See Table 11 in Supporting Documents for Exhaust Delay Timers) Primary Oncoming Clutch Pressure Command Status Primary Offgoing Clutch Pressure Command Status	= TRUE Boolean = Maximum pressurized = Clutch exhaust command				One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Range Shift Status \neq Initial Clutch Control Attained Gear Slip \leq 40 RPM If the above conditions are true increment appropriate Fail 1 Timers Below: fail timer 1 \geq 0.299804688 Fail Time (Sec) (4-1 shifting with throttle) fail timer 1 \geq 0.5 Fail Time (Sec) (4-1 shifting without throttle) fail timer 1 \geq 0.299804688 Fail Time (Sec) (4-2 shifting with throttle) fail timer 1 \geq 0.5 Fail Time (Sec) (4-2 shifting without throttle) fail timer 1 \geq 0.299804688 Fail Time (Sec) (4-3 shifting with throttle) fail timer 1 \geq 0.5 Fail Time (Sec) (4-3 shifting without throttle) fail timer 1 \geq 0.299804688 Fail Time (Sec) (5-3 shifting with throttle) fail timer 1 \geq 0.5 Fail Time (Sec) (5-3 shifting without throttle) fail timer 1 \geq 0.299804688 Fail Time (Sec) (6-2 shifting with throttle) fail timer 1 \geq 0.5 Fail Time (Sec) (6-2 shifting without throttle)				Total Fail Time = (Fail 1 + Fail 2) See Enable Timers for Fail \geq Timer 1, and Reference Supporting Table 15 for Fail Timer 2 sec	
			If Attained Gear Slip is Less than Above Cal Increment Fail Timers					

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			<p>If fail timer is greater than threshold increment corresponding gear fail counter and total fail counter</p> <p>4th gear fail counter</p> <p>5th gear fail counter</p> <p>6th gear fail counter</p> <p>Total fail counter</p>				<p>>= 3 Fail Counter From 4th Gear OR</p> <p>>= 3 Fail Counter From 5th Gear OR</p> <p>>= 3 Fail Counter From 6th Gear OR</p> <p>>= 5 Total Fail Counter</p>	
					<p>TUT Enable temperature = -6.65625 °C</p> <p>Input Speed Sensor fault = FALSE Boolean</p> <p>Output Speed Sensor fault = FALSE Boolean</p> <p>Command / Attained Gear ≠ 1st Boolean</p> <p>High Side Driver ON = TRUE Boolean</p> <p>output speed limit for TUT >= 100 RPM</p> <p>input speed limit for TUT >= 150 RPM</p> <p>PRNDL state defaulted = FALSE Boolean</p> <p>IMS Fault Pending = FALSE Boolean</p> <p>Service Fast Learn Mode = FALSE Boolean</p> <p>HSD Enabled = TRUE Boolean</p>	<p>Disable Conditions:</p> <p>MIL not Illuminated for DTC's: P0716, P0717, P0722, P0723, P182E</p> <p>ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E</p>		
Tap Up Tap Down Switch (TUTD)	P0815	Upshift Switch Circuit	<p><u>Fail Case 1</u> Tap Up Switch Stuck in the Up Position in Range 1 Enabled</p>	= 0 Boolean				Special No MIL

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Tap Up Switch Stuck in the Up Position in Range 2 Enabled	= 0 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 3 Enabled	= 0 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 4 Enabled	= 0 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 5 Enabled	= 0 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 6 Enabled	= 0 Boolean				
			Tap Up Switch Stuck in the Up Position in Neutral Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Park Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Reverse Enabled	= 0 Boolean				
			Tap Up Switch ON	= TRUE Boolean			>= 1 Fail Time (Sec)	
			<u>Fail Case 2</u>					
			Tap Up Switch Stuck in the Up Position in Range 1 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 2 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 3 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 4 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 5 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 6 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Neutral Enabled	= 0 Boolean				
			Tap Up Switch Stuck in the Up Position in Park Enabled	= 0 Boolean				
			Tap Up Switch Stuck in the Up Position in Reverse Enabled	= 0 Boolean				
			Tap Up Switch ON	= TRUE Boolean				
			NOTE: Both Failcase1 and Failcase 2 Must Be Met				>= 600 Fail Time (Sec)	

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	MIL Illum.
					Time Since Last Range Change Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for P0815 Status is	>= 1 Enable Time (Sec) >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec Test Failed This Key On or Fault Active		
					Disable Conditions:	MIL not Illuminated for DTC's: TCM: P0816, P0826, P182E, P1876, P1877, P1915, P1761 ECM: None		
Tap Up Tap Down Switch (TUTD)	P0816	Downshift Switch Circuit	<u>Fail Case 1</u> Tap Down Switch Stuck in the Down Position in Range 1 Enabled Tap Down Switch Stuck in the Down Position in Range 2 Enabled Tap Down Switch Stuck in the Down Position in Range 3 Enabled Tap Down Switch Stuck in the Down Position in Range 4 Enabled	= 0 Boolean = 0 Boolean = 0 Boolean = 0 Boolean				Special No MIL

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Tap Down Switch Stuck in the Down Position in Range 5 Enabled	= 0 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 6 Enabled	= 0 Boolean				
			Tap Down Switch Stuck in the Down Position in Range Neutral Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range Park Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range Reverse Enabled	= 0 Boolean				
			Tap Down Switch ON	= TRUE Boolean			>= 1 sec	
			<u>Fail Case 2</u>					
			Tap Down Switch Stuck in the Down Position in Range 1 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 2 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 3 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 4 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 5 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 6 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Neutral Enabled	= 0 Boolean				
			Tap Down Switch Stuck in the Down Position in Park Enabled	= 0 Boolean				

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Tap Down Switch Stuck in the Down Position in Reverse Enabled Tap Down Switch ON NOTE: Both Failcase1 and Failcase 2 Must Be Met	= 0 Boolean = TRUE Boolean			>= 600 sec	
					Time Since Last Range Change Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for P0816 Status is	>= 1 Enable Time (Sec) >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec Test Failed This Key On or Fault Active		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: P0815, P0826, P182E, P1876, P1877, P1915, P1761 ECM: None		
Tap Up Tap Down Switch (TUTD)	P0826	Up and Down Shift Switch Circuit	TUTD Circuit Reads Invalid Voltage	= TRUE Boolean			>= 60 Fail Time (Sec)	Special No MIL
					Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo	>= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Engine Speed Hi Engine Speed is within the allowable limits for P0826 Status is	<= 7500 RPM >= 5 Sec ≠ Test Failed This Key On or Fault Active		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P1761 ECM: None		
Variable Bleed Solenoid (VBS)	P0961	Pressure Control (PC) Solenoid A Control Circuit Rationality Test (Line Pressure VBS)	The HWIO reports an invalid voltage (out of range) error flag	= TRUE Boolean			>= 4.4 Fail Time (Sec) out of 5 Sample Time (Sec)	Two Trips
					Ignition Voltage >= 8.5996094 Volts Ignition Voltage <= 31.999023 Volts Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec	TCM: None ECM: None		
Variable Bleed Solenoid (VBS)	P0962	Pressure Control (PC) Solenoid A Control Circuit Low Voltage (Line Pressure VBS)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			>= 1.5 Fail Time (Sec) out of 1.875 Sample Time (Sec)	One Trip
					Ignition Voltage >= 8.5996094 Volts Ignition Voltage <= 31.999023 Volts Engine Speed >= 400 RPM Engine Speed <= 7500 RPM			

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	MIL Illum.
					Engine Speed is within the allowable limits for	>= 5 Sec		
					Disable Conditions:	MIL not Illuminated for DTC's: TCM: None ECM: None		
Variable Bleed Solenoid (VBS)	P0963	Pressure Control (PC) Solenoid A Control Circuit High Voltage (Line Pressure VBS)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			>= 4.4 Fail Time (Sec)	Two Trips
							out of 5 Sample Time (Sec)	
Variable Bleed Solenoid (VBS)	P0966	Pressure Control (PC) Solenoid B Control Circuit Low Voltage (C35R VBS)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean	Ignition Voltage	>= 8.5996094 Volts		One Trip
					Ignition Voltage	<= 31.999023 Volts		
					Engine Speed	>= 400 RPM		
					Engine Speed	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					Disable Conditions:	MIL not Illuminated for DTC's: TCM: None ECM: None		
Variable Bleed Solenoid (VBS)	P0966	Pressure Control (PC) Solenoid B Control Circuit Low Voltage (C35R VBS)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec)	One Trip
							out of 0.375 Sample Time (Sec)	
					Ignition Voltage	>= 8.5996094 Volts		
					Ignition Voltage	<= 31.999023 Volts		
					Engine Speed	>= 400 RPM		
					Engine Speed	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
						Test Failed This Key On or Fault Active = TCM: None ECM: None		
Variable Bleed Solenoid (VBS)	P0967	Pressure Control (PC) Solenoid B Control Circuit High Voltage (C35R VBS)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.375 Sample Time (Sec)	One Trip
					Ignition Voltage >= 8.5996094 Volts Ignition Voltage <= 31.999023 Volts Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec Test Failed This Key On or Fault Active = TCM: None ECM: None			
Variable Bleed Solenoid (VBS)	P0970	Pressure Control (PC) Solenoid C Control Circuit Low Voltage (C456/CBR1 VBS)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.375 Sample Time (Sec)	One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					P0970 Status is not Ignition Voltage Ignition Voltage Engine Speed Engine Speed Engine Speed is within the allowable limits for	= Test Failed This Key On or Fault Active >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec		
					Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None	
Variable Bleed Solenoid (VBS)	P0971	Pressure Control (PC) Solenoid C Control Circuit High Voltage (C456/CBR1 VBS)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.375 Sample Time (Sec)	One Trip
					P0971 Status is not Ignition Voltage Ignition Voltage Engine Speed Engine Speed Engine Speed is within the allowable limits for	= Test Failed This Key On or Fault Active >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec		
					Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None	
Shift Solenoid	P0973	Shift Solenoid A Control Circuit Low (Mode 2 Solenoid)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			>= 1.2 Fail Time (Sec)	One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	MIL Illum.
							out of 1.5 Sample Time (Sec)	
					P0973 Status is not	= Test Failed This Key On or Fault Active		
					Ignition Voltage	>= 8.5996094 Volts		
					Ignition Voltage	<= 31.999023 Volts		
					Engine Speed	>= 400 RPM		
					Engine Speed	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Shift Solenoid	P0974	Shift Solenoid A Control Circuit High (Mode 2 Solenoid)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			>= 1.2 Fail Time (Sec) out of 1.5 Sample Time (Sec)	Two Trips
					P0974 Status is not	= Test Failed This Key On or Fault Active		
					Ignition Voltage	>= 8.5996094 Volts		
					Ignition Voltage	<= 31.999023 Volts		
					Engine Speed	>= 400 RPM		
					Engine Speed	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					MIL not Illuminated for DTC's:	TCM: None ECM: None		
Mode 3 Multiplex Valve	P0977	Shift Solenoid B Control Circuit High (Mode 3 Solenoid)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			>= 1.2 Sec	One Trip
							out of 1.5 Sec	
						Test Failed This Key On or Fault Active		
					P0977 Status is not	=		
					Ignition Voltage	>= 8.5996094 Volts		
					Ignition Voltage	<= 31.999023 Volts		
					Engine Speed	>= 400 RPM		
					Engine Speed	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					MIL not Illuminated for DTC's:	TCM: None ECM: None		
Tap Up Tap Down Switch (TUTD)	P1761	Tap Up and Down switch signal circuit (rolling count)	Rolling count value received from BCM does not match expected value	= TRUE Boolean			>= 3 Fail Counter	Special No MIL
							> 10 Sample Timer (Sec)	
					Tap Up Tap Down Message Health	= TRUE Boolean		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Internal Mode Switch (IMS)	P182E	Internal Mode Switch - Invalid Range	<u>Fail Case 1</u>	Current range = Transition 1 Range (bit state 1110)				One Trip
			Previous range ≠ CeTRGR_e_P Range RNDL_Drive6					
			Previous range ≠ CeTRGR_e_P Range RNDL_Drive4					
			Range Shift State = Range Shift Completed ENUM					
			Absolute Attained Gear Slip ≤ 50 rpm					
			Attained Gear ≤ Sixth					
			Attained Gear ≥ First					
			Throttle Position Available = TRUE					
			Throttle Position ≥ 8.000183105 pct					
			Output Speed ≥ 200 rpm					
			Engine Torque ≥ 50 Nm					
			Engine Torque ≤ 8191.75 Nm					
			If the above conditions are met then Increment Fail Timer				≥ 1	Fail Seconds
			If Fail Timer has Expired then Increment Fail Counter				≥ 5	Fail Counts
			<u>Fail Case 2</u>	Output Speed ≤ 70 rpm				
			The following PRNDL sequence events occur in this exact order:					
			PRNDL state = Drive 6 (bit state 0110) Range					
			PRNDL state = Drive 6 for ≥ 1 Sec					

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			PRNDL state = Transition 8 (bit state 0111) Range					
			PRNDL state = Drive 6 (bit state 0110) Range					
			PRNDL state = Transition 1 (bit state 1110) Range					
			Above sequencing occurs in Neutral Idle Mode = Inactive	<= 1 Sec				
			If all conditions above are met Increment delay Timer					
			If the below two conditions are met Increment Fail Timer				>= 3 Fail Seconds	
			delay timer	>= 1 Sec				
			Input Speed	>= 400 Sec				
			If Fail Timer has Expired then Increment Fail Counter				>= 2 Fail Counts	
		<u>Fail Case 3</u>	Current range = Transition 13 (bit state 0010) Range		Previous range	≠ CeTRGR_e_PRNDL_Drive1		
			Engine Torque	>= -8192 Nm	Previous range	≠ CeTRGR_e_PRNDL_Drive2		
			Engine Torque	<= 8191.75 Nm	IMS is 7 position configuration if the IMS / POSITION config = 1 then the "previous range" criteria above must also be satisfied when the "current range" = "Transition 13"	= 1 Boolean	>= 0.225 Seconds	
			If the above conditions are met then, Increment Fail Timer					
			If Fail Timer has Expired then Increment Fail Counter				>= 15 Fail Counts	
		<u>Fail Case 4</u>	Current range = Transition 8 (bit state 0111) Range		Disable Fail Case 4 if last positive range was Drive 6 and current range is transition 8			
			Inhibit bit (see definition)	= FALSE	Set inhibit bit true if PRNDL = 1100 (rev) or 0100 (Rev-Neutral transition 11) Set inhibit bit false if PRNDL = 1001 (park)			
			Steady State Engine Torque	>= 100 Nm				

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Steady State Engine Torque If the above conditions are met then Increment Fail Timer	<= 8191.75 Nm			>= 0.225 Seconds	
			If the above Conditions have been met, Increment Fail Counter				>= 15 Fail Counts	
			<u>Fail Case 5</u> Throttle Position Available The following PRNDL sequence events occur in this exact order:	= TRUE Boolean				
			PRNDL State	= Reverse (bit state 1100) Range				
			PRNDL State	= Transition 11 (bit state 0100) Range				
			PRNDL State	= Neutral (bit state 0101) Range				
			PRNDL State	= Transition 11 (bit state 0100) Range				
			Above sequencing occurs in Then delay timer increments	<= 1 Sec				
			Delay timer	>= 5 sec				
			Range Shift State	= Range Shift Complete				
			Absolute Attained Gear Slip	<= 50 rpm				
			Attained Gear	<= Sixth				
			Attained Gear	>= First				
			Throttle Position	>= 8.000183105 pct				
			Output Speed	>= 200 rpm				
			If the above conditions are met Increment Fail Timer				>= 20 Seconds	
			<u>Fail Case 6</u> Current range	= Illegal (bit state 0000 or 1000 or 0001)	A Open Circuit Definition (flag set false if the following conditions are met):			
			and		Current Range	≠ Transition 11 (bit state 0100)		
			A Open Circuit (See Definition)	= FALSE Boolean	or			

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					Last positive state or Previous transition state Fail case 5 delay timer	≠ Neutral (bit state 0101) ≠ Transition 8 (bit state 0111) = 0 sec	>= 6.25 Seconds	
			If the above Conditions are met then, Increment Fail timer					
			<u>Fail Case 7</u> Current PRNDL State = PRNDL circuit ABCP = 1101 Range and Previous PRNDL state = PRNDL circuit ABCP =1111 Range Input Speed >= 150 RPM Reverse Trans Ratio <= 2.845825195 ratio Reverse Trans Ratio >= 3.274169922 ratio If the above Conditions are met then, Increment Fail timer				>= 6.25 Seconds	
			P182E will report test fail when any of the above 7 fail cases are met					
					Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for Engine Torque Signal Valid	>= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec = TRUE Boolean		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.	
					Disable Conditions: MIL not illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P07C0, P07BF, P077C, P077D ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E			
Internal Mode Switch (IMS)	P1915	Internal Mode Switch Does Not Indicate Park/Neutral (P/N) During Start	PRNDL State is ≠	Park or Neutral	Enumeration			One Trip	
			The following events must occur Sequentially						
			Initial Engine speed	≤	50	RPM			≥ 0.25 Enable Time (Sec)
			Then Engine Speed Between Following Cals						
			Engine Speed Lo Hist	≥	50	RPM			≥ 0.06875 Enable Time (Sec)
Engine Speed Hi Hist	≤	480	RPM						
Then Final Engine Speed			≥	525	RPM	≥ 1.25 Fail Time (Sec)			
Final Transmission Input Speed	≥	100	RPM						
					DTC has Ran this Key Cycle?	= FALSE Boolean			
					Ignition Voltage Lo	≥ 6 V			
					Ignition Voltage Hi	≤ 31.999023 V			
					Ignition Voltage Hyst High (enables above this value)	≥ 5 V			
					Ignition Voltage Hyst Low (disabled below this value)	≤ 2 V			
					Transmission Output Speed	≤ 90 rpm			

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					P1915 Status is	≠ Test Failed This Key On or Fault Active		
					Disable Conditions:	MIL not Illuminated for DTC's: TCM: P0722, P0723 ECM: None		
Transmission Control Module (TCM)	P2534	Ignition Switch Run/Start Position Circuit Low	TCM Run crank active (based on voltage thresholds below) Ignition Voltage High Hyst (run crank goes true when above this value) Ignition Voltage Low Hyst (run crank goes false when below this value)	= FALSE Boolean				
				5 Volts			>= 280 Fail Counts (25ms loop)	
				2 Volts			Out of 280 Sample Counts (25ms loop)	
					ECM run/crank active status available = TRUE Boolean ECM run/crank active status = TRUE Boolean			
					Disable Conditions:	MIL not Illuminated for DTC's: TCM: None ECM: None		
Transmission Control Module (TCM)	P2535	Ignition Switch Run/Start Position Circuit High	TCM Run crank active (based on voltage thresholds below) Ignition Voltage High Hyst (run crank goes true when above this value) Ignition Voltage Low Hyst (run crank goes false when below this value)	= TRUE Boolean				
				5 Volts			>= 280 Fail Counts (25ms loop)	
				2 Volts			Out of 280 Sample Counts (25ms loop)	
					ECM run/crank active status available = TRUE Boolean ECM run/crank active status = FALSE Boolean			

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.	
Variable Bleed Solenoid (VBS)	P2714	Pressure Control (PC) Solenoid D Stuck Off [CB26]	<u>Fail Case 1</u>	Case: Steady State 2nd Gear				One Trip	
				Gear slip >= 400 RPM					>= Please See Table 5 For Neutral Time Cal Neutral Timer (Sec)
				Intrusive test: commanded 3rd gear					
				If attained Gear = 3rd for Time >= Enable Time (Sec) see Table 2 in Supporting Documents					
		If Above Conditions have been met							
		Increment 2nd gear fail count					>= 3 2nd Gear Fail Count or		
		and CB26 Fail Count					>= 14 CB26 Fail Count		
			<u>Fail Case 2</u>	Case: Steady State 6th Gear					
				Gear slip >= 400 RPM				>= Please See Table 5 For Neutral Time Cal Neutral Timer (Sec)	
				Intrusive test: commanded 5th gear					
				If attained Gear = 5th For Time >= Enable Time (Sec) see Table 2 in Supporting Documents					
				If Above Conditions have been met, Increment 5th gear fail counter				>= 3 5th Gear Fail Count or	
				and CB26 Fail Count				>= 14 CB26 Fail Count	
					PRNDL State defaulted	= FALSE Boolean			
					inhibit RVT	= FALSE Boolean			
					IMS fault pending indication	= FALSE Boolean			

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.	
					TPS validity flag = TRUE Boolean Hydraulic System Pressurized = TRUE Boolean Minimum output speed for RVT >= 0 RPM A OR B (A) Output speed enable >= 67 RPM (B) Accelerator Pedal enable >= 0.5004883 Pct Common Enable Criteria Ignition Voltage Lo >= 8.5996094 Volts Ignition Voltage Hi <= 31.999023 Volts Engine Speed Lo >= 400 RPM Engine Speed Hi <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec Throttle Position Signal valid = TRUE Boolean HSD Enabled = TRUE Boolean Transmission Fluid Temperature >= -6.65625 °C Input Speed Sensor fault = FALSE Boolean Output Speed Sensor fault = FALSE Boolean Default Gear Option is not present = TRUE				
					Disable Conditions: MIL not Illuminated for DTC's: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E				
Variable Bleed Solenoid (VBS)	P2715	Pressure Control (PC) Solenoid D Stuck On [CB26] (Dynamic)	Primary Offgoing Clutch is exhausted (See Table 13 in Supporting Documents for Exhaust Delay Timers) Primary Oncoming Clutch Pressure Command Status	= TRUE Boolean = Maximum pressurized				One Trip	

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.	
			Primary Offgoing Clutch Pressure Command Status =	Clutch exhaust command					
			Range Shift Status ≠	Initial Clutch Control					
			Attained Gear Slip ≤	40 RPM					
			If above coditons are true, increment appropriate Fail 1 Timers						
			Below:						
			fail timer 1 (2-1 shifting with throttle) ≥	0.299804688	Fail Time (Sec)				
			fail timer 1 (2-1 shifting without throttle) ≥	0.5	Fail Time (Sec)				
			fail timer 1 (2-3 shifting with throttle) ≥	0.299804688	Fail Time (Sec)				
			fail timer 1 (2-3 shifting without throttle) ≥	0.5	Fail Time (Sec)				
			fail timer 1 (2-4 shifting with throttle) ≥	0.299804688	Fail Time (Sec)				
			fail timer 1 (2-4 shifting without throttle) ≥	0.5	Fail Time (Sec)				
			fail timer 1 (6-4 shifting with throttle) ≥	0.299804688	Fail Time (Sec)				
			fail timer 1 (6-4 shifting without throttle) ≥	0.5	Fail Time (Sec)				
			fail timer 1 (6-5 shifting with throttle) ≥	0.299804688	Fail Time (Sec)				
			fail timer 1 (6-5 shifting without throttle) ≥	0.5	Fail Time (Sec)				

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			<p>If Attained Gear Slip is Less than Above Cal Increment Fail Timers</p> <p>If fail timer is greater than threshold increment corresponding gear fail counter and total fail counter</p> <p>2nd gear fail counter</p> <p>6th gear fail counter</p> <p>total fail counter</p>				<p>Total Fail Time = (Fail 1 + Fail 2) See Enable Timers for Fail</p> <p>>= Timer 1, and Reference Supporting Table 15 for Fail Timer 2</p> <p>sec</p> <p>>= 3 Fail Counter From 2nd Gear OR</p> <p>>= 3 Fail Counter From 6th Gear OR</p> <p>>= 5 Total Fail Counter</p>	
					<p>TUT Enable temperature</p> <p>Input Speed Sensor fault</p> <p>Output Speed Sensor fault</p> <p>Command / Attained Gear</p> <p>High Side Driver ON</p> <p>output speed limit for TUT</p> <p>input speed limit for TUT</p> <p>PRNDL state defaulted</p> <p>IMS Fault Pending</p> <p>Service Fast Learn Mode</p> <p>HSD Enabled</p>	<p>>= -6.65625 °C</p> <p>= FALSE Boolean</p> <p>= FALSE Boolean</p> <p>≠ 1st Boolean</p> <p>= TRUE Boolean</p> <p>>= 100 RPM</p> <p>>= 150 RPM</p> <p>= FALSE Boolean</p> <p>= FALSE Boolean</p> <p>= FALSE Boolean</p> <p>= TRUE Boolean</p>		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P2715	Pressure Control (PC) Solenoid D Stuck On [CB26] (Steady State)	<u>Fail Case 1</u>	Case: Steady State 1st Attained Gear slip >= 400 RPM Table Based Time Please If the Above is True for Time >= Refer to Table Enable Time 4 in (Sec) supporting documents Intrusive test: (CBR1 clutch exhausted) Gear Ratio <= 2.482177734 Gear Ratio >= 2.245849609 If the above parameters are true			>= 1.1 Fail Timer (Sec) >= 5 Fail Count in 1st Gear or >= 5 Total Fail Counts	One Trip
			<u>Fail Case 2</u>	Case: Steady State 3rd Gear Max Delta Output Speed Hysteresis >= Refer to Table 22 in rpm/sec supporting documents				

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Min Delta Output Speed Hysteresis	>= 23 in rpm/sec Table Based value Please Refer to Table supporting documents				
			If the Above is True for Time	>= 17 in Sec Table Based Time Please Refer to Table supporting documents				
			Intrusive test: (C35R clutch exhausted) Gear Ratio	<= 2.482177734				
			Gear Ratio	>= 2.245849609				
			If the above parameters are true				>= 1,1 Fail Timer (Sec)	
							>= 3 Fail Count in 3rd Gear or Total Fail Counts	
			<u>Fail Case 3</u> Case: Steady State 4rd Gear					
			Max Delta Output Speed Hysteresis	>= 22 in rpm/sec Table Based value Please Refer to Table supporting documents				
			Min Delta Output Speed Hysteresis	>= 23 in rpm/sec Table Based value Please Refer to Table supporting documents				

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			<p>If the Above is True for Time</p> <p>Intrusive test: (C1234 clutch exhausted) Gear Ratio <= 0.700317383 Gear Ratio >= 0.633666992 If the above parameters are true</p>	<p>Table Based Time Please Refer to Table 17 in supporting documents</p> <p>Sec</p>			<p>>= 1.1 Fail Timer (Sec)</p> <p>>= 3 Fail Count in 4th Gear or Total Fail Counts</p> <p>>= 5</p>	
			<p><u>Fail Case 4</u> Case: Steady State 5th Gear</p> <p>Max Delta Output Speed Hysteresis</p> <p>Min Delta Output Speed Hysteresis</p> <p>If the Above is True for Time</p> <p>Intrusive test: (C35R clutch exhausted) Gear Ratio <= 0.700317383 Gear Ratio >= 0.633666992</p>	<p>Table Based value Please Refer to Table 22 in supporting documents</p> <p>rpm/sec</p> <p>Table Based value Please Refer to Table 23 in supporting documents</p> <p>rpm/sec</p> <p>Table Based Time Please Refer to Table 17 in supporting documents</p> <p>Sec</p>				

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			If the above parameters are true				>= 1.1 Fail Timer (Sec) >= 3 Fail Count in 5th Gear or >= 5 Total Fail Counts	
					PRNDL State defaulted inhibit RVT IMS fault pending indication output speed TPS validity flag HSD Enabled Hydraulic_System_Pressurized A OR B (A) Output speed enable (B) Accelerator Pedal enable Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for if Attained Gear=1st FW Accelerator Pedal enable if Attained Gear=1st FW Engine Torque Enable if Attained Gear=1st FW Engine Torque Enable Transmission Fluid Temperature Input Speed Sensor fault Output Speed Sensor fault Default Gear Option is not present	= FALSE Boolean = FALSE Boolean = FALSE Boolean >= 0 RPM = TRUE Boolean = TRUE Boolean = TRUE Boolean >= 67 Nm >= 0.5004883 Nm >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec >= 5.0003052 Pct >= 5 Nm <= 8191.875 Nm >= -6.65625 °C = FALSE Boolean = FALSE Boolean = TRUE		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P2720	Pressure Control (PC) Solenoid D Control Circuit Low (CB26 VBS)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec)	One Trip
							out of 0.375 Sample Time (Sec)	
						Test Failed This Key On or Fault Active Ignition Voltage >= 8.5996094 Volts Ignition Voltage <= 31.999023 Volts Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Bleed Solenoid (VBS)	P2721	Pressure Control (PC) Solenoid D Control Circuit High (CB26 VBS)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.375 Sample Time (Sec)	One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					P2721 Status is not Ignition Voltage Ignition Voltage Engine Speed Engine Speed Engine Speed is within the allowable limits for	= Test Failed This Key On or Fault Active >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec		
					Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None	
Variable Bleed Solenoid (VBS)	P2723	Pressure Control (PC) Solenoid E Stuck Off	<u>Fail Case 1</u> Case: Steady State 1st Gear Gear slip >= 400 RPM Intrusive test: commanded 2nd gear If attained Gear ≠ 2nd for Time >= Please refer to Table 3 in Supporting Documents Shift Time (Sec) If Above Conditions have been met, Increment 1st gear fail counter and C1234 fail counter				Please See Table 5 For Neutral Time Cal >= Neutral Timer (Sec) >= 3 1st Gear Fail Count or >= 14 C1234 Clutch Fail Count	One Trip
			<u>Fail Case 2</u> Case: Steady State 2nd Gear Gear slip >= 400 RPM				Please See Table 5 For Neutral Time Cal >= Neutral Timer (Sec)	

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			Intrusive test: commanded 3rd gear If attained Gear ≠ 3rd for Time If Above Conditions have been met, Increment 2nd gear fail counter and C1234 fail counter	Please refer to Table 3 in Supporting Documents Shift Time (Sec)			>= 3 2nd Gear Fail Count or >= 14 C1234 Clutch Fail Count	
			<u>Fail Case 3</u> Case: Steady State 3rd Gear Gear slip Intrusive test: commanded 4th gear If attained Gear ≠ 4th for time If Above Conditions have been met, Increment 3rd gear fail counter and C1234 fail counter	>= 400 RPM Please refer to Table 3 in Supporting Documents Shift Time (Sec)			>= Please See Table 5 For Neutral Time Cal Neutral Timer (Sec) >= 3 3rd Gear Fail Count or >= 14 C1234 Clutch Fail Count	
			<u>Fail Case 4</u> Case: Steady State 4th Gear Gear slip Intrusive test: commanded 5th gear If attained Gear = 5th For Time	>= 400 RPM Please refer to Table 3 in Supporting Documents Shift Time (Sec)			>= Please See Table 5 For Neutral Time Cal Neutral Timer (Sec)	

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	MIL Illum.
			If Above Conditions have been met, Increment 4th gear fail counter				>= 3	4th Gear Fail Count
			and C1234 fail counter				>= 14	or C1234 Clutch Fail Count
					PRNDL State defaulted	= FALSE Boolean		
					inhibit RVT	= FALSE Boolean		
					IMS fault pending indication	= FALSE Boolean		
					TPS validity flag	= TRUE Boolean		
					Hydraulic System Pressurized	= TRUE Boolean		
					Minimum output speed for RVT	>= 0 RPM		
					A OR B			
					(A) Output speed enable	>= 67 RPM		
					(B) Accelerator Pedal enable	>= 0.5004883 Pct		
					Common Enable Criteria			
					Ignition Voltage Lo	>= 8.5996094 Volts		
					Ignition Voltage Hi	<= 31.999023 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					Throttle Position Signal valid	= TRUE Boolean		
					HSD Enabled	= TRUE Boolean		
					Transmission Fluid Temperature	>= -6.65625 °C		
					Input Speed Sensor fault	= FALSE Boolean		
					Output Speed Sensor fault	= FALSE Boolean		
					Default Gear Option is not present	= TRUE		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	MIL Illum.
					Disable Conditions:	MIL not illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E	
Variable Bleed Solenoid (VBS)	P2724	Pressure Control (PC) Solenoid E Stuck On (Dynamic)	<p>Primary Offgoing Clutch is exhausted (See Table 10 in Supporting Documents for Exhaust Delay Timers)</p> <p>Primary Oncoming Clutch Pressure Command Status =</p> <p>Primary Offgoing Clutch Pressure Command Status =</p> <p>Range Shift Status ≠</p> <p>Attained Gear Slip ≤</p> <p>If the above conditions are true increment appropriate Fail 1 Timers</p> <p>Below:</p> <p>fail timer 1 (2-6 shifting with throttle) ≥</p> <p>fail timer 1 (2-6 shifting without throttle) ≥</p> <p>fail timer 1 (3-5 shifting with throttle) ≥</p> <p>fail timer 1 (3-5 shifting without throttle) ≥</p> <p>fail timer 1 (4-5 shifting with throttle) ≥</p> <p>fail timer 1 (4-5 shifting without throttle) ≥</p> <p>fail timer 1 (4-6 shifting with throttle) ≥</p>	<p>TRUE Boolean</p> <p>Maximum pressurized</p> <p>Clutch exhaust command</p> <p>Initial Clutch Control</p> <p>40 RPM</p> <p>0.299804688 sec</p> <p>0.5 sec</p> <p>0.299804688 sec</p> <p>0.5 sec</p> <p>0.299804688 sec</p> <p>0.5 sec</p> <p>0.299804688 sec</p>				One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
			fail timer 1 (4-6 shifting without throttle)	>= 0.5 sec			Total Fail Time = (Fail 1 + Fail 2) See Enable Timers for Fail >= Timer 1, and sec Reference Supporting Table 15 for Fail Timer 2	
			If Attained Gear Slip is Less than Above Cal Increment Fail Timers					
			If fail timer is greater than threshold increment corresponding gear fail counter and total fail counter					
			2nd gear fail counter				>= 3 Fail Counter From 2nd Gear	
			3rd gear fail counter				>= 3 Fail Counter From 3rd Gear	
			4th gear fail counter				>= 3 Fail Counter From 4th Gear	
			total fail counter				>= 5 Total Fail Counter	
					TUT Enable temperature	>= -6.65625 °C		
					Input Speed Sensor fault	= FALSE Boolean		
					Output Speed Sensor fault	= FALSE Boolean		
					Command / Attained Gear	≠ 1st Boolean		
					High Side Driver ON	= TRUE Boolean		
					output speed limit for TUT	>= 100 RPM		
					input speed limit for TUT	>= 150 RPM		
					PRNDL state defaulted	= FALSE Boolean		
					IMS Fault Pending	= FALSE Boolean		
					Service Fast Learn Mode	= FALSE Boolean		
					HSD Enabled	= TRUE Boolean		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P2724	Pressure Control (PC) Solenoid E Stuck On (Steady State)	<u>Fail Case 1</u> Case: 5th Gear	Table Based value Please Refer to Table 22 in rpm/sec supporting documents Table Based value Please Refer to Table 23 in rpm/sec supporting documents Table Based Time Please Refer to Table 17 in Sec supporting documents Intrusive test: (C35R clutch exhausted) Gear Ratio <= 1.209594727 Gear Ratio >= 1.094360352 If the above parameters are true			>= 1.1 Fail Timer (Sec) >= 3 Fail Count in 5th Gear OR	One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
							>= 3 Total Fail Counts	
			Fail Case 2 Case: 6th Gear	Table Based value Please Refer to Table 22 in rpm/sec supporting documents				
			Max Delta Output Speed Hysteresis	>= 22 in rpm/sec supporting documents				
			Min Delta Output Speed Hysteresis	>= 23 in rpm/sec supporting documents				
			If the Above is True for Time	>= 17 in Sec supporting documents				
			Intrusive test: (CB26 clutch exhausted) Gear Ratio <= 1.209594727 Gear Ratio >= 1.094360352 If the above parameters are true					
					PRNDL State defaulted	= FALSE Boolean		
					inhibit RVT	= FALSE Boolean		
					IMS fault pending indication	= FALSE Boolean		
					output speed	>= 0 RPM		
					TPS validity flag	= TRUE Boolean		
					HSD Enabled	= TRUE Boolean		
					Hydraulic_System_Pressurized	= TRUE Boolean		
							>= 1.1 Fail Timer (Sec)	
							>= 3 Fail Count in 6th Gear OR	
							>= 3 Total Fail Counts	

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					A OR B (A) Output speed enable (B) Accelerator Pedal enable Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for if Attained Gear=1st FW Accelerator Pedal enable if Attained Gear=1st FW Engine Torque Enable if Attained Gear=1st FW Engine Torque Enable Transmission Fluid Temperature Input Speed Sensor fault Output Speed Sensor fault Default Gear Option is not present	>= 67 Nm >= 0.5004883 Nm >= 8.5996094 Volts <= 31.999023 Volts >= 400 RPM <= 7500 RPM >= 5 Sec >= 5.0003052 Pct >= 5 Nm <= 8191.875 Nm >= -6.65625 °C = FALSE Boolean = FALSE Boolean = TRUE		
					Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E	
Variable Bleed Solenoid (VBS)	P2729	Pressure Control (PC) Solenoid E Control Circuit Low (C1234 VBS)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.375 Sample Time (Sec)	One Trip

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
					P2729 Status is not Ignition Voltage Ignition Voltage Engine Speed Engine Speed Engine Speed is within the allowable limits for	= Test Failed This Key On or Fault Active >= 8.5996094 Volt <= 31.999023 Volt >= 400 RPM <= 7500 RPM >= 5 Sec		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Bleed Solenoid (VBS)	P2730	Pressure Control (PC) Solenoid E Control Circuit High (C1234 VBS)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			>= 0.3 Fail Time (Sec) out of 0.375 Sample Time (Sec)	One Trip
					P2730 Status is not Ignition Voltage Ignition Voltage Engine Speed Engine Speed Engine Speed is within the allowable limits for	= Test Failed This Key On or Fault Active >= 8.5996094 Volt <= 31.999023 Volt >= 400 RPM <= 7500 RPM >= 5 Sec		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: None ECM: None		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
Variable Bleed Solenoid (VBS)	P2763	Torque Converter Clutch Pressure High	The HWIO reports a low pressure/high voltage (open or power short) error flag	= TRUE Boolean			>= 4.4 Fail Time (Sec)	Two Trips
							out of 5 Sample Time (Sec)	
						P2763 Status is not = Test Failed This Key On or Fault Active Ignition Voltage >= 8.5996094 Volt Ignition Voltage <= 31.999023 Volt Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec High Side Driver Enabled = TRUE Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0658, P0659 ECM: None		
Variable Bleed Solenoid (VBS)	P2764	Torque Converter Clutch Pressure Control Solenoid Control Circuit Low	The HWIO reports a high pressure/low voltage (ground short) error flag	= TRUE Boolean			>= 4.4 Fail Time (Sec)	One Trip
							out of 5 Sample Time (Sec)	
						P2764 Status is not = Test Failed This Key On or Fault Active Ignition Voltage >= 8.5996094 Volt Ignition Voltage <= 31.999023 Volt Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec High Side Driver Enabled = TRUE Boolean		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	Mil Illum.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0658, P0659 ECM: None		

20 OBDG03D TCM Summary Tables

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Malfunction	Enable Conditions	Time Required	MIL Illum.
Communication	U0073	Controller Area Network Bus Communication Error	CAN Hardware Circuitry Detects a Low Voltage Error	= TRUE Boolean			>= 62 Fail counts (≈ 10 seconds) Out of 70 Sample Counts (≈ 11 seconds)	One Trip
			Delay timer	>= 0,1125 sec		Stabilization delay >= 3 sec Ignition Voltage >= 8.5996094 Volt Ignition Voltage <= 31.999023 Volt Power Mode = Run Disable Conditions: MIL not Illuminated for DTC's: TCM: None ECM: None		
Communication	U0100	Lost Communications with ECM (Engine Control Module)	CAN messages from ECM are not received by the TCM	= TRUE Boolean			>= 12 sec	One Trip
					Stabilization delay >= 3 sec Ignition Voltage >= 8.5996094 Volt Ignition Voltage <= 31.999023 Volt Power Mode = Run Disable Conditions: MIL not Illuminated for DTC's: TCM: U0073 ECM: None			

Supporting Documents

Table 1

Axis	0.00	64.00	128.00	192.00	256.00	320.00	384.00	448.00	512.00	N*m
Curve	50.00	50.00	50.00	50.00	50.00	50.00	50.00	50.00	50.00	RPM

Table 2

Axis	-6.67	-6.66	40.00	°C
Curve	409.59	2.00	2.00	Sec

Table 3

Axis	-6.67	-6.66	40.00	°C
Curve	409.59	4.00	4.00	Sec

Table 4

Axis	-6.67	-6.66	40.00	°C
Curve	409.59	2.00	2.00	Sec

Table 5

Axis	-6.67	-6.66	40.00	°C
Curve	409.59	3.00	3.00	Sec

Table 6

Axis	-6.67	-6.66	40.00	80.00	120.00	°C
Curve	409.00	3.60	1.60	1.40	1.40	Sec

Table 7

Axis	-6.67	-6.66	40.00	80.00	120.00	°C
Curve	409.00	3.40	1.40	1.30	1.20	Sec

20 OBDG03D TCM Supporting Tables

Table 8

Axis	-6.67	-6.66	40.00	80.00	120.00	°C
Curve	409.00	3.60	1.60	1.50	1.40	Sec

Table 9

Axis	-6.67	-6.66	40.00	80.00	120.00	°C
Curve	409.00	3.30	1.30	1.20	1.10	Sec

Table 10

Axis	-6.67	-6.66	40.00	80.00	120.00	°C
Curve	3.03	1.86	1.00	0.75	0.58	Sec

Table 11

Axis	-6.67	-6.66	40.00	80.00	120.00	°C
Curve	1.72	1.11	0.60	0.36	0.22	Sec

Table 12

Axis	-6.67	-6.66	40.00	80.00	120.00	°C
Curve	2.12	1.39	0.84	0.64	0.33	Sec

Table 13

Axis	-6.67	-6.66	40.00	80.00	120.00	°C
Curve	2.51	0.95	0.50	0.29	0.13	Sec

Table 14

Axis	-6.67	-6.66	40.00	80.00	120.00	°C
Curve	2.97	0.82	0.47	0.20	0.13	Sec

20 OBDG03D TCM Supporting Tables

Table 15

Axis	-40.00	-30.00	-20.00	-10.00	0.00	10.00	20.00	30.00	40.00	°C
Curve	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	Sec

Table 16

Axis	-6.67	-6.66	40.00	°C
Curve	409.59	2.50	2.50	Sec

Table 17

Axis	-6.67	-6.66	40.00	°C
Curve	0.40	0.35	0.30	Sec

Table 18

Axis	-40.10	-40.00	-20.00	0.00	30.00	60.00	100.00	149.00	149.10	°C
Curve	256.00	50.00	45.00	40.00	34.00	25.00	20.00	20.00	256.00	°C

Table 19

Axis	-40.10	-40.00	-20.00	0.00	30.00	60.00	100.00	149.00	149.10	°C
Curve	256.00	50.00	45.00	40.00	34.00	25.00	20.00	20.00	256.00	°C

Table 20

Axis	-40.10	-40.00	-20.00	0.00	30.00	60.00	100.00	149.00	149.10	°C
Curve	256.00	10.00	8.00	8.00	8.00	8.00	8.00	8.00	256.00	°C

Table 21

Axis	-40.00	-20.00	40.00	°C
Curve	5.00	3.00	1.00	Sec

20 OBDG03D TCM Supporting Tables

Table 22

Axis	-6.67	-6.66	40.00	°C
Curve	8191.75	8191.75	8191.75	RPM/Sec

Table 23

Axis	-6.67	-6.66	40.00	°C
Curve	8191.75	8191.75	8191.75	RPM/Sec