2017 ATS-V Sedan

°C

adillac Pre-Delivery Inspection Form

Vehicle Identification Number

Dealer/BAC Code

Repair Order #

Stock #

Remove wristwatches, jewelry, cell phones, etc., and cover belt buckles to prevent damage to the vehicle.

Deficiencies must be called to Service Management's attention. Inspect, perform, verify proper operation, assembly, fit and routing of the following.

Initial Preparation:

- Leave door edge protection and other shipping/storage materials on until customer delivery
- Adjust tires to pressures specified on the Certification/Tire Label. Do NOT relearn the Tire Pressure Monitoring System. Record adjusted results.

Temperature: _____°F

Tires: LF____ RF___ LR___ RR_

Spare ____ (if equipped)

 Install loose shipped parts and all accessories (torque as needed)

Interior:

- Power mirrors (if equipped)
- Seats, all: Check material, operation and that removable seats are properly secured
- Seat belts, all: material, operation, routing and latches
- Displays, gauges, interior and exterior lights

Exterior:

- Doors, locks, all keys/fobs and keyless entry system
- Check child safety door/window locks are in normal (unlocked) position (if equipped)
- Fit/Function removable top/panel convertible top (if equipped)
- Fit/function/retention of parts such as bumpers, moldings, grille, emblems, doors, deck lid, hood, fuel door and cap, tailgate, liftgate and hatches, sunroof (if equipped)
- Check antenna mast installation

Under Hood:

- Remote hood release, latch and hood safety latch
- Check condition and charge 12V battery using *PDI Mode* on the EL-50313 battery tester/charger (Midtronics GR8). Attach print out to repair order. See TSB 03-06-03-004 for additional information.
- Hoses, lines, cables and wire attachments are free of kinks and clear of any moving/hot parts
- Hoses, clamps, pipes, fittings, seals, and gaskets for seepage and proper connection
- □ Fluid levels: Add as required

Under Vehicle:

- Visually inspect underbody; check all fluid systems for leaks
- □ Brake/fuel lines secured in clips

Road Test: ODOMETER:

Before _____ After __

Before, during and after this test, check all standard equipment, options and accessories for proper operation, as applicable. Drive on a legal roadway with road conditions permitting. Evaluate the following:

- Check Automatic Transmission Shift lock control
- Check electronic steering column lock (PEPS vehicles only) (if equipped)
- Remote start (if equipped)
- Engine Performance: Cold start, idle quality
- Forward Collision Alert, Front and Rear Parking Assist, Lane Departure Warning, Side Blind Zone Alert, Lane Change Alert, Rear Cross Traffic Alert, Safety Seat Alert, Rear Vision Camera (if equipped)
- Front and rear HVAC system controls, blower(s), heater, A/C, front defroster and rear defogger
- Electronic compass for function. Set to correct zone and calibrate (if equipped)
- Regular and steering wheel controls for radio, CD, MP3, XM, RSA, RSE and NAV (if equipped)
- □ Steering wheel center position
- Steering for leads, pulls, vibration at idle, vibration while driving
- Wipers, delay, RainSense and washers, front and rear (if equipped)
- Brakes for noise, pulls, vibration or shudder at both high and low speeds
 Unusual wind noise
- Unusual wind noise
- Unusual noise/vibration/squeak/rattle
 Cruise/adaptive cruise (if equipped)
- Transfer case operation, all ranges (if
- equipped)
- Transmission shifter, clutch, noise, shift smoothness
- □ Engine performance: Hot start, idle quality
- Check for MIL, SES, SVS, and any warning lights

OnStar: Verify Hot Spot (if equipped)

- Verify OnStar indicator light is green
- Wi-Fi® broadcast check Press the OnStar "Voice Command" button and say "Wi-Fi® Settings"
- Using the information on the screen connect a device, using a Wi-Fi® enabled device (e.g. smartphone), verify that you can connect to vehicle's Hot Spot

<u>Note:</u> You do not need to press the Blue OnStar button. The Demo message will continue to play during each ignition cycle until a customer purchases the vehicle and an Online Enrollment is submitted by the selling Dealer.

- Special Inspection Items Suspension – Remove the Transit Blocks from the front springs & place them in the molded storage tray with the tow eye hook. Remove the Transit Block sticker from the windshield.
- Interior If equipped with Adaptive Froward Lighting RPO T4F access personalization menu for vehicle settings/lighting and enable this feature.
- Interior Slowly remove the protective film from the Bose speakers, to avoid damaging the speaker grille or emblem.
- Interior Confirm the operation of the USB ports in the center console and in the ICS by connecting a cell phone and confirming that the phone will charge with ignition on.
- Interior Place cleaning cloth (from loose shipped parts) in Integrated Center Stack behind the faceplate.
- Interior Set the LKA (Lane Keep Assist) button left of the steering column lower IP to the off position.
- □ Interior Remove and discard the red cap on the Performance Data Recorder (PDR) camera that is located in front of the rearview mirror.
- Exterior Verify the vehicle is equipped with a front splitter/spoiler. If the vehicle was ordered with RPO R6G (no splitter option) see PI1531for instructions on how to order and install a splitter prior to delivery.
- <u>Trunk</u> Place the tow eye in the upper right corner of the molded storage bin under the trunk close out panel.
- Trunk If equipped with the Y4Q (Track Performance Package) which includes the JIM (Battery, Low Mass) place the Low Mass retaining brackets in the storage bin under the trunk close out panel.

Final Inspection & Preparation:

Perform just prior to delivery.

- Interior: Remove protective coverings.
 Clean as required: seats, headliner, kick panels, carpets, console, instrument panel, moldings and hard trim
- Install/secure the floor mat retainers to the carpet side retainers (if equipped)
- Check heated/cooled seats/steering wheel (if equipped)
- □ Set NAV to correct region (if required)
- Exterior wash and dry. Check for water leaks
- Check paint finish for dents, dings, chips, scratches, or blemishes. Repair.
- □ Reset fuel economy readings
- Set clock/calendar to local time
- Using a clean cloth, clean the wiper blades using GM Optikleen windshield washer fluid, if necessary
- Thoroughly clean all glass surfaces, use plain water on interior glass
- Recheck tire pressures (Including spare, if equipped) and 12V battery condition (using EL50313 battery tester/charger *PDI Mode*)
- Check Investigate Vehicle History (IVH) for required field actions. All open field actions must be completed prior to vehicle delivery

Certification: I certify that this Pre-Delivery Inspection has been completed by: