

2017 Silverado 2500 HD & 3500 HD **CHEVROLET** Pre-Delivery Inspection Form

Certification: I certify that this Pre-Delivery Inspection has been completed by:

Service Manager (Signature)

File With Repair Order

Technician (Print Name)

Vehicle Identification Number

Dealer/BAC Code

		Repair Order #
Remove wristwatches, jewelry, cel	Il phones, etc., and cover belt buckles to	prevent damage to the vehicle.
Deficiencies must be called to Service Manager	ment's attention. Inspect, perform, verify proper operatio	n, assembly, fit and routing of the following.
nitial Preparation:	Road Test:	Special Inspection Items
Leave door edge protection and other	ODOMETER:	□ Preparation – "Transport Mode On" may display
shipping/storage materials on until	Before After	on the DIC or the red battery light may flash. To
customer delivery	Before, during and after this test, check all	turn the mode off, start the engine, activate
Adjust tires to pressures specified on the	standard equipment, options and accessories	hazard flashers, press brake pedal and turn the
Certification/Tire Label. Do NOT relearn	for proper operation, as applicable.	ignition key to the crank position for 15 seconds.
the Tire Pressure Monitoring System.	Drive on a legal roadway with road conditions	☐ <u>Initial Prep</u> – Ensure all GM accessories are installed. Examples: cargo lamps, running boards,
Record adjusted results.	permitting. Evaluate the following:	cargo hooks. Refer to accessory installation
Femperature:°F °C		manual in SI – Dual Rear Wheel Vehicles Only.
<u> </u>	 Check Automatic Transmission Shift lock 	Install valve stem extensions on vehicles with
Fires: LF RF LR RR	control	Chrome Trim Skins (RPO Q9A).
Spare (if equipped)	 Check electronic steering column lock 	□ Note - Vehicles built with SEO 8S3, Backup
Install loose shipped parts and all	(PEPS vehicles only) (if equipped)	Alarm. The backup alarm must be connected during PDI, refer to latest bulletin PIT5386 for
accessories (torque as needed)	 Remote start (if equipped) 	instructions.
nterior:	 Engine Performance: Cold start, idle 	☐ <u>Interior</u> – Place cleaning cloth (from loose
Power mirrors (if equipped)	quality	shipped parts) in Integrated Center Stack behind
Seats, all: Check material, operation and	□ Forward Collision Alert, Front and Rear	the faceplate (if equipped). Otherwise, place in
	Parking Assist, Lane Departure Warning,	glove box.
that removable seats are properly secured	Side Blind Zone Alert, Lane Change Alert,	☐ Final Inspection & Prep — Vehicles built with Duramax Diesel engines (RPOs L5P) only. Diesel
Seat belts, all: material, operation, routing	Rear Cross Traffic Alert, Safety Seat Alert,	Exhaust Fluid (DEF) MUST be filled at the time of
and latches	Rear Vision Camera (if equipped)	Pre-Delivery Inspection up to 2.5 gallons. Refer to
Displays, gauges, interior and exterior	☐ Front and rear HVAC system controls,	the Duramax Diesel Owner Manual supplement.
lights	blower(s), heater, A/C, front defroster and	☐ Final Inspection & Prep — CNG Fuel System
Exterior:	rear defogger	(RPO: LC8) Check operation and functionality of
Doors, locks, all keys/fobs and keyless	☐ Electronic compass for function. Set to	CNG system during road test. *DO NOT remove any CNG stickers or placards.
entry system	correct zone and calibrate (if equipped)	·
Check child safety door/window locks are	Regular and steering wheel controls for	Final Inspection & Preparation:
in normal (unlocked) position (if equipped)	radio, CD, MP3, XM, RSA, RSE and NAV	Perform just prior to delivery.
Fit/Function removable top/panel	(if equipped)	 Interior: Remove protective coverings.
convertible top (if equipped)	☐ Steering wheel – center position	Clean as required: seats, headliner, kick
Fit/function/retention of parts such as	 Steering wheel – center position Steering for leads, pulls, vibration at idle, 	panels, carpets, console, instrument panel
bumpers, moldings, grille, emblems, doors,	vibration while driving	moldings and hard trim
deck lid, hood, fuel door and cap, tailgate,	☐ Wipers, delay, RainSense and washers,	 Secure floor mat retainers to the carpet
liftgate and hatches, sunroof (if equipped)	front and rear (if equipped)	side retainers (if equipped). Do Not stack
Check antenna mast installation	` · · · · ·	mats. See warning in TSB 10-08-110-001.
	 Brakes for noise, pulls, vibration or shudder at both high and low speeds 	☐ Check heated/cooled seats/steering wheel
Jnder Hood:	□ Unusual wind noise	(if equipped)
Remote hood release, latch and hood	☐ Unusual noise/vibration/squeak/rattle	 Set NAV to correct region (if required)
safety latch		 Exterior wash and dry. Check for water
Check condition and charge 12V battery	Cruise/adaptive cruise (if equipped)	leaks
using PDI Mode on the EL-50313 battery	☐ Transfer case operation, all ranges (if	□ Check paint finish for dents, dings, chips,
tester/charger (Midtronics GR8). Attach	equipped)	scratches, or blemishes. Repair.
print out to repair order. See TSB 03-06-	☐ Transmission shifter, clutch, noise, shift	□ Reset fuel economy readings
03-004 for additional information.	smoothness	□ Set clock/calendar to local time
Hoses, lines, cables and wire attachments	☐ Engine performance: Hot start, idle quality	☐ Using a clean cloth, clean the wiper blades
are free of kinks and clear of any	□ Check for MIL, SES, SVS, and any	using GM Optikleen windshield washer
moving/hot parts	warning lights	fluid, if necessary
Hoses, clamps, pipes, fittings, seals, and	OnStar: Verify Hot Spot (if equipped)	☐ Thoroughly clean all glass surfaces, use
gaskets for seepage and proper	 Verify OnStar indicator light is green 	plain water on interior glass
connection	☐ Wi-Fi® broadcast check – Press the	Recheck tire pressures (Including spare, if
☐ Fluid levels: Add as required	OnStar "Voice Command" button and say	equipped) and 12V battery condition
Jnder Vehicle:	"Wi-Fi® Settings"	
☐ Visually inspect underbody; check all fluid	☐ Using the information on the screen	(using EL50313 battery tester/charger PDI Mode)
systems for leaks	connect a device, using a Wi-Fi® enabled	,
	device (e.g. smartphone), verify that you	☐ Check Investigate Vehicle History (IVH) for
Brake/fuel lines secured in clips	can connect to vehicle's Hot Spot	required field actions. All open field actions
	Note: You do not need to press the Blue OnStar button.	must be completed prior to vehicle delivery
	The Demo message will continue to play during each	
	ignition cycle until a customer purchases the vehicle and	
	an Online Enrollment is submitted by the selling Dealer.	

Date