

Vehicle Identification Number

Technician (Print Name)

Dealer/BAC Code

| _  | =   | Repair Order #  |
|--|---|---|
| Remove wristwatches, jewelry, cel  | Il phones, etc., and cover belt buckles to  | o prevent damage to the vehicle.  |
| Deficiencies must be called to Service Manager   | ment's attention. Inspect, perform, verify proper operation                                       | on, assembly, fit and routing of the following.   |
| Initial Preparation:  ☐ Leave door edge protection and other   | Road Test:<br>ODOMETER:   | Special Inspection Items Initial Preparation - "Transport Mode On"                                      |
| shipping/storage materials on until  | Before After  | may display on the DIC or the red battery   |
| customer delivery  | Before, during and after this test, check all   | light may flash. Disable the Transport Mode.  |
| <ul> <li>Adjust tires to pressures specified on the<br/>Certification/Tire Label. Do NOT relearn</li> </ul>  | standard equipment, options and accessories for proper operation, as applicable.                  | Refer to latest TSB 11-08-49-001.  Initial Prep – For information on delivering                         |
| the Tire Pressure Monitoring System.   | Drive on a legal roadway with road conditions   | quality vehicles and generating higher CSI  |
| Record adjusted results.   | permitting. Evaluate the following:   | scores. Refer to latest TSB 03-00-89-006.  Initial Preparation – Set the tire pressure to               |
| Temperature:°F °C  | ☐ Check Automatic Transmission Shift lock   | 40 PSI. Refer to the Tire Pressure Label.   |
| Tires: LF RF LR RR   | control   | □ Exterior - Verify that the 2 (two) rear license   |
| Spare (if equipped)  | <ul> <li>Check electronic steering column lock</li> </ul>   | plate screws are firmly seated so the plate does not rattle.  |
| ☐ Install loose shipped parts and all  | (PEPS vehicles only) (if equipped)  | □ Note - Vehicles in dealer inventory need to   |
| accessories (torque as needed)   | Remote start (if equipped)  | be properly maintained for a quality delivery.  |
| Interior:  | <ul> <li>Engine Performance: Cold start, idle quality</li> </ul>                                  | Refer to latest TSB 09-00-89-002.  Final Inspection & Prep – Use plain water,                           |
| Power mirrors (if equipped)  | ☐ Forward Collision Alert, Front and Rear   | not glass cleaner, to clean the inside of the   |
| <ul> <li>Seats, all: Check material, operation and<br/>that removable seats are properly secured</li> </ul>  | Parking Assist, Lane Departure Warning,   | windshield. This will help prevent film/haze  |
| ☐ Seat belts, all: material, operation, routing  | Side Blind Zone Alert, Lane Change Alert,   | build up.   |
| and latches  | Rear Cross Traffic Alert, Safety Seat Alert,  | Final Inspection & Preparation:   |
| □ Displays, gauges, interior and exterior  | Rear Vision Camera (if equipped)  Front and rear HVAC system controls,                            | Perform just prior to delivery.   |
| lights   | blower(s), heater, A/C, front defroster and   | ☐ Interior: Remove protective coverings.  |
| Exterior:  | rear defogger   | Clean as required: seats, headliner, kick panels, carpets, console, instrument panel,                   |
| □ Doors, locks, all keys/fobs and keyless  | <ul> <li>Electronic compass for function. Set to</li> </ul>                                       | moldings and hard trim  |
| entry system   | correct zone and calibrate (if equipped)  | <ul> <li>Install and secure the floor mat retainers to</li> </ul>                                       |
| <ul> <li>Check child safety door/window locks are<br/>in normal (unlocked) position (if equipped)</li> </ul> | Regular and steering wheel controls for   | the carpet side retainers (if equipped)   |
| ☐ Fit/Function removable top/panel   | radio, CD, MP3, XM, RSA, RSE and NAV (if equipped)  | ☐ Check heated/cooled seats/steering wheel  |
| convertible top (if equipped)  | ☐ Steering wheel – center position  | <ul><li>(if equipped)</li><li>Set NAV to correct region (if required)</li></ul>                         |
| ☐ Fit/function/retention of parts such as  | ☐ Steering for leads, pulls, vibration at idle,   | Exterior wash and dry. Check for water  |
| bumpers, moldings, grille, emblems, doors,   | vibration while driving   | leaks   |
| deck lid, hood, fuel door and cap, tailgate,   | □ Wipers, delay, RainSense and washers,   | ☐ Check paint finish for dents, dings, chips,   |
| liftgate and hatches, sunroof (if equipped)  Check antenna mast installation                                 | front and rear (if equipped)  | scratches, or blemishes. Repair.  |
| Under Hood:  | <ul> <li>Brakes for noise, pulls, vibration or<br/>shudder at both high and low speeds</li> </ul> | <ul> <li>□ Reset fuel economy readings</li> <li>□ Set clock/calendar to local time</li> </ul>           |
| □ Remote hood release, latch and hood  | ☐ Unusual wind noise  | ☐ Using a clean cloth, clean the wiper blades   |
| safety latch   | <ul> <li>Unusual noise/vibration/squeak/rattle</li> </ul>   | using GM Optikleen windshield washer  |
| ☐ Check condition and charge 12V battery   | ☐ Cruise/adaptive cruise (if equipped)  | fluid, if necessary   |
| using <b>PDI Mode</b> on the EL-50313 battery  | ☐ Transfer case operation, all ranges (if   | ☐ Thoroughly clean all glass surfaces, use  |
| tester/charger (Midtronics GR8). Attach  | equipped)  Transmission shifter, clutch, noise, shift   | plain water on interior glass   |
| print out to repair order. See TSB 03-06-<br>03-004 for additional information.                              | smoothness  | <ul> <li>Recheck tire pressures (Including spare, if<br/>equipped) and 12V battery condition</li> </ul> |
| ☐ Hoses, lines, cables and wire attachments  | <ul> <li>Engine performance: Hot start, idle quality</li> </ul>                                   | (using EL50313 battery tester/charger <b>PDI</b>  |
| are free of kinks and clear of any   | ☐ Check for MIL, SES, SVS, and any  | Mode)   |
| moving/hot parts   | warning lights  | □ Check Investigate Vehicle History (IVH) for   |
| ☐ Hoses, clamps, pipes, fittings, seals, and   | OnStar: Verify Hot Spot (if equipped)   | required field actions. All open field actions  |
| gaskets for seepage and proper connection  | ☐ Verify OnStar indicator light is green  | must be completed prior to vehicle delivery   |
| □ Fluid levels: Add as required  | <ul> <li>Wi-Fi® broadcast check – Press the<br/>OnStar "Voice Command" button and say</li> </ul>  |   |
| Under Vehicle:   | "Wi-Fi® Settings"   |   |
| ☐ Visually inspect underbody; check all fluid  | <ul> <li>Using the information on the screen</li> </ul>   |   |
| systems for leaks  | connect a device, using a Wi-Fi® enabled  |   |
| □ Brake/fuel lines secured in clips  | device (e.g. smartphone), verify that you   |   |
|  | can connect to vehicle's Hot Spot  Note: You do not need to press the Blue OnStar button.         |   |
|  | The Demo message will continue to play during each  |   |
|  | ignition cycle until a customer purchases the vehicle and   |   |
|  | an Online Enrollment is submitted by the selling Dealer.  |   |
|  |   |   |
| Certification: I certify that this Pre-Delivery Inspection has been completed by:                            |   |   |

Service Manager (Signature)

File With Repair Order

Date

042517 r1.6

Page 1 of 1