

Vehicle Identification Number

☐ Hoses, lines, cables and wire attachments

Hoses, clamps, pipes, fittings, seals, and

gaskets for seepage and proper retention

are free of kinks and clear of any

moving/hot parts

☐ Fluid levels: Add as required

Dealer/BAC Code

venicle identification (varibe)	Deale/DAC Code	
	Stock #	Repair Order #
Remove wristwatches, iewelry, cel	Il phones, etc., and cover belt buckles to	
	ment's attention. Inspect, perform, verify proper operation	
Initial Preparation:	Under Vehicle:	Special Inspection Items
☐ Leave door edge protection and other	☐ Visually inspect underbody; check all fluid	☐ Initial Preparation — "Transport Mode On"
shipping/storage materials on until	systems for leaks	may display on the DIC or the red battery
customer delivery	□ Brake/fuel lines secured in clips	light may flash. Disable the Transport
□ Adjust tires to pressures specified on the	Road Test:	Mode. Refer to latest TSB 11-08-49-001.  Interior – Tighten the spare tire retainer nut
Certification/Tire Label. Do NOT relearn	ODOMETER:	<ul> <li>Interior – Tighten the spare tire retainer nut to prevent noises while driving.</li> </ul>
the Tire Pressure Monitoring System.	Before After	□ Engine – Vehicle may be equipped with
Record adjusted results.	Before, during and after this test, check all	Stop/Start. For further information see Doc
Temperature:°F °C	standard equipment, options and accessories	ID 4212978 (Stop/Start Description and
Tires: LF RF LR RR	for proper operation, as applicable.	Operation).
□ Spare (if equipped)	Drive on a legal roadway with road conditions	□ Exterior – (Accessories) Luggage Carrier
☐ Install loose shipped parts and all	permitting. Evaluate the following:	Cross Rail Kit. The rubber inserts must be
accessories (torque as needed)	☐ Check Automatic Transmission Shift lock	installed into the Cross Rails prior to the Cross Rail being installed on the vehicle.
Interior:	control and shifter operation	Refer to Doc ID: 3371996.
☐ Power mirrors (if equipped)	☐ Check electronic steering column lock	□ Road Test – Verify operation of the Driver
☐ Seats, all: Check material and operation of	(PEPS vehicles only) (if equipped)	Assistance Systems e.g., Ultrasonic
all features	□ Remote start (if equipped)	Front/Rear Parking Assist & Rear Vision
☐ Check all accessory power outlets and AC	☐ Engine Performance: Cold start, idle	Camera (if equipped).
inverter (if equipped)	quality	Final Inspection & Prep – Due to normal
☐ Seat belts, all: material, operation, routing	□ Safety Systems:Front and Rear Parking	daily & seasonal temperature changes, tire pressures MUST be rechecked at time of
and latches	Assist, Lane Departure Warning, Side	delivery. Consult Tire Loading Label
□ Displays, gauges, interior and exterior	Blind Zone Alert, Lane Change Alert, Rear	Recommended Cold Tire Inflation Pressure.
lights	Cross Traffic Alert, Safety Alert Seat,	Final Inspection & Preparation:
☐ Center stack and steering wheel controls	Camera Vision Systems (if equipped)	Perform just prior to delivery.
for infotainment/ radio and NAV (if	<ul> <li>Electronic compass for function.</li> </ul>	Interior: Remove protective coverings.
equipped)	<ul> <li>Steering wheel – center position</li> </ul>	Clean as required: seats, headliner, kick
☐ HVAC system controls, blower, heater,	<ul> <li>Steering for leads, pulls, vibration at idle,</li> </ul>	panels, carpets, console, instrument panel,
A/C, defroster and rear defogger	vibration while driving	moldings and hard trim
☐ Check heated/cooled seats/steering wheel	<ul> <li>Wipers, delay, RainSense and washers,</li> </ul>	<ul> <li>Secure floor mat retainers to the carpet</li> </ul>
(if equipped)	front and rear (if equipped)	side retainers (if equipped). Do Not stack
Exterior:	<ul> <li>Brakes for noise, pulls, vibration or</li> </ul>	mats. See warning in TSB 10-08-110-001
□ Doors, locks, all keys/fobs and keyless	shudder at both high and low speeds	<ul> <li>Exterior wash and dry. Check for water</li> </ul>
entry system	□ Unusual wind noise	leaks
☐ Check child safety door/window locks are	☐ Unusual noise/vibration/squeak/rattle	<ul> <li>Check paint finish for dents, dings, chips,</li> </ul>
in normal (unlocked) position	☐ Cruise/adaptive cruise (if equipped)	scratches, or blemishes.
☐ Fit/Function removable top/panel	☐ Transfer case operation, all ranges (if	□ Reset fuel economy readings
convertible top (if equipped)	equipped)	☐ Set clock/calendar to local time
Fit/function/retention of parts such as	Automatic Transmission shift performance	☐ Using a clean cloth, clean the wiper blades
bumpers, moldings, grille, emblems, doors,	□ Automatic Park Assist for operation (if	using GM Optikleen windshield washer
deck lid, hood, fuel door and cap, tailgate,	equipped)	fluid, if necessary
liftgate and hatches, sunroof (if equipped)	☐ Verify AutoStop/Start operation during	☐ Thoroughly clean all glass surfaces, use
Check antenna mast installation	Road Test	plain water on interior glass
Under Hood:  □ Permote hood release, latch and hood	☐ Engine performance: Hot start, idle quality	Recheck tire pressures (Including spare, if
Remote hood release, latch and hood	<ul> <li>Check for warning lights and messages</li> <li>OnStar:</li> </ul>	equipped) and 12V battery condition
safety latch  ☐ Check condition and charge 12V battery		(using EL50313 battery tester/charger <b>PDI</b>
using <b>PDI Mode</b> on the EL-50313 battery	<ul> <li>Verify OnStar indicator light is green</li> </ul>	Mode)  Chook Investigate Vehicle History (IVH) for
tester/charger (Midtronics GR8). Attach	□ Connect a Wi-Fi® enabled device (e.g.	□ Check Investigate Vehicle History (IVH) for
print out to repair order. See TSB 03-06-	smartphone) to the vehicle and verify that	required field actions. All open field actions
03-004 for additional information.	you can connect to vehicle's Hot Spot. If	must be completed prior to vehicle delivery
Uses lines askins and wire attackers.	you can't connect to the Hot Spot, refer to	

Certification: I certify that this Pre-Delivery Inspection has been completed by: Technician (Print Name) Service Manager (Signature) Date

steps to enable it.

the latest version of TSB 16-NA-239 for

Note: The Demo message will continue to play during each

ignition cycle until a customer purchases the vehicle and

an Online Enrollment is submitted by the selling Dealer.

Page 1 of 1