

are free of kinks and clear of any

☐ Fluid levels: Add as required

☐ Hoses, clamps, pipes, fittings, seals, and

gaskets for seepage and proper retention

moving/hot parts

2018 XTS

Pre-Delivery Inspection Form

Vehicle Identification Number

Dealer/RAC Code

venicle identification Number	Dealei/BAC Code	
	Stock #_	Repair Order #
Remove wristwatches, jewelry, ce	I phones, etc., and cover belt buckles to	prevent damage to the vehicle.
Deficiencies must be called to Service Manager	ment's attention. Inspect, perform, verify proper operatio	on, assembly, fit and routing of the following.
Initial Preparation:	Under Vehicle:	Special Inspection Items
□ Leave door edge protection and other	☐ Visually inspect underbody; check all fluid	☐ Initial Preparation — 'Transport Mode On'
shipping/storage materials on until	systems for leaks	may display on the DIC or the red battery
customer delivery	☐ Brake/fuel lines secured in clips	light may flash. To turn the Mode Off, start
☐ Adjust tires to pressures specified on the	Road Test:	engine, activate hazard flashers, press
Certification/Tire Label. Do NOT relearn	ODOMETER:	brake pedal, then press & hold the
the Tire Pressure Monitoring System.	Before After	Start/Stop button or turn the ignition key to the crank position for 15 seconds.
Record adjusted results.	Before, during and after this test, check all	☐ Interior — Place cleaning cloth (from loose
Temperature:°F °C	standard equipment, options and accessories	shipped parts) in Integrated Center Stack
Tires: LF RF LR RR	for proper operation, as applicable.	behind the faceplate (if equipped).
□ Spare (if equipped)	Drive on a legal roadway with road conditions	Otherwise, place in glovebox.
☐ Install loose shipped parts and all	permitting. Evaluate the following:	Road Test - Verify operation of all the ESS
accessories (torque as needed)	☐ Check Automatic Transmission Shift lock	1 & ESS 2 Safety features (if equipped). Final Inspection & Prep – Use a non-
Interior:	control and shifter operation	alkaline solution for washing the Bright
□ Power mirrors (if equipped)	☐ Check electronic steering column lock	Aluminum Moldings. Do Not wash the
☐ Seats, all: Check material and operation of	(PEPS vehicles only) (if equipped)	vehicle until latest bulletin PIC5779 has
all features	□ Remote start (if equipped)	been reviewed.
☐ Check all accessory power outlets and AC	□ Engine Performance: Cold start, idle	☐ Final Inspection & Prep — Due to normal
inverter (if equipped)	quality	daily & seasonal temperature changes, tire pressures MUST be rechecked at the time
☐ Seat belts, all: material, operation, routing	 Safety Systems: Front and Rear Parking 	of delivery. Consult Tire Loading Label
and latches	Assist, Lane Departure Warning, Side	Recommended Cold Tire Inflation Pressure.
 Displays, gauges, interior and exterior 	Blind Zone Alert, Lane Change Alert, Rear	Final Inspection & Preparation:
lights	Cross Traffic Alert, Safety Alert Seat,	Perform just prior to delivery.
☐ Center stack and steering wheel controls	Camera Vision Systems (if equipped)	Interior: Remove protective coverings.
for infotainment/ radio and NAV (if	 Electronic compass for function. 	Clean as required: seats, headliner, kick
equipped)	☐ Steering wheel – center position	panels, carpets, console, instrument panel
☐ HVAC system controls, blower, heater,	 Steering for leads, pulls, vibration at idle, 	moldings and hard trim
A/C, defroster and rear defogger	vibration while driving	 Install and secure the floor mat retainers to
Rear HVAC Control function (if equipped)	☐ Wipers, delay, RainSense and washers,	the carpet side retainers (if equipped)
☐ Check heated/cooled seats/steering wheel	front and rear (if equipped)	 Exterior wash and dry. Check for water
(if equipped)	☐ Brakes for noise, pulls, vibration or shudder	leaks
Exterior: ☐ Doors, locks, all keys/fobs and keyless	at both high and low speeds Unusual wind noise	□ Check paint finish for dents, dings, chips,
	☐ Unusual noise/vibration/squeak/rattle	scratches, or blemishes
entry systemCheck child safety door/window locks are	☐ Cruise/adaptive cruise (if equipped)	Reset fuel economy readings
in normal (unlocked) position	☐ Transfer case operation, all ranges (if	☐ Set clock/calendar to local time
☐ Fit/Function removable top/panel	equipped)	☐ Using a clean cloth, clean the wiper blades
convertible top (if equipped)	Manual Transmission shifter, clutch, noise,	using GM Optikleen windshield washer fluid, if necessary
☐ Fit/function/retention of parts such as	shift smoothness	☐ Thoroughly clean all glass surfaces, use
bumpers, moldings, grille, emblems, doors,	□ Automatic Transmission shift performance	plain water on interior glass
deck lid, hood, fuel door and cap, tailgate,	□ Automatic Park Assist for operation (if	□ Recheck tire pressures (Including spare, if
liftgate and hatches, sunroof (if equipped)	equipped)	equipped) and 12V battery condition
☐ Check antenna mast installation	 Verify AutoStop/Start operation during 	(using EL50313 battery tester/charger PDI
Under Hood:	Road Test	Mode)
Remote hood release, latch and hood	□ Engine performance: Hot start, idle quality	 Check charge of the vehicle high voltage
safety latch	☐ Check for warning lights and messages	battery (if equipped)
☐ Check condition and charge 12V battery	OnStar:	□ Check Investigate Vehicle History (IVH) for
using PDI Mode on the EL-50313 battery	 Verify OnStar indicator light is green 	required field actions. All open field actions
tester/charger (Midtronics GR8). Attach	□ Connect a Wi-Fi® enabled device (e.g.	must be completed prior to vehicle delivery
print out to repair order. See TSB 03-06-	smartphone) to the vehicle and verify that	, ,
03-004 for additional information.	you can connect to vehicle's Hot Spot. If	
☐ Hoses, lines, cables and wire attachments	you can't connect to the Hot Spot, refer to	

Certification: I certify that this Pre-Delivery Inspection has been completed by: Technician (Print Name) Service Manager (Signature) Date File With Repair Order

steps to enable it.

the latest version of TSB 16-NA-239 for

Note: The Demo message will continue to play during each ignition cycle until a customer purchases the vehicle and

an Online Enrollment is submitted by the selling Dealer.