Vehicle Identification Number

Technician (Print Name)

Dealer/BAC Code

Deficiencies must be called to Service Manager	ment's attention. Inspect, perform, verify proper operation	n, assembly, fit and routing of the following.
Deficiencies must be called to Service Manager nitial Preparation: Leave door edge protection and other shipping/storage materials on until customer delivery Adjust tires to pressures specified on the Certification/Tire Label. Do NOT relearn the Tire Pressure Monitoring System. Record adjusted results. Temperature:	Under Vehicle: Visually inspect underbody; check all fluid systems for leaks Brake/fuel lines secured in clips Road Test: ODOMETER: Before After Before, during and after this test, check all standard equipment, options and accessories for proper operation, as applicable. Drive on a legal roadway with road conditions permitting. Evaluate the following: Check Automatic Transmission Shift lock control and shifter operation Check electronic steering column lock (PEPS vehicles only) (if equipped) Remote start (if equipped) Engine Performance: Cold start, idle quality Safety Systems:Front and Rear Parking Assist, Lane Departure Warning, Side Blind Zone Alert, Lane Change Alert, Rear Cross Traffic Alert, Safety Alert Seat, Camera Vision Systems (if equipped) Electronic compass for function. Steering wheel – center position Steering wheel – center position Steering or leads, pulls, vibration at idle, vibration while driving Wipers, delay, RainSense and washers, front and rear (if equipped) Brakes for noise, pulls, vibration or shudder at both high and low speeds Unusual wind noise Unusual noise/vibration/squeak/rattle Cruise/adaptive cruise (if equipped) Transfer case operation, all ranges (if equipped) Automatic Park Assist for operation (if equipped) Engine performance: Hot start, idle quality Check for warning lights and messages Onstar: Verify OnStar indicator light is green Connect a Wi-Fi® enabled device (e.g. smartphone) to the vehicle and verify that you can connect to vehicle's Hot Spot. If you can't connect to the Hot Spot, refer to the latest version of TSB 16-NA-239 for steps to enable it. Note: The Demo message will continue to play during each ignition cycle until a customer purchases the vehicle and an Online Enrollment is submitted by the selling Dealer.	Special Inspection Items Preparation - "Transport Mode On" may display on the DIC or the red battery light may flash. To turn the mode off, start the engine, activate hazard flashers, press brake pedal and turn the ignition key to the crank position for 15 seconds. Initial Preparation - Ensure all GM Accessories have been installed. Examples: Cargo Lamps, Running Boards, cargo hooks. Refer to the Accessories Installation Manual in SI. Interior - Set NAV radio to the correct region. NAV Map data is loaded into internal memory hard disc drive from factory (if equipped). Note - Vehicles in dealer inventory need to be properly maintained for a quality delivery. Refer to latest TSB 09-00-89-002. Final Inspection & Prep - Due to normal daily & seasonal temperature changes, tire pressures MUST be rechecked at time of delivery. Consult Tire Loading Label Recommended Cold Tire Inflation Pressure. Final Inspection & Prep - Vehicles built with Duramax Diesel engine (RPOs LWN) only. Diesel Exhaust Fluid (DEF) MUST be filled at the time of Pre-Delivery Inspection up to 9.5L (2.5 gal). Refer to the Duramax Diesel Owner Manual supplement. Final Inspection & Preparation: Perform just prior to delivery. Interior: Remove protective coverings. Clean as required: seats, headliner, kick panels, carpets, console, instrument pan moldings and hard trim Install and secure the floor mat retainers the carpet side retainers (if equipped) Exterior wash and dry. Check for water leaks Check paint finish for dents, dings, chips, scratches, or blemishes. Reset fuel economy readings Set clock/calendar to local time Using a clean cloth, clean the wiper blade using GM Optikleen windshield washer fluid, if necessary Thoroughly clean all glass surfaces, use plain water on interior glass Recheck tire pressures (Including spare, equipped) and 12V battery condition (using EL50313 battery tester/charger PL Mode) Check Investigate Vehicle History (IVH) for required field actions. All open field actior must be completed prior to vehicle deliver

Service Manager (Signature)

Date