# 2018 Volt

CHEVROLET Pre-Delivery Inspection Form

Vehicle Identification Number

Stock #

\_\_\_\_ Repair Order #\_\_\_\_\_

Remove wristwatches, jewelry, cell phones, etc., and cover belt buckles to prevent damage to the vehicle.

Deficiencies must be called to Service Management's attention. Inspect, perform, verify proper operation, assembly, fit and routing of the following.

#### Initial Preparation:

- Leave door edge protection and other shipping/storage materials on until customer delivery
- Adjust tires to pressures specified on the Certification/Tire Label. Do NOT relearn the Tire Pressure Monitoring System. Record adjusted results.

°F

°C

Temperature:

## Tires: LF\_\_\_\_ RF\_\_\_\_ LR\_\_\_\_ RR\_\_\_\_

Install loose shipped parts and all accessories (torque as needed)

#### Interior:

- Power mirrors (if equipped)
- Seats, all: Check material and operation of all features
- Check all accessory power outlets and AC inverter (if equipped)
- Seat belts, all: material, operation, routing and latches
- Displays, gauges, interior and exterior lights
- Center stack and steering wheel controls for infotainment/ radio and NAV (if equipped)
- HVAC system controls, blower, heater, A/C, defroster and rear defogger
- Check heated/cooled seats/steering wheel (if equipped)

#### Exterior:

- Doors, locks, all keys/fobs and keyless entry system
- Check child safety door/window locks are in normal (unlocked) position
- Fit/function/retention of parts such as bumpers, moldings, grille, emblems, doors, deck lid, hood, fuel door and cap, tailgate, liftgate and hatches, sunroof (if equipped)
- Check antenna mast installation

#### Under Hood:

- Remote hood release, latch and hood safety latch
- Check condition and charge 12V battery using *PDI Mode* on the EL-50313 battery tester/charger (Midtronics GR8). Attach print out to repair order. See TSB 03-06-03-004 for additional information.
- Hoses, lines, cables and wire attachments are free of kinks and clear of any moving/hot parts
- Hoses, clamps, pipes, fittings, seals, and gaskets for seepage and proper retention
- Fluid levels: Add as required

#### Under Vehicle:

- Visually inspect underbody; check all fluid systems for leaks
- Brake/fuel lines secured in clips

#### Road Test:

# ODOMETER:

#### Before \_\_\_\_\_ After

Before, during and after this test, check all standard equipment, options and accessories for proper operation, as applicable. Drive on a legal roadway with road conditions permitting. Evaluate the following:

- □ Check Automatic Transmission Shift lock control and shifter operation
- Check electronic steering column lock (PEPS vehicles only) (if equipped)
- Remote start (if equipped)
- Engine Performance: Cold start, idle guality
- Safety Systems: Front and Rear Parking Assist, Lane Departure Warning, Side Blind Zone Alert, Lane Change Alert, Rear Cross Traffic Alert, Safety Alert Seat, Camera Vision Systems (if equipped)
- □ Electronic compass for function.
- □ Steering wheel center position
- Steering for leads, pulls, vibration at idle, vibration while driving
- Wipers, delay, RainSense and washers, front and rear (if equipped)
- Brakes for noise, pulls, vibration or shudder at both high and low speeds
- Unusual wind noise
- Unusual noise/vibration/squeak/rattle
- Cruise/adaptive cruise (if equipped)
- Automatic Transmission shift performance
- Automatic Park Assist for operation (if equipped)
- □ Engine performance: Hot start, idle quality
- Check for warning lights and messages

### OnStar:

- Verify OnStar indicator light is green
- Connect a Wi-Fi® enabled device (e.g. smartphone) to the vehicle and verify that you can connect to vehicle's Hot Spot. If you can't connect to the Hot Spot, refer to the latest version of TSB 16-NA-239 for steps to enable it.

<u>Note:</u> The Demo message will continue to play during each ignition cycle until a customer purchases the vehicle and an Online Enrollment is submitted by the selling Dealer.

- Special Inspection Items
  Initial Preparation "Transport Mode On" may display on the DIC or the red battery light may flash. Disable the Transport Mode. Refer to latest TSB 11-08-49-001.
   Note Table the choice and instructions out
- Note Take the charge cord instructions out of package & place with delivery information to be presented to the customer.
- Final Inspection & Prep Verify charge operation using 120V charge cord provided with the vehicle – verify LEDs and horn chirp – stow the 120V charge cord.
- Final Inspection & Prep Hang GTKY booklet, Radio Guide & Mobile app card around the shifter.
- Final Inspection & Prep Due to normal daily & seasonal temperature changes, tire pressures MUST be rechecked at time of delivery. Consult Tire Loading Label Recommended Cold Tire Inflation Pressure.

### Final Inspection & Preparation:

#### Perform just prior to delivery.

- Interior: Remove protective coverings.
  Clean as required: seats, headliner, kick panels, carpets, console, instrument panel, moldings and hard trim
- Install and secure the floor mat retainers to the carpet side retainers (if equipped)
- Exterior wash and dry. Check for water leaks
- □ Check paint finish for dents, dings, chips, scratches, or blemishes.
- Reset fuel economy readings in both the DIC (all ranges) and Center Stack Display
  - Set clock/calendar to local time
  - Using a clean cloth, clean the wiper blades using GM Optikleen windshield washer fluid, if necessary
  - Thoroughly clean all glass surfaces, use plain water on interior glass
- Recheck tire pressures and 12V battery condition (using EL50313 battery tester/charger *PDI Mode*)
- Check charge of the vehicle high voltage battery
- Check Investigate Vehicle History (IVH) for required field actions. All open field actions must be completed prior to vehicle delivery

Certification: I certify that this Pre-Delivery Inspection has been completed by: