

Certification: I certify that this Pre-Delivery Inspection has been completed by:

Technician (Print Name)

Vehicle Identification Number

Dealer/BAC Code

	Stock #_	Repair Order #
Remove wristwatches, jewelry, cel	I phones, etc., and cover belt buckles to	prevent damage to the vehicle.
Deficiencies must be called to Service Manager	ment's attention. Inspect, perform, verify proper operatio	n, assembly, fit and routing of the following.
nitial Preparation:	Road Test:	
Leave door edge protection and other	ODOMETER:	Special Inspection Items ☐ Suspension – Remove the Transit Blocks from the front
shipping/storage materials on until	Before After	springs & place them in the molded storage tray with the
customer delivery	Before, during and after this test, check all	tow eye hook. Remove the Transit Block sticker from the windshield.
Adjust tires to pressures specified on the	standard equipment, options and accessories	□ Interior – Reprogram the HMI Module (Radio RPO
Certification/Tire Label. Do NOT relearn	for proper operation, as applicable.	IO5/IO6) with the latest software available. Refer to latest
the Tire Pressure Monitoring System.	Drive on a legal roadway with road conditions	TSB 16-NA-042 for applicable vehicle builds. Interior – If equipped with Adaptive Froward Lighting
Record adjusted results.	permitting. Evaluate the following:	RPO T4F access personalization menu for vehicle
「emperature:°F °C	☐ Check Automatic Transmission Shift lock	settings/lighting and enable this feature. Interior – Slowly remove the protective film from the Bose
Fires: LF RF LR RR	control	speakers, to avoid damaging the speaker grille or
Spare (if equipped)	☐ Check electronic steering column lock	emblem. Interior – Confirm the operation of the USB ports in the
Install loose shipped parts and all	(PEPS vehicles only) (if equipped)	center console and in the ICS by connecting a cell phone
accessories (torque as needed)	Remote start (if equipped)	and confirming that the phone will charge with ignition on. ☐ Interior — Place cleaning cloth (from loose shipped parts)
	☐ Engine Performance: Cold start, idle	in Integrated Center Stack behind the faceplate.
nterior: □ Power mirrors (if equipped)	guality	 Interior – Set the LKA (Lane Keep Assist) button left of the steering column lower IP to the off position.
Seats, all: Check material, operation and	□ Forward Collision Alert, Front and Rear	☐ <u>Interior</u> – Remove and discard the red cap on the
that removable seats are properly secured	Parking Assist, Lane Departure Warning,	Performance Data Recorder (PDR) camera that is located in front of the rearview mirror.
Seat belts, all: material, operation, routing	Side Blind Zone Alert, Lane Change Alert,	Exterior – Verify the vehicle is equipped with a front
and latches	Rear Cross Traffic Alert, Safety Seat Alert,	splitter/spoiler. If the vehicle was ordered with RPO R6G
Displays, gauges, interior and exterior	Rear Vision Camera (if equipped)	(no splitter option) see PI1531 for instructions on how to order and install a splitter prior to delivery.
lights	☐ Front and rear HVAC system controls,	☐ <u>Trunk</u> – Place the tow eye in the upper right corner of the
Exterior:	blower(s), heater, A/C, front defroster and	molded storage bin under the trunk close out panel. Trunk – If equipped with the Y4Q (Track Performance
Doors, locks, all keys/fobs and keyless	rear defogger	Package) which includes the JIM (Battery, Low Mass)
entry system	☐ Electronic compass for function. Set to	place the Low Mass retaining brackets in the storage bin under the trunk close out panel.
Check child safety door/window locks are	correct zone and calibrate (if equipped) Regular and steering wheel controls for	 Exterior – For special care and handling instructions for
in normal (unlocked) position (if equipped)	 Regular and steering wheel controls for radio, CD, MP3, XM, RSA, RSE and NAV 	Crystal White Frost Matte-Finish Paint (RPO G7V) refer to latest TSB 15-NA-034 (if equipped).
Fit/Function removable top/panel	(if equipped)	
convertible top (if equipped)	☐ Steering wheel – center position	Final Inspection & Preparation:
Fit/function/retention of parts such as	☐ Steering for leads, pulls, vibration at idle,	Perform just prior to delivery. Interior: Remove protective coverings.
bumpers, moldings, grille, emblems, doors,	vibration while driving	Clean as required: seats, headliner, kick
deck lid, hood, fuel door and cap, tailgate,	□ Wipers, delay, RainSense and washers,	panels, carpets, console, instrument pane
liftgate and hatches, sunroof (if equipped)	front and rear (if equipped)	moldings and hard trim
Check antenna mast installation	 Brakes for noise, pulls, vibration or 	☐ Install/secure the floor mat retainers to the
Jnder Hood:	shudder at both high and low speeds	carpet side retainers (if equipped)
Remote hood release, latch and hood	☐ Unusual wind noise	☐ Check heated/cooled seats/steering whee
safety latch	☐ Unusual noise/vibration/squeak/rattle	(if equipped)
Check condition and charge 12V battery	Cruise/adaptive cruise (if equipped)	 Set NAV to correct region (if required)
using PDI Mode on the EL-50313 battery	☐ Transfer case operation, all ranges (if	 Exterior wash and dry, preferably by hand
tester/charger (Midtronics GR8). Attach	equipped)	or touchless car wash to avoid paint
print out to repair order. See TSB 03-06-	 Transmission shifter, clutch, noise, shift smoothness 	scratches; check for water leaks
03-004 for additional information.	☐ Engine performance: Hot start, idle quality	☐ Check paint finish for dents, dings, chips,
Hoses, lines, cables and wire attachments	☐ Check for MIL, SES, SVS, and any	scratches, or blemishes. Repair.
are free of kinks and clear of any	warning lights	Reset fuel economy readings
moving/hot parts ☐ Hoses, clamps, pipes, fittings, seals, and	OnStar: Verify Hot Spot (if equipped)	☐ Set clock/calendar to local time
gaskets for seepage and proper		Using a clean cloth, clean the wiper blade:
connection	☐ Verify OnStar indicator light is green	using GM Optikleen windshield washer solvent
Fluid levels: Add as required	☐ Wi-Fi® broadcast check – Press the	☐ Thoroughly clean all glass surfaces, use
•	OnStar "Voice Command" button and say	plain water on interior glass
Jnder Vehicle:	"Wi-Fi® Settings" Using the information on the screen	 Recheck tire pressures (Including spare, if
Visually inspect underbody; check all fluid	connect a device, using a Wi-Fi® enabled	equipped) and 12V battery condition
systems for leaks Brake/fuel lines secured in clips	device (e.g. smartphone), verify that you	(using EL50313 battery tester/charger PD
Diane/luci iiiles seculeu III dips	can connect to vehicle's Hot Spot	Mode)
	Note: You do not need to press the Blue OnStar button.	☐ Check Investigate Vehicle History (IVH) fo
	The Demo message will continue to play during each	required field actions. All open field action
	ignition cycle until a customer purchases the vehicle and	must be completed prior to vehicle deliver
	an Online Enrollment is submitted by the selling Dealer.	•

Service Manager (Signature) File With Repair Order 011217 r1.7 Page 1 of 1

Date