Vehicle Identification Number

Technician (Print Name)

Dealer/BAC Code

Initial Preparation:		
□ Leave door edge protection and other shipping/storage materials on until customer delivery □ Adjust tires to pressures specified on the Certification/Tire Label. Do NOT relearn the Tire Pressure Monitoring System. Record adjusted results. Temperature:°F °C Tires: LF RF LR RR Spare (if equipped) □ Install loose shipped parts and all accessories (torque as needed) Interior: □ Power mirrors (if equipped) □ Seats, all: Check material, operation and that removable seats are properly secured □ Seat belts, all: material, operation, routing and latches □ Displays, gauges, interior and exterior lights Exterior: □ Doors, locks, all keys/fobs and keyless entry system □ Check child safety door/window locks are in normal (unlocked) position (if equipped) □ Fit/Function removable top/panel convertible top (if equipped) □ Fit/function/retention of parts such as bumpers, moldings, grille, emblems, doors, deck lid, hood, fuel door and cap, tailgate, liftgate and hatches, sunroof (if equipped) □ Check antenna mast installation □ Under Hood: □ Remote hood release, latch and hood safety latch □ Check condition and charge 12V battery using PDI Mode on the EL-50313 battery tester/charger (Midtronics GR8). Attach print out to repair order. See TSB 03-06-03-004 for additional information. □ Hoses, lines, cables and wire attachments are free of kinks and clear of any moving/hot parts □ Hoses, clamps, pipes, fittings, seals, and gaskets for seepage and proper connection □ Fluid levels: Add as required	Road Test: ODOMETER: Before After Before, during and after this test, check all standard equipment, options and accessories for proper operation, as applicable. Drive on a legal roadway with road conditions permitting. Evaluate the following: Check Automatic Transmission Shift lock control Check electronic steering column lock (PEPS vehicles only) (if equipped) Remote start (if equipped) Engine Performance: Cold start, idle quality Forward Collision Alert, Front and Rear Parking Assist, Lane Departure Warning, Side Blind Zone Alert, Lane Change Alert, Rear Cross Traffic Alert, Safety Seat Alert, Rear Vision Camera (if equipped) Front and rear HVAC system controls, blower(s), heater, A/C, front defroster and rear defogger Electronic compass for function. Set to correct zone and calibrate (if equipped) Regular and steering wheel controls for radio, CD, MP3, XM, RSA, RSE and NAV (if equipped) Steering wheel – center position Steering wheel – center position Steering wheel – center position at idle, vibration while driving Wipers, delay, RainSense and washers, front and rear (if equipped) Brakes for noise, pulls, vibration or shudder at both high and low speeds Unusual wind noise Unusual wind noise Unusual vind noise Unusual vind noise Housel fequipped) Transfer case operation, all ranges (if equipped) Transfer case operation (if equipped) Check for MIL, SES, SVS, and any warning lights OnStar: Verify Hot Spot (if equipped) Verify OnStar indicator light is green Wi-Fi® broadcast check – Press the OnStar "Voice Command" button and say "Wi-Fi® Settions"	Special Inspection Items Initial Prep - Transport Mode On' may display on the DIC or the red battery light may flash. To disable the Transport Mode, refer to latest TSB 11-08-49-001. Initial Prep - Verify charge operation using 120V charge cord provided with the vehicle – verify LEDs and horn chirp – stow the 120V charge cord. Interior – Reprogram the HMI Module (Radio RPO IO5/IO6) with the latest software available. Refer to latest TSB 16-NA-042 for applicable vehicle builds. Note – Take the charge cord instructions out of package & place with the delivery information to be presented to the customer. Exterior – The door striker cover must be installed with the tabs facing outboard. Refer to SI Doc ID 3561823. Under Hood – Remove under hood protective cover on Power Inverter Module. Install the tamper bracket on coolant cap. Refer to SI DOC ID 3641559. Tip: To Install the bracket, a 10 mm swivel ratcheting box wrench can be used under the upper radiator cross bar. Final Inspection & Prep – Put the GTK booklet and Radio Guide on the front passenger seat. Final Inspection & Prep – Due to normal daily & seasonal temperature changes, tire pressures MUST be rechecked at time of delivery. Consult Tire Loading Label Recommended Cold Tire Inflation Pressure.
 Fluid levels: Add as required Under Vehicle: Visually inspect underbody; check all fluid 	OnStar "Voice Command" button and say "Wi-Fi® Settings" Using the information on the screen	using GM Optikleen windshield washer
systems for leaks Brake/fuel lines secured in clips Certification: I certify that this Pre-Delivery Insp	connect a device, using a Wi-Fi® enabled device (e.g. smartphone), verify that you can connect to vehicle's Hot Spot Note: You do not need to press the Blue OnStar button. The Demo message will continue to play during each ignition cycle until a customer purchases the vehicle and an Online Enrollment is submitted by the selling Dealer.	Recheck tire pressures (Including spare, if equipped) and 12V battery condition (using EL50313 battery tester/charger <i>PD Mode</i>) Check Investigate Vehicle History (IVH) for required field actions. All open field action must be completed prior to vehicle delivery

Service Manager (Signature)