

Vehicle Identification Number

Technician (Print Name)

Dealer/BAC Code

nitial Preparation:	Road Test:	Special Inspection Items
Leave door edge protection and other	ODOMETER:	☐ Preparation – "Transport Mode On" may display
shipping/storage materials on until	Before After	on the DIC or the red battery light may flash. To
customer delivery	Before, during and after this test, check all	turn the mode off, start the engine, activate hazard flashers, press brake pedal and turn the
Adjust tires to pressures specified on the	standard equipment, options and accessories	ignition key to the crank position for 15 seconds.
Certification/Tire Label. Do NOT relearn	for proper operation, as applicable.	□ <u>Initial Prep</u> – Ensure all GM accessories are
the Tire Pressure Monitoring System. Record adjusted results.	Drive on a legal roadway with road conditions permitting. Evaluate the following:	installed. Examples: cargo lamps, running boards, cargo hooks. Refer to accessory installation
Femperature:°F °C		manual in SI – Dual Rear Wheel Vehicles Only.
	☐ Check Automatic Transmission Shift lock	Install valve stem extensions on vehicles with
Fires: LF RF LR RR Spare (if equipped)	control  Check electronic steering column lock	Chrome Trim Skins (RPO Q9A).  Note – Vehicles built with SEO 8S3, Backup
Install loose shipped parts and all	(PEPS vehicles only) (if equipped)	Alarm. The backup alarm must be connected
accessories (torque as needed)	Remote start (if equipped)	during PDI, refer to latest PIT5386 for instructions.
nterior:	☐ Engine Performance: Cold start, idle	☐ Interior – Reprogram the HMI Module (Radio RPO IO5/IO6) with the latest software available.
Therior:  ☐ Power mirrors (if equipped)	quality	Refer to latest TSB 16-NA-042 for applicable
Seats, all: Check material, operation and	<ul> <li>Forward Collision Alert, Front and Rear</li> </ul>	vehicle builds.  □ Interior – Place cleaning cloth (from loose
that removable seats are properly secured	Parking Assist, Lane Departure Warning,	☐ <u>Interior</u> — Place cleaning cloth (from loose shipped parts) in Integrated Center Stack behind
Seat belts, all: material, operation, routing	Side Blind Zone Alert, Lane Change Alert,	the faceplate (if equipped). Otherwise, place in
and latches	Rear Cross Traffic Alert, Safety Seat Alert, Rear Vision Camera (if equipped)	glove box.
Displays, gauges, interior and exterior	☐ Front and rear HVAC system controls,	Final Inspection & Prep – Vehicles built with Duramax Diesel engines (RPOs LML/LGH) only.
lights	blower(s), heater, A/C, front defroster and	Diesel Exhaust Fluid (DEF) MUST be filled up to
Exterior:	rear defogger	2.5 gallons, at the time of Pre-Delivery Inspection.  Refer to the Duramax Diesel Owner Manual
Doors, locks, all keys/fobs and keyless	<ul> <li>Electronic compass for function. Set to</li> </ul>	supplement.
entry system	correct zone and calibrate (if equipped)	☐ Final Inspection & Prep — CNG Fuel System
<ul> <li>Check child safety door/window locks are in normal (unlocked) position (if equipped)</li> </ul>	□ Regular and steering wheel controls for	(RPO: LC8) Check operation and functionality of CNG system during road test. *DO NOT remove
☐ Fit/Function removable top/panel	radio, CD, MP3, XM, RSA, RSE and NAV	any CNG stickers or placards.
convertible top (if equipped)	<ul><li>(if equipped)</li><li>□ Steering wheel – center position</li></ul>	Final Inspection & Preparation:
Fit/function/retention of parts such as	☐ Steering wheel definer position ☐ Steering for leads, pulls, vibration at idle,	Perform just prior to delivery.
bumpers, moldings, grille, emblems, doors,	vibration while driving	☐ Interior: Remove protective coverings.
deck lid, hood, fuel door and cap, tailgate,	<ul> <li>Wipers, delay, RainSense and washers,</li> </ul>	Clean as required: seats, headliner, kick
liftgate and hatches, sunroof (if equipped)	front and rear (if equipped)	panels, carpets, console, instrument pane
Check antenna mast installation	☐ Brakes for noise, pulls, vibration or	moldings and hard trim
Jnder Hood:	shudder at both high and low speeds	☐ Install and secure the floor mat retainers to
Remote hood release, latch and hood	<ul><li>Unusual wind noise</li><li>Unusual noise/vibration/squeak/rattle</li></ul>	the carpet side retainers (if equipped)  Check heated/cooled seats/steering whee
safety latch  ☐ Check condition and charge 12V battery	☐ Cruise/adaptive cruise (if equipped)	(if equipped)
using <b>PDI Mode</b> on the EL-50313 battery	☐ Transfer case operation, all ranges (if	☐ Set NAV to correct region (if required)
tester/charger (Midtronics GR8). Attach	equipped)	<ul> <li>Exterior wash and dry, preferably by hand</li> </ul>
print out to repair order. See TSB 03-06-	<ul> <li>Transmission shifter, clutch, noise, shift</li> </ul>	or touchless car wash to avoid paint
03-004 for additional information.	smoothness	scratches; check for water leaks
Hoses, lines, cables and wire attachments	☐ Engine performance: Hot start, idle quality	☐ Check paint finish for dents, dings, chips,
are free of kinks and clear of any	☐ Check for MIL, SES, SVS, and any	scratches, or blemishes. Repair.  Reset fuel economy readings
moving/hot parts	warning lights OnStar: Verify Hot Spot (if equipped)	☐ Set clock/calendar to local time
<ul> <li>Hoses, clamps, pipes, fittings, seals, and gaskets for seepage and proper</li> </ul>		☐ Using a clean cloth, clean the wiper blade
connection	□ Verify OnStar indicator light is green	using GM Optikleen windshield washer
Fluid levels: Add as required	<ul> <li>Wi-Fi® broadcast check – Press the OnStar "Voice Command" button and say</li> </ul>	solvent
Jnder Vehicle:	"Wi-Fi® Settings"	☐ Thoroughly clean all glass surfaces, use
☐ Visually inspect underbody; check all fluid	☐ Using the information on the screen	plain water on interior glass
systems for leaks	connect a device, using a Wi-Fi® enabled	□ Recheck tire pressures (Including spare, if
☐ Brake/fuel lines secured in clips	device (e.g. smartphone), verify that you	equipped) and 12V battery condition
·	can connect to vehicle's Hot Spot	(using EL50313 battery tester/charger <b>PD Mode</b> )
	<u>Note:</u> You do not need to press the Blue OnStar button.	☐ Check Investigate Vehicle History (IVH) fo
	The Demo message will continue to play during each ignition cycle until a customer purchases the vehicle and	required field actions. All open field action
	an Online Enrollment is submitted by the selling Dealer.	must be completed prior to vehicle delivery

Service Manager (Signature)

File With Repair Order 011317 r1.7 Page 1 of 1

Date