

Vehicle Identification Number

Dealer/BAC Code

	Stock #_	
Remove wristwatches, jewelry, ce	II phones, etc., and cover belt buckles to	prevent damage to the vehicle.
Deficiencies must be called to Service Manage	ment's attention. Inspect, perform, verify proper operatio	n, assembly, fit and routing of the following.
Initial Preparation:	Road Test:	Special Inspection Items
<ul> <li>□ Leave door edge protection and other shipping/storage materials on until customer delivery</li> <li>□ Adjust tires to pressures specified on the Certification/Tire Label. Do NOT relearn the Tire Pressure Monitoring System. Record adjusted results.</li> <li>Temperature:</li></ul>	ODOMETER: Before After Before, during and after this test, check all standard equipment, options and accessories for proper operation, as applicable. Drive on a legal roadway with road conditions permitting. Evaluate the following:  Check Automatic Transmission Shift lock	□ Initial Prep – "Transport Mode On" may display on the DIC or the red battery light may flash. To turn the Mode off, start engine, activate hazard flashers, press brake pedal, and then turn the ignition key to the crank position for 15 seconds. □ Initial Prep – Ensure all GM Accessories have been installed. Examples: Cargo Lamps, Running Boards, cargo hooks. Refer to the Accessories Installation Manual in SI.
Tires: LF RF LR RR	control	□ Interior – Reprogram the HMI Module (Radio
Spare (if equipped)  Install loose shipped parts and all accessories (torque as needed)  Interior:  Power mirrors (if equipped)  Seats, all: Check material, operation and that removable seats are properly secured  Seat belts, all: material, operation, routing	<ul> <li>Check electronic steering column lock (PEPS vehicles only) (if equipped)</li> <li>Remote start (if equipped)</li> <li>Engine Performance: Cold start, idle quality</li> <li>Forward Collision Alert, Front and Rear Parking Assist, Lane Departure Warning, Side Blind Zone Alert, Lane Change Alert, Rear Cross Traffic Alert, Safety Seat Alert, Rear Vision Camera (if equipped)</li> </ul>	RPO IO5/IO6) with the latest software available. Refer to latest TSB 16-NA-042 for applicable vehicle builds.  Interior — Set NAV radio to the correct region. NAV Map data is loaded into internal memory hard disc drive from factory (if equipped).  Interior — Place cleaning cloth (from loose shipped parts) in Integrated Center Stack behind the faceplate (if equipped). Otherwise, place in glove box.  Note — Vehicles in dealer inventory need to be
and latches  □ Displays, gauges, interior and exterior lights	□ Front and rear HVAC system controls,	properly maintained for a quality delivery. Refer
	blower(s), heater, A/C, front defroster and	to latest TSB 09-00-89-002.
Exterior:  Doors, locks, all keys/fobs and keyless entry system  Check child safety door/window locks are in normal (unlocked) position (if equipped)  Fit/Function removable top/panel	rear defogger  Electronic compass for function. Set to correct zone and calibrate (if equipped)  Regular and steering wheel controls for radio, CD, MP3, XM, RSA, RSE and NAV (if equipped)	<ul> <li><u>Exterior</u> – Check operation of power-retractable running side board (if equipped).</li> <li><u>Final Inspection &amp; Prep</u> – Due to normal daily &amp; seasonal temperature changes, tire pressures MUST be rechecked at time of delivery. Consult Tire Loading Label Recommended Cold Tire Inflation Pressure.</li> </ul>
convertible top (if equipped)  Fit/function/retention of parts such as	Steering wheel – center position Steering for leads, pulls, vibration at idla.	Final Inspection & Preparation:
bumpers, moldings, grille, emblems, doors, deck lid, hood, fuel door and cap, tailgate, liftgate and hatches, sunroof (if equipped)  Check antenna mast installation	<ul> <li>Steering for leads, pulls, vibration at idle, vibration while driving</li> <li>Wipers, delay, RainSense and washers, front and rear (if equipped)</li> <li>Brakes for noise, pulls, vibration or shudder</li> </ul>	Perform just prior to delivery.  Interior: Remove protective coverings. Clean as required: seats, headliner, kick panels, carpets, console, instrument panel, moldings
☐ Check operation of power-retractable running	at both high and low speeds  Unusual wind noise	and hard trim  ☐ Install and secure the floor mat retainers to
side board (if equipped)  Under Hood:  Remote hood release, latch and hood safety latch	<ul> <li>Unusual noise/vibration/squeak/rattle</li> <li>Cruise/adaptive cruise (if equipped)</li> <li>Transfer case operation, all ranges (if equipped)</li> </ul>	the carpet side retainers (if equipped)  Check heated/cooled seats/steering wheel (if equipped)  Set NAV to correct region (if required)
□ Check condition and charge 12V battery using <i>PDI Mode</i> on the EL-50313 battery tester/charger (Midtronics GR8). Attach print out to repair order. See TSB 03-06-03-004	<ul> <li>Transmission shifter, clutch, noise, shift smoothness</li> <li>Engine performance: Hot start, idle quality</li> </ul>	<ul> <li>Exterior wash and dry, preferably by hand or touchless car wash to avoid paint scratches; check for water leaks</li> <li>Check paint finish for dents, dings, chips,</li> </ul>
for additional information.  Hoses, lines, cables and wire attachments are free of kinks and clear of any moving/hot	<ul> <li>Check for MIL, SES, SVS, and any warning lights</li> <li>Verify AutoStop/Start operation during Road Test</li> </ul>	scratches, or blemishes. Repair.  Reset fuel economy readings Set clock/calendar to local time
parts  Hoses, clamps, pipes, fittings, seals, and	OnStar: Verify Hot Spot (if equipped)	<ul> <li>Using a clean cloth, clean the wiper blades using GM Optikleen windshield washer</li> </ul>
gaskets for seepage and proper connection  Fluid levels: Add as required	<ul> <li>Verify OnStar indicator light is green</li> <li>Wi-Fi® broadcast check – Press the OnStar</li> <li>"Voice Command" button and say "Wi-Fi®</li> </ul>	solvent  Thoroughly clean all glass surfaces, use plain water on interior glass
<ul><li>Under Vehicle:</li><li>□ Visually inspect underbody; check all fluid systems for leaks</li></ul>	Settings"  Using the information on the screen connect	Recheck tire pressures (Including spare, if equipped) and 12V battery condition (using
□ Brake/fuel lines secured in clips	a device, using a Wi-Fi® enabled device (e.g. smartphone), verify that you can connect to vehicle's Hot Spot <u>Mote:</u> You do not need to press the Blue OnStar button.  The Demo message will continue to play during each ignition cycle until a customer purchases the vehicle and an Online Enrollment is submitted by the selling Dealer.	EL50313 battery tester/charger <b>PDI Mode</b> )  Check Investigate Vehicle History (IVH) for required field actions. All open field actions must be completed prior to vehicle delivery

Certification: I certify that this Pre-L	Delivery Inspection has been completed by:	
Technician (Print Name)	Service Manager (Signature)	Date
	File With Repair Order	011317 r1.5