

2017 XTS

Pre-Delivery Inspection Form

Vehicle Identification Number

Dealer/BAC Code

Remove wristwatches, jewelry, cell phones, etc., and cover belt buckles to prevent damage to the vehicle. Deficiencies must be called to Service Management's attention. Inspect, perform, verify proper operation, assembly, fit and routing of the following.

Stock #_

Repair Order #_

Initial Preparation:	Road Test:	Special Inspection Items
 Leave door edge protection and other 	ODOMETER:	☐ <u>Initial Preparation</u> – 'Transport Mode On'
shipping/storage materials on until	Before After	may display on the DIC or the red battery
customer delivery	Before, during and after this test, check all	light may flash. To turn the Mode Off, start
□ Adjust tires to pressures specified on the	standard equipment, options and accessories	engine, activate hazard flashers, press
Certification/Tire Label. Do NOT relearn	for proper operation, as applicable.	brake pedal, then press & hold the Start/Stop button or turn the ignition key to
the Tire Pressure Monitoring System.	Drive on a legal roadway with road conditions	the crank position for 15 seconds.
Record adjusted results.	permitting. Evaluate the following:	□ Interior − Place cleaning cloth (from loose
Temperature:°F °C	☐ Check Automatic Transmission Shift lock	shipped parts) in Integrated Center Stack
Tires: LF RF LR RR	control	behind the faceplate (if equipped).
Spare (if equipped)	 Check electronic steering column lock 	Otherwise, place in glove box.
☐ Install loose shipped parts and all	(PEPS vehicles only) (if equipped)	 Road Test – Verify operation of all the ESS 1 & ESS 2 Safety features (if equipped).
accessories (torque as needed)	□ Remote start (if equipped)	Final Inspection & Prep – Use a non-
Interior:	□ Engine Performance: Cold start, idle	alkaline solution for washing the Bright
□ Power mirrors (if equipped)	quality	Aluminum Moldings. Do Not wash the
☐ Seats, all: Check material, operation and	 Forward Collision Alert, Front and Rear 	vehicle until latest bulletin PIC5779 has
that removable seats are properly secured	Parking Assist, Lane Departure Warning,	been reviewed.
☐ Seat belts, all: material, operation, routing	Side Blind Zone Alert, Lane Change Alert,	☐ Final Inspection & Prep — Due to normal
and latches	Rear Cross Traffic Alert, Safety Seat Alert,	daily & seasonal temperature changes, tire pressures MUST be rechecked at time of
☐ Displays, gauges, interior and exterior	Rear Vision Camera (if equipped)	delivery. Consult Tire Loading Label
lights	 Front and rear HVAC system controls, 	Recommended Cold Tire Inflation Pressure.
	blower(s), heater, A/C, front defroster and	
Exterior:	rear defogger	Final Inspection & Preparation:
□ Doors, locks, all keys/fobs and keyless	☐ Electronic compass for function. Set to	Perform just prior to delivery. Interior: Remove protective coverings.
entry systemCheck child safety door/window locks are	correct zone and calibrate (if equipped)	Clean as required: seats, headliner, kick
in normal (unlocked) position (if equipped)	□ Regular and steering wheel controls for	panels, carpets, console, instrument pane
☐ Fit/Function removable top/panel	radio, 62, 111 0, 7111, 11671, 1162 and 1771	moldings and hard trim
convertible top (if equipped)	(if equipped)	☐ Install and secure the floor mat retainers to
☐ Fit/function/retention of parts such as	☐ Steering wheel – center position	the carpet side retainers (if equipped)
bumpers, moldings, grille, emblems, doors	☐ Steering for leads, pulls, vibration at idle,	☐ Check heated/cooled seats/steering wheel
deck lid, hood, fuel door and cap, tailgate,	vibration while drivingWipers, delay, RainSense and washers,	(if equipped)
liftgate and hatches, sunroof (if equipped)		☐ Set NAV to correct region (if required)
□ Check antenna mast installation	front and rear (if equipped) Brakes for noise, pulls, vibration or	☐ Exterior wash and dry. Check for water
	shudder at both high and low speeds	leaks
Under Hood:	☐ Unusual wind noise	□ Check paint finish for dents, dings, chips,
Remote hood release, latch and hood	☐ Unusual noise/vibration/squeak/rattle	scratches, or blemishes. Repair.
safety latch Check condition and charge 12V battery	☐ Cruise/adaptive cruise (if equipped)	□ Reset fuel economy readings
using PDI Mode on the EL-50313 battery	☐ Transfer case operation, all ranges (if	 Set clock/calendar to local time
tester/charger (Midtronics GR8). Attach	equipped)	 Using a clean cloth, clean the wiper blades
print out to repair order. See TSB 03-06-	☐ Transmission shifter, clutch, noise, shift	using GM Optikleen windshield washer
03-004 for additional information.	smoothness	fluid, if necessary
☐ Hoses, lines, cables and wire attachments		 Thoroughly clean all glass surfaces, use
are free of kinks and clear of any	☐ Check for MIL, SES, SVS, and any	plain water on interior glass
moving/hot parts	warning lights	 Recheck tire pressures (Including spare, if
☐ Hoses, clamps, pipes, fittings, seals, and	OnStar: Verify Hot Spot (if equipped)	equipped) and 12V battery condition
gaskets for seepage and proper	□ Verify OnStar indicator light is green	(using EL50313 battery tester/charger PDI
connection	□ Wi-Fi® broadcast check – Press the	Mode)
☐ Fluid levels: Add as required	OnStar "Voice Command" button and say	☐ Check Investigate Vehicle History (IVH) for
·	"Wi-Fi® Settings"	required field actions. All open field actions
<u>Under Vehicle:</u>□ Visually inspect underbody; check all fluid	☐ Using the information on the screen	must be completed prior to vehicle delivery
systems for leaks	connect a device, using a Wi-Fi® enabled	
□ Brake/fuel lines secured in clips	device (e.g. smartphone), verify that you	
brake/ruer lines secured in clips	can connect to vehicle's Hot Spot	
	Note: You do not need to press the Blue OnStar button.	
	The Demo message will continue to play during each	
	ignition cycle until a customer purchases the vehicle and	
	an Online Enrollment is submitted by the selling Dealer.	
Certification: I certify that this Pre-Delivery In	spection has been completed by:	
Technician (Print Name)	Service Manager (Signature)	 Date
redinician (i init ivanie)		
	File With Repair Order	042517 r1.4 Page 1 of 1