

Vehicle Identification Number

Dealer/BAC Code

Remove wristwatches, jewelry, cel	ے# Stock Il phones, etc., and cover belt buckles to	Repair Order # o prevent damage to the vehicle.
	ment's attention. Inspect, perform, verify proper operation	
Initial Preparation: □ Leave door edge protection and other shipping/storage materials on until customer delivery □ Adjust tires to pressures specified on the Certification/Tire Label. Do NOT relearn the Tire Pressure Monitoring System. Record adjusted results. Temperature:°F °C	Road Test: ODOMETER: Before After Before, during and after this test, check all standard equipment, options and accessories for proper operation, as applicable. Drive on a legal roadway with road conditions permitting. Evaluate the following: Check Automatic Transmission Shift lock	Special Inspection Items Preparation - "Transport Mode On" may display on the DIC or the red battery light may flash. To turn the mode off, start the engine, activate hazard flashers, press brake pedal and turn the ignition key to the crank position for 15 seconds. Initial Preparation - Ensure all GM Accessories have been installed. Examples: Cargo Lamps, Running Boards, cargo hooks. Refer to the Accessories Installation Manual in
Tires: LF RF LR RR Spare (if equipped) Install loose shipped parts and all accessories (torque as needed) Interior:	control Check electronic steering column lock (PEPS vehicles only) (if equipped) Remote start (if equipped) Engine Performance: Cold start, idle quality Forward Collision Alert, Front and Rear Parking Assist, Lane Departure Warning, Side Blind Zone Alert, Lane Change Alert, Rear Cross Traffic Alert, Safety Seat Alert, Rear Vision Camera (if equipped) Front and rear HVAC system controls, blower(s), heater, A/C, front defroster and rear defogger Electronic compass for function. Set to correct zone and calibrate (if equipped) Regular and steering wheel controls for radio, CD, MP3, XM, RSA, RSE and NAV (if equipped) Steering wheel – center position Steering for leads, pulls, vibration at idle, vibration while driving Wipers, delay, RainSense and washers, front and rear (if equipped) Brakes for noise, pulls, vibration or shudder at both high and low speeds Unusual wind noise Unusual noise/vibration/squeak/rattle Cruise/adaptive cruise (if equipped) Transfer case operation, all ranges (if equipped) Transfer case operation, all ranges (if equipped) Transmission shifter, clutch, noise, shift smoothness Engine performance: Hot start, idle quality Check for MIL, SES, SVS, and any warning lights OnStar: Verify Hot Spot (if equipped) Verify OnStar indicator light is green Wi-Fi® broadcast check – Press the OnStar "Voice Command" button and say "Wi-Fi® Settings" Using the information on the screen	SI. Interior - Set NAV radio to the correct region. NAV Map data is loaded into internal memory hard disc drive from factory (if equipped). Note - Vehicles in dealer inventory need to be properly maintained for a quality delivery. Refer to latest TSB 09-00-89-002. Final Inspection & Prep - Due to normal daily & seasonal temperature changes, tire pressures MUST be rechecked at time of delivery. Consult Tire Loading Label Recommended Cold Tire Inflation Pressure. Final Inspection & Prep - Vehicles built with Duramax Diesel engine (RPOs LWN) only. Diesel Exhaust Fluid (DEF) MUST be filled at the time of Pre-Delivery Inspection up to 2.5 gallons. Refer to the Duramax Diesel Owner Manual supplement. Final Inspection & Preparation: Perform just prior to delivery. Interior: Remove protective coverings. Clean as required: seats, headliner, kick panels, carpets, console, instrument pane moldings and hard trim Install and secure the floor mat retainers the carpet side retainers (if equipped) Check heated/cooled seats/steering whee (if equipped) Set NAV to correct region (if required) Exterior wash and dry. Check for water leaks Check paint finish for dents, dings, chips, scratches, or blemishes. Repair. Reset fuel economy readings Set clock/calendar to local time Using a clean cloth, clean the wiper blade using GM Optikleen windshield washer fluid, if necessary Thoroughly clean all glass surfaces, use plain water on interior glass Recheck tire pressures (Including spare, if equipped) and 12V battery condition (using EL50313 battery tester/charger PD Mode) Check Investigate Vehicle History (IVH) for the condition (using EL50313 battery tester/charger PD Mode) Check Investigate Vehicle History (IVH) for the condition (Using EL50313 battery tester/charger PD Mode) Check Investigate Vehicle History (IVH) for the condition (Using EL50313 battery tester/charger PD Mode)
systems for leaks Brake/fuel lines secured in clips	connect a device, using a Wi-Fi® enabled device (e.g. smartphone), verify that you can connect to vehicle's Hot Spot Note: You do not need to press the Blue OnStar button. The Demo message will continue to play during each ignition cycle until a customer purchases the vehicle and an Online Enrollment is submitted by the selling Dealer	required field actions. All open field action must be completed prior to vehicle deliver

Certification: I certify that this Pre-Delivery Inspection has been completed by:

Technician (Print Name)

Service Manager (Signature)

File With Repair Order

042517 r1.4