

Vehicle Identification Number

Dealer/BAC Code

		Repair Order #
Remove wristwatches, jewelry, cell phones, etc., and cover belt buckles to prevent damage to the vehicle.  Deficiencies must be called to Service Management's attention. Inspect, perform, verify proper operation, assembly, fit and routing of the following.		
•		
Initial Preparation:	Road Test: ODOMETER:	Special Inspection Items  "Transport Made Or" required and a control of the second sec
□ Leave door edge protection and other shipping/storage materials on until customer	Before After	<ul> <li>Initial Prep – "Transport Mode On" may display on the DIC or the red battery light may flash. To turn the Mode off, start engine, activate hazard</li> </ul>
delivery	Before, during and after this test, check all	flashers, press brake pedal, and then turn the
<ul> <li>Adjust tires to pressures specified on the Certification/Tire Label. Do NOT relearn the</li> </ul>	standard equipment, options and accessories for proper operation, as applicable.	ignition key to the crank position for 15 seconds.
Tire Pressure Monitoring System. Record	Drive on a legal roadway with road conditions	□ <u>Initial Prep</u> – Ensure all GM Accessories have
adjusted results.	permitting. Evaluate the following:	been installed. Examples: Cargo Lamps,
Temperature:°F °C	, ,	Running Boards, cargo hooks. Refer to the Accessories Installation Manual in SI.
Tires: LF	<ul> <li>Check Automatic Transmission Shift lock control</li> </ul>	<ul> <li>Interior – Set NAV radio to the correct region.</li> </ul>
Spare (if equipped)	☐ Check electronic steering column lock (PEPS	NAV Map data is loaded into internal memory
☐ Install loose shipped parts and all	vehicles only) (if equipped)	hard disc drive from factory (if equipped).
accessories (torque as needed)	□ Remote start (if equipped)	<ul> <li>Interior – Place cleaning cloth (from loose shipped parts) in Integrated Center Stack behind</li> </ul>
	☐ Engine Performance: Cold start, idle quality	the faceplate (if equipped). Otherwise, place in
Interior:	□ Forward Collision Alert, Front and Rear	glove box.
<ul><li>Power mirrors (if equipped)</li><li>Seats, all: Check material, operation and that</li></ul>	Parking Assist, Lane Departure Warning,	□ <u>Note</u> – Vehicles in dealer inventory need to be
removable seats are properly secured	Side Blind Zone Alert, Lane Change Alert,	properly maintained for a quality delivery. Refer to latest TSB 09-00-89-002.
☐ Seat belts, all: material, operation, routing	Rear Cross Traffic Alert, Safety Seat Alert,	<ul> <li><u>Exterior</u> – Check operation of power-retractable</li> </ul>
and latches	Rear Vision Camera (if equipped)	running side board (if equipped).
☐ Displays, gauges, interior and exterior lights	☐ Front and rear HVAC system controls,	☐ Final Inspection & Prep — Due to normal daily
Exterior:	blower(s), heater, A/C, front defroster and	& seasonal temperature changes, tire pressures
□ Doors, locks, all keys/fobs and keyless entry	rear defogger	MUST be rechecked at time of delivery. Consult Tire Loading Label Recommended Cold Tire
system	<ul> <li>Electronic compass for function. Set to correct zone and calibrate (if equipped)</li> </ul>	Inflation Pressure.
☐ Check child safety door/window locks are in	Regular and steering wheel controls for radio,	Final Inquestion 9 Decreasion.
normal (unlocked) position (if equipped)	CD, MP3, XM, RSA, RSE and NAV (if	Final Inspection & Preparation:  Perform just prior to delivery.
□ Fit/Function removable top/panel	equipped)	<ul> <li>Interior: Remove protective coverings. Clear</li> </ul>
convertible top (if equipped)	☐ Steering wheel – center position	as required: seats, headliner, kick panels,
☐ Fit/function/retention of parts such as	<ul> <li>Steering for leads, pulls, vibration at idle,</li> </ul>	carpets, console, instrument panel, moldings
bumpers, moldings, grille, emblems, doors,	vibration while driving	and hard trim
deck lid, hood, fuel door and cap, tailgate,	□ Wipers, delay, RainSense and washers, front	□ Secure floor mat retainers to the carpet side
liftgate and hatches, sunroof (if equipped)	and rear (if equipped)	retainers (if equipped). Do Not stack mats.
☐ Check antenna mast installation	□ Brakes for noise, pulls, vibration or shudder	See warning in TSB 10-08-110-001.
☐ Check operation of power-retractable running	at both high and low speeds	<ul> <li>Check heated/cooled seats/steering wheel (</li> </ul>
side board (if equipped)	☐ Unusual wind noise	equipped)
Under Hood:	<ul> <li>Unusual noise/vibration/squeak/rattle</li> <li>Cruise/adaptive cruise (if equipped)</li> </ul>	☐ Set NAV to correct region (if required)
Remote hood release, latch and hood safety	<ul> <li>Cruise/adaptive cruise (if equipped)</li> <li>Transfer case operation, all ranges (if</li> </ul>	<ul> <li>Exterior wash and dry. Check for water</li> </ul>
latch	equipped)	leaks  ☐ Check paint finish for dents, dings, chips,
□ Check condition and charge 12V battery	☐ Transmission shifter, clutch, noise, shift	scratches, or blemishes. Repair.
using <b>PDI Mode</b> on the EL-50313 battery	smoothness	Reset fuel economy readings
tester/charger (Midtronics GR8). Attach print	<ul> <li>Engine performance: Hot start, idle quality</li> </ul>	☐ Set clock/calendar to local time
out to repair order. See TSB 03-06-03-004	☐ Check for MIL, SES, SVS, and any warning	☐ Using a clean cloth, clean the wiper blades
for additional information.	lights	using GM Optikleen windshield washer
Hoses, lines, cables and wire attachments	<ul> <li>Verify AutoStop/Start operation during Road</li> </ul>	fluid, if necessary
are free of kinks and clear of any moving/hot parts	Test	<ul> <li>Thoroughly clean all glass surfaces, use</li> </ul>
☐ Hoses, clamps, pipes, fittings, seals, and	OnStar: Verify Hot Spot (if equipped)	plain water on interior glass
gaskets for seepage and proper connection	<ul> <li>Verify OnStar indicator light is green</li> </ul>	□ Recheck tire pressures (Including spare, if
☐ Fluid levels: Add as required	□ Wi-Fi® broadcast check – Press the OnStar	equipped) and 12V battery condition (using
·	"Voice Command" button and say "Wi-Fi®	EL50313 battery tester/charger <b>PDI Mode</b> )
<ul><li>Under Vehicle:</li><li>□ Visually inspect underbody; check all fluid</li></ul>	Settings"	☐ Check Investigate Vehicle History (IVH) for
<ul> <li>Visually inspect underbody; check all fluid systems for leaks</li> </ul>	☐ Using the information on the screen connect	required field actions (open recall campaign service update bulletins, systems software
□ Brake/fuel lines secured in clips	a device, using a Wi-Fi® enabled device (e.g.	updates
	smartphone), verify that you can connect to	αρααιοσ
	vehicle's Hot Spot <u>Note:</u> You do not need to press the Blue OnStar button.	
	The Demo message will continue to play during each ignition cycle until	

Certification: I certify that this Pre-Delivery Inspection has been completed by:

Technician (Print Name)

Service Manager (Signature)

Date

submitted by the selling Dealer.

a customer purchases the vehicle and an Online Enrollment is

File With Repair Order

ler 052417 r1.6