

gaskets for seepage and proper retention

Certification: I certify that this Pre-Delivery Inspection has been completed by:

□ Fluid levels: Add as required

## 2018 ATS-V Coupe **Pre-Delivery Inspection Form**

Vehicle Identification Number	Dealer/BAC Code	
	Stock #	Repair Order #
Remove wristwatches, jewelry, ce	II phones, etc., and cover belt buckles to	
	ment's attention. Inspect, perform, verify proper operation	
Initial Preparation:	Under Vehicle:	Suspension – Remove the Transit Blocks from the
Leave door edge protection and other	□ Visually inspect underbody; check all fluid	□ Suspension – Remove the Transit Blocks from the front springs & place them in the molded storage tray
shipping/storage materials on until	systems for leaks	with the tow eye hook. Remove the Transit Block
customer delivery	☐ Brake/fuel lines secured in clips	sticker from the windshield.  Interior – If equipped with Adaptive Froward Lighting
Adjust tires to pressures specified on the	Road Test: ODOMETER:	RPO T4F access personalization menu for vehicle
Certification/Tire Label. Do NOT relearn		settings/lighting and enable this feature.  Interior – Slowly remove the protective film from the
the Tire Pressure Monitoring System.	Before After	☐ Interior — Slowly remove the protective film from the Bose speakers, to avoid damaging the speaker grille
Record adjusted results. <b>Temperature:</b> °F °C	Before, during and after this test, check all	or emblem.
<u> </u>	standard equipment, options and accessories	☐ Interior — Confirm the operation of the USB ports in the center console and in the ICS by connecting a cell
Tires: LF RF LR RR	for proper operation, as applicable.  Drive on a legal roadway with road conditions	phone and confirming that the phone will charge with
□ Spare (if equipped)	permitting. Evaluate the following:	ignition on.    Interior – Place cleaning cloth (from loose shipped
<ul> <li>Install loose shipped parts and all</li> </ul>		parts) in Integrated Center Stack behind the faceplate.
accessories (torque as needed)	<ul> <li>Check Automatic Transmission Shift lock</li> </ul>	□ <u>Interior</u> – Set the LKA (Lane Keep Assist) button left
Interior:	control and shifter operation	of the steering column lower IP to the off position.  Interior – Remove and discard the red cap on the
□ Power mirrors (if equipped)	□ Check electronic steering column lock	Performance Data Recorder (PDR) camera that is
□ Seats, all: Check material and operation of	(PEPS vehicles only) (if equipped)	located in front of the rearview mirror.  Infotainment – Press the User icon on the CUE home
all features	Remote start (if equipped)	screen and sign in as a Guest. Connect a smart
☐ Check that removable seats are properly	☐ Engine Performance: Cold start, idle	phone via USB and verify you can make a phone call
secured	quality	and listen to music.  Infotainment – If vehicle has RPO IOT (Navigation),
☐ Check all accessory power outlets and AC	□ Safety Systems:Front and Rear Parking	ensure that the Nav SD card that is located beneath
inverter (if equipped)	Assist, Lane Departure Warning, Side	the USB hub in the armrest console is inserted correctly and is functional.
☐ Seat belts, all: material, operation, routing	Blind Zone Alert, Lane Change Alert, Rear	□ <u>Infotainment</u> – Go to the Collection icon on the CUE
and latches	Cross Traffic Alert, Safety Alert Seat,	screen, Verify that there are apps available to
☐ Displays, gauges, interior and exterior	Camera Vision Systems (if equipped)	download.  Exterior – Verify the vehicle is equipped with a front
lights	☐ Electronic compass for function.	splitter/spoiler. If the vehicle was ordered with RPO
Center stack and steering wheel controls	Steering wheel – center position Steering for leade, pulls, vibration at idla.	R6G (no splitter option) see PI1531for instructions on how to order and install a splitter prior to delivery.
for infotainment/ radio and NAV (if	Steering for leads, pulls, vibration at idle,  vibration while driving.	☐ Trunk – Place the tow eye roadside fuel funnel in the
equipped)  HVAC system controls, blower, heater,	vibration while driving  Wipers, delay, RainSense and washers,	upper right corner of the molded storage bin under the trunk close out panel.
A/C, defroster and rear defogger	front and rear (if equipped)	☐ Trunk - If equipped with the Y4Q (Track Performance
□ Rear HVAC Control function (if equipped)	☐ Brakes for noise, pulls, vibration or shudder	Package) which includes the JIM (Battery, Low Mass)
□ Check heated/cooled seats/steering wheel	at both high and low speeds	place the Low Mass retaining brackets in the storage bin under the trunk close out panel.
(if equipped)	☐ Unusual wind noise	Final Inspection & Preparation:
Exterior:	☐ Unusual noise/vibration/squeak/rattle	Perform just prior to delivery.
□ Doors, locks, all keys/fobs and keyless	☐ Cruise/adaptive cruise (if equipped)	□ Interior: Remove protective coverings.
entry system	☐ Transfer case operation, all ranges (if	Clean as required: seats, headliner, kick
☐ Check child safety door/window locks are	equipped)	panels, carpets, console, instrument panel
in normal (unlocked) position	☐ Manual Transmission shifter, clutch, noise,	moldings and hard trim
☐ Fit/Function removable top/panel	shift smoothness	<ul> <li>Install and secure the floor mat retainers to</li> </ul>
convertible top (if equipped)	<ul> <li>Automatic Transmission shift performance</li> </ul>	the carpet side retainers (if equipped)
☐ Fit/function/retention of parts such as	Automatic Park Assist for operation (if	<ul> <li>Exterior wash and dry. Check for water</li> </ul>
bumpers, moldings, grille, emblems, doors,	equipped)	leaks
deck lid, hood, fuel door and cap, tailgate,	☐ Engine performance: Hot start, idle quality	☐ Check paint finish for dents, dings, chips,
liftgate and hatches, sunroof (if equipped)	☐ Check for warning lights and messages	scratches, or blemishes.
□ Check antenna mast installation	OnStar:	<ul> <li>Reset fuel economy readings</li> </ul>
<u>Under Hood</u> :	<ul> <li>Verify OnStar indicator light is green</li> </ul>	<ul> <li>Set clock/calendar to local time</li> </ul>
☐ Remote hood release, latch and hood	☐ Connect a Wi-Fi® enabled device (e.g.	<ul> <li>Using a clean cloth, clean the wiper blades</li> </ul>
safety latch	smartphone) to the vehicle and verify that	using GM Optikleen windshield washer
☐ Check condition and charge 12V battery	you can connect to vehicle's Hot Spot. If	fluid, if necessary
using PDI Mode on the EL-50313 battery	you can't connect to the Hot Spot, refer to	☐ Thoroughly clean all glass surfaces, use
tester/charger (Midtronics GR8). Attach	the latest version of TSB 16-NA-239 for	plain water on interior glass
print out to repair order. See TSB 03-06-	steps to enable it.	□ Recheck tire pressures (Including spare, if
03-004 for additional information.	Note: The Demo message will continue to play during each	equipped) and 12V battery condition
☐ Hoses, lines, cables and wire attachments	ignition cycle until a customer purchases the vehicle and	(using EL50313 battery tester/charger PDI
are free of kinks and clear of any	an Online Enrollment is submitted by the selling Dealer.	Mode)
moving/hot parts		□ Check Investigate Vehicle History (IVH) for
☐ Hoses, clamps, pipes, fittings, seals, and		required field actions. All open field actions

Technician (Print Name) Service Manager (Signature) Date

must be completed prior to vehicle delivery

Page 1 of 1