

07_GRP04_All Engines.xls

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumin.	Special Prep
Catalytic Converter Monitoring	P0420	Front vs. Rear O2 sensor signal	Evaluated data 1,75 times FTP std	65 (unitless)	Coolant temp Throttle Delta load, positive Delta load, negative Engine speed, man. trans Engine speed, aut. trans Load Time after engine start Fuel control Catalyst temperature Front O2 sensor duty cycle Rear O2 sensor signal	>70°C Open < 200 mg/combustion/s < - 100 mg/combustion/s 1270 - 2800 rpm 1200 - 2800 rpm 140 - 400 mg/combustion >200 s Closed loop >350 C, calculated 35-65% Not below 550 mV for over 650 ms	20 s accumulated Once / DCY	Statistical treatment, up to 6 DCY, after that: Immediately	
Synchronization error	P0340	Rationality	Ignition	Not synchronized	Engine speed Revolutions Extra enablement delay when ECT or IAT is below -10°C at engine starting Battery voltage	Running >500 after start phase 500 revolutions > 10,0 V	1 sec Once / DCY	Two DCY	
Misfire Emissions	P0300 to P0304	Ion current detection. At idle: combination of ion current and crankshaft speed evaluation.	Misfire counter 1000 revs.	> 3,0 %	Engine speed Load change transient MAP Load EVAP test, disablement at purge valve activation and deactivator No fuel cut off Battery voltage Enabling delay when ECT is below -7C at engine starting	< redline rpm > ± 5,0 kPa/combustion, trig + 10 – 25 revolutions > 0 and not in disable region above 3000 rpm & low load At purge valve activation status change + 10 revolutions At fuel cut and for 10 revolutions after fueling re-start > 10,0 V Delayed until ECT > 21 °C	1000 revolutions Continuous	Two DCY	
		Special case in hot fuel conditions	Count 70% of detected misfires before evaluating vs. fault limit. Applies only to first 1000 revs.		ECT at engine shut off ECT at engine starting IAT at engine starting	> 110 °C > 110 °C > 70 °C			
Misfire Catalyst Temperature	P1300 to P1304	Same as above	Misfire counter 200 revolutions	See separate map	Same as above	Same as above	200 revolutions	Two DCY / MIL blink	
Misfire Catalyst temperature at low fuel conditions	P1390 to P1394	Same as above	Same as above	Same as above	Same as above + Fuel level	Same as above + < 5% (4 liters)	Same as above Continuous	Same as above	
Detect signals	P1312 P1334	Detect 1-2 missing Detect 3-4 missing	Detect signal	High	Engine speed Battery voltage	Running > 10,0 V	200 combustions Continuous	Two DCY	
Knock signal	P0327	Knock signal low	Knock signal	< 250 mV	Engine speed Voltage No ignition cut in throttle limp-home	> 800 rpm > 11,0 V	25 combustions Continuous	Two DCY	
0,5 mm leak check									
EVAP Canister Vent Valve	P1444 P1445	Circuit continuity check	Short-cut gnd or not connected	0V	Engine speed Battery voltage Purge	Running > 10,0 V Not active	1 sec, Continuous At engine start	Two DCY	
EVAP leak test						Enable Disable			

07_GRP04_All Engines.xls

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumin.	Special Prep	
					Purge HC Δ vs. start Lambda integrator Δ vs. start Ambient pressure Δ Fuel tank pressure Ramp 0 vapor generation Variation between parts in decay measurement	- -< 25% -> -12% -<10kPa/3 min -> -2000 Pa -< 8 Pa/s -				
EVAP large leak > 3 mm	P0455	Rationality check	Pressure does not reach specified level in specified time. See separate document	Leakage factor > 1000				Two DCY		
	P1455	When fuel level info is incorrect								
EVAP small leak 1 mm < X < 3 mm	P0442	Rationality check	Pressure gradient check. See separate document	Leakage factor 4				Two DCY		
	P1442	When fuel level info is incorrect								
EVAP very small leak 0,5 < X < 1 mm	P0456	Rationality check	Pressure gradient check. See separate document	Leakage factor 1, 2, 3				Up to eight DCY		
	P1456	When fuel level info is incorrect								
EVAP pressure sensor	P0452	Low end check	Min failure or not connected	< 300 mV	Ignition on	>2 sec	5 sec	Two DCY		
	P0453	High end check	Max failure	> 4950 mV	Engine speed	Running	Continuous			
	P1451	Rationality	Max amplitude & no. of shifts	>40Pa & >20	Engine speed	Idle	3,5 sec	Two DCY		
	P1491	When fuel level info is incorrect			Vehicle speed	0 mph			Once / DCY	
					Brake status changes Tank pressure readings Fuel level ECT & IAT No DTC set	Max one Unfiltered, unadapted 0 - 85%, if fuel level info OK > +5°C Fuel tank pressure sensor circuit Canister vent valve Purge valve Brake light switch				
	P1452	Sensor Offset	Min failure	Adaption value < -1000 Pa	Engine speed	Running	Ignition on + 10s	Two DCY		
	P1492	When fuel level info is incorrect			Fuel tank pressure sensor adaption	Done	Once / DCY			
	P1453	Sensor Offset	Max failure	Adaption value >1000 Pa	Same as above	Same as above	Ignition on + 10s	Two DCY		
	P1493	When fuel level info is incorrect					Once / DCY			
Fuel tank pressure adaption					Ambient pressure Vehicle speed Engine speed ECT Fuel tank volume	75 - 106 kPa 0 0 -10°C < X < + 40°C 0 < X < 69% (50 liters)				
EVAP Purge Valve	P0441	Valve leaking	Tank pressure drop when valve is commanded close	> 40 Pa/sec	Vehicle speed	0	3 sec	Two DCY		
	P1441	When fuel level info is incorrect			Fuel volume	15 - 85 %	Once / DCY			
					Engine speed IAT & ECT at engine start	Running +5 - +40 °C				

07_GRP04_All Engines.xls

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumin.	Special Prep
					Battery voltage MAP	10 - 16 Volts < - 20 kPa			
	P0444	Circuit continuity check	Short-cut gnd or not connected	0V	Engine speed	Running	60 sec	Two DCY	
	P0445		Short-cut Ubatt	12V	Battery voltage	> 10,0 V	Continuous		
Fuel level	No code	Min signal			Engine speed	Running		No MIL, will set alternate DTC for EVAP rationalities. Will also set fuel volume to default 69% (50 liters)	
		Max signal			Engine speed	Running			
		No activity	Fuel level info change	< 0,3 liters	Engine speed	Running	15,5 miles		
		Rationality	Fuel level change	Fuel consumption less than 0.3 l in 20 miles. Five checks done for fault setting. Results saved in buffer, also between DCY:s.	Reference volume taken when: Vehicle speed Load Tank volume ripple Stable conditions during Vehicle speed decrease during stable period If the volume increases with more than 5 liters during DCY, refueling is assumed, and a new reference will be taken When volume reference is above 61 liters, driving distance for evaluation is increased to 40 miles.	> 50 mph 160 - 320 mg/combustion < 1,5 liters 17 sec < 3 mph	5 X 15,5 miles		
Fuel trim, long term Multiplicative	P0171	System lean	Long term	<-25%	Engine speed	Running	30 sec	Two DCY	
	P0172	System rich	Long term	>+25%	Lambda control	Active	Continuous		
					First multiplicative adaption	Done			
Fuel trim, long term Additive	P1181	System lean	Long term	<-5 mg/combustion	Engine speed	Running	30 sec		
	P1182	System rich	Long term	>+5 mg/combustion	Lambda control	Active	Continuous		
					First multiplicative adaption	Done			
Front O2 sensor	P0132	Range check high	Voltage	>2000 mV	Engine speed Battery voltage Sensor heater active	Running > 10,0 V > 4 sec	3 sec Continuous	Two DCY	
	P0131	Range check low	Voltage	< 70 mV	Engine speed Rear sensor signal Sensor heater active	Running > 700 mV > 4 sec	15 sec Continuous	Two DCY	
	P0134	Circuit Continuity check	Voltage	300 - 600 mV	Engine speed Battery voltage Sensor heater Closed loop active or Time from engine starting, depending on IAT or ECT at start.	Running > 10,0 V Active < -10°C: 580 sec -10 - +10°C: 145 sec > +10°C: 55 sec	10 sec Continuous	Two DCY	
	P0133	Response rate	Signal switches OR Combustions	< 2 in 180 combustions or > 135 for 2 switches	Engine speed Fuel control Delta load Engine load Integrator Coolant temperature Time from engine starting Purge valve	1300-2300 rpm Closed loop -20 - 600 mg/comb/10 msec 250 - 500 mg/combustion Stable, deviation < 12% > 70°C > 180 sec Not closing, no ramping	95 combustions Once / DCY	Two DCY	
	P1133	Short to heater ground	Voltage	50 - 300 mV	Engine speed Sensor heater active	Running > 4 sec	30 sec Continuous	Two DCY	

07_GRP04_All Engines.xls

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumin.	Special Prep
					Rear sensor signal Battery voltage	> 700 mV > 10.0 V			
Integrator Switch Point	P1131	Switch point trim value	Lean	> 35 combustions	Coolant temp	>70°C	Continuous	Two DCY	Steady state at 50 mph for 300 sec
	P1132		Rich	> 35 combustions	Throttle	Open			
					Delta load, positive Delta load, negative Engine speed Load Time after engine start Fuel control Catalyst temperature Rear sensor voltage for trim activation Purge adaption Stable time	< 60 mg/combustion/s < - 15 mg/combustion/s 1250 - 2600 rpm 200 - 400 mg/combustion >200 s Closed loop >350 C, calculated > 650 mV or < 300 mV < ±3% 2 sec			
Front O2 sensor heater	P1135	Range check min	Short-cut gnd or not connected	0 V	Engine speed	Running	5 sec	Two DCY	
	P1136	Range check max	Short-cut Ubatt	12 V	Battery voltage	> 10.0 V	Continuous		
	P1135	Heater current	min	< 300 mA	Engine speed	Running	5 sec	Two DCY	
	P1136		max	> 2300 mA	Battery voltage	> 10.0 V	Continuous		
				Sensor heater	Active				
Rear O2 sensor	P0137	Signal low	Voltage	< 70 mV	Engine speed Coolant temperature Sensor heater active Closed loop Integrator	Running > 60°C > 4 sec > 5 sec -20 to +20	60 sec Continuous	Two DCY	
		Signal high	Voltage	>2000 mV	Engine speed Sensor heater active	Running > 4 sec	3 sec Continuous	Two DCY	
	P0140	Activity	Voltage	>350 mV	Engine speed Fuel cut Coolant temp. Fuel control Time from start Sensor heater	Running Active for > 2 sec >70 °C Closed loop for 5 sec before fuel cut > 30 sec Active	2 sec Once/DCY	Two DCY	
P1137	Short to heater ground	Voltage	50 - 300 mV	Engine speed Closed loop Coolant temp. Integrator Battery voltage	Running > 5 sec > 60 °C > -20% > 10.0 V	90 sec Continuous	Two DCY		
Rear O2 sensor heater	P1141	Range check min	Short-cut gnd or not connected	0 V	Engine speed	Running	5 sec	Two DCY	
	P1142	Range check max	Short-cut Ubatt	12 V	Battery voltage	> 10.0 V	Continuous		
	P1141	Heater current	min	< 500 mA	Engine speed	Running	5 sec	Two DCY	
	P1142		max	> 2300 mA	Battery voltage	> 10.0 V	Continuous		
				Sensor heater	Active				
MAP sensor	P0106	Rationality, MAP vs.BARO	Pressure difference	> 15 kPa	Engine speed Pressure diff. BARO vs. intake Vehicle speed	0 < 10 kPa 0	3 readings Once / DCY	Two DCY	

07_GRP04_All Engines.xls

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumin.	Special Prep
	P0106	MAP vs. BARO, BARO vs. Intake & Intake vs. MAP	All pressure differences	> 15 kPa	Engine speed Vehicle speed	0 0	3 readings Once / DCY	Two DCY	
	P0106	Rationality, at engine overrun	MAP	> 50 kPa	Engine speed Load Accelerator	> 1300 rpm < 110 mg/combustion Released + 400 msec	5 readings Continuous	Two DCY	
	P0107	Range check min	Short-cut gnd or not connected	0 V	Ignition	On	10 sec	Two DCY	
	P0108	Range check max	Short-cut voltage	5 V	Ignition	On	Continuous		
Barometric pressure sensor	P1631	Rationality, BARO vs. MAP OR BARO vs. Intake	Pressure difference	>15 kPa	Engine speed Pressure diff. MAP vs. intake Vehicle speed	0 < 10 kPa 0	3 readings Once / DCY	Two DCY	
	P1632	Range check min	Short-cut gnd or not connected	0 V	Ignition	On	1 sec	Two DCY	
	P1633	Range check max	Short-cut voltage	5 V			Continuous		
Intake air pressure sensor, upstream throttle	P1106	Rationality, intake vs. BARO	Pressure difference	> 15 kPa	Engine speed Pressure diff. BARO vs. MAP Vehicle speed	0 < 10 kPa 0	3 readings Once / DCY	Two DCY	
	P1106	MAP vs. BARO, BARO vs. Intake & Intake vs. MAP	All pressure differences	> 15 kPa	Engine speed Vehicle speed	0 0	3 readings Once / DCY	Two DCY	
	P1107	Range check min	Short-cut gnd or not connected	0 V	Ignition	On	10 sec	Two DCY	
	P1108	Range check max	Short-cut voltage	5 V			Continuous		
	P1105	No activity	Intake air pressure vs. BARO	< 5 kPa	Engine speed MAP vs. BARO Pressure sensor adaptions	> 1500 rpm > 5 kPa Done	3 sec Continuous	Two DCY	Unified cycle demo
MAF sensor	P0100	No signal	Short-cut gnd or not connected	0 V	Engine speed	> 400 rpm for 0,5 sec	1 sec	Two DCY	
	P0102	Range check, low signal	Frequency	< 500 Hz	Battery voltage	> 10,0 V	Continuous		
	P0103	Range check, high signal	Frequency	> 15000 Hz					
MAF sensor, rationality	P0101	Comparison of measured MAF sensor signal with mass air flow calculated from throttle area, BARO, MAP and intake air pressure (before throttle) Samples are taken in two load windows, below and above 16 g air/sec. To report fault, the average deviation in one of the windows has to be above the limit after 400 samples. To report pass, 400 samples have to be taken in both load windows with less deviation than the fault limit	MAF deviation & Multiplicative Fuel Trim MAF deviation & Multiplicative Fuel Trim MAF deviation MAF deviation	> -12% > -17% > 12% > 17% > -30% > 30%	Coolant and intake air temperatures Altitude Engine speed Battery Voltage Pressure Sensor Adaption Coolant Temperature Engine Speed Pressure quote, MAP vs. pressure before throttle Throttle Area MAP deviation between samples (100 msec) Throttle area deviation between samples (100 msec) Boost by-pass status change	> -7 °C < 2500 meters Running > 10 Volts Completed once after battery disconnect or reprogramming 78 - 115 °C 700 - 4000 rpm 0,20 - 0,70 50 - 500 mm ² < ±12% (test abortion) < ±12% in 1500 msec (test enablement) < ±12% (test abortion) < ±12% in 1500 msec (test enablement) No change (test abortion)	400 samples or more (100 msec) Continuous	Two DCY	

07_GRP04_All Engines.xls

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumin.	Special Prep
					Vehicle speed to enable test Throttle area adaption EVAP purge Fuel cut	No change for 500 ms (test enablement) > 28 mph for 60 sec Done, or conditions for adaption fulfilled Active Inactive			
IAT sensor	P0112	Range check min	Short-cut	< 70 ohm	Engine speed	Running	10 sec	Two DCY	
	P0113	Range check max	Not connected	> 38000 ohm			Continuous		
IAT sensor, rationality	P0111	No activity	Change less than	2 deg C	Engine speed Coolant and intake air temperatures Altitude ECM power-down, engine-off time Engine run time	Running > -7 °C < 2500 meters > 15 minutes 900 sec	900 sec Once / DCY	Two DCY	
ECT sensor / Thermostat	P0116	Comparison between Coolant temperature model and ECT sensor reading. Model calculated based mainly on mass air flow, with corrections for IAT, engine speed and ECT at start.	Comparison done when the model temperature has reached 83°C, fault report if ECT	< 78 °C or > 130 °C	Coolant and intake air temperatures Altitude ECT at start	> -7 °C < 2500 meters < 65 °C	400 - 800 sec Once / DCY	Two DCY	
	P0115	Rationality	Temperature change	< 1°C	Engine speed Vehicle speed	Running > 15.5 mph	8000 combustions Continuous	Two DCY	
	P0117	Range check min	Short-cut	< 47 ohm	Engine speed	Running	1 sec	Two DCY	
	P0118	Range check max	Not connected	> 54520 ohm			Continuous		
	P0119	Too quick change	Mean value in stack	> 10 °C	Engine speed Comparison of each ECT reading, insert into stack when diff. from previous reading	Running > 5 °C	10 readings, time base 100 msec. Continuous	Two DCY	
	P0126	Comparison between Coolant temperature model and ECT sensor reading. Model calculated based mainly on mass air flow, with corrections for IAT, engine speed and ECT at start.	Comparison done when the model temperature has reached 25 °C, fault report if ECT	< 20 °C or > 100 °C	ECT at start Engine speed	< -7 °C Running	300 sec Once / DCY	Two DCY	
	P011B	High sided coolant rationality diagnostic, comparison between IAT and ECT sensor reading after an engine off period, check done after 20 secs engine operation	ECT vs IAT	ECT > 15 deg C above IAT OR IAT > 15 deg C above ECT	Engine speed ECM power-down, engine-off time Block heater start ECM reset Previous DCY minimum run Intake air temperature change 20 secs after engine start vs temp at start ECT at start IAT rise after previous DCY engine shut-off	Running > 15 minutes Not allowed Not allowed > 40000 combustions (20000 revs) < 2 deg C > -7 deg C Minimum rise between 100 secs and 250 secs after shut-off	20 sec Once / DCY	Two DCY	
Time to closed loop	P0125	Rationality	Time	> 600 sec	Engine speed Start Temperature, lowest of ECT/IAT No front O2 sensor or ECT sensor fault codes	Running < -7°C	600 sec Once / DCY	Two DCY	
			Time	>150 sec	Engine speed Start Temperature, lowest of ECT/IAT No front O2 sensor or ECT sensor fault codes	Running < 10°C	300 sec Once / DCY	Two DCY	

07_GRP04_All Engines.xls

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumin.	Special Prep
			Time	> 60 sec	Engine Start Temperature, lowest of ECT/IAT No front O2 sensor or ECT sensor fault codes	running >10°C	120 sec Once / DCY	Two DCY	
Crankshaft position sensor	P0336	Sensor activity	Output at cranking	No signal	MAP Battery voltage Throttle Pressure sensor adaption	3,0 kPa below BARO $\Delta > 0,8 V$ Closed Done	4 sec Once / DCY	Immediately	
	P0337	Rationality	Lost position twice in same DCY	Position found then lost	Vehicle speed Brake	> 19 mph Not active	10 msec Continuous	Two DCY	
Vehicle speed	P0501	High change	Derivative	From >31 to 0 mph or D>+75 mph in two readings	Engine speed Vehicle speed Brake	Running 31 - 127 mph for 10 sec Not active (speed decrease determination)	2 readings Continuous	Two DCY	
	P0501	Signal high	Vehicle speed	>168 mph	Engine speed	Running	20 readings Continuous	Two DCY	
	P0502	Signal missing	Vehicle speed	=0 mph	Gear (automatic) Engine speed Engine load Brake Above conditions fulfilled	Not in neutral >1750 rpm > 480 mg/c Not active 5 sec	1000 sec Continuous	Two DCY	
Brake switch	P1577	Rationality - low	Signal	Always low	Vehicle speed change	25 mph to zero, 5 times	2 - 12 sec each	Two DCY	
	P1576	Rationality - high	Signal	Always high	Engine speed	Running	Once / DCY		
ECM internal	P0605	General internal ECM fault					Continuous	Immediately	
ECM internal stack 1	P1621	Stack overflow			Ignition System	On Not in mechanical Limp-home	4 calculations Continuous	Immediately	
ECM internal stack 2	P1602	Stack overflow			Ignition System	On Not in mechanical Limp-home	4 calculations Continuous	Immediately	
ECM internal ROM 1	P1604	Checksum	Faulty		Ignition System	On Not in mechanical Limp-home	4 calculations Continuous	Immediately	
ECM internal ROM 2	P1603	Checksum	Faulty		Ignition System	On Not in mechanical Limp-home	4 calculations Continuous	Immediately	
ECM internal communication 1	P1605	Internal serial communication	Faulty		Ignition System	On Not in mechanical Limp-home	Continuous	Immediately	
ECM internal Watch Dog 1	P1606	SW monitor failure	Mismatch		Ignition System	On Not in mechanical Limp-home	4 calculations Continuous	Immediately	
ECM internal communication 2	P1607	Internal serial communication	Faulty		Ignition System	On Not in mechanical Limp-home	Continuous	Immediately	
ECM internal Watch Dog 2	P1608	SW monitor failure	Mismatch		Ignition System	On Not in mechanical Limp-home	4 calculations Continuous	Immediately	
ECM internal TP power	P1609	Powerstage inhibit error	Test failed		Ignition	Off	Once / DCY	Six DCY	

07_GRP04_All Engines.xls

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumin.	Special Prep
stage					System Engine speed Main relay	Not in mechanical Limp-home Not running On			
ECM int A/D	P1610	Comparison A/D conversion	Processor 1 vs. 2 difference	> 70 bits	Ignition System	On Not in mechanical Limp-home	Δ pedal >25%, 500 msec Δ pedal <25%, 760 msec Continuous	Immediately	
ECM internal throttle current	P1611	Current too high in Limp-home	Powerstage current	> 300 mA	Ignition System DTC P1251 DTC P1610	On In mechanical Limp-home Present Not present	Throttle > 50%, 300 msec Throttle < 50%, 500 msec Continuous	Fuel shut off	
ECM int airmass map	P1613	Airmass checksum	Faulty		Ignition System	On Not in mechanical Limp-home	2 failures Continuous	Immediately	
H-bridge short-cut	P1240	Short- cut			Ignition System	On Not in mechanical Limp-home	3 minutes Continuous	Two DCY	
Accel pedal pos 1-2 sum	P1530	Rationality check	Potentiometer sum	< 227 bit (4.45V) >283 bits (5.55V)	Ignition System	On Not in mechanical Limp-home	Δ pedal >25%, 500 msec Δ pedal <25%, 760 msec Continuous	Immediately	
Accel pedal pos 1-2 adaption	P1531	Rationality check	Potentiometer sum	> adapted sum + 6% (Adapted at idle)	Ignition System Pedal position	On Not in mechanical Limp-home < 13 bits(250 mV) above adapted idle position	Δ pedal >25%, 500 msec Δ pedal <25%, 760 msec Continuous	Immediately	
Accelerator pedal pos shorted	P1532	Potentiometers shorted	Testpulse on 1	Detected on 2, ≥ 4bits (78 mV)	Ignition System Pedal position	On Not in mechanical Limp-home < 75%	Δ pedal >25%, 500 msec Δ pedal <25%, 760 msec Continuous	Immediately	
Throttle pot. 1-2 sum	P1230	Rationality check	Potentiometer sum	< 234 bit (4.59V) > 291 bit (5.70V)	Ignition System	On Not in mechanical Limp-home	280 msec Continuous	Immediately	
Throttle closed	P1251	Rationality check, full PWM in closing direction	Throttle position	Actual > demanded	Ignition System Vehicle speed	On Not in mechanical Limp-home ≠ 0	280 msec Continuous	Immediately	
			Throttle position	Actual > demanded	Ignition System Vehicle speed Crankshaft position sensor Engine speed	On Not in mechanical Limp-home 0 Pulses present Not above 500 rpm, > 5 sec	280 msec Continuous	Immediately	
Throttle motor, full PWM cranking	P1253	Throttle can not open during cranking, no engine start	Throttle position	Actual < demanded	Ignition System Engine speed Throttle area	On Not in mech. L-H Cranking (engine speed<500 rpm) < 17 mm ²	3000 msec Continuous	Immediately	
Throttle return spring	P1260	Rationality check, broken spring	I-part of throttle pos. controller	Close to 0	Ignition System Throttle position Vehicle speed	On Not in mechanical Limp-home > mechanical block + 40 bits (of 1024 bit) > 3 mph	4000 msec Continuous	Two DCY	
Throttle in limp-home, high	P1261	Rationality check	MAF air Flow	> calculated Air Flow	Ignition	On	500 msec	Immediately	

07_GRP04_All Engines.xls

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumin.	Special Prep
torque					System DTC P1530 DTC P1531 DTC P1532 DTC P1610 Throttle control current	In mechanical Limp-home Not present Not present Not present Not present < 300 mA	Continuous	Fuel shut off	
Throttle controller, safety switch	P1264	Rationality check, accelerator at idle, throttle not closing	Throttle position	> calculated	Ignition System Cruise Control Accelerator pedal position	On Not in mechanical Limp-home Not active In idle position	800 msec Continuous	Immediately	
Throttle limp-home solenoid relay	P1670	Range check min	Short-cut gnd or not connected	0 V	Ignition	On	1 sec	Two DCY	
	P1671	Range check max	Short-cut Ubatt	12 V			Continuous		
Boost pressure control valve	P1549	Rationality, too high air mass	Difference actual vs. requested	> 0 mg/combustion	Engine speed Throttle control Pressure upstream throttle Negative throttle control Function is disabled when: Lowest of ECT or IAT Altitude Reenablement when: ECT IAT Altitude	Running Closed loop >200 kPa Min limit < -7°C > 2500 meters > 60°C > 5°C < 2000 meters	500 msec Continuous	Two DCY	US06 demo
	P1549	Rationality, too high air mass	Difference actual vs. requested	> 100 mg/combustion	Engine speed Boost control Requested boost or Boost throttle control Function is disabled when: Lowest of ECT or IAT Altitude Reenablement when: ECT IAT Altitude	Running Closed loop Min Min limit < -7°C > 2500 meters > 60°C > 5°C < 2000 meters	300 msec Continuous	Two DCY	US06 demo
	P1662	Range check min	Short-cut gnd or not connected	0 V	Ignition	On	60 sec	Two DCY	
	P1663	Range check max	Short-cut Ubatt	12 V			Continuous		
Boost pressure by-pass control valve	P1110	Functional check, stuck closed	Pressure variation before throttle	>3 kPa amplitude	Δ MAP Accelerator fully released Pressure before throttle By-pass valve Number of tests Function is disabled when: Lowest of ECT or IAT Altitude Reenablement when: ECT IAT Altitude	> 3.0 kPa Within 0.1 sec after Δ MAP > 120 kPa Commanded open Two, within 10 minutes < -7°C > 2500 meters > 60°C > 5°C < 2000 meters	0,75 sec Continuous	Two DCY	US06 demo
	P1658	Range check min	Short-cut gnd or not connected	0 V	Ignition	On	1 sec	Two DCY	

07_GRP04_All Engines.xls

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Time Required	MIL Illumin.	Special Prep
	P1659	Range check max	Short-cut Ubatt	12 V			Continuous		
Idle Speed	P0507	Functional check - high	Engine speed vs. nominal	> +200 rpm	Vehicle speed Accelerator pedal Air reduced or throttle at min	= 0 mph Idle position	10 sec Continuous	Two DCY	
	P0506	Functional check - low	Engine Speed vs. nominal	< -100 rpm	Vehicle speed Accelerator pedal Air added Load	= 0 mph Idle position < 225 mg/combustion	10 sec Continuous	Two DCY	
Main engine relay	P1640	Rationality	ECM system voltage	< 3 V	Main relay commanded	On	1 sec Continuous	Immediately	
			ECM system voltage	> 8 V	Main relay commanded	Off			
	P1652	Control circuit range check min	Short-cut gnd or not connected	0 V	Ignition	On	0,5 sec Continuous		
P1653	Control circuit range check max	Short-cut Ubatt	12 V						
TCM CAN data	P1623	Transmission data missing			Engine speed	Running	3 sec Continuous	Immediately	
TCS/ABS CAN data	P1625	TCS/ABS data missing			Engine speed	Running	3 sec Continuous	Two DCY	
Instrument cluster CAN data	P1622	Cluster data missing			Engine speed	Running	10 sec Continuous	Immediately	
Fuel pump relay	P1641	Rationality	Consecutive misfires O2 Sensors, Heater Current	15 when RPM >1500 6 when RPM < 1500 < 10 mA	Engine speed	Running	1,5 sec Continuous	Immediately	
Cold Start Emission Strategy Reduction Diagnostic	P1400	Exhaust temperature model	Engine speed AND Load FOR	< 850 RPM > 180 mg air / combustion 275 revolutions	Engine speed Vehicle speed	Running 0 ECT	1500 engine revolutions Once / DCY Between -30 and 90 deg C	Two DCY	