

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
Transmission Control Module (TCM)	P0601	Transmission Electro-Hydraulic Control Module Read Only Memory	Incorrect program/calibrations checksum	= TRUE Boolean			>= 5 Fail Counts	one trip
					Ignition Voltage Lo Ignition Voltage Hi	>= 9 Volts <= 18 Volts	Disable Conditions: MIL not Illuminated for DTC's: TCM: P0601 ECM: None	
Transmission Control Module (TCM)	P0603	Transmission Electro-Hydraulic Control Module Long-Term Memory Reset	Non-volatile memory (static or dynamic) checksum failure at Powerup	= TRUE Boolean			Runs Continuously	one trip
					Ignition Voltage Lo Ignition Voltage Hi	>= 9 Volts <= 18 Volts	Disable Conditions: MIL not Illuminated for DTC's: TCM: P0603 ECM: None	
Transmission Control Module (TCM)	P0604	Transmission Electro-Hydraulic Control Module Random Access Memory	RAM Read/Write Failure (Single Word)	= TRUE Boolean			>= 5 Fail Counts = 16 Sample Counts	one trip
					Ignition Voltage Lo Ignition Voltage Hi	>= 9 Volts <= 18 Volts	Disable Conditions: MIL not Illuminated for DTC's: TCM: P0604 ECM: None	
Transmission Control Module (TCM)	P062F	Transmission Electro-Hydraulic Control Module Long Term Memory Performance	TCM Non-Volatile Memory bit Incorrect flag at Powerdown	= TRUE Boolean			Runs Continuously	one trip
					Ignition Voltage Lo	>= 9 Volts		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.	
					Ignition Voltage Hi	<= 18 Volts			
					Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P062F ECM: None		
Transmission Control Module (TCM)	P0634	Transmission Electro-Hydraulic Control Module Internal Temperature Too High	Fail Case 1	Substrate Temperature	>= 144 °C		>= 5	Fail Time (Sec)	one trip
			Fail Case 2	Substrate Temperature	>= 50 °C		>= 2	Fail Time (Sec)	
				Ignition Voltage	>= 18 Volts				
			Note: either fail case can set the DTC						
					Ignition Voltage Lo	>= 9 Volts			
					Ignition Voltage Hi	<= 31.99 Volts			
					Substrate Temp Lo	>= 0 °C			
					Substrate Temp Hi	<= 240 °C			
					Substrate Temp Between Temp Range for Time	>= 0.25 Sec			
					P0634 Status is	≠ This Key On or Fault Active			
					Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
HWIO	P0658	Actuator Supply Voltage Circuit Low	The HWIO reports a low voltage (open or ground short) error flag	= TRUE Boolean			>= 3	Fail Counts	one trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.	
							out of 5 Sample Counts		
					P0658 Status is not High Side Driver 1 On Disable Conditions:	= Test Failed This Key On or Fault Active = True Boolean TCM: None ECM: None			
Transmission Control Module (TCM)	P0667	TCM Internal Temp (substrate) Sensor Circuit Range/Performance	If transmission oil temp to substrate temp Δ If TCM substrate temp to power up temp Δ	> 19 in $^{\circ}\text{C}$ supporting documents > 20 in $^{\circ}\text{C}$ supporting documents			Both conditions above required to increment fail counter Note: table reference temp = to the median temp of trans oil temp, substrate temp and power up temp. Non-continuous (intermittent) fail conditions will delay resetting fail counter until	>= 3000 Fail Counts (100ms loop) Out of 3750 Sample Counts (100ms loop) >= 700 Pass Counts (100ms loop)	two trips

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
							Out of 875 Sample Counts (100ms loop)	
					Engine Torque Signal Valid Accelerator Position Signal Valid Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for Brake torque active	= TRUE Boolean = TRUE Boolean >= 9 Volts <= 31.99 Volts >= 400 RPM <= 7500 RPM >= 5 Sec = FALSE		
					Below describes the brake torque entry criteria Engine Torque Throttle Transmission Input Speed Vehicle Speed Transmission Range Transmission Range PTO Set Brake Torque Active TRUE if above conditions are met for:	>= 90 N*m >= 30 Pct <= 200 RPM <= 8 Kph ≠ Park ≠ Neutral = Not Active >= 7 sec		
					Below describes the brake torque exit criteria Brake torque entry criteria Clutch hydraulic pressure	= Not Met ≠ Hydraulic Air Purge Event		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Clutch used to exit brake torque active	= CeTFT D_e_C 3_Ratl Enbl		
					The above clutch pressure is greater than this value for one loop	>= 600 kpa		
					Set Brake Torque Active FALSE if above conditions are met for:	>= 20 Sec		
					P0667 Status is	≠ Test Failed This Key On or Fault Active		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0658, P0668, P0669, P06AD, P06AE, P0716, P0712, P0713, P0717, P0722, P0723, P0962, P0963, P0966, P0967, P0970, P0971, P215C, P2720, P2721, P2729, P2730 ECM: P0101, P0102, P0103,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Transmission Control Module (TCM)	P0668	TCM internal temperature (substrate) thermistor failed at a low voltage	<p>Type of Sensor Used = CeTFTI_e_VoltageInverseProp</p> <p>If TCM Substrate Temperature Sensor = Direct Proportional and Temp <= 254 °C</p> <p>If TCM Substrate Temperature Sensor = Indirect Proportional and Temp >= 254 °C</p>	<p>= 254 °C</p> <p>>= 254 °C</p>			<p>>= 60 Fail Timer (Sec)</p>	two trips
			Either condition above will satisfy the fail conditions		<p>Ignition Voltage Lo >= 9 Volts</p> <p>Ignition Voltage Hi <= 31.99 Volts</p>			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for P0668 Status is Disable Conditions:	>= 400 RPM <= 7500 RPM >= 5 Sec Test Failed This Key On or Fault Active MIL not Illuminated for DTC's: TCM: None ECM: None		
Transmission Control Module (TCM)	P0669	TCM internal temperature (substrate) thermistor failed at a high voltage	Type of Sensor Used = If TCM Substrate Temperature Sensor = Direct Proportional and Temp If TCM Substrate Temperature Sensor = Indirect Proportional and Temp Either condition above will satisfy the fail conditions	CeTFTI_e_Vol tagelInverseProp >= -254 °C <= -254 °C			>= 60 Fail Timer (Sec)	two trips
					Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for P0669 Status is	>= 9 Volts <= 31.99 Volts >= 400 RPM <= 7500 RPM >= 5 Sec Test Failed This Key On or Fault Active		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					For Hybrids, below conditions must also be met Estimated Motor Power Loss >= 0 kW Estimated Motor Power Loss greater than limit for time >= 0 Sec Lost Communication with Hybrid Processor Control Module = FALSE Estimated Motor Power Loss Fault = FALSE Disable Conditions: MIL not illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723 ECM: None		
Transmission Control Module (TCM)	P06AC	TCM Power-up Temp Sensor Circuit Range/Performance	If TCM power-up temp to substrate temp Δ > If transmission oil temp to power up temp Δ >	Refer to Table 20 in supporting documents °C Refer to Table 18 in supporting documents °C				two trips
			Both conditions above required to increment fail counter Note: table reference temp = to the median temp of trans oil temp, substrate temp and power up temp.				Fail Counts (100ms loop) >= 3000 Out of 3750 Sample Counts (100ms loop)	

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Non-continuous (intermittent) fail conditions will delay resetting fail counter until				Pass Counts (100ms loop) >= 700 Sample Counts (100ms loop) Out of 875	
					Engine Torque Signal Valid = TRUE Boolean Accelerator Position Signal Valid = TRUE Boolean Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.99 Volts Engine Speed Lo >= 400 RPM Engine Speed Hi <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec Brake torque active = FALSE			
					Below describes the brake torque entry criteria Engine Torque >= 90 N*m Throttle >= 30 Pct Transmission Input Speed <= 200 RPM Vehicle Speed <= 8 Kph Transmission Range ≠ Park Transmission Range ≠ Neutral PTO = Not Active Set Brake Torque Active TRUE if above conditions are met for: >= 7 sec			
					Below describes the brake torque exit criteria Brake torque entry criteria = Not Met			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Clutch hydraulic pressure	≠ Clutch Hydraulic Air Purge Event		
					Clutch used to exit brake torque active	= CeTFT D_e_C 3_Ratl Enbl		
					The above clutch pressure is greater than this value for one loop	>= 600 kpa		
					Set Brake Torque Active FALSE if above conditions are met for:	>= 20 Sec		
					P06AC Status is	≠ Test Failed This Key On or Fault Active		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0658, P0668, P0669, P06AD, P06AE, P0716, P0712, P0713, P0717, P0722, P0723, P0962, P0963, P0966, P0967, P0970, P0971, P215C, P2720, P2721, P2729, P2730		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Transmission Control Module (TCM)	P06AD	TCM power-up thermistor circuit voltage low	Power Up Temp	<= -254 °C			>= 60 Fail Time (Sec)	two trips
					Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for P06AD Status is	>= 9 Volts <= 31.99 Volts >= 400 RPM <= 7500 RPM >= 5 Sec Test Failed This Key On or Fault Active		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					For Hybrids, below conditions must also be met Estimated Motor Power Loss Estimated Motor Power Loss greater than limit for time Lost Communication with Hybrid Processor Control Module Estimated Motor Power Loss Fault Disable Conditions: MIL not Illuminated for DTC's:	>= 0 kW >= 0 Sec = FALSE = FALSE TCM: P0716, P0717, P0722, P0723 ECM: None		
Transmission Control Module (TCM)	P06AE	TCM power-up thermistor circuit voltage high	Power Up Temp	>= 254 °C			>= 60 Fail Time (Sec)	two trips
					Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for P06AE Status is	>= 9 Volts <= 31.99 Volts >= 400 RPM <= 7500 RPM >= 5 Sec ≠ Test Failed This Key On or Fault Active		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.	
					Disable Conditions: MIL not illuminated for DTC's:	TCM: None ECM: None			
Transmission Fluid Temperature Sensor (TFT)	P0711	Trans Fluid Temp Sensor Circuit Range/Performance	If transmission oil temp to substrate temp Δ	>	Refer to Table 19 in supporting documents °C			two trips	
			If transmission oil temp to power up temp Δ	>	Refer to Table 18 in supporting documents °C				
			Both conditions above required to increment fail counter						>= 3000 Fail Counts (100ms loop)
			Note: table reference temp = to the median temp of trans oil temp, substrate temp and power up temp.						Out of 3750 Sample Counts (100ms loop)
			Non-continuous (intermittent) fail conditions will delay resetting fail counter until					>= 700 Pass Counts (100ms loop)	
								Out of 875 Sample Counts (100ms loop)	
					Engine Torque Signal Valid = TRUE Boolean Accelerator Position Signal Valid = TRUE Boolean Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.99 Volts Engine Speed Lo >= 400 RPM Engine Speed Hi <= 7500 RPM				

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Engine Speed is within the allowable limits for Brake torque active	>= 5 Sec = FALSE		
					Below describes the brake torque entry criteria Engine Torque Throttle Transmission Input Speed Vehicle Speed Transmission Range Transmission Range PTO Set Brake Torque Active TRUE if above conditions are met for:	>= 90 N*m >= 30 Pct <= 200 RPM <= 8 Kph ≠ Park ≠ Neutral = Not Active >= 7 sec		
					Below describes the brake torque exit criteria Brake torque entry criteria Clutch hydraulic pressure Clutch used to exit brake torque active The above clutch pressure is greater than this value for one loop Set Brake Torque Active FALSE if above conditions are met for:	= Not Met ≠ Clutch Hydraulic Air Purge Event = CeTFT D_e_C 3_Ratl Enbl >= 600 kpa >= 20 Sec		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					<p>P0711 Status is</p> <p>Disable Conditions:</p> <p>MIL not Illuminated for DTC's:</p>	<p>Test Failed This Key On or Fault Active</p> <p>TCM: P0658, P0668, P0669, P06AD, P06AE, P0716, P0712, P0713, P0717, P0722, P0723, P0962, P0963, P0966, P0967, P0970, P0971, P215C, P2720, P2721, P2729, P2730</p> <p>ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205,</p>		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Transmission Fluid Temperature Sensor (TFT)	P0712	Transmission fluid temperature thermistor failed at a low voltage	Type of Sensor Used =	CeTFTI_e_VoltageInverseProp				two trips
			If Transmission Fluid Temperature Sensor = Direct Proportional and Temp	<=	254 °C			
			If Transmission Fluid Temperature Sensor = Indirect Proportional and Temp	>=	254 °C			
			Either condition above will satisfy the fail conditions				>= 60 Fail Time (Sec)	
					Ignition Voltage Low	>= 9 Volts		
					Ignition Voltage High	<= 31.99 Volts		
					Engine Speed Low	>= 400 RPM		
					Engine Speed High	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					P0712 Status is	≠ Test Failed This Key On or Fault Active		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					For Hybrids, below conditions must also be met Estimated Motor Power Loss >= 0 kW Estimated Motor Power Loss greater than limit for time >= 0 Sec Lost Communication with Hybrid Processor Control Module = FALSE Estimated Motor Power Loss Fault = FALSE Disable Conditions: MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723 ECM: None		
Transmission Fluid Temperature Sensor (TFT)	P0713	Transmission fluid temperature thermistor failed at a high voltage	Type of Sensor Used = CeTFTI_e_VoltageInverseProp If Transmission Fluid Temperature Sensor = Direct Proportional and Temp >= -254 °C If Transmission Fluid Temperature Sensor = Indirect Proportional and Temp <= -254 °C Either condition above will satisfy the fail conditions					two trips
							>= 60 Fail Time (Sec)	
					Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.99 Volts Engine Speed Lo >= 400 RPM Engine Speed Hi <= 7500 RPM			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Engine Speed is within the allowable limits for P0713 Status is Disable Conditions: MIL not Illuminated for DTC's:	>= 5 Sec Test Failed This Key On or Fault Active TCM: P0713, P0716, P0717, P0722, P0723 ECM: None		
Transmission Input Speed Sensor (TISS)	P0716	Input Speed Sensor Performance	Transmission Input Speed Sensor Drops	>= 1350 RPM			>= 0.8 Fail Time (Sec)	one trip
					Engine Torque is >= 0 N*m Engine Torque is <= 8191.9 N*m Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec Vehicle Speed is >= 10 Kph Throttle Position is >= 0 Pct ----- Transmission Input Speed is >= 0 RPM The previous requirement has been satisfied for >= 0 Sec ----- The change (loop to loop) in transmission input speed is < 8191.8 RPM/Loop			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					The previous requirement has been satisfied for Throttle Position Signal Valid Engine Torque Signal Valid Ignition Voltage Ignition Voltage P0716 Status is not Disable Conditions:	>= 0 Sec = TRUE Boolean = TRUE Boolean >= 9 Volts <= 31.99 Volts Test Failed This Key On or Fault Active TCM: P0717, P0752, P0973, P0974 ECM: P0101, P0102, P0103, P0121, P0122, P0123		
Transmission Input Speed Sensor (TISS)	P0717	Input Speed Sensor Circuit Low Voltage	<u>Fail Case 1</u> Transmission Input Speed is	< 50 RPM			>= 4.5 Fail Time (Sec)	one trip
			<u>Fail Case 2</u> When P0722 DTC Status equal to Test Failed and Transmission Input Speed is	< 1000 RPM	Controller uses a single power supply for the speed sensors	= 1 Boolean		
					Engine Torque is Engine Torque is Vehicle Speed Engine Torque Signal Valid Ignition Voltage Ignition Voltage	>= 50 N*m <= 8191.9 N*m >= 16 Kph = TRUE Boolean >= 9 Volts <= 31.99 Volts		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for P0717 Status is not Disable Conditions: MIL not illuminated for DTC's:	>= 400 RPM <= 7500 RPM >= 5 Sec Test Failed This Key On or Fault Active =		
Transmission Output Speed Sensor (TOSS)	P0722	Output Speed Sensor Circuit Low Voltage	Transmission Output Speed Sensor Raw Speed	<= 35 RPM			>= 4.5 Fail Time (Sec)	one trip
					P0722 Status is not Transmission Input Speed Check Engine Torque Check Throttle Position Transmission Fluid Temperature Disable this DTC if the PTO is active Engine Torque Signal Valid Throttle Position Signal Valid Ignition Voltage is Ignition Voltage is Engine Speed is Engine Speed is Engine Speed is within the allowable limits for	= Test Failed This Key On or Fault Active = TRUE Boolean = TRUE Boolean >= 8.0002 Pct >= -40 °C = 1 Boolean = TRUE Boolean = TRUE Boolean >= 9 Volts <= 31.99 Volts >= 400 RPM <= 7500 RPM >= 5 Sec		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					<p>Enable_Flags Defined Below</p> <p>The Engine Torque Check is TRUE, if either of the two following conditions are TRUE</p> <p>Engine Torque Condition 1 Shift Status is not = complete OR Transmission Range is = Park or Neutral Engine Torque is >= 8191.8 N*m Engine Torque is <= 8191.8 N*m</p> <p>Engine Torque Condition 2 Engine Torque is >= 30 N*m Engine Torque is <= 8191.8 N*m</p> <p>-----</p>			
					<p>The Transmission Input Speed (TIS) Check is TRUE, if either of the two following conditions are TRUE</p> <p>TIS Check Condition 1 Transmission Input Speed is >= 1000 RPM Transmission Input Speed is <= 8191.8 RPM</p> <p>TIS Check Condition 2 Engine Speed without the brake applied is >= 3200 RPM Engine Speed with the brake applied is >= 3200 RPM Engine Speed is <= 8191.8 RPM</p>			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Controller uses a single power supply for the speed sensors Powertrain Brake Pedal is Valid	= 1 Boolean = TRUE Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0723 ECM: P0101, P0102, P0103, P0121, P0122, P0123		
Transmission Output Speed Sensor (TOSS)	P0723	Output Speed Sensor Circuit Intermittent	Raw Output Speed	>= 105 RPM			>= 0 Enable Time (Sec)	one trip
			Output Speed Delta	<= 8191.75 RPM			>= 0 Enable Time (Sec)	
			Output Speed Drop	> 1000 RPM			>= 3 Output Speed Drop Recover Fail Time (Sec)	
					Range_Disable OR Neutral_Range_Enable And Neutral_Speed_Enable are TRUE concurrently	= FALSE Boolean = TRUE Boolean = TRUE Boolean		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Transmission_Range_Enable	= TRUE Boolean		
					Transmission_Input_Speed_Enable	= TRUE Boolean		
					No Change in Transfer Case Range (High <-> Low) for	>= 5 Seconds		
					Engine Torque Signal Valid	= TRUE Boolean		
					Throttle Position Signal Valid	= TRUE Boolean		
					P0723 Status is not	= Test Failed This Key On or Fault Active		
					Disable this DTC if the PTO is active	= 1 Boolean		
					Ignition Voltage is	>= 9 Volts		
					Ignition Voltage is	<= 31.99 Volts		
					Engine Speed is	>= 400 RPM		
					Engine Speed is	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					Enable_Flags Defined Below			
					Transmission_Input_Speed_Enable is TRUE when either TIS Condition 1 or TIS Condition 2 is TRUE:			
					TIS Condition 1 is TRUE when both of the following conditions are satisfied for	>= 0 Enable Time (Sec)		
					Input Speed Delta	<= 4095 RPM		
					Raw Input Speed	>= 500 RPM		
					TIS Condition 2 is TRUE when ALL of the next three conditions are satisfied			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Input Speed	= 0 RPM		
					A Single Power Supply is used for all speed sensors	= TRUE Boolean		
					Powertrain Brake Pedal Applied is	= FALSE Boolean		
					Neutral_Range_Enable is TRUE when any of the next 3 conditions are TRUE			
					Transmission Range is	= Neutral ENUM		
					Transmission Range is	= Reverse/Neutral Transitional ENUM		
					Transmission Range is	= Neutral/Drive Transitional ENUM		
					And when a drop occurs Loop to Loop Drop of Transmission Output Speed is	> 650 RPM		
					Range_Disable is TRUE when any of the next three conditions are TRUE			
					Transmission Range is	= Park ENUM		
					Transmission Range is	= Park/Reverse Transitional ENUM		
					Input Clutch is not	= ON (Fully Applied) ENUM		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Neutral_Speed_Enable is TRUE when All of the next three conditions are satisfied for	> 1 Seconds		
					Transmission Output Speed	> 100 RPM		
					And the acceleration of the Transmission Output Speed is	< 500 RPM/ Loop Rate		
					And the acceleration of the Transmission Output Speed is	> 0 RPM/ Loop Rate		
					Transmission_Range_Enable is TRUE when one of the next four conditions is TRUE			
					Transmission Range is	= Neutral ENUM		
					Transmission Range is	= Reverse/Neutral Transitional ENUM		
					Transmission Range is	= Neutral/Drive Transitional ENUM		
					Range Change Delay Timer	>= 5 Sec		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0973, P0974, P0976, P0977 ECM: P0101, P0102,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0103, P0121, P0122, P0123		
Torque Converter Clutch (TCC)	P0741	TCC System Stuck OFF	TCC Pressure	>= 500 Kpa			>= 2 Enable Time (Sec)	two trips
			Either Condition (A) or (B) Must be Met (A) TCC Slip Error @ TCC On Mode (B) TCC Slip @ Lock On Mode If Above Conditions Have been Met, and Fail Timer Expired, Increment Fail Counter	Refer to Table 1 in Supporting Documents >= 130 RPM		>= 5 Fail Time (Sec) >= 5 Fail Time (Sec) >= 6 TCC Stuck Off Fail Counter		
					Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.99 Volts Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec Engine Torque Lo >= 50 N*m Engine Torque Hi <= 8191.9 N*m Throttle Position Lo >= 8.0002 Pct Throttle Position Hi <= 99.998 Pct 2nd Gear Ratio Lo >= 2.7528 Ratio 2nd Gear Ratio High <= 3.1672 Ratio 3rd Gear Ratio Lo >= 1.7762 Ratio			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					3rd Gear Ratio High	<= 2.0437 Ratio		
					4th Gear Ratio Lo	>= 1.3485 Ratio		
					4th Gear Ratio High	<= 1.5515 Ratio		
					5th Gear Ratio Lo	>= 0.9301 Ratio		
					5th Gear Ratio Hi	<= 1.0699 Ratio		
					6th Gear Ratio Lo	>= 0.6975 Ratio		
					6th Gear Ratio High	<= 0.8025 Ratio		
					Transmission Fluid Temperature Lo	>= -6.656 °C		
					Transmission Fluid Temperature Hi	<= 130 °C		
					TCC Command Lock ON or ON mode	= TRUE Boolean		
					PTO Not Active	= TRUE Boolean		
					Engine Torque Signal Valid	= TRUE Boolean		
					Throttle Position Signal Valid	= TRUE Boolean		
					Dynamic Mode	= FALSE Boolean		
					P0741 Status is	≠ Test Failed This Key On or Fault Active		
				Disable Conditions:	MIL not illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P0742, P2763, P2764 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Torque Converter Clutch (TCC)	P0742	TCC System Stuck ON	TCC Slip Speed TCC Slip Speed	>= -50 RPM <= 30 RPM			>= 1.2 Fail Time (Sec) >= 5 Fail Counter	one trip
			If Above Conditions Have been Met, and Fail Timer Expired, Increment Fail Counter		Run TCC Stuck On Test Enable Criteria: Gear Ratio <= 3.1715 Ratio Gear Ratio >= 2.7565 Ratio Engine Speed Hi <= 6500 RPM Engine Speed Lo >= 500 RPM Vehicle Speed Hi <= 511 KPH Vehicle Speed Lo >= 16 KPH Stuck On During Upshift Enabled = 1 Boolean			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Common Enables: Ignition Voltage >= 9 V Ignition Voltage <= 31.99 V Vehicle Speed <= 511 KPH Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec Engine Torque Signal Valid = TRUE Boolean Throttle Position Signal Valid = TRUE Boolean P0742 Status is ≠ Test Failed This Key On or Fault Active			
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P0741, P2763, P2764 ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					TPS OR Output Speed Throttle Position Signal Valid from ECM Engine Torque Signal Valid from ECM, High side driver is enabled High-Side Driver is Enabled Input Speed Sensor fault Output Speed Sensor fault Default Gear Option is not present	>= 0.5005 % >= 0 RPM = TRUE Boolean = TRUE Boolean = TRUE Boolean = FALSE Boolean = FALSE Boolean = TRUE		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Mode 2 Multiplex Valve	P0752	Shift Solenoid Valve A Stuck On	Gear Box Slip Commanded Gear Commanded Gear has Achieved 1st Locked OR 1st Free-Wheel OR 2nd with Mode 2 Sol. Commanded On C456/CBR1 Pressure Switch C456/CBR1 Pressure Switch Fault If the above parameters are true	>= 400 Rpm = 3rd Gear = TRUE Boolean = Pressurized Boolean = FALSE Boolean			Please Refer to Neutral Timer (Sec) >= 16 in Supporting Documents >= 5 Counts	one trip
					Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi	>= 9 Volts <= 31.99 Volts >= 400 RPM <= 7500 RPM		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Engine Speed is within the allowable limits for High-Side Driver is Enabled Throttle Position Signal Valid from ECM Output Speed OR TPS Shift is Complete Transmission Fluid Temperature Input Speed Sensor fault Output Speed Sensor fault Default Gear Option is not present	>= 5 Sec = TRUE Boolean = TRUE Boolean >= 0 RPM >= 0.5005 % >= -6.656 °C = FALSE Boolean = FALSE Boolean = TRUE		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P0776	Pressure Control (PC) Solenoid B Stuck Off [C35R]	<p><u>Fail Case</u> 1</p> <p>Case: Steady State 3rd Gear Commanded Gear = 3rd Gear</p> <p>Gearbox Slip >= 400 Rpm</p> <p>Intrusive Test: Command 4th Gear</p> <p>If attained Gear=4th gear for Time >= Table Based Time Please Refer to Table 3 in supporting documents</p> <p>If the above conditions are true, Increment 3rd gear fail counter</p> <p>and C35R Fail counter</p>				<p>one trip</p> <p>Please Refer to Table 5 in Supporting Documents</p> <p>Neutral Timer (Sec)</p> <p>>= 2 3rd Gear Fail Counts</p> <p>or</p> <p>>= 14 3-5R Clutch Fail Counts</p>	

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			<p>Fail Case 2</p> <p>Case: Steady State 5th Gear</p> <p>Commanded Gear = 5th Gear</p> <p>Gearbox Slip >= 400 Rpm</p> <p>Intrusive Test: Command 6th Gear</p> <p>If attained Gear=6th gear Time >= 3 in (Sec)</p> <p>Table Based Time Please Refer to Table 5 in supporting documents</p> <p>If the above conditions are true, Increment 5th gear fail counter</p> <p>and C35R Fail counter</p>				<p>Please Refer to Table 5 in Supporting Documents</p> <p>>= 3 5th Gear Fail Counts or >= 14 3-5R Clutch Fail Counts</p>	
					<p>PRNDL State defaulted = FALSE Boolean</p> <p>inhibit RVT = FALSE Boolean</p> <p>IMS fault pending indication = FALSE Boolean</p> <p>TPS validity flag = TRUE Boolean</p> <p>Hydraulic System Pressurized = TRUE Boolean</p> <p>Minimum output speed for RVT >= 0 RPM</p>			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					A OR B (A) Output speed enable (B) Accelerator Pedal enable Common Enable Criteria Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for Throttle Position Signal valid HSD Enabled Transmission Fluid Temperature Input Speed Sensor fault Output Speed Sensor fault Default Gear Option is not present Disable Conditions: MIL not Illuminated for DTC's:	>= 650 RPM >= 0.5005 Pct >= 9 Volts <= 31.99 Volts >= 400 RPM <= 7500 RPM >= 5 Sec = TRUE Boolean = TRUE Boolean >= -6.656 °C = FALSE Boolean = FALSE Boolean = TRUE TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P0777	Pressure Control (PC) Solenoid B Stuck On [C35R] (Steady State)	<u>Fail Case</u> 1 Case: Steady State 1st Attained Gear slip If the Above is True for Time Intrusive test: (CBR1 clutch exhausted) Gear Ratio Gear Ratio If the above parameters are true	>= 400 RPM Table Based Time Please Refer to Table Enable Time 4 in (Sec) supporting documents <= 2.007324219 >= 1.744628906			>= 1.1 Fail Timer (Sec) >= 2 Fail Count in 1st Gear or	one trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
							Total Fail Counts >= 3	
			<u>Fail Case 2</u> Case: Steady State 2nd gear	Table Based value Please Refer to 3D Table 1 in supporting documents Max Delta Output Speed Hysteresis >= rpm/sec				
			Min Delta Output Speed Hysteresis >= rpm/sec	Table Based value Please Refer to 3D Table 2 in supporting documents				
			If the Above is True for Time >= Sec	Table Based Time Please Refer to Table 17 in supporting documents				
			Intrusive test: (CB26 clutch exhausted)					
			Gear Ratio <= 2.007324219	2.007324219				
			Gear Ratio >= 1.744628906	1.744628906				
			If the above parameters are true				Fail Timer (Sec) >= 1.1	
							Fail Count in 2nd Gear >= 3 or	

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
							Total Fail Counts >= 3	
			<u>Fail Case 3</u> Case: Steady State 4th gear	Table Based value Please Refer to 3D Table 1 in supporting documents Max Delta Output Speed Hysteresis >= rpm/sec				
			Min Delta Output Speed Hysteresis >= rpm/sec	Table Based value Please Refer to 3D Table 2 in supporting documents				
			If the Above is True for Time >= Sec	Table Based Time Please Refer to Table 17 in supporting documents				
			Intrusive test: (C1234 clutch exhausted)					
			Gear Ratio <= 1.069946289					
			Gear Ratio >= 0.930053711					
			If the above parameters are true				Fail Timer (Sec) >= 1.1	
							Fail Count in 4th Gear or >= 3	
							Total Fail Counts >= 3	

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			<p>Fail Case 4 Case: Steady State 6th gear</p> <p>Max Delta Output Speed Hysteresis >=</p> <p>Min Delta Output Speed Hysteresis >=</p> <p>If the Above is True for Time >=</p> <p>Intrusive test: (CB26 clutch exhausted)</p> <p>Gear Ratio <=</p> <p>Gear Ratio >=</p> <p>If the above parameters are true</p>	<p>Table Based value Please Refer to 3D Table 1 in supporting documents rpm/sec</p> <p>Table Based value Please Refer to 3D Table 2 in supporting documents rpm/sec</p> <p>Table Based Time Please Refer to Table 17 in supporting documents Sec</p> <p>1.069946289</p> <p>0.930053711</p>			<p>>= 1.1 Fail Timer (Sec)</p> <p>>= 3 counts</p> <p>>= 1.1 Fail Timer (Sec)</p> <p>>= 3 Fail Count in 6th Gear</p> <p>or</p> <p>>= 3 Total Fail Counts</p>	
					PRNDL State defaulted	= FALSE Boolean		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					inhibit RVT	= FALSE Boolean		
					IMS fault pending indication	= FALSE Boolean		
					output speed	>= 0 RPM		
					TPS validity flag	= TRUE Boolean		
					HSD Enabled	= TRUE Boolean		
					Hydraulic_System_Pressurized	= TRUE Boolean		
					Minimum output speed for RVT	>= 0 Nm		
					A OR B			
					(A) Output speed enable	>= 650 Nm		
					(B) Accelerator Pedal enable	>= 0.5005 Nm		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.99 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					if Attained Gear=1st FW Accelerator Pedal enable	>= 10.001 Pct		
					if Attained Gear=1st FW Engine Torque Enable	>= 45 Nm		
					if Attained Gear=1st FW Engine Torque Enable	<= 8191.9 Nm		
					Transmission Fluid Temperature	>= -6.656 °C		
					Input Speed Sensor fault	= FALSE Boolean		
					Output Speed Sensor fault	= FALSE Boolean		
				Disable Conditions:	MIL not illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P0777	Pressure Control (PC) Solenoid B StuckOn [C35R] (Dymanic)	Primary Offgoing Clutch is exhausted (See Table 12 in Supporting Documents for Exhaust Delay Timers) Primary Oncoming Clutch Pressure Command Status Primary Offgoing Clutch Pressure Command Status	= TRUE Boolean = Maximum pressurized = Clutch exhaust command				one trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.	
			Range Shift Status	≠	Initial Clutch Control				
			Attained Gear Slip	<=	40 RPM				
			If the above conditions are true run appropriate Fail 1 Timers Below:						
			fail timer 1 (3-1 shifting with Closed Throttle)	>=	0.900390625	Fail Time (Sec)			
			fail timer 1 (3-2 shifting with Throttle)	>=	0.700195313	Fail Time (Sec)			
			fail timer 1 (3-2 shifting with Closed Throttle)	>=	0.900390625	Fail Time (Sec)			
			fail timer 1 (3-4 shifting with Throttle)	>=	0.700195313	Fail Time (Sec)			
			fail timer 1 (3-4shifting with Closed Throttle)	>=	0.900390625	Fail Time (Sec)			
			fail timer 1 (3-5 shifting with Throttle)	>=	0.700195313	Fail Time (Sec)			
			fail timer 1 (3-5 shifting with Closed Throttle)	>=	0.900390625	Fail Time (Sec)			
			fail timer 1 (5-3 shifting with Throttle)	>=	0.700195313	Fail Time (Sec)			
			fail timer 1 (5-3 shifting with Closed Throttle)	>=	0.900390625	Fail Time (Sec)			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			fail timer 1 (5-4 shifting with Throttle)	>= 0.700195313 Fail Time (Sec)			Total Fail Time = (Fail 1 + Fail 2) See Enable Timers for >= Fail Timer 1, and Reference Supporting Table 15 for Fail Timer 2	
			fail timer 1 (5-4 shifting with Closed Throttle)	>= 0.900390625 Fail Time (Sec)				
			fail timer 1 (5-6 shifting with Throttle)	>= 0.700195313 Fail Time (Sec)				
			fail timer 1 (5-6 shifting with Closed Throttle)	>= 0.900390625 Fail Time (Sec)				
			If Attained Gear Slip is Less than Above Call Increment Fail Timers					
			If fail timer is greater than threshold increment corresponding gear fail counter and total fail counter					

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			3rd gear fail counter				>= 3	3rd gear fail counts
			5th gear fail counter				>= 3	5th gear fail counts
			Total fail counter				>= 5	total fail counts
					Trans oil temperature	> 255.99 °C		
					Input Speed Sensor fault	= FALSE Boolean		
					Output Speed Sensor fault	= FALSE Boolean		
					Command / Attained Gear	≠ 1st Boolean		
					High Side Driver ON	= TRUE Boolean		
					output speed limit for TUT	>= 200 RPM		
					input speed limit for TUT	>= 200 RPM		
					TUT Enable temperature	>= 0 °C		
					PRNDL state defaulted	= FALSE Boolean		
					IMS Fault Pending	= FALSE Boolean		
					Service Fast Learn Mode	= FALSE Boolean		
					HSD Enabled	= TRUE Boolean		
					Default Gear Option is not present	= TRUE		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Transmission Output Speed Sensor (TOSS)	P077C	Output Speed Sensor Circuit Low	<p>TOSS Analog Signal Voltage</p> <p>P077C Status is not</p> <p>If the above conditons have been met, increment the P077C Fail Counter</p> <p>DTC P077C Sets when the Fail Counter</p>	<p><= 0.25 Volts</p> <p>Test Failed</p> <p>= This Key On or Fault Active</p> <p>>= 75 Counts</p>	<p>P077C Enable Calibration</p>	<p>= 1 Boolean</p>	<p>>= 0.05 sec</p>	<p>one trip</p>

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Ignition Voltage Lo Ignition Voltage Hi	>= 9 Volts <= 31.99 Volts		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: P077D		
Transmission Output Speed Sensor (TOSS)	P077D	Output Speed Sensor Circuit High	TOSS Analog Signal Voltage P077D Status is not If the above conditons have been met, increment the P077D Fail Counter	<= 4.75 Volts Test Failed = This Key On or Fault Active			>= 0.05 sec	one trip
			DTC P077D Sets when the Fail Counter	>= 75 Counts	P077D Enable Calibration Ignition Voltage Lo Ignition Voltage Hi	= 1 Boolean >= 9 Volts <= 31.99 Volts		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: P077C		
Variable Bleed Solenoid (VBS)	P0796	Pressure Control (PC) Solenoid C Stuck Off [C456] (Steady State)	<u>Fail Case</u> 1 Case: Steady State 4th Gear Gear slip Intrusive test: commanded 5th gear	>= 400 RPM			>= 5 For Neutral Timer (Sec) Please See Table 5 For Neutral Time Cal	one trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			<p>If attained Gear #5th for time</p> <p>if the above conditions have been met</p> <p>Increment 4th Gear Fail Counter</p> <p>and C456 Fail Counters</p>	<p>>=</p> <p>Table Based Time Please Refer to Table 3 in supporting documents</p> <p>Enable Time (Sec)</p>			<p>>= 2 4th Gear Fail Count</p> <p>OR</p> <p>>= 14 C456 Fail Counts</p>	
			<p><u>Fail Case 2</u> Case: Steady State 5th Gear</p> <p>Gear slip</p> <p>Intrusive test: commanded 6th gear</p> <p>If attained Gear # 6th for time</p> <p>if the above conditions have been met</p> <p>Increment 5th Gear Fail Counter</p>	<p>>=</p> <p>400 RPM</p> <p>>=</p> <p>Table Based Time Please Refer to Table 3 in supporting documents</p> <p>Enable Time (Sec)</p>			<p>>= 5 For Neutral Time Cal Neutral Timer (Sec)</p> <p>>= 2 5th Gear Fail Count</p> <p>OR</p>	

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			and C456 Fail Counters				>= 14 C456 Fail Counts	
			<p><u>Fail Case 3</u> Case: Steady State 6th Gear</p> <p>Gear slip</p> <p>Intrusive test: commanded 5th gear</p> <p>If attained Gear ≠ 5th for time</p> <p>if the above conditions have been met</p> <p>Increment 6th Gear Fail Counter and C456 Fail Counter</p> <p>and C456 Fail Counter</p>	<p>>= 400 RPM</p> <p>>= Table Based Time Please Refer to Table 3 in supporting documents Enable Time (Sec)</p>			<p>>= 5 For Neutral Timer (Sec) Time Cal</p> <p>>= 2 6th Gear Fail Count</p> <p>OR</p> <p>>= 14 C456 Fail Counts</p>	
					<p>PRNDL State defaulted = FALSE Boolean</p> <p>inhibit RVT = FALSE Boolean</p> <p>IMS fault pending indication = FALSE Boolean</p> <p>TPS validity flag = TRUE Boolean</p> <p>Hydraulic System Pressurized = TRUE Boolean</p> <p>Minimum output speed for RVT >= 0 RPM</p> <p>A OR B</p>			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					(A) Output speed enable	>= 650 RPM		
					(B) Accelerator Pedal enable	>= 0.5005 Pct		
					Common Enable Criteria			
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.99 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					Throttle Position Signal valid	= TRUE Boolean		
					HSD Enabled	= TRUE Boolean		
					Transmission Fluid Temperature	>= -6.656 °C		
					Input Speed Sensor fault	= FALSE Boolean		
					OutputSpeed Sensor fault	= FALSE Boolean		
					Default Gear Option is not present	= TRUE		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P0797	Pressure Control (PC) Solenoid C Stuck On [C456] (Steady State)	<p><u>Fail Case</u> Case: Steady State 1st Attained Gear slip</p> <p>If the Above is True for Time</p> <p>Intrusive test: (CBR1 clutch exhausted)</p> <p>Gear Ratio</p> <p>Gear Ratio</p> <p>If the above parameters are true</p>	<p>>= 400 RPM</p> <p>Table Based Time Please</p> <p>>= Refer to Table Enable Time 4 in (Sec)</p> <p>supporting documents</p> <p><= 1.529052734</p> <p>>= 1.328979492</p>			<p>>= 1.1 Fail Timer (Sec)</p> <p>>= 2 Fail Count in 1st Gear or</p> <p>>= 3 Total Fail Counts</p>	one trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			<p><u>Fail Case</u> 2 Case Steady State 2nd</p> <p>Max Delta Output Speed Hysteresis \geq</p> <p>Min Delta Output Speed Hysteresis \geq</p> <p>If the Above is True for Time \geq</p> <p>Intrusive test: (CB26 clutch exhausted)</p> <p>Gear Ratio \leq</p> <p>Gear Ratio \geq</p> <p>If the above parameters are true</p>	<p>Table Based value Please Refer to 3D Table 1 in supporting documents rpm/sec</p> <p>Table Based value Please Refer to 3D Table 2 in supporting documents rpm/sec</p> <p>Table Based Time Please Refer to Table 17 in supporting documents Sec</p> <p>1.529052734</p> <p>1.328979492</p>			<p>\geq 1.1 Fail Timer (Sec)</p> <p>\geq 3 Fail Count in 2nd Gear</p> <p>or</p> <p>\geq 3 Total fail counts</p>	
			<p><u>Fail Case</u> 3 Case Steady State 3rd</p>					

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Max Delta Output Speed Hysteresis	>=	Table Based value Please Refer to 3D Table 1 in supporting documents rpm/sec			
			Min Delta Output Speed Hysteresis	>=	Table Based value Please Refer to 3D Table 2 in supporting documents rpm/sec			
			If the Above is True for Time	>=	Table Based Time Please Refer to Table 17 in supporting documents Sec			
			Intrusive test: (C35R clutch exhausted)					
			Gear Ratio	<=	1.529052734			
			Gear Ratio	>=	1.328979492			
			If the above parameters are true				>= 1.1 Fail Timer (Sec)	
							>= 3 Fail Count in 3rd Gear	
							OR	
							>= 3 Total Fail Counts	
						PRNDL State defaulted = FALSE Boolean		
						inhibit RVT = FALSE Boolean		
						IMS fault pending indication = FALSE Boolean		
						output speed >= 0 RPM		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					TPS validity flag	= TRUE Boolean		
					HSD Enabled	= TRUE Boolean		
					Hydraulic_System_Pressurized	= TRUE Boolean		
					Minimum output speed for RVT	>= 0 Nm		
					A OR B			
					(A) Output speed enable	>= 650 Nm		
					(B) Accelerator Pedal enable	>= 0.5005 Nm		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.99 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					if Attained Gear=1st FW Accelerator Pedal enable	>= 10.001 Pct		
					if Attained Gear=1st FW Engine Torque Enable	>= 45 Nm		
					if Attained Gear=1st FW Engine Torque Enable	<= 8191.9 Nm		
					Transmission Fluid Temperature	>= -6.656 °C		
					Input Speed Sensor fault	= FALSE Boolean		
					Output Speed Sensor fault	= FALSE Boolean		
					Default Gear Option is not present	= TRUE		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P0797	Pressure Control (PC) Solenoid C Stuck On [C456] (Dynamic)	Primary Offgoing Clutch is exhausted (See Table 11 in Supporting Documents for Exhaust Delay Timers) Primary Oncoming Clutch Pressure Command Status Primary Offgoing Clutch Pressure Command Status Range Shift Status Attained Gear Slip	= TRUE Boolean = Maximum pressurized = Clutch exhaust command ≠ Initial Clutch Control ≤ 40 RPM				one trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			If the above conditions are true increment appropriate Fail 1 Timers Below:					
			fail timer 1 (4-1 shifting with throttle)	>= 0.700195313	Fail Time (Sec)			
			fail timer 1 (4-1 shifting without throttle)	>= 0.900390625	Fail Time (Sec)			
			fail timer 1 (4-2 shifting with throttle)	>= 0.700195313	Fail Time (Sec)			
			fail timer 1 (4-2 shifting without throttle)	>= 0.900390625	Fail Time (Sec)			
			fail timer 1 (4-3 shifting with throttle)	>= 0.700195313	Fail Time (Sec)			
			fail timer 1 (4-3 shifting without throttle)	>= 0.900390625	Fail Time (Sec)			
			fail timer 1 (5-3 shifting with throttle)	>= 0.700195313	Fail Time (Sec)			
			fail timer 1 (5-3 shifting without throttle)	>= 0.900390625	Fail Time (Sec)			
			fail timer 1 (6-2 shifting with throttle)	>= 0.700195313	Fail Time (Sec)			
			fail timer 1 (6-2 shifting without throttle)	>= 0.900390625	Fail Time (Sec)			
			If Attained Gear Slip is Less than Above Call Increment Fail Timers				Total Fail Time = (Fail 1 + Fail 2) See Enable Timers for Fail	

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			<p>If fail timer is greater than threshold increment corresponding gear fail counter and total fail counter</p>				<p>Timer 1, and Reference Supporting Table 15 for Fail Timer 2</p>	
			<p>4th gear fail counter</p>				<p>>= 3 Fail Counter From 4th Gear</p>	
			<p>5th gear fail counter</p>				<p>OR >= 3 Fail Counter From 5th Gear</p>	
			<p>6th gear fail counter</p>				<p>OR >= 3 Fail Counter From 6th Gear</p>	
			<p>Total fail counter</p>				<p>OR >= 5 Total Fail Counter</p>	
					<p>Trans oil temperature</p>	<p>> 255.99 °C</p>		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Input Speed Sensor fault	= FALSE Boolean		
					Output Speed Sensor fault	= FALSE Boolean		
					Command / Attained Gear	≠ 1st Boolean		
					High Side Driver ON	= TRUE Boolean		
					output speed limit for TUT	>= 200 RPM		
					input speed limit for TUT	>= 200 RPM		
					TUT Enable temperature	>= 0 °C		
					PRNDL state defaulted	= FALSE Boolean		
					IMS Fault Pending	= FALSE Boolean		
					Service Fast Learn Mode	= FALSE Boolean		
					HSD Enabled	= TRUE Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Transmission Input Speed Sensor (TISS)	P07BF	Input/Turbine Speed Sensor A Circuit Low	TISS Analog Signal Voltage	<= 0.25 Volts			>= 0.05 sec	one trip
			P07BF Status is not	= Test Failed This Key On or Fault Active				
			If the above conditons have been met, increment the P07BF Fail Counter					
			DTC P07BF Sets when the Fail Counter	>= 75 Counts				
					P07BF Enable Calibration = 1 Boolean Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.99 Volts			
					Disable Conditions:	MIL not Illuminated for DTC's:		
Transmission Input Speed Sensor (TISS)	P07C0	Input/Turbine Speed Sensor A Circuit High	TISS Analog Signal Voltage	>= 4.75 Volts			>= 0.05 sec	one trip
			P07C0 Status is not	= Test Failed This Key On or Fault Active				
			If the above conditons have been met, increment the P07C0 Fail Counter					

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			DTC P07C0 Sets when the Fail Counter	>= 75 Counts	P07C0 Enable Calibration Ignition Voltage Lo Ignition Voltage Hi	= 1 Boolean >= 9 Volts <= 31.99 Volts		
				Disable Conditions:	MIL not Illuminated for DTC's:			
Tap Up Tap Down Switch (TUTD)	P0815	Upshift Switch Circuit	Fail Case 1 Tap Up Switch Stuck in the Up Position in Range 1 Enabled	= 1 Boolean				Special No Trip
			Tap Up Switch Stuck in the Up Position in Range 2 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 3 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 4 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 5 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 6 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Neutral Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Park Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Reverse Enabled	= 1 Boolean				

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Tap Up Switch ON	= TRUE Boolean			>= 1 Fail Time (Sec)	
			Fail Case 2 Tap Up Switch Stuck in the Up Position in Range 1 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 2 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 3 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 4 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 5 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 6 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Neutral Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Park Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Reverse Enabled	= 1 Boolean				
			Tap Up Switch ON	= TRUE Boolean				
			NOTE: Both Failcase1 and Failcase 2 Must Be Met				>= 600 Fail Time (Sec)	

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Time Since Last Range Change Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for P0815 Status is	>= 1 >= 9 <= 31.99 >= 400 <= 7500 >= 5 ≠	Enable Time (Sec) Volts Volts RPM RPM Sec Test Failed This Key On or Fault Active	
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0816, P0826, P182E, P1876, P1877, P1915, P1761 ECM: None		
Tap Up Tap Down Switch (TUTD)	P0816	Downshift Switch Circuit	<u>Fail Case 1</u> Tap Down Switch Stuck in the Down Position in Range 1 Enabled Tap Down Switch Stuck in the Down Position in Range 2 Enabled Tap Down Switch Stuck in the Down Position in Range 3 Enabled Tap Down Switch Stuck in the Down Position in Range 4 Enabled	= 1 Boolean = 1 Boolean = 1 Boolean = 1 Boolean				Special No Trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Tap Down Switch Stuck in the Down Position in Range 5 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 6 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range Neutral Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range Park Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range Reverse Enabled	= 1 Boolean				
			Tap Down Switch ON	= TRUE Boolean			>= 1 sec	
			<u>Fail Case 2</u> Tap Down Switch Stuck in the Down Position in Range 1 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 2 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 3 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 4 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 5 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 6 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Neutral Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Park Enabled	= 1 Boolean				

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Tap Down Switch Stuck in the Down Position in Reverse Enabled Tap Down Switch ON NOTE: Both Failcase 1 and Failcase 2 Must Be Met	= 1 Boolean = TRUE Boolean			>= 600 sec	
					Time Since Last Range Change Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for P0816 Status is Disable Conditions:	>= 1 Enable Time (Sec) >= 9 Volts <= 31.99 Volts >= 400 RPM <= 7500 RPM >= 5 Sec ≠ Test Failed This Key On or Fault Active MIL not Illuminated for DTC's:		
Tap Up Tap Down Switch (TUTD)	P0826	Up and Down Shift Switch Circuit	TUTD Circuit Reads Invalid Voltage	= TRUE Boolean		TCM: P0815, P0826, P182E, P1876, P1877, P1915, P1761 ECM: None	>= 60 Fail Time (Sec)	Special No Trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for P0826 Status is	>= 9 Volts <= 31.99 Volts >= 400 RPM <= 7500 RPM >= 5 Sec Test Failed This Key On or Fault Active ≠		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: P1761 ECM: None		
Transmission Fluid Pressure Switch	P0872	Transmission Fluid Pressure (TFP) Sensor C Circuit Low Voltage	CB26 Hydraulic pressure Hydraulic Delay Timer (Table Based) Check for Switch to be in Exhausted Position after delay. If so then Increment Fail Counter	<= 50 KPa >= See Table 8 for Delay Timer Cal Sec			>= 8 Fail Counts	Special No Trip
			Note: Subsequent fail counts require CB26 pressure above this value to re-enable fail logic. Results in one fail count per clutch transition	> 50 Kpa				
					Transmission Fluid Temperature Lo	>= -6.656 °C		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Transmission Fluid Temperature Hyst Hi (disable above this)	Not >= 110 °C		
					Transmission Fluid Temperature Hyst Lo (enable below this)	<= 100 °C		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.99 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					Default Gear Action	= FALSE		
					High Side Driver ON	= TRUE		
					RVT Status	= Normal		
					Hydraulic Pressure Available	= TRUE		
					Engine Speed Min	>= 550 RPM		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0711, P0712, P0713, P0716, P0717, P0722, P0723, P0751, P0742, P0756, P0757, P0973, P0974, P0976, P0977, P1915, P182E ECM: None		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
Transmission Fluid Pressure Switch	P0873	Transmission Fluid Pressure (TFP) Sensor C Circuit High Voltage	CB26 Hydraulic Pressure	>= 700 KPa				Special No Trip
			Hydraulic Delay Timer (Table Based)	>= See Table 8 for Delay Timer Cal Sec				
			Check for Switch to be in Pressurized Position after delay. If so then Increment Fail Counter				>= 11 Fail Counts	
			Note: Subsequent fail counts require CB26 pressure below this value to re-enable fail logic. Results in one fail count per clutch transition	< 700 kpa				
					Transmission Fluid Temperature Lo	>= -6.656 °C		
					Transmission Fluid Temperature Hyst Hi (disable above this)	Not >= 110 °C		
					Transmission Fluid Temperature Hyst Lo (enable below this)	<= 100 °C		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.99 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					Default Gear Action	= FALSE		
					High Side Driver ON	= TRUE		
					RVT Status	= Normal		
					Hydraulic Pressure Available	= TRUE		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Engine Speed Min Disable Conditions: MIL not Illuminated for DTC's:	>= 550 RPM TCM: P0711, P0712, P0713, P0716, P0717, P0722, P0723, P0751, P0742, P0756, P0757, P0973, P0974, P0976, P0977, P1915, P182E ECM: None		
Transmission Fluid Pressure Switch	P0877	Transmission Fluid Pressure (TFP) Sensor D Circuit Low Voltage	C1234 Hydraulic pressure Hydraulic Delay Timer (Table Based) Check for Switch to be in Exhausted Position after delay. If so then Increment Fail Counter	<= 50 KPa >= See Table 6 for Delay Timer Cal Sec			>= 12 Fail Counts	Special No Trip
			Note: Subsequent fail counts require C1234 pressure above this value to re-enable fail logic. Results in one fail count per clutch transition	> 50 kpa				
					Transmission Fluid Temperature Lo	>= -6.656 °C		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Transmission Fluid Temperature Hyst Hi (disable above this)	Not >= 110 °C		
					Transmission Fluid Temperature Hyst Lo (enable below this)	<= 100 °C		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.99 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					Default Gear Action	= FALSE		
					High Side Driver ON	= TRUE		
					RVT Status	= Normal		
					Hydraulic Pressure Available	= TRUE		
					Engine Speed Min	>= 550 RPM		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0711, P0712, P0713, P0716, P0717, P0722, P0723, P0751, P0742, P0756, P0757, P0973, P0974, P0976, P0977, P1915, P182E ECM: None		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
Transmission Fluid Pressure Switch	P0878	Transmission Fluid Pressure (TFP) Sensor D Circuit High Voltage	C1234 Hydraulic pressure	>= 700 KPa				Special No Trip
			Hydraulic Delay Timer (Table Based)	>= See Table 6 for Delay Timer Cal Sec				
			Check for Switch to be in Pressurized Position after delay. If so then Increment Fail Counter				>= 12 Fail Counts	
			Note: Subsequent fail counts require C1234 pressure below this value to re-enable fail logic. Results in one fail count per clutch transition	< 700 Kpa				
					Transmission Fluid Temperature Lo	>= -6.656 °C		
					Transmission Fluid Temperature Hyst Hi (disable above this)	Not >= 110 °C		
					Transmission Fluid Temperature Hyst Lo (enable below this)	<= 100 °C		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.99 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					Default Gear Action	= FALSE		
					High Side Driver ON	= TRUE		
					RVT Status	= Normal		
					Hydraulic Pressure Available	= TRUE		
					Engine Speed Min	>= 550 RPM		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Disable Conditions: MIL not illuminated for	TCM: P0711, P0712, P0713, P0716, P0717, P0722, P0723, P0751, P0742, P0756, P0757, P0973, P0974, P0976, P0977, P1915, P182E ECM: None		
Variable Bleed Solenoid (VBS)	P0961	Pressure Control (PC) Solenoid A Control Circuit Rationality Test (Line Pressure VBS)	The HWIO reports an invalid voltage (out of range) error flag	= TRUE Boolean			Fail Time (Sec) >= 4.4 Sample Time (Sec) out of 5	two trips
					Ignition Voltage >= 9 Volts Ignition Voltage <= 31.99 Volts Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec	TCM: None ECM: None		
					Disable Conditions: MIL not illuminated for	TCM: None ECM: None		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
Variable Bleed Solenoid (VBS)	P0962	Pressure Control (PC) Solenoid A Control Circuit Low Voltage (Line Pressure VBS)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			Fail Time (Sec) >= 1.5 Sample out of 1.875 Time (Sec)	one trip
Variable Bleed Solenoid (VBS)	P0963	Pressure Control (PC) Solenoid A Control Circuit High Voltage (Line Pressure VBS)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			Fail Time (Sec) >= 4.4 Sample out of 5 Time (Sec)	two trips

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
Variable Bleed Solenoid (VBS)	P0966	Pressure Control (PC) Solenoid B Control Circuit Low Voltage (C35R VBS)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			Fail Time (Sec)	one trip
							>= 0.3	
							Sample out of 0.375 Time (Sec)	
					Ignition Voltage	>= 9 Volts		
					Ignition Voltage	<= 31.99 Volts		
					Engine Speed	>= 400 RPM		
					Engine Speed	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					P0966 Status is not	= Test Failed This Key On or Fault Active		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Bleed Solenoid (VBS)	P0967	Pressure Control (PC) Solenoid B Control Circuit High Voltage (C35R VBS)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			Fail Time (Sec)	one trip
							>= 0.3	
							Sample out of 0.375 Time (Sec)	
					Ignition Voltage	>= 9 Volts		
					Ignition Voltage	<= 31.99 Volts		
					Engine Speed	>= 400 RPM		
					Engine Speed	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						Test Failed This Key On or Fault Active = TCM: None ECM: None		
Variable Bleed Solenoid (VBS)	P0970	Pressure Control (PC) Solenoid C Control Circuit Low Voltage (C456/CBR1 VBS)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			Fail Time (Sec) >= 0.3 Sample Time (Sec) out of 0.375	one trip
						Test Failed This Key On or Fault Active = Ignition Voltage >= 9 Volts Ignition Voltage <= 31.99 Volts Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec TCM: None ECM: None		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
Variable Bleed Solenoid (VBS)	P0971	Pressure Control (PC) Solenoid C Control Circuit High Voltage (C456/CBR1 VBS)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			Fail Time (Sec) >= 0.3 Sample Time (Sec) out of 0.375	one trip
Shift Solenoid	P0973	Shift Solenoid A Control Circuit Low (Mode 2 Solenoid)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			Fail Time (Sec) >= 1.2 Sample Time (Sec) out of 1.5	one trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Engine Speed Engine Speed is within the allowable limits for Disable Conditions: MIL not Illuminated for DTC's:	<= 7500 RPM >= 5 Sec TCM: None ECM: None		
Shift Solenoid	P0974	Shift Solenoid A Control Circuit High (Mode 2 Solenoid)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			>= 1.2 Fail Time (Sec) out of 1.5 Sample Time (Sec)	two trips
Transmission Fluid Pressure Switch	P0989	Transmission Fluid Pressure (TFP) Sensor E Circuit Low Voltage	CBR1/C456 Hydraulic pressure Hydraulic Delay Timer (Table Based)	<= 50 Kpa >= See Table 9 for Delay Timer Cal Sec				Special No Trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Check for Switch to be in Exhausted Position after delay. If so then Increment Fail Counter				>= 17 Fail Counts	
			Note: Subsequent fail counts require C35R pressure above this value to re-enable fail logic. Results in one fail count per clutch transition	> 50 kpa				
					Transmission Fluid Temperature Lo Transmission Fluid Temperature Hyst Hi (disable above this) Transmission Fluid Temperature Hyst Lo (enable below this) Ignition Voltage Lo Ignition Voltage Hi Engine Speed Lo Engine Speed Hi Engine Speed is within the allowable limits for Default Gear Action High Side Driver ON RVT Status Hydraulic Pressure Available Engine Speed Min Disable Conditions:	>= -6.656 °C Not >= 110 °C <= 100 °C >= 9 Volts <= 31.99 Volts >= 400 RPM <= 7500 RPM >= 5 Sec = FALSE = TRUE = Normal = TRUE >= 550 RPM TCM: P0711, P0712, P0713, P0716, P0717,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.	
						P0722, P0723, P0751, P0742, P0756, P0757, P0973, P0974, P0976, P0977, P1915, P182E ECM: None			
Transmission Fluid Pressure Switch	P0990	Transmission Fluid Pressure (TFP) Sensor E Circuit High Voltage	CBR1/C456 Hydraulic pressure	>= 700 Kpa				>= 30 Fail Counts	Special No Trip
			Hydraulic Delay Timer (Table Based)	>=	See Table 9 for Delay Timer Cal	Sec			
			Check for Switch to be in Pressurized Position after delay, If so then Increment Fail Counter						
			Note: Subsequent fail counts require C35R pressure above this value to re-enable fail logic. Results in one fail count per clutch transition	<	700 kpa				
					Transmission Fluid Temperature Lo	>= -6.656 °C			
					Transmission Fluid Temperature Hyst Hi (disable above this)	Not >= 110 °C			
					Transmission Fluid Temperature Hyst Lo (enable below this)	<= 100 °C			
					Ignition Voltage Lo	>= 9 Volts			
					Ignition Voltage Hi	<= 31.99 Volts			
					Engine Speed Lo	>= 400 RPM			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Engine Speed Hi Engine Speed is within the allowable limits for Default Gear Action High Side Driver ON RVT Status Hydraulic Pressure Available Engine Speed Min	<= 7500 RPM >= 5 Sec = FALSE = TRUE = Normal = TRUE >= 550 RPM		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0711, P0712, P0713, P0716, P0717, P0722, P0723, P0751, P0742, P0756, P0757, P0973, P0974, P0976, P0977, P1915, P182E ECM: None		
Tap Up Tap Down Switch (TUTD)	P1761	Tap Up and Down switch signal circuit (rolling count)	Rolling count value received from BCM does not match expected value	= TRUE Boolean			>= 3 Fail Counter > 10 Sample Timer (Sec)	Special No Trip
					Tap Up Tap Down Message Health	= TRUE Boolean		
					Engine Speed Lo	>= 400 RPM		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Engine Speed Hi Engine Speed is within the allowable limits for Disable Conditions: MIL not Illuminated for DTC's:	<= 7500 RPM >= 5 Sec TCM: None ECM: None		
Internal Mode Switch (IMS)	P182E	Internal Mode Switch - Circuit A Low Reported as Internal Mode Switch-Invalid Range	<u>Fail Case 1</u> Current range = "Transitional 1" Range State Previous range ≠ CeTRGR_e_P RNDL_Drive6 Range State Previous range ≠ CeTRGR_e_P RNDL_Drive5 Range State Either the S1 or S3 Pressure Switch indicates "Pressure Present" = TRUE Boolean Engine Torque >= -50 Nm Engine Torque <= 8191.75 Nm If the above conditions are present Increment Fail Timer If Fail Timer has Expired then Increment Fail Counter				Fail >= 0.225 Seconds Fail >= 15 Counts	one trip
			<u>Fail Case 2</u> Current range = "Transitional 1" Range State S3 Pressure Switch indicates "Exhausted" = TRUE Boolean Commanded Gear = 1st Locked Gear If the above conditions are present Increment Fail Timer				Fail >= 0.225 Seconds	

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			If Fail Timer has Expired then Increment Fail Counter				>= 15 Fail Counts	
			<u>Fail Case 3</u>					
			Current range	= "Transitional 13"	Previous range	≠ CeTRG R_e_P RNDL_Drive5		
			Either the S1 or S3 Pressure Switch indicates "Pressure Present"	= TRUE Boolean	Previous range	≠ CeTRG R_e_P RNDL_Drive5		
			Engine Torque	>= -8192 Nm	IMS is 7 position configuration	= 0 Boolean		
			Engine Torque	<= 8191.75 Nm	If the "IMS 7 Position config" = 1 then the "previous range" criteria above must also be satisfied when the "current range" = "Transitional 13"			
			If the above conditions are present Increment Fail Timer				>= 0.225 Seconds	
			If Fail Timer has Expired then Increment Fail Counter				>= 15 Fail Counts	
			<u>Fail Case 4</u>					
			Current range	= "Transitional 2" or "Transitional 8"	Disable Fail Case 4 if last positive range was Drive 6 and current range is transitional 8			
			Inhibit bit (see definition)	= FALSE	Set inhibit bit true if PRNDL = 1100 (rev) or 0100 (Rev-Neu transitional) Set inhibit bit false if PRNDL = 1001 (park)			
			Either the S1 or S3 Pressure Switch indicates "Pressure Present"	= TRUE Boolean				

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Steady State Engine Torque	>= 20 Nm				
			Steady State Engine Torque	<= 8191.75 Nm				
			If the above conditions are present Increment Fail Timer				>= 0.225 Seconds	
			If the above Conditions have been met, Increment Fail Counter				>= 15 Fail Counts	
			<u>Fail Case 5</u>					
			Current range	= "Transitional 11"				
			Engine Torque	>= 20 Nm				
			Either the S1 or S3 Pressure Switch indicates "Pressure Present"	= TRUE Boolean				
			If the above conditions are present Increment Fail Timer				>= 0.225 Seconds	
			If the above Conditions have been met, Increment Fail Counter				>= 15 Fail Counts	
			<u>Fail Case 6</u>					
			Current range	= "Illegal"	A Open Circuit Definition (flag set false if the following conditions are met):			
			and		Current Range	≠ "Transitional 11"		
			A Open Circuit (See Definition)	= FALSE Boolean	or			
					Last positive state	≠ Neutral		
					or			
					Previous transitional state	≠ Transitional 8 and Illegal		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						and PRNDL Circuit A = Open Circuit PRNDL Circuit B = Closed Circuit PRNDL Circuit C = Open Circuit PRNDL Circuit P = Open Circuit	>= 6.25 Seconds	
			If the above Conditions are present, Increment Fail timer					
			<u>Fail Case</u> Z	Current PRNDL State = PRNDL circuit ABCP = 1101				
			and Previous valid state = PRNDL circuit ABCP = 1111 Range					
			Input Speed >= 150 RPM					
			Reverse Trans Ratio <= 2.795898438 ratio					
			Reverse Trans Ratio >= 3.149047852 ratio					
			If the above Conditions are present, Increment Fail timer				>= 6.25 Seconds	
			P182E will report test fail when any of the above 7 fail cases are met					
						Ignition Voltage Lo >= 9 Volts		
						Ignition Voltage Hi <= 31.99 Volts		
						Vehicle Speed Lo <= 511 KPH		
						Engine Speed Lo >= 400 RPM		
						Engine Speed Hi <= 7500 RPM		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Engine Speed is within the allowable limits for Engine Torque Signal Valid Disable Conditions: MIL not Illuminated for DTC's:	>= 5 Sec = TRUE Boolean		
Tap Up Tap Down Switch (TUTD)	P1876	Tap Up and Down Enable Switch Circuit	Current range = Park or Reverse or Neutral Range State TUTD Enable Switch is Active = TRUE Boolean				>= 3 Fail Time (Sec) >= 5 Fail Counts	Special No Trip
					Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.99 Volts Vehicle Speed Lo <= 511 KPH Engine Speed Lo >= 400 RPM Engine Speed Hi <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec P1876 Status is ≠ Test Failed This Key On or Fault Active Disable Conditions: MIL not Illuminated for DTC's:	TCM: P0815, P0816, P0826, P1761, P1825, P1877,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.		
						P1915, U0100 ECM: None				
Internal Mode Switch (IMS)	P1915	Internal Mode Switch Does Not Indicate Park/Neutral (P/N) During Start	PRNDL State is	≠	Park or Neutral Enumeration			one trip		
			The following events must occur Sequentially							
			Initial Engine speed	<=	50 RPM			>= 0.1	Enable Time (Sec)	
			Then							
			Engine Speed Between Following Cals							
			Engine Speed Lo Hist	>=	50 RPM					
			Engine Speed Hi Hist	<=	480 RPM			>= 0.069	Enable Time (Sec)	
			Then							
			Final Engine Speed	>=	500 RPM					
			Final Transmission Input Speed	>=	100 RPM			>= 1.25	Fail Time (Sec)	
					DTC has Ran this Key Cycle?	=	FALSE Boolean			
					Ignition Voltage Lo	>=	6 V			
					Ignition Voltage Hi	<=	31.99 V			
					Ignition Voltage Hyst High (enables above this value)	>=	6 V			
					Ignition Voltage Hyst Low (disabled below this value)	<=	2 V			
					Transmission Output Speed	<=	90 rpm			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					P1915 Status is	≠ Test Failed This Key On or Fault Active TCM: P0722, P0723 ECM: None		
Transmission Control Module (TCM)	P2534	Ignition Switch Run/Start Position Circuit Low	Run crank active (based on voltage thresholds below)	= FALSE		Disable Conditions: MIL not Illuminated for DTC's:		one trip
			Ignition Voltage High Hyst (run crank goes true when above this value) Ignition Voltage Low Hyst (run crank goes false when below this value)	6 Volts 2 Volts	≥ 280 Fail Counts (25ms loop) Out of 280 Sample Counts (25ms loop)			
					Normal CAN Comm Enabled ECM run/crank active status	= TRUE Boolean = TRUE Boolean		
					Disable Conditions: MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Bleed Solenoid (VBS)	P2714	Pressure Control (PC) Solenoid D Stuck Off [CB26]	<u>Fail Case</u> 1 Case: Steady State 2nd Gear					one trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Gear slip	>= 400 RPM			Pleas e See Table 5 For Neutr al Time Cal	
			Intrusive test: commanded 3rd gear					
			If attained Gear = 3rd for Time	>=	Table Based Time Please see Table 2 in Supporting Documents		Enable Time (Sec)	
			If Above Conditions have been met					
			Increment 2nd gear fail count				>= 3	2nd Gear Fail Count
			and CB26 Fail Count				>= 14	CB26 Fail Count
			<u>Fail Case</u> 2 Case: Steady State 6th Gear					
			Gear slip	>= 400 RPM			Pleas e See Table 5 For Neutr al Time Cal	
			Intrusive test: commanded 5th gear					
			If attained Gear = 5th For Time	>=	Table Based Time Please see Table 2 in Supporting Documents		Enable Time (Sec)	

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			If Above Conditions have been met, Increment 5th gear fail counter and CB26 Fail Count				>= 3 5th Gear Fail Count or >= 14 CB26 Fail Count	
					PRNDL State defaulted = FALSE Boolean inhibit RVT = FALSE Boolean IMS fault pending indication = FALSE Boolean TPS validity flag = TRUE Boolean Hydraulic System Pressurized = TRUE Boolean Minimum output speed for RVT >= 0 RPM A OR B (A) Output speed enable >= 650 RPM (B) Accelerator Pedal enable >= 0.5005 Pct Common Enable Criteria Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.99 Volts Engine Speed Lo >= 400 RPM Engine Speed Hi <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec Throttle Position Signal valid = TRUE Boolean HSD Enabled = TRUE Boolean Transmission Fluid Temperature >= -6.656 °C Input Speed Sensor fault = FALSE Boolean Output Speed Sensor fault = FALSE Boolean Default Gear Option is not present = TRUE			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P2715	Pressure Control (PC) Solenoid Stuck On [CB26] (Dynamic)	Primary Offgoing Clutch is exhausted (See Table 13 in Supporting Documents for Exhaust Delay Timers) Primary Oncoming Clutch Pressure Command Status	= TRUE Boolean = Maximum pressurized				one trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.	
			Primary Offgoing Clutch Pressure Command Status =	Clutch exhaust command					
			Range Shift Status ≠	Initial Clutch Control					
			Attained Gear Slip ≤	40 RPM					
			If above coditons are true, increment appropriate Fail 1 Timers Below:						
			fail timer 1 (2-1 shifting with throttle) ≥	0.700195313	Fail Time (Sec)				
			fail timer 1 (2-1 shifting without throttle) ≥	0.900390625	Fail Time (Sec)				
			fail timer 1 (2-3 shifting with throttle) ≥	0.700195313	Fail Time (Sec)				
			fail timer 1 (2-3 shifting without throttle) ≥	0.900390625	Fail Time (Sec)				
			fail timer 1 (2-4 shifting with throttle) ≥	0.700195313	Fail Time (Sec)				
			fail timer 1 (2-4 shifting without throttle) ≥	0.900390625	Fail Time (Sec)				
			fail timer 1 (6-4 shifting with throttle) ≥	0.700195313	Fail Time (Sec)				
			fail timer 1 (6-4 shifting without throttle) ≥	0.900390625	Fail Time (Sec)				
			fail timer 1 (6-5 shifting with throttle) ≥	0.700195313	Fail Time (Sec)				
			fail timer 1 (6-5 shifting without throttle) ≥	0.900390625	Fail Time (Sec)				
			If Attained Gear Slip is Less than Above Call Increment Fail Timers						
							Total Fail Time = (Fail	sec	

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			<p>If fail timer is greater than threshold increment corresponding gear fail counter and total fail counter</p> <p>2nd gear fail counter</p> <p>6th gear fail counter</p> <p>total fail counter</p>				<p>1 + Fail 2) See Enable Timers for Fail Timer 1, and Reference Supporting Table 15 for Fail Timer 2</p> <p>>= 3 Fail Counter From 2nd Gear</p> <p>OR</p> <p>>= 3 Fail Counter From 6th Gear</p> <p>OR</p> <p>>= 5 Total Fail Counter</p>	
					Trans oil temperature	> 255.99 °C		
					Input Speed Sensor fault	= FALSE Boolean		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Output Speed Sensor fault Command / Attained Gear High Side Driver ON output speed limit for TUT input speed limit for TUT TUT Enable temperature PRNDL state defaulted IMS Fault Pending Service Fast Learn Mode HSD Enabled Disable Conditions:	= FALSE Boolean ≠ 1st Boolean = TRUE Boolean >= 200 RPM >= 200 RPM >= 0 °C = FALSE Boolean = FALSE Boolean = FALSE Boolean = TRUE Boolean MIL not Illuminated for DTC's: TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305.		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P2715	Pressure Control (PC) Solenoid D Stuck On [CB26] (Steady State)	<u>Fail Case 1</u> Case: Steady State 1st Gear Attained Gear slip If the Above is True for Time Intrusive test: (CBR1 clutch exhausted) Gear Ratio Gear Ratio If the above parameters are true	>= 400 RPM Table Based Time Please Refer to Table 4 in supporting documents >= 3.112670898 >= 2.705322266			>= 1.1 Fail Timer (Sec) >= 8 Fail Count in 1st Gear or >= 8 Total Fail Counts	one trip
			<u>Fail Case 2</u> Case: Steady State 3rd Gear					

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Max Delta Output Speed Hysteresis	>=	Table Based value Please Refer to 3D Table 1 in supporting documents rpm/sec			
			Min Delta Output Speed Hysteresis	>=	Table Based value Please Refer to 3D Table 2 in supporting documents rpm/sec			
			If the Above is True for Time	>=	Table Based Time Please Refer to Table 17 in supporting documents Sec			
			Intrusive test: (C35R clutch exhausted)					
			Gear Ratio	<=	3.112670898			
			Gear Ratio	>=	2.705322266			
			If the above parameters are true					
							>= 1.1	Fail Timer (Sec)
							>= 3	Fail Count in 3rd Gear or
							>= 8	Total Fail Counts
			Fail Case 3 Case: Steady State 4rd Gear					

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Max Delta Output Speed Hysteresis	>=	Table Based value Please Refer to 3D Table 1 in supporting documents rpm/sec			
			Min Delta Output Speed Hysteresis	>=	Table Based value Please Refer to 3D Table 2 in supporting documents rpm/sec			
			If the Above is True for Time	>=	Table Based Time Please Refer to Table 17 in supporting documents Sec			
			Intrusive test: (C1234 clutch exhausted)					
			Gear Ratio	<=	0.798217773			
			Gear Ratio	>=	0.693725586			
			If the above parameters are true					
							>= 1.1	Fail Timer (Sec)
							>= 3	Fail Count in 4th Gear
								or
							>= 8	Total Fail Counts
			<u>Fail Case</u> 4 Case: Steady State 5th Gear					

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Max Delta Output Speed Hysteresis	>=	Table Based value Please Refer to 3D Table 1 in supporting documents rpm/sec			
			Min Delta Output Speed Hysteresis	>=	Table Based value Please Refer to 3D Table 2 in supporting documents rpm/sec			
			If the Above is True for Time	>=	Table Based Time Please Refer to Table 17 in supporting documents Sec			
			Intrusive test: (C35R clutch exhausted)					
			Gear Ratio	<=	0.798217773			
			Gear Ratio	>=	0.693725586			
			If the above parameters are true				>= 1.1	Fail Timer (Sec)
							>= 3	Fail Count in 5th Gear
							or	
							>= 8	Total Fail Counts
					PRNDL State defaulted = FALSE Boolean inhibit RVT = FALSE Boolean			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					IMS fault pending indication	= FALSE Boolean		
					output speed	>= 0 RPM		
					TPS validity flag	= TRUE Boolean		
					HSD Enabled	= TRUE Boolean		
					Hydraulic_System_Pressurized	= TRUE Boolean		
					Minimum output speed for RVT	>= 0 Nm		
					A OR B			
					(A) Output speed enable	>= 650 Nm		
					(B) Accelerator Pedal enable	>= 0.5005 Nm		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.99 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					if Attained Gear=1st FW Accelerator Pedal enable	>= 10.001 Pct		
					if Attained Gear=1st FW Engine Torque Enable	>= 45 Nm		
					if Attained Gear=1st FW Engine Torque Enable	<= 8191.9 Nm		
					Transmission Fluid Temperature	>= -6.656 °C		
					Input Speed Sensor fault	= FALSE Boolean		
					Output Speed Sensor fault	= FALSE Boolean		
					Default Gear Option is not present	= TRUE		
				Disable Conditions:	MIL not illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P2720	Pressure Control (PC) Solenoid D Control Circuit Low (CB26 VBS)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			Fail Time (Sec) >= 0.3 Sample Time (Sec) out of 0.375	one trip
					P2770 Status is not	= Test Failed This Key On or Fault Active		
					Ignition Voltage	>= 9 Volts		
					Ignition Voltage	<= 31.99 Volts		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec Disable Conditions: MIL not Illuminated for DTC's:	TCM: None ECM: None		
Variable Bleed Solenoid (VBS)	P2721	Pressure Control (PC) Solenoid D Control Circuit High (CB26 VBS)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			Fail Time (Sec) >= 0.3 Sample out of 0.375 Time (Sec)	one trip
					P2721 Status is not = Ignition Voltage >= 9 Volts Ignition Voltage <= 31.99 Volts Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec Disable Conditions: MIL not Illuminated for DTC's:	Test Failed This Key On or Fault Active TCM: None ECM: None		
Variable Bleed Solenoid (VBS)	P2723	Pressure Control (PC) Solenoid E Stuck Off	<u>Fail Case</u> 1 Case: Steady State 1st Gear					one trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Gear slip	>= 400 RPM			Please See Table 5 For Neutral Timer (Sec) >= 5 Neutral Timer (Sec) Time Cal	
			Intrusive test: commanded 2nd gear					
			If attained Gear ≠ 2nd for Time	>=	Table based Timer, Please See Table 3 in Supporting Documents		Enable Time (Sec)	
			If Above Conditions have been met, Increment 1st gear fail counter				>= 2	1st Gear Fail Count
			and C1234 fail counter				>= 14	or C1234 Clutch Fail Count
			<u>Fail Case 2</u> Case: Steady State 2nd Gear					
			Gear slip	>= 400 RPM			Please See Table 5 For Neutral Timer (Sec) >= 5 Neutral Timer (Sec) Time Cal	
			Intrusive test: commanded 3rd gear					
			If attained Gear ≠ 3rd for Time	>=	Table based Timer, Please See Table 3 in Supporting Documents		Enable Time (Sec)	

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			<p>If Above Conditions have been met, Increment 2nd gear fail counter</p> <p>and C1234 fail counter</p>				<p>>= 2 2nd Gear Fail Count</p> <p>or</p> <p>>= 14 C1234 Clutch Fail Count</p>	
			<p><u>Fail Case 3</u> Case: Steady State 3rd Gear</p> <p>Gear slip</p> <p>Intrusive test: commanded 4th gear</p> <p>If attained Gear ≠ 4th for time</p> <p>If Above Conditions have been met, Increment 3rd gear fail counter</p> <p>and C1234 fail counter</p>	<p>>= 400 RPM</p> <p>>= Table based Timer, Please See Table 3 in Supporting Documents Enable Time (Sec)</p>			<p>>= 5 Neutral Timer (Sec)</p> <p>>= 2 3rd Gear Fail Count</p> <p>or</p> <p>>= 14 C1234 Clutch Fail Count</p>	
			<p><u>Fail Case 4</u> Case: Steady State 4th Gear</p>					

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Gear slip	>= 400 RPM			Please See Table 5 For Neutral Timer (Sec)	
			Intrusive test: commanded 5th gear					
			If attained Gear = 5th For Time	>= Table based Timer, Please See Table 3 in Supporting Documents	Enable Time (Sec)			
			If Above Conditions have been met, Increment 4th gear fail counter				>= 3 4th Gear Fail Count	
			and C1234 fail counter				>= 14 C1234 Clutch Fail Count	
					PRNDL State defaulted	= FALSE Boolean		
					inhibit RVT	= FALSE Boolean		
					IMS fault pending indication	= FALSE Boolean		
					TPS validity flag	= TRUE Boolean		
					Hydraulic System Pressurized	= TRUE Boolean		
					Minimum output speed for RVT	>= 0 RPM		
					A OR B			
					(A) Output speed enable	>= 650 RPM		
					(B) Accelerator Pedal enable	>= 0.5005 Pct		
					Common Enable Criteria			
					Ignition Voltage Lo	>= 9 Volts		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Ignition Voltage Hi	<= 31.99 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					Throttle Position Signal valid	= TRUE Boolean		
					HSD Enabled	= TRUE Boolean		
					Transmission Fluid Temperature	>= -6.656 °C		
					Input Speed Sensor fault	= FALSE Boolean		
					Output Speed Sensor fault	= FALSE Boolean		
					Default Gear Option is not present	= TRUE		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P2724	Pressure Control (PC) Solenoid E Stuck On (Dynamic)	<p>Primary Offgoing Clutch is exhausted (See Table 10 in Supporting Documents for Exhaust Delay Timers)</p> <p>Primary Oncoming Clutch Pressure Command Status</p> <p>Primary Offgoing Clutch Pressure Command Status</p> <p>Range Shift Status</p> <p>Attained Gear Slip</p> <p>If the above conditions are true increment appropriate Fail 1 Timers Below:</p> <p>fail timer 1 (2-6 shifting with throttle)</p> <p>fail timer 1 (2-6 shifting without throttle)</p> <p>fail timer 1 (3-5 shifting with throttle)</p> <p>fail timer 1 (3-5 shifting without throttle)</p>	<p>= TRUE Boolean</p> <p>= Maximum pressurized</p> <p>= Clutch exhaust command</p> <p>≠ Initial Clutch Control</p> <p><= 40 RPM</p> <p>>= 0.700195313 sec</p> <p>>= 0.900390625 sec</p> <p>>= 0.700195313 sec</p> <p>>= 0.900390625 sec</p>				one trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			fail timer 1 (4-5 shifting with throttle)	>= 0.700195313 sec				
			fail timer 1 (4-5 shifting without throttle)	>= 0.900390625 sec				
			fail timer 1 (4-6 shifting with throttle)	>= 0.700195313 sec				
			fail timer 1 (4-6 shifting without throttle)	>= 0.900390625 sec				
			If Attained Gear Slip is Less than Above Call Increment Fail Timers				Total Fail Time = (Fail 1 + Fail 2) See Enabl e Timer s for >= Fail sec Timer 1, and Refer ence Suppo rting Table 15 for Fail Timer 2	
			If fail timer is greater than threshold increment corresponding gear fail counter and total fail counter					
			2nd gear fail counter				>= 3 Fail Counte r From 2nd Gear	

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			3rd gear fail counter				>= 3	Fail Counter From 3rd Gear
			4th gear fail counter				>= 3	Fail Counter From 4th Gear
			total fail counter				>= 5	Total Fail Counter
					Trans oil temperature	> 255.99 °C		
					Input Speed Sensor fault	= FALSE Boolean		
					Output Speed Sensor fault	= FALSE Boolean		
					Command / Attained Gear	≠ 1st Boolean		
					High Side Driver ON	= TRUE Boolean		
					output speed limit for TUT	>= 200 RPM		
					input speed limit for TUT	>= 200 RPM		
					TUT Enable temperature	>= 0 °C		
					PRNDL state defaulted	= FALSE Boolean		
					IMS Fault Pending	= FALSE Boolean		
					Service Fast Learn Mode	= FALSE Boolean		
					HSD Enabled	= TRUE Boolean		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202, P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P2724	Pressure Control (PC) Solenoid E Stuck On (Steady State)	<u>Fail Case</u> 1 Case: 5th Gear	Max Delta Output Speed Hysteresis >= rpm/sec Min Delta Output Speed Hysteresis >= rpm/sec	Table Based value Please Refer to 3D Table 1 in supporting documents Table Based value Please Refer to 3D Table 2 in supporting documents			one trip

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			<p>If the Above is True for Time</p> <p>Intrusive test: (C35R clutch exhausted)</p> <p>Gear Ratio</p> <p>Gear Ratio</p> <p>If the above parameters are true</p>	<p>Table Based Time Please Refer to Table 17 in supporting documents</p> <p>>= Sec</p> <p><= 1.529052734</p> <p>>= 1.328979492</p>			<p>>= 1.1 Fail Timer (Sec)</p> <p>>= 3 Fail Count in 5th Gear</p> <p>OR</p> <p>>= 3 Total Fail Counts</p>	
			<p><u>Fail Case 2</u> Case: 6th Gear</p> <p>Max Delta Output Speed Hysteresis</p> <p>Min Delta Output Speed Hysteresis</p>	<p>Table Based value Please Refer to 3D Table 1 in supporting documents</p> <p>>= rpm/sec</p> <p>Table Based value Please Refer to 3D Table 2 in supporting documents</p> <p>>= rpm/sec</p>				

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			<p>If the Above is True for Time</p> <p>Intrusive test: (CB26 clutch exhausted)</p> <p>Gear Ratio</p> <p>Gear Ratio</p> <p>If the above parameters are true</p>	<p>Table Based Time Please Refer to Table 17 in supporting documents</p> <p>>= 17 in Sec</p> <p><= 1.529052734</p> <p>>= 1.328979492</p>			<p>>= 1.1 Fail Timer (Sec)</p> <p>>= 3 Fail Count in 6th Gear</p> <p>OR</p> <p>>= 3 Total Fail Counts</p>	
					<p>PRNDL State defaulted = FALSE Boolean</p> <p>inhibit RVT = FALSE Boolean</p> <p>IMS fault pending indication = FALSE Boolean</p> <p>output speed >= 0 RPM</p> <p>TPS validity flag = TRUE Boolean</p> <p>HSD Enabled = TRUE Boolean</p> <p>Hydraulic_System_Pressurized = TRUE Boolean</p> <p>Minimum output speed for RVT >= 0 Nm</p> <p>A OR B</p> <p>(A) Output speed enable >= 650 Nm</p> <p>(B) Accelerator Pedal enable >= 0.5005 Nm</p>			

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.99 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					if Attained Gear=1st FW Accelerator Pedal enable	>= 10.001 Pct		
					if Attained Gear=1st FW Engine Torque Enable	>= 45 Nm		
					if Attained Gear=1st FW Engine Torque Enable	<= 8191.9 Nm		
					Transmission Fluid Temperature	>= -6.656 °C		
					Input Speed Sensor fault	= FALSE Boolean		
					Output Speed Sensor fault	= FALSE Boolean		
					Default Gear Option is not present	= TRUE		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0716, P0717, P0722, P0723, P182E ECM: P0101, P0102, P0103, P0106, P0107, P0108, P0171, P0172, P0174, P0175, P0201, P0202,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P0203, P0204, P0205, P0206, P0207, P0208, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0307, P0308, P0401, P042E		
Variable Bleed Solenoid (VBS)	P2729	Pressure Control (PC) Solenoid E Control Circuit Low (C1234 VBS)	The HWIO reports a low voltage (ground short) error flag	= TRUE Boolean			Fail Time (Sec) Sample out of 0.375 Time (Sec)	one trip
					P2729 Status is not Ignition Voltage >= 9 Volt Ignition Voltage <= 31.99 Volt Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for Disable Conditions: MIL not Illuminated for DTC's:	Test Failed This Key On or Fault Active = TCM: None ECM: None		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
Variable Bleed Solenoid (VBS)	P2730	Pressure Control (PC) Solenoid E Control Circuit High (C1234 VBS)	The HWIO reports a high voltage (open or power short) error flag	= TRUE Boolean			Fail Time (Sec) >= 0.3 Sample out of 0.375 Time (Sec)	one trip
Variable Bleed Solenoid (VBS)	P2763	Torque Converter Clutch Pressure High	The HWIO reports a low pressure/high voltage (open or power short) error flag	= TRUE Boolean			Fail Time (Sec) >= 4.4 Sample out of 5 Time (Sec)	two trips

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					Ignition Voltage <= 31.99 Volt Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec High Side Driver Enabled = TRUE Boolean Disable Conditions: MIL not Illuminated for DTC's:	TCM: P0658, P0659 ECM: None		
Variable Bleed Solenoid (VBS)	P2764	Torque Converter Clutch Pressure Control Solenoid Control Circuit Low	The HWIO reports a high pressure/low voltage (ground short) error flag	= TRUE Boolean			>= 4.4 MPH out of 5 MPH	one trip
					P2764 Status is not = Ignition Voltage >= 9 Volt Ignition Voltage <= 31.99 Volt Engine Speed >= 400 RPM Engine Speed <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec High Side Driver Enabled = TRUE Boolean Disable Conditions: MIL not Illuminated for DTC's:	Test Failed This Key On or Fault Active TCM: P0658, P0659 ECM: None		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
Communication	U0073	Controller Area Network Bus Communication Error	CAN Hardware Circuitry Detects a Low Voltage Error	= TRUE Boolean			>= 62 Fail counts (≈ 10 seconds)	one trip
			Delay timer	>= 0.1125 sec			Out of 70 Sample Counts (≈ 11 seconds)	
					Stabilization delay >= 3 sec Power Mode = Run Ignition Voltage Lo >= 9 Volt Ignition Voltage Hi <= 31.99 Volt Disable Conditions: MIL not Illuminated for DTC's: TCM: None ECM: None			
Communication	U0100	Lost Communications with ECM (Engine Control Module)	CAN messages from ECM are not received by the TCM	= TRUE Boolean			>= 12 sec	one trip
						Stabilization delay >= 3 sec Power Mode = Run Ignition Voltage Lo >= 9 Volt Ignition Voltage Hi <= 31.99 Volt Disable Conditions: MIL not Illuminated for DTC's: TCM: U0073 ECM: None		

Supporting Documents - 2D Tables

Table 1

Axis	0	64	128	192	256	320	384	448	512	Units Nm
Curve	100	120	150	150	150	150	150	150	150	RPM

Table 2

Axis	-6.67188	-6.65625	40	Units °C
Curve	409.5938	2	2	Sec

Table 3

Axis	-6.67188	-6.65625	40	Units °C
Curve	409.5938	3.5	3.5	Sec

Table 4

Axis	-6.67188	-6.65625	40	Units °C
Curve	409.5938	2.99375	2	Sec

Table 5

Axis	-6.67188	-6.65625	40	Units °C
Curve	409.5938	3	3	Sec

Table 6

Axis	-6.65625	-6.65625	40	80	120	Units °C
Curve	409	3.6	1.6	1.4	1.4	Sec

Table 7

Axis	-6.65625	-6.65625	40	80	120	Units °C
Curve	409	3.4	1.4	1.3	1.2	Sec

Supporting Documents - 2D Tables

Table 8

Axis	-6.65625	-6.65625	40	80	120	Units °C
Curve	409	3.6	1.6	1.5	1.4	Sec

Table 9

Axis	-6.65625	-6.65625	40	80	120	Units °C
Curve	409	3.3	1.3	1.2	1.1	Sec

Table 10

Axis	-40	-20	0	30	110	Units °C
Curve	8.849609	3.75	1.30957	0.280273	0.280273	Sec

Table 11

Axis	-40	-20	0	30	110	Units °C
Curve	5	1.700195	0.400391	0.25	0.25	Sec

Table 12

Axis	-40	-20	0	30	110	Units °C
Curve	8	2.200195	0.700195	0.25	0.25	Sec

Table 13

Axis	-40	-20	0	30	110	Units °C
Curve	5.200195	1.599609	0.5	0.269531	0.160156	Sec

Table 14

Axis	-40	-20	0	30	110	Units °C
Curve	5	1.5	0.700195	0.25	0.25	Sec

Supporting Documents - 2D Tables

Table 15

Axis	-40	-30	-20	-10	0	10	20	30	40	Units °C
Curve	0	0	0	0	0	0	0	0	0	Units Sec

Table 16

Axis	-6.67188	-6.65625	40	Units °C
Curve	409.5938	1.5	1.5	Units Sec

Table 17

Axis	-6.67188	-6.65625	40	Units °C
Curve	0.4	0.35	0.3	Units Sec

Table 18

Axis	-40.1016	-40	-20	0	30	60	100	149	149.1016	Units °C
Curve	255.9961	50	45	40	34	25	20	20	255.9961	Units °C

Table 19

Axis	-40.1016	-40	-20	0	30	60	100	149	149.1016	Units °C
Curve	255.9961	50	45	40	34	25	20	20	255.9961	Units °C

Table 20

Axis	-40.1016	-40	-20	0	30	60	100	149	149.1016	Units °C
Curve	255.9961	10	8	8	8	8	8	8	255.9961	Units °C

Supporting Documents - 3D Tables

3D_Table 1

X-Axis Calibration	%
Y-Axis Calibration	°C
Table Calibration	RPM/Sec

	0.00	2.00	5.00	25.00	100.00
-6.67	8191.75	8191.75	8191.75	8191.75	8191.75
-6.66	1125.00	1125.00	850.00	700.00	700.00
40.00	1125.00	1125.00	850.00	700.00	700.00

3D_Table 2

X-Axis Calibration	%
Y-Axis Calibration	°C
Table Calibration	RPM/Sec

	0.00	2.00	5.00	25.00	100.00
-6.67	8191.75	8191.75	8191.75	8191.75	8191.75
-6.66	500.00	500.00	300.00	300.00	300.00
40.00	500.00	500.00	300.00	300.00	300.00

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
Tap Up Tap Down Switch (TUTD)	P0815	Upshift Switch Circuit	<u>Fail Case 1</u> Tap Up Switch Stuck in the Up Position in Range 1 Enabled	= 0 Boolean				Special No Trip
			Tap Up Switch Stuck in the Up Position in Range 2 Enabled	= 0 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 3 Enabled	= 0 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 4 Enabled	= 0 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 5 Enabled	= 0 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 6 Enabled	= 0 Boolean				
			Tap Up Switch Stuck in the Up Position in Neutral Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Park Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Reverse Enabled	= 0 Boolean				
			Tap Up Switch ON	= TRUE Boolean			>= 1 Fail Time (Sec)	
			<u>Fail Case 2</u> Tap Up Switch Stuck in the Up Position in Range 1 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 2 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 3 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 4 Enabled	= 1 Boolean				

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Tap Up Switch Stuck in the Up Position in Range 5 Enabled Tap Up Switch Stuck in the Up Position in Range 6 Enabled Tap Up Switch Stuck in the Up Position in Neutral Enabled Tap Up Switch Stuck in the Up Position in Park Enabled Tap Up Switch Stuck in the Up Position in Reverse Enabled Tap Up Switch ON NOTE: Both Failcase1 and Failcase 2 Must Be Met	= 1 Boolean = 1 Boolean = 0 Boolean = 0 Boolean = 0 Boolean = TRUE Boolean			>= 600 Fail Time (Sec)	
						Time Since Last Range Change >= 1 Enable Time (Sec) Ignition Voltage Lo >= 9 Volts Ignition Voltage Hi <= 31.99 Volts Engine Speed Lo >= 400 RPM Engine Speed Hi <= 7500 RPM Engine Speed is within the allowable limits for >= 5 Sec P0815 Status is ≠ Test Failed This Key On or Fault Active		
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0816, P0826, P182E, P1876, P1877,		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
						P1915, P1761 ECM: None		
Tap Up Tap Down Switch (TUTD)	P0816	Downshift Switch Circuit	<u>Fail Case 1</u> Tap Down Switch Stuck in the Down Position in Range 1 Enabled	= 0 Boolean				Special No Trip
			Tap Down Switch Stuck in the Down Position in Range 2 Enabled	= 0 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 3 Enabled	= 0 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 4 Enabled	= 0 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 5 Enabled	= 0 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 6 Enabled	= 0 Boolean				
			Tap Down Switch Stuck in the Down Position in Range Neutral Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range Park Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range Reverse Enabled	= 0 Boolean				
			Tap Down Switch ON	= TRUE Boolean			>= 1 sec	
			<u>Fail Case 2</u> Tap Down Switch Stuck in the Down Position in Range 1 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 2 Enabled	= 1 Boolean				

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
			Tap Down Switch Stuck in the Down Position in Range 3 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 4 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 5 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Range 6 Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Neutral Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Park Enabled	= 1 Boolean				
			Tap Down Switch Stuck in the Down Position in Reverse Enabled	= 1 Boolean				
			Tap Down Switch ON	= TRUE Boolean				
			NOTE: Both Failcase1 and Failcase 2 Must Be Met				>= 600 sec	
					Time Since Last Range Change	>= 1 Enable Time (Sec)		
					Ignition Voltage Lo	>= 9 Volts		
					Ignition Voltage Hi	<= 31.99 Volts		
					Engine Speed Lo	>= 400 RPM		
					Engine Speed Hi	<= 7500 RPM		
					Engine Speed is within the allowable limits for	>= 5 Sec		
					P0816 Status is	≠ Test Failed This Key On or Fault Active		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
				Disable Conditions:	MIL not Illuminated for DTC's:	TCM: P0815, P0826, P182E, P1876, P1877, P1915, P1761 ECM: None		

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
Tap Up Tap Down Switch (TUTD)	P0815	Upshift Switch Circuit	<u>Fail Case 1</u> Tap Up Switch Stuck in the Up Position in Range 1 Enabled	= 1 Boolean				Special No Trip
			Tap Up Switch Stuck in the Up Position in Range 2 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 3 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 4 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 5 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 6 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Neutral Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Park Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Reverse Enabled	= 1 Boolean				
			Tap Up Switch ON	= TRUE Boolean		>= 1 Fail Time (Sec)		
			<u>Fail Case 2</u> Tap Up Switch Stuck in the Up Position in Range 1 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 2 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 3 Enabled	= 1 Boolean				
			Tap Up Switch Stuck in the Up Position in Range 4 Enabled	= 1 Boolean				

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.	
					Disable Conditions:	MIL not Illuminated for DTC's:			
						TCM: P0816, P0826, P182E, P1876, P1877, P1915, P1761 ECM: None			
Tap Up Tap Down Switch (TUTD)	P0816	Downshift Switch Circuit	<u>Fail Case 1</u> Tap Down Switch Stuck in the Down Position in Range 1 Enabled	= 1 Boolean				>= 1 sec	Special No Trip
			Tap Down Switch Stuck in the Down Position in Range 2 Enabled	= 1 Boolean					
			Tap Down Switch Stuck in the Down Position in Range 3 Enabled	= 1 Boolean					
			Tap Down Switch Stuck in the Down Position in Range 4 Enabled	= 1 Boolean					
			Tap Down Switch Stuck in the Down Position in Range 5 Enabled	= 1 Boolean					
			Tap Down Switch Stuck in the Down Position in Range 6 Enabled	= 1 Boolean					
			Tap Down Switch Stuck in the Down Position in Range Neutral Enabled	= 1 Boolean					
			Tap Down Switch Stuck in the Down Position in Range Park Enabled	= 1 Boolean					
			Tap Down Switch Stuck in the Down Position in Range Reverse Enabled	= 1 Boolean					
			Tap Down Switch ON	= TRUE Boolean					
			<u>Fail Case 2</u> Tap Down Switch Stuck in the Down Position in Range 1 Enabled	= 1 Boolean					

COMPONENT/ SYSTEM	FAULT CODE	MONITOR STRATEGY DESCRIPTION	MALFUNCTION CRITERIA	THRESHOLD VALUE	SECONDARY PARAMETERS	ENABLE CONDITIONS	TIME REQUIRED	MIL ILLUM.
					<p>P0816 Status is</p> <p>MIL not Illuminated for</p>	<p>Test Failed This Key On or Fault Active</p> <p>TCM: P0815, P0826, P182E, P1876, P1877, P1915, P1761</p> <p>ECM: None</p>		