

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
Internal Control Module Memory	P0601	Check Sum Error	Detectin of differences between the result of the checksum calculation executed after IG ON and the correct checksum. If there are differences from the correct checksum value stored in the FLASH ROM, a second calculation is made.		Ignition	OFF->ON (only at Transmission computer initialization function)	2 times	2nd
Lost communication with ECM (Engine)	U0100	Frame missing from ECM	No CAN status frame from ECM detected		Diagnostic Service "Disable Normal Communication" not detected  Engine speed  Ignition DS_Active_CAN <sup>2</sup>	> 400 rpm once within the driving cycle ON >3 sec TRUE	4 sec Continuous	2nd
CAN Bus Off Counter Overrun	U0001	CAN controller continuity check	Receiving "BUS OFF" state from CAN controller		Ignition DS_Active_CAN <sup>2</sup>	ON >3 sec TRUE	8 times	2nd
Invalid data from ECM	P1895	Engine Torque signal is indicated invalid	TCM receives Engine Torque Actual Validity	"Invalid"	Diagnostic Service "Disable Normal Communication" not detected  Emergency mode Ignition DS_Active_CAN <sup>2</sup>  No DTC set	FALSE ON >3 sec TRUE  U0100	4 sec Continuous	2nd
Solenoid S1	P0985	Circuit continuity check	Short-cut ground  Detected signal of the S1 monitor when S1 driver outputs the "ON" signal (12V)	"OFF" signal (0V)	DS_Active <sup>3</sup>  Time after solenoid output changed  Emergency mode	TRUE  >10 ms  FALSE	500 msec  Continuous	2nd
	P0986		Not connected or short-cut Ubatt  Detected signal of the S1 monitor when S1 driver outputs the "OFF" signal (0V)	"ON" signal (12V)				

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
Solenoid S2	P0973	Circuit continuity check	Short-cut ground  Detected signal of the S2 monitor when S2 driver outputs the "ON" signal (12V)	"OFF" signal (0V)	DS_Active <sup>3</sup>  Time after solenoid output  Emergency mode	TRUE  >10 ms  FALSE	500 msec  Continuous	2nd
	P0974		Not connected or short-cut Ubatt  Detected signal of the S2 monitor when S2 driver outputs the "OFF" signal (0V)	"ON" signal (12V)				
Torque Converter Clutch	P0741	Comparison of engine speed and transmission input speed	Converter is slipping with active lock-up on.  (Engine Speed - Transmission Input Speed)	> 100rpm	DS_Active <sup>3</sup>  Fdetect_inh <sup>4</sup> Shift position Time after N-D shifting control <sup>9</sup> ends Engine Torque  Engine Speed Time after SLU target current (_ir) >= 1000 mA abs( 1- SpeedABS / Transmission Output Speed calculated from Transmission Input Speed)  Time after shifting control <sup>9</sup> ends Oil temperature Lock-up  No DTC set	TRUE  FALSE RANGE_D(defined) 8 sec  >= 0 Nm  < 4000 rpm 3sec  < 10 %  0.5 sec  >= 20°C FALSE  P2759 P0716 P0717 P0721 P0722	12 sec  Continuous	2nd
	P0742		Abs(EngineSpeed - Transmission Input Speed)	< 30 rpm for 2.0 sec continuously	DS_Active <sup>3</sup> Fdetect_inh <sup>4</sup> Shift position Time after N-D shifting	TRUE FALSE RANGE_D (defined) 1.0 sec	4sec	

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
					control <sup>9</sup> end Time after changing to Shift position = RANGE_D(defined) Time after shifting control <sup>9</sup> ends EngineTorque_noACC <sup>8</sup> Engine Speed  abs( 1- SpeedABS / Transmission Output Speed calculated from Transmission Input Speed)  Oil temperature Time after SLU pressure = 0 kPa  No DTC set	8.0 sec  0.5 sec  >= 60Nm >1000 rpm < 3000 rpm <10 %  >= 20 °C  3sec  P2759 P0716 P0717 P0721 P0722		
Pressure solenoid SLU	P2764	Circuit continuity check	Short-cut ground or open  Current (AD	<23 mA <15)	DS_Active <sup>3</sup>  Emergency mode  No DTC set	TRUE  FALSE  P2763 for 1 sec and over	500 ms  Continuous	2nd
	P2762		Terminal short Error current	> 80 mA	No Shifting Control <sup>9</sup> Emergency mode Oil temperature System voltage change System voltage SLU Output current target  DS_Active <sup>3</sup>  No DTC set	FALSE > 20°C < 0,2V 11 -18 V > 835mA and constant. TRUE  P0711 P0712  P0713	2,75 sec Continuous	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
	P2763		Short-cut Ubatt (+B) Measured Current (AD	> 1,333 mA > 1000)	DS_Active <sup>3</sup> Emergency mode  No DTC set	TRUE FALSE  P2764 for 1 sec and over	500 ms Continuous	2nd
	P2759		Feed Back Current sum_ie "ie" is added to "sum_ie" every 10 msec. "ie" : Difference of "ir" and "ifb". "ir" : Target current "ifb": Feedback current "sum_ie" is cleared as follows: (1) or (2) or (3) (1): Detection window = FALSE (2): -50 mA <= ie <= 50 mA (3): ie value cahnges from "ie < 0mA" ("ie >0mA") to "ie >0mA" ("ie < 0mA").	>20000	IG voltage Input AD value Emergency mode DS_Active <sup>3</sup>  No DTC set	> 10.5 V < 1000(1333mA) FALSE TRUE  P2763 P2764	1 sec	2nd
Pressure solenoid SLT	P0962	Circuit continuity check	Short-cut ground or open Current (AD	<23 mA <15)	DS_Active <sup>3</sup> Emergency mode  No DTC set	TRUE FALSE  P0963 for 1 sec and over	500 ms Continuous	2nd
	P0961		Terminal short Error current	> 80 mA	No Shifting Control <sup>9</sup> Emergency mode Oil temperature System voltage change System voltage SLT Output current target  DS_Active <sup>3</sup>  No DTC set	FALSE > 20°C < 0,2V 11 -18 V > 835mA and constant. TRUE  P0711 P0712 P0713	2.75 sec Continuous	2nd
	P0963		Short-cut Ubatt (+B) Measured Current (AD	> 1,333 mA > 1000)	DS_Active <sup>3</sup> Emergency mode  No DTC set	TRUE FALSE  P0962 for 1 sec and over	500 ms Continuous	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
	P0748		Feed Back Current sum_ie <b>"ie" is added to "sum_ie" every 10 msec.</b> "ie" : Difference of "ir" and "ifb". "ir" : Target current "ifb": Feedback current "sum_ie" is cleared as follows: (1) or (2) or (3) (1): Detection window = FALSE (2): -50 mA <= ie <= 50 mA (3): ie value cahnges from "ie < 0mA" ("ie >0mA") to "ie >0mA" ("ie < 0mA").	>20000	IG voltage Input AD value Emergency mode DS_Active <sup>3</sup>  No DTC set	> 10.5 V < 1000(1333mA) FALSE TRUE  P0962 P0963	1 sec	2nd
Timing solenoid SLC1	P0966	Circuit continuity check	Short-cut ground or open  Current (AD	<23 mA <15)	DS_Active <sup>3</sup> Emergency mode  No DTC set	TRUE FALSE  P0967 for 1 sec and over	500 msec Continuous	2nd
	P0965		Terminal short Error current	> 80 mA	No Shifting Control <sup>9</sup> Emergency mode Oil temperature System voltage change System voltage SLC1 Output current target  DS_Active <sup>3</sup>  No DTC set	FALSE > 20°C < 0,2V 11 -18 V > 835mA and constant. TRUE  P0711 P0712 P0713	2.75 sec Continuous	2nd
	P0967		Short-cut Ubatt (+B)  Measured Current (AD	> 1,333 mA > 1000)	DS_Active <sup>3</sup> Emergency mode  No DTC set	TRUE FALSE  P0966 for 1 sec and over	500 msec Continuous	2nd
	P0778		Feed Back Current sum_ie <b>"ie" is added to "sum_ie" every 10 msec.</b> "ie" : Difference of "ir" and "ifb". "ir" : Target current "ifb": Feedback current	>20000	IG voltage input AD value Emergency mode DS_Active <sup>3</sup>  No DTC set	> 10.5 V < 1000(1333mA) FALSE TRUE  P0966	1 sec	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
			"sum_ie" is cleared as follows: (1) or (2) or (3) (1): Detection window = FALSE (2): -50 mA <= ie <= 50 mA (3): ie value cahnges from "ie < 0mA" ("ie >0mA") to "ie >0mA" ("ie < 0mA").			P0967		
Timing solenoid SLC2	P0970	Circuit continuity check	Short-cut ground or open Current (AD	<23 mA <15)	DS_Active <sup>3</sup> Emergency mode  No DTC set	TRUE FALSE  P0971 for 1 sec and over	500 msec Continuous	2nd
	P0969		Terminal short Error current	> 80 mA	No Shifting Control <sup>9</sup> Emergency mode Oil temperature System voltage change System voltage SLC2 Output current target  DS_Active <sup>3</sup>  No DTC set	FALSE > 20°C < 0,2V 11 -18 V > 835mA and constant. TRUE  P0711 P0712 P0713	2.75 sec Continuous	2nd
	P0971		Short-cut Ubatt (+B)  Measured Current (AD	> 1,333 mA > 1000)	DS_Active <sup>3</sup> Emergency mode  No DTC set	TRUE FALSE  P0970 for 1 sec and over	500 msec Continuous	2nd
	P0798		Feed Back Current sum_ie  <b>"ie" is added to "sum_ie" every 10 msec.</b> "ie" : Difference of "ir" and "ifb". "ir" : Target current "ifb": Feedback current "sum_ie" is cleared as follows: (1) or (2) or (3) (1): Detection window = FALSE (2): -50 mA <= ie <= 50 mA (3): ie value cahnges from "ie < 0mA" ("ie >0mA") to "ie >0mA" ("ie < 0mA").	>20000	IG voltage Input AD value Emergency mode DS_Active <sup>3</sup>  No DTC set	> 10.5 V < 1000(1333mA) FALSE TRUE  P0970 P0971	1 sec	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
Timing solenoid SLC3	P2720	Circuit continuity check	Short-cut ground or open  Current (AD	<23 mA <15)	DS_Active <sup>3</sup>  Emergency mode  No DTC set	TRUE  FALSE  P2721 for 1 sec and over	500 msec  Continuous	2nd
	P2719		Terminal short Error current	> 80 mA	No Shifting Control <sup>9</sup> Emergency mode Oil temperature System voltage change System voltage SLC3 Output current target  DS_Active <sup>3</sup>  No DTC set	FALSE > 20°C < 0,2V 11 -18 V > 835mA and constant.  TRUE  P0711 P0712 P0713	2.75 sec Continuous	2nd
	P2721		Short-cut Ubatt (+B)  Measured Current (AD	> 1,333 mA > 1000)	DS_Active <sup>3</sup> Emergency mode  No DTC set	TRUE FALSE  P2720 for 1 sec and over	500 msec Continuous	2nd
	P2716		Feed Back Current sum_ie <b>"ie" is added to "sum_ie" every 10 msec.</b> "ie" : Difference of "ir" and "ifb". "ir" : Target current "ifb": Feedback current "sum_ie" is cleared as follows: (1) or (2) or (3) (1): Detection window = FALSE (2): -50 mA <= ie <= 50 mA (3): ie value cahnges from "ie < 0mA" ("ie >0mA") to "ie >0mA" ("ie < 0mA").	>20000	IG voltage Input AD value Emergency mode DS_Active <sup>3</sup>  No DTC set	> 10.5 V < 1000(1333mA) FALSE TRUE  P2720 P2721	1 sec	2nd
Timing solenoid SLB1	P2729	Circuit continuity check	Short-cut ground or open  Current (AD	<23 mA <15)	DS_Active <sup>3</sup> Emergency mode  No DTC set	TRUE FALSE  P2730 for 1 sec and over	500 msec Continuous	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
	P2728		Terminal short Error current	> 80 mA	No Shifting Control <sup>9</sup> Emergency mode Oil temperature System voltage change System voltage SLB1 Output current target  DS_Active <sup>3</sup>  No DTC set	FALSE > 20°C < 0,2V 11 -18 V > 835mA and constant.  TRUE  P0711 P0712 P0713	2.75 sec Continuous	2nd
	P2730		Short-cut Ubatt (+B) Measured Current (AD	> 1,333 mA > 1000)	DS_Active <sup>3</sup> Emergency mode  No DTC set	TRUE FALSE  P2729 for 1 sec and over	500 msec Continuous	2nd
	P2725		Feed Back Current sum_ie  "ie" is added to "sum_ie" every 10 msec. "ie" : Difference of "ir" and "ifb". "ir" : Target current "ifb": Feedback current "sum_ie" is cleared as follows: (1) or (2) or (3) (1): Detection window = FALSE (2): -50 mA <= ie <= 50 mA (3): ie value cahnges from "ie < 0mA" ("ie >0mA") to "ie >0mA" ("ie < 0mA").	>20000	IG voltage Input AD value Emergency mode DS_Active <sup>3</sup>  No DTC set	> 10.5 V < 1000(1333mA) FALSE TRUE  P2729 P2730	1 sec	2nd
Gear error, hydraulic fault	P0729	Rationality	Calculation of actual gear ratio for 6th gear is not correct. (Condition A or Condition B)  <b>Condition A</b> abs(1- GRCurrent/GRExpected)  <b>Condition B</b>  abs(1-Gear Ratio Current/ 4th Gear Ratio)	> 20%          <4%	No Shifting Control <sup>9</sup> Not in neutral control <sup>10</sup>  Not garage shifting control <sup>11</sup> (N-D or N-R) Throttle (A only)  Transmission Output Speed (A)  Transmission Output Speed (B)	   => 10%  => 500rpm  =>250rpm	12 sec Continuous	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
			<p>or</p> <p>abs(1-Gear Ratio Current/ 5th Gear Ratio)</p>	<4%	<p>Current gear</p> <p>Engine Torque_noACC<sup>8</sup> (B only)</p> <p>DS_Active<sup>3</sup></p> <p>Fdetect_Inh<sup>4</sup></p> <p>Shift position</p> <p>Time after changing to Shift position = RANGE_D(defined)</p> <p>Time after garage shift control<sup>11</sup> end</p> <p>Time after neutral control<sup>10</sup> end</p> <p>Time after shifting control<sup>9</sup> end</p> <p>Oil temperature</p> <p>Brake</p> <p>abs(1-SpeedABS/Trans. Output Speed)</p> <p>QS_AirSuction<sup>5</sup></p> <p>No DTC set</p>	<p>6</p> <p>&gt;=80Nm</p> <p>TRUE</p> <p>FALSE</p> <p>RANGE_D(defined)</p> <p>8.0 sec</p> <p>1.0 sec</p> <p>1.0 sec</p> <p>0.5 sec</p> <p>&gt;= 20°C</p> <p>OFF</p> <p>&lt; 10%</p> <p>FALSE</p> <p>P0703</p> <p>P0716</p> <p>P0717</p> <p>P0721</p> <p>P0722</p>		
	P0731	Rationality	<p>Calculation of actual gear ratio for 1st gear is not correct.</p> <p>abs( 1 - GRCurrent/ 2nd GearRatio)</p> <p>or</p> <p>abs(1 - GRCurrent/ 3rd GearRatio)</p> <p>or</p>	<p>&lt; 4%</p> <p>&lt; 4%</p>	<p>Not garage shifting control<sup>11</sup>(N-D or N-R)</p> <p>Not in neutral control<sup>10</sup></p> <p>No Shifting Control<sup>9</sup></p> <p>Current Gear</p> <p>Transmission Output Speed</p> <p>EngineTorque_noACC<sup>8</sup></p> <p>EngineTorque_noACC<sup>8</sup></p>	<p>GEAR_1ST or GEAR_1STEB</p> <p>1350 rpm &gt;= outRpm &gt;= 250 rpm</p> <p>&gt;=100Nm (GEAR_1ST)</p> <p>&gt;= 80 Nm (GEAR_1STEB)</p>	<p>12 sec</p> <p>Continuous</p>	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
			abs(1 - GRCurrent/ 4th	< 4%	DS_Active <sup>3</sup> Fdetect_Inh <sup>4</sup> Shift position Time after changing to Shift position = RANGE_D(defined)  Time after garage shift control <sup>11</sup> end Time after neutral control <sup>10</sup> end Time after shifting control <sup>9</sup> end  Oil temperature Brake abs(1- SpeedABS/Trans.Output Speed)  QS_AirSuction <sup>5</sup>  No DTC set	TRUE FALSE RANGE_D(defined) 8.0 sec  1.0 sec 1.0 sec 0.5 sec  >= 20°C OFF < 10%  FALSE  P0703 P0716 P0717 P0721 P0722		
	P0732	Rationality	Calculation of actual gear ratio for 2nd gear is not correct. (Condition A or Condition B)  <b>Condition A</b> abs(1- GRCurrent/GRExpected)  <b>Condition B</b>  abs(1-Gear Ratio Current/ 1st Gear Ratio)  <b>or</b> abs(1-Gear Ratio Current/ 3rd Gear Ratio)  <b>or</b>	>20%  <4%  <4%	No Shifting Control <sup>9</sup> Not in neutral control <sup>10</sup>  Not garage shifting control <sup>11</sup> (N-D or N-R) Throttle (A only)  Transmission Output Speed (A)  Transmission Output Speed (B)  Current gear Engine Torque_noACC <sup>8</sup> (B only)  DS_Active <sup>3</sup>	>= 10%  >= 500rpm  >=250rpm 2 >=80Nm  TRUE	12 sec  Continuous	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
			abs(1-Gear Ratio Current/ 4th Gear Ratio)  <b>or</b> abs(1-Gear Ratio Current/ 6th Gear Ratio)	<4%  <4%	Fdetect_Inh <sup>4</sup>  Shift position  Time after changing to Shift position = RANGE_D(defined)  Time after garage shift control <sup>11</sup> end  Time after neutral control <sup>10</sup> end  Time after shifting control <sup>9</sup> end  Oil temperature Brake abs(1-SpeedABS/Trans. Output Speed)  QS_AirSuction <sup>5</sup>  No DTC set	FALSE  RANGE_D(defined)  8.0 sec  1.0 sec  1.0 sec  0.5 sec  >= 20°C OFF < 10%  FALSE  P0703 P0716 P0717 P0721 P0722		
	P0733	Rationality	Calculation of actual gear ratio for 3rd gear is not correct. (Condition A or Condition B)  <b>Condition A</b> abs(1- <b>Condition B</b>  abs(1-Gear Ratio Current/ 1st Gear Ratio)  <b>or</b> abs(1-Gear Ratio Current/ 4th Gear Ratio)  <b>or</b> abs(1-Gear Ratio Current/ 5th Gear Ratio)	>20%  <4%  <4%  <4%	No Shifting Control <sup>9</sup> Not in neutral control <sup>10</sup>  Not garage shifting control <sup>11</sup> (N-D or N-R)  Throttle (A only) Transmission Output Speed (A)  Transmission Output Speed (B)  Current gear Engine Torque_noACC <sup>8</sup> (B only)  DS_Active <sup>3</sup> Fdetect_Inh <sup>4</sup>	>= 10% >= 500rpm    >=250rpm 3 >=80Nm  TRUE FALSE	12 sec Continuous	2nd





## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
					Time after shifting control <sup>9</sup> end Oil temperature Brake abs(1-SpeedABS/Trans. Output Speed) QS_AirSuction <sup>5</sup>  No DTC set	0.5 sec >= 20°C OFF < 10% FALSE  P0703 P0716 P0717 P0721 P0722		
Engine speed signal	P0725	Signal from ECM stated as unreliable	Engine Speed Validity	"Invalid"	Diagnostic Service "Disable Normal Communication" not detected  Ignition DS_Active_CAN <sup>2</sup> Emergency mode  No DTC set	ON >3 sec TRUE FALSE  U0100	4 sec  Continuous	2nd
Transmission Range Sensor Circuit	P0707	Voltage low	POS1 Voltage or POS2 Voltage	< 0.127 (AD value=26) V	Battery voltage  Diagnosis Service mode	6.0 V < Battery Voltage < 18 V  FALSE	200ms	2nd
	P0708	Voltage high	Input POS1 Voltage or Input POS2 Voltage	> 4.87 (AD value=997)V	Diagnosis Service mode  Battery voltage	FALSE  6.0 V < Battery Voltage < 18 V	200 ms  Continuous	2nd
	P0706	Signal out of range	Input POS1 Voltage + Input POS2 Voltage	<= 5V -0.29V or >= 5V +0.29V	Diagnosis Service mode  Battery voltage	FALSE  6.0 V < Battery Voltage < 18 V	200 ms  Continuous	2nd
Output speed sensor circuit	P0722		No pulse  Number of pulses from Transmission Output Speed Sensor	0	Not in neutral control <sup>10</sup> No Shifting Control <sup>9</sup> Not garage shifting control <sup>11</sup> (N-D)		Dependent of Speed	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
			Number of pulses from Transmission Input Speed Sensor	16	DS_Active <sup>3</sup> Emergency mode Shift position  Time since change from P,R or N range to others if vehicle speed >= 66km/h and oil temperature >20°C  Time since change from P,R or N range to others if vehicle speed < 66km/h and oil temperature <= 20°C  SpeedABS  No DTC set	TRUE FALSE RANGE_D(defined)  2.5sec  10sec > 300 rpm  P0501 P0706 P0707 P0708 P0716 P0717 P0748 P0778 P0798 P0961 P0962 P0963 P0965 P0966 P0967 P0969 P0970 P0971 P0973 P0974 P0985 P0986 P1895 P2159 P2716 P2719 P2720		

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
						P2721 P2725 P2728 P2729 P2730 U0001 U0121		
	P0721		Range/Performance, wrong pulse   1-SpeedABS/Transmission Output Speed	> 15 %	Not garage shifting control <sup>11</sup> (N-D)  No Shifting Control <sup>9</sup> CurrentGear   1-SpeedABS/ Trans. Output Speed   Time after shifting control Time after changing to Position Shift position Engine speed Speed ABS  Spinning <sup>6</sup> DS_Active <sup>3</sup> Emergency mode  No DTC set	>= 2ND  < 5% 8 sec 8 sec RANGE_D(defined) > 400rpm >= 30 km/h  FALSE TRUE FALSE  P0501 P0706 P0707 P0708 P0711 P0712 P0713 P0725 P0741 P0742 P0748 P0778 P0798 P0961 P0962 P0963 P0965 P0966 P0967	10 sec	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
						P0969 P0970 P0971 P0973 P0974 P0985 P0986 P1820 P1895 P2159 P2716 P2719 P2720 P2721 P2725 P2728 P2729 P2730 P2759 P2762 P2763 P2764 U0001 U0121		
Transmission input speed sensor	P0717		No pulse  No of pulses from Transmission Input Speed Sensor No of pulses from Transmission Output Speed Sensor	0  24	No Shifting Control <sup>9</sup> Not garage shifting control <sup>11</sup> (N-D)  DS_Active <sup>3</sup> Emergency mode Trans. Output Speed * CurrentGearRatio  Shift position CurrentGear Time since change from P,R or N range to others if vehicle speed >= 66km/h and oil temperature >20°C	TRUE FALSE > 600 rpm  RANGE_D(defined) >= 2nd gear  2.5sec	Dependent of Speed	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
					Time since change from P,R or N range to others if vehicle speed < 66km/h and oil temperature <= 20°C  No DTC set	10sec P0501 P0706 P0707 P0708 P0721 P0722 P0748 P0778 P0798 P0961 P0962 P0963 P0965 P0966 P0967 P0969 P0970 P0971 P0973 P0974 P0985 P0986 P1895 P2159 P2716 P2719 P2720 P2721 P2725 P2728 P2729 P2730 U0001 U0121		

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
	P0716		Wrong Pulse   1-speedABS/Transmission Input Speed	> 15 %	No Shifting Control <sup>9</sup> Not garage shifting control <sup>11</sup> (N-D)   1-SpeedABS/Trans. Output Speed     1-SpeedABS/Engine Speed   Time after shifting control Time after changing to Position switch = RANGE_D  Gear  Range Engine speed Spinning <sup>6</sup> DS_Active <sup>3</sup> LockUpActive Emergency mode Speed ABS  No DTC set	< 5 % < 5 % 8 sec 8 sec  >= 2ND other than P and N and R > 400rpm FALSE TRUE TRUE FALSE > 30 km/h  U0001 P0501 P0706 P0707 P0708 P0711 P0712 P0713 P0721 P0722 P0725 P0741 P0742 P0748 P0778 P0798 P0961 P0962 P0963 P0965 P0966	10 sec	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
						P0967 P0969 P0970 P0971 P0973 P0974 P0985 P0986 P1820 P1895 P2159 P2716 P2719 P2720 P2721 P2725 P2728 P2729 P2730 P2759 P2762 P2763 P2764 U0121		
Transmission oil temperature sensor	P0711	Rationality	Oil temperature change less than	10 (AD value)	Oil temp DS_Active <sup>3</sup> AD value of oil temperature AD value of oil temperature Emergency mode Range Vehicle Speed  No DTC set	< 20°C TRUE > 10 < 1000 FALSE ≠ (P, R or N) > 40km/h once  P0706 P0707 P0708	10 min	2nd
	P0712	Circuit continuity check	Short-cut ground  AD value of Oil Temp	< 10 (More than 200 °C).	DS_Active <sup>3</sup>	TRUE	300sec	2nd
	P0713	Circuit continuity check	Short-cut Ubat or open circuit  AD value of Oil temperature	> 1000 ( -43 °C)	DS_Active <sup>3</sup>  DriveTime	TRUE  > 10 min	12 sec	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
Invalid signal from ECM	P1820	Accelerator pedal position signal is invalid	Accelerator Position Validity	"Invalid"	Diagnostic Service "Disable Normal Communication" not detected  Ignition DS_Active_CAN <sup>2</sup> Emergency mode  No DTC set	ON > 3sec TRUE FALSE  U0100	4 sec	2nd
Neutral condition	P1701		<b>Step 1:</b> abs(Engine Speed - Transmission Input Speed) Transmission Input Speed (at D range)  Transmission Input Speed (at R range)  <b>Step 2:</b> Transmission Input Speed Engine Speed	<150rpm  > Transmission Output Speed x (1st gear ratio at RANGE_D) +400rpm  > Transmission Output Speed x (reverse gear ratio at RANGE_R) +1000rpm  <200rpm >600rpm	Not garage shifting control <sup>11</sup> (N-D or N-R) Not in neutral control <sup>10</sup>  No Shifting Control <sup>9</sup> DS_Active <sup>3</sup>  Fdetect_Inh <sup>4</sup>  Oil temperature Shift position  Time after changing to shift position = RANGE_D or R(defined) Time after garage shifting end Time after neutral control end Time after shifting control end  Transmission Output Speed SpeedABS Lockup Current gear QS_AirSuction <sup>5</sup>  No DTC set	TRUE  FALSE (except P0966)  >0°C RANGE_D or RANGE_R (defined) 1.0sec  1.0sec 1.0sec 0.5sec  <=500rpm <=500rpm FALSE 1 or 2 or 3 or 4 FALSE  P0716 P0717 P0721 P0722	<b>Step1:</b>  at D range: 3.3 sec if (0 <= X <= 1500)  1.3 sec if (1501 <= X <= 3000) 0.8 sec if (3001 <= X)  at R range: 1.8 sec if (0 <= Y <= 1500) 1.3 sec if (1501 <= Y <= 3000) 0.8 sec if (3001 <= Y)  X = inRpm - outRpm X (1st gear ratio at RANGE_D)	2nd

## 12 OBDG03 Transmission Diagnostics

Component/ System	Fault Code	Monitor Strategy Description	Malfunction Criteria	Threshold Value	Secondary Parameters	Enable Conditions	Required	MIL Illumin.
							Y = inRpm - outRpm X (reverse gear ratio at RANGE_R)  <b>Step 2:</b> 0.1sec	
Neutral control	P1704		C1 apply control Transmission Input Speed  C1 pressure	>= (Transmission Input Speed at apply start + 400rpm + Transmission Output Speed x gear ratio)  >=3.0kg/cm <sup>2</sup>	DS_Active <sup>3</sup> Shift position  Fdetect_Inh <sup>4</sup> Oil temperature QS_AirSuction <sup>5</sup>  No DTC set	TRUE  RANGE_D(defined)  FALSE >=10°C FALSE  P0716 P0717 P0721 P0722	0.3sec	2nd

<sup>1)</sup> Q\_NORMAL  
Q\_NORMAL means that no failure is detected

<sup>2)</sup> DS\_Active\_CAN  
DS\_Active\_CAN = TRUE when the start condition for CAN failure detection is fulfilled for 2.0 sec continuously.  
DS\_Active\_CAN = FALSE when the permission condition for CAN failure detection is not fulfilled.

**Start Condition for CAN failure detection:**

Ignition ON and  
10.2V < Battery Voltage < 18V and  
Not in service mode and  
Reading EEPROM finish

**Permission condition for CAN failure detection:**

Ignition ON and  
9.0V < Battery Voltage < 18V and  
Not in service mode

## 12 OBDG03 Transmission Diagnostics

### 3) DS\_Active

DS\_Active = TRUE when the start condition for failure detection is fulfilled for 2.0 sec continuously.

DS\_Active = FALSE when the permission condition for failure detection is not fulfilled.

#### **Start Condition for failure detection:**

Ignition ON and  
10.2V < Battery Voltage < 18V and  
Not in service mode and  
Reading EEPROM finish and  
Egrpm > 400rpm and Egrpm = Q\_NORMAL<sup>1</sup>

#### **Permission condition for failure detection:**

Ignition ON and  
9.0V < Battery Voltage < 18V and  
Not in service mode and  
Egrpm > 400rpm and Egrpm = Q\_NORMAL<sup>1</sup>

### 4) Fdetech\_Inh = TRUE if:

In Emergency mode **or**

spinning<sup>6</sup> = TRUE **or**

within 10.0 sec after spinning detection end **or**

DTC set: P0973, P0974, P0985, P0986, P0966, P0967, P0970, P0971, P2720, P2721, 2729, 2730,  
P0962, P0963, P2763, P0716, P0717, P0721, P0722, P0706, P0707, P0708, P0562, P0563, U0001,

### 5) QS\_AirSuction : Quick stop detection flag for the prevention of failure misdetection for Air suction, is set if the vehicle brakes hard.

### 6) Spinning

Spinning = 1 if Transversal acceleration > 0.7G (input from ABS signal)

Spinning = 0 if Transversal acceleration parameter < 0.7G for 2sec. Continuously. (input from ABS signal)

### 7) Wheel spin condition

(1) 300 rpm < outRpm < 3000rpm

(2) Egtorque\_noACC > 0Nm

(3) ABS (vehicle front wheels average speed - vehicle rear wheels average speed) > 5.0 km/h

(4) Throttle > 70 %

(5) outRpmSpeed < -20 rpm/sec

{{(1)and(2)and(3)}or{ (1)and(4)and(5)}}continuously detected for 300 msec

After that, Wheel spin condition = TRUE continuously 10000 msec

### 8) EngineTorque\_noACC

Engine output torque, acceleration inertia torque not included.

## 12 OBDG03 Transmission Diagnostics

9) Shifting Control

"Shifting Control" is activated when the transmission is in between two gears (undefined gear ratio), until applied pressure has reached to full

10) "Neutral Control"

Neutral Control is activated if the vehicle is at stand still and in range D with the brake pressed for 2 seconds until the brake is released.

11) "Garage Shifting"

"Garage Shifting Control" is activated when the range selector changes from N to D or R until appropriate Gear Ratio is detected.